

UNCLASSIFIED

AD NUMBER

AD834728

LIMITATION CHANGES

TO:

Approved for public release; distribution is unlimited.

FROM:

Distribution authorized to U.S. Gov't. agencies and their contractors; Critical Technology; APR 1968. Other requests shall be referred to Air Force Weapons Laboratory, WLRT, Kirtland AFB, NM 87117. This document contains export-controlled technical data.

AUTHORITY

afwl ltr, 30 nov 1971

THIS PAGE IS UNCLASSIFIED

AFWL-TR-67-131, VOL IV

AFWL-TR-
67-131,
VOL IV



NUCLEAR EXPLOSION INTERACTION STUDIES

Volume IV

Material Property Codes


J. R. Triplett et al.
Gulf General Atomic Incorporated
San Diego, California 92112
Contract No. F29601-67-C-0014

TECHNICAL REPORT NO. AFWL-TR-67-131, VOL IV

April 1968

AIR FORCE WEAPONS LABORATORY
Air Force Systems Command
Kirtland Air Force Base
New Mexico

This document is subject to special export controls and each transmittal to foreign governments or foreign nationals may be made only with prior approval of AFWL (WLRT) , Kirtland AFB, NM, 87117.



545

ACCESSION FOR	
CFSTI	WHITE SECTION <input type="checkbox"/>
DDC	BUFF SECTION <input checked="" type="checkbox"/>
UNANNOUNCED	<input type="checkbox"/>
JUSTIFICATION	
BY	
DISTRIBUTION/AVAILABILITY CODES	
DIST.	AVAIL. AND/OR SPECIAL
2	

AIR FORCE WEAPONS LABORATORY
Air Force Systems Command
Kirtland Air Force Base
New Mexico

When U. S. Government drawings, specifications, or other data are used for any purpose other than a definitely related Government procurement operation, the Government thereby incurs no responsibility nor any obligation whatsoever, and the fact that the Government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data, is not to be regarded by implication or otherwise, as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use, or sell any patented invention that may in any way be related thereto.

This report is made available for study with the understanding that proprietary interests in and relating thereto will not be impaired. In case of apparent conflict or any other questions between the Government's rights and those of others, notify the Judge Advocate, Air Force Systems Command, Andrews Air Force Base, Washington, D. C. 20331.

DO NOT RETURN THIS COPY. RETAIN OR DESTROY.

BLANK PAGE

NUCLEAR EXPLOSION INTERACTION STUDIES

Volume IV

Material Property Codes

J. R. Triplett et al.
Gulf General Atomic Incorporated
San Diego, California 92112
Contract No. F29601-67-C-0014

TECHNICAL REPORT NO. AFWL-TR-67-131, Vol IV

This document is subject to special export controls and each transmittal to foreign governments or foreign nationals may be made only with prior approval of AFWL (WLRT), Kirtland AFB, NM, 87117. Distribution is limited because of the technology discussed in the report.

FOREWORD

This report was prepared by Gulf General Atomic Incorporated, San Diego, California, under Contract F29601-67-C-0014. The research was funded by DASA under Project 5710, Subtask 07.017, Program Element 6.16.46.01H, and by ARPA Order 313, Program Element 6.25.03.01R.

Inclusive dates of research were 29 September 1966 to 27 October 1967. The report was submitted 13 March 1968 by the Air Force Weapons Laboratory Project Officer, Major John Bode (WLRT).

This report is published in four volumes: Volume I, Laser Phenomenology (classified CONFIDENTIAL); Volume II, Two-Dimensional Code Development; Volume III, The OUTPUT Code; and Volume IV, Material Property Codes. The first volume contains a classified report on interaction of laser radiation with solid targets and a brief description of calculations done in conjunction with experiments at the Air Force Weapons Laboratory. The remaining three volumes contain reports of code development efforts in the areas of radiative transfer, hydrodynamics, radiative absorption coefficients, and equations of state.

The projects described in this report are for the most part in an incomplete state of development. This is due in part to the nature of the existing computer programs themselves, which continue in a state of development as long as they are in use, and in part to the time scale involved in bringing new programs to a state of capability for solving real problems.


Gulf General Atomic staff personnel responsible for the direction of the research include J. H. Alexander, R. Brightman, R. S. Englemore, B. E. Freeman, W. B. Lindley, L. Norris, J. T. Palmer, L. M. Schalit, J. R. Triplett, and Mrs. Chris Imes. Contractor's report number is GA-7764, Vol IV.

The cooperation of Dr. P. V. Avizonis, Major J. Bode, Capt C. C. David, Major G. Spillman, and Lt L. Stoessel of AFWL is gratefully acknowledged.

Other documents produced under this contract are: GAMD-7592, "A Numerical Scheme for First-Order Compton Scattering," J. T. Palmer, December 13, 1966; GAMD-7846, "Difference Equations for Heat Flow in Two Dimensions," J. R. Triplett, March 2, 1967; GAMD-7879, "A Modified Characteristic Method for Radiative Transfer," J. R. Triplett, March 17, 1967; GAMD-7889, "R D C D. A FORTRAN Input Routine," J. H. Alexander, March 24, 1967; GAMD-8333, "Hydrodynamic Equations


for Multidimensional Problems," J. R. Triplett, October 24, 1967; GAMD-8379, "A Brief Study of the Thermodynamic Properties of Several Low Z Elements at Low Temperature," L. M. Schalit, November 22, 1967.

This technical report has been reviewed and is approved.


JOHN BODE

Major, USAF


Project Officer



TRUMAN L. FRANKLIN

Colonel, USAF

Chief, Theoretical Branch



CLAUDE K. STAMBAUGH

Colonel, USAF

Chief, Research Division

ABSTRACT

(Distribution Limitation Statement No. 2)

The work covered by this volume falls into three parts: (1) opacity data generated by the DIAPHANOUS code; (2) equation-of-state-data generated by the SPUTTER/HECTIC subroutines AIRMOL and CMOL and the MARIER, HELAS, and HELIKE ionization potential routines; (3) descriptions of codes used to transfer data between LASL, AFWL, Gulf General Atomic, and the DASA Analysis and Information Center (DASIAC).

CONTENTS

<u>Section</u>	<u>Page</u>
I INTRODUCTION	1
II DISCUSSION OF THERMODYNAMIC AND OPACITY PLOTS AND DIAPHANOUS DATA TABULATIONS	3
SPUTTER Material Numbers (as used by EIONX)	4
Introduction to Discussion of Material Properties Subroutines and Data Processing Codes	11
III EQUATION-OF-STATE DATA AND CODES	12
AIRMOL: A Molecular Equation-of-State Subroutine for Air	12
Thermodynamic Variables	26
Special Cases	29
Interface with Other Equation-of-State Subroutines	30
Coefficients for Least-Squares Fits	31
Variables Used in AIRMOL	33
GOLEM: A Tool to Study Equation-of-State and Opacity Subroutines	35
Standard Output Format	60
MARIER: An Isoelectronic Ionization Potential Predictor . .	61
MARIE: A Block Data Program of Ionization Potentials . . .	68
HELIKE: The Helium Isoelectronic Sequence	78
HELAS: The Helium Isoelectronic Sequence	79
IV OPACITY AND DATA TRANSFORMATION CODES	88
DYPER4: A Plot Preparation Code for Opacity and Thermodynamic Data	88
GRAPH: A Plotting Program	102
Description of Input	113
TRANS: A Plotting Program Adjunct	116
DENSER: A DIAPHANOUS Tape Compressor Code	118
DASE: An Editing Code for Denser-Produced Tapes	129
DAPHNE: A DIAPHANOUS Tape-Edit Code	132
ANDIMX: Conversion of Opacity Data from ANN to DIAPHANOUS Form	139
COMBO: A Program to Combine Opacity Tapes	148
Purpose	148

<u>Section</u>	<u>Page</u>
DIANTC: A DIANE Transfer Program (Tape to Cards or Tape)	175
DIANE Tape and DIANE Card Format	185
GREYS: A Grey Opacity Tape from DIANE Data	208
EGREY: An Editing Code for the GREY Opacity Tape	212
REDGRE: Transfer of Grey Opacity Data	212
TEDIUS: A GOLEM Adjunct	221
EDSILV: A SILVIA Tape Edit Program	226
LEVELS: Partial Sums of Ionization Potentials	230
DLISTR: A DIAPHANOUS Card Edit Code	233
DYPDIN: A Rapid Technique for Making Pseudo-DIANE Tapes	233
 Appendixes	
I AIRMOL AND CMOL DATA TABULATED BY GOLEM	243
II EGREY OUTPUT AND CARD INPUT USED WITH GREYS	259
III EQUATION-OF-STATE AND RELATED PROGRAMS	475
IV EQUATION-OF-STATE INVERSION TECHNIQUES- MODIFICATION TO THE GEST AND LIBEX PROGRAMS	485
References	533

FIGURES

<u>Figure</u>	<u>Page</u>
1 Equation-of-State and Related Programs General Flow	476
2 Opacity Programs General Flow	478
3 Procedure for Creating a DIANE Tape	480

TABLES

<u>Table</u>	<u>Page</u>
I LIAPHANOUS Compositions for Specified Material Numbers	7
II EIONX Compositions for Specified Material Numbers	8
III Coefficients for Various Species	32
IV Ionization Potentials for the Two-Electron Atom	87

NOTATIONS

$A_\alpha, B_\alpha, C_\alpha, D_\alpha, E_\alpha$	Coefficients for least-squares fit of enthalpy for species α
C_α	Concentration of species α in moles/cc; also used as above
E_α°	Internal energy (cal mole) of species α at temperature T, one atmosphere
E_{sp}	Specific energy of gas mixture, cal/gm or erg/gm
G_α°	Gibbs free energy (cal mole) of species α at temperature T, one atmosphere
H_α°	Enthalpy of species α at temperature T, one atmosphere
$H_{0,\alpha}^\circ$	Heat of formation of species α at 0°K , one atmosphere; stable molecules N_2 , O_2 , and A taken as reference state
K_1, K_2, K_3	Equilibrium constants in units of pressure for the reactions $\text{N}_2 \rightleftharpoons 2\text{N}$, $\text{O}_2 \rightleftharpoons 2\text{O}$, and $\text{NO} \rightleftharpoons \text{N} + \text{O}$ respectively
k_α	Integration constant needed to relate Gibbs free energy to enthalpy with polynomial expression
M	Mean atomic weight of air, about 14.55 gm/mole
M°	Mean molecular weight of air at standard temperature and pressure (STP), about 29 gm/mole
\bar{N}	Mean number of atoms per molecule for the mixture
P	Total pressure; units will be either atmospheres or dynes/cm ² to be consistent with context
P_α	Pressure for species α
Q	Classical partition function
R	Gas constant, units vary according to context used

NOTATIONS (continued)

T	Temperature in $^{\circ}\text{K}$
V	Volume in cc
X_A°	Atom fraction of argon in air at STP
X_O°	Atom fraction of oxygen in air at STP
X_N°	Atom fraction of nitrogen in air at STP
$(\Delta G_T^{\circ})_j$	Change in Gibbs free energy for the j^{th} reaction at temperature T , one atmosphere
η_{α}	Number of atoms in molecule α
θ	Temperature in eV
ρ	Density in gm/cc
τ	Specific volume in cc/gm; $\tau = \rho^{-1}$
ϕ	Gas constant in SPUTTER units

SECTION I

INTRODUCTION

The NEIS contract has called for the continued development of the material properties representations used by the SPUTTER, MOTET, HECTIC, and other radiation transport and hydrodynamics codes used in the study of the interactions due to nuclear explosions.

The material properties data and codes that have been developed during this contract are, in large part, connected with the need to improve the opacity formulations used by the above-mentioned codes. The MOTET and HECTIC codes formerly had to use hand-computed fits to the opacities; it is now possible for them to use a data tape containing "grey" opacities. This tape contains data for over 30 different materials.

Techniques for efficient transfer of opacity data have been extensively developed and have been used to transfer such data between Los Alamos Scientific Laboratory, Gulf General Atomic, Air Force Weapons Laboratory, and the Defense Atomic Support Agency Information and Analysis Center (DASIAC). DASIAC has been supplied with a full set of the opacity data generated at Gulf General Atomic.

Descriptions of the numerous codes used to transfer information to DASIAC and other installations have been included in this volume. (The code listings and a discussion of the data formats are included.)

Extensive summaries of the opacity data computed using the DIAPHANOUS code were prepared using codes described in this volume. These summaries are presented in a separate report (Ref. 1).

The EIONX code (used for SPUTTER and HECTIC equation-of-state data) requires ionization potentials for the elements in the material under study. AUGIAS, a DIAPHANOUS input generator, also requires this data.

AFWL-TR-67-131, Vol IV

The MARIER, HELAS, and HELIKE codes were written to help satisfy this need. (This part of the continuing research effort has not yet been concluded.)

In this program Gulf General Atomic has used opacity data generated at Los Alamos Scientific Laboratory. Several codes had to be written before these data could be used by the SPUTTER code. These codes (ANDIMX and COMBO) are described in this volume.

SECTION II

DISCUSSION OF THERMODYNAMIC AND OPACITY PLOTS AND DIAPHANOUS DATA TABULATIONS

The plots and tabulations reported in reference 1 are of the thermodynamic and opacity data calculated by using the DIAPHANOUS code. In most respects the DIAPHANOUS code is similar to the one discussed in references 2 and 3. A few minor modifications and program corrections have been made, which will be discussed in greater detail in a series of follow-on volumes to the report of reference 2. The follow-on reports will also present the absorption coefficient plots as a function of frequency for the thermodynamic properties of materials presented in reference 1.

The data presented are consistent with a model of a monatomic ionizing gas. Other assumptions made are discussed (Ref. 2).

The elements for which data are presented (Ref. 1) are:

<u>Material No.</u>	<u>Material</u>
1	Hydrogen
2	Helium
4	Beryllium
6	Carbon
10	Neon
13	Aluminum
18	Argon
26	Iron
29	Copper

(The material number is the atomic number.)

The (composite) multi-element materials are:

<u>Material No.</u>	<u>Material</u>
101	Polyethylene
102	Air
103	Teflon
105	Wet Tuff
106	Refrasil
108	Lithium Hydride
111	H - M - X
119	Grout
124	Playa
129	Average Shale
131	Average Limestone
134	Granite
136	Wet Alluvium
138	Sea Water

These material numbers are the same as those the SPUTTER subroutine EIONX uses in calculating the thermodynamic properties of an ionized gas. The compositions used by both DIAPHANOUS and EIONX are presented in tables I and II.

SPUTTER Material Numbers (as used by EIONX)

<u>Material No.</u>	<u>Material</u>
101	Polyethylene
102	Air
103	Teflon
104	Nylon-Phenolic A
105	Wet Tuff
106	Refrasil
107	Phenolic A
108	Lithium Hydride

AFWL-TR-67-131, Vol IV

<u>Material No.</u>	<u>Material</u>
109	Salt
110	Magnalium
111	H - M - X
112	Refrasil B
113	Phenolic B
114	Refrasil C
115	Carbon-Phenolic (R. Schlaug A)
116	Card Input Material 1
117	Card Input Material 2
118	Card Input Material 3
119	Roy Pauls Grout
120	Playa (R. T. Whittaker - AFWL)
121	Carbon-Phenolic (Mosen-Hays)
122	Refrasil-Phenolic (Mosen-Hays)
123	Lithium Deuteride
124	QPlaya-Calcium
125	DIAPHANOUS Air with Argon (R. T. Walsh)
126	Average Crust
127	Average Wood
128	Average Igneous Rock
129	Average Shale
130	Average Sandstone
131	Average Limestone
132	Average Sediment
133	N. T. Soil (Ref. AFWL-TR-65-171, 1966)
134	Granite (Mem. 97, Am. Geophys. Soc., Table 1. 1)
135	Hi Temp Epoxy-Novalac (Dow Chem. Co.)
136	Wet Alluvium (Ref. DuPont DP-1055)

AFWL-TR-67-131, Vol IV

<u>Material No.</u>	<u>Material</u>
137	Dry Alluvium (Ref. - Hugoniot Data from Sandia, SC-4903 (RR))
138	Sea Water (Handbook of Chemistry and Physics, Chemical Rubber Co., 45th ed. p. F82)
139	Lubri Seal, "HI Vacuum" (Source: A. H. Thomas Co., Philadelphia, Penn.)

TABLE I
DIAPHANOUS COMPOSITIONS FOR SPECIFIED MATERIAL NUMBERS

MATERIAL NO.	MATERIAL NAME	NOLMNT	Z	PART	Z	PART	Z	PART	Z	PART	Z	PART	Z	PART
101	Polyethylene	2	1	0.667	6	0.333								
102	Air	2	7	0.78	8	0.22								
103	Teflon	2	6	0.333	9	0.667								
105	Wet Tuff/Lo	3	1	0.305	8	0.497	14	0.198						
105	Wet Tuff/Hi	5	1	0.305	8	0.497	14	0.180	20	0.014	26	0.004		
106	Refrasil	4	1	0.25	6	0.25	8	0.35	14	0.15				
108	Lithium Hydride	2	1	0.5	3	0.5								
111	H - M - X	4	1	0.286	6	0.143	7	0.286	8	0.286				
119	Grout	4	1	0.439	7	0.502	13	0.048	22	0.011				
124	Playa/Lo	4	1	0.221	6	0.049	8	0.536	14	0.197				
124	Playa/Hi	5	1	0.221	6	0.049	8	0.536	14	0.161	20	0.036		
129	Shale	4	1	0.1029	8	0.6005	14	0.2562	26	0.0404				
131	Limestone	5	1	0.016	6	0.181	8	0.596	12	0.058	20	0.148		
134	Granite/Lo	3	1	0.027	8	0.606	14	0.367						
134	Granite/Hi	5	1	0.027	8	0.606	12	0.106	14	0.206	22	0.055		
136	Wet Alluvium	4	1	0.22	8	0.535	14	0.229	26	0.02				
138	Sea Water	5	1	0.6623	8	0.3311	11	0.0032	17	0.0033	20	0.0001		

NOLMNT: Number of elements

Z: Atomic number

PART: Number fraction

TABLE II
EIONX COMPOSITIONS FOR SPECIFIED MATERIAL NUMBERS

MATERIAL NUMBER	NOLMINT	Z	PART	Z	PART	Z	PART	Z	PART	Z	PART
101	2.	1.	0.66666667	6.	0.33333333	18.	0.00471	8.	0.0625	19.	0.023
102	3.	7.	0.78467	8.	0.21062				0.1367		
103	2.	6.	0.33333333	9.	0.66666667	7.	0.03125	14.	0.15		
104	4.	1.	0.5625	6.	0.34375	13.	0.033	14.			
105	5.	1.	0.31	8.	0.497	8.	0.35				
106	4.	1.	0.25	6.	0.25	8.	0.09090909				
107	3.	1.	0.45454545	6.	0.45454545						
108	2.	1.	0.5	3.	0.5						
109	2.	11.	0.5	17.	0.5						
110	2.	12.	0.3	13.	0.7						
111	4.	1.	0.28571428	6.	0.14285714	7.	0.28571428	8.	0.28571428		
112	4.	1.	0.19136	6.	0.2392	8.	0.39026	14.	0.17918		
113	3.	1.	0.414	6.	0.517	8.	0.069	8.	0.321	14.	0.132
114	5.	1.	0.248	5.	0.007	6.	0.292				
115	3.	1.	0.179	6.	0.779	8.	0.042				
116	5.	1.	0.4282	6.	0.3264	7.	0.02697	8.	0.1602	14.	0.05626
117	5.	1.	0.22	6.	0.049	8.	0.535	14.	0.164	20.	0.032
118	5.	1.	0.0272	6.	0.8631	7.	0.0078	8.	0.0922	26.	0.0097
119	5.	1.	0.023	6.	0.252	7.	0.003	8.	0.384	14.	0.337
120	2.	1.	0.5	3.	0.5						
121	5.	1.	0.221	6.	0.049	8.	0.536	14.	0.161	20.	0.036
122	5.	7.	0.785	8.	0.21	18.	0.005				
123	3.	8.	0.6255	13.	0.1095	14.	0.2122	20.	0.0336	26.	0.0192
124	3.	1.	0.473	6.	0.317	8.	0.21				
125	5.	1.	0.0266	9.	0.6064	12.	0.1065	14.	0.2059	22.	0.0546
126	4.	1.	0.1029	8.	0.6005	14.	0.2562	26.	0.0404		
127	5.	1.	0.0352	8.	0.6553	12.	0.0266	14.	0.2542	20.	0.0286
128	5.	1.	0.0164	6.	0.18139999	8.	0.5958	12.	0.0578	20.	0.1485
129	5.	1.	0.0687	8.	0.6279	14.	0.0699	14.	0.1865	20.	0.047
130	4.	1.	0.163	8.	0.558	12.	0.226	14.	0.053		
131	5.	8.	0.6399	13.	0.0854	14.	0.2392	19.	0.0251	26.	0.0104
132	3.	1.	0.4615	6.	0.4461	8.	0.0923				
133	4.	1.	0.22	8.	0.535	14.	0.229	26.	0.02		
134	4.	1.	0.083	8.	0.609	14.	0.281	26.	0.026		
135	5.	1.	0.6623	8.	0.3311	11.	0.0032	17.	0.0033	20.	0.0001
136	3.	1.	0.657	6.	0.342	8.	0.001				

Note that the compositions listed are not always identical. However, they are enough alike, in light of other concurrent approximations in the radiation-transport hydrodynamics codes, for the user to consider the opacity data (provided by DIAPHANOUS to SPUTTER) to be for the same material as the thermodynamic data (provided by EIONX to SPUTTER), when the same number is used as (1) the equation-of-state material number, specifier, and (2) the opacity material number specifiers in SPUTTER input.

DIAPHANOUS runs for a given material are usually done in two sets, a low-temperature set and a high-temperature set. It is now standard practice to run the temperatures 1, 1.5, 2.25, 3.4, 5., 7., 10., 15., 22.5, and 34. eV as the low-temperature set. Graphs made from such runs have the material name followed by /LO in their upper titles. Similarly, the standard high-temperature set comprises 50., 70., 100., 225., 340., 500., 700., 1000., and 2250. eV. Occasionally, more temperature values are added (3400., 5000., and 10,000. eV). These graphs have the material name followed by /HI in the upper title. In any case, the graphs plotted at a constant temperature on any given curve have a list of these temperatures (with their respective plotting symbol) just below the upper title. In addition, various dates, tape numbers, and other data are recorded in the plot titles for historical background.

The two independent variables in DIAPHANOUS runs are temperature, θ (in eV), and Γ , a dimensionless "electron degeneracy parameter,"

$$\Gamma \equiv \frac{2(2\pi m \theta)^{3/2}}{h^3 N_e}$$

where N_e is the number density of free electrons, m is the electron mass, and h is Planck's constant, and

$$(1/N_e) = \frac{(\overline{M^0}/N_a)}{\rho \bar{Z}}$$

where ρ is the density in gm/cc, \bar{Z} is the mean ionization (i.e., mean ion charge), $\overline{M^0}$ is the mean atomic weight, and N_a is Avogadro's number of

molecules per mole. Thus $(\overline{M^0}/N_a)$ is the mean mass per molecule.

Then Γ is seen to be inversely proportional to both ρ and \overline{Z} :

$$\Gamma = \frac{2(2\pi m \theta)^{3/2} (\overline{M^0}/N_a)}{h^3 \rho \overline{Z}}$$

$$= c' \left(\frac{\theta^{3/2}}{\rho \overline{Z}} \right) \overline{M^0} \cong (0.01 \theta^{3/2} \overline{M^0}) / (\rho \overline{Z})$$

Γ is a natural variable for the DIAPHANOUS code; however, it is an inconvenient variable for intuitive physical reasoning since $\Gamma = \Gamma[\theta, \rho, \overline{Z}(\theta, \rho)]$ for a given material. For this reason, most of the plots have been done for the several dependent variables on curves of constant temperature. For completeness, some plots at constant Γ have been included for each material. The graphs at constant Γ have a list of the Γ values, along with the respective plotting symbol, just below the upper title.

For any given material, the plots are usually in two sets, a /LO set and a /HI set. Within a given set, a group of plots with curves at constant temperature are followed by a group of plots with curves at constant Γ . The y-axis labels are complete and self-explanatory with the exception of the quantity EGAM which is defined as

$$\text{EGAM} \equiv 1 + P/\rho E$$

where P is the pressure in dynes/cm², ρ is the density in gm/cc, and E is the specific internal energy in ergs/gm so EGAM is dimensionless. (The quantities ρ and E are the same quantities used in the other graphs and tabular data. P is in units of bars in the other graphs and in the tabular data.)

The plots are arranged in order of increasing material number.

Refer to reference 1 for further information on the codes used.

The plots were produced by the following sequence of computer runs:

- a. DYPER4 was run to produce plots of the absorption coefficient as a function of frequency and to punch summary cards of thermodynamic and opacity data.
- b. GRAPH and TRANS were run using the above summary cards as input. Plot tapes were prepared for the SC-4020 plotter.

The tabulations following the plots were produced by the DLISTR program from the summary cards.

INTRODUCTION TO DISCUSSION OF MATERIAL PROPERTIES SUBROUTINES AND DATA PROCESSING CODES

The following code descriptions are of some of the computer programs developed for and used in the material property calculations performed for this contract.

The codes discussed fall into two overlapping categories:

1. Codes used to generate the tabular or graphical data presented in reference 1. These include:

GOLEM, AIRMOL, DYPER4, GRAPH, TRANS, HELIKE, HELAS, LEVELS, TEDIUS, MARIER, MARIE, DLISTR, GREYS, and EGREY.

2. Codes that have been used in transferring opacity data from one installation to another. These codes have been used to process data from LASL, to supply data to AFWL, and most recently, to create sizeable quantities of stored opacity data at the DASA Information and Analysis Center (DASIAC) in Santa Barbara, California. These include:

DENSER, DASE, DAPHNE, ANDIMX, COMBO,
DIANE, DIANTC, DIANCT, DYPDIN, GREYS,
EGREY, REDGRE, DLISTR, LEVELS, TEDIUS,
EDSILV, DYPER4, GRAPH, and TRANS.

Some applications of the codes discussed in this volume are given in reference 1.

SECTION III

EQUATION-OF-STATE DATA AND CODES

A description of the physics and programming techniques used in the SPUTTER/HECTIC molecular air equation-of-state subroutine AIRMOL, and a description of several codes used to generate needed ionization potentials for the EIONX subroutine is presented in this section.

Several accessory codes (such as GOLEM) are also described.

AIRMOL: A MOLECULAR EQUATION-OF-STATE SUBROUTINE FOR AIR

The computer subroutine AIRMOL develops a molecular equation-of-state for air in thermodynamic equilibrium from room temperature to 25,000°K over a density range of 10 gm/cc to 10^{-7} gm/cc. Enthalpies and free energies are obtained from analytic fits of tabulated data. The system composition is derived from conservation relations and reaction equations. The thermodynamic variables E , P , $(\partial E/\partial \theta)_\tau$, $(\partial E/\partial \tau)_\theta$, $(\partial P/\partial \theta)_\tau$, and \bar{N} are the final output of the code. These are transferred to the EIONX code, which calculates all translation and ionization quantities. These two subroutines are used in the SPUTTER code, which is a general purpose one-dimensional radiation and fluid mechanics program.

SUBROUTINE AIRMOL(THETA,TAU,PESIER)

```

C
C
C      GLOSSARY FOR AIRMOL
C
C      .....
C      *      UEDTAU      SAME AS      CARBNZ(13)
C      *      UEDTHI      SAME AS      CARBNZ(14)
C      *      UPUTAU      SAME AS      CARBNZ(15)
C      *      UPUTHI      SAME AS      CARBNZ(16)
C      *      EDIS        SAME AS      CARBNZ(11)
C      *      NBAR        SAME AS      EION(17)
C      .....
C
C      A(6)      POLYNOMIAL COEFFICIENT FOR ENTHALPY.
C      AI        XREFN*RH0. THE TOTAL NUMBER OF N ATOMS (IN MOLE/CC) AT
C                ANY TEMPERATURE AND PRESSURE.
C      AEST      2.*EST
C      B(6)      POLYNOMIAL COEFFICIENT FOR ENTHALPY.
C      BARK(6)    INTEGRATION CONSTANT FOR FREE ENERGY IF ENTHALPY IS
C                POLYNOMIAL
C      BARK2(6)   INTEGRATION CONSTANT FOR FREE ENERGY IF ENTHALPY IS
C                5/2RT
C      C(6)      POLYNOMIAL COEFFICIENT FOR ENTHALPY.
C      CON(6)     CONCENTRATION, MOLES/CC.
C      U(6)      POLYNOMIAL COEFFICIENT FOR ENTHALPY.
C      U1        SQRT(CON(12))
C      UCDT(6)    D(CON(1))/DT
C      UCDTAU(6)  D(CON(1))/DTAU
C      UEDT(6)    D(ESPEC2(1))/DT
C      UEDTAU     D(EDIS)/DTAU
C      UEDIS      D(EDIS)/DT
C      UEDTHI     D(EDIS)/D(THETA)
C      UELH(6)    ENTHALPY AT ONE ATMOSPHERE, ZERO DEGREES KELVIN, 'HEAT
C                OF FORMATION AT REFERENCE STATE', CALORIE/MOLE.
C      UGDT(6)    D(FRENG(1))/DT.
C      UKP1DT     D(KP1)/DT
C      UKP2DT     D(KP2)/DT
C      UKP3DT     D(KP3)/DT
C      UNDT       D(NBAR)/DT
C      UNUM       DENOMINATOR IN DETERMINANT EQUATS. FOR D(CON(1))/DT
C                AND D(CON(1))/DTAU
C      UPUTAU     D(PRESHR)/DTAU = -PRESHR/NBAR*U(NBAR)/DTAU

```

AFWL-TR-67-131, Vol IV

```

C      UPUTHI      =PRESHR * DTHETA/DT * (DT/DTHETA)/NBAH * DP/DTHETA
C      WITHOUT P/THETA TERM
C      E(6)        POLYNOMIAL COEFFICIENT FOR ENTHALPY.
C      E1          2*H2IKEL/KP2
C      EUIS        ENERGY -3/2*PHI*(1/NBAH)*THETA. TOTAL SPECIFIC ENERGY
C      DUE TO DISSOCIATION.
C      ENERGY     TOTAL SPECIFIC ENERGY, ERG/GM
C      ESPECZ(6)   INTERNAL ENERGY AT TKEL, ONE ATMOSPHERE, CAL/MOLE
C      ESI         ESTIMATE AT RATIO CONINO)/CONIN2) BEFORE ITERATION START
C      EZ          TOTAL DIMENSIONLESS ENERGY, E/RT
C      F1          1 + CONINO)/KP3*H2IKEL
C      FHENRG(6)   (FREE ENERGY AT TKEL)/(R*TKEL), DIMENSIONLESS
C      HSPECZ(6)   ENTHALPY AT TKEL, ONE ATMOSPHERE, CAL./MOLE
C      KP1         EQUILIBRIUM CONSTANT IN PRESSURE UNITS FOR N2=2N
C      KP2         EQUILIBRIUM CONSTANT IN PRESSURE UNITS FOR O2=2O
C      KP3         EQUILIBRIUM CONSTANT IN PRESSURE UNITS FOR N+O=NO
C      MARK        CALLING PARAMETER
C      - INCLUDE  ELECTRONIC EXCITATION FOR ATOMS
C      + NO ELECTRONIC EXCITATION FOR ATOMS
C      0 LIKE +, ALSO PRINTOUT DEBUG QUANTITIES IN AIRMOL
C      MUFRACT(6)  MOLE FRACTION
C      NBAH        MEAN NUMBER OF ATOMS PER MOLECULE FOR GAS MIXTURE
C      NITER       ITERATION COUNTER
C      NUNOH1      0 IF ENTHALPY/RT IS CONSTANT FOR ATOMS, 1 IF ENTHALPY/RT
C      IS POLYNOMIAL
C      OLUX(6)     CONCENTRATION OF PREVIOUS ITERATION
C      PHI         9.649E11/RTREF
C      PU          TOTAL PRESSURE, ATMOSPHERES
C      PRESHR      TOTAL PRESSURE, UTNE/CM**2
C      RHU         DENSITY, GM/CC
C      RH1*RH2     RIGHT HAND SIDE OF DETERMINANT EQUATS. FOR DICON(11)/DTAU
C      RH3=5       RIGHT HAND SIDE OF DETERMINANT EQUATS. FOR DICON(11)/D1
C      RTKEL       R*TKEL, R=1.98726 CAL/MOLE/DEG
C      R2IKEL      R*TKEL, R=82.054 CC*ATM/MOLE/DEG
C      RT2         R2TKEL**2
C      SCUE        SUM OF D(ESPECZ(1))/DT * CON(1)
C      SCE         SUM OF D(ICON(1))/DT * ESPECZ(1)
C      SUI         SUM OF D(ICON(1))/DT
C      SUTAU       SUM OF D(ICON(1))/DTAU
C      SNC         TOTAL NUMBER OF ATOM PER CC. SUM OF N(1)*CON(1), WHERE
C      N(1) IS ATOM/MOLECULE
C      SNUAU       SUM OF N(1)*D(ICON(1))/DTAU. N(1)=ATOM/MOLECULE
C      SUMCON      SUM OF ALL CON(1), MOLE/CC
C      SUMNRG      TOTAL ENERGY, CAL/CC. SUM OF CON(1)*ESPECZ(1)
C      TAU         SPECIFIC VOLUME, CC./GM.
C      THETA       TEMPERATURE, EV.
C      TKEL        TEMPERATURE, DEGREES KELVIN
C      TKELN       ALOG(TKEL) NATURAL LOG
C      TRM1        KP1/R2IKEL
C      TRM2        A1-CONINO)
C      VV          XRLFU*RHU. THE TOTAL NUMBER OF O ATOMS (IN MOLE/CC) AT
C      ANY TEMPERATURE
C      V1*V2*V3    CHANGE IN FREE ENERGY/RT1 FOR REACTIONS N2=2N, O2=2O,
C      AND N+O=NO RESPECTIVELY
C      WTHET       ATOMIC WEIGHT OF AIR AT STP, ABOUT 14.55 GM/MOLE

```

AFWL-TR-67-131, Vol IV

```

C      XREFA      MOLE FRACTION OF A ATOMS/MEAN ATOMIC WEIGHT AT STP
C      XREFU      MOLE FRACTION OF U ATOMS/MEAN ATOMIC WEIGHT AT STP
C      XREFN      MOLE FRACTION OF N ATOMS/MEAN ATOMIC WEIGHT AT STP
C
COMMON/LMS/EION(20)
EQUIVALENCE (NHAK,EION(1))
COMMON/LMSG/CARBNZ(10)
DIMENSION AIR(10)
EQUIVALENCE(AIR(1),CARBNZ(1))
EQUIVALENCE(AIR(1),EDIS),(AIR(3),DEDTAU),(AIR(4),DEDTHT),
* (AIR(5),DPTAU),(AIR(6),DPTH)
DIMENSION A(6), B(6), C(6), D(6), E(6), BAKK(6), BAKK2(6), CON(6) AIRM 30
* ,DELH(6),OLUX(6),FHENRG(6),HSPECZ(6),ESPECZ(6),MOFRC(6)
DIMENSION DCDT(6),DCDTAU(6),DEDI(6),DGD(6) AIRM 60
REAL KP1, KP2, KP3, MOFRC1, NHAK AIRM 70
DATA XREFN, XREFU, XREFA/5.3929E-2, 1.4476E-2, 3.237E-4/ AIRM 80
DATA XREF/14.55/, AIR(8)/0./,PHI/6.63E10/
DATA A/3.39032, 3.46754, 3.02986, 2.54395, 2.66918, 2.49716/ AIRM 100
DATA B/3.26691E-4, 3.33691E-4, 2.39195E-4, - 7.03288E-5, - AIRM 110
* 6.76606E-5, 2.06980E-6/ AIRM 120
DATA C/-4.43869E-8, - 3.26154E-8, - 2.68348E-8, 2.10493E-8, AIRM 130
* 1.16238E-8, - 2.90268E-10/ AIRM 140
DATA D/2.84212E-12, 1.78842E-12, 1.46612E-12, - 1.23848E-12, - AIRM 150
* 6.49696E-13, - 2.16444E-15/ AIRM 160
DATA E/-5.61017E-17, - 3.45129E-17, - 2.68536E-17, 2.27227E-17, AIRM 170
* 1.25238E-17, 1.16325E-18/ AIRM 180
DATA DELH/0., 0., 21476.5, 112579.5, 58986.5, 0./ AIRM 190
DATA BAKK/3.47421, 4.63168, 4.44607, 3.99389, 4.12663, 4.37850/ AIRM 200
DATA BAKK2/1., 1., 1., 4.48452, 5.26387, 4.37217/ AIRM 210
DATA EREF/2.699E11/

C
C
C      MARK=FESTER+.5

TKEL = 11605.4*THETA AIRM 220
RHU = 1./IAU AIRM 230
RTKEL = 1.98726*TKEL AIRM 240
R2TKEL = 82.054*TKEL AIRM 250
RT2 = R2TKEL**2 AIRM 260
TKELN = ALOG(TKEL) AIRM 270
UO J 1 = 1.6
UCDT(1) = 0.
CON(1) = 0.
3 UCDTAU(1) = 0.
PRESHR = 0.
SUMNRG = 0.
ENERGY = 0.
PO = 0.
EZ = 0.
DEDTAU = 0.
DPTH1 = 0.
DPTAU = 0.
DEDTHT = 0.
KP1 = 0.

```

AFWL-TR-67-131, Vol IV

```

      KP2 = 0.
      KP3 = 0.
      IF (TKEL .LT. 25000.) GO TO 1
      ED15 = 2.899E11 - EREF
      NBAR = 1.
      GO TO 1000
1 CONTINUE
      IF (RHU .LT. 10.1) GO TO 2
      AIR(8) = 96.0001
      RETURN
2 CONTINUE

C
C      COMPUTE ENTHALPY, FREE ENERGY, AND DEDT(1), AND DGD(1)
C
      L=3
      IF (MARK .LT. 0) L=6
10 CONTINUE
      DO 15 I = 1, L
      HSPCZ(1) = RTKEL*(A(1) + TKEL*(B(1) + TKEL*(C(1) + TKEL*(D(1) +
      * TKEL*(E(1)))) + DELH(1)
      DEUT(1) = HSPCZ(1)/TKEL + 1.98726*(-1. + TKEL*(B(1) + TKEL*(2.*C(1)
      * 1) + TKEL*(3.*D(1) + TKEL*(4.*E(1))))
      FRENHG(1) = A(1)*(1. - TKELN) - (BARK(1) + TKEL*(B(1) + TKEL*(C(1)
      * 2. + TKEL*(D(1)/3. + TKEL*(E(1)/4.))) + DELH(1)/RTKEL
15 DGD(1) = -(A(1)/TKEL + B(1) + TKEL*(C(1) + TKEL*(D(1) + TKEL*(E(1)
      * DELH(1)/(RTKEL*TKEL))
      IF (MARK .LT. 0) GO TO 20
      DO 25 I = 4, 6
      HSPCZ(1) = 2.5*RTKEL*DELH(1)
      DEUT(1) = 1.5*1.98726
      FRENHG(1) = 2.5*(1. - TKELN) - BARK2(1) + DELH(1)/RTKEL
25 DGD(1) = -(2.5*DELH(1)/RTKEL)/TKEL
20 CONTINUE

C
C      ARGON CONCENTRATION.
C
      CON(6) = XREFA*RHU
      NITER = 1
      IF (TKEL - 1200. .GT. -1.E-30) GO TO 60

C
C      LOW TEMPERATURE APPROXIMATION.
C
      CON(1) = 2.6965E-2*RHU
      CON(2) = 7.2379E-3*RHU
      DEUTHI = TAU*(DEUT(1)*CON(1) + DEUT(2)*CON(2) + DEUT(6)*CON(6))*
1      4.184E7*11605.4 - 1.5*PHI/1.99
      GO TO 70

C
C      CALCULATE CONCENTRATION BY ITERATIVE METHOD.
C
      DO CONTINUE

C
C      EQUILIBRIUM CONSTANTS.
C
      V1 = 2.*FRENHG(4) - FRENHG(1)

```


KP1 = EXP(-V1)	AIRN 540
V2 = 2.*FRENKG(5) - FRENKG(2)	AIRN 550
KP2 = EXP(-V2)	AIRN 560
V3 = FRENKG(4) + FRENKG(5) - FRENKG(3)	AIRN 570
KP3 = EXP(-V3)	AIRN 580
C	
C CALCULATE CON(N2) BY ASSUMING CON(N0)/CON(N2) = EST	
C	
EST = .01	AIRN 640
TRM1 = KP1/R2TKEL	AIRN 700
A1 = XREFN*RHO	AIRN 710
VV = XREFU*RHO	AIRN 720
E1 = 2.*R2TKEL/KP2	AIRN 730
300 CONTINUE	AIRN 740
C	
C AFTER FIRST PASS, USE OLD VALUE OF CON(N0) IN EQUATION	
C FOR CON(N2)	
C	
IF (NITER .NE. 1)	AIRN 750
' GO TO 325	AIRN 760
AEST = 2. + EST	AIRN 770
U1 = 2.*A1/(SQRT(TRM1) + SQRT(AEST)*SQRT(TRM1/AEST + 4.*A1))	AIRN 780
GO TO 330	AIRN 790
325 CONTINUE	AIRN 800
TRM2 = A1 - CON(3)	AIRN 810
IF (TRM2 .LT. 0.)	AIRN 820
' TRM2 = 0.	AIRN 830
U1 = 2.*(A1 - CON(3))/(SQRT(TRM1) + SQRT(TRM1 + 8.*TRM2))	AIRN 840
C	
C	
330 CON(1) = U1**2	AIRN 850
C	
C CON(N)	
C	
CON(4) = SQRT(KP1)*SQRT(CON(1)/R2TKEL)	AIRN 860
F1 = 1. + CON(4)/KP3*R2TKEL	AIRN 870
C	
C CON(0)	
C	
CON(5) = 2.*VV/(F1 + SQRT(F1**2 + 4.*E1*VV))	AIRN 880
C	
C CON(02)	
C	
CON(2) = CON(5)**2/KP2*R2TKEL	AIRN 890
C	
C CON(N0)	
C	
CON(3) = CON(4)*CON(5)*R2TKEL/KP3	AIRN 900
70 CONTINUE	AIRN 910
SUMCON = 0.	AIRN 920
DO 30 J = 1, 6	AIRN 930
30 SUMCON = SUMCON + CON(J)	AIRN 940
C	
C MOLE FRACTIONS	
C	

AFWL-TR-67-131, Vol IV

```

DO 35 J = 1, 6
35 MOFRCT(J) = CON(J)/SUMCON
IF (MARK .NE. 0) GO TO 235
/5 WRITE (6, 210)MOFRCT, NITER
210 FORMAT (18HMOFRCT(1), NITER,1P6E12.5,15)
WRITE (6, 220)CON
220 FORMAT (7H CON(1),10X,1P6E12.5)
WRITE (6, 230)SUMCON
230 FORMAT (7H SUMCON,1P6E12.6)
235 CONTINUE
C
C      FOR LOW TEMPERATURE, NO ITERATIONS
C
IF (TKEL .LT. 1200.)
* GO TO 110
IF (NITER .EQ. 1)
* GO TO 310
C
C      TEST FOR CONVERGENCE
C
TEST = ABS(OLDX(1) - CON(1))/OLDX(1)*100.
IF (TEST .LT. .1)
* GO TO 110
C
C      TEST IF ITERATION LIMIT EXCEEDED
C
IF (NITER .GE. 10)
* GO TO 120
310 DO 314 I = 1, 6
314 OLDX(I) = CON(I)
NITER = NITER + 1
C
C      ITERATE
C
GO TO 300
120 AIR(8) = 96.0120
RETURN
110 CONTINUE
C
C      THERMO. PROPERTIES OF MIXTURE
C
SNC = 2.*(CON(1) + CON(2) + CON(3)) + CON(4) + CON(5) + CON(6)
MHESHM = 0.314/E/*TKEL*SUMCON
NBAR = SNC/SUMCON
DO 200 I = 1, 6
ESPECZ(I) = HSPECZ(I) - RTKEL
EZ = EZ + MOFRCT(I)*ESPECZ(I)/RTKEL
200 SUMNRG = SUMNRG + CON(I)*ESPECZ(I)
ENERGY = TAU*SUMNRG*4.184E+7
EUIS = ENERGY - 1.5*PH1*THETA/NBAR-EREF
PO = RTKEL*SUMCON
C
C      ***DERIVATIVES OF CONCENTRATIONS ***
C
IF (TKEL .LT. 1200.) GO TO 1000

```

AIRM 950
 AIRM 960
 AIRM 970
 AIRM 980
 AIRM 990
 AIRM1010
 AIRM1020
 AIRM1030
 AIRM1040
 AIRM1050
 AIRM1060
 AIRM1070
 AIRM1080
 AIRM1090
 AIRM1100
 AIRM1110
 AIRM1120
 AIRM1130
 AIRM1140
 AIRM1150
 AIRM1160
 AIRM1190
 AIRM1200
 AIRM1210
 AIRM1240
 AIRM1250
 AIRM1260
 AIRM1270
 AIRM1290
 AIRM1300
 AIRM1320

AFWL-TR-67-131, Vol IV

```

C
C
C      EQUILIBRIUM CONSTANTS DERIVATIVES
C
C      AIRM1330
C      AIRM1350
C      DV1DT = -2.*DGD1(4) + DGD1(1)
C      DV2DT = -2.*DGD1(5)+DGD1(2)
C      DV3DT = -(DGD1(4)+DGD1(5))+DGD1(3)
C      DKP1DT = KP1*DV1DT
C      DKP2DT = KP2*DV2DT
C      DKP3DT = KP3*DV3DT
C
C
C      RIGHT HAND SIDE OF DEL. EQUATS. FOR CONCENTRATION'S
C      DERIVATIVES
C
C      AIRM1390
C      AIRM1410
C      AIRM1420
C      AIRM1430
C      AIRM1440
C      AIRM1450
C      AIRM1460
C      RH1 = -XREFN*RH0**2
C      RH2 = -XREFD*RH0**2
C      RH3 = CON(1)*DKP1DT - 82.054*CON(4)**2
C      RH4 = CON(2)*DKP2DT - 82.054*CON(5)**2
C      RH5 = CON(3)*DKP3DT - 82.054*CON(4)*CON(5)
C
C
C      CONCENTRATIONS DERIVATIVES
C
C      XX = CON(4)*R21KEL
C      YY = CON(5)*R21KEL
C      ZZ = 4.*XX/KP1 + 1.
C      UU = YY + KP3*ZZ
C      WW = 2./(KP2*ZZ)
C      DD1 = RH4 - KP2/KP1*RH5
C      EE1 = RH5 + 2.*KP3/KP1*RH3
C      DD2 = .5*KP2*(RH2 - RH1)
C      EE2 = KP3*RH1
C      A55 = XX + (2.*YY + .5*KP2)*UU*WW
C      A56 = EE1 + WW*DD1*UU
C      d56 = EE2 + WW*DD2*UU
C      DCDT(5) = A56/A55
C      DCDT(4) = WW*((2.*YY + .5*KP2)*DCDT(5) - DD1)
C      DCDT(3) = 2.*RH3/KP1 - ZZ*DCDT(4)
C      DCDT(2) = -.5*(DCDT(3) + DCDT(5))
C      DCDT(1) = -.5*(DCDT(3) + DCDT(4))
C      DCDTAU(5) = D56/A55
C      DCDTAU(4) = WW*((2.*YY + .5*KP2)*DCDTAU(5) - DD2)
C      DCDTAU(3) = RH1 - ZZ*DCDTAU(4)
C      DCDTAU(2) = .5*(RH2 - DCDTAU(3) - DCDTAU(5))
C      DCDTAU(1) = .5*(- DCDTAU(3) + (RH1 - DCDTAU(4)))
C      DCDT(6) = 0.
C      DCDTAU(6)=-CON(6)*RH0
C
C
C      THERMO. PROPERTIES DERIVATIVES
C
C      SUT = DCDT(1) + DCDT(2) + DCDT(3) + DCDT(4) + DCDT(5) + DCDT(6)
C      SUTAU = DCDTAU(1) + DCDTAU(2) + DCDTAU(3) + DCDTAU(4) + DCDTAU(5)
C      + DCDTAU(6)
C      SNUT = 2.*(DCDT(1) + DCDT(2) + DCDT(3)) + DCDT(4) + DCDT(5) + DCDT(6)
C      SNUTAU = 2.*(DCDTAU(1) + DCDTAU(2) + DCDTAU(3)) + DCDTAU(4) +
C      DCDTAU(5) + DCDTAU(6)

```

AFWL-TR-67-131, Vol IV

```

UNUT = (SDT - NBAR*SDT)/SUMCON
UNUTAU = (SDUTAU - NBAR*SDUTAU)/SUMCON
IF (NBAR-1. .LT. 1.E-6) UNUTAU = DCUTAU(1) + DCUTAU(2) + DCUTAU(3)
SCE = 0.
SCUE = 0.
FRUG = 0.
DO 405 I = 1, 6
SCE = SCE + DCUT(I)*ESPECZ(I)
FRUG = FRUG + DCUTAU(I)*ESPECZ(I)
405 SCUE = SCUE + UDOT(I)*CON(I)
UEDTAU = ENERGY*RH0 + IAU*FRUG*4.184E7
UNRGUT = IAU*(SCE + SCUE)*4.184E7
UEDTHI = UNRGUT*11605.4 - 1.5*PHI/NBAR
UPDTHT = -PRESHR*UNUT*11605.4/NBAR
UPUTAU = -PRESHR/NBAR*UNUTAU
C
C          DEBUG PRINTOUT
C
1000 CONTINUE
IF (MARK .NE. 0) RETURN
CALL DVCHK (KALL)
WRITE (6,1003) IKEL,RH0,MARK
WRITE (6,1005) PRESHR,NBAR,SUMNRG,ENERGY,PO,EZ
WRITE (6,1006) EUIS,UEDTAU,UEDTHI,DPDTHT,DPDTAU,SUMCON
WRITE (6,1004) KP1,KP2,KP3
WRITE (6,1007) HSPECZ
WRITE (6,1008) FENRG
WRITE (6,1021) DGD
WRITE (6,1009) ESPECZ
WRITE (6,1010) MOFRC
WRITE (6,1011) CON
WRITE (6,1017) DKP1DT, DKP2DT, DKP3DT
WRITE (6,1018) RH1, RH2, RH3, RH4, RH5
WRITE (6,1019) XX,YY,ZZ,A55,A56,B56
WRITE (6,1020) UNUT, UNUTAU, UNRGUT, KALL
WRITE (6,1015) UDOT
WRITE (6,1016) DCUTAU
1002 FORMAT (2E12.0,I12)
1003 FORMAT (16H1IKEL,RH0,MAINUM,2E15.5,I10)
1004 FORMAT (12H0KP1,KP2,KP3,3E15.5)
1005 FORMAT (32H0PRESHR,NBAR,SUMNRG,ENERGY,PO,EZ,6E15.5)
1006 FORMAT (40H0EUIS,UEDTAU,UEDTHI,DPDTHT,DPDTAU,SUMCON,6E15.5)
1007 FORMAT (7H HSPECZ,6E15.5)
1008 FORMAT (7H FENRG,6E15.5)
1009 FORMAT (7H ESPECZ,6E15.5)
1010 FORMAT (7H MOFRC,6E15.5)
1011 FORMAT (4H CON,6E15.6)
1015 FORMAT (5H0UDCUT,6E15.5)
1016 FORMAT (7H0UDCUTAU,6E15.6)
1017 FORMAT (11H DKP1-DT,3E15.5)
1018 FORMAT (10H RH1-5,5E15.5)
1019 FORMAT (22H XX,YY,ZZ,A55,A56,B56,6E15.5)
1020 FORMAT (24H UNUT,UNUTAU,UNRGUT,KALL,3E15.6,15)
1021 FORMAT (6H DGD,6E15.5)
RETURN
END

```

AIRM1860
 AIRM1870
 AIRM1910
 AIRM1920
 AIRM1930
 AIRM1940
 AIRM1950
 AIRM1990
 AIRM2000

System Composition. The AIRMOL code considers a gas mixture composed of N_2 , O_2 , NO, N, O, and A in thermodynamic equilibrium. The first step in obtaining the thermodynamic properties of the mixture is to determine the composition as a function of temperature T and density ρ . The argon concentration can be found immediately, because it enters no chemical reactions:

$$C_A = \frac{X_A^0}{M} \rho \quad (1)$$

where X_A^0 is the mole fraction of argon in air at STP; M is the mean atomic weight of the mixture, ≈ 14.55 gm/mole; C_A is the argon concentration in mole/cc; and ρ is the density in gm/cc.

Conservation Equations. Five concentrations are still unknown. Two equations can be written to express the conservation of nitrogen and oxygen atoms. (AIRMOL does not consider ionization.) For any temperature and density, the total number of moles of nitrogen atoms per cc is $X_N^0 \rho / M$, where X_N^0 is the mole fraction of nitrogen atoms in air at STP. The conservation equation is then

$$2 C_{N_2} + C_N + C_{NO} = X_N^0 \rho / M \quad (2)$$

where C_α is the concentration of species α in moles/cc. A similar equation applies to oxygen:

$$2 C_{O_2} + C_O + C_{NO} = X_O^0 \rho / M \quad (3)$$

Equilibrium Constants. The following three reactions are considered:



The equilibrium constants in dimensionless pressure units for these reactions are:

$$\left. \begin{aligned} K_1 &= \frac{P_N^2}{P_{N_2}} \\ K_2 &= \frac{P_O^2}{P_{O_2}} \\ K_3 &= \frac{P_N P_O}{P_{NO}} \end{aligned} \right\} \quad (5)$$

(The usual conventions referencing the above pressures to the STP values are to be understood.)

Assuming that each species behaves as a perfect gas, the partial pressure for species α can be written

$$P_\alpha = n_\alpha RT/V \quad (6)$$

where P_α is in atmospheres, n_α is the number of moles of species α , V is the volume in cc, and

$$R = 82.054 \text{ (atm-cc)/(mole-}^\circ\text{K)}$$

However, (n_α/V) is the concentration C_α . Substituting Eq. (6) into Eq. (5) yields equations that express the equilibrium constants in terms of the dimensionless concentrations:

$$\left. \begin{aligned} K_1 &= C_N^2 RT/C_{N_2} \\ K_2 &= C_O^2 RT/C_{O_2} \\ K_3 &= C_N C_O RT/C_{NO} \end{aligned} \right\} \quad (7)$$

(The usual conventions referencing the above concentrations to the STP values are to be understood.)

Free Energies and Enthalpies. If the equilibrium constants are known as a function of T , then Eq. (7) and the conservation equations are five non-linear equations in the five unknowns (the concentrations). The equilibrium

constants can be written in terms of the change in the Gibbs free energy ΔG_T^0 across the reaction:

$$K_j = \exp (-\Delta G_T^0 / RT)_j \quad (8)$$

where the superscript o indicates a standard state of one atmosphere. To solve Eq. (8), one must know the Gibbs free energy, G_α^0 , for each species. These are available from analytic fits of tabulated data produced by another code, SALLY. SALLY computes the classical partition function Q from basic molecular and atomic constants, then derives the enthalpy, free energy, etc.* A least-squares technique was used to fit the tabulated enthalpies to a fourth-order polynomial in T . The dimensionless enthalpy for species α is given by

$$\left(\frac{H_T^0 - H_0^0}{RT} \right)_\alpha = A_\alpha + B_\alpha T + C_\alpha T^2 + D_\alpha T^3 + E_\alpha T^4 \quad (9)$$

H_T^0 is the enthalpy at T °K, and one atmosphere. H_0^0 is the enthalpy at 0 °K, one atmosphere. (Stable gas molecules N_2 , O_2 , and A are taken as reference states.) Thermodynamic consistency requires that the following relations hold:

$$-T \frac{d}{dT} \left(\frac{G_T^0 - H_0^0}{RT} \right)_\alpha = \left(\frac{H_T^0 - H_0^0}{RT} \right)_\alpha \quad (10)$$

So we must have, from Eqs. (9) and (10)

$$\begin{aligned} \left(\frac{G_T^0 - H_0^0}{RT} \right)_\alpha &= A_\alpha (1 - \ln T) - B_\alpha T - C_\alpha T^2/2 \\ &\quad - D_\alpha T^3/3 - E_\alpha T^4/4 + k_\alpha \end{aligned} \quad (11)$$

* See any reference on thermodynamics and statistical mechanics, e. g., N. Davidson, Statistical Mechanics, New York, 1962.

The integration constant k_α is determined numerically by comparing the value of the free energy produced by SALLY and the polynomial value, Eq. (11), and finally taking an average k_α over the whole temperature range.

Computer Solution of Composition. With the free energies available, we can calculate the equilibrium constants. We then have five equations with known coefficients in the unknown concentrations; they are listed here as a group:

$$2 C_{N_2} + C_N + C_{NO} = X_N^0 \rho / M \quad (12a)$$

$$2 C_{O_2} + C_O + C_{NO} = X_O^0 \rho / M \quad (12b)$$

$$RT C_N^2 - K_1 C_{N_2} = 0 \quad (12c)$$

$$RT C_O^2 - K_2 C_{O_2} = 0 \quad (12d)$$

$$RT C_N C_O - K_3 C_{NO} = 0 \quad (12e)$$

Solving Eq. (12c) for C_N and substitution in Eq. (12a) gives an equation in C_{N_2} and C_{NO} :

$$2 C_{N_2} + (K_1 C_{N_2} / RT)^{1/2} + C_{NO} = X_N^0 \rho / M \quad (13)$$

It was observed from published data that over a large temperature and density range the ratio of C_{NO} to C_{N_2} is about 0.01. This fact is the basis of the beginning of an iterative solution for the concentrations. If 0.01 C_{N_2} is substituted for C_{NO} in Eq. (13), one is left with an equation in which only C_{N_2} is unknown:

$$2 C_{N_2} + (K_1 C_{N_2} / RT)^{1/2} + 0.01 C_{N_2} = X_N^0 \rho / M$$

After solving the above equation for C_{N_2} , we can solve Eq. (12c) for C_N :

$$C_N = (K_1 C_{N_2} / RT)^{1/2}$$

To solve Eq. (12b) for C_O , Eq. (12d) is used to eliminate C_{O_2} , and Eq. (12e) to eliminate C_{NO} . The result is

$$(2RT/K_2) C_O^2 + [1 + (C_N RT/K_3)] C_O = X_O^0 \rho / M$$

After this is solved for C_O , Eq. (12d) is solved for C_{O_2} :

$$C_{O_2} = (RT/K_2) C_O^2$$

Iteration. To begin the calculation, it is assumed that $C_{NO} = 0.01 C_{N_2}$. (C_{NO} has not been explicitly solved.) It is now calculated from Eq. (12e):

$$C_{NO} = RT C_N C_O / K_3$$

This completes the first iteration. The value just determined for C_{NO} is now used to solve Eq. (12a) again for C_{N_2} . The other concentrations are solved again in the same manner as the first iteration. After a new value for each concentration is obtained, some kind of convergence test must be made.

Convergence of Solution. Several methods were tried to determine the simplest way to test convergence and still ensure that all concentrations had changed less than some relative percent from their previous value. It was noted that C_{N_2} was always the last concentration to converge; hence, the criterion used in that C_{N_2} changed less than 0.1 percent for two successive iterations. Using values less than 0.1 percent did not improve the scheme. A limit of 10 iterations is set, but usually no more than 3 are required.

Thermodynamic Variables

The following variables are of interest.

$$P = RT \sum_{\alpha} C_{\alpha} \quad (14)$$

$$\left(\frac{\partial P}{\partial T}\right)_{\tau} = \frac{P}{T} + RT \sum_{\alpha} \left(\frac{\partial C_{\alpha}}{\partial T}\right)_{\tau} \quad (15)$$

$$\left(\frac{\partial P}{\partial \tau}\right)_T = RT \sum_{\alpha} \left(\frac{\partial C_{\alpha}}{\partial \tau}\right)_T \quad (16)$$

$$E_{sp} = \tau \sum_{\alpha} E_{\alpha}^0 C_{\alpha} \quad (17)$$

$$\left(\frac{\partial E_{sp}}{\partial \tau}\right)_T = \sum_{\alpha} E_{\alpha}^0 C_{\alpha} + \tau \left\{ \sum_{\alpha} E_{\alpha}^0 \left(\frac{\partial C_{\alpha}}{\partial \tau}\right)_T \right\} \quad (18)$$

$$\left(\frac{\partial E_{sp}}{\partial T}\right)_{\tau} = \tau \left[\sum_{\alpha} C_{\alpha} \left(\frac{dE_{\alpha}^0}{dT}\right)_{\tau} + \sum_{\alpha} E_{\alpha}^0 \left(\frac{\partial C_{\alpha}}{\partial T}\right)_{\tau} \right] \quad (19)$$

$$\bar{N} = \frac{\sum_{\alpha} \eta_{\alpha} C_{\alpha}}{\sum_{\alpha} C_{\alpha}} \quad (20)$$

η_{α} is the number of atoms in molecule α .

For $y = T$ or $y = \tau$

$$\frac{\partial \bar{N}}{\partial y} = \frac{\sum_{\alpha} \eta_{\alpha} \frac{\partial C_{\alpha}}{\partial y}}{\sum_{\alpha} C_{\alpha}} - \frac{\left(\sum_{\alpha} \eta_{\alpha} C_{\alpha} \right) \left(\sum_{\alpha} \frac{\eta_{\alpha} C_{\alpha}}{dy} \right)}{\left(\sum_{\alpha} C_{\alpha} \right)^2}$$

E_{sp} is the specific energy in cal/gm. E_{α}^0 is the internal energy of species α for a standard state of one atmosphere. It is a function of T , but not of τ . The dE_{α}^0/dT derivatives are obtained from the fits for the enthalpy in Eq. (9). For a perfect gas

$$\begin{aligned} E_{\alpha}^0 &= H_{\alpha}^0 - RT \\ &= (A_{\alpha} + B_{\alpha} T + C_{\alpha} T^2 + D_{\alpha} T^3 + E_{\alpha} T^4) RT \\ &\quad + H_{0,\alpha}^0 - RT \end{aligned} \quad (21)$$

$$\frac{dE_{\alpha}^0}{dT} = R(A_{\alpha} - 1 + 2B_{\alpha} T + 3C_{\alpha} T^2 + 4D_{\alpha} T^3 + 5E_{\alpha} T^4) \quad (22)$$

Internal Energy for Atoms. AIRMOL is a subroutine of EIONX. The latter calculates all electronic excitation and ionization contributions to the energy. To be consistent with EIONX, AIRMOL must not add in these terms. Thus, for atoms, the energy is simply:*

$$E_{\alpha}^0 = 3 RT/2 + H_{0,\alpha}^0 \quad (23)$$

* An option is available in AIRMOL to include the electronic excitation terms. The third calling parameter would be set negative. This would be done if AIRMOL were coupled with a routine that did not calculate excitation and ionization for molecular species.

$$\frac{dE_{\alpha}^0}{dT} = 3 R/2 \quad (24)$$

Concentration Derivatives. The concentration derivatives are obtained by differentiating the five equations, (12a-e), for C_{α} . If the equations are differentiated with respect to T or τ , the result is five linear equations in $\partial C_{\alpha}/\partial T$ or $\partial C_{\alpha}/\partial \tau$. The coefficients involve the C_{α} , but for a given T and p , the C_{α} have already been calculated. Hence, we have five linear equations in five unknowns with known coefficients:

$$\left. \begin{aligned} 2C'_{N_2} + C'_N + C'_{NO} &= J_1 \\ 2C'_{O_2} + C'_O + C'_{NO} &= J_2 \\ 2C_N RT C'_N - K_1 C'_{N_2} &= J_3 \\ 2C_O RT C'_O - K_2 C'_{O_2} &= J_4 \\ C_O RT C'_N + C_N RT C'_O - K_3 C'_{NO} &= J_5 \end{aligned} \right\} \quad (25)$$

The derivative C'_{α} may be with respect to either T or τ . The quantities J_i are known. If C'_{α} refers to $(\partial C_{\alpha}/\partial T)_{\tau}$, J_i is:

$$J_1 = J_2 = 0$$

$$J_3 = C_{N_2} \frac{dK_1}{dT} - C_N^2 R$$

$$J_4 = C_{O_2} \frac{dK_2}{dT} - C_O^2 R$$

$$J_5 = C_{NO} \frac{dK_3}{dT} - C_N C_O R$$

If C'_α refers to $(\partial C_\alpha / \partial \tau)_T$ then

$$J_3 = J_4 = J_5 = 0$$

$$J_1 = -X_N^0 / M\tau^2$$

$$J_2 = -X_O^0 / M\tau^2$$

The system given by Eq. (25) is solved by using the Gauss-Jordan method, which reduces the coefficient matrix to a triangular matrix.

Special Cases

If T is less than 1200°K or greater than about $25,000^\circ\text{K}$, limiting values may be introduced.

Low Temperature. For T less than 1200°K , the system composition is assumed to be the same as at room temperature. This is assumed valid for $\rho \geq 10^{-10}$ gm/cc. The mole fractions of N_2 , O_2 , and A are constant. The mole fractions of N , O , and NO are zero. \bar{N} is therefore constant; hence, the derivatives of \bar{N} with respect to T or τ are zero. As explained in the next section, the EIONX subroutine calculates the translational contributions to the pressure and energy derivatives. AIRMOL calculates the contributions due to changes in \bar{N} . Therefore, in the low-temperature limit the $(\partial P / \partial \tau)_T$, $(\partial P / \partial T)_\tau$, and $(\partial E_{sp} / \partial \tau)_T$ terms passed on from AIRMOL to EIONX are zero. However, the $(\partial E_{sp} / \partial T)_\tau$ term is not zero, because it contains contributions from terms such as $\partial E_\alpha^0 / \partial T$. It follows from Eq. (19) that

$$\left(\frac{\partial E_{sp}}{\partial T} \right)_\tau = \tau \sum_\alpha C_\alpha \left(\frac{\partial E_\alpha^0}{\partial T} \right)_\tau \quad (26)$$

when $T < 1200^\circ\text{K}$.

High Temperature. The other extreme is to have T so great, or ρ so small, or both, that no molecules are left. Beyond this point the energy due to dissociation is constant. The nontranslational AIRMOL contributions to the derivatives $(\partial E/\partial T)_T$, $(\partial E/\partial \tau)_T$, $(\partial P/\partial T)_T$, and $(\partial P/\partial \tau)_T$ are all zero and $\bar{N} \equiv 1$.

Interface with Other Equation-of-State Subroutines

The SPUTTER code uses a general equation-of-state subroutine, EIONX, which interfaces with molecular equations-of-state as follows:

1. All ionization contributions are calculated by EIONX.
2. All translational contributions are calculated by EIONX.

While the equations written in this report have been given in terms of the temperature T in $^{\circ}\text{K}$, SPUTTER uses θ in eV for a temperature scale.

Also, the reference state for the energy is not the same in AIRMOL and EIONX. The following steps must be taken before any quantities are passed on to EIONX from AIRMOL:

1. All quantities must be converted to a temperature scale of eV, θ .
2. The translational terms must be deleted.
3. A constant ΔE_{ref} must be added to the energy to have consistent reference states. (The value 2.899×10^{11} ergs/gm has been chosen.)

Six quantities are transferred from AIRMOL to EIONX by means of the arrays named CARBNZ and EION, which appear in named common. The quantities, and the cell of the array to which they are made equivalent, are listed here.

EDIS	=	CARBNZ(1)
DEDTAU	=	CARBNZ(3)
DEDTHT	=	CARBNZ(4)
DPDTAU	=	CARBNZ(5)
DPDTHT	=	CARBNZ(6)
NBAR	=	EION(17)

The above quantities are defined as follows:

$$EDIS = E_{sp} \left(\frac{\text{erg}}{\text{gm}} \right) - \frac{3}{2} \frac{\phi\theta}{N} + \Delta E_{\text{ref}}$$

$$DED\tau = (\partial E_{sp} / \partial \tau)_{\theta}$$

$$DED\theta = (\partial E_{sp} / \partial \theta)_{\tau} - \frac{3}{2} \frac{\phi}{N}$$

$$DPD\theta = (\partial P / \partial \theta)_{\tau} - \frac{P}{\theta}$$

$$DPD\tau = (\partial P / \partial \tau)_{\theta} - \frac{P}{\tau}$$

$$NBAR = \bar{N} = \frac{\sum_{\alpha} \eta_{\alpha} C_{\alpha}}{\sum_{\alpha} C_{\alpha}}$$

Coefficients for Least-Squares Fits

The dimensionless enthalpy $[(H_{\alpha}^{\circ} - H_{0\alpha}^{\circ})/RT]$ for each species was calculated by the SALLY code as a function of T . The data were then fit to a fourth-order polynomial in T by the NOLOUT code, which uses a least-square technique.

$$\left(\frac{H_{\alpha}^{\circ} - H_{0\alpha}^{\circ}}{RT} \right) = A_{\alpha} + B_{\alpha} T + C_{\alpha} T^2 + D_{\alpha} T^3 + E_{\alpha} T^4$$

Table III gives the coefficients in the above equation for the various species. Also listed are the integration constants k_{α} and k'_{α} , needed for the analytic expression, Eq. (11), for the Gibbs free energies. The term k_{α} is used if $(H_{\alpha}^{\circ} - H_{0\alpha}^{\circ})/RT = 5/2$ for the atomic species, while k'_{α} is used if the full polynomial expression is used.

TABLE III
COEFFICIENTS FOR VARIOUS SPECIES

Coefficients						
A_α	B_α	C_α	D_α	E_α	k_α	k'_α
N ₂ 3.39032	3.26691-4	-4.43869-8	2.84212-12	-5.61017-17	3.47421	---
O ₂ 3.48754	3.33691-4	-3.26154-8	1.78842-12	-3.45129-17	4.63168	---
NO 3.62986	2.39195-4	-2.68348-8	1.46612-12	-2.68536-17	4.44607	---
N 2.54395	-7.03288-5	2.10493-8	-1.23848-12	2.27227-17	3.99389	4.48452
O 2.66918	-6.76606-5	1.16238-8	-6.49696-13	1.25238-17	4.12663	5.26387
A 2.49716	2.06980-6	-2.90268-10	-2.16444-18	1.16325-18	4.37850	4.37217

Variables Used in AIRMOL

A(6)	Polynomial coefficients for enthalpy
Al	Total number of N atoms (in mole/cc) at any temperature and pressure
B(6)	Polynomial coefficients for enthalpy
BARK(6)	Integration constants for free energy if enthalpy is polynomial
BARK2(6)	Integration constants for free energy if enthalpy is $5RT/2$
C(6)	Polynomial coefficients for enthalpy
CON(6)	Concentrations, moles/cc
D(6)	Polynomial coefficients for enthalpy
DCDT(6)	$(\partial C_{\alpha} / \partial T)_T$
DEDT(6)	dE_{α}^0 / dT
DEDTAU	$(\partial E_{sp} / \partial \tau)_{\theta}$
DEDTHT	$(\partial E_{sp} / \partial \theta)_{\tau} - \rho \phi / N$
DELH(6)	$H_{0,\alpha}^0$, enthalpies at one atmosphere, $0^{\circ}K$
DGDT(6)	dG_{α}^0 / dT
DKP1DT	dK_1 / dT
DKP2DT	dK_2 / dT
DKP3DT	dK_3 / dT
DNDT	$(\partial \bar{N} / \partial T)_{\tau}$
DPDTAU	$(\partial P / \partial \tau)_{\theta} - P / \tau$
DPDTHT	$(\partial P / \partial \theta)_{\tau} - P / \theta$
E(6)	Polynomial coefficients for enthalpy
EDIS	$E_{sp} - \frac{3}{2} \phi \theta / \bar{N}$, total specific energy due to dissociation
ENERGY	Total specific energy, erg/gm
ESPECZ(6)	Internal energies at $T^{\circ}K$, one atmosphere, cal/mole
EZ	Total dimensionless energy, E / RT
FRENRG(6)	G_{α}^0 / RT , dimensionless Gibbs free energies
HSPECZ(6)	Enthalpies at $T^{\circ}K$, one atmosphere, cal/mole

KP1	Equilibrium constant in pressure units for $N_2 \rightleftharpoons 2N$
KP2	Equilibrium constant for $O_2 \rightleftharpoons 2O$
KP3	Equilibrium constant for $NO \rightleftharpoons N + O$
MARK	Third calling parameter for AIRMOL: if negative, include electronic excitation for atoms; if positive, no electronic excitation; if 0, like positive, and also print debug quantities in AIRMOL
MOFRCT(6)	Mole fractions
NBAR	Mean number of atoms per molecule in gas mixture
NITER	Iteration counter
OLDX(6)	Concentrations from preceding iteration
PHI	Gas constant (SPUTTER units), $9.649E11/WTREF$
PO	Total pressure, atmospheres
PRESHR	Total pressure, dyne/cm ²
RHO	Density, gm/cc
RH1-RH5	Right-hand side of equations for derivatives of concentrations
RTKEL	RT , with $R = 1.98726 \text{ cal/mole-}^\circ K$
R2TKEL	$R_2 T$, with $R_2 = 82.054 \text{ cc-atm/(mole-}^\circ K)$
RT2	$(R_2 T)^2$
SCDE	$\sum_{\alpha} (dE_{\alpha}^0/dT) C_{\alpha}$
SCE	$\sum_{\alpha} (\partial C_{\alpha} / \partial T)_{\tau}$
SDTAU	$\sum_{\alpha} (\partial C_{\alpha} / \partial \tau)_T$
SNC	$\sum_{\alpha} \eta_{\alpha} C_{\alpha}$ where η_{α} is number of atoms per molecule; total number of atoms/cc
SNDTAU	$\sum_{\alpha} \eta_{\alpha} (\partial C_{\alpha} / \partial \tau)_T$
SUMCON	$\sum_{\alpha} C_{\alpha}$
SUMNRG	Total energy, cal/cc, $\sum_{\alpha} C_{\alpha} E_{\alpha}^0$

TAU	Specific volume, cc/gm
THETA	Temperature in eV
TKEL	Temperature in $^{\circ}\text{K}$
TKELN	$\ln T$, natural log
V1, V2, V3	$\Delta G_T^0/RT$ for the reactions (1) $\text{N}_2 \rightleftharpoons 2\text{N}$; (2) $\text{O}_2 \rightleftharpoons 2\text{O}$, and (3) $\text{NO} \rightleftharpoons \text{N} + \text{O}$ respectively
WTREF	Mean atomic weight of air, about 14.55 gm/mole
XREFA	Mole fraction of argon atoms at STP, divided by mean atomic weight of air
XREFN	Mole fraction of nitrogen atoms at STP, divided by mean atomic weight of air
XREFO	Mole fraction of oxygen atoms at STP, divided by mean atomic weight of air

GOLEM: A TOOL TO STUDY EQUATION-OF-STATE AND OPACITY SUBROUTINES

The GOLEM code was developed to study the data computed by the equation-of-state and opacity subroutines (used in SPUTTER, MOTET, and other radiation-transport and hydrodynamic codes) that use temperature θ and density ρ (or specific volume $\tau \equiv 1/\rho$) as independent variables.

GOLEM is an edit control code.

The GOLEM code input requirements are extremely simple. The sole input card format required is as follows:

AFWL-TR-67-131, Vol IV

```

SUBROUTINE GULEM
C ELL GULEM/S0905,100/0905, 36292
SUBROUTINE GULEM
C ** LOAD KONTRL DECK FOR (MOLECULAR EQUATIONS OF STATE, ETC) PARAMETERS **
C ** LOAD KONTRL DECK FOR (MOLECULAR EQUATIONS OF STATE, ETC) PARAMETERS **
C ** LOAD KONTRL DECK FOR (MOLECULAR EQUATIONS OF STATE, ETC) PARAMETERS **
C ** LOAD KONTRL DECK FOR (MOLECULAR EQUATIONS OF STATE, ETC) PARAMETERS **
C ** LOAD KONTRL DECK FOR (MOLECULAR EQUATIONS OF STATE, ETC) PARAMETERS **
C THIS ROUTINE USABLE FOR TABULATION OF THERMODYNAMIC QUANTITIES
C.....
C
C          S P O T T E R   C O M M O N
C
C
COMMON LMDA(37), NK , NSMLR , IA , IB , ICA , ICB ,
1 KMAX , BLANK1, BLANK2, BLANK3, IAP1 , IBP1 , ICAP1 , ICBP1 ,
2 I1 , I2 , I3 , I4 , I5 , I6 , I7 , I8 , I9 , I10 , I11 , I12 , I13 , I14 , I15 , I16 , I17 , I18 , I19 , I20 , I21 , I22 , I23 , I24 , I25 , I26 , I27 , I28 , I29 , I30 , I31 , I32 , I33 , I34 , I35 , I36 , I37 ,
3 I1P1 , I1M1 , I1ALPHA, BLANK5, I1H , I1MAX , BLANK6, DELPH1 ,
4 FREQ , CNIMAX, AK , ASMLR , POSHA , POSHM , BOILA , BOILB ,
5 CVA , CVD , SLOG , ALPHA , IVA , IVB , HCA , HCB ,
6 EMINA , EMINB , CA , CB , GA , GB , GL , GR ,
7 KHOL , KHOK , EP10 , EPS1 , KIA , KIB , KUIA , KUIB ,
8 KPIA , KPIB , KPDIA , KPDIB , IPRINI, IA , IB , IC ,
COMMON I1 , I2 , I3 , I4 , I5 , I6 , I7 , I8 , I9 , I10 , I11 , I12 , I13 , I14 , I15 , I16 , I17 , I18 , I19 , I20 , I21 , I22 , I23 , I24 , I25 , I26 , I27 , I28 , I29 , I30 , I31 , I32 , I33 , I34 , I35 , I36 , I37 ,
1 DIMAX1, DIMAX2, DIMAX3, DTK , SWITCH, CO , CMIN , DELTA ,
2 GAMMA , WCH1 , SIGMA9, AC , ACUST4, CNVRI , SUMRA , SUMRB ,
3 KUIA , KUIAM1, KUIB , KUIBP1, GMS , S1 , S2 , S3 ,
4 S4 , S5 , S6 , S7 , S8 , S9 , S10 , S11 ,
5 S12 , S13 , S14 , S15 , S16 , S17 , S18 , S19 ,
6 S20 , EU , FU , IAU , ZERU , H (152), DELTA(152),
7 ASU (152), RU (152), VD (152), RUU (152), SMLR (152),
8 DELR (152), P (152), P1 (152), PH (152), PB1 (152),
COMMON P2 (152), SV (152), KHU (152), THETA (152),
1 W (152), E (152), EI (152), EK (152), X (152),
2 V (152), G (152), U (152), C (152), X2 (152),
3 X3 (152), X4 (152), X5 (152), X6 (152), X7 (152),
4 SMLA (152), SMLB (152), SMLC (152), SMLU (152), SMLE (152),
5 EC (152), EK (152), SMLG (152), SMLH (152), HIGA (152),
6 BIGB (152), CV (152), BC (152), HK (152), CHIC (152),
7 CHIK (152), CAPAL (152), CAPAH (152), CRIC (152), CHTR (152),
8 CRIPL (152), GOFK (152), FEW (152), CAK (152), UKLM (152),
COMMON TELM (152), EKLM (152), ELM (152), FCLM (152),
1 FRLM (152), WLM (152), QLM (152), AMASNO(152), CHHNO (152),
2 ZP1 (152), ZP2 (152), SOL10 (152), ECHK (152), KK (152),
3 KL (152), KHOK (152), KOK (152), IMELAK(152), TEMP (152),
4 HEAD (152), MAXL , MAXLM
C
C
C.....
COMMON/CIA/GOLUO(12240)
COMMON/LMS/ EION(20)
EQUIVALENCE(ZBAR,EION(3))
EQUIVALENCE (EION(5),PHI), (EION(16),ZMEAN)
EQUIVALENCE (EION(15), NSUBE)
REAL LNGAMA
REAL NSUBE

```

AFWL-TR-67-131, Vol IV

```

COMMON/TATESA/EUSPAK(50)
COMMON/LMSH/POTENL(5350)
DIMENSION H(3)
EQUIVALENCE (POTENL(1),H(1))
C      LOAD ENTIRE POTENTIAL TABLE
COMMON/LMSC/M(51)
DIMENSION Z(51),PART(51)
EQUIVALENCE (M(1),NOLM(1), (M(2),Z(2)), (M(3),PART(3))
COMMON/LMSU/      TLMS(30)
EQUIVALENCE (TLMS(1),BACK1), (TLMS(2),BACK2), (TLMS(7),ZBACKN)
EQUIVALENCE (DPDIAU,EION(12)), (DPDHT,EION(13)), (NHAK,EION(17)),
2      (TLMS(15),UZDIAU), (TLMS(16),UZDHT)
COMMON/LMSE/MATERL,ILEMNI,SNAPU,11,12,13,14,15,16,17,18,19,110,J1,      0800
2 J2,J3,J4,J5,J6,J/
EQUIVALENCE (SNAPU,PATH)
EQUIVALENCE (110,M2)
COMMON/LMSEN/ILMSH(15)
COMMON/LMSG/CARBNZ(10)
DIMENSION AIR(10)
EQUIVALENCE (AIR(1),CARBNZ(1))
COMMON/CNTRL/CYCLE,JMULI
COMMON/EOSIN/EIONIN(30)
EQUIVALENCE (MARK,EIONIN(28))
COMMON/GOLEMA/THATA(250),KHIA(250)
DIMENSION ROW(1)
DIMENSION WORD(8)
EQUIVALENCE (DELKMO, DELIAU)
COMMON/LNES//EIA
COMMON/LMSJ/MATREL(11,3/)
REAL MATREL
DATA MARKER/1/,IPRNTD/U/,EION(1),SUMPTS,XNPTS,OLUWAY,OKLM(1)/5*0./
DATA ALEX/1.E-4/
C
C
WRITE(6,7000)
WRITE(6,7001)
WRITE(6,7002)
WRITE(6,7003)
WRITE(6,7004)
WRITE(6,7005)
WRITE(6,7006)
WRITE(6,7007)
WRITE(6,7008)
WRITE(6,7009)
WRITE(6,7010)
WRITE(6,7011)
WRITE(6,7012)
WRITE(6,7013)
MAXPOT = EUSPAK(2)
WRITE(6,712)
WRITE(6,7016) (POTENL(K), K=1,MAXPOT)
WRITE(6,765)
DO 777 N=1,37
N100=      N + 100
WRITE(6,764) N100, (MATREL(L,N), L=1,11)

```

//// CONTINUE

38

AFWL-TR-67-131, Vol IV

```

      IF ((IPNCHU.EQ.2.OR.IPNCHU.EQ.3).AND.TRAIL.EQ.11.) PUNCH 7704
      IF ((IPNCHU.EQ.3.OR.IPNCHU.EQ.4).AND.TRAIL.EQ.11.) PUNCH 7707
      IF ((EUSPAR(37).NE.U.).AND.(IPNCHU.NE.1)) PUNCH 7705
      IF ((OKLM(1).EQ.0.).OR.(OKLM(1).EQ.306.)) PUNCH 7706
      IF (MUTE1.EQ.1) PUNCH 7720
1599 CONTINUE
      XNPIS = U.
C
      IF (ABS(OKLM(1) + .4) .LT. ALEX) GO TO 10
      IF (ABS(OKLM(1) + .41) .LT. ALEX) GO TO 41
      IF (ABS(OKLM(1) + .43) .LT. ALEX) GO TO 43
      IF (ABS(OKLM(1) + .44) .LT. ALEX) GO TO 44
      IF (ABS(OKLM(1) + .45) .LT. ALEX) GO TO 45
      IF (ABS(OKLM(1) + .48) .LT. ALEX) GO TO 48
      GO TO 42
C .....
C      THE FOLLOWING CARDS ARE ALL
C      READ WITH 10EB.3 FORMATS
C      (INCLUSIVE BOUNDARIES ARE
C      WORD N STARTS AT BIN-1)+1
C      AND ENDS AT BN )
41 CONTINUE
      READ (5,751) (EUSPAR(K), K=1,10)
      GO TO 10
43 CONTINUE
      READ (5,751) (EUSPAR(K), K=11,20)
      GO TO 10
44 CONTINUE
      READ (5,751) (EUSPAR(K), K=21,30)
      GO TO 10
45 CONTINUE
      READ (5,751) (EUSPAR(K), K=31,40)
      GO TO 10
48 CONTINUE
      READ (5,751) (EUSPAR(K), K=41,50)
      GO TO 10
42 CONTINUE
      IF (TEST.NE.U.) GO TO 102
      IF ((IPRNTU.NE.2 .AND. IPRNTU.NE.3) WRITE(6,7014) (EUSPAR(K),
1      K=1,50)
C
      KIA = EUSPAR(1)
      ECHCK(18) = EUSPAR(5)
      DO 46 I=1,11
      EIONIN(I) = EUSPAR(1+5)
46 CONTINUE
C      EUSPAR(17) CONTROLS FASTER, THE CMOL CALL SEQUENCE PARAMETER.
      EIONIN(28) = EUSPAR(17)
      EIONIN(29) = EUSPAR(18)
      EIONIN(30) = EUSPAR(19)
      M2 = EUSPAR(20)
      KP1A = EUSPAR(21)
      IF (KP1A .EQ. U.) WRITE(6,7015)
C      KP1A = U IF INCLUDE BLACK-BODY RADIATION CONTRIBUTION
C      IN SUBROUTINE EOS

```

```

PUSH=      EOSPAR(22)
MAXLM=     EOSPAR(23)+.5
LMUA(2)=   EOSPAR(24)+.5
SOLID(18)= EOSPAR(25)
SCTCLE=    EOSPAR(26)
NH=        EOSPAR(27)+.5
IAM1=      EOSPAR(28)+.5
IB=        EOSPAR(29)+.5
CVA=       EOSPAR(30)
SOLID(17)= EOSPAR(31)
HIB=       EOSPAR(32)
MVA=       EOSPAR(33)
HCA=       EOSPAR(34)
AMASHO(1)= EOSPAR(35)
CHRNA(1)=  EOSPAR(38)
OKLM(18)=  EOSPAR(39)
CMIN =     EOSPAR(40)
LMUA(1) =  EOSPAR(41) + .5
MAXL =     EOSPAR(42) + .5
SZ=        EOSPAR(43)
MOXI =     OKLM(1)+.5
IF (MOXI.EQ. 102) MARK=EOSPAR(44)+.5
EOSPAR(44) CONTROLS MARK, THE AIRMOL CALL SEQUENCE PARAMETER.

SET EOSPAR(37).NE. 0. TO CALL KAPPA
IF KAPPA IS TO BE CALLED, FIRST CALL EIONX TO GET PHI AND ZMEAN
IF (EOSPAR(37).EQ. 0.) GO TO 47
CALL EIONX(1., 1., MOXI, -1.)
AMASHO(1)=  PHI
CHRNA(1)=   ZMEAN

ZP1(1)=     CHRNA(1)*(-1.3333333)
ZP2(1)=     CHRNA(1)*(2.3333333)
47 CONTINUE
WRITE ( 6, 712)
TIMEA = 0.
FEW(1)=     0.
NSUHE=      0.
EGAM3=      0.
ZUAR = 0.
TLMS(10)=   0.
EIONIZ = 0.
GAMMA=      0.
LNGAMA = 0.
IF (IPRNTD.NE.3 .AND. IPRNTD.NE.2) GO TO 4
ASSIGN 4 TO LRN
GO TO 5
4 IPRNTD = IPRNTU
SET IPRNTD = IPRNTD TO AVOID IPRNTD WIPE-OUT BY LAST DATA CARD

OLDWAY = TRAIL
LTRAIL = TRAIL + 1.5
GO TO (13,13,15,15,15,15,13,13,15,13,13,13,13,13,15,13), LTRAIL
15 CONTINUE

```


AFWL-TR-67-131, Vol IV

```

      IF (ROW(1).EQ.0.) ROW(1)=1./SV(1)
      IF (SV(1).EQ.0.) SV(1)=1./ROW(1)
13  CONTINUE
      WRITE(6,705) OKLM(1),TRAIL,IPRHO,IPNCHO,J,THETA(1),ROW(1),SV(1)
C
C ***** TRAIL OPTIONS *****
C TRAIL = 0.  NORMAL GRID OF TEMPERATURE-DENSITY POINTS
C TRAIL = 1.  SPECIAL ZMEAN PATH
C TRAIL = 2.  PERFECT GAS AND READ ONE CARD PER POINT
C TRAIL = 3.  READ ONE CARD PER POINT
C TRAIL = 4.  COMPUTE (THETA, TAU) RECTANGLE AROUND CENTRAL POINT
C TRAIL = 5.  NORMAL GRID OF SELECTED TEMPERATURE-DENSITY POINTS
C TRAIL = 6.  MOLECULAR EQUATION OF STATE CHECKOUT SET
C TRAIL = 7.  COMPUTE (THETA, RHO) RECTANGLE AROUND CENTRAL POINT
C TRAIL = 8.  GRID OF TEMPERATURE-LOW DENSITY I.E. .01 POINTS
C TRAIL = 9.  GRID OF TEMPERATURE-HIGH DENSITY I.E. .01 POINTS
C TRAIL = 10. GRID OF DENSITIES-LOW TEMPERATURE I.E. 10 E.V.)
C TRAIL = 11. READ DIAPHRAGM DATA CARD
C TRAIL = 12. READ GILMORE DATA CARD (SEE TRAIL=11 PATH, COMMENTS)
C TRAIL = 13. READ HILSENKATH DATA CARD (SEE TRAIL=11 PATH, COMMENTS)
C TRAIL = 14. NORMAL TEMPERATURE SET AT ONE SELECTED DENSITY
C TRAIL = 15. NORMAL DENSITY SET AT ONE SELECTED TEMPERATURE
C
C *****
C
C
C
      IF (TRAIL .EQ. 2.) OKLM(1) = -OKLM(1)
      IF (TRAIL .EQ. 1.) GO TO 12
      IF (MOXIE .NE. 207) GO TO 6601
      READ (5,751) SOLID,OKLM(2)
      WRITE (6,729) SOLID
      WRITE (6,733) OKLM(2)
      PUNCH 7722
      OKLM(1) = OKLM(2)
6601 CONTINUE
      IF (TRAIL .EQ. 0. .OR. TRAIL .EQ. 8. .OR. TRAIL .EQ. 9. .OR. TRAIL
2    .EQ. 5. .OR. TRAIL .EQ. 10. .OR. TRAIL .EQ. 14.) GO TO 500
      IF (TRAIL .EQ. 15.) GO TO 500
      IF (TRAIL .EQ. 4.) GO TO 200
      IF (TRAIL .EQ. 6.) GO TO 400
      IF (TRAIL .EQ. 7.) GO TO 600
      IF (TRAIL .GE. 11. .AND. TRAIL .LE. 13.) GO TO 100
C
C
C
      1 CONTINUE
      WRITE(6,718)
C TRAIL = 2.  PERFECT GAS AND READ ONE CARD PER POINT
C TRAIL = 3.  READ ONE CARD PER POINT
      ASSIGN 14 TO LREIN
      GO TO 6500.
14 CONTINUE
      GO TO 10
C
11 CONTINUE

```

AFWL-TR-67-131, Vol IV

```

C      NORMAL EXIT POINT
      IF (OLDWAY.EQ.1..OR.OLDWAY.EQ.2..OR.OLDWAY.EQ.3.) GO TO 17
      TIMEC = TIMEA/XNPIS
      TIMEB = (TIME3 - TIME1) * 16.666667
      TIMEB = TIMEB/SUMPTS
      ASSIGN 2 TO LRN
      IF (IPRNTD.NE.2 .AND. IPRNTD.NE.3) GO TO 2
5      CONTINUE
      MAKER = 1
      WRITE (6,7014) (EOSPAR(K), K=1,50)
      WRITE (6,7020) MOXIE
      IF (MOXIE.LT.101 .OR. MOXIE.GT.200) GO TO 7776
      ICD1 = MOXIE - 100
      ICD2 = 2 * IFIX(MATHEL(1,ICD1) * .5) + 1
      WRITE (6,7023) (MATHEL(ICD1,ICD2), ICD2=2,ICD2)
7776    CONTINUE
      WRITE (6,7024) ZMEAN, PHI, TLMS(3), ECHCK(18)
      DO 3 J = 1,11628,612
      L = J + 611
      IF (IPRNTD.EQ.2) GO TO 6
      WRITE (6,7021) (GOLOUT(I), I=J,L)
      GO TO 7
6      WRITE (6,7022) (GOLOUT(I), I=J,L)
7      CONTINUE
      IF (GOLOUT(L+1).EQ.0.) GO TO 21
3      CONTINUE
21     CONTINUE
      WRITE (6,712)
      GO TO LRN,(2,4)
2      CONTINUE

C
C      TIMEA = (TIME3 - TIME2) * 16.666667, SUM OF TIMES USED DURING CALLS
C      TO EOS.
C      TIMEB = (TIME3 - TIME1) * 16.666667, TOTAL TIME (IN MILLISECONDS)
C      BETWEEN START OF RUN AND LAST CALL TO EOS FOR THE LAST INPUT
C      CARD.
C      TIMEC = TIMEA/XNPIS, WHERE XNPIS IS THE TOTAL NUMBER OF THETA-RHO
C      POINTS FROM THE LAST INPUT CARD.
C      TIMEB = TIMEB/SUMPTS, WHERE SUMPTS IS THE TOTAL NUMBER OF POINTS
C      IN THE ENTIRE GOLEM RUN.
C      ALL TIMES PRINTED ARE IN MILLISECONDS
C
      WRITE (6,7025)
      WRITE (6,7026) TIME1, TIMEA, TIME2, TIMEB, TIME3, TIMEC, XNPIS,
1      TIMEB, SUMPTS
C
C      17 CONTINUE
C      CALL EXIT
C      RETURN
C
C
C      12 CONTINUE
C      TRAIL = 1. SPECIAL ZMEAN PATH
      WRITE (6,720)
      IDIOT = OKLM(1) * .5

```

AFWL-TR-67-131, Vol IV

```

      CALL EIONX (1.,1.,IDIO),-1.)
      WRITE(6,701) OKLM(1),ZMEAN,PHI,TLMS(3)
      GO TO 10
C
16 CONTINUE
      WRITE(6,753)
      CALL EXIT
      RETURN
C
100 CONTINUE
C
C      TRAIL = 11. READ DIAPHANOUS DATA CARD
C      DIAPHANOUS DATA IS
C      WORD(1) = THETA OR RHU      WORD(2) = PRESSURE
C      WORD(3) = ENERGY          WORD(4) = EION
C      EION IS THE DIAPHANOUS NAME FOR EIONIZ
C      WORD(5) = KRUS              WORD(6) = KPLK
C      WORD(7) = ZBAR              WORD(8) = EGAM
C      TRAIL = 12. READ GILMORE DATA CARD (SEE TRAIL=11 PATH, COMMENTS)
C      GILMORE DATA HAS WORD(1), AND WORD(3) AS IN DIAPHANOUS, AND
C      WORD(2) = P (DYNES/CM2) AND WORDS(4) THRU (8)
C      ARE NOT USED.
C      TRAIL = 13. READ HILSENATH DATA CARD(SEE TRAIL=11 PATH,COMMENTS)
C      HILSENATH DATA HAS WORD(1) = T (DEG. KELVIN) OR
C      LOG(RHU/REFERENCE-RHU). (WHERE REFERENCE-RHU IS WORD(2)
C      ON CARD WITH T IN WORD(1))
C      WORD(2) = REFERENCE RHU (G/CC) OR P (ATMOSPHERES)
C      WORD(3) = E/RT
C      WORDS (4), (5), AND (6) ARE NOT USED
C      WORD(7) = 1.991 * (1.+ZBAR)
C      WORD(8) IS NOT USED
C
      READ(5,730) (HEAD(I), I=1,12)
      WRITE(6,732) (HEAD(I), I=1,12)
      HELPRS = 0.
      HELENG = 0.
      HELE2 = 0.
      HELZER = 0.
      HELION = 0.
102 READ(5,734) (WORD(I), I=1,8)
      IF(WORD(3) .NE. 0.) GO TO 104
C      IF WORD(1) .EQ. -.4, END INPUT AND GO TO NEXT TRAIL CARD.
C      TO END DIAPHANOUS SET, USE CARD PUNCHED WITH -.40 IN COLUMNS 1-4.
C      IF A BLANK CARD FOLLOWS DIAPHANOUS CARD, PROGRAM GOES INTO EXIT
      IF (ABS(WORD(1) + .4) .LT. ALEX) GO TO 103
      IF(WORD(1) .EQ. 0.) GO TO 11
      IF(THETA(1) .NE. WORD(1)) WRITE(6,712)
      IF(TRAIL .LE. 12.) THETA(1) = WORD(1)
      IF(TRAIL .EQ. 13.) THETA(1) = WORD(1)/1.16054E4
      IF(TRAIL .EQ. 13.) REFRHU = WORD(2)
      GO TO 102
103 TIMEC = TIMEA/XNPIS
      WRITE (6,700) TIMEC, TIMEA, XNPIS
C      TIMEC UNITS ARE MILLISECOND PER COMPUTATIONAL POINT.
      GO TO 10

```

AFWL-TR-67-131, Vol IV

```

104 CONTINUE
    IF (KAIL .EQ. 12.) ROW(1) = WORD(1)
    IF (KAIL .EQ. 13.) ROW(1) = EXP(WORD(1)*2.3025851) * REFRMU
    SV(1) = 1./ROW(1)
    IF (OKLM(1) .EQ. 0. .OR. OKLM(1) .EQ. 306.) .AND. ROW(1) .GT. 10.
    1 .AND. KIA .NE. 0.) GO TO 102
    IF (KAIL .EQ. 13.) WORD(2) = WORD(2)*1.01325
    IF (KAIL .NE. 13.) GO TO 108
    WORD(1) = WORD(1)/1.491 - 1.0
    WORD(3) = WORD(3) * THETA(1) * 3.3312097E10
108 CONTINUE
    IF (KAIL .NE. 12.) WORD(2) = WORD(2) * 1.E6
    IF (KAIL .EQ. 11.) WRITE(6,735)
    IF (KAIL .EQ. 12.) WRITE(6,736)
    IF (KAIL .EQ. 13.) WRITE(6,737)
    WRITE(6,738) THE(1), ROW(1), (WORD(1), 1=2,8)
    WRITE(6,739)
    ASSIGN 115 TO LKRN
    GO TO 6500
115 CONTINUE
    IF (EIONIZ .NE. 0.) RELION = 1.E2 * (WORD(4)-EIONIZ)/WORD(4)
    RELPHS = (WORD(2)-P1(1))/WORD(2)*1.E2
    RELENG = (WORD(3)-E(1))/WORD(3)*1.E2
    RELEZ = (WORD(3)-L(1)+ECHK(18))/WORD(3) * 1.E2
    IF (WORD(7) .NE. 0.) RELZBR = (WORD(7)-FEW(1))/WORD(7)*1.E2
    WRITE(6,740) RELPHS, RELENG, RELZBR, RELEZ, RELION
    GAMMA = 0.
    LGGAMA = 0.
    GO TO 102
C
200 CONTINUE
C   TRAIL = 4.   COMPUTE (THETA, TAU) RECTANGLE AROUND CENTRAL POINT
    WRITE(6,722)
    WRITE(6,716) DELTHT, DELTAU
    SAVTAU = SV(1)
    SAVHT = (THETA(1)
    THETA(1) = SAVHT - 5.0 * DELTHT
    TIMEA = 0.
    DO 220 N1=1,11
    SV(1) = SAVTAU - 5.0 * DELTAU
    IF (IPKNTU.NE.2 .AND. IPKNTU.NE.3) WRITE(6,712)
    DO 210 N2=1,11
    ROW(1) = 1./SV(1)
    ASSIGN 205 TO LKRN
    GO TO 6500
205 CONTINUE
    SV(1) = SV(1) + DELTAU
210 CONTINUE
    THETA(1) = THETA(1) + DELTHT
220 CONTINUE
    TIMEC = TIMEA/XNPTS
    WRITE (6,700) TIMEC, TIMEA, XNPTS
    GO TO 10
C
400 CONTINUE

```

```

C      TRAIL = 6.  MOLECULAR EQUATION OF STATE CHECKOUT SET
      WRITE(6,724)
      TIMEA = 0.
      DO 420 I=1,60
      FI = 1
      THETA(1) = FI*.E2/1.16054E4
      IF (IPRNT0.NE.2 .AND. IPRNT0.NE.3) WRITE(6,712)
      DO 420 J=1,12
      JJ = 11-J
      SV(1) = 10.**JJ
      ROW(1) = 1./SV(1)
      ASSIGN 410 TO LKRN
      GO TO 6500
410  CONTINUE
420  CONTINUE
      TIMEC = TIMEA/XNPIS
      WRITE (6,700) TIMEC, TIMEA, XNPIS
      GO TO 10

C
500  CONTINUE
C      TRAIL = 0.  NORMAL GRID OF TEMPERATURE-DENSITY POINTS
C      TRAIL = 5.  NORMAL GRID OF SELECTED TEMPERATURE-DENSITY POINTS
C      TRAIL = 8.  GRID OF TEMPERATURE-LOW DENSITY (.LE. .1) POINTS
C      TRAIL = 9.  GRID OF TEMPERATURE-HIGH DENSITY (.GE. .01) POINTS
C      TRAIL = 10. GRID OF DENSITIES-LOW TEMPERATURE (.LE. 10 E.V.)
C      TRAIL = 14. NORMAL TEMPERATURE SET AT ONE SELECTED DENSITY
C      TRAIL = 15. NORMAL DENSITY SET AT ONE SELECTED TEMPERATURE
      IF (TRAIL .EQ. 0.) WRITE(6,726)
      IF (TRAIL .EQ. 5.) GO TO 502
      IF (TRAIL .EQ. 8.) WRITE(6,708)
      IF (TRAIL .EQ. 9.) WRITE(6,709)
      IF (TRAIL .EQ. 10.) WRITE(6,710)
      IF (TRAIL .EQ. 14.) WRITE(6,719)
      IF (TRAIL.EQ.15.) WRITE(6,725)
      GO TO 504
502  CONTINUE
      WRITE(6,746) THETA(1),DELTHI,ROW(1),DELTAU
      THETLO = THETA(1)
      THETHI = DELTHI
      RHLO = ROW(1)
      RHUHI = DELTAU
504  CONTINUE
      WRITE(6,742) THATA
      WRITE(6,707)
      WRITE(6,744) RHA
      TIMEA = 0.
      WRITE (6,712)
      DO 530 I=1,250
      IF (THATA(1) .EQ. 0.) GO TO 540
      IF (TRAIL .EQ. 5. .AND. (THATA(1) .GT. THETHI .OR. THATA(1) .LT.
2    THETLO)) GO TO 530
      IF (TRAIL .EQ. 10. .AND. THATA(1) .GT. 10.) GO TO 540
      IF (TRAIL.NE.15.) THETA(1) = THATA(1)
      IF ((TRAIL.NE.14.) .AND. (IPRNT0.NE.3) .AND. (IPRNT0.NE.2))
1    WRITE (6,712)

```

AFWL-TR-67-131, Vol IV

```

      IF(MOTE1.EQ.1) WRITE(6,760)
      IF(MOTE1.EQ.1.AND.HPIA.NE.U.) WRITE(6,763)
      DO 520 J=1,250
      IF(RHA(J).EQ.0.0) GO TO 525
      IF((TRAIL.EQ.5. .AND.(RHA(J).GT. RHUMI .OR. RHA(J).LT.
2    RHOLU)) GO TO 520
      IF((TRAIL.EQ.8. .AND. RHA(J).GT. 1.E-1) GO TO 520
      IF((TRAIL.EQ.9. .AND. RHA(J).LT. 1.E-2) GO TO 530
      IF((TRAIL.NE.14.) ROW(1) = RHA(J)
      SV(1) = 1./ROW(1)
      ASSIGN 510 TO LKRN
      GO TO 6500
510 CONTINUE
      IF((TRAIL.EQ.14.) GO TO 530
520 CONTINUE
525 CONTINUE
      IF((TRAIL.EQ.15.) GO TO 540
530 CONTINUE
540 CONTINUE
      TIMEC = TIMEA/XNPTS
      WRITE (6,700) TIMEC, TIMEA, XNPTS
      GO TO 10
C
600 CONTINUE
C   TRAIL = 7    COMPUTE (THETA, RHO) RECTANGLE AROUND CENTRAL POINT
      WRITE(6,722)
      WRITE(6,717) DELTHI, DELRHO
      SAVRHO = ROW(1)
      SAVTHI = THETA(1)
      THETA(1) = SAVTHI - 5.0 * DELTHI
      TIMEA = 0.
      DO 620 NI=1,11
      ROW(1) = SAVRHO/(DELRHO**5)
      IF (IPRNT0.NE.2 .AND. IPRNT0.NE.3) WRITE(6,712)
      DO 610 NZ=1,11
      SV(1) = 1./ROW(1)
      ASSIGN 605 TO LKRN
      GO TO 6500
605 CONTINUE
      ROW(1) = ROW(1) * DELRHO
610 CONTINUE
      THETA(1) = THETA(1) + DELTHI
620 CONTINUE
      TIMEC = TIMEA/XNPTS
      WRITE (6,700) TIMEC, TIMEA, XNPTS
      GO TO 10
C
C   ***** WRITE AND PUNCH STATEMENTS *****
6500 CONTINUE
6602 CONTINUE
      IF(MOTE1.EQ.1) GO TO 300
      IF((OKLM(1).EQ.0. .OR. OKLM(1).EQ.306.) .AND. ROW(1).GT. 10.
1    .AND. HIA.NE.0.) GO TO 6550
      GAMMA = 0.
      LNGAMA = 0.

```

AFWL-TR-67-131, Vol IV

```

      EMUL = 0.
      EIONIZ = 0.
      XNPIS = XNPIS + 1.
C
C      SET EUSPAR(36) .EQ. 0. TO CAEL EOS
      IF (EUSPAR(36) .NE. 0.) GO TO 6503
      CAEL (TICKER(TIME2))
C
      CAEL EOS(1)
      CALL TICKER(TIME3)
      TIMEA = (TIME3 - TIME2) * 16.666667 + TIMEA
      IF (MOXIE.EQ.207) GO TO 6500
      EGAM = 1. + P1(1)*SV(1)/(E(1)-ECHK(18))
      EGAM2 = 1. + P1(1)*SV(1)/E(1)
      IF (EION(1).NE.0.) EGAM3 = 1.+EION(7)*EION(2)/(1.5*TEMS(9)*EION(1))
      IF (IPRNTU.EQ.2 .OR. IPRNTU.EQ.3) GO TO 6503
      WRITE(6,703) THETA(1), ROW(1), SV(1), P1(1), E(1), CV(1), PHI(1),
1      FEW(1), ASQ(1)
6503 CONTINUE
C      SET EUSPAR(36).EQ.0. TO CAEL EOS
C      SET EUSPAR(37).EQ.0. TO AVOID KAPPA
      IF (EUSPAR(37).NE.0.) GO TO 6502
6501 CONTINUE
      IF (COREM(1) .GE. 201. .AND. OKLM(1) .LE. 300.) GO TO 6530
      IF (ZBAR .EQ. 0.) GO TO 6515
      EIONIZ = EION(8)-1.5*EION(1)*ILMS(9) +ECHK(18)
      CALCULATION OF ILMS(10) REMOVED BECAUSE EIONX APPROXIMATION IS GOOD. L.N.
      LNGAMA = TEMS(10)/THETA(1)
      IF (LNGAMA .GT. 88.028) GAMMA = 1.E-38
      IF (LNGAMA .LT. (-89.415987)) GAMMA = 1.E-38
      IF (GAMMA .EQ. 0.) GAMMA = EXP(LNGAMA)
      IF ((GAMMA.EI.2.7182818) .AND. (IPRNTU.NE.2 .AND. IPRNTU.NE.3))
1      WRITE (6,715)
      NSUBE = (6.0247E23/ILMS(3))*ZBAR*ROW(1)
      GO TO 6520
6515 CONTINUE
      IF (IPRNTU.NE.2 .AND. IPRNTU.NE.3) WRITE (6,728)
6520 IF (IPRNTU .EQ. 1) GO TO 6530
      IF (IPRNTU.EQ.2 .OR. IPRNTU.EQ.3) GO TO 6504
      THCNST = EION(10)-EION(1)*EION(13)+EION(7)
      RELCNS = THCNST/EION(10)
      KK = 10*NOEMNT - 6
      KKK = 10*NOEMNT + 1
      WRITE(6,701)(EION(K),K=1,20),(ILMS(K),K=1,30),SNAFU,GAMMA,LNGAMA,
2      NSUBE,THCNST,RELCNS
      WRITE(6,701) (Z(K),K=2,KKK)
      IF (MOXIE.EQ.101) WRITE(6,701)(ILMSB(K),K=1,15)
      IF (MOXIE .EQ. 6 .OR. MOXIE .EQ. 306 .OR. MOXIE .EQ. 102)
1      WRITE (6,701) (CARBNZ(K),K=1,10)
      WRITE(6,702)11,12,13,14,15,16,17,18,19,110,M(1),(M(K),K=4,KK,10),
2      MATEKE,IEEMNT,J1,J2,J3,J4,J5,J6,J7
C      EQUIVALENCE(J2,L0)
      IF (NOEMNT.EQ.1) WRITE(6,701) POTENL(11),POTENL(13-1),POTENL(13)
6530 CONTINUE
      IF (IPRNTU.EQ.2 .OR. IPRNTU.EQ.3) GO TO 6504

```

AFWL-TR-67-131, Vol IV

```

      IF (IPRNT0.EQ. 1) WRITE(6,752) SNAFU,GAMMA,LNGAMA,PHI,TLMS(10)
1     .NSUBE, THCHS1, HELCNS, DPTAU, EION(14)
      WRITE(6,7018) EGAM, EGAM2, EGAM3, EIONIZ
      IF (IPNCHU.EQ. 1) GO TO 6540
      IF ((IPNCHU.EQ.2.OR.IPNCHU.EQ.3).AND.TRAIL.EQ.11.) PUNCH 721,MOXIE,
1THETA(1),HOW(1),WOKU(K),K=2,8)
      IF ((IPNCHU.EQ.3.OR.IPNCHU.EQ.4).AND.TRAIL.EQ.11.) PUNCH 727,MOXIE,
1THETA(1),HOW(1),HELPHS,HELENG,HELE2,HELZBH,HELION
      PUNCH 704, MOXIE, THETA(1),HOW(1),P1(1),E(1),CV(1),PB1(1),FEW(1),
2      ASQ(1)
      IF ((OKLM(1).GE.201.).AND.(OKLM(1).LE.300.)) GO TO 6509
      PUNCH 711, MOXIE, THETA(1), HOW(1), P1(1), E(1), GAMMA, TLMS(10),
2      FEW(1), EIONIZ
      PUNCH 713, MOXIE, THETA(1),HOW(1),DPTAU,DPTHT,DZDTAU,DZDHT,NEAR,
1      NSUBE
6509 CONTINUE
      PUNCH 714, MOXIE, THETA(1), HOW(1), P1(1), E(1), EGAM, EGAM2,
1      FEW(1), ECHCK(18)
      IF ((OKLM(1).EQ.6.).OR.(OKLM(1).EQ.306.).AND.(RIA.NE.0.))
1      GO TO 6510
6511 CONTINUE
6550 CONTINUE
6540 IF ((THAIL.LE. 10.) .OR. (THAIL.GE. 14.)) WRITE(6,707)
6541 CONTINUE
      GO TO LKRTN.(14,215,510,205,410,605)
6502 CONTINUE
      CALL KAPPA(1,1)
      IF (IPRNT0.EQ.2 .OR. IPRNT0.EQ.3) GO TO 6505
      WRITE(6,7100) THETA(1),HOW(1),SV(1),OKLM(1),CAPAK(1),CAPAC(1),
2FEW(1)
      IF (IPNCHU.NE. 1) PUNCH 7101, MOXIE, THETA(1), HOW(1), FEW(1),
2 CAPAK(1), CAPAC(1)
6505 CONTINUE
      IF ((EUSPAR(36).NE.0.) .AND. (IPRNT0.EQ.2 .OR. IPRNT0.EQ.3)) GO
1      TO 6504
      IF (EUSPAR(36).NE.0.) GO TO 6550
      GO TO 6501
6504 CONTINUE
      GOLOUT(MARKER) = THETA(1)
      GOLOUT(MARKER + 1) = HOW(1)
      GOLOUT(MARKER + 2) = P1(1)
      GOLOUT(MARKER + 3) = E(1)
      IF (EUSPAR(37).EQ. 0.) GO TO 6512
      GOLOUT(MARKER + 4) = CAPAK(1)
      GOLOUT(MARKER + 5) = CAPAC(1)
6513 CONTINUE
      GOLOUT(MARKER + 6) = FEW(1)
      GOLOUT(MARKER + 7) = CV(1)
      GOLOUT(MARKER + 8) = PB1(1)
      GOLOUT(MARKER + 9) = ASQ(1)
      GOLOUT(MARKER + 10) = EGAM
      GOLOUT(MARKER + 11) = EGAM2
      IF (EGAM.EQ. EGAM2) GOLOUT(MARKER+11) = GAMMA
      MARKER = MARKER+12
      GO TO 6541

```


AFWL-TR-67-131, Vol IV

```

6512 CONTINUE
      GOLOUT(MARKER+4) = EION12
      IF (EUSPAR(1).NE.0. .AND. EION(17).NE.1.) GOLOUT(MARKER+4) =
1          EION(17)
C      EION(17) = NBAR
      GOLOUT(MARKER+5) = TLMS(10)
      GO TO 6513
6510 CONTINUE
      ISAVMX= MOXIE
      MOXIE= 6
      EMOL= CARBNZ(1) +ECHCK(18)
      PUNCH 723, MOXIE, THETA(1), ROW(1), EMOL, P1(1), (CARBNZ(K), K=3,6),
2      NBAR, ECHCK(18)
      MOXIL= ISAVMX
      GO TO 6511
6600 CONTINUE
      CALL ES7
      REL P1 = (EION(7)-P1(1))/EION(7)
      REL P2 = (EION(7)-P1(1))/P1(1)
      WRITE (6,7019) THETA(1), ROW(1), ETA, P1(1), EION(7), REL P1, REL P2
      WRITE (6,701) EION
      WRITE (6,701) E(1), CV(1)
      PUNCH 731, MOXIE, THETA(1), ROW(1), P1(1), EION(7), REL P1, REL P2, E(1),
1      EION(3)
      GO TO 6541
300 CONTINUE
      CALL DVCHK(IFAKE)
      CALL TICKER(TIME2)
      THUTA= THETA(1)*1.E-3
      CALL EOSMOT(MOXIE1,1,SV(1), THUTA ,ANS)
      P1(1)= ANS*1.E16
      CALL EOSMOT(MOXIE1,2,SV(1), THUTA ,ANS)
      E(1)= ANS*1.E16
      CALL EOSMOT(MOXIE1,3,SV(1), THUTA ,ANS)
      CV(1)= ANS*1.E13
      CALL EOSMOT(MOXIE1,4,SV(1), THUTA ,ANS)
      PB1(1)= ANS*1.E16
      THUTA= THUTA**4
      CALL EOSMOT(MOXIE1,5,SV(1), THUTA ,ANS)
      ALMDA= ANS
      CAPAR(1)= 1.37*SV(1)/ANS
      CALL TICKER(TIME3)
      SAVEP= P1(1)
      SAVEE= E(1)
      SAVECV= CV(1)
      SAVEPB= PB1(1)
      TIMEA= (TIME3 - TIME2) * 16.666667 + TIMEA
      IF(RPIA.EQ.0.) GO TO 105
      THETA4= THETA(1)**4
      P1(1)= P1(1) -45.66/*THETA4
      PB1(1)= PB1(1) -137.0*THETA4
      E(1)= E(1) -137.0*THETA4*SV(1)
      CV(1)= CV(1) -548.0*THETA4/THETA(1)*SV(1)
105 CONTINUE
      WRITE(6,761) MOXIL, THETA(1), ROW(1), P1(1), E(1), CV(1), PB1(1), CAPAR(1)

```

AFWL-TR-67-131, Vol IV

```

1),XLMUA
IF (NP1A.NE.0.) WRITE(6,762) SAVEP,SAVEE,SAVECV,SAVEPR
IF (IPNCHU.NE.1) PUNCH /721,MUXIE,THETA(1),RHO(1),P1(1),E(1),
1 CV(1),PU1(1),CAPAR(1),XLMUA
GO TO LKRTN,(14,115,510,205,410,605)

C
C ***** F O R M A T S *****
C
C ***** HEAD FORMATS *****
C
706 FORMAT(F4.0, F4.1, 2I1, F10.0, 1P2E15.8, UPF4.0, 1P2E12.6, I2)
730 FORMAT(12A6)
734 FORMAT(6E10.4, 2F6.3)
751 FORMAT(10E8.3)

C
C ***** WRITE FORMATS *****
C
700 FORMAT (10H1 TIMEC = ,E15.6, 3X, 13H= TIMEA/XNPTS /10H TIMEA = ,
1E15.6,3X, 51H= SUM OF TIMES USED DURING CALLS TO EOS (OR EOSMOT) /
210H XNPTS = ,E15.6,3X,60H= TOTAL NUMBER OF THETA-RHO POINTS FROM
31H= LAST INPUT CARD. /40H ALL TIMES PRINTED ARE IN MILLISECOND.)
701 FORMAT (1H , 1P10E15.6)
702 FORMAT (1H , 10(1X,110) )
703 FORMAT (1H0 , 3X 1P9E14.7)
705 FORMAT(10H0OKLM(1) = F6.1, 3X 7HTRAIL = F5.1, 3X 8HPRNT0 = I2, 3X
2 8HIPNCHU = I2, 3X 3HJ = I2 //1X 10HTHETA(1) = 1PE15.8, 5H E.V. 3X
3 8HHRHO(1) = E15.8, 8H G./C.C. 3X 7H5V(1) = E15.8, 8H C.C./G.)
707 FORMAT(///)
708 FORMAT(67H0 GRID OF NORMAL TEMPERATURE-LOW DENSITY POINTS (FROM .1
2 G/CC DOWN)/)
709 FORMAT(67H0 GRID OF NORMAL TEMPERATURE-HIGH DENSITY POINTS (FROM .
201 G/CC UP)/)
710 FORMAT(58H0 GRID OF NORMAL DENSITIES-LOW TEMPERATURE (BELOW 10 E.V
2.)/)
712 FORMAT ( 1H1)
715 FORMAT(53H0 ***** NOTE THAT GAMMA WAS LESS THAN 2.7182818 *****/)
716 FORMAT(15H0 DELTA THETA = 1PE12.5, 4H EV 5X 12H DELTA TAU =E12.5,
1 6H CC/G)
717 FORMAT(15H0 DELTA THETA = 1PE12.5, 4H EV 5X 12H DELTA RHO =E12.5,
1 6H G/CC)
718 FORMAT(86H0 HEAD ONE CARD PER TEMPERATURE-DENSITY POINT. PERFECT
16AS IF TRAIL (INPUT) EQUALS 2./)
719 FORMAT(48H0 NORMAL TEMPERATURE SET AT ONE SELECTED DENSITY /)
720 FORMAT(20H0 SPECIAL ZMEAN PATH///)
722 FORMAT(40H0 COMPUTE RECTANGLE AROUND CENTRAL POINT///)
724 FORMAT(38H0 MOLECULAR EQUATION OF STATE CHECKOUT///)
725 FORMAT(49H0 NORMAL DENSITY SET AT ONE SELECTED TEMPERATURE /)
726 FORMAT(43H0 NORMAL GRID OF TEMPERATURE-DENSITY POINTS/)
728 FORMAT(45H0 PERFECT GAS ANSWER. GAMMA WAS NOT COMPUTED/)
729 FORMAT (19H1THE SOLID ARRAY IS /(5X,1P10E12.5))
732 FORMAT(1H0 12A6)
733 FORMAT (9H OKLM(2)=,F8.1)
735 FORMAT(28H0 DIAPHANOUS TYPE CARDS HAVE )
736 FORMAT(25H0 GILMORE TYPE CARLS HAVE )

```

AFWL-TR-67-131, Vol IV

```

737 FORMAT(2BH0 HILSEN RATH TYPE CARUS HAVE )
738 FORMAT( 5X 7HTHEIA = 1PE12.5, 5H E.V. 3X
25HRRHO = E12.5, 5H G/CC 3X 3HP = E12.5, 10H DYNES/CM2 3X 3HE =
3E12.5, 7H ERGS/G /5X 6HEION = E12.5, 7H ERGS/G 3X 6HKPOS = E12.5,
46H CM2/G 3X 6HKPLK = E12.5, 6H CM2/G 3X 6HZBAR = 0PF7.3, 3X
56HEGAM = F7.3/)
739 FORMAT(15H0 EOS OUTPUT IS )
740 FORMAT(9H REL P = 1PE12.5, 3X 7HREL E = E12.5, 3X 9HRELZBAR =
2E12.5, 3X 15HREL (E-EZER0) = E12.5, 3X 13HREL IONIC E = E12.5//)
742 FORMAT(14H0 THEIA SET IS/(1P10E12.5))
744 FORMAT(12H0 RHO SET IS/(1P10E12.5))
746 FORMAT(54H0 NORMAL GRID WITH SELECTED TEMPERATURE-DENSITY POINTS/
21X,17H MINIMUM THETA = ,F9.3,6H E.V. ,17H MAXIMUM THETA = ,1PE12.5
3,6H E.V. ,/1X,19H MINIMUM DENSITY = ,1PE10.4,5H G/CC,19H MAXIMUM D
4ENSITY = ,E12.5,5H G/CC)
752 FORMAT(5X 7HSNAPU = 1PE10.5, 4X 7HGAMMA = E12.5, 4X 8HNGAMA =
2 E12.5,4X,5HPHI = E12.5,4X, 23H TLM5(10)=THETA*LGAMA = E12.5
3 /5X, 8HNSUBE = ,E12.5,10H THCNST = ,E12.5,10H HELCNS = ,E12.5,
4 10H DPUTAU = ,E12.5,12H LION(14) = ,E12.5)
753 FORMAT(67H1 J MUST BE SPECIFIED ON TRAIL CARD SINCE RHCR= EOSPAR(J
2) FOR AIR. 46H USE J=3 TO AVOID ESB WHEN MATERIAL NO. =102. /51H
3USE J=4 TO AVOID EIONX WHEN MATERIAL NO. IS 208. )
760 FORMAT(11H0,5HOKLM ,5X,6HTHEIA ,10X,4HRRHO ,7X, 9HPPRESSURE ,5X,7HEHE
2HGY ,7X,7HDEDTHI ,7X,7HDEDTAU ,8X,6HCAPAK ,7X,7HLAMBDA )
761 FORMAT(11H0,14,8(2X,1PE12.5))
762 FORMAT(11H0,40X,4(2X,1PE12.5))
763 FORMAT(173H THE SHORT LINE IS P, E, DEDTHI, DEDTAU, WITH RADIATION
1 CONTRIBUTIONS. /)
764 FORMAT(5X, 14,7X,F3.0,2X,5(F5.0,2X,F9.8))
765 FORMAT(16H1MATHREL ARRAY IS //99H MATERIAL NO. NOLMNT Z PA
1RT Z PART Z PART Z PART Z PART
2 )
7000 FORMAT(11H1 45X 32H*** STANDARD OUTPUT FORMAT *** //15H OUTPUT
2LINE 1)
7001 FORMAT( 116H THEIA
1(EV), RHO (G/CC), SV (CC/G), PI (DYNES/CM SQ), E (ERGS/G), CV (ERG
2S/G/EV), PHI (ERGS/CC), FEW, ASU (CM/SEC) /)
7002 FORMAT(21H0 EION ARRAY CONTAINS/ 19H OUTPUT LINES 2, 3)
7003 FORMAT( 126H THEIA (EV), TAU (CC/G), ZHA
1R, ZBAR1, PHI, ESUM, PRESHR (DYNES/CM SQ), ENERGY (ERGS/G), DEDTHI
2 (ERGS/GM/EV), DEDTAU (ERGS/CC) / 122H SNDSPO (CM/SEC), DPUTAU (E
3RG-G/CC SQ), DPUTHT (DYNES/CM SQ/EV), FAILURE RECORD, NSURE, ZMEA
4H, NBAR, ZSUM1, ZSUM2, ZSUM3/)
7004 FORMAT(31H EXPLANATION OF SYMBOLS ABOVE )
7005 FORMAT(18H 1) TAU = , 22HSPECIFIC VOLUME (CC/G) /18H 2)
1ZBAR = , 48HMEAN ION CHARGE (NO. OF ELECTRONS / NO. OF IONS)/
218H 3) PHI = , 32H9.648679E11 / MEAN ATOMIC WEIGHT /
3/2H 4) ALL DERIVATIVES W.R.T. TAU (DEDIAU, DPUTAU) ARE AT CONSTA
4NT THETA. / 72H 5) ALL DERIVATIVES W.R.T. THETA (DEDTHI, DPUTHT)
5 ARE AT CONSTANT TAU. / 18H 6) SNDSPEED = , 57H((PARTIAL PRESHM
6)/(PARTIAL DENSITY)) AT CONSTANT ENTROPY. / 71H 7) FAILURE RECON
7D CONTAINS THE ERROR FLAG AFTER CATASTROPHIC ERRORS. )
7006 FORMAT(18H 9) NBAR , 102HMEAN NO. OF ATOMS PER MOLECULE.
1 IF DIFFERS FROM UNITY IF MOLECULAR EQUATIONS-OF-STATE SO COMPUTE
211. /)

```

AFWL-TR-67-131, Vol IV

7007 FORMAT(21H0 TLMS ARRAY CONTAINS/ 25H OUTPUT LINES 4, 5, 6, 7)
7008 FORMAT(126H BACK1, BACK2, MEAN ATOMIC W
WEIGHT, 4 VARIES, LN(GAMMA*ZBAR), XBAR(1), ZBARLN, SIGMA, XI, SYNTH
ETIC POTENTIAL (I=THETA*LN(GAMMA)) / 107H ZBAR + BACK2 - 2*BACK1, ZB
BAR - BACK1, V(1,J) - V(1,J-1), SUMPOT, UZDTAU, UZDINT, THE NEXT 14
4 VALUES VARY /41H SNAFU, GAMMA, LNGAMA, NSUBE, THCNST, RELCNS /)
7009 FORMAT(31H EXPLANATION OF SYMBOLS ABOVE)
7010 FORMAT(36H 1) BACK1 IS PREVIOUS ZBAR ITERATE / 43H 2) BACK2 IS
1 SECOND PREVIOUS ZBAR ITERATE / 39H 3) XBAR(1) IS RELEVANT MOLE
FRACTION / 40H 4) SIGMA (USED IN EIONM5) IS VARIABLE /10H 5) X
XI = 8X 22H PHI + (1./NBAR + ZBAR) / 65H 6) V(1,J) IS THE JTH IONI
ZATION POTENTIAL (1 .LE. J .LE. Z(1)) / 20X 35H FOR THE ITH ELEMENT
5 OF THE MATERIAL / 79H 7) SUMPOT (USED IN EIONM5) SUMS THE FIKSI
6 (J-1) POTENTIALS WHERE 1 .LE. V(J) / 14H 8) UZDINT = 4X 26HZSUM
/1/2SUM2 (CONSTANT TAU) / 14H 9) UZDTAU = 4X 28HZSUM3/ZSUM2 (CONS
TANT THETA)
7011 FORMAT(75H 10) ALL QUANTITIES INDEXED WITH I ARE SPECIES DEPENDEN
T AND CELL CONTAINS / 20X 55H QUANTITY FOR LAST SPECIES IN MATERIAL
2 (1.E. I = NOLMNT)
7012 FORMAT(60H 11) SNAFU CONTAINS A) 19TH ITERATE OF Z BAR IF IS .EQ
1. 20 / 12X 2H0R 8X 28HB) Z BAR IF Z BAR .GT. ZMEAN / 85H 12) GAM
ZMA IS DEFINED AS THE DIMENSIONLESS DEGENERACY PARAMETER IN THE SAH
JA EQUATION / 46H 13) LNGAMA IS THE NATURAL LOGARITHM OF GAMMA /
49H 14) NSUBE = (0.0245E23)*ZBAR*RHO/(MEAN ATOMIC WEIGHT), THE NUM
BER DENSITY OF ELECTRONS (NO./CC) / 96H 15) THCNST = EION(10)
6 - EION(1) + EION(13) + EION(7) / THERMODYNAMIC CONSISTENCY DEVIATI
/ON / 81H 16) RELCNS = THCNST/EION(10) / RELATIVE THERMODYNAMIC
8 CONSISTENCY DEVIATION //)
7013 FORMAT(107H THE NEXT 1 TO 5 LINES (DEPENDING ON THE NUMBER OF ELE
MENTS, 1 TO 5) ARE Z(2) ONWARD, 10 VALUES PER ELEMENT /123H IF THE
B MATERIAL IS CH2 THE NEXT 2 LINES ARE THE TLMSB ARRAY, IF THE MATE
RIAL IS CARBON THE NEXT LINE IS THE CARBNZ ARRAY, /40H OTHERWISE
THESE LINES WILL NOT APPEAR. / 93H THE NEXT LINES ARE 11 TO 110, MI
E1), (MK), K=4, KK, 10), MATERL, ILEMNI, J1 TO J7, KK=(10*NOLMNT-6) /30H
EXPLANATION OF SYMBOLS ABOVE /67H 1) NOLMNT = M(1) IS THE N
UMBER OF ELEMENTS IN THE MATERIAL / 44H 2) MATERL IS THE SPUTTER
H MATERIAL NUMBER / 29H TWO LINES MAY NEXT APPEAR: /3X, 126H IF NOL
MNT=1, A LINE PRINTS WITH THE ATOMIC NUMBER, V(J-1), AND V(J) (WH
ERE V(J-1).LT.SYNPOT.LE.V(J) WAS USED IN THE EIONX /3X, 46H SUBRO
UTINE UNLESS (J-1)=0 OR J=ATOMIC NO.) /3X, 111H IF IPRNT0=1, A L
INE PRINTS WITH SNAFU, GAMMA, LNGAMA, PHI, TLMS(10), NSUBE, THCNST
M, RELCNS, DPDTAU, EION(14). /
N 45H THE LAST LINE IS
0EGAM, EGAM2, EGAM3, EIONIZ //6X, 29H EGAM= 1.+P1*SV/(E-ECHK(16))
P/6X, 18H EGAM2= 1.+P1*SV/E /6X, 48H EGAM3= 1.+EION(7)*EION(2)/(1.5*1
ULMS(9)*EION(1)) /6X, 42H EIONIZ= ENERGY-(1.5*THETA*XI) +ECHK(16))
7014 FORMAT(23H1 EOSPAR ARRAY CONTAINS/(1P10E12.5))
7015 FORMAT(61HUBBLACK-BODY RADIATION CONTRIBUTION INCLUDED BY SUBROUTIN
2E EOS)
7016 FORMAT(20H MARI DECK CONTAINS/(1P10E12.5))
7017 FORMAT(20H0 EGAM (USES E-E0) = 1PE10.3, 5X 16HEGAM2 (USES E) =
2 E10.3, 5X 23HEGAM3 (USES THANS E) = E10.3, 5X 8HEIONIZ = E10.3)
7019 FORMAT(7HUTHEA=,1PE12.5,5H RHO=,E12.5,15H (RHO/RHOZERO)=,E12.5,10
1H PRESSURE=,E12.5,
216H EIONX PRESSURE=,E12.5,/10X,25H ((P1(1)-P EIONX)/P1(1))=,E12.5,

AFWL-TR-67-131, Vol IV

```

326H(1P1(1)-P E10N1)/P E10N1)=,E12.5 )
7020 FORMAT (24H1THE MATERIAL NUMBER IS ,13)
7021 FORMAT(1H1,5X,5H1HETA,7X,3H1H0,8X,2HP1,9X,1HE,4X,6HCAPAH/,4X,6HCAP
2AC/,5X,3HFEW,8X,2HCV,7X,3HPB1,7X,3HASQ,6X,4HEGAM,4X,6HEGAM2//44X,6
3HE10N1Z,4X,6HSYNPOT,53X,5HGAMMA/(1H ,1P6E10.3,0PF8.5,1P5E10.3))
7022 FORMAT (1H1 ,1P6E10.3,0PF8.5,1P5E10.3))
7023 FORMAT (16HCOMPOSITION IS ,10X,1H2,8X,4HPART ,/(24X,F4.0,4X,
1 F9.8))
7024 FORMAT (1HU,30X,14HZMEAN = ,0PF8.3/31X,14HMH1 = ,1PE
112.5/31X,14HAMEAN = ,0PF9.3/31X,14HENERGY ZERO = ,1PE12.5)
7025 FORMAT (85H1 TIMES RECORDED PER GOLEM RUN ARE AS FOLLOWS (ALL TIM
AES ARE IN MILLISECOND), WHERE / 87H 1) XNPTS = TOTAL NUMBER OF
BTHETA-RHO COMPUTATIONAL POINTS FROM THE LAST INPUT CARD / 87H 2)
C SUMPTS = TOTAL NUMBER OF THETA-RHO COMPUTATIONAL POINTS IN THE E
UNTINE GOLEM RUN. / 22HU QUANTITY MEANING // 54H TIME1 T1
EME1 IS THE TIME AT THE START OF THE RUN / 70H TIME2 TIME2 IS
F THE TIME PRECEDING EACH CALL TO EOS (OR EOSMOT) / 72H TIME3
GTIME3 IS TIME UPON RETURN FROM EACH CALL TO EOS (OR EOSMOT) // 101
HH TIMEA TIMEA = (TIME3 - TIME2)*16.666667, THE SUM OF TIMES
USED DURING CALLS TO EOS (OR EOSMOT) / 118H TIMEB TIMEB = (T
IME3 - TIME1)*16.666667, TOTAL TIME USED BETWEEN START OF RUN AND
LAST CALL TO EOS (OR EOSMOT) / 13X,24HFOR THE LAST INPUT CARD. /
1106H TIMEC TIMEC = TIMEA/XNPTS, TIME USED PER CALL TO EOS (O
R EOSMOT) PER THETA-RHO COMPUTATIONAL POINT. / 112H TIMED T1
NMED = TIMEB/SUMPTS, TIME USED BETWEEN START OF RUN AND LAST CALL I
OO EOS (OR EOSMOT) PER THETA-RHO / 13X, 24HCOMPUTATIONAL POINT. )
7026 FORMAT (10HU TIME1 = , F14.6,10X, 8HTIMEA = ,F14.6,10H TIME2 = ,
F14.6,10X, 8HTIMEB = ,F14.6,10H TIME3 = ,F14.6,10X,8HTIMEC = ,
2F14.6,10H XNPTS = ,F14.6,10X,8HTIMED = ,F14.6,11H SUMPTS = ,
3F13.6)
7100 FORMAT(1HU,3X,7H THETA=,1PE12.5,5H RHO=,E12.5,4H SV=,E12.5,6H OKLM
2=,0PF6.1,7H CAPAC=,1PE12.5,7H CAPAC=,E12.5,5H FEW=,E12.5)
C
C ***** PUNCH FORMATS *****
C
704 FORMAT( 1HA, 14, F9.3, 1P5E10.4, 0PF8.5, 1PE8.2 )
711 FORMAT( 1HB, 14, F9.3,1PE10.4,E8.2,2E10.4,0PF11.3,1PE9.4,E8.2)
713 FORMAT(1HC, 14, F9.3, 1P5E10.4, 0PF6.2, 1PE10.4)
714 FORMAT(1HD, 14, F9.3, 1P5E10.4, 0PF8.5, 1PE8.2)
721 FORMAT(1HE,14,F9.3,6E9.3,2F6.3)
723 FORMAT(1HH,11,F9.3,1P7E8.2,0PF5.2,E8.2)
727 FORMAT(1HG,14,F9.3,1P6E11.3)
731 FORMAT (1HI,14,F9.3,1P6E10.3,0PF6.2)
7101 FORMAT(1HF,14,F9.3,1P4E10.4)
7700 FORMAT(1HA 1X 5HMOX1E 2X 5H1HETA 3X 3H1H0 7X 1HP 9X 1HE 9X 2HCV 8X
. 3HPB1 6X 3HFEW 5X 3HASQ -)
7701 FORMAT(1HB 1X 5HMOX1E 2X 5H1HETA 3X 3H1H0 7X 1HP 9X 1HE 8X 5HGAMMA
. 4X 6HSYNPOT 3X 3HFEW 5X 7HE10N1Z-)
7702 FORMAT(1HC 1X 5HMOX1E 2X 5H1HETA 3X 3H1H0 6X 6HDPUTAU 4X 6HDPUTH
. 4X 6HDPZTAU 4X 6HDPZTHT 3X 4HNUAR 4X 6HNSURE-)
7703 FORMAT(1HD 1X 5HMOX1E 2X 5H1HETA 3X 3H1H0 7X 1HP 9X 1HE 9X 4HEGAM
. 5X 5HEGAM2 5X 3HFEW 4X 6HECHK-)
7704 FORMAT(1HE,1X,5HMOX1E,6H THETA,3X,4H RHO,6X,2H P,7X,2H E,6X,5H E10
2N,4X,5H KHOS,4X,5H KPLK,1X,5H ZBAR,1X,6H EGAM-)
7705 FORMAT(1HF,1X,5HMOX1E,6H THETA,4X,4H RHO,6X,4H FEW,5X,6H CAPAC,4X,
26H CAPAC,26X,1H-)
7706 FORMAT(1HH,17H MOX1E THETA RHO ,3X,6H EMUL ,3X,3H P ,2X,45H DEDTAU
2 DEDTHT DPUTAU DPTHHT NBAR ECHK- )
7707 FORMAT(1HG,1X,5HMOX1E,6H THETA,3X,4H RHO,8X,6HRELPHS,5X,6HRELENG,
15X,5HRELE2,6X,6HRELZBN,5X,7HRELION- )
7720 FORMAT(1HM,13H MOX1E THETA ,2X,5H RHO ,5X,3H P ,6X,3H E ,4X,35H DE
2UTHT DEDTAU CAPAR LAMHUA- )
7721 FORMAT(1HN,14,F9.3,1P7E9.3)
7722 FORMAT(5HMOX1E,2X, 5H1HETA,6X,3H1H0,9X,2HP1,9X,2HP2,7X,6HREL P1,5X
1,6HREL P2,7X,5HE -)
END

```

GOLEM INPUT CARD FORMAT (continued)

COLUMNS	FORMAT	DATA
1-4	F4.0	OKLM(1)
5-8	F4.1	TRAIL
9	I1	IPRNT 0 If (IPRNT0 .EQ. 0), print If (IPRNT0 .EQ. 1), no print If (IPRNT0 .EQ. 2), print GOLOUT Array only (no titles) If (IPRNT0 .EQ. 3), print GOLOUT Array with titles
10	I1	IPNCH0 If (IPNCH0 .EQ. 0) punch If (IPNCH0 .EQ. 1) no punch If (IPNCH0 .EQ. 2. OR. IPNCH0. EQ. 3) .AND. TRAIL. EQ. 11.) punch DIAPHANOUS input in standard output format If (IPNCH0. EQ. 3. OR. IPNCH0. EQ. 4) .AND. TRAIL. EQ. 11.) punch RELE2, RELZBR, RELICN, RELPRS, RELENG
11-20	F10.0	THETA(1)
21-35	E15.8	RHO(1)
36-50	E15.8	SV(1)
51-54	F4.0	TEST
55-66	E12.6	DELTH
67-78	E12.6	DELTAU
79-80	I2	J

These quantities are used as follows:

OKLM(1): A material number used to specify the substance under study. A list of the material numbers used by the SPUTTER code is present in the DIAPHANOUS writeup, earlier in this volume.

TRAIL: The specifier of the path (through the temperature-density plane) to be studied

IPRNT0: Controls the type of printout

IPNCH0: Controls the kind of punch output

THETA: Specifies the first input temperature (if one is required)

RHO: Specifies the first input density (if one is required). Either RHO or TAU (see next quantity) may be input

TAU: Specifies the first input specific volume (if one is required). Either RHO or TAU may be input

TEST: This field is used only to distinguish TRAIL cards from other possible GOLEM input cards

DELTHT: Specifies either the increment in temperature or the second input temperature (if either is required)

DELTAU: Specifies either the increment in density or in specific volume or a second input density (if any of these are required)

J: This field is not presently used

The possible trails through the temperature-density plane that can be used are:

TRAIL OPTIONS

- TRAIL = 0. Normal grid of temperature-density points (see next page)
- TRAIL = 1. Special ZMEAN path
- TRAIL = 2. Perfect gas and read one card per point
- TRAIL = 3. Read one card per point
- TRAIL = 4. Compute (THETA, TAU) rectangle around central point
- TRAIL = 5. Normal grid of selected temperature-density points
- TRAIL = 6. Molecular equation-of-state checkout set
- TRAIL = 7. Compute (THETA, RHO) rectangle around central point
- TRAIL = 8. Grid of temperature-low density (. LE. 0.1) points
- TRAIL = 9. Grid of temperature-high density (. GE. 0.01) points
- TRAIL = 10. Grid of densities-low temperature (. LE. 10 eV)
- TRAIL = 11. Read DIAPHANOUS data card
- TRAIL = 12. Read GILMORE data card
- TRAIL = 13. Read HILSEN RATH data card
- TRAIL = 14. Normal temperature set at one selected density
- TRAIL = 15. Normal density set at one selected temperature

The normal grid of points takes advantage of a set of temperatures, the THETA array, the RHO array, and densities that are built into the program in the form of data statements. These two data statements and a third, the EOSPAR array, (containing the parameters required by various equation-of-state or opacity subroutines) are gathered together in a block data program (called the KONTRL block data program). The temperature and density arrays so specified can be changed at will. Thus, the normal path is really as variable as desired. In practice, a standard set of temperatures and densities have been used. They are:

Normal THETA array /0.025, 0.05, 0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7,
0.8, 0.9, 1., 1.5,
1 2.25, 3.4, 5., 7., 10., 15., 22.5, 34., 50.,
70., 100.,
2 150., 225., 340., 400., 500., 600., 700.,
800., 900.,
3 1.E3, 1.5E3, 2.25E3, 3.4E3, 5.E3, 7.E3,
1.E4, 210*0.

Normal RHO array /75., 50., 25., 10., 5., 2., 1.5, 1., 0.5, 0.1,
1.E-2, 1.E-3,
1 1.E-4, 1.E-5, 1.E-6, 1.E-7, 1.E-8, 1.E-9,
2 1.0000001E-10, 1.E-11, 1.E-12, 1.E-13,
1.E-14, 227*0.

Similarly, the standard set of input parameters in the EOSPAR array (which specifies quantities used by the subroutines) is:

Normal EOSPAR array /0., 488., -1.E38, 1.E38, 6*0.,
1 7*0., 1.E-18, 1.E-3, 0.,
2 1., 0., 1., 2., 2*0., 3., 2*0., 1.5,
3 8*0., 1., 8.2E11,
4 1., 2., 8*0.

AFWL-TR-67-131, Vol IV

These array elements are used in the following way:

EOSPAR(1) Controls usage of molecular equation-of-state by EIONX to allow ES1LMS, AIRMOL, and CMOL, set EOSPAR(1). NE. 0.

EOSPAR(2) Equals number of entries in MARI deck

EOSPAR(3) Free parameter

EOSPAR(4) Free parameter

EOSPAR(5) Controls ECHCK(18)

EOSPAR(5) Controls energy zero choice - see comment below

EOSPAR(5) = 5.98566E11 ergs/gm for atomization energy of carbon using CMOL

EOSPAR(5) = 9.63E11 ergs/gm for ES1LMS CH2 computations

EOSPAR(5) = 2.899E11 ergs/gm for dissociation energy of air for AIRMOL

EOSPAR(6) Controls EIONIN(1)

EOSPAR(7) Controls EIONIN(2)

EOSPAR(8) Controls EIONIN(3)

EOSPAR(9) Controls EIONIN(4)

EOSPAR(10) Controls EIONIN(5)

EOSPAR(11) Controls EIONIN(6)

EOSPAR(12) Controls EIONIN(7)

EOSPAR(13) Controls EIONIN(8)

EOSPAR(14) Controls EIONIN(9)

EOSPAR(15) Controls EIONIN(10)

EOSPAR(16) Controls EIONIN(11)

These 11 cells can be used to enter a special material composition to EIONX codes. Set EOSPAR(6) = the number of elements in the material. Set EOSPAR(7) through (16) = successive sets of (atomic number, atom number fraction) EOSPAR(6) . LT. 5. 5 is required

EOSPAR(17) Controls EIONIN(28)

EOSPAR(17) For CMOL only

Equivalence (EIONIN(28), FESTER), controls choice of run, full-equilibrium or translation-only

Use EIONIN(28) . EQ. -1. for translation-only treatment

Use EIONIN(28) . EQ. +1. for full-equilibrium treatment at GGA; . EQ. 0. or +1. for full equilibrium treatment at AFWL.

for identity of results, use same value of EIONIN(28) at GGA and AFWL.

AFWL-TR-67-131, Vol IV

EOSPAR(18) Controls EIONIN(29)
Equivalence (EIONIN(29), ZBRMIN), controls minimum
allowed ZBAR

EOSPAR(19) Controls EIONIN(30)
Equivalence (EIONIN(30), EPSI), controls ZBAR for EIONX
iteration test

EOSPAR(20) Controls M2

EOSPAR(21) Controls RPIA
Set EOSPAR(21) . EQ. 0. to include radiation contributions
in EOS.
Set EOSPAR(21) . NE. 0. to avoid radiation contributions
in EOS

EOSPAR(22) Controls PUSHA

EOSPAR(23) Controls MAXLM

EOSPAR(24) Controls LMDA(2)

EOSPAR(25) Controls SOLID(18)

EOSPAR(26) Controls SCYCLE

EOSPAR(27) Controls NR
Set EOSPAR(27) . GE. 2. for path = 0. in EIONX
Set EOSPAR(27) . LE. 1. for path = -3. in EIONX

EOSPAR(28) Controls IAM1

EOSPAR(29) Controls IB

EOSPAR(30) Controls CVA

EOSPAR(31) Controls SOLID(17)

EOSPAR(32) Controls RIB

EOSPAR(33) Controls HVA

EOSPAR(34) Controls HCA

EOSPAR(35) Controls AMASNO(1)

EOSPAR(36) Controls EOS
Set EOSPAR(36) . NE. 0. to avoid EOS
Set EOSPAR(36) . EQ. 0. to call EOS

EOSPAR(37) Controls KAPPA
Set EOSPAR(37) . NE. 0. to call KAPPA

EOSPAR(38) Controls CHRNO(1)

EOSPAR(39) Controls OKLM(18)

AFWL-TR-67-131, Vol IV

EOSPAR(40) Controls CMIN = 8. 2E11

EOSPAR(41) Controls LMDA(1)

EOSPAR(42) Controls MAXL

EOSPAR(43) Controls S2, normal value = 0

EOSPAR(44) Controls MARK, the AIRMOL control parameter MARK is equivalenced to EIONIN(28).

Set EOSPAR(44) to +2. , 0. , or -2. to achieve desired results. +2. is standard value

Remaining cells free.

The main print and punch options are:

IPRNT0 = 0 : Normal printout with all debug and intermediate quantities

IPRNT0 = 1 : Limited printout with main thermodynamic variables

IPRNT0 = 2 : Tabular output without captions

IPRNT0 = 3 : Tabular output (with titles) of θ , ρ , P , E , \bar{Z} , $(\partial E / \partial \theta)_\tau$, $(\partial E / \partial \tau)_\theta$, the speed of sound, $EGAM = 1 + P / \rho E$, and several other variables

IPNCH0 = 0 : Punches all thermodynamic quantities computed by subroutines

IPNCH0 = 1 : No punch output

No matter which printout format is chosen, a page explaining all quantities is printed. On this page the units used, some relations used, and some definitions for several variables used are discussed.

If the option to punch cards is exercised, the different types of cards are prefaced by title cards and made sortable, together with the title cards, by a distinguishing character punched in column 1 of the card.

The input requirements of the various trails are simple: wherever any temperature-density point is the single or central point of a path to be studied, those values are input to THETA and RHO (or THETA and TAU). If increments are required, the values are input into DELTHT and DELTAU (DELTAU is also used for Δp if needed). If a trail requires upper and lower temperatures, the upper one is input into DELTHT and the lower one is input to THETA. If upper and lower densities are required, they are

STANDARD OUTPUT FORMAT

OUTPUT LINE 1
 THETA (EV), RHO (G/CC), QV (CC/G), P1 (DYNES/CM SQ), E (EKG/0), CV (EKG/0/EV), PD1 (EKG/CCI), PEX, ASQ (CM/SEC)

ESON ARRAY CONTAINS

OUTPUT LINES 2-5
 THETA (EV), TAU (CC/G), ZBAR, ZBAR1, PHI, CSUM, PRESHE (DYNES/CM SQ), ENERGY (EKG/0), DEPTH (EKG/CM/EV), DEBYAU (EKG/CC),
 DENSITY (G/CC), SPDTAU (EKG/0/CC SQ), SPDTHT (DYNES/CM SQ/EV), FAILURE RECORD, NSUBS, ZUEBN, NSAN, ZSUM, ZSUMS, ZSUMS

EXPLANATION OF SYMBOLS ABOVE

- 1) TAU 0 SPECIFIC VOLUME (CC/G)
- 2) ZBAR 0 MEAN ION / MOLE (NO. OF ELECTRONS / NO. OF IONS)
- 3) PHI 0 0.00070E11 / MEAN ATOMIC WEIGHT
- 4) ALL DERIVATIVES O.A.T. TAU (DEPTH), SPDTAU ARE AT CONSTANT THETA.
- 5) ALL DERIVATIVES O.A.T. THETA (DEPTH), SPDTHT ARE AT CONSTANT TAU.
- 6) SPDTAU 0 (PARTIAL PRESHE)/(PARTIAL DENSITY) AT CONSTANT TAU.
- 7) FAILURE RECORD CONTAINS THE ERROR FLAG AFTER CATASTROPHIC ERRORS.
- 8) NSAN MEAN NO. OF ATOMS PER MOLECULE. IT DIFFERS FROM UNITY IF MOLECULAR EQUATIONS-OF-STATE SO COMPUTE IT.

TLMS ARRAY CONTAINS

OUTPUT LINES 6-9
 OACAC, BACAC, MEAN ATOMIC WEIGHT, A VERICO, LUSAMMA(ZBAR), ABAAC(1), ZBARLN, S1MA, A1, SYNTHETIC POTENTIAL (10THETA/LUSAMMA),
 ZBAR 0 BACAC 0 BACAC1, ZBAR 0 BACAC1, VILJ1 = VILJ-1, SUMPOT, DEBYAU, DEBYN, THE MEAT IN VALUES VARY,
 SAMPUSAMMA, LUSAMA, NSUBS, THENST, RELCHS

EXPLANATION OF SYMBOLS ABOVE

- 1) BACAC1 IS PREVIOUS ZBAR ITERATE
- 2) BACAC2 IS SECOND PREVIOUS ZBAR ITERATE
- 3) BACAC3 IS THIRD PREVIOUS ZBAR ITERATE
- 4) S1MA USED IN EQUATION IS VARIABLE
- 5) A1 0 PHI 0 11, NSAN 0 ZBAR1
- 6) VILJ1 IS THE JTH IONIZATION POTENTIAL (1, LE, J, LE, S111)
 FOR THE JTH ELEMENT OF THE MATERIAL
- 7) SUMPOT (USED IN EQUATION) SUMS THE FIRST (J-1) POTENTIALS WHERE 1, LE, VILJ
- 8) DEBYN 0 LUSMA/DEBYAU (CONSTANT TAU)
- 9) DEBYAU 0 LUSMA/DEBYN (CONSTANT THETA)
- 10) ALL QUANTITIES INDEXED WITH 1 ARE SPECIES DEPENDENT AND CELL CONTAINING
 QUANTITY FOR LAST SPECIES IN MATERIAL (I.E. V & NSUBST)
- 11) SAMPUSAMMA 0 10TH ITERATE OF Z BAR IF IS .EQ. 0
 OR 01 Z BAR IF Z BAR .GT. ZERO
- 12) LUSAMA IS DEFINED AS THE DIMENSIONLESS DEGENERACY PARAMETER IN THE SAM EQUATION
- 13) LUSAMA IS THE NATURAL LOGARITHM OF LUSAMA
- 14) NSUBS (0.0000001/ZBAR0000)/MEAN ATOMIC WEIGHT, THE NUMBER DENSITY OF ELECTRONS (NO./CC)
- 15) THENST 0 LUSMA(1) - EION(1) 0 CION(1) 0 CION(1) 1 THERMODYNAMIC CONSISTENCY DEVIATION
- 16) RELCHS 0 THENST/EION(1) 1 RELATIVE THERMODYNAMIC CONSISTENCY DEVIATION

THE MEAT C TO 9 LINES (DEPENDENT ON THE NUMBER OF ELEMENTS, 1 TO 9) ARE Z101 FORWARD, 10 VALUES PER ELEMENT
 IF THE MATERIAL IS C4 THE MEAT 2 LINES ARE THE TLMS ARRAY. IF THE MATERIAL IS CARBON THE MEAT LINE TO THE CORRE ARRAY,
 OTHERWISE THESE LINES WILL NOT APPEAR.
 THE MEAT LINES ARE 11 TO 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127, 128, 129, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 140, 141, 142, 143, 144, 145, 146, 147, 148, 149, 150, 151, 152, 153, 154, 155, 156, 157, 158, 159, 160, 161, 162, 163, 164, 165, 166, 167, 168, 169, 170, 171, 172, 173, 174, 175, 176, 177, 178, 179, 180, 181, 182, 183, 184, 185, 186, 187, 188, 189, 190, 191, 192, 193, 194, 195, 196, 197, 198, 199, 200, 201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 221, 222, 223, 224, 225, 226, 227, 228, 229, 230, 231, 232, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 247, 248, 249, 250, 251, 252, 253, 254, 255, 256, 257, 258, 259, 260, 261, 262, 263, 264, 265, 266, 267, 268, 269, 270, 271, 272, 273, 274, 275, 276, 277, 278, 279, 280, 281, 282, 283, 284, 285, 286, 287, 288, 289, 290, 291, 292, 293, 294, 295, 296, 297, 298, 299, 300, 301, 302, 303, 304, 305, 306, 307, 308, 309, 310, 311, 312, 313, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330, 331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341, 342, 343, 344, 345, 346, 347, 348, 349, 350, 351, 352, 353, 354, 355, 356, 357, 358, 359, 360, 361, 362, 363, 364, 365, 366, 367, 368, 369, 370, 371, 372, 373, 374, 375, 376, 377, 378, 379, 380, 381, 382, 383, 384, 385, 386, 387, 388, 389, 390, 391, 392, 393, 394, 395, 396, 397, 398, 399, 400, 401, 402, 403, 404, 405, 406, 407, 408, 409, 410, 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421, 422, 423, 424, 425, 426, 427, 428, 429, 430, 431, 432, 433, 434, 435, 436, 437, 438, 439, 440, 441, 442, 443, 444, 445, 446, 447, 448, 449, 450, 451, 452, 453, 454, 455, 456, 457, 458, 459, 460, 461, 462, 463, 464, 465, 466, 467, 468, 469, 470, 471, 472, 473, 474, 475, 476, 477, 478, 479, 480, 481, 482, 483, 484, 485, 486, 487, 488, 489, 490, 491, 492, 493, 494, 495, 496, 497, 498, 499, 500, 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515, 516, 517, 518, 519, 520, 521, 522, 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534, 535, 536, 537, 538, 539, 540, 541, 542, 543, 544, 545, 546, 547, 548, 549, 550, 551, 552, 553, 554, 555, 556, 557, 558, 559, 560, 561, 562, 563, 564, 565, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577, 578, 579, 580, 581, 582, 583, 584, 585, 586, 587, 588, 589, 590, 591, 592, 593, 594, 595, 596, 597, 598, 599, 600, 601, 602, 603, 604, 605, 606, 607, 608, 609, 610, 611, 612, 613, 614, 615, 616, 617, 618, 619, 620, 621, 622, 623, 624, 625, 626, 627, 628, 629, 630, 631, 632, 633, 634, 635, 636, 637, 638, 639, 640, 641, 642, 643, 644, 645, 646, 647, 648, 649, 650, 651, 652, 653, 654, 655, 656, 657, 658, 659, 660, 661, 662, 663, 664, 665, 666, 667, 668, 669, 670, 671, 672, 673, 674, 675, 676, 677, 678, 679, 680, 681, 682, 683, 684, 685, 686, 687, 688, 689, 690, 691, 692, 693, 694, 695, 696, 697, 698, 699, 700, 701, 702, 703, 704, 705, 706, 707, 708, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 740, 741, 742, 743, 744, 745, 746, 747, 748, 749, 750, 751, 752, 753, 754, 755, 756, 757, 758, 759, 760, 761, 762, 763, 764, 765, 766, 767, 768, 769, 770, 771, 772, 773, 774, 775, 776, 777, 778, 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 790, 791, 792, 793, 794, 795, 796, 797, 798, 799, 800, 801, 802, 803, 804, 805, 806, 807, 808, 809, 810, 811, 812, 813, 814, 815, 816, 817, 818, 819, 820, 821, 822, 823, 824, 825, 826, 827, 828, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 840, 841, 842, 843, 844, 845, 846, 847, 848, 849, 850, 851, 852, 853, 854, 855, 856, 857, 858, 859, 860, 861, 862, 863, 864, 865, 866, 867, 868, 869, 870, 871, 872, 873, 874, 875, 876, 877, 878, 879, 880, 881, 882, 883, 884, 885, 886, 887, 888, 889, 890, 891, 892, 893, 894, 895, 896, 897, 898, 899, 900, 901, 902, 903, 904, 905, 906, 907, 908, 909, 910, 911, 912, 913, 914, 915, 916, 917, 918, 919, 920, 921, 922, 923, 924, 925, 926, 927, 928, 929, 930, 931, 932, 933, 934, 935, 936, 937, 938, 939, 940, 941, 942, 943, 944, 945, 946, 947, 948, 949, 950, 951, 952, 953, 954, 955, 956, 957, 958, 959, 960, 961, 962, 963, 964, 965, 966, 967, 968, 969, 970, 971, 972, 973, 974, 975, 976, 977, 978, 979, 980, 981, 982, 983, 984, 985, 986, 987, 988, 989, 990, 991, 992, 993, 994, 995, 996, 997, 998, 999, 1000, 1001, 1002, 1003, 1004, 1005, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1047, 1048, 1049, 1050, 1051, 1052, 1053, 1054, 1055, 1056, 1057, 1058, 1059, 1060, 1061, 1062, 1063, 1064, 1065, 1066, 1067, 1068, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112, 1113, 1114, 1115, 1116, 1117, 1118, 1119, 1120, 1121, 1122, 1123, 1124, 1125, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1181, 1182, 1183, 1184, 1185, 1186, 1187, 1188, 1189, 1190, 1191, 1192, 1193, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229, 1230, 1231, 1232, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256, 1257, 1258, 1259, 1260, 1261, 1262, 1263, 1264, 1265, 1266, 1267, 1268, 1269, 1270, 1271, 1272, 1273, 1274, 1275, 1276, 1277, 1278, 1279, 1280, 1281, 1282, 1283, 1284, 1285, 1286, 1287, 1288, 1289, 1290, 1291, 1292, 1293, 1294, 1295, 1296, 1297, 1298, 1299, 1300, 1301, 1302, 1303, 1304, 1305, 1306, 1307, 1308, 1309, 1310, 1311, 1312, 1313, 1314, 1315, 1316, 1317, 1318, 1319, 1320, 1321, 1322, 1323, 1324, 1325, 1326, 1327, 1328, 1329, 1330, 1331, 1332, 1333, 1334, 1335, 1336, 1337, 1338, 1339, 1340, 1341, 1342, 1343, 1344, 1345, 1346, 1347, 1348, 1349, 1350, 1351, 1352, 1353, 1354, 1355, 1356, 1357, 1358, 1359, 1360, 1361, 1362, 1363, 1364, 1365, 1366, 1367, 1368, 1369, 1370, 1371, 1372, 1373, 1374, 1375, 1376, 1377, 1378, 1379, 1380, 1381, 1382, 1383, 1384, 1385, 1386, 1387, 1388, 1389, 1390, 1391, 1392, 1393, 1394, 1395, 1396, 1397, 1398, 1399, 1400, 1401, 1402, 1403, 1404, 1405, 1406, 1407, 1408, 1409, 1410, 1411, 1412, 1413, 1414, 1415, 1416, 1417, 1418, 1419, 1420, 1421, 1422, 1423, 1424, 1425, 1426, 1427, 1428, 1429, 1430, 1431, 1432, 1433, 1434, 1435, 1436, 1437, 1438, 1439, 1440, 1441, 1442, 1443, 1444, 1445, 1446, 1447, 1448, 1449, 1450, 1451, 1452, 1453, 1454, 1455, 1456, 1457, 1458, 1459, 1460, 1461, 1462, 1463, 1464, 1465, 1466, 1467, 1468, 1469, 1470, 1471, 1472, 1473, 1474, 1475, 1476, 1477, 1478, 1479, 1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492, 1493, 1494, 1495, 1496, 1497, 1498, 1499, 1500, 1501, 1502, 1503, 1504, 1505, 1506, 1507, 1508, 1509, 1510, 1511, 1512, 1513, 1514, 1515, 1516, 1517, 1518, 1519, 1520, 1521, 1522, 1523, 1524, 1525, 1526, 1527, 1528, 1529, 1530, 1531, 1532, 1533, 1534, 1535, 1536, 1537, 1538, 1539, 1540, 1541, 1542, 1543, 1544, 1545, 1546, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561, 1562, 1563, 1564, 1565, 1566, 1567, 1568, 1569, 1570, 1571, 1572, 1573, 1574, 1575, 1576, 1577, 1578, 1579, 1580, 1581, 1582, 1583, 1584, 1585, 1586, 1587, 1588, 1589, 1590, 1591, 1592, 1593, 1594, 1595, 1596, 1597, 1598, 1599, 1600, 1601, 1602, 1603, 1604, 1605, 1606, 1607, 1608, 1609, 1610, 1611, 1612, 1613, 1614, 1615, 1616, 1617, 1618, 1619, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646, 1647, 1648, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661, 1662, 1663, 1664, 1665, 1666, 1667, 1668, 1669, 1670, 1671, 1672, 1673, 1674, 1675, 1676, 1677, 1678, 1679, 1680, 1681, 1682, 1683, 1684, 1685, 1686, 1687, 1688, 1689, 1690, 1691, 1692, 1693, 1694, 1695, 1696, 1697, 1698, 1699, 1700, 1701, 1702, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714, 1715, 1716, 1717, 1718, 1719, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1727, 1728, 1729, 1730, 1731, 1732, 1733, 1734, 1735, 1736, 1737, 1738, 1739, 1740, 1741, 1742, 1743, 1744, 1745, 1746, 1747, 1748, 1749, 1750, 1751, 1752, 1753, 1754, 1755, 1756, 1757, 1758, 1759, 1760, 1761, 1762, 1763, 1764, 1765, 1766, 1767, 1768, 1769, 1770, 1771, 1772, 1773, 1774, 1775, 1776, 1777, 1778, 1779, 1780, 1781, 1782, 1783, 1784, 1785, 1786, 1787, 1788, 1789, 1790, 1791, 1792, 1793, 1794, 1795, 1796, 1797, 1798, 1799, 1800, 1801, 1802, 1803, 1804, 1805, 1806, 1807, 1808, 1809, 1810, 1811, 1812, 1813, 1814, 1815, 1816, 1817, 1818, 1819, 1820, 1821, 1822, 1823, 1824, 1825, 1826, 1827, 1828, 1829, 1830, 1831, 1832, 1833, 1834, 1835, 1836, 1837, 1838, 1839, 1840, 1841, 1842, 1843, 1844, 1845, 1846, 1847, 1848, 1849, 1850, 1851, 1852, 1853, 1854, 1855, 1856, 1857, 1858, 1859, 1860, 1861, 1862, 1863, 1864, 1865, 1866, 1867, 1868, 1869, 1870, 1871, 1872, 1873, 1874, 1875, 1876, 1877, 1878, 1879, 1880, 1881, 1882, 1883, 1884, 1885, 1886, 1887, 1888, 1889, 1890, 1891, 1892, 1893, 1894, 1895, 1896, 1897, 1898, 1899, 1900, 1901, 1902, 1903, 1904, 1905, 1906, 1907, 1908, 1909, 1910, 1911, 1912, 1913, 1914, 1915, 1916, 1917, 1918, 1919, 1920, 1921, 1922, 1923, 1924, 1925, 1926, 1927, 1928, 1929, 1930, 1931, 1932, 1933, 1934, 1935, 1936, 1937, 1938, 1939, 1940, 1941, 1942, 1943, 1944, 1945, 1946, 1947, 1948, 1949, 1950, 1951, 1952, 1953, 1954, 1955, 1956, 1957, 1958, 1959, 1960, 1961, 1962, 1963, 1964, 1965, 1966, 1967, 1968, 1969, 1970, 1971, 1972, 1973, 1974, 1975, 1976, 1977, 1978, 1979, 1980, 1981, 1982, 1983, 1984, 1985, 1986, 1987, 1988, 1989, 1990, 1991, 1992, 1993, 1994, 1995, 1996, 1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036,

input into DELTAU and RHO (or TAU), respectively. If some subset of the normal θ set is used, then only the needed density need be input, and vice versa. For further guidance consult the code.

Note that although the GOLEM code is lengthy and appears complicated, it has an extremely simple logical structure on any given trail. Each trail generates a member of a set of temperature-density points. The equation-of-state or opacity subroutine is then called to compute the thermodynamic data relevant to this temperature-density point. These data are then either printed, punched (or both), or stored in an array for later printout. The trail next generates the succeeding temperature-density point and the process is repeated. Any number of trail-specifying input cards may be stacked in a given run.

Finally, further development of the GOLEM code will couple it to a plotting routine, GRAPH (which can already couple with the DYPER4 and TRANS codes). Examples of GOLEM output for the AIRMOL subroutine are given in Appendix I. An example is also given for the CMOL subroutine in reference 4.

MARIER: AN ISOELECTRONIC IONIZATION POTENTIAL PREDICTOR

MARIER does 2nd- or 4th-order least-square fits to a given isoelectronic sequence of ionization potentials.

The program contains one read statement:

```
READ (5, 7701) KSTART, KEND, LASTZ, LOWERGO, LOWERZ,  
              NEXT, LORDER, LREDUC, LSTEP, MORE
```

```
7701 FORMAT (10 (I2, 2X))
```

The meaning of these variables is:

KSTART	is the lowest atomic number used in the first isoelectronic sequence done
KEND	is defined by: (KEND-KSTART+1) isoelectronic sequences are done
LASTZ	is the highest atomic number used in any isoelectronic sequence

AFWL-TR-67-131, Vol IV

```

PROGRAM MARIET(INPUT,OUTPUT,TAPE5=INPUT,TAPE6=OUTPUT)
COMMON/LMSH/U(1)
DATA KPREV, KSTART, KEND, LASTZ /4* 0/ 1M/0/ 1M2/0/
DIMENSION X(100),Y(100), COEF(8,100),COE(5),POTENL(100),KATNO(100)
REAL MARIAN
DIMENSION MARIAN(100,100)
DIMENSION MATNU(100)
DIMENSION XX(3),YY(3),COE2(3)
DATA L3/3/ L2/2/
DATA UEVEAT/0./ POTENL/100*0./ DEVIAI/0./

```

ASSUME MARI DECK USED HAS ELEMENTS IN MONOTONE INCREASING ORDER
FOLLOWED BY ISOTOPIC MIXTURES

MARI DECK IS ASSUMED TO CONTAIN ONE OR TWO SPECIFICATIONS FOR EACH
ELEMENT. (THE SECOND SPECIFICATION WILL ORDINARILY BE USED FOR
SPECIAL ISOTOPIC MIXTURES.) THIS PROGRAM WILL USE DATA FROM THE
FIRST SPECIFICATION FOR A GIVEN ELEMENT. THE MARI DECK ENDS WITH
A ZERO.

```

1 CONTINUE
READ (5,7701) KSTART, KEND, LASTZ, LOWRG0, LOWRZ, NEXT, LORDER,
1 LREDUC, LSTEP, MORE
7701 FORMAT(10(I2,2X))

```

KSTART IS THE LOWEST ATOMIC NUMBER USABLE IN THE FIRST ISOELEC-
TRONIC SEQUENCE DONE
KEND IS DEFINED BY: (KEND-KSTART+1) ISOELECTRONIC SEQUENCES ARE
DONE
LASTZ IS THE HIGHEST ATOMIC NUMBER USED IN ANY ISOELECTRONIC
SEQUENCE
KPREV IS THE VALUE OF KEND USED ON THE PREVIOUS DATA CARD. IT
IS INITIALLY SET TO ZERO.
LOWRG0 SPECIFIES THE INDEX OF THE FIRST TERM IN THE ISOELECTRO-
NIC SEQUENCE WHICH IS ACTUALLY USED IN THE CALCULATION.
LOWRZ SPECIFIES THE LOWEST ATOMIC NUMBER WHICH CAN BE USED IN A
CALCULATION.
NEXT SPECIFIES THE CORE PARAMETER FOR SUBROUTINE UERUG. IF NEXT
EQUALS ZERO, PRINT MESSAGE AND CONTINUE RUN. IF NEXT.NE.0,
PRINT MESSAGE AND CALL MERR
LORDER SPECIFIES FITTING POLYNOMIAL ORDER
IF LREDUC EQUALS 0, LORDER WILL ORDINARILY BE 4. IF LREDUC.NE.0
LORDER WILL ORDINARILY BE 3
IF LORDER .GT. 4 IS USED, REDIMENSION COEF ARRAY TO COEF(LORDER+4,
100) AND COE ARRAY TO COE(LORDER+1)
LREDUC .EQ. 0 USES IONIZATION POTENTIALS. LREDUC .NE. 0 USES
IONIZATION POTENTIALS DIVIDED BY TERM INDEX

LSTEP CAN BE USED TO MODIFY THE TERM INDEX VALUE (I.E. WE COULD
CALL THE INITIAL TERM INDEX THE (1+LSTEP-TH) TERM.)

```

WRITE (6,7702) KSTART,KEND,LASTZ,KPREV,LOWRG0,LOWRZ,NEXT,LORDER,

```

AFWL-TR-67-131, Vol IV

```

      1          LREDDC, LSTEP, MORE
7702 FORMAT (18H1INPUT AS READ WAS/ 8H KSTART=,13, 6H KEND=,13, 7H LAST
      12=,13, 7H KPREV= , 13, 8H LOWRGO= ,13, 7H LOWRZ= ,13,6H NEXT= ,13,
      28H LOWRER=,13, 8H LREDDC=,13, 7H LSTEP=,13,6H MORE=,13)
C
      IF (KSTART.EQ.0) KSTART=1
      IF (LASTZ .EQ.0) LASTZ= 92
      IF (KEND.EQ.0 .OR. KEND .GT. LASTZ ) KEND=LASTZ
      IF (KSTART .GT. KEND) KSTART=KEND
      IF (LOWRGO .EQ.0) LOWRGO=1
      IF (LOWRER .EQ. 0) LOWRER=4
      IF (KPREV.EQ.KEND.AND.LOWRZ.EQ.1) CALL EXIT
C      TO END RUN, DUPLICATE THE LAST DATA CARD BUT SET LOWRZ=1. THIS
C      IS THE LAST REQUIRED INPUT CARD AND WILL CALL EXIT.
      WRITE(6,7001)KSTART,KEND, LASTZ,KPREV,LOWRGO,LOWRER,LREDDC
      1,LSTEP,MORE
7001 FORMAT(24H PARAMETERS AS USED WERE/8H KSTART=,13,6H KEND=,13,7H LA
      1STZ=, 13,7H KPREV=,13, 8H LOWRGO= ,13 , 7H LOWRZ= ,13,
      28H LOWRER=,13, 8H LREDDC=,13, 7H LSTEP=,13,6H MORE=,13)
C
      KPREV= KEND
      KCOUNT=KEND-KSTART+1
C
C
C
C
      DO SUB I=1,100
      DO SUB J=1,100
      MARIAN(1,J)=0.
300 CONTINUE
      DO 90 I=1,6
      DO 90 J2=1,100
      COLP (1,J2)=0.
      90 CONTINUE
101 CONTINUE
      DO 500 K= KSTART, KEND
C
C      DO ALL SEQUENCES BETWEEN KSTART AND KEND INCLUSIVE.
C
C      THE K-TH SEQUENCE FITS THE (LASTZ-K+1) IONIZATION POTENTIALS
C
C
C      K      K+1      KK      LASTZ
C      V      V      .... V      .... V
C      1      2      LOWER      LASTZ-K+1
C
C
C      USING J.GRATTEAUS LEAST-SQUARE POLYNOMIAL FIT SUBROUTINE
C      TO A QUADRATIC EQUATION.
C
C
C      K2=      K+LOWRGO-1
      LSTORE=      0
102 CONTINUE
      DO 103 KK= K2, LASTZ
C

```

AFWL-TR-67-131, Vol IV

```

C      THIS ISOELECTRONIC IONIZATION SEQUENCE HAS (LASTZ-K+1) ELEMENTS
C      WHICH STORE INTO THE Y ARRAY. SOME MAY BE ZERO IN THE MARI DECK OR
C      MAY BE MISSING. IF SO, THE SEQUENCE HAS THESE ELEMENTS MISSING IN
C      THE Y ARRAY AND HAS LESS THAN (LASTZ-K+1) TERMS
C
C      LOWER SPECIFIES WHICH IONIZATION POTENTIAL IS USED
C      KK SPECIFIES THE ATOMIC NUMBER OF THE SUCCESSIVE SEQUENCE TERMS
C      LSTORE SPECIFIES THE SEQUENCE INDEX (1,2,3,...,LOWER,LE,(LASTZ-K+1))
C
C      LOWER=      KK-K+1
104 CONTINUE
    M=1
C      M SUBSCRIPTS ATOMIC NUMBERS IN THE MARI ARRAY
105 KMAHI=U(M)
    IF (KMAHI .EQ. KK) GO TO 107
    IF (KMAHI .EQ. 0) GO TO 103
C      THE ABOVE OCCURS WHENEVER THE KK-TH ELEMENT IS NOT IN THE MARI
C      DECK
106 CONTINUE
    MEM= KMAHI+ 2
    GO TO 105
107 CONTINUE
C      AT THIS POINT THE KK-TH ELEMENT HAS BEEN LOCATED
C      ITS LOWER-TH IONIZATION POTENTIAL WILL BE USED
C
C      TEST LOWER-TH IONIZATION POTENTIAL. IF ZERO, SKIP TO NEXT ELEMENT.
C      IF (KMAHI.LT.LOWER) GO TO 103
C
C      INDEX=M+1+ LOWER
C      IF (ABS(U(INDEX)).LT. 1.E-6 ) GO TO 103
C      WE NOW HAVE A VALID DATUM AND CAN ENTER IT INTO THE Y ARRAY.
    LSTORE=      LSTORE+1
    X(LSTORE)=    LOWER+LSTEP
    Y(LSTORE)=    U(INDEX)
    IF (LREDUC.NE.0) Y(LSTORE)=Y(LSTORE)/X(LSTORE)
    MAINO(LSTORE)= KK
    MARIAN(KK,LOWER)=U(INDEX)
103 CONTINUE
C      AT THIS POINT, THE X AND Y ARRAYS HAVE BEEN SET UP.
C      THERE ARE LSTORE ENTRIES IN THESE ARRAYS
    LORDER=LORDER
    ILORDN=LORDER+1
    IF (LSTORE .LT. ILORDN .AND. LORDER .EQ. 4) LORDER=2
C
C
C
    CALL FIT (X, Y, LSTORE, LORDER, DEVEAT, IM, COE)
    IF (IM) 201,202,201
201 CONTINUE
    WRITE(6,7703)LSTORE,LORDER,LOWER,(Y(J),MATNO(J),J=1,LSTORE)
    CALL DEBUG(201,202,NEXT)
    GO TO 500
202 CONTINUE
    IF (LORDER.NE.LORDER) ILORDN=LORDER+1

```


AFWL-TR-67-131, Vol IV

```

      DO 203 J=1, ILOWUR
      COEF( J, K ) = COE( J )
203  CONTINUE
      LMS(LOWUR+8)
C
C      EVALUATE SEQUENCE FROM POLYNOMIAL
      DO 204 J=1, LOWER
      XJ=J
      KATNO( J ) = K-1+J
      POTENL( J ) = COE( 1 )
      DO 91 I=2, ILOWUR
      POTENL( J ) = POTENL( J ) + COE( I ) * ( XJ ** ( I - 1 ) )
91  CONTINUE
      KKATNO = KATNO( J )
      IF ( MARIAN( KKATNO, J ) .EQ. 0 ) MARIAN( KKATNO, J ) = POTENL( J )
204  CONTINUE
C
      NUXI=LOWER+1
C
      WRITE( 6, 7703 ) LSTORE, LOWUR, LOWER, ( Y( J ), MATNO( J ), J=1, LSTORE )
7703  FORMAT( 6H USING 13.25H IONIZATION POTENTIALS, 3X, 15H A FIT OF ORDER
      1, 12, 8H TO THE 13.26H-1H ISOELECTRONIC SEQUENCE, 3X, 4H WITH, 3X,
      212H INPUT VALUE 18H AT ATOMIC NUMBER / ( 10X, 1PE10.4, 14X, 13 ) )
C
      WRITE( 6, 7702 ) ( KATNO( J ), J, POTENL( J ), J=1, LOWER )
7702  FORMAT( 21H HAS A FIT EVALUATION, 318H FOR Z = 13.6H AT J = 13.11H, A
      1 VALUE OF, 1PE9.1, 3X ) )
C
      7704  FORMAT( 29H FURTHER EVALUATED VALUES ARE / ( 3X, 4H Z = 13.3X, 4H J =,
      1 13.1PE15.8 ) )
C
      IF ( LOWUR .EQ. 4 ) WRITE( 6, 7705 ) ( COE( J ), J=1, 5 )
      IF ( LOWUR .EQ. 2 ) WRITE( 6, 7707 ) ( COE( J ), J=1, 3 )
7705  FORMAT( 21H USING THE POLYNOMIAL, 5X, 1PE14.8, 6H +J*, 1PE14.8,
      1 7H +J*J*, 1PE14.8, 10H +J**3*, 1PE14.8, 10H +J**4*, 1PE14.8 )
C
      7707  FORMAT( 21H USING THE POLYNOMIAL, 5X, 1PE14.8, 6H +J*, 1PE14.8,
      1 7H +J*J*, 1PE14.8 )
C
      WRITE( 6, 7703 ) DEVAL
7703  FORMAT( 28H THE STANDARD DEVIATION WAS, 1PE12.5 )
C
C
C      MORE=0 FIT Z=93 TO 100 WITH INPUT IF AVAILABLE, OUTPUT IF NOT
C      MORE=1 FIT Z=93 TO 100 WITH INPUT ONLY
C      MORE=2 FIT Z=93 TO 100 WITH OUTPUT ONLY
C      MORE = 3 MYPASS FIT OF 2.61.92
      IF ( MORE .EQ. 3 ) GO TO 500
      IF ( MORE .EQ. 1 ) GO TO 301
C
      PATH FOR MORE.EQ.2.OR.MORE.EQ.0
      XX( 3 ) = LOWER
      YY( 3 ) = POTENL( LOWER )
      XX( 2 ) = LOWER-1
      YY( 2 ) = POTENL( LOWER-1 )
      XX( 1 ) = LOWER-2

```

AFWL-TR-67-131, Vol IV

```

      YY(1)=POTENL(LOWER-2)
      IF (MORE.NE.0) GO TO 302
      IF (MAINU(LSTORE) .EQ. KAINU(LOWER)) YY(3)=Y(LSTORE)
      IF (MAINU(LSTORE-1) .EQ. KAINU(LOWER-1)) YY(2)=Y(LSTORE-1)
      IF (MAINU(LSTORE-2) .EQ. KAINU(LOWER-2)) YY(1)=Y(LSTORE-2)
302  CONTINUE
      WRITE (6,7110)
7110  FORMAT (30HINPUT TO THE QUADRATIC FIT IS /)
      DO 401 LY=1,3
      LTY=LOWER-3+LY
      LTTY=AX(LTY)
      WRITE (6,7109) KAINU(LTY),LTTY,YY(LTY)
7109  FORMAT (5X,10H ATOMIC NUMBER ,13,10H WITH J = ,13,
      120H AN IONIZATION POTENTIAL OF ,1PE15.8)
401  CONTINUE
      GO TO 303
303  CONTINUE
C    PAIR FOR MORE = 1
      XX(1)=X(LSTORE-2)
      XX(2)=X(LSTORE-1)
      XX(3)=X(LSTORE)
      YY(1)=Y(LSTORE-2)
      YY(2)=Y(LSTORE-1)
      YY(3)=Y(LSTORE)
      DO 100 LX=1,3
      LXX=LSTORE-3+LX
      LXXX=AX(LX)
      WRITE (6,7109) MAINU(LXX),LXXX,YY(LX)
100  CONTINUE
303  CONTINUE
      CALL F11 (XX,YY,L3,L2,DEVIAT,IM2,COE2)
      IF (IM2) 2001,2002,2003
2001  CONTINUE
      WRITE (6,7003) L3,L2,(YY(J),MAINU(J),J=1,3)
      CALL DEBUG(2001,2002,NEXT)
      GO TO 500
2002  CONTINUE
      DO 2003 J=6,8
      COE1(J,K)=COE2(J-5)
2003  CONTINUE
C
C
      DO 2004 J=NXST,LAST
      XJ=XJ
      KAINU(J)=K-1+J
      POTENL(J)=COE2(1)+COE2(2)*XJ+XJ*XJ*COE2(3)
      KKAINU=KAINU(J)
      MAKIAN(KKAINU,J)=POTENL(J)
2004  CONTINUE
      WRITE (6,7704) (KAINU(J), J, POTENL(J), J=NXST,LAST)
      WRITE (6,7707) COE2
      WRITE (6,7003) DEVIAT
C
C
500  CONTINUE

```

AFWL-TR-67-131, Vol IV

```

      WRITE (6,7006)
7006 FORMAT (11H1)
C
C
      DO 600 J=1,100
      IF (J.GT.92 .AND. MORE.EQ.3 ) GO TO 600
      WRITE (6,7007) J
7007 FORMAT (20HUFOR ELEMENT NUMBER ,15, 31H, THE IONIZATION POTENTIALS
      1 ARE)
C
C
      DO 601 J2=1,J      ,10
      J4= MIN0(J2+9,J    )
      WRITE (6,7005)      J2,(MARIAN(J,J3), J3=J2,J4)
7005 FORMAT ( 1X,13,3X,1P10E12.5)
C
      601 CONTINUE
      600 CONTINUE
C
      JLORDR=ILORDR+3
      IF (MORE.EQ.3) JLORDR=ILORDR
      IF (JLORDR.EQ.8)
      1 WRITE (6,7706) (J,(COEF(JJ,J),JJ=1,JLORDR),J=1,KCOUNT)
7706 FORMAT (14H1COEF ARRAY 15/(4X,13,1P5E15.8,3X,1P3E15.8))
      IF (JLORDR.EQ.6)
      1 WRITE (6,7708) (J,(COEF(JJ,J),JJ=1,JLORDR),J=1,KCOUNT)
7708 FORMAT (14H1COEF ARRAY 15/(4X,13,1P3E15.8,3X,1P3E15.8))
      IF (JLORDR.EQ.5)
      1 WRITE (6,7710) (J,(COEF(JJ,J),JJ=1,JLORDR),J=1,KCOUNT)
7710 FORMAT (14H1COEF ARRAY 15/(4X,13,1P5E15.8))
      IF (JLORDR.EQ.3)
      1 WRITE (6,7709) (J,(COEF(JJ,J),JJ=1,JLORDR),J=1,KCOUNT)
7709 FORMAT (14H1COEF ARRAY 15/(4X,13,1P3E15.8))
      GO TO 1
C
      CALL MARIE
      RETURN
      END

```

LOWRGO specifies the index of the first term in the isoelectronic sequence that is actually used in the calculation

LOWERZ specifies the lowest atomic number that can be used in a calculation

NEXT is a debug parameter

LORDER specifies the order of the polynomial fit

LREDUC = 0 uses ionization potentials; LREDUC \neq 0 uses (ionization potentials / term index) in the input to the polynomial fit

MORE is used to decide on extrapolations for atomic numbers > 92

All sequences between the (KSTART)-th and the (KEND)-th inclusive are done. The kth sequence fits the (LASTZ-k+1) ionization potentials:

$$V_1^k, V_2^{k+1}, \dots, V_{\text{LOWER}}^{kk}, \dots, V_{\text{LASTZ}-k+1}^{\text{LASTZ}}$$

(unless some of the initial members of the sequence are for elements with atomic numbers less than LOWERZ, in which case these terms are not used in the input to the least-squares fit). If the sequence of known ionization potentials contains less than 5 terms, a 2nd-order fit is tried even if LORDER = 4.

MARIER has been used with the block data program MARIE (see separate writeup) to calculate a tentative set of ionization potentials for the first 92 elements. Where present, experimental values have been used. (The sources for these are listed in the MARIE writeup.) Some further work on this task is needed; however, it is felt that further value changes will be within 10 percent of the presently assigned value.

MARIE: A BLOCK DATA PROGRAM OF IONIZATION POTENTIALS

The MARIE program is an intermediate step toward the final completion of the MARI block data program, a table of the ionization potentials of the elements. (See the writeup of program MARIER.)

AFWL-TR-67-131, Vol IV

SUBROUTINE MARIE

LAST COMPILED FEB. 9, 1966 BY GARY LANE

THIS DECK CONTAINS FOR ALL ELEMENTS PRESENT
A TABLE MADE UP OF THE FOLLOWING QUANTITIES, IN ORDER
ATOMIC NUMBER OF THE ELEMENT
ATOMIC WEIGHT OF THE ELEMENT
IONIZATION POTENTIALS OF THE ELEMENT
EITHER ALL IONIZATION POTENTIALS ARE ENTERED IN
• STRICTLY MONOTONIC ORDER OR MISSING ONES ARE ENTERED
AS ZERO

DATA TAKEN FROM NBS 270-1, NBS 270-2, M.H. GANSTANG I.A.U. SYMP. 20
(1966), ALLENS ASTROPHYSICAL TABLES, 3RD ED., AND BERNE HUNS (USED
FOR XE, W, AND U).

COMMON/LMSB/H (3)	H	1MAH
DATA H/1., 1.008, 13.598/	H	2MAH
COMMON/LMSB/HE (4)	HE	1MAH
DATA HE/2., 4.0026, 24.586, 54.403/	HE	2MAH
COMMON/LMSB/LI (5)	LI	1MAH
REAL LI	LI	2MAH
DATA LI/3., 6.939, 5.39, 75.619, 122.419/	LI	3MAH
COMMON/LMSB/BE (6)	BE	1MAH
DATA BE/4., 9.0122, 9.32, 18.206, 153.85, 217.657/	BE	2MAH
COMMON/LMSB/B (7)	B	1MAH
DATA B/5., 10.811, 8.297, 25.155, 37.929, 259.36, 340.21/	B	2MAH
COMMON/LMSB/C (8)	C	1MAH
DATA C/6., 12.0112, 11.259, 24.382, 47.876, 64.492, 392.08,	C	2MAH
1 489.95/	C	3MAH
COMMON/LMSB/N (9)	N	1MAH
REAL N	N	2MAH
DATA N/7., 14.0067, 14.532, 29.612, 47.438, 77.469, 97.886,	N	3MAH
1 552.06, 666.99/	N	4MAH
COMMON/LMSB/O (10)	O	1MAH
DATA O/8., 15.999, 13.618, 35.155, 54.947, 77.413, 113.9,	O	2MAH
1 138.12, 139.3, 87.134/	O	3MAH
COMMON/LMSB/F (11)	F	1MAH
DATA F/9., 18.9984, 17.42, 34.986, 62.66, 87.255, 114.24,	F	2MAH
1 157.16, 185.18, 953.8, 1102.7/	F	3MAH
COMMON/LMSB/NE (12)	NE	1MAH
REAL NE	NE	2MAH
DATA NE/10., 20.189, 21.564, 41.082, 63.76, 97.18, 126.4,	NE	3MAH
1 157.91, 207.2, 239.1, 1195.6, 1360.4/	NE	4MAH

AFWL-TR-67-131, Vol IV

C	COMMON/LMSB/NA (13)	
	REAL NA	NA 1MAH1
	DATA NA/11.: 22.9898, 5.138, 47.29, 71.65, 98.88, 138.37,	NA 2MAH1
	1 172.09, 208.444, 264.155, 299.78, 1464.8, 1646.1/	NA 3MAH1
		NA 4MAH1
C	COMMON/LMSB/MG (14)	
	REAL MG	MG 1MAH1
	DATA MG/12.: 24.312, 7.644, 15.031, 80.12, 109.29, 141.23,	MG 2MAH1
	1 186.49, 224.9, 265.957, 327.9, 367.36, 1761.2, 1959./	MG 3MAH1
		MG 4MAH1
C	COMMON/LMSB/AL (15)	
	DATA AL/13.: 26.9815, 5.986, 18.828, 28.448, 119.98, 153.81,	AL 1MAH1
	1 190.47, 241.99, 285.2, 330.22, 398.64, 441.96, 2085.5,	AL 2MAH1
	2 2299./	AL 3MAH1
		AL 4MAH1
C	COMMON/LMSB/SI (16)	
	DATA SI/14.: 28.086, 8.1509, 16.343, 33.467, 45.141, 166.76,	SI 1MAH1
	1 205.16, 246.49, 303.93, 351.89, 401.37, 476.17, 523.39,	SI 2MAH1
	2 2436., 2666./	SI 3MAH1
		SI 4MAH1
C	COMMON/LMSB/P (17)	
	DATA P/15.: 30.9738, 10.484, 19.72, 30.156, 51.354, 65.007,	P 1MAH1
	1 220.414, 263.31, 309.26, 371.6, 424.3, 479.4, 560.3,	P 2MAH1
	2 611.4, 2815., 3061./	P 3MAH1
		P 4MAH1
C	COMMON/LMSB/S (18)	
	DATA S/16.: 32.004, 10.4, 23.41, 35.04, 47.292, 72.48,	S 1MAH1
	1 88.03, 281., 328.82, 378.95, 447., 505.8, 566.,	S 2MAH1
	2 651., 706., 3220., 3482./	S 3MAH1
		S 4MAH1
C	COMMON/LMSB/CL (19)	
	DATA CL/17.: 33.453, 13.02, 23.804, 39.913, 53.455, 67.815,	CL 1MAH1
	1 96.7, 114.3, 348.4, 400.85, 455.4, 530.9, 593.,	CL 2MAH1
	2 663., 749., 807., 3654., 3931./	CL 3MAH1
		CL 4MAH1
C	COMMON/LMSB/AN (20)	
	DATA AN/18.: 39.948, 15.759, 27.626, 40.891, 59.8, 75.02,	AN 1MAH1
	1 91.32, 124., 143.49, 422.6, 479.4, 538.9, 621.,	AN 2MAH1
	2 687., 755., 854., 916., 4115., 4407./	AN 3MAH1
		AN 4MAH1
C	COMMON/LMSB/K (21)	
	REAL K	K 1MAH1
	DATA K/19.: 39.102, 4.339, 31.81, 46., 60.9, 82.6,	K 2MAH1
	1 99.7, 118., 155., 175.94, 503.8, 564., 629.,	K 3MAH1
	2 717., 788., 870., 966., 1031., 4603., 4910./	K 4MAH1
		K 5MAH1
C	COMMON/LMSB/CA (22)	
	DATA CA/20.: 40.086, 11.1, 11.868, 51.21, 67.84, 39.109, 128., 143.3,	CA 1MAH1
	1 188., 211.3, 591.8, 655., 727., 820., 896., 990., 1084., 1153., 5119., 5471./	CA 2MAH1
		CA 3MAH1
C	COMMON/LMSB/SC (23)	
	DATA SC/21.: 44.956, 6.54, 12.8, 24.75, 73.9, 92.,	SC 1MAH1
	1 111., 139., 159., 180., 226., 250., 687.,	SC 2MAH1
	2 758., 830., 930., 1010., 1115., 1210., 1282.,	SC 3MAH1
		SC 4MAH1

AFWL-TR-67-131, Vol IV

C	3 5483.3, 6035.4/	SC 5MAHI
	COMMON/LMSB/I1 (24)	I1 1MAHI
	DATA I1/22., 47.9, 6.82, 13.57, 27.47, 43.24, 44.8,	I1 2MAHI
	1 120., 141., 172., 193., 217., 266., 2.1.,	I1 3MAHI
	2 788., 864., 941., 1046., 1132., 1245., 1341.,	I1 4MAHI
	3 1417.8, 6049.3, 6627.7/	I1 5MAHI
C	COMMON/LMSB/V (25)	V 1MAHI
	DATA V/ 23., 50.942, 6.74, 14.65, 29.4, 48., 65., 129., 151.,	V 2MAHI
	1174., 206., 230.5, 258., 309., 336., 897., 976., 1057., 1170.,	V 3MAHI
	21200., 1380., 1480.5, 1560.3, 6643.8, 7248.4/	V 4MAHI
C	COMMON/LMSB/LR (26)	CR 1MAHI
	DATA LR/24., 51.996, 6.764, 16.49, 30.95, 50., 73.,	CR 2MAHI
	1 91., 161., 185., 210., 249., 272., 299.,	CR 3MAHI
	2 355., 384., 1013., 1095., 1182., 1301., 1395.,	CR 4MAHI
	3 1525.2, 1626.3, 1709.7, 7266.7, 7897.4/	CR 5MAHI
C	COMMON/LMSB/MN (27)	MN 1MAHI
	REAL MN	MN 2MAHI
	DATA MN/25., 54.938, 7.433, 15.636, 33.64, 53., 76.,	MN 3MAHI
	1 100., 119., 196., 222., 248., 288., 315.,	MN 4MAHI
	2 350., 404., 435., 1136., 1222., 1313., 1438.,	MN 5MAHI
	3 1538., 1678., 1774., 1860., 7918., 8575.7/	MN 6MAHI
C	COMMON/LMSB/FE (28)	FE 1MAHI
	DATA FE/26., 55.847, 7.87, 16.18, 30.643, 57., 79.,	FE 2MAHI
	1 103., 130., 151., 275., 262., 290., 330.,	FE 3MAHI
	2 355., 390., 457., 464., 1206., 1354., 1450.,	FE 4MAHI
	3 1513., 1687., 1837., 1938., 2029., 8599., 9281.7/	FE 5MAHI
C	COMMON/LMSB/CO (29)	CO 1MAHI
	DATA CO/27., 58.9332, 7.86, 17.05, 33.49, 53., 83., 108., 134., 164., 190.,	CO 2MAHI
	1290., 305., 337., 380., 412., 444., 512., 547., 1403., 1495., 600., 9307.7,	CO 3MAHI
	210016.7/	CO 4MAHI
C	COMMON/LMSB/NI (30)	NI 1MAHI
	REAL NI	NI 2MAHI
	DATA NI/28., 58.71, 7.633, 18.15, 35.16, 56., 79., 112., 140., 169., 202.,	NI 3MAHI
	1230., 321., 350., 385., 430., 455., 500., 530., 607., 1541., 700., 10046.,	NI 4MAHI
	210780.7/	
C	COMMON/LMSB/CO (31)	CO 1MAHI
	DATA CO/29., 63.54, 7.724, 20.29, 36.83, 59., 82., 110., 140., 170.,	CO 2MAHI
	1206., 241., 265., 370., 400., 440., 480., 520., 560., 630., 671.,	CO 3MAHI
	21694., 1796., 1905., 2057., 2175., 2360., 2458., 2559., 10813.,	CO 4MAHI
	311573.7/	CO 5MAHI
C	COMMON/LMSB/ZN (32)	ZN 1MAHI
	DATA ZN/30., 65.37, 9.391, 17.96, 39.7, 62., 86., 115., 145., 180., 210.,	ZN 2MAHI
	1250., 0., 311., 420., 450., 490., 540., 580., 620., 700., 900., 11610.,	ZN 3MAHI
	212395.7/	ZN 4MAHI
C	COMMON/LMSB/GA (33)	GA 1MAHI

AFWL-TR-67-131, Vol IV

	DATA GA/31.: 69./2. 6.: 20.511, 30.684, 64.18, 90.,	GA 2MAH1
	1 114., 144., 174., 218., 255.,	GA 3MAH1
	2 190., 12436., 13246./	GA 4MAH1
C	COMMON/LMSB/GE (34)	
	DATA GE/32.: 72.59, 7.885, 15.934, 34.223, 45.711, 93.447,	GE 1MAH1
	1 113., 148., 177., 212., 262.,	GE 2MAH1
	2 200., 13291., 14127./	GE 3MAH1
C	COMMON/LMSB/AS (35)	
	DATA AS/33.: 74.9216, 9.815, 20.209, 28.317, 50.134, 62.626,	AS 1MAH1
	1 127.55, 150., 182., 218., 253.,	AS 2MAH1
	2 210., 14176., 15037./	AS 3MAH1
C	COMMON/LMSB/SE (36)	
	DATA SE/34.: 78.9649, 75.21.5, 32., 43., 68., 82., 155., 167., 223., 260.,	SE 1MAH1
	12200., 15042., 15977./	SE 2MAH1
C	COMMON/LMSB/SH (37)	
	DATA SH/35.: 79.909, 11.84, 21.6, 35.9, 47.3, 59.7,	SH 1MAH1
	1 88.6, 103., 193., 228., 266.,	SH 2MAH1
	2 230., 16037., 16947./	SH 3MAH1
C	COMMON/LMSB/KH (38)	
	REAL KH	SH 4MAH1
	DATA KH/36.: 83.8, 13.999, 24.571, 36.951, 52., 65.,	KH 1MAH1
	1 79., 110., 126., 234., 270.,	KH 2MAH1
	2 240., 17013., 17947./	KH 3MAH1
C	COMMON/LMSB/KB (39)	
	DATA KB/37.: 85.47, 4.176, 27.5, 40., 52., 71.,	KB 1MAH1
	1 85., 100., 135., 151., 277.,	KB 2MAH1
	2 230., 18019., 18978./	KB 3MAH1
C	COMMON/LMSB/SK (40)	
	DATA SK/38.: 87.62, 5.692, 11.027, 43., 57., 72.,	SK 1MAH1
	1 92., 107., 124., 162., 179., 324.,	SK 2MAH1
	2 230., 19055., 20038./	SK 3MAH1
C	COMMON/LMSB/T (41)	
	DATA T/39.: 88.905, 6.38, 12.23, 20.5, 62., 77.,	T 1MAH1
	1 93., 116., 131., 148., 191., 206.,	T 2MAH1
	2 260., 20123., 21130./	T 3MAH1
C	COMMON/LMSB/ZH (42)	
	DATA ZH/40.: 91.22, 6.84, 13.13, 22.98, 34.33, 82., 99., 117., 141., 157.,	ZH 1MAH1
	1176., 222., 270., 21221., 22252./	ZH 2MAH1
C	COMMON/LMSB/NB (43)	
	REAL NB	ZH 3MAH1
	DATA NB/41.: 92.906, 6.88, 14.32, 25.04, 38.3, 50.,	NB 1MAH1
	1 103., 125., 143., 167., 185., 203.,	NB 2MAH1
	2 280., 22351., 23406./	NB 3MAH1
C	COMMON/LMSB/MO (44)	
		NB 4MAH1
		NB 5MAH1
		MO 1MAH1

AFWL-TR-67-131, Vol IV

	REAL MU		MU 2MAHI
	DATA MU/42., 95.94, 7.1, 16.15, 27.13, 46.4, 61.2,		MU 3MAHI
	1 68., 126., 153., 169., 197., 210.,		MU 4MAHI
	2 290., 23513., 24590./		MU 5MAHI
C	COMMON/LMSB/IC (45)		IC 1MAHI
	DATA IC/43., 99., 7.28, 15.26, 31., 43., 59., 76., 94., 161., 183., 199.,		IC 2MAHI
	1224., 3000., 24706., 25807./		IC 3MAHI
C	COMMON/LMSB/HU (46)		HU 1MAHI
	DATA HU/44., 101.07, 7.364, 16.76, 28.46, 46., 63., 81., 100., 119., 193.,		HU 2MAHI
	1216., 225., 3100., 25931., 27056./		HU 3MAHI
C	COMMON/LMSB/KH (47)		KH 1MAHI
	DATA KH/45., 102.903, 7.46, 18.07, 31.05, 46., 67.,		KH 2MAHI
	1 85., 105., 126., 147., 226., 250.,		KH 3MAHI
	2 320., 27189., 28336./		KH 4MAHI
C	COMMON/LMSB/PU (48)		PU 1MAHI
	DATA PU/46., 106.4, 8.33, 19.42, 32.92, 49., 66., 90., 110., 132., 155.,		PU 2MAHI
	1178., 261., 3300., 28478., 29648./		PU 3MAHI
C	COMMON/LMSB/AG (49)		AG 1MAHI
	DATA AG/47., 107.87, 7.574, 21.48, 34.82, 52., 70.,		AG 2MAHI
	1 89., 116., 139., 162., 187.,		AG 3MAHI
	2 350., 29801., 30993./		AG 4MAHI
C	COMMON/LMSB/CO (50)		CO 1MAHI
	DATA CO/48., 112.4, 8.991, 16.92, 38.2, 55., 73.,		CO 2MAHI
	1 94., 115., 146., 170., 195.,		CO 3MAHI
	2 360., 31156., 32371./		CO 4MAHI
C	COMMON/LMSB/IN (51)		IN 1MAHI
	REAL IN		IN 2MAHI
	DATA IN/49., 114.82, 5.786, 18.869, 28.029, 54.41, 77.,		IN 3MAHI
	1 98., 120., 144., 178., 204.,		IN 4MAHI
	2 370., 32545., 33782./		IN 5MAHI
C	COMMON/LMSB/SN (52)		SN 1MAHI
	DATA SN/50., 118.69, 7.344, 14.632, 30.524, 40.733, 72.273,		SN 2MAHI
	1 103., 126., 150., 176., 213.,		SN 3MAHI
	2 380., 33968., 35227./		SN 4MAHI
C	COMMON/LMSB/SB (53)		SB 1MAHI
	DATA SB/51., 121.75, 8.641, 16.53, 25.32, 44.156, 55.7,		SB 2MAHI
	1 107.6, 132., 157., 184., 211.,		SB 3MAHI
	2 390., 35425., 36705./		SB 4MAHI
C	COMMON/LMSB/TE (54)		TE 1MAHI
	DATA TE/52., 127.6, 9.01, 18.6, 30.6, 37.81, 60.27,		TE 2MAHI
	1 72.33, 137.2, 164., 192., 220.,		TE 3MAHI
	2 400., 36916., 38217./		TE 4MAHI
C	COMMON/LMSB/I (55)		I 1MAHI
	REAL I		I 2MAHI

AFWL-TR-67-131, Vol IV

	DATA 1/53., 126.9044, 10.456, 19.099, 32., 42., 66.,	I 3MAH I
	1 81., 99., 170., 200., 229.,	I 4MAH I
	2 4100., 38441., 39764./	I 5MAH I
C	COMMON/LMSB/XE (56)	
	DATA XE/54., 131.3, 12.129, 21.21, 32.12, 38.3, 51.5,	XE 1MAH I
	1 64.2, 91.4, 106.6, 175.2, 196.2, 218.6, 242.3,	XE 2MAH I
	2 267.4, 293.6, 323.6, 352.6, 382.7, 414., 443.6,	XE 3MAH I
	3 563.8, 599.2, 635.9, 690.8, 730., 753., 864.,	XE 4MAH I
	4 1521., 1582., 1642., 1712., 1782., 1854., 1945.,	XE 5MAH I
	5 2025., 2106., 2461., 2471., 2559., 2649., 2742.,	XE 6MAH I
	6 2919., 3022., 3224., 3330., 7632., 7822., 8020.,	XE 7MAH I
	7 8234., 8821., 9082., 9528., 9802., 40260., 41430./	XE 8MAH I
		XE 9MAH I
C	COMMON/LMSB/CS (57)	
	DATA CS/55., 132.905, 3.893, 25.1, 35., 46., 62.,	CS 1MAH I
	1 74., 101., 120., 144., 253.,	CS 2MAH I
	2 4300., 41597., 42962./	CS 3MAH I
		CS 4MAH I
C	COMMON/LMSB/BA (58)	
	DATA BA/56., 137.34, 5.21, 10.001, 36., 49., 62.,	BA 1MAH I
	1 80., 93., 120., 143., 157.,	BA 2MAH I
	2 4400., 43229., 44613./	BA 3MAH I
		BA 4MAH I
C	COMMON/LMSB/LA (59)	
	REAL LA	LA 1MAH I
	DATA LA/57., 138.91, 5.61, 11.43, 19.17, 52., 66.,	LA 2MAH I
	1 80., 100., 114., 144., 165., 204.,	LA 3MAH I
	2 4400., 44897., 46301./	LA 4MAH I
		LA 5MAH I
C	COMMON/LMSB/CE (60)	
	DATA CE/58., 140.12, 5.6, 12.3, 20., 35., 70.,	CE 1MAH I
	1 85., 100., 122., 137., 165., 189.,	CE 2MAH I
	2 4500., 46601., 48025./	CE 3MAH I
		CE 4MAH I
C	COMMON/LMSB/PK (61)	
	DATA PK/59., 140.907, 5.48, 0., 23.2, 200.,	PK 1MAH I
	1 89., 106., 122., 146., 162., 197.,	PK 2MAH I
	2 4600., 48342., 49785./	PK 3MAH I
		PK 4MAH I
C	COMMON/LMSB/NU (62)	
	REAL NU	NU 1MAH I
	DATA NU/60., 144.24, 5.5, 400.,	NU 2MAH I
	1 100., 110., 128., 147., 171.,	NU 3MAH I
	2 4800., 50120., 51582./	NU 4MAH I
		NU 5MAH I
C	COMMON/LMSB/PM (63)	
	DATA PM/61., 147., 700., 135., 154., 173., 4900., 51936., 53417./	PM 1MAH I
		PM 2MAH I
C	COMMON/LMSB/SM (64)	
	DATA SM/62., 150.35, 5.6, 11.3,	SM 1MAH I
	1 5800., 53790., 55290./	SM 2MAH I
		SM 3MAH I
C	COMMON/LMSB/EU (65)	
	DATA EU/63., 151.96, 5.67, 11.2700., 187., 5100., 55683., 57201./	EU 1MAH I
		EU 2MAH I

AFWL-TR-67-131, Vol IV

C	COMMON/LMSB/GU (66)	GU 1MAH1
	DATA GU/64.: 15/.25.6.16.12.: 60*U.: 57615.: 59151./	GU 2MAH1
C	COMMON/LMSB/TB (67)	TB 1MAH1
	DATA TB/65.: 158.924. 5.98.	TB 2MAH1
	1 62*U.: 59587.: 61140./	TB 3MAH1
C	COMMON/LMSB/UT (68)	UT 1MAH1
	DATA UT/66.: 162.5. 6.8. 63*U.: 61599.: 63169./	UT 2MAH1
C	COMMON/LMSB/HO (69)	HO 1MAH1
	DATA HO/67.: 164.93. 6..	HO 2MAH1
	1 64*U.: 63652.: 65239./	HO 3MAH1
C	COMMON/LMSB/EK (70)	EK 1MAH1
	DATA EK/68.: 16/.26. 6.08.	EK 2MAH1
	1 65*U.: 65746.: 67350./	EK 3MAH1
C	COMMON/LMSB/IM (71)	IM 1MAH1
	DATA IM/69.: 168.934. 6..	IM 2MAH1
	1 66*U.: 67882.: 69502./	IM 3MAH1
C	COMMON/LMSB/TH (72)	TH 1MAH1
	DATA TH/70.: 173.04.6.2.12.1.66*U.: 70062.: 71696./	TH 2MAH1
C	COMMON/LMSB/LU (73)	LU 1MAH1
	REAL LU	LU 2MAH1
	DATA LU/71.: 174.97. 6.1. 15.. 19..	LU 3MAH1
	1 66*U.: 72284.: 73933./	LU 4MAH1
C	COMMON/LMSB/HF (74)	HF 1MAH1
	DATA HF/72.: 178.49. 7.. 14.9. 25.3. 33.1.	HF 2MAH1
	1 66*U.: 74550.: 76214./	HF 3MAH1
C	COMMON/LMSB/IA (75)	IA 1MAH1
	DATA IA/73.: 180.948. 7.88. 16.2. 22.. 33.. 45..	IA 2MAH1
	1 66*U.: 76860.: 78539./	IA 3MAH1
C	COMMON/LMSB/W (76)	W 1MAH1
	DATA W/74.: 163.85.7.98.17.7.24.35.48.61.114.3.131.2.149.1.	W 2MAH1
	1168.200.222.276.300.309.338.369.401.434.468.504.541..	W 3MAH1
	2583.623.664.706.750.796.1045.1093.1142.1192.1244.1297..	W 4MAH1
	3136.1423.1481.1539.1758.1818.1880.1942.2101.2168.2333..	W 5MAH1
	42402.4032.4133.4238.4346.4457.4575.4767.4891.5020.5459..	W 6MAH1
	55590.5722.5857.5996.6498.6651.6970.7124.15545.15816..	W 7MAH1
	616109.16426.18209.18597.19275.19680.79377.81009./	W 8MAH1
C	COMMON/LMSB/HE (77)	HE 1MAH1
	DATA HE/75.: 186.2. 7.87. 16.6. 26.. 38.. 51..	HE 2MAH1
	1 64.. 79..	HE 3MAH1
	2 66*U.: 81618.: 83325./	HE 4MAH1
C	COMMON/LMSB/OS (78)	OS 1MAH1
	DATA OS/76.: 190.2.H.7.17.25.40.54.68.83.99.66*U.: 84067..	OS 2MAH1

BLANK PAGE

AFWL-TR-67-131, Vol IV

DATA HA/88..228.05.5.277.10.144.34..46..58..76..89..103..140..
1156..7600..117449..119287./ HA 2MAHI
HA 3MAHI

C
COMMON/LMSB/AC (91)
DATA AC/89..227..6.9.12.1.20..49..62..76..95..109..123..164..
17700..120600..122442./ AC 1MAHI
AC 2MAHI
AC 3MAHI

C
COMMON/LMSB/IM (92)
DATA IM/90..232.038. 6.95. 12.. 20.. 29.2. 65..
1 80.. 94.. 115.. 130.. 145..
2 7800.. 123809.. 125658./ IM 1MAHI
IM 2MAHI
IM 3MAHI
IM 4MAHI

C
COMMON/LMSB/PA (93)
DATA PA/91..231..500..84..100..115..138..154..
1 7900..127084..128938./ PA 1MAHI
PA 2MAHI
PA 3MAHI

C
COMMON/LMSB/U (94)
DATA U/92..235.04. 6.12. 11.45. 17.92. 31.12. 47.33. 62.83. 92.7. U 1MAHI
1105.7 119.1 149. 162.7 178.4 221.8.241. 339.3 363.4. U 2MAHI
2388.2.414..440.5.468..508..537.5.568..599..733.2.766.3.801..835.. U 3MAHI
3948..486..1091..1131..1354..1404..1455..1508..1562..1618..1675.. U 4MAHI
41733.. 1808.. 1869.. 1932.. 1997.. 2062..2130..2513..2581.. 2651.. U 5MAHI
52721..2795..2869..3003..3081..3160..3242..3355..3637..3720..3804.. U 6MAHI
64209..4300..4536..4629..7428..7562..7701..7844..7991..8146..8312.. U 7MAHI
8675..8843..9016..9593..9764..9938..10120..11370..11570..12000.. U 8MAHI
812220..25330..25670..26040..26440..30960..31460..32390..32920.. U 9MAHI
9130400..132300./ U 10MAHI
U 11MAHI

C
COMMON/LMSB/ENUWHU(2)
DATA ENUWHU/0..854./

C
RETURN
END

The way in which the MARI deck is used by the EIONX program and other equation-of-state subroutines requires that, if any given ionization potential is unknown, it and all higher ionization potentials must be replaced by zeros. The MARIE block data program is not held to this restriction and has zeros replacing only the unknown ionization potentials (and not any higher ones that may be known). However, it must have the elements entered in the order of increasing atomic number. The MARI block data program is ordered in the same fashion, but this is merely for reading ease and is not a requirement on the MARI program.

The potentials used in MARIE are taken from HELAS, which follows, and Allen (Ref. 5), Garstang (Ref. 6), Moore (Ref. 7), NBS tables (Ref. 8), Stewart and Rotenberg (Ref. 9), and Lotz (Ref. 10).

MARIE is a FORTRAN IV block data program used by many other programs as a source of the atomic weights and the ionization potentials of the elements. It is organized in the same fashion as the MARI block data program, namely:

1. For each element, in sequence as listed below:
 - a. The atomic number
 - b. The atomic weight
 - c. The ionization potentials

For any given element, those ionization potentials that are not known are entered as zero.

2. The MARIE deck has the elements entered in the order of increasing atomic number.

HELIKE: THE HELIUM ISOELECTRONIC SEQUENCE

HELIKE is one of two programs used to generate the ionization potentials of the helium sequence. (HELAS is the other program; refer to the HELAS writeup.) HELIKE is based on the development of Bethe and Salpeter.

1. $V_{Z-1}^Z = J_{NR} + E_j + \Delta E_j$ in Rydbergs
2. $J_{NR} = Z^2 - \frac{5}{4}Z + 0.315311 - 0.01707/Z + 0.00068/Z^2 + 0.00164/Z^3 + 0.00489/Z^4$
3. $E_j = \frac{1}{4}\alpha^2 Z^2 \{Z^2 - 3.606Z + 3.29 + 0.05/Z\}$
4. $\Delta E_j = \frac{-16Z^4\alpha^3}{3\pi} \{3.745 - \ln Z - \left(\frac{1}{Z}\right)(5.97 - 1.31 \ln Z) + (3.08 - 0.28 \ln Z)/Z^2\}$
5. $\alpha \equiv 1./137.037$

where V_{Z-1}^Z is the (Z-1)-st ionization potential of the element with atomic number Z.

The helium-sequence ionization potentials generated by the above equation appear to diverge from measured values for $Z > 17$. For this reason, the technique used in the HELAS program was next coded. A comparison tabulation follows the HELAS writeup.

HELAS: THE HELIUM ISOELECTRONIC SEQUENCE

HELAS is the second program used to generate the ionization potentials of the helium sequence (refer to the HELIKE writeup). HELAS is based on the paper by Brenner and Brown (Ref. 11).

The relativistic Dirac equation for the energy of a one-electron atom can be written:

$$E_{\text{DIRAC}} = -2(\beta_Z - 1)\alpha^2 \quad \text{in Rydbergs}$$

where

$$\beta_Z = [1 - (\alpha Z)^2]^{1/2} \quad \text{and } \alpha \equiv (1./137.037)$$

The two-electron-interaction energy can be expressed as

$$\gamma_Z = 2 [\beta_Z (2\beta_Z - 1)]^{-1} [-1 + 10\beta_Z - 2(\beta_Z)^2 - 4(\beta_Z)^3] \\ - 2 \left[\frac{2}{(3)(2\beta_Z + 1)\Gamma(2\beta_Z + 1)} \right] \left[\frac{\Gamma(2\beta_Z + 1)(-1 + 18\beta_Z - 2(\beta_Z)^2 - 12(\beta_Z)^3)}{2\pi^{1/2}\beta_Z} \right]$$

Then, the helium-sequence ionization potential is given by:

$$\phi_{Z-1}^Z = E_{\text{DIRAC}} - \gamma_Z \quad \text{in Rydbergs}$$

It proved necessary to normalize this equation to the value of V_1^{He} by using

$$X_{Z-1}^Z = \phi_{Z-1}^Z - (\phi_1^2 - V_1^2) \quad \text{in Rydbergs}$$

where V_1^2 is the (measured) first ionization potential of helium and $(\phi_1^2 - V_1^2)$ is thus an additive constant. The set of X_{Z-1}^Z ; $2 \leq Z \leq 92$ form the final program output. These values are tabulated together with the HELIKE values in table IV.

AFWL-TR-67-131, Vol IV

```

PROGRAM MELIKE(INPUT,OUTPUT,TAPE5=INPUT,TAPE6=OUTPUT)
C
C REFERENCE
C      BETHE AND SALPETER
C      QUANTUM MECHANICS OF ONE AND TWO ELECTRON SYSTEMS.
C      EQUATIONS (33.12), (41.11A), AND (41.12A)
C
C      DIMENSION V CM(100), V EV(100), JNR(100), EJ(100), DEL EJ(100)
C      REAL JNR
C      DATA PI/3.14159265/, HY CM/109737.31/, RT EV/13.6048/, ALF MI/137.
1      U37/
C
C      COMMON/LMSB/A(1)
C
C      ALFA= 1./ALF MI
C      ALFASQ= ALFA * ALFA
C
C
C      DO 1 I=2,100
C      Z=I
C      ZLN=ALOG(Z)
C      ZSQ=Z*Z
C      Z4TH= ZSQ*ZSQ
C
C      NON-RELATIVISTIC CONTRIBUTION
C      JNR(I)= ZSQ -1.25*Z +.315311 -1.707E-2/Z +6.8E-4/ZSQ +1.64E-3/Z
1      /ZSQ + 4.89E-3/Z4TH
C
C      RELATIVISTIC CONTRIBUTION
C      EJ(I)= .25 * ALFASQ *ZSQ + (ZSQ-3.606*ZLN +3.29 + .05/Z )
C      DEL EJ(I)= -16. * Z4TH *ALFASQ *ALFA/3./PI * (3.747-ZLN-(5.97-1.3
1      1*ZLN)/Z +(3.08-.28*ZLN)/ZSQ )
C
C      K=5
C
C      NYA CM= HY CM-60.22/A(K)
C      NYA EV= NYA CM * 1.23977E-4
C      K=K+2+IFIX(A(K-1))
C
C      SUM= JNR(I)+EJ(I)+DEL EJ(I)
C      V CM(I)= NYA CM * SUM
C      V EV(I)= NYA EV * SUM
1      CONTINUE
C
C
C      WRITE(6,2)
2      FORMAT(1H1)
C      WRITE(6,3)
3      FORMAT(53H THE 2 ELECTRON GROUND STATE IONIZATION POTENTIAL IS )
C      WRITE(6,4) ( I,V EV(I),V CM(I), JNR(I),EJ(I),DEL EJ(I),I=2,100)
4      FORMAT(1X, 7HFOR Z= ,I3, 9H: N E.V.,1PE13.6,13H (CM,IN /CM, ,E13.
10, 6H ), = ,E13.6, 7H JNR + ,E13.6, 6H EJ + , E13.6, 7H DEL EJ )
C      CALL EXIT
C      CALL MAHIE
C      RETURN
C      ENH

```

AFWL-TR-67-131, Vol IV

```

C      PROGRAM MELAS(INPUT,OUTPUT,TAPE5=INPUT,TAPE6=OUTPUT)
C
C      REFERENCE
C
C      S.BHENNEN AND G.E. BROWN
C      PROC. ROY. SOC. LONDON, SERIES A, VOL.218, P.422-432
C      (1953)
C
C
C      DIMENSION BETA(100), EDIRAC(100), BRACES(100), E TO E(100), ETOTEV(10
10), ETOT(100), ETOTEV(100), ETOT2(100), EVTOT2(100), EDHCEV(100)
C
C      DATA ALF M1/137.037,RY/13.6048/,SQHTPI/1.7724539 /,ME RY/1.8071
1 /, ME EV/24.585/
C
C      ALFA= 1./ALFM1
C      ALFSQ= ALFA*ALFA
C
C
C      DO 1 I=2,100
C      Z=I
C      ZSQ= Z*Z
C      BETA(1)=SQHT(1.-ALFSQ * ZSQ)
C      X=BETA(1)
C      EDIRAC(1)=-2.*(X-1.)/ALFSQ
C      EDHCEV(1)=EDIRAC(1)*RY
C      CALL GAMMA(2.*X+1.,GAM1,S2,S3)
C      CALL GAMMA(2.*X+.5,GAMHAF,S4,S3)
C      GO TO 4
C      3 CALL MEHH
C      4 CONTINUE
C      Y= 2.*X-1.
C      BRACES(1)= (-1.+X*(10. - X*(2.+4.*X)))/X/Y/3.
C      1 -2./GAM1/3./Y * GAMHAF * (-1.+ X*(10.-X*(2.+ 12.*X)))/
C      2 SQHTPI/2. /X
C      E TO E(1)= 2.* Z * BRACES(1)
C      ETOTEV(1)= E TO E(1) *RY
C      ETOT(1)= EDIRAC(1)-E TO E(1)
C      ETOTEV(1)=EDHCEV(1)-ETOTEV(1)
C      IF (1.61,2) GO TO 5
C      MELOT= ME RY-ETOT(2)
C      MELEV= ME EV-ETOTEV(2)
C      5 CONTINUE
C      ETOT2(1)= ETOT(1) + MELOT
C      EVTOT2(1) = ETOTEV(1)+MELEV
C      1 CONTINUE

```

AFWL-TR-67-131, Vol IV

```

C
C
C
      WRITE(6,7)
7  FORMAT(1H1)
      WRITE(6,8) MELOT, MLEV
8  FORMAT(1X,14HUSING MELOT = ,1PE15.8,2X, 12HAND MLEV = ,1PE15.8,
12H WE COMPUTE //1X,3H 2, 5X,7HBETA(2),4X,9HEUIRAC(2),3X,9HEOMCE
2V(2),3X,9HBRACES(2),3X,9HE 10 E(2),2X,10ME TO EV(2),4X,8HE TOT(2),
33X,9HLOTOTEV(2),3X,9HE 10T2(2),3X, 9HEVTO12(2))
      WRITE(6,9) (1,HE1A(1),EUIRAC(1),EOMCEV(1),BRACES(1),ETOE(1),
1  E10EV(1),ETOT(1),ETOTEV(1),ETOT2(1),EVTOT2(1), I=2,100)
9  FORMAT (1X,13,1PE12.6,1X,9E12.6)
      CALL EX11
C
      END
      IF (KMANI .EQ. KK) GO TO 107
      IF (KMANI .EQ. 0) GO TO 103
C
      THE ABOVE OCCURS WHENEVER THE KK-TH ELEMENT IS NOT IN THE MARI
      DECK
C
106 CONTINUE
      MEM= KMANI+ 2
      GO TO 105
107 CONTINUE
C
      AT THIS POINT THE KK-TH ELEMENT HAS BEEN LOCATED
C
      ITS LOWER-TH IONIZATION POTENTIAL WILL BE USED
C
C
      TEST LOWER-TH IONIZATION POTENTIAL. IF ZERO, SKIP TO NEXT ELEMENT.
      IF (KMANI.LT.LOWHZ) GO TO 103
C
      INDEX=M+1+ LOWER
      IF (ABS(U(INDEX)).LT. 1.E-8 ) GO TO 103
C
      WE NOW HAVE A VALID DATUM AND CAN ENTER IT INTO THE Y ARRAY.
      LSTORE= LSTORE+1
      X(LSTORE)= LOWER+LSTEP
      Y(LSTORE)= U(INDEX)
      IF (LREDUC.NE.0) Y(LSTORE)=Y(LSTORE)/X(LSTORE)
      MATNO(LSTORE)= KK
103 CONTINUE
C
      AT THIS POINT, THE X AND Y ARRAYS HAVE BEEN SET UP.
C
      THERE ARE LSTORE ENTRIES IN THESE ARRAYS
C
C
C
      CALL F11 (X, Y, LSTORE, LOWDER, DEVEAT, IM, COE)
      IF (IM) 201,202,201
201 CONTINUE
      WRITE(6,7703)LSTORE,LOWDER,LOWER,(Y(J),MATNO(J),J=1,LSTORE)
      CALL DEBUG(201,202,NEXT)
      GO TO 500
202 CONTINUE
      ILONDR=LOWDER+1
      DO 203 J=1,ILONDR
      COEF( J, K ) = COE(J)
203 CONTINUE

```

AFWL-TR-67-131, Vol IV

```

      LAST=LOWER+8
C
C      EVALUATE SEQUENCE FROM POLYNOMIAL
      DO 204 J=1,LOWER
      XJ=J
      KATNO(J)=K-1+J
      POTENL(J)=COE(1)
      DO 91 I=2,ILOORD
      POTENL(J)=POTENL(J)+COE(I)*(XJ**((I-1)))
91 CONTINUE
      KKATNO = KATNO(J)
      MAHIAN(KKATNO,J) = POTENL(J)
204 CONTINUE
C
      NUAT=LOWER+1
C
      WRITE(6,7703) LSTORE, LORDER, LOWER, (Y(J), MATNO(J), J=1, LSTORE)
7703 FORMAT(6H1USING,13,23H IONIZATION POTENTIALS,3X,15H A FIT OF ORDER
1,12,6H TO THE ,13,26H-1H ISOELECTRONIC SEQUENCE/3X,4H WITH,3X,
212H INPUT VALUE ,18H AT ATOMIC NUMBER /(10X,1PE10.4,14X,13))
C
      WRITE(6,7702) (KATNO(J), J, POTENL(J), J=1, LOWER)
7702 FORMAT(21H HAS A FIT EVALUATION/318H FOR Z =,13,6H AT J=,13,11H, A
1VALUE OF, 0PF9.1,3X))
C
7704 FORMAT(29H FURTHER EVALUATED VALUES ARE /(13X,4H Z =,13,3X,4H J =,
1 13,1PE15.8))
C
      WRITE(6,7705) COE
7705 FORMAT(21H USING THE POLYNOMIAL ,5X,1PE14.8,6H +J*,1PE14.8,
1 7H +J*J*,1PE14.8,10H +J**3*,1PE14.8,10H +J**4*,1PE14.8)
C
7707 FORMAT(21H USING THE POLYNOMIAL ,5X,1PE14.8,6H +J*,1PE14.8,
1 7H +J*J*,1PE14.8)
C
      WRITE(6,7703) DEVEAT
7703 FORMAT(28H THE STANDARD DEVIATION WAS ,1PE12.5 )
C
C
C      MORE=0 FIT Z=93 TO 100 WITH INPUT IF AVAILABLE, OUTPUT IF NOT
C      MORE=1 FIT Z=93 TO 100 WITH INPUT ONLY
C      MORE=2 FIT Z=93 TO 100 WITH OUTPUT ONLY
      IF (MORE .EQ. 1) GO TO 301
      PATH FOR MORE.EQ.2.OR.MORE.EQ.0
      XX(3)=LOWER
      YY(3)=POTENL(LOWER)
      XX(2)=LOWER-1
      YY(2)=POTENL(LOWER-1)
      XX(1)=LOWER-2
      YY(1)=POTENL(LOWER-2)
      IF (MORE.NE.0) GO TO 302
      IF (MATNO(LSTORE) .EQ. KATNO(LOWER)) YY(3)=Y(LSTORE)
      IF (MATNO(LSTORE-1) .EQ. KATNO(LOWER-1)) YY(2)=Y(LSTORE-1)
      IF (MATNO(LSTORE-2) .EQ. KATNO(LOWER-2)) YY(1)=Y(LSTORE-2)
302 CONTINUE

```

AFWL-TR-67-131, Vol IV

```

      WRITE (6,7110)
7110 FORMAT (30HINPUT TO THE QUADRATIC FIT IS /)
      DO 401 LY=1,3
      LYY=LOWEN-3+LY
      LYYY=XX(LY)
      WRITE (6,7109) KATNO(LYY),LYYY,YY(LY)
7109 FORMAT (5X,10H AT ATOMIC NUMBER ,I3,10H WITH J = ,I3,
      120H AN IONIZATION POTENTIAL OF ,1PE15.8)
401 CONTINUE
      GO TO 303
301 CONTINUE
C     PATH FOR MORE = 1
      XX(1)=X(LSTOKE-2)
      XX(2)=X(LSTOKE-1)
      XX(3)=X(LSTOKE)
      YY(1)=Y(LSTOKE-2)
      YY(2)=Y(LSTOKE-1)
      YY(3)=Y(LSTOKE)
      DO 100 LX=1,3
      LXX=LSTOKE-3+LX
      LXXX=XX(LX)
      WRITE (6,7109) MATNO(LXX),LXXX,YY(LX)
100 CONTINUE
303 CONTINUE
      CALL FIT (XX,YY,L3,L2,DEVIAT,IM2,COE2)
      IF (IM2) 2001,2002,2001
2001 CONTINUE
      WRITE (6,7703) L3,L2,(YY(J),MATNO(J),J=1,3)
      CALL DEBUG(2001,2002,NEXT)
      GO TO 500
2002 CONTINUE
      DO 2003 J=6,8
      COEF(J,K)=COE2(J-5)
2003 CONTINUE
C
C
      DO 2004 J=NUXT, LAST
      XJ=X
      KATNO(J)=K-1+J
      POTENL(J)=COE2(1)+COE2(2)*XJ+XJ*XJ*COE2(3)
      KKATNO=KATNO(J)
      MAKIAN(KKATNO,J)=POTENL(J)
2004 CONTINUE
      WRITE (6,7704) (KATNO(J), J, POTENL(J), J=NUXT, LAST)
      WRITE (6,7707) COE2
      WRITE (6,7003) DEVIAT
C
C
500 CONTINUE
      WRITE (6,7006)
7006 FORMAT (1H1)
C
C
      DO 600 J=1,100
      WRITE (6,7007) J

```

AFWL-TR-67-131, Vol IV

7007 FORMAT (20HOFOR ELEMENT NUMBER ,13, 31H, THE IONIZATION POTENTIALS
1 ANE)

C
C

DO 601 J2=1,J ,10
J4= MINU(J2+9,J)
WRITE (6,7005) J2,(MAHAN(J,J3), J3=J2,J4)

7005 FORMAT (1X,13,3X,1P10E12.5)

C

601 CONTINUE
600 CONTINUE

C

JLONUM=JLONUM+3
WRITE(6,7706) (J,(COEF(JJ,J),JJ=1,JLONUM),J=1,KCOUNT)

7706 FORMAT (14H1COEF ARRAY IS/(4X,13,1P5E15.8,3X,1P3E15.8))
GO TO 1

C

CALL MAHE
RETURN
END

TABLE IV
IONIZATION POTENTIALS FOR THE TWO-ELECTRON ATOM

Z	(Ref. 5)	HELAS	HELIXE	Z	HELAS	HELIXE
2	2.4581+01	2.458500+01	2.459021+01	51	3.574248+04	3.575074+04
3	7.5619+01	7.559767+01	7.564295+01	52	3.723141+04	3.723577+04
4	1.5385+02	1.538334+02	1.539037+02	53	3.875441+04	3.875410+04
5	2.59298+02	2.592956+02	2.593939+02	54	4.031182+04	4.030598+04
6	3.91986+02	3.920030+02	3.921350+02	55	4.190398+04	4.189166+04
7	5.51925+02	5.519665+02	5.521509+02	56	4.353126+04	4.351138+04
8	7.39114+02	7.392276+02	7.394696+02	57	4.519402+04	4.516541+04
9	9.536+02	9.537974+02	9.541228+02	58	4.689264+04	4.685401+04
10	1.1956+03	1.195717+03	1.196147+03	59	4.862751+04	4.857744+04
11	1.4648+03	1.465021+03	1.465582+03	60	5.039905+04	5.033598+04
12	1.7612+03	1.761765+03	1.762473+03	61	5.220768+04	5.212990+04
13	2.0855+03	2.085968+03	2.086870+03	62	5.405386+04	5.395948+04
14	2.436+03	2.437710+03	2.438826+03	63	5.593802+04	5.582502+04
15	2.815+03	2.817031+03	2.818401+03	64	5.786065+04	5.772679+04
16	3.22+03	3.223997+03	3.225656+03	65	5.982224+04	5.966511+04
17	3.654+03	3.658670+03	3.660660+03	66	6.182331+04	6.164026+04
18	4.115+03	4.121115+03	4.123485+03	67	6.386439+04	6.365256+04
19	4.603+03	4.611420+03	4.614207+03	68	6.594602+04	6.570232+04
20	5.119+03	5.129647+03	5.132907+03	69	6.806879+04	6.778985+04
21		5.675899+03	5.679673+03	70	7.023330+04	6.991547+04
22		6.250255+03	6.254594+03	71	7.244014+04	7.207951+04
23		6.852810+03	6.857765+03	72	7.469000+04	7.428230+04
24		7.483672+03	7.489287+03	73	7.698353+04	7.652417+04
25		8.142944+03	8.149263+03	74	7.932141+04	7.880546+04
26		8.830720+03	8.837804+03	75	8.170441+04	8.112653+04
27		9.547140+03	9.555024+03	76	8.413326+04	8.348771+04
28		1.029231+04	1.030104+04	77	8.660876+04	8.588937+04
29		1.106637+04	1.107598+04	78	8.913176+04	8.833187+04
30		1.186944+04	1.187996+04	79	9.170308+04	9.081556+04
31		1.270166+04	1.271312+04	80	9.432365+04	9.334082+04
32		1.356319+04	1.357561+04	81	9.699440+04	9.590803+04
33		1.445417+04	1.446755+04	82	9.971633+04	9.851756+04
34		1.537476+04	1.538910+04	83	1.024905+05	1.011698+05
35		1.632512+04	1.634041+04	84	1.053179+05	1.038651+05
36		1.730543+04	1.732163+04	85	1.081997+05	1.066040+05
37		1.831586+04	1.833293+04	86	1.111371+05	1.093867+05
38		1.935660+04	1.937448+04	87	1.141314+05	1.122137+05
39		2.042784+04	2.044643+04	88	1.171838+05	1.150854+05
40		2.152478+04	2.154898+04	89	1.202957+05	1.180022+05
41		2.266262+04	2.268229+04	90	1.234686+05	1.209646+05
42		2.382660+04	2.384855+04	91	1.267040+05	1.239730+05
43		2.502191+04	2.504196+04	92	1.300036+05	1.270277+05
44		2.624880+04	2.626871+04	93	1.333689+05	1.301293+05
45		2.750751+04	2.752699+04	94	1.368018+05	1.332781+05
46		2.879828+04	2.881702+04	95	1.403042+05	1.364746+05
47		3.012137+04	3.013899+04	96	1.438782+05	1.397193+05
48		3.147706+04	3.149313+04	97	1.475258+05	1.430126+05
49		3.286562+04	3.287965+04	98	1.512492+05	1.463550+05
50		3.428732+04	3.429878+04	99	1.550511+05	1.497469+05
				100	1.589338+05	1.531888+05

SECTION IV
OPACITY AND DATA TRANSFORMATION CODES

All of the valid DIAPHANOUS, DIANE, SYLVIA, ALOUETTE, and ZSAZSA opacity information in use at General Atomic has been transmitted on tape to the DASIAC. Enough information has been presented in the code writeups (which follow) to enable these tapes to be read. For further information refer to:

1. DIAPHANOUS data: see the DENSER, DASE, DAPHNE, DYPER4, GRAPH, and TRANS writeups. The DENSER writeup specifies the DASIAC tape format. The other codes listed are able to use, edit, or modify the data as specified in their writeups.
2. DIANE data: see the DIANCT and DIANE-tape-and-card-format writeups, and the GREYS, EGREY, REDGRE, and DYPDIN writeups. The DIANCT and DIANE-tape-and-card-format writeups specify the DASIAC tape format.
3. SYLVIA, ZSAZSA, and ALOUETTE data: see the EDSILV writeup for a discussion of the DASIAC tape format.

DYPER4: A PLOT PREPARATION CODE FOR OPACITY AND THERMODYNAMIC DATA

The primary functions of the DYPER4 program are to read data from either a DIAPHANOUS, a DENSER, or an ANDIMX tape and prepare plot tapes for the SC-4020. DYPER4 reads one input data tape and either plots opacity data and punches cards containing thermodynamic data, or sets up a one-dimensional array containing thermodynamic data to be plotted by subroutine GRAPH. DYPER4 requires only one data card, containing the following information:

AFWL-TR-67-131, Vol IV

```

00100 1. C ELT DYPEN/50824,1.670905, 59099
00100 2. C EOF 3
00100 3. C SUBROUTINE DIAPER
00100 4. C
00100 5. C *** COMPILED SEPTEMBER 28, 1966 SCHALIT/YATES ***
00100 6. C
00100 7. C VARIABLE NAME MEANING
00100 8. C
00100 9. C *** AUGAS ***
00100 10. C DELEPJ (2000) ENERGY CHANGE DURING A TRANSITION (EV)
00100 11. C DELEPS (1300) IONIZATION POTENTIAL OF A STATE (EV)
00100 12. C EIN (15) ENERGY OF GROUND STATE OF AN IONIZATION LEVEL
00100 13. C EPSD (1300) SAME AS EPS IN DIAPHANOUS
00100 14. C FPC (3, 3, 3) FRACTIONAL PERCENTAGE COEFFICIENT FOR TRANSITION BETWEEN
00100 15. C SPLIT CONFIGURATIONS
00100 16. C IJ (2000) IDENTIFICATION NUMBER OF INITIAL STATE ASSOCIATED WITH A
00100 17. C TRANSITION
00100 18. C ISPLIT (15, 40) IDENTIFICATION OF A SPLIT CONFIGURATION
00100 19. C MERGE (15, 40) TRUE IF THIS CONFIGURATION IS THE AVERAGE OF SOME OTHER
00100 20. C CONFIGURATIONS IN THE TABLE
00100 21. C MJD (2670) NUMBER OF ELECTRONS IN LEVEL FROM WHICH ONE IS REMOVED IN
00100 22. C THIS TRANSITION
00100 23. C NFJ (1300) SAME AS NF IN DIAPHANOUS
00100 24. C NJU (2000) PRINCIPAL QUANTUM NUMBER (OR REDUCED QUANTUM NUMBER) OF
00100 25. C ELECTRON REMOVED IN THIS TRANSITION.
00100 26. C NG (6, 15, 40) NUMBER OF ELECTRONS IN AN ELECTRON LEVEL IN A CONFIGURATION
00100 27. C NMAY (15) NUMBER OF CONFIGURATIONS AT AN IONIZATION LEVEL
00100 28. C NRSPLV (1300) CONFIGURATION IDENTIFICATION OF A STATE
00100 29. C NSAVE (1300) QUANTUM NUMBER OF OUTER ELECTRON, IF BEYOND TABLE, OF A
00100 30. C STATE
00100 31. C QJ (1300) SAME AS Q IN DIAPHANOUS
00100 32. C JNT (15, 40) DEGENERACY OF A CONFIGURATION
00100 33. C WU (15, 40) COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
00100 34. C CONFIGURATION
00100 35. C W1 (15, 40) COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
00100 36. C CONFIGURATION
00100 37. C W2 (15, 40) COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
00100 38. C CONFIGURATION
00100 39. C *** DIAPH2 ***
00100 40. C BE (100) SAME AS BEJ, INDEXED BY (INF + 1) FOR INITIAL STATE
00100 41. C BEJ (1600) PARAMETER DETERMINING LINE WIDTH FOR A TRANSITION
00100 42. C C (10) CONCENTRATION OF AN ELEMENT (ATOMS/ATOM)
00100 43. C COM (12) COMMENT CARD IN FORMAT 12A6
00100 44. C DELE (100) SUM OF DEL: AT PREVIOUS IONIZATION LEVELS (EV)
00100 45. C DELEPJ (2200) ENERGY CHANGE DURING A TRANSITION (EV)
00100 46. C DELEPS (1500) IONIZATION POTENTIAL OF A STATE (EV)
00100 47. C OCLI (100) PRESSURE IONIZATION AT AN IONIZATION LEVEL (EV)
00100 48. C EPS (1500) ENERGY OF A STATE, USUALLY REFERRED TO THE ENERGY OF THE
00100 49. C GROUND STATE OF THE NEUTRAL ATOM (EV)
00100 50. C EPJPRM (1500) ENERGY OF A STATE AFTER REDUCTION DUE TO PRESSURE IONIZA-
00100 51. C TION (EV)
00100 52. C EA (100) SAME AS EXJ, INDEXED BY (INF + 1) FOR INITIAL STATE
00100 53. C EAJ (1600) PARAMETER DETERMINING LINE LOCATIONS FOR A TRANSITION
00100 54. C GAMBLA (10) ARRAY OF GAMMA
00100 55. C IJ (2200) IDENTIFICATION NUMBER OF INITIAL STATE ASSOCIATED WITH A
00100 56. C TRANSITION
00100 57. C MAKEZ (1500) IDENTIFICATION OF STATE TO BE ELIMINATED
00100 58. C MJ (2200) NUMBER OF ELECTRONS IN LEVEL FROM WHICH ONE IS REMOVED IN
00100 59. C THIS TRANSITION
00100 60. C NEW (2200) ORIGINAL IDENTIFICATION NUMBER OF A TRANSITION
00100 61. C NF (1500) NUMBER OF FREE ELECTRONS FOR A STATE
00100 62. C NJ (2200) TOTAL QUANTUM NUMBER (OR REDUCED QUANTUM NUMBER) OF ELEC-
00100 63. C TRON REMOVED DURING A TRANSITION
00100 64. C NLAST (10) INDEX NUMBER OF LAST STATE IN TABLE FOR AN ELEMENT
00100 65. C PHI (2200) STRENGTH OF EDGE DUE TO THIS TRANSITION

```

AFWL-TR-67-131, Vol IV

00100	66.	C	J (1500)	DEGENERACY OF A STATE	
00100	67.	C	R (1500)	FIRST PROPORTIONAL TO LOG POPULATION AND THEN TO POPULATION	
00100	68.	C		OF A STATE	
00100	69.	C	R ₅ (10)	FIRST MAXIMUM R, THEN SUM OF R'S. FOR AN ELEMENT	
00100	70.	C	SMALLP (1500)	POPULATION OF A STATE	
00100	71.	C	TESTJ (2200)	LOWEST VALUE OF MU AT WHICH THE ABSORPTION COEFFICIENT IS	
00100	72.	C		AFFECTED BY THE LINE SERIES FOR THIS TRANSITION	
00100	73.	C	TK3LK (10)	ARRAY OF KT	
00100	74.	C	U (5)	COEFFICIENTS IN GAUSSIAN INTEGRATION	
00100	75.	C	R (5)	COEFFICIENTS IN GAUSSIAN INTEGRATION	
00100	76.	C	UOLD (2200)	LOCATION OF EDGE DUE TO THIS TRANSITION (EV/EV)	
00100	77.	C	UPHM (2200)	LOWEST EDGE TO APPROXIMATE HIGH LINES (EV/EV)	
00100	78.	C	W (10)	ATOMIC WEIGHT OF AN ELEMENT	
00100	79.	C	Z (10)	ATOMIC NUMBER OF AN ELEMENT	
00100	80.	C	*** DIAPER ***		
00100	81.	C	AMU (1000)	ABSORPTION COEFFICIENT AT A PARTICULAR VALUE OF MU(.6 .LE.	
00100	82.	C		MU .LE. 15) (PER CM)	
00100	83.	C	BMU (1000)	BOTTOM OF EDGE OCCURRING AT A PARTICULAR VALUE OF MU(MU .6T.	
00100	84.	C		15) (PER CM)	
00100	85.	C	ID (12)	COMMENT CARD	
00100	86.	C	TMU (1000)	TOP OF EDGE OCCURRING AT A PARTICULAR VALUE OF U (U>15) (PER	
00100	87.	C		CM)	
00100	88.	C	*** SPECTRA ***		
00100	89.	C	DETECT (100, 4)	QUANTUM DEFECT INDEXED BY THE IONIZATION LEVEL AND L + 1	
00100	90.	C	DELEPJ (3500)	SAME AS DELEPJ IN DIAPHANOUS	
00100	91.	C	DELEPS (1750)	SAME AS DELEPS IN DIAPHANOUS	
00100	92.	C	EPSD (1750)	SAME AS EPS IN DIAPHANOUS	
00100	93.	C	IJJ (3500)	SAME AS IJ IN DIAPHANOUS	
00100	94.	C	IONZC (100)	ZCORE FOR AN IONIZATION LEVEL	
00100	95.	C	L (19)	L FOR AN ELECTRON LEVEL	
00100	96.	C	LIN (10)	LEVEL AT WHICH AN ELECTRON IS BEING ADDED	
00100	97.	C	LOUT (10)	LEVEL AT WHICH AN ELECTRON IS BEING REMOVED	
00100	98.	C	MJD (3500)	SAME AS MJ IN DIAPHANOUS	
00100	99.	C	N (19)	N FOR AN ELECTRON LEVEL	
00100	100.	C	NE (92, 19)	NUMBER OF ELECTRONS PER ELECTRON LEVEL IN THE GROUND STATE	
00100	101.	C		OF AN IONIZATION LEVEL	
00100	102.	C	NFD (1750)	SAME AS NF IN DIAPHANOUS	
00100	103.	C	NJD (3500)	SAME AS NJ IN DIAPHANOUS	
00100	104.	C	QU (1750)	SAME AS Q IN DIAPHANOUS	
00100	105.	C			3MAN0000
00101	106.			DIMENSION AU(3000), BMU(1500), TMU(1500), U1(3000), U2(1500),	
00101	107.			1A(6B2), TX(2), TY(2), CHARA(4), CHARB(3), AA(20),	
00101	108.			2 CHARC(4), CHARD(3), CHARE(3), CHARG(3), CHARM(3)	3MAN0070
00101	109.			3, BCDBLK(40), HUB(14), IHUB(13), HUBB(8), COMP(10), IZ(10)	
00103	110.			EQUIVALENCE (AA(1),ZBAR), (AA(2),RHO), (AA(3),SIGP), (AA(4),EPSMAL	
00103	111.			1), (AA(5),AKAPPA), (AA(6),WAMBDA), (AA(7),EIPART), (AA(8),BAMNEW)	
00104	112.			EQUIVALENCE (BCDBLK, CHARA), (SCDBLK(5), CHARE),	3MAN0090
00104	113.			1 (BCDBLK(6), CHARE), (BCDBLK(9), CHARE),	3MAN0100
00104	114.			2 (BCDBLK(12), CHARE), (BCDBLK(15), CHARE),	3MAN0110
00104	115.			3 (BCDBLK(18), CHARE), (HUBB(12), UIN), (HUBB(13), DUI)	3MAN0130
00104	116.	C			
00105	117.			INTEGER ANDIMX,DENSER	
00106	118.			INTEGER W	
00107	119.			EQUIVALENCE(IUX,UX)	

AFWL-TR-67-131, Vol IV

00107	120.	C	COMMON/PRSA/NFRAME, SAVET, SECRET(6), ANDIMX, IDANDI(12,5)	
00110	121.	C		
00110	122.	C	COMMON/CIA/DYPOUT(5000)	
00111	123.		DATA DYPOUT/5000*0./	
00112	124.		COMMON/DCII/IEND(100), NPTS(100), J1, NAME, ID(12)	
00114	125.		DATA J1/1/, MARKER/-9/, EPSILN/1.E-4/, IEND,NPTS/200*0/	
00125	126.		DATA IENDED/0/	
00125	127.		DATA MIN/10/	
00125	128.	C	MIN = 10 COMPRESSED INPUT TAPE UNIT.	
00125	129.	C		
00125	130.	C	MUB(3) IS TEMPERATURE IN EV	
00125	131.	C	MUB(4) IS DENSITY IN GM/CM2	
00125	132.	C	MUB(6) IS ZBAR	
00125	133.	C	MUB(15) IS ROSSELAND MEAN CONTINUOUS OPACITY IN CM2/GM	
00125	134.	C	MUB(16) IS ROSSELAND MEAN (TOTAL RADIATION) OPACITY IN CM2/GM	
00125	135.	C		
00125	136.	C	DATA NFRAME, SAVET/0.0.0/SECRET/6HSECRET.6H R/D -.6HGROUP ,	
00127	137.		16H 1 / ANDIMX/6HANDIMX/,DENSER/6MDENSER/	
00127	138.			
00127	139.	C		3MAN0150
00127	140.	C	FORMAT OF INTERMEDIATE DIAPHANOUS TAPE	3MAN0160
00127	141.	C		3MAN0170
00127	142.	C	SIGNAL	3MAN0180
00127	143.	C	-1. NEXT RECORD CONTAINS IDENTIFICATION CARD	3MAN0190
00127	144.	C	-2. BEGINNING OF CASE, NEXT RECORD CONTAINS TEMPERATURE AND	3MAN0200
00127	145.	C	GAMMA, SUCCEEDING RECORDS CONTAIN COMPUTED ABSORPTION	3MAN0210
00127	146.	C	COEFFICIENTS, WITH LINES, FOR U LESS THAN 15.	3MAN0220
00127	147.	C	-3. TRANSITIONS HAVE BEEN EXHAUSTED BEFORE REACHING U = 15.	3MAN0230
00127	148.	C	FOLLOWING RECORDS CONTAIN SOME EXTRAPOLATED VALUES.	3MAN0240
00127	149.	C	-4. FOLLOWING RECORDS CONTAIN DATA, WITHOUT LINES, FOR U	3MAN0250
00127	150.	C	GREATER THAN 15.	3MAN0260
00127	151.	C	-5. NEXT RECORD CONTAINS SUMMARY OF RESULTS. END OF CASE.	3MAN0270
00127	152.	C	-6. END OF TAPE.	3MAN0280
00127	153.	C		
00127	154.	C		
00127	155.	C	FORMAT OF ANDIMX TAPE	
00127	156.	C	A) A FIRST RECORD OF: ANDIMX	
00127	157.	C	B) A SECOND RECORD OF: 60 IDENTIFICATION WORDS	
00127	158.	C	C) A SIGNAL RECORD OF: -7. (DATA FOLLOWS FOR A GIVEN	
00127	159.	C	TEMPERATURE-DENSITY POINT	
00127	160.	C	D) A 3A WORD RECORD (CAYT IS WORD(3), RHO IS WORD(4))	
00127	161.	C	E) A RECORD WITH (NMAX+1) WORDS: NMAX,(MU(J),J=1,NMAX)	
00127	162.	C		
00127	163.	C	RECORDS (C,D,AND E) ARE THEN REPEATED, TEMPERATURES	
00127	164.	C	AND DENSITIES ARE MONOTONIC, TEMPERATURES ARE LOWEST	
00127	165.	C	AT THE BEGINNING OF THE TAPE,THE HIGHEST DENSITY FOR	
00127	166.	C	A GIVEN TEMPERATURE IS THE FIRST DENSITY AT THAT	
00127	167.	C	TEMPERATURE.	
00127	168.	C		
00127	169.	C	F) A SIGNAL RECORD OF: -8. SIGNIFIES END OF DATA.	
00127	170.	C		
00127	171.	C		
00127	172.	C	5 FORMAT (12A6)	3MAN0290
00127	173.	C	6 FORMAT (1M1,12A6/15M0TEMPERATURE = , F10.3///6X, 5M0GAMMA, 6X	

```

00136 174.      1      11HRHO(GM/CM3), 6X, 7HP(9ARS), 5X, 12HENG(ERGS/GM), 3X,      3MAN0310
00136 175.      2      13HEION(ERGS/GM), 3X, 12HKROS(CM2/GM), 2X,      3MAN0320
00136 176.      3      12HKPLK(CM2/GM), 3X, 4H2BAR, 5X, 4HEGAM      3MAN0330
00137 177.     11 FORMAT (6HTHETA=, E12.2, 6HGAMMA=, E12.5, 6HMU2R0=, E12.3,      3MAN0340
00137 178.      1      6HMUONE=, E12.3)      3MAN0350
00140 179.     12 FORMAT (48H      0      5      10      15      1      10      100      1000)      3MAN0360
00141 180.     13 FORMAT (52H THERE IS AN ERROR IN THIS RUN. CONSULT PROGRAMMER      3MAN0370
00141 181.      1      33HBEFORE SENDING TAPE M TO PLOTTER.)      3MAN0380
00142 182.     14 FORMAT (10H THERE ARE, 14, 33H FRAMES ON TAPE M. PLEASE NOTE      3MAN0390
00142 183.      1      47HTHIS ON THE SAVE TAPE REQUEST, IF THERE IS ONE.)      3MAN0400
00143 184.     15 FORMAT(1P2E13.3, 3E13.3, E13.2, E13.1, 0PF11.2, F9.2)      3MAN0410
00144 185.     16 FORMAT(1P6E10.4, 0P2F6.3)      3MAN0420
00145 186.     19 FORMAT(1PE10.4)      3MAN0430
00146 187.      1      REWIND 16
00146 188.      C
00146 189.      C      TKIN IS THE TEMPERATURE AT WHICH PLOTTING BEGINS
00146 190.      C      TKEND IS THE LAST TEMPERATURE WHICH IS PLOTED
00146 191.      C      M      IF (M .GT. 0) THE VALUE OF AMIN IS CHANGED TO THE HIGHEST
00146 192.      C      POWER OF 10 WHICH DIVIDES AMIN
00146 193.      C      IF (M .EQ. 0) AMIN IS NOT CHANGED
00146 194.      C      N      IF (N .GT. 0) MUEBNER DATA IS ONLY PLOTTED FOR U FROM U = .3
00146 195.      C      TO U = 15.
00146 196.      C      IPLIT1 DETERMINES WHETHER THE DYPDOUT ARRAY IS TO BE FILLED.
00146 197.      C      IF (IPLIT1 .EQ. 1) USE DYPDOUT ARRAY
00146 198.      C      IF (IPLIT1 .NE. 1) NORMAL PLOTTING PATH
00146 199.      C
00146 200.      C
00146 201.      C      FOLLOWING ARE THE VARIABLES STORED IN DYPDOUT(1) (AND INTEGRAL
00146 202.      C      MULTIPLES OF 1)
00146 203.      C
00146 204.      C      I      SADDY VARIABLE      MUEBNER VARIABLE
00146 205.      C      1      TK      TK
00146 206.      C      2      RHO      RHO
00146 207.      C      3      GAMMA
00146 208.      C      4      PRESNR
00146 209.      C      5      ENERGY
00146 210.      C      6      EION
00146 211.      C      7      KPLK      CROPA
00146 212.      C      8      KROS      TROPA (KROS)
00146 213.      C      9      ZBAR      CAPNF (ZBAR)
00146 214.      C      10     EGAM
00146 215.      C
00146 216.      C
00146 217.      C      READ INPUT CARD 1/1
00146 218.      C      READ (5,101) TKIN, TKEND, SZ, M, N, IPLIT1, IBCD0
00146 219.     101 FORMAT (3F10.4,4(5X,15))
00146 220.      C      WRITE (6,3) TKIN, TKEND, SZ, M, N, IPLIT1, IBCD0
00146 221.     3 FORMAT (17H INPUT AS READ IS//11H TKIN      = ,E12.4, /11H TKEND      =
00146 222.      1      ,E12.4//11H SZ      = ,E12.4//11H M      = ,15, /11H N      =
00146 223.      2      ,15, /10H IPLIT1 = ,15, /11H IBCD0      = ,15)
00146 224.      C
00146 225.      C      IF (TKEND .LT. 1.E-35) TKEND=1.E30
00146 226.      C
00146 227.      C      WRITE (6,4) TKIN, TKEND, SZ, M, N, IPLIT1, IBCD0

```

AFWL-TR-67-131, Vol IV

```

00206 226. * FORMAT (17H0INPUT AS USED IS//11M TRIM z .E12.4, /11M TREND z
00206 229. 1 .E12.4, /11M SIZ z .E12.4, /11M M z .IS, /11M M z
00206 230. 2 .IS, /10M IPLOT1 z .IS, /11M ICDO z .IS, /1M1)
00206 231. C
00207 232. IF (IPLOT1 .EQ. 1) GO TO 400
00207 233. C DO PLOTTING OF THERM OR DO (PLOTS OF MU VS. U AND PUNCH CARDS)
00207 234. C BUT NOT BOTH
00207 235. C
00207 236. C
00211 237. CALL SETUP(A.002,16)
00212 238. CALL SCDCOM (SCDCLX)
00213 239. WRITE (0, 12)
00213 240. C P R O C E S S I N P U T
00213 241. C
00215 242. 400 CONTINUE
00216 243. IF (ICDO .EQ. 0) GO TO 9401
00220 244. READ(15)UX
00221 245. NAME z IUX
00224 246. IUX=UX-.5
00225 247. IF(IUX .EQ. (-1)) GO TO 100
00226 248. IF (IUX .EQ. ANDIMK) GO TO 700
00230 249. WRITE(6,7999) UX, IUX, IUX, IUX
00232 250. 7999 FORMAT (20H PROBLEM WITH FIRST RECORD /5X,1PE15.0,2X,16,2X,A0, 2X0
00240 251. 11d)
00240 252. GO TO 999
00241 253. 9401 CONTINUE
00243 254. READ (MIN,7431) IUX, (ID(I),I=1,12), NZ, (COMP(K),I=1,NZ)
00243 255. NAME z IUX
00246 256. 7401 FORMAT (13A6, / 12, (F6.4, 12))
00246 257. IF (IUX .EQ. DENSER) GO TO 9403
00246 258. 9402 CONTINUE
00246 259. WRITE (6,7999) UX, IUX, IUX, IUX
00246 260. GO TO 999
00273 261. 9403 CONTINUE
00274 262. WRITE (6,7404) JJ, II, ULAST, AKLAST, TK, GAMMA, (AA(K),K=1,20),
00275 263. 1(U1(I),I=6,II), (AMU(I),I=6,II), (U2(I), I=2,JJ), (BMU(I),I=2,JJ),
00275 264. 2(TMU(I),I=2,JJ)
00275 265. 7404 FORMAT (214, 13E9.4, /(14E9.4))
00335 266. IF (JJ .GT. 1500) THE A ARRAY HAS BEEN WIPEO OUT
00335 267. C
00336 268. 9404 CONTINUE
00337 269. READ (MIN,7404) JJ,II, ULAST, AKLAST, TK, GAMMA, (AA(K),K=1,20),
00337 270. 1(U1(I), I=6,II), (AMU(I),I=6,II), (U2(I),I=2,JJ), (BMU(I),I=2,JJ),
00337 271. 2(TMU(I),I=2,JJ)
00377 272. IF (JJ .GT. 0) GO TO 9000
00401 273. NEND z 2
00402 274. GO TO 200
00403 275. 9000 CONTINUE
00404 276. IF ((II .GT. 150) .OR. (JJ .GT. 1500)) GO TO 9405
00406 277. ITCH z 10000
00407 278. *DIAGNOSTIC* THE TEST FOR EQUALITY BETWEEN NON-INTEGERS MAY NOT BE MEANINGFUL.
00407 279. IF (ULAST .NE. 0.) ITCH=II
00411 279. NO z 2
00412 279. *DIAGNOSTIC* THE TEST FOR EQUALITY BETWEEN NON-INTEGERS MAY NOT BE MEANINGFUL.

```

3MAN050
3MAN0400
3MAN0470

AFWL-TR-67-131, Vol IV

```

00412 280.      IF (U2(I) .NE. 0.) NOZ1
00414 281.      DO 9406 I=6,11
00417 282.      U1(I-5) = U1(I)
00420 283.      AMU(I-5) = AMU(I)
00421 284.      9406 CONTINUE
00423 285.      DO 9407 I=2,JJ
00426 286.      U2(I-1) = U2(I)
00427 287.      BMU(I-1) = BMU(I)
00430 288.      TMU(I-1) = TMU(I)
00431 289.      9407 CONTINUE
00433 290.      IMAX=      II - 5
00434 291.      JMAX=      JJ - 1
00435 292.      GO TO 9409
00436 293.      100 CONTINUE
00437 294.      NAME = -1
00440 295.      READ(15) (ID(I), I=1,12)
00446 296.      9403 CONTINUE
00447 297.      IF (IPLOT1 .EQ. 1) GO TO 401
00451 298.      PUNCH 5, (ID(I), I = 1, 12)
00457 299.      CALL FRAME(0.5, 1.0, 1.0, 0.0)
00460 300.      CALL TSP(0.2, 0.5, ID, 72)
00461 301.      CALL ADF
00462 302.      NFNAME=FRAME+1,
00463 303.      401 CONTINUE
00464 304.      IF (ISCDO .EQ. 0) GO TO 9404
00466 305.      READ(15) UX
00471 306.      IF (ABS(UX+2.) .LT. EPSILN) GO TO 32
00473 307.      WRITE (6,20) UX
00476 308.      40 FORMAT (74MONO SIGNAL OF -2. FOLLOWS FIRST (ID) RECORD ON THE DIAP
00476 309.      1HMONOUS TAPE. UX = , F10.4)
00477 310.      GO TO 999
00477 311.      C READ IN MU VERSUS U FOR GIVEN T, GAMMA
00500 312.      32 CONTINUE
00501 313.      READ (15) TK, GAMMA
00505 314.      I = 1
00506 315.      ITWCH = 10000
00507 316.      34 READ(15) U1(I), AMU(I)
00513 317.      IF (ABS(U1(I) + 3.) .LT. EPSILN) GO TO 60
00515 318.      IF (ABS(U1(I) + 6.) .LT. EPSILN) GO TO 40
00517 319.      IF (ABS(U1(I) + 4.) .LT. EPSILN) GO TO 73
00521 320.      I = I + 1
00522 321.      GO TO 34
00523 322.      40 ITWCH = I - 1
00524 323.      GO TO 34
00525 324.      60 NU = 1
00526 325.      J = 1
00527 326.      65 READ(15) U2(J), BMU(J), TMU(J)
00534 327.      IF (ABS(U2(J) + 4.) .LT. EPSILN) GO TO 75
00536 328.      J = J + 1
00537 329.      GO TO 65
00540 330.      73 NO = 2
00541 331.      75 CONTINUE
00542 332.      READ (15) ZBAR,RHO,SIOP,EPHML,AKAPPA,WANDQA,EPART,GAMNEW
00544 333.      IMAX = I - 1

```

3MAN0510
3MAN0520
3MAN0530
3MAN0540
3MAN0550

3MAN0580

3MAN0600
3MAN0610

3MAN0660
3MAN0670
3MAN0680
3MAN0690
3MAN0700
3MAN0710

3MAN0740
3MAN0750
3MAN0760

3MAN0780

00555	334.	JMAX = J - 1	3MAN0798
00556	335.	C	
00556	336.	9408 CONTINUE	
00557	337.	IF ((TK+EPSLN).LT.VKIN .OR. TK.GT.(TKEND+EPSLN)) GO TO 291	
00561	338.	IF (IPL0T1.EQ. 1) GO TO 410	
00561	339.	C	
00561	340.	C	
00563	341.	80 START PLOTTING FIRST FRAME	3MAN0830
00564	342.	CALL FRAME(0.0, 20.0, 20.0, 0.0)	3MAN0840
00565	343.	CALL GXA(4, 0.7, 1.0, 8.25)	3MAN0850
00566	344.	CALL GYA(4, 1.0, 0.9, 8.0)	3MAN0860
00567	345.	CALL TSP(1.5, 19.0, 10, 72)	3MAN0870
00570	346.	AMIN = 1.E9	3MAN0880
00573	347.	DO 120 I = 1, IMAX	3MAN0890
00575	348.	120 AMIN= AMIN1(AMIN, AMU(I))	3MAN0900
00577	349.	IF (M.EQ. 0) GO TO 81	
00600	350.	I2 = IFIX(ALOG10(AM1))	
00602	351.	IF (I2.LE. 0) I2 = I2 - 1	
00603	352.	AMIN = 10.**I2	
00604	353.	81 CONTINUE	
00605	354.	80 TO (83, 84), NO	3MAN0910
00606	355.	83 BMIN = 1.E9	3MAN0920
00611	356.	DO 190 J = 1, JMAX	3MAN0930
00614	357.	190 IF ((I2(J)-150.) .LT. 1.E-37) BMIN = AMIN1(BMIN, BNU(J))	
00615	358.	84 CALL WCDON (WCDONK(9))	3MAN0950
00623	359.	WRITE (0, 11) TK, GAMMA, AMIN, BMIN	3MAN0960
00624	360.	CALL TSP(1.3, 2.0, CHARD, 18)	3MAN0970
00625	361.	CALL TSP(1.3, 2.3, CHARE(1), 18)	3MAN0980
00630	362.	DO 90 I = 1, 4	3MAN0990
00631	363.	XTYP = 5. * FLOAT(I) - 4.7	3MAN1000
00632	364.	85 CALL TSP(XTYP, .6, CHARA(I), 8)	3MAN1010
00633	365.	YTYP = 6.25 * FLOAT(I) - 5.25	3MAN1020
00635	366.	90 CALL TSP(1, YTYP, CHARC(I), 8)	3MAN1030
00636	367.	CALL TSP(1.3, 2.0, CHARD, 18)	3MAN1040
00636	368.	C	
00641	369.	PLOT MU VERSUS U	3MAN1050
00642	370.	DO 130 I = 1, IMAX	3MAN1060
00644	371.	PMU1 = 2.7143 * ALOG(AMU(I) / AMIN) + 1.0	3MAN1070
00645	372.	IF (I.EQ. 1) GO TO 140	3MAN1080
00647	373.	TX(1) = TX(2)	3MAN1090
00650	374.	IF (ITWCH .GE. 1) GO TO 134	3MAN1100
00651	375.	TY(1) = TY(2)	3MAN1110
00652	376.	TX(2) = U1(I) + 1.00	3MAN1120
00654	377.	134 TY(2) = AMIN1(PMU1, 20.)	3MAN1130
00655	378.	IF (TY(1).GT. 20.) GO TO 150	3MAN1140
00657	379.	138 CALL DVR(1, 0, TX, TY, 1)	3MAN1150
00660	380.	IF (ITWCH .LT. 1) GO TO 150	3MAN1160
00661	381.	140 TX(1) = U1(I) + .95	3MAN1170
00662	382.	TY(2) = PMU1	3MAN1180
00663	383.	TX(2) = U1(I) + 1.05	3MAN1190
00665	384.	TY(1) = AMIN1(PMU1, 20.)	3MAN1200
00667	385.	IF ((PMU1-20.) .LT. 1.E-37) CALL DVR(1, 0, TX, TY, 1)	
00670	386.	150 CONTINUE	3MAN1220
00671	387.	CALL AOP	3MAN1230
		NFRAME=NFRAME+1	3MAN1240
		GO TO (160, 248), NO	3MAN1250

AFWL-TR-67-131, Vol IV

00671	306.	C	START PLOTTING SECOND FRAME	SMAN1280
00672	309.	160	CALL GXA(4, 0.7, 1.0, 6.25)	SMAN1270
00673	390.		CALL GYA(3, 1.0, 0.9, 6.25)	SMAN1280
00674	391.		CALL TSP(1.5, 19.0, 10, 72)	SMAN1290
00675	392.		CALL TSP(1.3, 2.6, CHARG, 10)	SMAN1300
00676	393.		CALL TSP(1.3, 2.3, CHARG, 10)	SMAN1310
00677	394.		DO 160 I = 1, 4	SMAN1320
00678	395.		XTYP = 6.25 * FLOAT(I) - 5.75	SMAN1330
00679	396.		TTYP = 0.7	SMAN1340
00680	397.	170	CALL TSP(XTYP, TTYP, CHARG(I), 6)	SMAN1350
00681	398.		XTYP = 0.1	SMAN1360
00682	399.		TTYP = 6.25 * FLOAT(I) - 5.25	SMAN1370
00683	400.	180	CALL TSP(XTYP, TTYP, CHARG(I), 6)	SMAN1380
00684	401.		CALL TSP(1.3, 2.0, CHARG, 10)	SMAN1390
00685	402.	C	PLOT MU VERSUS U	SMAN1400
00686	403.		DO 240 J = 1, JMAX	SMAN1410
00687	404.		PU = 2.7143 * ALOG(U2(J) / 10.0) + 1.0	SMAN1420
00688	405.		IF (PU .GT. 20.) GO TO 9999	
00689	406.		PMU1 = 1.0 + 2.7143 * ALOG(TMU(J) / 0.01)	SMAN1430
00690	407.		PMU2 = 1.0 + 2.7143 * ALOG(BMU(J) / 0.01)	SMAN1440
00691	408.	210	TX(2) = PU	SMAN1450
00692	409.		IF (J .EQ. 1) GO TO 230	SMAN1460
00693	410.		TY(1) = TY(2)	SMAN1470
00694	411.		TY(2) = PMU2	SMAN1480
00695	412.		IF (PMU2 .GT. -1.E-37) GO TO NPMU1, (210, 230)	
00696	413.		IF ((U2(J)-150.) .LT. 1.E-37) GO TO 999	
00697	414.		GO TO 230	SMAN1510
00698	415.	9999	CONTINUE	
00699	416.		WRITE (6,9998) TX, GAMMA, (U2(J), BMU(J), TMU(J), J, JMAX)	
00700	417.	9998	FORMAT (11H0U=PU, BT, 20.3X, 9H AT TX = , 0PF10.2, 13H AND GAMMA = ,	
00701	418.	1	1PE12.5 / (15X, 4HJ = , 1PE12.0, 6X, 0H BMU = , 1PE12.0, 6X,	
00702	419.	2	7H TMU = , 1PE12.5))	
00703	420.		GO TO 9997	
00704	421.	210	CALL DVR(1.0, TX, TY, 1)	SMAN1520
00705	422.	230	TX(1) = PU	SMAN1530
00706	423.		TY(1) = PMU2	SMAN1540
00707	424.		TY(2) = PMU1	SMAN1550
00708	425.		ASSIGN 210 TO NPMU1	SMAN1560
00709	426.		IF (PMU2 .GT. -1.E-37) GO TO 233	
00710	427.		TY(1) = 1.	SMAN1500
00711	428.		IF ((PMU1-1.) .GT. -1.E-37) GO TO 233	
00712	429.		TY(2) = 1.	SMAN1600
00713	430.		GO TO 240	SMAN1610
00714	431.	233	IF ((PMU1-20.) .LT. 1.E-37) GO TO 237	
00715	432.		TY(2) = 20.	SMAN1630
00716	433.		ASSIGN 230 TO NPMU1	SMAN1640
00717	434.		IF (PMU2 .GT. 20.) GO TO 240	SMAN1650
00718	435.	237	CALL DVR(1, 0, TX, TY, 1)	SMAN1660
00719	436.	240	CONTINUE	SMAN1670
00720	437.	9997	CONTINUE	
00721	438.		CALL ADF	SMAN1680
00722	439.		NFRAME=NFRAME+1	SMAN1690
00723	440.	242	CONTINUE	
00724	441.		IF (IPLOT1 .EQ. 1) GO TO 410	

AFWL-TR-67-131, Vol IV

```

01004 442.      IF (ABS((TK-SAVET)/TK) .LT. EPSILN) GO TO 290
01006 443.      245 CONTINUE
01007 444.      WRITE (6,2) (ID(I), I=1,12), TK
01010 445.      PUNCH 19, TK
01021 446.      SAVET= TK
01022 447.      WRITE (6,2) AMIN
01025 448.      2 FORMAT(8H AMIN = , 1PE15.8)
01026 449.      250 CONTINUE
01027 450.      WRITE (6,15) GAMMA,RHO,BIGP,EPHML,EIPART,AKAPPA,WAMBOA,ZBAR,
01027 451.      1 GAMNEW
01042 452.      PUNCH 18, RHO, BIGP, EPHML, EIPART, AKAPPA, WAMBOA, ZBAR, GAMNEW
01054 453.      251 CONTINUE
01055 454.      NEND= 1
01056 455.      IF (IBCD0 .EQ. 0) GO TO 9404
01060 456.      READ (15) UX
01063 457.      IF (ABS(UX*5.) .LT. EPSILN) NEND= 2
01065 458.      IF (ABS(UX*7.) .LT. EPSILN) NEND= 3
01065 459.      C
01067 460.      GO TO ( 32,260, 720 ), NEND
01070 461.      260 CONTINUE
01071 462.      IF (IPLOT1 .EQ. 1) GO TO 420
01073 463.      CALL FRAME(0.0, 1.0, 1.0, 0.0)
01074 464.      CALL TSP(2, .5, ID, 72)
01075 465.      CALL ADF
01076 466.      270 CALL FINISH
01077 467.      NFRAME=NFRAME+1
01100 468.      PRINT 14,NFRAME
01103 469.      WRITE (6, 14) NFRAME
01106 470.      GO TO 820
01107 471.      760 CONTINUE
01107 472.      C
01107 473.      C
01107 474.      C
01110 475.      READ (15)(( IDANDI(I,J), I=1,12), J=1,5)
01121 476.      IF (IPLOT1 .EQ. 1) GO TO 405
01123 477.      PUNCH 26, (( IDANDI(I,J), I=1,12), J=1,5)
01134 478.      46 FORMAT (12A6)
01135 479.      CALL FRAME( 0.0,1.0,1.0,0.0 )
01136 480.      DO 710 J = 1,5
01141 481.      YTP = 0.56 - FLOAT(J) * 0.04
01142 482.      710 CALL TSP( 0.2, YTP, IDANDI(1,J), 72 )
01144 483.      CALL TSP( 0.42, 0.8, SECRET, 20 )
01145 484.      CALL ADF
01146 485.      NFRAME = NFRAME + 1
01147 486.      405 CONTINUE
01150 487.      READ (15) UX
01153 488.      750 CONTINUE
01154 489.      NEND= 1
01155 490.      IF (ABS(UX * 5.) .LT. EPSILN) NEND=2
01157 491.      IF (ABS(UX * 7.) .LT. EPSILN) NEND=3
01161 492.      GO TO (32,999,720), NEND
01161 493.      C
01161 494.      C
01161 495.      C

```

3MAN1790
3MAN1800

3MAN1820
3MAN1830
3MAN1840

AFWL-TR-67-131, Vol IV

```

01162 496. 720 READ (15) MUB, IMUB, MUUB
01200 497. GAMMA= 0.
01201 498. SIGP= 0.
01202 499. EPSMAL= 0.
01203 500. EIPART= 0.
01204 501. GAMNEW= 0.
01205 502. TK= MUB(3)
01206 503. RMO= MUB(4)
01207 504. ZBAR= MUB(6)
01210 505. WAMBOA= MUUB(5)
01211 506. AKAPPA= MUUB(6)
01212 507. READ(15) MAXU, ( AMU(I), I=1, MAXU )
01221 508. IF ((TK+EPSILN).LT.TK)N .OR. TK.GT.(TKENO+EPSILN)) GO TO 631
01223 509. IF (IPLOT) ,EQ. 1) GO TO 410
01225 510. IF (ABS((TK-SAVET)/TK).LT. EPSILN) GO TO 403
01227 511. WRITE (6,21) ((IDANDI(I,J), I=1,12), J=1,5), TK
01241 512. #1 FORMAT (1H1.5(1X,12A6/),///15HOTEMPERATURE = ,0PF12.5,15H ELECTRON
01241 513. 1 VOLTS //10X,3HRMU,10X,4HZBAR,9X,5HTROPA,9X,5HCROPA )
01242 514. PUNCH 19, TK
01243 515. SAVETS TK
01246 516. 403 CONTINUE
01247 517. WRITE (6,22) RMO, ZBAR, AKAPPA, WAMBOA
01249 518. #2 FORMAT (3X,1P=14.5)
01256 519. PUNCH 16, RMO, ZBAR, AKAPPA, WAMBOA
01256 520. C
01256 521. C START PLOTTING FIRST FRAME OF MUEBNER DATA
01256 522. C
01260 523. CALL FRAME( 0.0,40.0,40.0,0.0 )
01265 524. CALL GXAI 4, 1.4, 2.0, 12.50 )
01266 525. CALL GYA( 7, 2.0, 1.0, 5.0 )
01267 526. DO 740 J = 1,5
01272 527. YTP = 36.2 - FLOAT(J) * 0.6
01273 528. 740 CALL TSP( 3.0, YTP, IDANDI(1,J), 72 )
01275 529. CALL TSP( 3.0, 39.0, SECRET, 20 )
01276 530. CALL UCDCOM( BCDBLK(21) )
01277 531. WRITE ( 0, 750 )
01301 532. 750 FORMAT(66H 0 5 10 15 20 25 30 1 10
01301 533. 1 100 1000)
01302 534. DO 755 I = 1,7
01305 535. XTYP = 5.0* FLOAT(I) - 4.7
01306 536. J = 20 + I
01307 537. 755 CALL TSP( XTYP,1.2,BCDBLK(J),6 )
01311 538. DO 756 I = 1,4
01314 539. J = 27 + I
01315 540. YTP = 12.5 * FLOAT(I) - 10.5
01316 541. 756 CALL TSP( 0.2, YTP, BCDBLK(J), 6 )
01320 542. AMIN = 1.E9
01321 543. DO 760 I = 1,MAXU, 5
01324 544. 760 AMIN = AMINI( AMIN, AMU(I) )
01326 545. IF (M ,EQ. 0) GO TO 757
01330 546. I2 = IFIX(ALOG10(AMIN))
01331 547. IF (I2 .LE. 0) I2 = I2 - 1
01333 548. AMIN = 10.**I2
01334 549. 757 CONTINUE

```

AFWL-TR-67-131, Vol IV

```

01335 550.      CALL BCDCON( BCDBLK(32) )
01336 551.      WRITE( 0, 843 ) TX, RHO, AMIN
01343 552.      840 FORMAT( 6HTHETA=, F12.2, 6RHO = , E12.5, 6AMIN=, E12.3 )
01344 553.      CALL TSP( 2.6, 5.2, BCDBLK(32), 18 )
01345 554.      CALL TSP( 2.6, 4.6, BCDBLK(35), 18 )
01346 555.      CALL TSP( 2.6, 4.0, BCDBLK(38), 18 )
01347 556.      DO 770 I = 1, MAXU, 5
01352 557.      UI(I) = UIN + FLOAT( I - 1 ) * DUI
01353 558.      PMU1 = 5.4286 * ALOG( AMU(1)/AMIN ) + 2.0
01354 559.      IF( ! .EQ. 1 ) GO TO 780
01356 560.      TX(1) = TX(2)
01357 561.      TY(2) = AMIN( PMU1, 39.5 )
01360 562.      IF( TY(1) .GT. 40.0 ) GO TO 770
01362 563.      CALL DVR( 1, 0, TX, TY, 1 )
01363 564.      760 TX(1) = UI(1) + 1.985
01364 565.      TY(2) = PMU1
01365 566.      TX(2) = UI(1) + 2.015
01366 567.      TY(1) = AMIN( PMU1, 39.5 )
01367 568.      IF( (PMU1-39.5) .LT. 1.E-37 ) CALL DVR(1, 0, TX, TY, 1)
01371 569.      770 CONTINUE
01373 570.      CALL ADF
01374 571.      NFRAME = NFRAME + 1
01374 572.      C
01375 573.      801 CONTINUE
01376 574.      READ (15) UX
01401 575.      NEND = 1
01402 576.      IF (ABS(UX + 5.) .LT. EPSLN) NEND = 2
01404 577.      IF (ABS(UX + 7.) .LT. EPSLN) NEND = 3
01406 578.      GO TO ( 32, 800, 720 ), NEND
01406 579.      C
01407 580.      800 CONTINUE
01410 581.      IF (IPLOT1 .EQ. 1) GO TO 420
01412 582.      CALL FRAME (0.0, 1.0, 1.0, 0.0)
01413 583.      DO 810 I = 1,5
01416 584.      YTP = 0.56 - FLOAT(I) * 0.04
01417 585.      810 CALL TSP( 0.2, YTP, IDANDI(1,1), 72 )
01421 586.      CALL ADF
01422 587.      CALL FINISH
01423 588.      NFRAME = NFRAME + 1
01424 589.      PRINT 14, NFRAME
01427 590.      820 CONTINUE
01430 591.      IF (IBCD0 .NE. 0) REWIND 15
01432 592.      0DIAGNOSTIC THE RETURN STATEMENT IS ILLEGAL IN A MAIN PROGRAM. IT WAS CHANGED TO STOP.
01433 593.      RETURN
01435 594.      999 PRINT 13
01437 595.      WRITE (6, 13)
01440 596.      CALL DUMP
01440 597.      GO TO 270
01440 598.      C
01440 599.      C SECTION FOR FILLING DYPDUT ARRAY, IPLOT1 .EQ. 1
01440 600.      C
01441 601.      910 CONTINUE
01441 602.      C

```

3MAN1850
 3MAN1868
 3MAN1878
 3MAN1890

AFWL-TR-67-131, Vol IV

```

01442 003.      IF (ABS((TK-SAVE)/TK) .LT. EPSILN) GO TO 411
01442 004.      C      IF ABOVE TRUE THEN PRESENT TEMPERATURE IS SAME AS LAST PREVIOUS
01442 005.      C      TEMPERATURE
01444 006.      IF (NAME .EQ. ANDIMX) GO TO 421
01444 007.      C
01444 008.      C      NEW TEMPERATURE, DIAPHANOUS INPUT TAPE
01446 009.      WRITE (6,0) (ID(I), I=1,12), TK
01454 010.      GO TO 420
01455 011.      C
01456 012.      441 CONTINUE
01456 013.      C      NEW TEMPERATURE, ANDIMX INPUT TAPE
01456 014.      C
01457 015.      WRITE (6,21) ((IDANDI(I,J), I=1,12), J=1,5), TK
01457 016.      C
01457 017.      C
01471 018.      440 CONTINUE
01472 019.      IF (SAVEY .LT. 1.E-37 .AND. NEND.NE.2) GO TO 412
01474 020.      IEND(J1)= MARKER + 9
01475 021.      NPTS(J1)= (IEND(J1)-IENDE)/10
01476 022.      IENDE= IEND(J1)
01477 023.      IF (NEND .EQ. 2) GO TO 430
01501 024.      J1= J1 + 1
01502 025.      412 CONTINUE
01503 026.      SAVEY= TK
01504 027.      411 CONTINUE
01505 028.      IF (NAME .EQ. ANDIMX) GO TO 422
01507 029.      WRITE (6,15) GAMMA, RMO, OIOP, EPSMAL, EIPART, AKAPPA, WAMBOA,
01507 030.      1 ZBAR, GAMNEW
01522 031.      GO TO 423
01522 032.      C
01523 033.      422 CONTINUE
01524 034.      WRITE (6,22) RMO, ZBAR, AKAPPA, WAMBOA
01524 035.      C
01532 036.      423 CONTINUE
01532 037.      C
01533 038.      MARKER= MARKER + 10
01534 039.      DYP0UT(MARKER)= TK
01535 040.      DYP0UT(MARKER+1)= GAMMA
01536 041.      DYP0UT(MARKER+2)= RMO
01537 042.      DYP0UT(MARKER+3)= OIGP
01540 043.      DYP0UT(MARKER+4)= EPSMAL
01541 044.      DYP0UT(MARKER+5)= EIPART
01542 045.      DYP0UT(MARKER+6)= AKAPPA
01543 046.      DYP0UT(MARKER+7)= WAMBOA
01544 047.      DYP0UT(MARKER+8)= ZBAR
01545 048.      DYP0UT(MARKER+9)= GAMNEW
01545 049.      C
01546 050.      GO TO 251
01546 051.      C
01547 052.      430 CONTINUE
01548 053.      JJ= IEND(J1)
01548 054.      WRITE (6,23) J1, (L, NPTS(L), IEND(L), L=1,J1)
01548 055.      43 FORMAT (1M1,15,57M SET(S) OF OUTPUT PARAMETERS HAVE BEEN STORED AS
01548 056.      1 FOLLOWS //10X,1M1,13X,7M1NPTS(I),13X,7MIEND(I)/16X,15,15X,15,15X,
01548 057.      2 15))
01548 058.      WRITE (6,24) (DYP0UT(LL), LL=1,JJ)
01571 059.      44 FORMAT (16M1DYP0UT ARRAY IS /(1P10E12,5))
01572 060.      WRITE (6,25)
01574 061.      45 FORMAT (35M0DYPERN RUN COMPLETED SUCCESSFULLY. )
01575 062.      CALL GRAPH
01576 063.      GO TO 820
01577 064.      END

```

END OF LISTING. 3 *DIAGNOSTIC* MESSAGE(S).

<u>COLUMNS</u>	<u>FORMAT</u>	<u>INPUT VARIABLE</u>	<u>MEANING</u>
1-10	F10.4	TKIN	Temperature at which plotting of opacity data and punching (of thermodynamic quantities) begin, or temperature at which array (of thermodynamic quantities) starts to be filled
11-20	F10.4	TKEND	Last temperature for which opacity data are plotted and thermodynamic quantities are punched on cards, or last temperature for which data are stored for plots of thermodynamic quantities
21-30	F10.4	SIZ	Not used
36-40	I5	M	If (M.GT.0), the value of AMIN is changed to the highest power of 10 which divides AMIN If (M.EQ.0), AMIN is not changed
46-50	I5	N	If (N.GT.0), ANDIMX (Huebner) opacity data are plotted only for $u = 0.3$ to $u = 15$. If (N.EQ.0), all ANDIMX (Huebner) opacity data are plotted
56-60	I5	IPLOT1	If (IPLOT1.EQ.0), DYPER4 does opacity plots and punches cards containing thermodynamic data If (IPLOT1.EQ.1), DYPER4 fills an array of thermodynamic quantities to be plotted by subroutine GRAPH
66-70	I5	IBCD0	If (IBCD0.EQ.0), the input data tape is a DENSER BCD data tape If (IBCD0.NE.0), the input data tape is a binary DIAPHANOUS or ANDIMX data tape

To use the DYPER4 program, the following tapes must be mounted:

1. One input data tape
 - a. DENSER data tape - mount on unit 10
 - b. DIAPHANOUS or ANDIMX data tape - mount on unit 15

2. The output (plot) tape, which must be written at a tape density of 556 BPI - mount on unit 16.

The plots in this volume were prepared by the DYPER4 program. Plots of the absorption coefficients as a function of frequency (at a given temperature - density point for these materials) are being prepared.

GRAPH: A PLOTTING PROGRAM

The GRAPH subprogram is used in conjunction with either the DYPER4, TRANS, or GOLEM programs. Given a one-dimensional array of variables set up in regularly spaced repeating groups, GRAPH produces SC-4020 plot tapes of user-specified quantities. It is written in FORTRAN IV language. The plots produced have, on each curve, the dependent variable plotted versus one of the (assumed) two independent variables, while one independent variable is held constant. Five cards per plot are required as GRAPH input. They are:

1. Two cards containing the following information:
 - a. Card 1/2 in format (4(I2, 1X), 6X, 15(I2, 1X)) specifying all data necessary to plot values. (Values are read into (IN(J), J=1, 4) and (OPN(JJ), JJ=1, 15))
 1. If (IN(1). EQ. 0) all plotting is done
 2. If (IN(1). EQ. -2) code returns to the calling program to allow a new VARB array to be set up so that more frames may be added to same plot tape
 - b. Card 2/2 in format (7E10.4, 4X, A6) that specifies 7 real constants to be used in setting up the x- and y-array variables (read into the XIN array), and ICURVE; ICURVE is a six-letter word specifying the independent variable held constant when the curve(s) are being plotted. Normally this is the temperature.

```

00101 1. SUBROUTINE GRAPH
00101 2. C
00101 3. C SUBROUTINE TO PLOT DIAPHANOUS, ANDIMX, DENSER, OR GOLEM-CALCULATED
00101 4. C VALUES
00101 5. C
00101 6. C
00103 7. INTEGER OPN, TEMP, CHAR, MCHAR
00104 8. INTEGER GOLEM, DENSER, ANDIMX
00105 9. INTEGER GLAB
00105 10. C
00106 11. COMMON/DI1/IEND(100), NPTS(100), J2, NAME, GLAB(12), AA(12240)
00107 12. COMMON/DI2/INI, IN2, IN3, IN4, C1, C2, C3, C4, C5, C6, C7, C8,
00110 13. 1 IDUMMY, JOUMMY, NGRID, MCHAR, ICON, NNTM
00110 14. COMMON/DI3/NGRID, KDUHM, IFLAG
00111 15. COMMON/PHSA/NFRAME, TESTT, SECRET(4), ANDIMX, IDANDI(12,5)
00112 16. C
00112 17. C
00113 18. DIMENSION IN(4), OPN(15)
00114 19. DIMENSION X(26,100), Y(26,100)
00115 20. DIMENSION XX(100), YY(100), NCHK(100), LABSAY(12)
00116 21. DIMENSION XLAB(12), YLAB(12), XIN(7), LABEL(54), CCURVE(26)
00117 22. DIMENSION CHAR(26), MCHAR(26), LCHAR(9)
00120 23. DIMENSION JCURVE(2), JABEL(26)
00121 24. DIMENSION C(8), VALS(100), ISCALE(2)
00121 25. C
00121 26. C
00121 27. C ITAPE IS THE PLOT OUTPUT TAPE, NORMALLY ON UNIT 10
00122 28. DATA ITAPE/16/
00124 29. DATA KDUHM,NDUM/0.,682/
00127 30. DATA JCURVE/2*6M //, LIN/3MLIN/, LOG/3ML00/
00133 31. DATA Y1/1.0443638322/
00135 32. DATA X1/0.026787715/, DELTY1/0.013392857/
00140 33. DATA EPSILN/1.E-5/
00142 34. DATA JBLANK/6M //, 1VPLYD/-1/
00145 35. DATA DENSER / 6MDENSER //, GOLEM / 6M GOLEM //, ANDIMX / 6MANDIMX /
00151 36. DATA ITEMP/6M TEMP /
00153 37. DATA CHAR/17,18,19,20,21,22,23,24,25,33,34,35,36,37,38,39,40,41;
00153 38. 1 50,51,52,53,54,55,56,57/
00153 39. DATA MCHAR/1MA, 1MB, 1MC, 1MD, 1ME, 1MF, 1MG, 1MH, 1MI, 1MJ, 1MK,
00155 40. 1 1ML, 1MM, 1MN, 1MO, 1MP, 1MQ, 1MR, 1MS, 1MT, 1MU, 1MV,
00155 41. 2 1MW, 1MX, 1MY, 1MZ/
00157 42. DATA LCHAR/ 1M1,1M2,1M3,1M4,1M5,1M6,1M7,1M8,1M9/
00157 43. C
00161 44. EQUIVALENCE (GLAB(1), ID(1))
00162 45. EQUIVALENCE (IN(1),IN1), (OPN(1),IDUMMY), (C(1),C1), (NCURVE,NNTM)
00163 46. EQUIVALENCE (XIN(5),CONSTX), (XIN(6),CONSTY), (OPN(12),IPL0TT)
00164 47. EQUIVALENCE (XIN(7), CONST)
00164 48. C
00164 49. C SUBROUTINE ASSUMES THE FOLLOWING (ALL COMMENTS CONCERNING DIAPHA-
00164 50. C NOUS ARE APPLICABLE TO DENSER)
00164 51. C 1. VALUES ARE STORED IN ORDER OF DECREASING OR INCREASING VALUE
00164 52. C (IF POINTS ARE TO BE CONNECTED).
00164 53. C 2. DIAPHANOUS VALUES ARE STORED IN 10-WORD GROUPS, AS TEMPERA-
00164 54. C TURE VECTORS, IN ORDER OF DECREASING DENSITIES PER TEMPERA-
00164 55. C TURE.
00164 56. C 3. ANDIMX VALUES ARE STORED IN 10-WORD GROUPS, IN THE SAME
00164 57. C MANNER AS DIAPHANOUS
00164 58. C 4. GOLEM VALUES ARE STORED AS 12-WORD GROUPS, IN ANY MANNER
00164 59. C THE USER DESIRES, AS LONG AS ALL VALUES STORED CAN BE PLOT-
00164 60. C TED IN ORDER OF INCREASING OR DECREASING X OR Y VALUE (IF
00164 61. C POINTS ARE TO BE CONNECTED).
00164 62. C 5. THE FOLLOWING QUANTITIES ARE KNOWN
00164 63. C A) IEND ARRAY, AN ARRAY CONTAINING THE LOCATIONS OF THE
00164 64. C LAST CELL USED TO STORE VALUES FOR A GIVEN CURVE
00164 65. C (E.G., THE LAST CELL USED AT A CONSTANT THETA, FOR
00164 66. C DIAPHANOUS).
00164 67. C B) NPTS ARRAY, AN ARRAY CONTAINING THE NUMBER OF X-Y POINTS
00164 68. C TO BE PLOTTED, PER GIVEN CONSTANT (COMPUTED AS NPTS(I)/2
00164 69. C NPTS(I)/10 FOR DIAPHANOUS AND ANDIMX OUTPUT, AND NPTS(I)
00164 70. C = NPTS(I)/12 FOR GOLEM OUTPUT)
00164 71. C C) J2, THE NUMBER OF TEMPERATURE SETS STORED FOR PLOTTING
00164 72. C D) NAME, AN INTEGER VALUE IDENTIFYING THE SOURCE OF THE
00164 73. C DATA TO BE PLOTTED
00164 74. C 1) NAME = -1, DIAPHANOUS OUTPUT
00164 75. C 2) NAME = DENSER, CONDENSED DIAPHANOUS OUTPUT
00164 76. C 3) NAME = ANDIMX, ANDIMX OUTPUT
00164 77. C 4) NAME = GOLEM, GOLEM OUTPUT
00164 78. C E) TRANS OR DYPER RUNS - AN IDENTIFYING TITLE TO BE PRINTED
00164 79. C AT THE TOP OF EACH GRAPH.

```



```

00160 80. C
00160 81. CO INPUT IS AS FOLLOWS
00160 82. CO 1) TWO CARDS CONTAINING THE FOLLOWING INFORMATION
00160 83. CO A) CARD 1/2 IN FORMAT (6(12:1X), 6X, 15(12:1X)) SPECIFYING
00160 84. CO ALL DATA NECESSARY TO PLOT VALUES. (VALUES ARE READ INTO
00160 85. CO (IN(J), J=1-6) AND (OPN(JJ), JJ=1-15))
00160 86. CO 1) IF (IN(1).EQ.0) ALL PLOTTING IS DONE.
00160 87. CO 2) IF (IN(1).EQ.-2) CODE RETURNS TO THE CALLING PROGRAM
00160 88. CO TO ALLOW A NEW VARD ARRAY TO BE SET UP SO THAT MORE
00160 89. CO FRAMES MAY BE ADDED TO THE SAME PLOT TAPE.
00160 90. CO B) CARD 2/2 IN FORMAT (7E10.0+4X.A6) THAT SPECIFIES 7 REAL
00160 91. CO CONSTANTS TO BE USED IN SETTING UP THE X- AND Y-ARRAY
00160 92. CO VARIABLES (READ INTO THE XIN ARRAY), AND ICURVE.
00160 93. CO ICURVE IS A 6-LETTER WORD SPECIFYING THE INDEPENDENT
00160 94. CO VARIABLE OF WHICH THE CURVE(S) ARE BEING PLOTTED. NORMALLY
00160 95. CO THIS IS THE TEMPERATURE.
00160 96. CO 3) A CARD IN FORMAT (12A6), CONTAINING TITLE INFORMATION USED
00160 97. CO AS A HEADING FOR EACH FRAME. (MAY BE A BLANK CARD)
00160 98. CO 4) TWO CARDS, EACH IN FORMAT 12A6, THAT SPECIFY THE APPROPRIATE
00160 99. CO LABELS FOR THE X- AND Y-AXES, RESPECTIVELY (EITHER ONE
00160 100. CO OR BOTH CARDS MAY BE BLANK)
00160 101. C
00160 102. CO ***** DESCRIPTION OF INPUT *****
00160 103. CO THE IN ARRAY CONTROLS WHICH VARIABLES IN THE VARD ARRAY ARE TO
00160 104. CO BE USED FOR PLOTTING
00160 105. CO A) IN(1) AND IN(2) SPECIFY VARIABLES TO BE USED IN THE X-ARRAY,
00160 106. CO THE ARRAY CONTAINING THE ABSISSAS OF POINTS TO BE PLOTTED.
00160 107. CO B) IN(3) AND IN(4) SPECIFY VARIABLES TO BE USED IN THE Y-ARRAY,
00160 108. CO THE ARRAY CONTAINING THE ORDINATES OF POINTS TO BE PLOTTED.
00160 109. C
00160 110. CO IN(I) SALT VARIABLE HUEDNER VARIABLE SOLEN VARIABLE
00160 111. CO 1 TK TK THETA(TK)
00160 112. CO 2 GAMMA RHO RHO
00160 113. CO 3 RHO RHO P1 (PRESSURE)
00160 114. CO 4 PRESNR E (ENERGY)
00160 115. CO 5 ENERGT NBAR OR CAPAC
00160 116. CO 6 EION EIONIZ OR CAPAR
00160 117. CO 7 KROS THOPA CV
00160 118. CO 8 KPLK CROPA FEW (ZBAR)
00160 119. CO 9 ZBAR CAPNF(ZBAR) PBI
00160 120. CO 10 EGAM ASD (SOUND SPEED)
00160 121. CO 11 EGAM
00160 122. CO 12 EGAM2 OR GAMMA
00160 123. C
00160 124. CO THE OPN ARRAY CONTROLS VARIOUS OPTIONS USED IN PLOTTING
00160 125. CO OPN(1) DETERMINES HOW TO MANIPULATE THE VARIABLES TO BE SET UP
00160 126. CO FOR THE X-ARRAY
00160 127. CO OPN(2) DETERMINES HOW TO MANIPULATE THE VARIABLES TO BE SET UP
00160 128. CO FOR THE Y-ARRAY
00160 129. CO
00160 130. CO OPN(I), I=1 OR 2 X OR Y ARRAY, J=1 OR 3 RESPECTIVELY
00160 131. CO (ANY VARD ARRAY VARIABLE MAY BE EXPONENTIATED
00160 132. CO BEFORE BEING OPERATED ON IN ONE OF THE FOLLOWING
00160 133. CO WAYS)
00160 134. CO
00160 135. CO
00160 136. CO 1 VARD(IN(J))
00160 137. CO 2 VARD(IN(J)) + XIN(J)
00160 138. CO 3 VARD(IN(J)) * XIN(J)
00160 139. CO 4 VARD(IN(J)) + VARD(IN(J+1))
00160 140. CO 5 (VARD(IN(J)) + VARD(IN(J+1))) * XIN(J)
00160 141. CO 6 (VARD(IN(J)) + VARD(IN(J+1))) * XIN(J)
00160 142. CO 7 VARD(IN(J)) - VARD(IN(J+1))
00160 143. CO 8 (VARD(IN(J)) - VARD(IN(J+1))) * XIN(J)
00160 144. CO 9 (VARD(IN(J)) - VARD(IN(J+1))) * XIN(J)
00160 145. CO 10 VARD(IN(J)) * VARD(IN(J+1))
00160 146. CO 11 (VARD(IN(J)) * VARD(IN(J+1))) * XIN(J)
00160 147. CO 12 (VARD(IN(J)) * VARD(IN(J+1))) * XIN(J)
00160 148. CO 13 VARD(IN(J)) / VARD(IN(J+1))
00160 149. CO 14 (VARD(IN(J)) / VARD(IN(J+1))) * XIN(J)
00160 150. CO 15 (VARD(IN(J)) / VARD(IN(J+1))) * XIN(J)
00160 151. C
00160 152. CO OPN(3) DETERMINES THE VALUE OF NGRID; THE TYPE OF GRID USED FOR
00160 153. CO PLOTTING
00160 154. CO TO GET TIC-MARKS ONLY (NO GRID LINES), ADD 4 TO THE VALUE OF NGRID
00160 155. CO NECESSARY TO OBTAIN THE TYPE OF GRID WANTED, AND INPUT THAT SUM
00160 156. CO FOR OPN(3). **EXCEPTION - IF NGRID.LE.0, SUBTRACT 8 TO GET THE
00160 157. CO CODE TO SCALE WITH TIC-MARKS**
00160 158. CO
00160 159. CO OPN(3) X-AXIS Y-AXIS

```


AFWL-TR-67-131, Vol IV

00164	160.	C	0	CODE SCALES	CODE SCALES
00164	161.	C	1	LINEAR	LINEAR
00164	162.	C	2	LOGARITHMIC	LINEAR
00164	163.	C	3	LINEAR	LOGARITHMIC
00164	164.	C	4	LOGARITHMIC	LOGARITHMIC
00164	165.	C	-1	LIN	CODE WILL SCALE
00164	166.	C	-2	LOG	CODE WILL SCALE
00164	167.	C	-3	CODE SCALES	LIN
00164	168.	C	-4	CODE SCALES	LOG
00164	169.	C			
00164	170.	C		OPN(4) DETERMINES THE VALUE OF NCHAR, THE DECIMAL CODE OF THE	
00164	171.	C		CHARACTER TO BE PLOTTED. NORMAL VALUE IS 42, A PLOTTING DOT.	
00164	172.	C		IF MORE THAN ONE CURVE PER FRAME.	
00164	173.	C		1) IF (OPN(4).EQ.0), 'A' FOR THE FIRST CURVE, '0' FOR THE SECOND	
00164	174.	C		CURVE, ETC. (MAXIMUM OF 26 CURVES PER FRAME)	
00164	175.	C		2) IF (OPN(4).LT.0), '1' FOR THE FIRST CURVE, '2' FOR THE SECOND	
00164	176.	C		CURVE, ETC. (MAXIMUM OF 9 CURVES PER FRAME)	
00164	177.	C			
00164	178.	C		OPN(5) DETERMINES THE VALUE OF ICON, THE OPTION FOR CONNECTING	
00164	179.	C		POINTS WITH A LINE SEGMENT.	
00164	180.	C		IF (ICON.EQ.1) CONNECT POINTS	
00164	181.	C		IF (ICON.EQ.2) DO NOT CONNECT POINTS	
00164	182.	C			
00164	183.	C		OPN(6) CONTROLS THE NUMBER OF PLOTS PER FRAME.	
00164	184.	C		NOTE - NO MORE THAN 18 CURVES MAY BE PUT ON ANY GIVEN FRAME	
00164	185.	C			
00164	186.	C		OPN(7) DETERMINES WHETHER LABELS WILL BE PRINTED ON THE PLOTS.	
00164	187.	C		IF (OPN(7).EQ.0) PRINT LABELS ALONG THE TOP OF THE FRAME AND	
00164	188.	C		ALONG THE X- AND Y-AXES (TO BE READ FROM THE THREE INPUT DATA	
00164	189.	C		CARDS THAT FOLLOW, EACH IN FORMAT 12A6, AND USED TO LABEL THE TOP	
00164	190.	C		OF THE FRAME, THE X-AXIS, AND THE Y-AXIS, RESPECTIVELY.	
00164	191.	C			
00164	192.	C		IF (OPN(7).LT.0) PRINT A SUMMARY OF ALL THE CURVE LABELS AND	
00164	193.	C		VALUES IN A BOX IN ONE CORNER (-1 FOR UPPER LEFT, -2 FOR UP-	
00164	194.	C		PER RIGHT, -3 FOR LOWER LEFT, -4 FOR LOWER RIGHT)	
00164	195.	C			
00164	196.	C		IF (OPN(7).EQ.1) USE THE DIAPHANOUS, DENSER, OR ANDINX ID RECORD	
00164	197.	C		(READ BY OYPER OR TRANS) TO LABEL THE TOP OF THE GRAPHS, USING	
00164	198.	C		THE NORMAL PRINTOUT (NO BOX)	
00164	199.	C			
00164	200.	C		TO USE THE ID RECORD READ BY TRANS OR OYPER, PLUS A BOX PRINTOUT,	
00164	201.	C		SUBTRACT 4 FROM THE VALUE (AS SPECIFIED ABOVE) NECESSARY TO	
00164	202.	C		INDICATE THE CORNER CHOSEN FOR PRINTING THE BOX.	
00164	203.	C			
00164	204.	C		IF (OPN(7).EQ.2) DO NO PRINTING ON THE PLOTS	
00164	205.	C			
00164	206.	C		OPN(8), OPN(9), OPN(10), AND OPN(11) DETERMINE WHETHER LOGARITHMS	
00164	207.	C		(COMMON OR NATURAL) ARE TO BE TAKEN OF VARD(IN(J)), J=1 TO 4,	
00164	208.	C		RESPECTIVELY, BEFORE THE X- AND Y-ARRAYS ARE SET UP.	
00164	209.	C		A) NEGATIVE OPN(I), I=8,9,10,OR 11, MEANS USE NATURAL LOG OF	
00164	210.	C		(VARD(J)*XIN(J)), J=1,4), RESPECTIVELY.	
00164	211.	C		B) POSITIVE OPN(I), I=8,9,10,OR 11, MEANS USE COMMON LOG OF	
00164	212.	C		(VARD(J)*XIN(J)), J=1,4), RESPECTIVELY.	
00164	213.	C			
00164	214.	C		OPN(12)=IPLOTT, USED IF THETA CURVES ARE NOT BEING PLOTTED. SPEC-	
00164	215.	C		IFIES THE GENERAL CELL LOCATION OF THE CURVE VARIABLE (EX.,	
00164	216.	C		IPLOTT=2 IF GAMMA CURVES ARE BEING PLOTTED FOR DIAPHANOUS)	
00164	217.	C			
00164	218.	C		OPN(13) IS A QUANTITY INPUT IFF USER WISHES CODE TO SCALE EITHER	
00164	219.	C		OR BOTH GRID AXES, USING A LIMITING VALUE DIFFERENT THAN 100	
00164	220.	C		AS A DECIDING VALUE TO PLOT LOGARITHMICALLY, RATHER THAN	
00164	221.	C		LINEARLY.	
00164	222.	C			
00164	223.	C			

AFWL-TR-67-131, Vol IV

```

00164 224. C (OPN(J),J=14,15) FREE PARAMETERS
00164 225. C
00164 226. C (XIN(J),J=1,4) MAY BE USED TO EXPONENTIATE (VARD(IN(J)),J=1,4),
00164 227. C RESPECTIVELY, BEFORE THE X- AND Y-ARRAYS ARE SET UP IF INPUT
00164 228. C AS ZERO, CODE SETS THEM TO ONE.
00164 229. C
00164 230. C XIN(5) AND XIN(6) ARE ADDITIVE OR MULTIPLICATIVE CONSTANTS USED TO
00164 231. C MODIFY VARD ARRAY VARIABLES CHOSEN FOR THE X- AND Y-ARRAYS,
00164 232. C RESPECTIVELY
00164 233. C
00164 234. C XIN(7) IS INPUT IFF OPN(12), I.E., IPLOTT, IS USED. ALLOWS USER TO
00164 235. C INPUT A CONSTANT VALUE FOR PLOTTING ONE CURVE (EX., OPN(12)=2,
00164 236. C XIN(7)=100., TO PLOT A CURVE FOR GAMMA=100., IN DIAPHANOUS.)
00164 237. C
00164 238. C A NORMAL RUN SCALES THE GRID, USES ALPHABETIC CHARACTERS, CONNECTS
00164 239. C POINTS, AND PLOTS ALL CURVES ON ONE FRAME (MAXIMUM OF 26)
00164 240. C IF THE INPUT CARD CONTAINS ZEROS (BLANKS) FOR THE VARIABLES CON-
00164 241. C TROLLING THESE THINGS (OPN(3), OPN(4), OPN(6), ICURVE, RESPEC-
00164 242. C TIVELY), THE CODE WILL SET THE VALUES NECESSARY TO DO THEM.
00164 243. C
00164 244. C
00164 245. C LASTI= IEND(J2)
00164 246. C NCELLS= 10
00164 247. C IF (NAME .EQ. GOLEM) NCELLS=12
00164 248. C NSET= LASTI/NCELLS
00164 249. C J2SAVE= J2
00164 250. C DO 10 NM=1,12
00164 251. C LABSAY(NM)= GLAB(NM)
00164 252. C 10 CONTINUE
00164 253. C
00164 254. C 502 CONTINUE
00164 255. C READ INPUT CARDS SPECIFYING PLOTTING OPTIONS
00164 256. C READ (5,1) (IN(J),J=1,4), (OPN(JJ),JJ=1,15), (XIN(JJ),JJ=1,7)
00164 257. C 1, ICURVE
00164 258. C 1 FORMAT (4(I2,1X), 4X, 15(I2,1X) / 7E10.4, 4X, A6)
00164 259. C IF (IN(1).EQ.0 .AND. IVPLTD.GT.(-1)) GO TO 500
00164 260. C WRITE (6,16) (IN(J),J=1,4), (OPN(JJ),JJ=1,15), (XIN(JJ),JJ=1,7)
00164 261. C 1, ICURVE
00164 262. C 16 FORMAT (17H1INPUT AS READ IS / 14H IN ARRAY IS,3(I2,1M,1X), 12 /
00164 263. C 115H OPN ARRAY IS, 14(I2,1M,1X), 12 / 15H XIN ARRAY IS,
00164 264. C 2 6(IPE12.4, 1M, 1X), 1PE12.4 / 12H0 ICURVE IS, A6)
00164 265. C
00164 266. C SET IN(1).EQ.0 TO FINISH PLOT TAPE
00164 267. C IS IN(1).EQ.07 -YES,NO-
00164 268. C IF (IN(1).EQ.0 .AND. IVPLTD.EQ.(-1)) GO TO 507
00164 269. C IVPLTD= IVPLTD + 1
00164 270. C
00164 271. C SET IN(1).EQ.-2 TO RETURN TO THE MAIN PROGRAM TO COMPUTE NEW
00164 272. C VALUES FOR THE VARD ARRAY
00164 273. C IS IN(1).EQ.-2? -YES,NO-
00164 274. C IF (IN(1).EQ.-2) GO TO 503
00164 275. C
00164 276. C
00164 277. C HAS OPN(1) BEEN INPUT INCORRECTLY? -YES,NO-
00164 278. C IF (OPN(1).LE.0 .OR. OPN(1).GE.16) GO TO 499
00164 279. C HAS OPN(2) BEEN INPUT INCORRECTLY? -YES,NO-
00164 280. C IF (OPN(2).LE.0 .OR. OPN(2).GE.16) GO TO 498
00164 281. C
00164 282. C HAS OPN(7) BEEN INPUT INCORRECTLY? -YES,NO-
00164 283. C IF (OPN(7).GT. 2) GO TO 498
00164 284. C DO 22 K5=1,LASTI
00164 285. C AA(K5)= VARD(K5)
00164 286. C 22 CONTINUE
00164 287. C J2= J2SAVE
00164 288. C READ TITLE CARD
00164 289. C
00164 290. C LABOLD= OPN(7) + 4
00164 291. C IF (OPN(7).LT. (-4)) OPN(7)=LABOLD
00164 292. C READ (5,2) (GLAB(I),I=1,12)
00164 293. C 2 FORMAT (12A6)
00164 294. C 20 CONTINUE
00164 295. C WRITE (6,5) (GLAB(I), I=1,12)
00164 296. C 5 FORMAT (1X,12A6)
00164 297. C 27 CONTINUE
00164 298. C READ (5,2) (XLAB(I),I=1,12), (YLAB(I),I=1,12)
00164 299. C WRITE (6,5) (XLAB(I),I=1,12), (YLAB(I),I=1,12)
00164 300. C IF (OPN(7).NE.1 .AND. LABOLD.GT.0) GO TO 29
00164 301. C DO 75 J5=1,12
00164 302. C GLAB(J5)= LABSAY(J5)
00164 303. C 75 CONTINUE
00164 304. C

```

AFWL-TR-67-131, Vol IV

```

00345 305. 29 CONTINUE
00345 306. C
00345 307. C SET UP PLOTTING OPTION
00345 308. C
00346 309. IF (NGRID .GT. 8) GO TO 496
00346 310. C
00350 311. NNGRID= 0
00351 312. IF (NGRID .GT. 4) NNGRID=NGRID - 4
00353 313. IF (NGRID .LT. (-4)) NNGRID=NGRID+5
00353 314. C
00355 315. IF (NNGRID.NE. 0) NGRID=NNGRID
00355 316. C
00357 317. IF (NGRID.GT. 0 .OR. NGRID.LT.(-4)) GO TO 55
00361 318. IF (NGRID .EQ. (-1)) ISCALE(1)=LIN
00363 319. IF (NGRID .EQ. (-2)) ISCALE(1)=LO8
00365 320. IF (NGRID .EQ. (-3)) ISCALE(2)=LIN
00367 321. IF (NGRID .EQ. (-4)) ISCALE(2)=LO8
00371 322. 55 CONTINUE
00371 323. C
00372 324. IF (NCHAR.EQ.0 .AND. NNTM.EQ.1) NCHAR=42
00374 325. IF (ICON .EQ. 0) ICON = 1
00376 326. IF (ICON.LT.1 .OR. ICON.GT.2) GO TO 495
00400 327. IF (NNTM.GT.J2 .OR. NNTM.GT.18) GO TO 494
00402 328. IF (NNTM .EQ. 0) NNTM=J2
00404 329. IF (IPLOTT .EQ. 0) IPLOTT=1
00406 330. IF (ICURVE .EQ. JBLANK) ICURVE = ITEMP
00410 331. BSCALE= 100.
00411 332. IF (OPN(13) .NE. 0) BSCALE=OPN(13)
00413 333. ICURVE(1)= ICURVE
00413 334. C
00413 335. C DETERMINE VALUES OF COEFFICIENTS NECESSARY TO SET UP PLOTTING
00413 336. C 1 VARIABLES
00413 337. C
00416 338. DO 18 JKK=1,8
00417 339. C(JKK)= 1.
00420 340. 18 CONTINUE
00422 341. KK= 1
00423 342. DO 20 K=1,2
00426 343. IF (OPN(K).LE.3 .OR. OPN(K).GE.10) C(KK)=0.
00430 344. IF (OPN(K).GE.7 .AND. OPN(K).LE.9) C(KK)=-1.
00432 345. IF (OPN(K) .LE. 9) C(KK+1)=0.
00434 346. IF (OPN(K) .GE. 13) C(KK+1)=1.
00436 347. IF (MOD(OPN(K),3) .NE. 0) C(KK+2)=0.
00440 348. IF (MOD(OPN(K)-1,3).EQ.0 .OR. MOD(OPN(K),3).EQ.0) C(KK+3)=0.
00442 349. KK= 5
00443 350. 20 CONTINUE
00445 351. WRITE (6,15) (C(I), I=1,8)
00453 352. 15 FORMAT (12HOC ARRAY IS , 7(F4.1,2H, ), F4.1)
00454 353. 17 FORMAT (1H1)
00454 354. C
00454 355. C
00454 356. C
00455 357. IF (ABS(CONSTX) .LT. 1,E-37) CONSTX=1.
00457 358. IF (ABS(CONSTY) .LT. 1,E-37) CONSTY=1.
00457 359. C
00461 360. WRITE (6,25) (IN(J),J=1,4), (OPN(J),J=1,15), (XIN(J),J=1,8),
00461 361. 1 ICURVE
00462 362. WRITE (6,5) (GLAB(I),I=1,12), (XLAB(I),I=1,12), (YLAB(I),I=1,12)
00516 363. 25 FORMAT (17HINPUT AS USED IS / 14H 1N ARRAY IS,3(I2,1H,1X), I2 /
00516 364. 115H OPN ARRAY IS , 14(I2,1H,1X), I2 / 13H XIN ARRAY IS ,
00516 365. 2 5(IPE12.4, 1H, 1X), IPE12.4 / 13H ICURVE IS , A6)
00517 366. IF (IPLOTT .EQ. 1) GO TO 750
00521 367. CALL SEQ(AA, NSETS, NCELLS, IPLOTT, VALS, NVALS)
00522 368. NROW= 0
00523 369. DO 749 J=1,NVALS
00526 370. NROW= NROW + 1
00527 371. CALL SERCH(VALS(J), IPLOTT, AA, NSETS, NCELLS, NPTS(J), NROW,
00527 372. 1 NROW)
00530 373. IEND(J)= NROW + NCELLS
00531 374. WRITE (6,1005) J, VALS(J), NPTS(J), NROW, NROW
00540 375. 1005 FORMAT (14, E15.8, 16, 10, 16)
00541 376. 749 CONTINUE
00543 377. IF (NNTM.EQ.J2 .AND. NVALS.NE.J2) NNTM=NVALS
00545 378. IF (NVALS .LT. NNTM) NNTM=NVALS
00547 379. IF (NNTM .GT. 18) NNTM=18
00551 380. J2= NVALS
00552 381. 750 CONTINUE
00552 382. C
00552 383. C USE (XIN(J),J=1,4) TO EXPONENTIATE (VAR(IN(J)), J=1,4),
00552 384. C RESPECTIVELY.
00553 385. IF (ABS(XIN(1)).LT.1,E-37 .AND. ABS(XIN(2)).LT.1,E-37 .AND.

```

AFWL-TR-67-131, Vol IV

```

00553 388.      1      ABS(XIN(3)).LT.1.E-37 .AND. ABS(XIN(4)).LT.1.E-37) GO TO 72
00555 387.      IF (IN2.EQ. 0) IN2=1
00557 388.      IF (IN4.EQ. 0) IN4=1
00561 389.      DO 71 KK5=1,NSETS
00564 390.      F6=      (KK5-1) * NCELLS
00565 391.      IF (ABS(XIN(1)) .GT. 1.E-37) AA(K6+IN1)=AA(K6+IN1)+XIN(1)
00567 392.      IF (ABS(XIN(2)) .GT. 1.E-37) AA(K6+IN2)=AA(K6+IN2)+XIN(2)
00571 393.      IF (ABS(XIN(3)) .GT. 1.E-37) AA(K6+IN3)=AA(K6+IN3)+XIN(3)
00573 394.      IF (ABS(XIN(4)) .GT. 1.E-37) AA(K6+IN4)=AA(K6+IN4)+XIN(4)
00575 395.      71 CONTINUE
00577 396.      72 CONTINUE
00577 397.      C
00600 398.      DO 64 K4=0,11
00603 399.      IF (OPN(K4) .EQ. 0) GO TO 65
00605 400.      DO 69 KK5=1,NSETS
00610 401.      K5=      (KK5-1) * NCELLS
00611 402.      INN=      IN(K4-7)
00612 403.      IF (OPN(K4) .LT. 0) GO TO 67
00614 404.      AA(INN+K5)= ALOG10(AA(INN+K5))
00615 405.      GO TO 68
00616 406.      67 CONTINUE
00617 407.      AA(INN+K5)= ALOG(AA(INN+K5))
00620 408.      68 CONTINUE
00621 409.      69 CONTINUE
00623 410.      65 CONTINUE
00624 411.      64 CONTINUE
00624 412.      C
00624 413.      C
00624 414.      C
00624 415.      C      MAKE INITIAL CALL TO SETUP
00626 416.      IF (IVPLTD .GT. 0) GO TO 33
00630 417.      NFRAME=      3
00631 418.      CALL SETUP(XDUM, NDUM, IYAP)
00631 419.      C
00631 420.      C      PLOT INITIAL FRAME CONTAINING TITLE INFORMATION
00632 421.      CALL FRAME (0.0, 1.0, 1.0, 0.0)
00632 422.      C      IS PLOT DATA FROM ANDIMX? -YES,NO--
00633 423.      IF (OPN(7) .EQ. 2) GO TO 32
00635 424.      IF (NAME .EQ. ANDIMX) GO TO 30
00637 425.      CALL TSP(0.2, 0.5, ID, 72)
00640 426.      GO TO 32
00640 427.      C
00641 428.      30 CONTINUE
00642 429.      DO 31 J4=1,5
00645 430.      YTYPE=      0.56 - FLOAT(J4) * 0.04
00646 431.      CALL TSP( 0.2, YTYPE, IDANDI(1,J4), 72)
00647 432.      31 CONTINUE
00651 433.      CALL TSP(0.42, 0.6, SECRET, 20)
00652 434.      32 CONTINUE
00653 435.      CALL ADF
00654 436.      NFRAME=      NFRAME + 1
00655 437.      33 CONTINUE
00655 438.      C
00655 439.      C      SET UP ARRAYS OF POINTS, PER CONSTANT, TO BE PLOTTED

```

AFWL-TR-67-131, Vol IV

```

00656 440.      ISTART=      0
00657 441.      NTM1=      1
00660 442.      LCURVE=      J2 - NNTM * (J2/NNTH)
00661 443.      NNFRAME=      (J2 + NNTM - 1)/NNTH
00662 444.      DO 60 J3=1,NNFRAM
00663 445.          IF (J3.EQ.NNFRAM .AND. LCURVE.NE.0) NCURVE = LCURVE
00665 446.      C
00665 447.      C      SET UP X- AND Y- ARRAYS NECESSARY FOR PLOTTING EACH GRAPH
00667 448.      DO 41 KK2=1,NCURVE
00672 449.          NNPTS=      NPTS(NTM1)
00673 450.          NTM1=      NTM1 + 1
00674 451.          CCURVE(KK2)= AA(ISTART + 1,PLOTT)
00674 452.      C
00675 453.          NGOOD=      1
00676 454.          NFGP=      0
00677 455.          DO 42 KL=1,NNPTS
00702 456.              NCHK(KL)= 0
00703 457.          42 CONTINUE
00703 458.      C
00705 459.          DO 40 KK1=1,NNPTS
00710 460.              K1=      ISTART + NCELLS * (KK1 - 1)
00711 461.              X(KK2,KK1)= ( AA(K1+IN1) + C1*AA(K1+IN2)) * ( AA(K1+IN2)*C2)
00711 462.                  + (CONSTX**C3) + (C4 * CONSTX)
00712 463.              Y(KK2,KK1)= (A/(K1+IN3) + C5*AA(K1+IN4)) * ( AA(K1+IN4)*C6)
00712 464.                  + (CONSTY**C7) + (C8 * CONSTY)
00713 465.              IF (NGRID .EQ. 1) GO TO 48
00715 466.              IF (X(KK2,KK1).LT.1.E-37 .AND. (NGRID.EQ.2 .OR. NGRID.EQ.4 .OR.
00715 467.                  1 NGRID.EQ.(-2) .OR. NGRID.EQ.(-5))) NCHK(KK1)=1
00717 468.              IF (Y(KK2,KK1).LT.1.E-37 .AND. (NGRID.EQ.3 .OR. NGRID.EQ.4 .OR.
00717 469.                  1 NGRID.EQ.(-4) .OR. NGRID.EQ.(-5))) NCHK(KK1)=1
00721 470.              IF (NCHK(KK1) .EQ. 1) NGOOD=2
00723 471.              IF (NFGP.EQ.0 .AND. NCHK(KK1).EQ.0) NFGP=KK1
00725 472.          40 CONTINUE
00726 473.          40 CONTINUE
00730 474.              ISTART=      IEND(NTM1 - 1)
00730 475.      C
00731 476.          GO TO (43,44), NGOOD
00732 477.          44 CONTINUE
00732 478.      C
00733 479.          IF (NFGP .EQ. 1) GO TO 45
00735 480.          DO 46 JM=NFGP,1,-1
00740 481.              WRITE (6,1000) X(KK2,JM), Y(KK2,JM), X(KK2,NFGP), Y(KK2,NFGP)
00746 482.          1000 FORMAT (53H0***WARNING*** A NEGATIVE VALUE HAS BEEN FOUND. X = ,
00746 483.              1 IPE14.0, 6H, Y = , IPE14.0, / 10H X IS BEING SET TO ,
00746 484.              2 IPE14.0, 20H, Y IS BEING SET TO , IPE14.0 //)
00747 485.              X(KK2,JM)= X(KK2,NFGP)
00750 486.              Y(KK2,JM)= Y(KK2,NFGP)
00751 487.              NCHK(JM)= 0
00752 488.          46 CONTINUE
00754 489.          45 CONTINUE
00754 490.      C
00755 491.          DO 47 KM=NFGP,NNPTS
00760 492.              IF (NCHK(KM) .NE. 1) GO TO 747
00762 493.              WRITE (6,1000) X(KK2,KM), Y(KK2,KM), X(KK2,KM-1), Y(KK2,KM-1)

```

AFWL-TR-67-131, Vol IV

```

00770 494.      X(KK2,KP) = X(KK2,KM-1)
00771 495.      Y(KK2,KM) = Y(KK2,KM-1)
00772 496.      747 CONTINUE
00773 497.      47 CONTINUE
00775 498.      43 CONTINUE
00776 499.      41 CONTINUE
00778 500.      C
00779 501.      C      SET UP XMIN, XMAX, YMIN, AND YMAX
01000 502.      XMIN = X(1,1)
01001 503.      XMAX = X(1,1)
01002 504.      YMIN = Y(1,1)
01003 505.      YMAX = Y(1,1)
01003 506.      C
01003 507.      C      FIND THE MINIMA AND MAXIMA OF THE X- AND Y-ARRAYS
01004 508.      NTM3 = NTM1 - NCURVE
01005 509.      DO 80 K2=1,NCURVE
01010 510.      NMPTS = NMPTS(NM3)
01011 511.      NTM3 = NTM3 + 1
01012 512.      DO 80 L2=1,NMPTS
01013 513.      XMIN = AMIN1(XMIN, X(K2,L2))
01014 514.      XMAX = AMAX1(XMAX, X(K2,L2))
01015 515.      YMIN = AMIN1(YMIN, Y(K2,L2))
01020 516.      YMAX = AMAX1(YMAX, Y(K2,L2))
01021 517.      80 CONTINUE
01021 518.      C
01022 519.      XMIN = XMIN * .99
01023 520.      YMIN = YMIN * .99
01024 521.      XMAX = XMAX * 1.01
01025 522.      YMAX = YMAX * 1.01
01030 523.      WRITE (6,14) J3, XMIN, XMAX, YMIN, YMAX
01037 524.      14 FORMAT (//////11HOFOR FRAME ,14.9H, XMIN = ,1PE14.8,9H, XMAX = ,
01037 525.      1      E14.8,9H, YMIN = ,E14.8,9H, YMAX = ,E14.8)
01037 526.      C
01040 527.      IF (NCRID .GT. 0) GO TO 85
01042 528.      IF (NCRID.LT.0 .AND. NCRID.GT.(-3)) GO TO 82
01042 529.      C
01042 530.      C      SCALE X
01043 531.      XSCALE = ABS(XMAX/XMIN)
01044 532.      ISCALE(1) = LIN
01046 533.      IF (XSCALE .GT. 0SCALE) ISCALE(1) = LOG
01050 534.      IF (NCRID .NE. 0) GO TO 83
01052 535.      82 CONTINUE
01052 536.      C
01052 537.      C      SCALE Y
01053 538.      YSCALE = ABS(YMAX/YMIN)
01054 539.      ISCALE(2) = LIN
01055 540.      IF (YSCALE .GT. 0SCALE) ISCALE(2) = LOG
01057 541.      83 CONTINUE
01060 542.      IF (ISCALE(1) .EQ. LOG) GO TO 84
01062 543.      NCRID = 1
01063 544.      IF (ISCALE(2) .EQ. LOG) NCRID = 3
01065 545.      GO TO 81
01066 546.      84 CONTINUE
01067 547.      NCRID = 2

```

AFWL-TR-67-131, Vol IV

```

01070 546.      IF (ISCALE(2) .EQ. LOG) NGRID=4
01072 549.      81 CONTINUE
01073 550.      WRITE (6,1010) NGRID, (ISCALE(1),I=1,2)
01102 551.      1010 FORMAT (33H CODE HAS SCALED GRID.  NGRID IS ,I3, 12M, SCALE WAS ,
01102 552.      1  A3,1M-,A3)
01103 553.      85 CONTINUE
01104 554.      NTM= 1
01105 555.      NTM2= NTM1 - NCURVE
01106 556.      DO 52 JJ4=1,NCURVE
C
01106 557.      IF (OPN(4) .LT. 1) JCHAR=LCHAR(JJ4)
01111 558.      IF (NCURVE.GT.1 .AND. OPN(4).EQ.0) JCHAR=MCHAR(JJ4)
01113 559.      NNPTS= NPTS(NTM2)
01113 560.      DO 53 JJ=1,NNPTS
01116 561.      XX(JJ)= X(JJ4,JJ)
01121 562.      YY(JJ)= Y(JJ4,JJ)
01122 563.      53 CONTINUE
01123 564.      C
01123 565.      CALL SORT(XX,YY,NNPTS)
01125 566.      IF (NTM.EQ.1) WRITE (6,1007)
01126 567.      WHITE (6,19) JCHAR, ICURVE, CCURVE(JJ4)
01131 568.      19 FORMAT (7H CURVE ,A1,12M, ICURVE IS ,A6, 1M-,1PE15.6,21M, X AND Y
01136 569.      1AHRATS ARE )
01137 570.      1007 FORMAT (49H0AHRATS TO BE PLOTTED HAVE BEEN SORTED AS FOLLOWS /)
01140 571.      WHITE (6,1006) (1, XX(1), YY(1), I=1,NNPTS)
01140 572.      1006 FORMAT (316X,15,1X,1PE18.8)
01150 573.      C
01150 574.      PLOT GIVEN SETS, PER CONSTANT.
01150 575.      CALL PLOTV
01150 576.      C
01151 577.      NNCHAR= NCHAR
01152 578.      IF (NCURVE.GT.1 .AND. NCURVE.LT.10 .AND. OPN(4).LT.0) NNCHAR=JJ4
01154 579.      IF (NCURVE.GT.1 .AND. OPN(4).EQ.0) NNCHAR=CHAR(JJ4)
01156 580.      CALL PLOTV(NTM, NGRID, NNCHAR, ICON, NPTS(NTM2), XX, YY, XMIN,
01156 581.      1 XMAX, YMIN, YMAX, XLAB, YLAB, GLAB)
01157 582.      IF (OPN(7) .EQ. 2) GO TO 301
01161 583.      DO 300 L=1,54
01164 584.      LABEL(L)= JBLANK
01165 585.      300 CONTINUE
01167 586.      MCHAR= NNCHAR
01170 587.      IF (NCURVE.GT.1 .AND. NCURVE.LT.10 .AND. OPN(4).LT.0) MCHAR=LCHAR(JJ4)
01172 588.      IF (NCURVE.GT.1 .AND. OPN(4).EQ.0) MCHAR=MCHAR(JJ4)
01174 589.      IF (OPN(7).EQ.0 .OR. OPN(7).EQ.1) GO TO 91
01176 590.      JABEL(JJ4)= MCHAR
01177 591.      GO TO 301
01200 592.      91 CONTINUE
01201 593.      LABEL(JJ4*3-2)= ICURVE
01202 594.      IF (NCURVE .LE. 3) GO TO 302
01204 595.      CALL PRINT(MCHAR, CCURVE(JJ4), LABEL(JJ4*3-1))
01205 596.      IF (NTM .EQ. 1) Y1= YT1
01207 597.      IF (JJ4.LE.6) CALL TSP(X1,Y1,LABEL,100)
01211 598.      IF (JJ4.EQ.7 .OR. JJ4.EQ.13) Y1= Y1 - DELTY1
01213 599.      IF (JJ4.EQ.7 .AND. JJ4.LE.12) CALL TSP(X1,Y1,LABEL(19),100)
01215 600.      IF (JJ4.EQ.13) CALL TSP(X1,Y1,LABEL(37),100)
01217 601.      GO TO 303
01220 602.      302 CONTINUE
01221 603.      CALL RITE(0.02232343, 1.02679, 1.0, 90, 72, 1, LABEL)
01222 604.      303 CONTINUE
01223 605.      301 CONTINUE
01224 606.      NTM= 2
01225 607.      NTM2= NTM2 + 1
01226 608.      52 CONTINUE
01230 609.      X2= OPN(7)
01231 610.      IF (OPN(7).LT.0) CALL BOX(X2,DUM,NCURVE,CCURVE,YY,JCURVE,JABEL)
01233 611.      NFRAME= NFRAME + 1
01234 612.      60 CONTINUE
01236 613.      GO TO 502
C
01236 614.      500 CONTINUE
01237 615.      C
01237 616.      PLOT FINAL FRAME CONTAINING TITLE INFORMATION
01240 617.      CALL ADF
01241 618.      NFRAME= NFRAME + 1
01242 619.      CALL FRAME (0.0, 1.0, 1.0, 0.0)
01243 620.      IF (OPN(7) .EQ. 2) GO TO 63
01243 621.      C
01243 622.      IS PLOT DATA FROM ANDIMX? -YES,NO,-
01245 623.      IF (NAME .EQ. ANDIMX) GO TO 61
01247 624.      CALL TSP(0.2, 0.5, 10, 72)
01250 625.      GO TO 63
01251 626.      61 CONTINUE
01252 627.      DO 62 JJ4=1,5

```


AFWL-TR-67-131, Vol IV

```

01255 627.      YTYPE=      0.56 - FLOAT(J4) * 0.04
01256 628.      CALL TSP( 0.2, YTYPE, IDANDI(1,J4), 72)
01257 629.      62 CONTINUE
01261 630.      CALL TSP(0.42, 0.6, SECRET, 20)
01262 631.      63 CONTINUE
01263 632.      CALL ADF
01264 633.      NFRAME=      NFRAME + 1
01264 634.      C
01264 635.      C      MAKE CALL TO FINISH TO END PLOTTING
01265 636.      CALL FINISH
01266 637.      IFLAG=      2
01266 638.      C
01267 639.      503 CONTINUE
01270 640.      C      WRITE SUCCESSFUL COMPLETION STATEMENT
01270 641.      IF (NAME.EQ.GOLEM) WRITE (6,1006) (VARB(JK),JK=1,LAST1)
01271 642.      1006 FORMAT ('44HISUBROUTINE GRAPH HAS EXECUTED SUCCESSFULLY. / 16H VARB
01277 643.      1 ARRAY WAS / (1P12E10.3))
01300 644.      IF (NAME.NE.GOLEM) WRITE (6,3) (VARB(JK),JK=1,LAST1)
01307 645.      3 FORMAT ('44HISUBROUTINE GRAPH HAS EXECUTED SUCCESSFULLY. / 16H VAR
01307 646.      1U ARRAY WAS // (1P10E12.5))
01310 647.      IF (IN(1).EQ.-2) GO TO 506
01310 648.      C
01312 649.      501 CONTINUE
01313 650.      WRITE (6,17)
01318 651.      WRITE (6,4) ITAPE, NFRAME
01321 652.      WRITE (6,4) ITAPE, NFRAME
01328 653.      4 FORMAT (31H PLOTTING IS COMPLETED ON UNIT , 14, 16H THERE ARE, 15
01328 654.      1 , 88H FRAMES. PLEASE NOTE THIS ON PLOT LABEL, IF THERE IS ONE.)
01328 655.      508 CONTINUE
01327 656.      RETURN
01327 657.      C
01330 658.      506 CONTINUE
01330 659.      C      ZERO-OUT VARB ARRAY BEFORE RETURNING TO MAIN PROGRAM
01331 660.      DO 504 JK=1, LAST1
01334 661.      VARB(JK)=      0.
01335 662.      504 CONTINUE
01337 663.      IFLAG=      1
01340 664.      GO TO 508
01340 665.      C
01340 666.      C      E R R O R   E X I T S
01340 667.      C
01341 668.      494 CONTINUE
01342 669.      WRITE (6,13) OPN(6)
01345 670.      13 FORMAT ('46H1OPN(6) HAS BEEN INPUT INCORRECTLY. OPN(6) = ,14)
01346 671.      GO TO 507
01347 672.      495 CONTINUE
01350 673.      WRITE (6,12) OPN(5)
01353 674.      12 FORMAT ('46H1OPN(5) HAS BEEN INPUT INCORRECTLY. OPN(5) = ,14)
01354 675.      GO TO 507
01355 676.      496 CONTINUE
01356 677.      WRITE (6,9) OPN(3)
01361 678.      9 FORMAT ('46H1OPN(3) HAS BEEN INPUT INCORRECTLY. OPN(3) = ,14)
01362 679.      GO TO 507
01363 680.      497 CONTINUE
01364 681.      WRITE (6,6) OPN(7)
01367 682.      6 FORMAT ('46H1OPN(7) HAS BEEN INPUT INCORRECTLY. OPN(7) = ,14)
01370 683.      GO TO 507
01371 684.      498 CONTINUE
01372 685.      WRITE (6,7) OPN(2)
01375 686.      7 FORMAT ('46H1OPN(2) HAS BEEN INPUT INCORRECTLY. OPN(2) = ,14)
01376 687.      GO TO 507
01377 688.      499 CONTINUE
01400 689.      WRITE (6,8) OPN(1)
01403 690.      8 FORMAT ('46H1OPN(1) HAS BEEN INPUT INCORRECTLY. OPN(1) = ,14)
01404 691.      GO TO 506
01405 692.      507 CONTINUE
01406 693.      CALL MERR
01467 694.      END

```


2. A card in format (12A6), containing title information used as a heading for each frame (may be a blank card)
3. Two cards, each in format 12A6, that specify the appropriate labels for the x- and y-axes, respectively (either one or both cards may be blank)

DESCRIPTION OF INPUT

The IN array controls which variables in the VARB array are to be used for plotting:

1. IN(1) and IN(2) specify variables to be used in the x-array, the array containing abscissas of points to be plotted
2. IN(3) and IN(4) specify variables to be used in the y-array, the array containing the ordinates of points to be plotted

IN(I)	SADY variable	Huebner variable	GOLEM variable
1	TK	TK	THETA (TK)
2	GAMMA		RHO
3	RHO	RHO	P1 (pressure)
4	PRESHR		E (energy)
5	ENERGY		NBAR or CAPAC
6	EION		EIONIZ or CAPAR
7	KROS	TROPA	CV
8	KPLK	CROPA	FEW (ZBAR)
9	ZBAR	CAPNF(ZBAR)	PB1
10	EGAM		ASQ (sound speed)
11			EGAM
12			EGAM2 or GAMMA

The OPN array controls various options used in plotting. OPN(1) determines how to manipulate variables to be set up for the x-array. OPN(2) determines how to manipulate variables to be set up for the y-array.

OPN(I), I=1 or 2 x- or y-array, J=1 or 3 respectively. (Any VARB array variable may be exponentiated or be replaced by its common or natural logarithm before being operated on in one of the following ways.) XIN(L), (L=5, 6), is discussed below.

1	VARB(IN(J))
2	VARB(IN(J)) + XIN(L)
3	VARB(IN(J)) * XIN(L)
4	VARB(IN(J)) + VARB(IN(J+1))
5	(VARB(IN(J)) + VARB(IN(J+1))) + XIN(L)
6	(VARB(IN(J)) + VARB(IN(J+1))) * XIN(L)
7	VARB(IN(J)) - VARB(IN(J+1))
8	(VARB(IN(J)) - VARB(IN(J+1))) + XIN(L)
9	(VARB(IN(J)) - VARB(IN(J+1))) * XIN(L)
10	VARB(IN(J)) * VARB(IN(J+1))
11	(VARB(IN(J)) * VARB(IN(J+1))) + XIN(L)
12	(VARB(IN(J)) * VARB(IN(J+1))) * XIN(L)
13	VARB(IN(J)) / VARB(IN(J+1))
14	(VARB(IN(J)) / VARB(IN(J+1))) + XIN(L)
15	(VARB(IN(J)) / VARB(IN(J+1))) * XIN(L)

OPN(3) determines value of NGRID, the type of grid used for plotting. To get tick marks only (no grid lines), add 4 to value of NGRID necessary to obtain the type of grid wanted, and input that sum for OPN(3). An exception is if NGRID. LE. 0; then subtract 5 to get the code to scale with tick marks.

<u>OPN(3)</u>	<u>x-axis</u>	<u>y-axis</u>
0	Code scales	Code scales
1	Linear	Linear
2	Logarithmic	Linear
3	Linear	Logarithmic
4	Logarithmic	Logarithmic
-1	Linear	Code will scale
-2	Logarithmic	Code will scale
-3	Code scales	Linear
-4	Code scales	Logarithmic

OPN(4) determines value of NCHAR, the decimal code of the character to be plotted. Normal value is 42, a plotting dot. If more than one curve per frame:

1. If (OPN(4).EQ. 0), 'A' for first curve, 'B' for second curve, etc. (maximum of 18 curves per frame)
2. If (OPN(4).LT. 0), '1' for first curve, '2' for second curve, etc. (maximum of 9 curves per frame)

OPN(5) determines the value of ICON, the option for connecting points with a line segment. If (ICON .EQ. 1), connect points. If (ICON .EQ. 2), do not connect points.

OPN(6) controls number of plots per frame. Note that no more than 18 curves may be put on any given frame.

OPN(7) determines whether labels will be printed on plots. If (OPN(7) .EQ. 0), print labels along top of frame and along x- and y-axes (to be read from three input data cards that follow, each in format 12A6, and used to label top of frame, the x-axis, and the y-axis, respectively).

If (OPN(7) .LT. 0), print a summary of all curve labels and values in a box in one corner (-1 for upper left, -2 for upper right, -3 for lower left, -4 for lower right).

If (OPN(7) .EQ. 1), use DIAPHANOUS, DENSER, GOLEM or ANDIMX ID record (read by DYPERS or TRANS) to label top of the graphs, using normal printout (no box).

To use ID record read by TRANS or DYPERS plus a box printout, subtract 4 from value (as specified above) necessary to indicate corner chosen for printing the box.

If (OPN(7) .EQ. 2), do not print on the plots.

OPN(8), OPN(9), OPN(10), and OPN(11) determine whether logarithms (common or natural) are to be taken of (VARB(IN(J)), J=1 to 4), respectively,

before the x- and y-arrays are set up.

- a. Negative OPN(I), I=8, 9, 10, or 11, means use natural log of $(VARB(J)**XIN(J), J=1, 4)$, respectively.
- b. Positive OPN(I), I=8, 9, 10, or 11, means use common log of $(VARB(J)**XIN(J), J=1, 4)$, respectively.

OPN(12)=IPLOTT, used if THETA curves are not being plotted.

Specifies the general cell location of the variable being held constant on each curve (e. g., IPLOTT=2 if gamma curves are being plotted for DIAPHANOUS).

OPN(13) is an input quantity if user wishes code to scale either or both grid axes, using a limiting value different than 100 as a deciding value to plot logarithmically, rather than linearly.

(OPN(J), J=14, 15) free parameters

(XIN(J), J=1, 4) may be used to exponentiate $(VARB(IN(J)), J=1, 4)$, respectively, before the x- and y-arrays are set up. If input as zero, code does not use them.

XIN(5) and XIN(6) are additive or multiplicative constants used to modify VARB array variables chosen for the x- and y-arrays, respectively.

XIN(7) is input if OPN(12), I. E., IPLOTT, is used. Allows user to input a constant value for plotting one curve (e. g., OPN(12)=2, XIN(7)=100., to plot a curve for gamma = 100., in DIAPHANOUS.)

To use the GRAPH subprogram, mount one output (plot) tape on logical unit 16 and specify that it be written with a tape-density of 556 BPI.

GRAPH uses the General Atomic SC-4020 plotting routines discussed in Ref. 12.

TRANS: A PLOTTING PROGRAM ADJUNCT

The TRANS program and its associated subroutines, INPUT, INPUTG, DAR, and ARGE, were coded to read output data cards punched by programs DYPER4 or GOLEM and fill a one-dimensional array of regularly spaced quantities for subroutine GRAPH.

AFWL-TR-67-131, Vol IV

JIT FOR: 1-400/01001
 COMPILE: BY JH:AC 1103 FORTRAN-IV DATED 11 NOV 1966 F4008
 THIS COMPILE: WAS DONE ON 01 NOV 67 AT 14:54:10

```
00101 1. COMMON/CI4/VAR6(5000)
00103 2. COMMON/CI11/ICND(100),VPTS(100),NPTS(100),J2,NAME,GLAB(12)
00104 3. CALL INPUT (GLAB,VARS,NROW,NCOL,NPTS,J2)
00105 4. NEWCOL=NROW
00106 5. NAMES=1
00107 6. NSUM=0
00110 7. DO 10 I=1,J2
00113 8. VPTS(I)=NCOL*NPTS(I)
00114 9. ICND(I)=VPTS(I)*NSUM
00115 10. NSUM=NPTS(I)*NSUM
00117 11. CALL GRAPH
00120 12. CALL EXIT
00121 13. END
```

Input for TRANS

<u>CARD NO.</u>	<u>COLUMNS</u>	<u>FORMAT</u>	<u>VARIABLE NAME</u>	<u>MEANING</u>
1	1-6	A6	Name	If (NAME.EQ.SADY), DIAPHANOUS output data cards (punched by program DYP4) follow. If (NAME.EQ.GOLEM), GOLEM output data cards (punched by program GOLEM) follow
1A	1-72	12A6	(FMT(I), I=1, 12)	If (NAME.EQ.SADY), this card is not used. If (NAME.EQ.GOLEM), specifies the format with which the GOLEM output data cards are to be read
	76	I1	IWRIT1	If (IWRIT1.EQ. 0), no printout If (IWRIT1.EQ. 1), input cards and array as set up for GRAPH will be printed
	79-80	I2	ITEMS	Specifies the number of items to be read from each GOLEM output data card
2	1-72	12A6	(ID(I), I=1, 12)	72 columns of identification information
3, ..., N	Variable	Variable	Variable	Contain the data that are used to fill the array for use by GRAPH
N+1	Variable	Variable	Variable	If the first word on the card is $\leq 0.$, it signifies end of DYP4 or GOLEM output data cards

DENSER: A DIAPHANOUS TAPE COMPRESSOR CODE

The DENSER program was written to pack the data on DIAPHANOUS tapes so that more data could be written onto one tape. It is in FORTRAN IV language.

DENSER can read a number of DIAPHANOUS binary tapes and condense these onto one card-image tape file which can be read on most computers.

The card-image tape is written in even parity at 556 BPI in IBM-compatible

```

PROGRAM DENSER(INPUT,OUTPUT,TAPE10,TAPE9,TAPE5=INPUT,TAPE6=OUTPUT)
C
C DIAPHANOUS EDITOR
C* ALL DENSER RUNS MUST WRITE ON A TAPE IN EVEN PARITY -
C* THIS IS DONE BY SPECIFYING THE K AND E OPTIONS ON THE TAPE ASSIGN CARD
C DAPHNE WAS ORIGINALLY MODIFIED BY L. R. NORRIS TO READ A DIAPHANOUS
C TAPE AND MAKE THIS INTO A CONDENSED TAPE IN ORDER TO SAVE SPACE
C
C VARIABLE NAME MEANING
C
C *** AUGLAS ***
C UELPJ (2000) ENERGY CHANGE DURING A TRANSITION (EV)
C UELPS (1500) IONIZATION POTENTIAL OF A STATE (EV)
C EIN (15) ENERGY OF GROUND STATE OF AN IONIZATION LEVEL
C EPSU (1500) SAME AS EPS IN DIAPHANOUS
C FPC (3, 3, 3) FRACTIONAL PERCENTAGE COEFFICIENT FOR TRANSITION BETWEEN
C SPLI CONFIGURATIONS
C IJU (2000) IDENTIFICATION NUMBER OF INITIAL STATE ASSOCIATED WITH A
C TRANSITION
C ISPLI (15, 40) IDENTIFICATION OF A SPLIT CONFIGURATION
C MERGEU (15, 40) TRUE IF THIS CONFIGURATION IS THE AVERAGE OF SOME OTHER
C CONFIGURATIONS IN THE TABLE
C MJU (2000) NUMBER OF ELECTRONS IN LEVEL FROM WHICH ONE IS REMOVED IN
C THIS TRANSITION
C NFU (1500) SAME AS NF IN DIAPHANOUS
C NJU (2000) PRINCIPAL QUANTUM NUMBER (OR REDUCED QUANTUM NUMBER) OF
C ELECTRON REMOVED IN THIS TRANSITION
C NU (6, 15, 40) NUMBER OF ELECTRONS IN AN ELECTRON LEVEL IN A CONFIGURATION
C NMMAX (15) NUMBER OF CONFIGURATIONS AT AN IONIZATION LEVEL
C NNSAVE (1500) CONFIGURATION IDENTIFICATION OF A STATE
C NSAVE (1500) QUANTUM NUMBER OF OUTER ELECTRON, IF BEYOND TABLE, OF A
C STATE
C QU (1500) SAME AS Q IN DIAPHANOUS
C QW1 (15, 40) DEGENERACY OF A CONFIGURATION
C WU (15, 40) COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
C CONFIGURATION
C W1 (15, 40) COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
C CONFIGURATION
C W2 (15, 40) COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
C CONFIGURATION
C *** DIAPH2 ***
C BE (100) SAME AS BEJ, INDEXED BY (INF + 1) FOR INITIAL STATE
C BEJ (1600) PARAMETER DETERMINING LINE WIDTH FOR A TRANSITION
C C (10) CONCENTRATION OF AN ELEMENT (ATOMS/ATOM)
C COM (12) COMMENT CARD IN FORMAT 12A6
C DELE (100) SUM OF UELI AT PREVIOUS IONIZATION LEVELS (EV)
C UELPJ (2200) ENERGY CHANGE DURING A TRANSITION (EV)
C UELPS (1500) IONIZATION POTENTIAL OF A STATE (EV)
C UELI (100) PRESSURE IONIZATION AT AN IONIZATION LEVEL (EV)
C EPS (1500) ENERGY OF A STATE, USUALLY REFERRED TO THE ENERGY OF THE
C GROUND STATE OF THE NEUTRAL ATOM (EV)
C EPSPRM (1500) ENERGY OF A STATE AFTER REDUCTION DUE TO PRESSURE IONIZA-
C TION (EV)
C EX (100) SAME AS EXJ, INDEXED BY (INF + 1) FOR INITIAL STATE

```


AFWL-TR-67-131, Vol IV

C	EXJ (1600)	PARAMETER DETERMINING LINE LOCATIONS FOR A TRANSITION
C	GAMBLK (10)	ARRAY OF GAMMA
C	IJ (2200)	IDENTIFICATION NUMBER OF INITIAL STATE ASSOCIATED WITH A TRANSITION
C	MAKEZ (1500)	IDENTIFICATION OF STATE TO BE ELIMINATED
C	MJ (2200)	NUMBER OF ELECTRONS IN LEVEL FROM WHICH ONE IS REMOVED IN THIS TRANSITION
C	NEW (2200)	ORIGINAL IDENTIFICATION NUMBER OF A TRANSITION
C	NF (1500)	NUMBER OF FREE ELECTRONS FOR A STATE
C	NJ (2200)	TOTAL QUANTUM NUMBER (OR REDUCED QUANTUM NUMBER) OF ELECTRON REMOVED DURING A TRANSITION
C	NLAST (10)	INDEX NUMBER OF LAST STATE IN TABLE FOR AN ELEMENT
C	PHI (2200)	STRENGTH OF EDGE DUE TO THIS TRANSITION
C	Q (1500)	DEGENERACY OF A STATE
C	R (1500)	FIRST PROPORTIONAL TO LOG POPULATION AND THEN TO POPULATION OF A STATE
C	RS (10)	FIRST MAXIMUM R, THEN SUM OF R'S, FOR AN ELEMENT
C	SMALLP (1500)	POPULATION OF A STATE
C	TESTJ (2200)	LOWEST VALUE OF MU AT WHICH THE ABSORPTION COEFFICIENT IS AFFECTED BY THE LINE SERIES FOR THIS TRANSITION
C	TKBLK (10)	ARRAY OF KT
C	U (5)	COEFFICIENTS IN GAUSSIAN INTEGRATION
C	R (5)	COEFFICIENTS IN GAUSSIAN INTEGRATION
C	UOLD (2200)	LOCATION OF EDGE DUE TO THIS TRANSITION (EV/EV)
C	UPRM (2200)	LOWEST EDGE TO APPROXIMATE HIGH LINES (EV/EV)
C	W (10)	ATOMIC WEIGHT OF AN ELEMENT
C	Z (10)	ATOMIC NUMBER OF AN ELEMENT
C	*** DIAPER ***	
C	AMU (1000)	ABSORPTION COEFFICIENT AT A PARTICULAR VALUE OF MU(0.6 .LE. MU .LE. 15) (PER CM)
C	BMU (1000)	BOTTOM OF EDGE OCCURRING AT A PARTICULAR VALUE OF MU(MU .GT. 15)(PER CM)
C	ID (12)	COMMENT CARD
C	IMU (1000)	TOP OF EDGE OCCURRING AT A PARTICULAR VALUE OF U (U>15) (PER CM)
C	*** SPECTRA ***	
C	DEPECT (100, 4)	QUANTUM DEFECT INDEXED BY THE IONIZATION LEVEL AND L + 1
C	DELEPJ (3500)	SAME AS DELEPJ IN DIAPHANOUS
C	EPSU (1750)	SAME AS EPS IN DIAPHANOUS
C	DELEPS (1750)	SAME AS DELEPS IN DIAPHANOUS
C	IJU (3500)	SAME AS IJ IN DIAPHANOUS
C	IONZC (100)	ZCONE FOR AN IONIZATION LEVEL
C	L (19)	L FOR AN ELECTRON LEVEL
C	LIN (10)	LEVEL AT WHICH AN ELECTRON IS BEING ADDED
C	LOU (10)	LEVEL AT WHICH AN ELECTRON IS BEING REMOVED
C	MJU (3500)	SAME AS MJ IN DIAPHANOUS
C	N (19)	N FOR AN ELECTRON LEVEL
C	NE (92, 19)	NUMBER OF ELECTRONS PER ELECTRON LEVEL IN THE GROUND STATE OF AN IONIZATION LEVEL
C	NFU (1750)	SAME AS NF IN DIAPHANOUS
C	NJU (3500)	SAME AS NJ IN DIAPHANOUS
C	QU (1750)	SAME AS Q IN DIAPHANOUS
C		
	REAL LONG	
	REAL LENGTH	

AFWL-TR-67-131, Vol IV

```

      INTEGER NEWID, BLANK
      INTEGER DASA
      INTEGER GA
      DIMENSION NEWID(12)
      DIMENSION ID(12), A(20), B(2), U1(150), GAMT(150), AMU(150),
1      DAVE (150), DUMMY(50)
      DIMENSION THETA(5000), XGAMMA(5000), RHO(5000)
      DIMENSION U2(1500), BMU(1500), IMU(1500), COMP(10), IZ(10)
      DATA DENSEK/ 6MDENSEK /
      DATA INDEXA / 1/
      DATA LKN / 1 / , DUMMY / 50*0. /
      DATA IFILE1 / 0 / , BLANK / 6M      /

C
      MOUT = 10
1      CONTINUE

C
C      MENU      IF (MENU .EQ. 0) ANOTHER SADDY TAPE IS READ
C                IF (MENU .NE. 0) THE RUN TERMINATES
C      IFILE      IF (IFILE .NE. 0) NO END OF FILE MARKER IS PUT ON AFTER
C                THIS DIAPHANOUS TAPE HAS BEEN READ
C                IF (IFILE .EQ. 0) AN END OF FILE MARKER IS PUT ON AFTER
C                THIS TAPE HAS BEEN READ
C      IWRIT      IF (IWRIT .NE. 0) THE DIAPHANOUS INPUT TAPE IS EDITED
C                IF (IWRIT .EQ. 0) THE DIAPHANOUS INPUT TAPE IS NOT EDITED

C
C      MIN        IS THE INPUT TAPE UNIT. MIN MUST BE READ FOR EVERY
C                INPUT TAPE TO BE READ

C
C      ALL DENSEK TAPES MUST BE WRITTEN IN 556 BPI -
C      THIS IS ACCOMPLISHED BY SPECIFYING THE M OPTION ON THE TAPE
C      ASSIGNMENT CARD
C
      READ (5,8001) MIN, MENU, IFILE, IWRIT, TK, GAM
8001  FORMAT (4I2, 2E15.8)
      IF (MIN .EQ. 0) MIN=15
      READ (5,8000) NZ, (IZ(K), COMP(K), K=1,NZ)
8000  FORMAT (I2, 8X 6(I2, 2X, F6.4), / 4(I2, 2X, F6.4) )
      IF ((NZ .LT. 1) .OR. (NZ .GT. 10)) CALL MERR
      WRITE (6,8003) MIN, MENU, IFILE, IWRIT
8003  FORMAT (1H0,7H MIN = ,14,8H MENU = ,14,9H IFILE = ,14,9H IWRIT = ,
114)
      WRITE (6,8004) NZ, (I,COMP(I),IZ(I),I=1,NZ)
8004  FORMAT (1H0, 5H NZ = , 12, / (1H ,12,2X,F6.4,2X,12/))
      READ (5,8005) (NEWID(I),I=1,12)
8005  FORMAT (12A6)
      IF (NEWID(1) .NE. BLANK) WRITE (6,8006) (NEWID(I),I=1,12)
8006  FORMAT (1H0, 12A6)
      NEWIND MIN
      INCU = 0
      NMCU = 0
      IUMU2 = 1500

C
      IF (IWRIT .NE. 0)

```

AFWL-TR-67-131, Vol IV

```

1WRITE (6,9990)
HEAD(MIN) A(1)
WRITE (6,9995) A(1)
IF (A(1))25,999,999
25 IF (A(1)+1.) 999,2500,999
2500 CONTINUE
NMCD = NMCD + 1
HEAD (MIN) (ID(1),I=1,12)
WRITE (6,9999) (ID(K),K=1,12)
IF (NEWIU(1) .EQ. BLANK) GO TO 27
DO 26 I=1,12
IU(I) = NEWIU(I)
26 CONTINUE
27 CONTINUE
IF (IFILE1 .NE. 0) GO TO 26
WRITE (MOU1,3) DENSEN, (ID(K),K=1,12), NZ, (COMP(K),IZ(K),K=1,NZ)
3 FORMAT (13A6/I2,(F6.4,I2))
INCD = INCD + 2
26 CONTINUE
NMCD = NMCD + 1
HEAD(MIN) A(1)
IF (IWRITE .NE. 0)
1WRITE (6,9995) A(1)
IF (A(1)+2.) 999,3002,999
3002 CONTINUE
NMCD = NMCD + 1
32 HEAD (MIN) (B(1),I=1,2)
IF ((IK .GT. B(1)) GO TO 7000
IF (GAM .GT. B(2)) GO TO 7000
WRITE (6,9998) (B(J),J=1,2)
IF (IWRITE.EQ.0) WRITE (6,9995) A(1)
THETA (INDEXA)=B(1)
XGAMMA(INDEXA)=B(2)
7000 CONTINUE
J = 2
M = 6
ULAST1 = 0.
ALAST1 = 0.
UZ(J) = 0.
WANT(1) = 0.
DAVE(1) = 0.
THETA = B(1)
GAMMA = B(2)
IF ((IK .LE. B(1)) .AND. (GAM .LE. B(2)))
2NMCD = NMCD + 1
34 HEAD(MIN) A(1), A(2)
IF ((A(1) .LT. 0.) .AND. ((IK .LE. B(1)) .AND. (GAM .LE. B(2))))
1WRITE (6,9995) A(1)
UX = A(1)
UY = A(2)
IF ((IK .LE. B(1)) .AND. (GAM .LE. B(2)))
2NMCD = NMCD + 1
IF (UX + 3.) 35,65,35
35 IF (UX + 4.) 40,75,40
40 IF (UX + 6.) 55,45,55

```

AFWL-TR-67-131, Vol IV

```

45 HEAD(MIN) A(1), A(2)
   IF (IWKIT .NE. U)
   1WRITE (6,Y000) A(1),A(2)
   U1(M) = A(1)
   AMU(M) = A(2)
   M = M+1
   UX = A(1)
   UY = A(2)
   IF ((IK .LE. B(1)) .AND. (GAM .LE. B(2)))
   2NHCU = NHCU + 1
   IF(UX .LE. 0.) GO TO 4500
   ULAST = UX
   ULAST1 = UX
   ALAST1 = UY
   AKLAST = UY
   GO TO 34
4500 WRITE(6,Y000) UX, UY
   REWIND MIN
   CALL EX11
55 U1(M) = UX
   AMU(M) = UY
   M = M+1
   GO TO 34
65 HEAD(MIN) A(1), A(2), A(3)
   UX = A(1)
   UY = A(2)
   UZ = A(3)
   IF ((IK .LE. B(1)) .AND. (GAM .LE. B(2)))
   2NHCU = NHCU + 1
   IF(UX + 4.) 70,74,70
70 U2(J) = UX
   BMU(J) = UY
   TMU(J) = UZ
   J = J+1
   IF(J-IDMU2) 65,65,72
72 WRITE(6,15) IDMU2, THE1A, GAMMA, U2(J-1)
73 HEAD(MIN) A(1), A(2), A(3)
   UX = A(1)
   UY = A(2)
   UZ = A(3)
   IF ((IK .LE. B(1)) .AND. (GAM .LE. B(2)))
   2NHCU = NHCU + 1
   IF(UX + 4.) 73,74,73
74 ULAST=U2(J-1)
   AKLAST=TMU(J-1)
75 CONTINUE
   M = M - 1
   IF (IK .GT. B(1)) GO TO 7001
   IF (GAM .GT. B(2)) GO TO 7001
   IF (IWKIT .NE. U)
   1WRITE (6,Y980) (U1(K),K=6,M)
   IF(GARY(1) .NE. U.) WRITE(6,Y002) GARY
   IF (IWRIT .NE. U)
   1WRITE (6,Y982) (AMU(K),K=6,M)
   IF(DAVE(1) .NE. U.) WRITE(6,Y002) DAVE

```

AFWL-TR-67-131, Vol IV

```

IF (DAVE(1) .NE. 0.) CALL MEHR
HEAD(MIN) (A(JM), JM=1,8)
WRITE (6,9997) (A(JM),JM=1,8)
WRITE (6,4)
4 FORMAT (1M)
IF (U2(2) .EQ. 0.) GO TO 76
J = J - 1
IF (IWKIT .EQ. 0) GO TO 76
WRITE (6,9984) (U2(K),K=2,J)
WRITE (6,9986) (BMU(K),K=2,J)
WRITE (6,9988) (TMU(K),K=2,J)
76 CONTINUE
NMU(INDEXA)=A(2)
INDEXA=INDEXA+1
WRITE (MOUT,2) J, M, ULAST1, ALAST1, B(1), B(2), (A(JM),JM=1,20),
1 (U1(K),K=6,M), (AMU(K),K=6,M), (U2(K),K=2,J),
2 (BMU(K),K=2,J), (TMU(K),K=2,J)
NMCD = NMCD + 1
INCD1 = 11 + 2 * (M - 5) + 3 * (J - 1)
INCD2 = INCD1 / 14
INCD14 = INCD2 * 14
IF (INCD1 .GT. INCD14) INCD2 = INCD2 + 1
INCD = INCD + 1 + INCD2
7001 CONTINUE
HEAD (MIN) A(1)
IF (IWKIT.NE.0) WRITE (6,9996) A(1)
UX = A(1)
IF ((IK .LE. B(1)) .AND. (IAM .LE. B(2)))
2NMCD = NMCD + 1
IF (UX + 2.) 77,32,999
77 IF (UX + 5.) 999,155,999
155 CONTINUE
IF (IWKIT.EQ.0) WRITE (6,9995) A(1)
C
NMCD = NMCD + 1
C THE ABOVE RECORD COUNT INCLUDES THE EOF RECORD
IFILE1 = IFILE
LONG = FLOAT(NMCD) * .0625
LENGTH = FLOAT(INCD) * .0658
WRITE (6,8007) LONG, NMCD, LENGTH, INCD
CALL NEW1(MIN)
IF (IFILE .NE. 0) GO TO 1
I = -5
WRITE (MOUT,2) I, LKN, DUMMY
INCD = INCD + 2
8007 FORMAT (58H)THE DIAPHANOUS TAPE HAS BEEN CONDENSED SUCCESSFULLY FM
10M , F10.2,10M FEET WITH, 16, 21M PHYSICAL RECORDS TO F9.2,10MUP
2EE1 WITH,15,18M PHYSICAL RECORDS.)
ENDFILE MOUT
IF (MENU .EQ. 0) GO TO 1
NEWIND MOUT
INDEXA=INDEXA-1
WRITE(6,9001) (THETA(K),XGAMMA(K),RHO(K),K=1,INDEXA)
9001 FORMAT(1M,8X,
1 6HTHETA ,9X, 6HVGAMMA ,11X,4HRHO ,/(3(3X,1PE12.5)))

```

AFWL-TR-67-131, Vol IV

```

CALL EXIT
9999 CONTINUE
WRITE (6,99901)
99901 FORMAT (53H THERE IS AN ERROR IN THIS RUN. MERR HAS BEEN CALLED.)
CALL MERR
C
C ***** F O R M A T S *****
15 FORMAT (42H 2ND SET OF DIAPHRANOUS DATA HAS MORE THAN 13, 19H ENTH
21ES. THETA = F/2, BM, GAMMA=1PE10.5, 20H, NO GOOD ABOVE U = UPF6.
31)
9900 FORMAT(9H0 ULAST = 1PE15.7, 3X 8HAKLAST = E15.7)
9902 FORMAT(1P10E12.5)
9980 FORMAT(10H0 U1 AKKAY // (1P10E12.5))
9982 FORMAT(11H0 AMU AKKAY // (1P10E12.5))
9984 FORMAT(10H0 U2 AKKAY // (1P10E12.5))
9986 FORMAT(11H0 BMU AKKAY // (1P10E12.5))
9988 FORMAT(11H0 TMU AKKAY // (1P10E12.5))
9990 FORMAT(1H1)
2 FORMAT (214, 15E9.4, / (14E9.4))
9995 FORMAT(10H SIGNAL = F6.1)
9996 FORMAT(10H1 SIGNAL = F6.1)
9997 FORMAT(6H ZBAR=F6.4, 1X 4HMH0=1PE11.5, 2X 2HP=E11.5, 2X 2HE=E11.5,
1 2X 5HMKOS=E11.5, 2X 6HMKPLNK=E11.5, 2X 5HEIUN=E11.5, 2X 5HEGAM=
2UPF4.5)
9998 FORMAT(9H0 THETA = 1PE15.7, 3X 7HGAMMA = E15.7)
9999 FORMAT(1H0, 12A6)
END

```

format. The data from each separate set of DIAPHANOUS input tapes are written onto one file on the output tape. The condensed tape may contain several files, each of which corresponds to some chosen set of DIAPHANOUS tapes.

DENSER reads the DIAPHANOUS tape, under control of the variables TK and GAM (see below), the tape consisting of very short binary records, and stores the data into arrays. These arrays are written onto the output tape in 14 word records. Either the identification record from the DIAPHANOUS tape, or a new identification record, plus a material composition record is written as the first two records of every file on the DENSER output tape. All of the data at a given temperature-gamma point on a DIAPHANOUS tape are preserved in the condensation. The DENSER identification record need not be the same as the identification record that was on the DIAPHANOUS tape.

The output records made by DENSER must incorporate the information that DIAPHANOUS tapes formerly conveyed by signals. The possible situations at a given temperature-gamma point are:

1. The DIAPHANOUS tape had both extrapolated data (before $u = \frac{h\nu}{KT} = 15$) and edge data (i. e., both (-6.) and (-3.) signals were present).
2. The DIAPHANOUS tape had extrapolated data but no edge data (i. e., (-6.), but not a (-3.), signal was present).
3. The DIAPHANOUS tape had edge data but no extrapolated data (a (-3.), but not a (-6.), signal was present).
4. Neither extrapolated nor edge data were present (neither a (-6.) nor a (-3.) signal was present).

In the DENSER program, ULAST1, ALAST1, and U2(2) are all set to zero at the beginning of the processing done for each temperature-gamma point. If they are still zero when the DENSER output record is written, we have case (4). If a (-6.) signal is encountered on the DIAPHANOUS tape, then ULAST1 and ALAST1 are modified to specify the values of $h\nu/KT$ and

the absorption coefficient at the place where extrapolation began. If no (-3.) signal is encountered, U2(2) is still set to zero, and case (2) has been specified. If edge data are present U2(2) is modified to specify the location of the first edge. If a (-6.) had previously been encountered, then U2(2), ULAST1, and ALAST1 are nonzero and we have case (4). If no extrapolation has been performed, and edge data were present, we have case (3) with U2(2) \neq 0., but ULAST1=ALAST1-0.

The DENSER program contains two write statements. They, and their respective formats, are:

```
WRITE (10,3) DENSER, (ID(K), K=1,12), NZ, (COMP(K), IZ(K), K=1,NZ)
3 FORMAT (13A6/I2, (F6.4,I2))
```

The above write statement is used once to write identification data at the beginning of each file on the DENSER tape. The named variables are discussed below or are clear from context.

```
WRITE (10,2) J,M, ULAST1, ALAST1, B(1),B(2), (A(JM), JM=1,20),
(U1(K), K=6,M), (AMU(K), K=6,M), (U2(K), K=2,J), (BMU(K)K=2,J),
(TMU(K), K=2,J)
2 FORMAT (2I4,13E9.4, /(14E9.4))
```

The above write statement is used to write the data at each temperature and density point.

The length of the input DIAPHANOUS tapes and the length of each file on the DENSER output tape are computed after each file is completed. These values will help the user determine how many files can be written on a DENSER tape.

One may edit the input DIAPHANOUS tape, if desired, in the same manner as in present use. (DENSER is an adaptation of the DAPHNE code, which is able to edit DIAPHANOUS tapes.) A program was also coded to edit the files on the new condensed DIAPHANOUS tape, and this new program, DASE, can be used as a subroutine of DENSER to edit each file as it is written. DASE is in FORTRAN IV language. (Refer to separate writeup.)

Input for DENSER

CARD NO.	INPUT VARIABLE	COLUMNS	FORMAT
1	MIN	1-2	I2
	MEND	3-4	I2
	IFILE	5-6	I2
	IWRIT	7-8	I2
	TK	9-23	E15.8
	GAM	24-38	E15.8
2	NZ	1-2	I2
	IZ(1)	11-12	I2
	COMP(1)	15-20	F6.4
	IZ(2)	21-22	I2
	COMP(2)	25-30	F6.4
	up to 10	etc.	
3	NEWID	1-72	12A6

These three data cards must be repeated for each DIAPHANOUS input tape.

Card 3 needs to contain the above data only when the input tape is the first tape used to create a given file. (For subsequent tapes used to continue this file, it can be a blank card.)

MIN	The unit on which the input tape is mounted. If MIN = 0, MIN is set to 15 in the program
MEND	If MEND \neq 0, the program terminates after this set of input cards is processed; otherwise the program goes back to read the next set of input cards
IFILE	If IFILE \neq 0, no end-of-file is written at the end of the data read from this input tape; otherwise, an end-of-file is written
IWRIT	If IWRIT \neq 0, the DIAPHANOUS tape is edited in the fashion of DAPHNE; otherwise, only a limited printout is allowed
NZ	The number of elements in the material whose data are on the input DIAPHANOUS tape; $1 \leq NZ \leq 10$

IZ	The array of atomic numbers of the elements in the material on the input DIAPHANOUS tape. NZ atomic numbers are written on the DENSER tape
COMP	The array of number fractions corresponding to the elements in the IZ array. NZ number fractions are written on the DENSER tape
NEWID	An array of 12 alphanumeric words that allow a new title to be written on the DENSER tape. If this card is blank, the ID array from the SADY tape will be used as a title on the DENSER tape

To use the DENSER program, the following tapes must be mounted:

1. The input tapes are DIAPHANOUS tapes and may be mounted on any unit except unit 10
2. The output tape must be mounted on unit 10

TK, GAM If both TK and GAM are nonzero, the DIAPHANOUS input tape is spaced to the data at this temperature-gamma point. Writing on the DENSER tape then starts with the data at this point. GAM is the electronic degeneracy factor and is $\Gamma \approx [(0.01)(A)\theta^{3/2}]/(\rho\bar{Z})$, where A is the mean atomic weight, θ is the temperature in eV, ρ is the density in gm/cc, and \bar{Z} is the mean ionization (Ref. 2). If TK is zero, the DIAPHANOUS tape is not spaced.

If GAM is zero, the DIAPHANOUS tape is spaced to the first Γ point at which the temperature is TK.

DASE: AN EDITING CODE FOR DENSER-PRODUCED TAPES

DASE has been coded in FORTRAN IV language to edit a tape file from a multifile card-image DENSER tape. Each tape file of a DENSER tape is a condensation of a set of DIAPHANOUS tapes for a certain material. (Refer to the DENSER code writeup.)

DASE edits either the complete file or that part of the file from the beginning of a specified temperature set to the end of the file. DASE also has the ability to space a preliminary DENSER tape file to a specified temperature-gamma data set.

```

PROGRAM DASE(INPUT,OUTPUT,TAPE10,TAPE5=INPUT,TAPE6=OUTPUT)

C
C   THIS PROGRAM WAS WRITTEN BY L. H. MORRIS
C   THIS ROUTINE WILL EDIT A COMPRESSED DIAPHANOUS TAPE
C   IN THIS PROGRAM TKIN AND GAMIN SPECIFY THE TEMPERATURE AND GAMMA
C   AFTER WHICH THE TAPE IS SPACED TO
C   IWRITE SPECIFIES THE TEMPERATURE AT WHICH THE PROGRAM STARTS WRITING
C   VALUES FROM THE DENSEN TAPE ONTO THE OUTPUT FILE
C   WHEN THE LAST TKIN AND GAMMA=GAMIN ARE FOUND, LRN IS RESET FROM ZERO
C   TO ONE
C   ISPACO IS NOT USED BY THIS CODE
C   ISPACO IS IN THIS CODE TO MAINTAIN COMPATIBILITY WITH DAPHNE INPUT
C
  DIMENSION DZ(1500), BMU(1500), TMU(1500)
  DIMENSION ID(12),IZ(10), A(20), U(150), AMU(150), COMP(10)
  INTEGER DENSEN
  DATA DENSEN / DMUENSEN /,EPS /1.E-6/, ISPACO/0/

C
C   FORMATS
1001 FORMAT (1H0, A6,3X,12A6)
1002 FORMAT (1H0, 5HNZ = , 12, / (1H , 12,2X,F6.4,2X,12//)
1003 FORMAT (1H1THEIA = ,1PE9.4, 3X,DMGAMMA = ,1PE9.4)
1004 FORMAT (15H0TRANSITIONS WERE EXHAUSTED A) / 1H , 5H U = , 1PE9.4,
1       1H AND MU = , 1PE9.4)
1005 FORMAT (15H0U VALUES // (1H , 10(1X,1PE9.4,2X)))
1006 FORMAT (15H0MU VALUES // (1H , 10(1X,1PE9.4,2X)))
1007 FORMAT (15H0U VALUES // (1H , 10(1X,1PE9.4,2X)))
1008 FORMAT (15H0MU VALUES AT THE TOP OF THE EDGE // (1H , 10(1X,1PE9.4,
1       12X)))
1009 FORMAT (15H0MU VALUES AT THE BOTTOM OF THE EDGE // (1H , 10(1X,1PE9.
1       14,2X)))
1010 FORMAT (15H0EDGE DATA FOLLOWS)
1012 FORMAT (15H0ZBAN = ,F6.4,7H NHO = ,1PE9.4,5H P = ,1PE9.4,
1       5H E = ,1PE9.4,5H KNUZ = ,1PE9.4,5H KPLNK = ,1PE9.4,
2       15H EIPAKI = ,1PE9.4,5H EIAM = ,UPF6.3,/(1P6E15.8) )
1020 FORMAT (214, 13E9.4, / (14E9.4))
1019 FORMAT (13A6/12, (F6.4,12))

C
  NEW = 10
C   THIS PROGRAM DOES NOT REWIND THE DENSEN TAPE BEFORE READING
C   SO THAT THE NTH FILE ON A DENSEN TAPE MAY BE EDITED BY DASE
C   SUCH REWINDING MUST BE DONE BEFORE EXECUTING DASE
  WHILE (6,7001)
7001 FORMAT (1H1,36H BCU-COMPRESSED DIAPHANOUS EDIT RUN //)
  READ(5,9007) TKIN, GAMIN, IWRITE, ISPACO
9007 FORMAT (3F10.8,12)
  WRITE(6,9970) TKIN, GAMIN, IWRITE, ISPACO
9970 FORMAT (25H THE INPUT TEMPERATURE = ,1PE15.8,/,
1       15H THE INPUT GAMMA = ,1PE15.8,/,
2       11H IWRITE = ,1PE15.8,10H ISPACO = ,13)
  DATA LRN / 0 /, NMCU / 0 /, IFLAG/ 0 /

C
10 CONTINUE

```

AFWL-TR-67-131. Vol IV

```

      HEAD (NEW,1019) IUX, (IU(I),I=1,12), NZ, (COMP(K),I=1,NZ)
      IF (IUX .NE. DENSEN) CALL MENH
      WRITE (6,1001) IUX, (IU(I),I=1,12)
      WRITE (6,1002) NZ, (1,COMP(1),I=1,NZ)
C
20 CONTINUE
      HEAD (NEW,1020) J, M, ULAST, AKLAST, THEIA, GAMMA, (A(K),K=1,20),
      1 (U1(I),I=6,M), (AMU(I),I=6,M), (U2(I),I=2,J),
      2 (BMU(I),I=2,J), (IMU(I),I=2,J)
      IF (J .EQ. (-5)) GO TO 100
      NMCD = NMCD + 1
      IF (ABS((IKIN-THEIA)/THEIA).LT.EPS) GO TO 3000
      GO TO 3001
3000 CONTINUE
      IF (ABS((GAMIN-GAMMA)/GAMMA).LT.EPS) LNN=1
3001 CONTINUE
      IF (IWRITE .LE. U.) IFLAG=1
      IF (ABS((IWRITE-THEIA)/THEIA).LT.EPS) IFLAG=1
      IF (IFLAG.NE.1) GO TO 3002
      WRITE (6,1003) IMETA, GAMMA
      IF (ULAST .NE. U.) WRITE (6,1004) ULAST, AKLAST
C
      WRITE TRANSITION DATA
C
      WRITE (6,1005) (U1(I),I=6,M)
      IF ((M .GT. 150) .OR. (J .GT. 500)) CALL MENH
      WRITE (6,1006) (AMU(I),I=6,M)
C
      WRITE EDGE DATA: IF ANY EXIST
C
      IF (U2(2) .EQ. U.) GO TO 30
      WRITE (6,1007) (U2(I),I=2,J)
      WRITE (6,1008) (BMU(I),I=2,J)
      WRITE (6,1009) (IMU(I),I=2,J)
30 CONTINUE
      WRITE (6,1012) (A(K),K=1,20)
3002 CONTINUE
      IF (LNN.NE.1) GO TO 20
      WRITE (6,9991) IMETA, GAMMA
9991 FORMAT(61H)THE DENSEN DIAPHANOUS TAPE HAS BEEN SPACED TO AFTER THE
      1TA = , F10.4, 5X, 8H GAMMA = , F10.4)
C
100 CONTINUE
      WRITE (6,1011) NMCD
1011 FORMAT (39H)THIS TAPE HAS BEEN EDITED SUCCESSFULLY./
      1 11H THERE ARE ,I5, 24H THETA, GAMMA DATA SETS.)
      RETURN
      END

```

This feature of the program is useful when a DENSER tape file is not completed in a given DENSER run or when more data are to be added to the file at a later time.

Input for DASE

CARD NO.	INPUT VARIABLE	COLUMNS	FORMAT
1	TKIN	1-10	F10.8
	GAMIN	11-20	F10.8
	TWRITE	21-30	F10.8
	ISPAC0	31-32	I2
TKIN	The temperature to which the tape is spaced. If TKIN is blank, the tape is not spaced. TKIN is in eV		
GAMIN	The Γ to which the tape is spaced; if GAMIN is blank, the tape is not spaced. GAMIN is the "dimensionless electron degeneracy factor" (Ref. 2). Both GAMIN and TKIN must be specified to space the tape		
TWRITE	The temperature on the tape at which editing is begun. If $TWRITE \leq 0$, then the entire tape is edited		
ISPAC0	Not used. (This variable was used in the DAPHNE program, which can edit the original DIAPHANOUS tape. DAPHNE input cards can also be used by DASE.)		

To use the DASE program, the DENSER tape must be mounted on unit 10. DENSER tapes are written in event parity and at 556 BPI (bits per inch).

DAPHNE: A DIAPHANOUS TAPE-EDIT CODE

DAPHNE reads the DIAPHANOUS tape (Ref. 3), which contains very short binary records, and stores the data into arrays. DAPHNE then prints out these arrays in a suitable format. DAPHNE edits either the complete tape or that part of the tape from the beginning of a specific temperature set through the end of the data on the tape. DAPHNE also has the capability of spacing a DIAPHANOUS tape to the end of a specified temperature-gamma (Ref. 2) data set and putting an end-of-file mark on the tape, or of terminating

AFWL-TR-67-131, Vol IV

```

PROGRAM UAPHNE(INPUT,OUTPUT,TAPE15,TAPE5=INPUT,TAPE6=OUTPUT)

C
C   UAPHANOUS EUIION
C
C   VARIABLE NAME   MEANING
C
C   *** AUGLAS ***
C   ULEPJ (2000)    ENERGY CHANGE DURING A TRANSITION (EV)
C   ULEPS (1500)    IONIZATION POTENTIAL OF A STATE (EV)
C   EIN (15)        ENERGY OF GROUND STATE OF AN IONIZATION LEVEL
C   EPSJ (1500)     SAME AS EPS IN UAPHANOUS
C   FPC (3, 3, 3)   FRACTIONAL PERCENTAGE COEFFICIENT FOR TRANSITION BETWEEN
C                   SPLIT CONFIGURATIONS
C   IJU (2000)      IDENTIFICATION NUMBER OF INITIAL STATE ASSOCIATED WITH A
C                   TRANSITION
C   ISPLIT (15, 40) IDENTIFICATION OF A SPLIT CONFIGURATION
C   MERGED (15, 40) TRUE IF THIS CONFIGURATION IS THE AVERAGE OF SOME OTHER
C                   CONFIGURATIONS IN THE TABLE
C   MJU (2000)      NUMBER OF ELECTRONS IN LEVEL FROM WHICH ONE IS REMOVED IN
C                   THIS TRANSITION
C   NFU (1500)      SAME AS NF IN UAPHANOUS
C   NJU (2000)      PRINCIPAL QUANTUM NUMBER (OR REDUCED QUANTUM NUMBER) OF
C                   ELECTRON REMOVED IN THIS TRANSITION.
C   NG (6, 15, 40) NUMBER OF ELECTRONS IN AN ELECTRON LEVEL IN A CONFIGURATION
C   NMMAX (15)      NUMBER OF CONFIGURATIONS AT AN IONIZATION LEVEL
C   NMSAVE (1500)   CONFIGURATION IDENTIFICATION OF A STATE
C   NSAVE (1500)    QUANTUM NUMBER OF OUTER ELECTRON, IF BEYOND TABLE, OF A
C                   STATE
C   QU (1500)       SAME AS Q IN UAPHANOUS
C   QW1 (15, 40)    DEGENERACY OF A CONFIGURATION
C   WU (15, 40)     COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
C                   CONFIGURATION
C   W1 (15, 40)     COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
C                   CONFIGURATION
C   W2 (15, 40)     COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS
C                   CONFIGURATION
C   *** DIAPHZ ***
C   BE (100)        SAME AS BEJ, INDEXED BY (IN + 1) FOR INITIAL STATE
C   BEJ (1500)      PARAMETER DETERMINING LINE WIDTH FOR A TRANSITION
C   C (10)          CONCENTRATION OF AN ELEMENT (ATOMS/ATOM)
C   COM (12)        COMMENT CARU IN FORMAT 12A6
C   UELE (100)      SUM OF UEL1 AT PREVIOUS IONIZATION LEVELS (EV)
C   ULEPJ (2200)    ENERGY CHANGE DURING A TRANSITION (EV)
C   ULEPS (1500)    IONIZATION POTENTIAL OF A STATE (EV)
C   UEL1 (100)      PRESSURE IONIZATION AT AN IONIZATION LEVEL (EV)
C   EPS (1500)      ENERGY OF A STATE, USUALLY REFERRED TO THE ENERGY OF THE
C                   GROUND STATE OF THE NEUTRAL ATOM (EV)
C   EPSPHM (1500)   ENERGY OF A STATE AFTER REDUCTION DUE TO PRESSURE IONIZA-
C                   TION (EV)
C   EX (100)        SAME AS EXJ, INDEXED BY (IN + 1) FOR INITIAL STATE
C   EXJ (1500)      PARAMETER DETERMINING LINE LOCATIONS FOR A TRANSITION
C   GAMMA (10)      ARRAT OF GAMMA
C   IJ (2200)       IDENTIFICATION NUMBER OF INITIAL STATE ASSOCIATED WITH A
C                   TRANSITION

```

AFWL-TR-67-131, Vol IV

```

C MAKEZ (1500) IDENTIFICATION OF STATE TO BE ELIMINATED
C MJ (2200) NUMBER OF ELECTRONS IN LEVEL FROM WHICH ONE IS REMOVED IN
C THIS TRANSITION
C NEW (2200) ORIGINAL IDENTIFICATION NUMBER OF A TRANSITION
C NF (1500) NUMBER OF FREE ELECTRONS FOR A STATE
C NJ (2200) TOTAL QUANTUM NUMBER (OR REDUCED QUANTUM NUMBER) OF ELECTRON
C REMOVED DURING A TRANSITION
C NLAST (10) INDEX NUMBER OF LAST STATE IN TABLE FOR AN ELEMENT
C PHI (2200) STRENGTH OF EDGE DUE TO THIS TRANSITION
C U (1500) DEGENERACY OF A STATE
C K (1500) FIRST PROPORTIONAL TO LOG POPULATION AND THEN TO POPULATION
C OF A STATE
C KS (10) FIRST MAXIMUM K, THEN SUM OF K'S, FOR AN ELEMENT
C SMALLP (1500) POPULATION OF A STATE
C IESIJ (2200) LOWEST VALUE OF MU AT WHICH THE ABSORPTION COEFFICIENT IS
C AFFECTED BY THE LINE SERIES FOR THIS TRANSITION
C IRBLK (10) ARRAT OF KI
C U (5) COEFFICIENTS IN GAUSSIAN INTEGRATION
C K (5) COEFFICIENTS IN GAUSSIAN INTEGRATION
C UOLD (2200) LOCATION OF EDGE DUE TO THIS TRANSITION (EV/EV)
C UPHM (2200) LOWEST EDGE TO APPROXIMATE HIGH LINES (EV/EV)
C W (10) ATOMIC WEIGHT OF AN ELEMENT
C Z (10) ATOMIC NUMBER OF AN ELEMENT
C *** DIAPHR ***
C AMU (1000) ABSORPTION COEFFICIENT AT A PARTICULAR VALUE OF MU(0.6 .LE.
C MU .LE. 15) (PER CM)
C BMU (1000) BOTTOM OF EDGE OCCURRING AT A PARTICULAR VALUE OF MU(MU .GT.
C 15) (PER CM)
C ID (12) COMMENT CARD
C IMU (1000) TOP OF EDGE OCCURRING AT A PARTICULAR VALUE OF U (U>15) (PER
C CM)
C *** SPECIHA ***
C DEPECI (100, 4) QUANTUM DEFECT INDEXED BY THE IONIZATION LEVEL AND L + 1
C DELEPJ (1500) SAME AS DELEPJ IN DIAPHANOUS
C DELEPS (1750) SAME AS DELEPS IN DIAPHANOUS
C EPSU (1750) SAME AS EPS IN DIAPHANOUS
C IJU (1500) SAME AS IJ IN DIAPHANOUS
C IONZC (100) ZCODE FOR AN IONIZATION LEVEL
C L (10) L FOR AN ELECTRON LEVEL
C LIN (10) LEVEL AT WHICH AN ELECTRON IS BEING ADDED
C LOU (10) LEVEL AT WHICH AN ELECTRON IS BEING REMOVED
C MJU (1500) SAME AS MJ IN DIAPHANOUS
C N (10) N FOR AN ELECTRON LEVEL
C NE (102, 10) NUMBER OF ELECTRONS PER ELECTRON LEVEL IN THE GROUND STATE
C OF AN IONIZATION LEVEL
C NPU (1750) SAME AS NP IN DIAPHANOUS
C NJU (1500) SAME AS NJ IN DIAPHANOUS
C QU (1750) SAME AS U IN DIAPHANOUS
C
C DIMENSION U2(1000), BMU(1000), IMU(1000)
C DIMENSION ID(12), A(10), B(10), U1(150), GART(150), AMU(150), DAVE(150)
C
C DATA EPS / 1.E-07 /
C DATA IFLAU/U/

```


AFWL-TR-67-131, Vol IV

```

C      TKIN      IS THE TEMPERATURE AFTER WHICH AN END OF FILE IS WRITTEN
C              ON THE PROGRAM STOPS SPACING
C      GAMIN      IS THE GAMMA AFTER WHICH AN END OF FILE IS WRITTEN ON
C              THE PROGRAM STOPS SPACING
C      TWRITE     IS THE TEMPERATURE AT WHICH THE PROGRAM STOPS WRITING
C              VALUES FROM THE DAPHNE TAPE ONTO THE OUTPUT TAPE
C
C              IF (TWRITE .LE. U.) END ENTIRE TAPE
C
C      IF (ISPACU .LT. U)          AN END OF FILE WILL BE PUT ON THE
C                                DIAPHANOUS TAPE
C      IF (ISPACU .GE. U)          DAPHNE SPACES THE DIAPHANOUS TAPE
C                                PAST A CERTAIN TEMPERATURE AND GAMMA
C      IF SAUT IS TO BE USED AFTER THE TAPE IS SPACED BY DAPHNE, THEN THE
C      USER MUST USE AN IO CARD WITH COLUMNS 1 - 6 BLANK AS INPUT TO SAUT
C
C      LRN        IS A SIGNAL WHICH IS SET TO 1 WHEN GAMIN AND TKIN ARE
C              FOUND ON THE TAPE. IT IS TESTED AT THE END OF EACH THETA,
C              GAMMA SET. ITS VALUE IS ZERO OTHERWISE.
C
C      HEAD (5,9007) TKIN, GAMIN, TWRITE, ISPACU
C      WRITE (6,9970) TKIN, GAMIN, TWRITE, ISPACU
0007 FORMAT (3F10.0,12)
9970 FORMAT (25H THE INPUT TEMPERATURE = ,1PE15.0,/,
1      19H THE INPUT GAMMA = ,1PE15.0,/,
2      11H TWRITE = ,1PE15.0,10H ISPACU = ,13)
      MIN = 15
      LRN = 0
      NMCU = MIN
      NMCU = 0
      IOMU2 = 1000
C
      WRITE(6,9990)
      HEAD(MIN) A(1)
      WRITE(6,9995) A(1)
      IF (A(1)/25,999,999
25 IF(A(1)+1.) 999,2500,999
2500 CONTINUE
      NMCU = NMCU + 1
      HEAD (MIN) (ID(1),I=1,12)
      WRITE(6,9999) (ID(K), K=1,12)
      NMCU = NMCU + 1
      HEAD(MIN) A(1)
      WRITE(6,9995) A(1)
      IF(A(1)+2.) 999,3002,999
3002 CONTINUE
      NMCU = NMCU + 1
      32 HEAD (MIN) (B(1),I=1,2)
      IF (ABS((TKIN - B(1))/B(1)) .LT. EPS) GO TO 11
      GO TO 115
      11 CONTINUE
      IF (ABS((B(2) - GAMIN)/B(2)) .LT. EPS) LRN = 1
      115 CONTINUE
      IF (TWRITE .LE. U.) IFLAG=1
      IF (ABS((TWRITE - B(1))/B(1)) .LT. EPS) IFLAG=1

```

AFWL-TR-67-131, Vol IV

```

      IF (IPLAG.EQ.1) GO TO 30
      IK = B(1)
      UZ(U) = U.
      NMCD = NMCD + 1
33  CONTINUE
      NMCD = NMCD + 1
      HEAD (MIN) A(1),A(2)
      NMCD = NMCD + 1
      IF (A(1) + 3.) 31,61,31
31  CONTINUE
      IF (A(1) + 4.) 41,36,41
41  CONTINUE
      IF (A(1) + 6.) 33,42,33
42  CONTINUE
      HEAD (MIN) A(1),A(2)
      NMCD = NMCD + 1
      GO TO 33
61  CONTINUE
      HEAD (MIN) A(1),A(2),A(3)
      IF (A(1) + 4.) 62,36,62
62  CONTINUE
      J = J + 1
      IF (J - 10MU2) 61,61,69
69  CONTINUE
      HEAD (MIN) A(1),A(2),A(3)
      NMCD = NMCD + 1
      IF (A(1) + 4.) 69,36,69
36  CONTINUE
      NMCD = NMCD + 1
      HEAD (MIN) (A(JM),JM=1,8)
      IF (LMN .NE. 1) GO TO 12
13  CONTINUE
C   SPACE TAPE TO IKIN, GAMIN POSITION ON THE DIAPHANOUS TAPE
      IF (1SPACU .LT. U) GO TO 14
      WRITE (6,Y001) (B(I), I=1,2)
Y001  FORMAT (54H)THE DIAPHANOUS TAPE HAS BEEN SPACED TO AFTER THETA = ,
1     1PE15.8,3X,9H GAMMA = ,1PE15.8)
      WRITE (6,Y007) (A(JM),JM=1,8)
      WRITE (6,Y004) NMCD, LMN
      CALL EXIT
14  CONTINUE
C   WRITE AN END OF FILE ON THE TAPE
      TNU = -3.
      WRITE (MIN) TNU
      END FILE MIN
      WRITE (6,Y005) TNU
      WRITE (6,Y003) (B(I), I=1,2)
Y003  FORMAT (61H)AN END OF FILE WAS PUT ON THE DIAPHANOUS TAPE AFTER TH
      ETA = ,1PE15.8,3X,9H GAMMA = ,1PE15.8)
      GO TO 155
12  CONTINUE
C
      NMCD = NMCD + 1
      HEAD (MIN) A(1)
      IF (A(1) + 2.) 77,32,77

```


AFWL-TR-67-131. Vol IV

```

30 CONTINUE
C
  WRITE (6,9998) (B(J),J=1,2)
  J = 2
  M = 6
  UZ(J) = U.
  GANT(1) = U.
  UAVE(1) = U.
  TK = B(1)
  GAMMA = B(2)
  NHCU = NHCU + 1
34 REAU(MIN) A(1), A(2)
  IF(A(1) .LT. 0.) WRITE(6,9995) A(1)
  UX = A(1)
  UY = A(2)
  NHCU = NHCU + 1
  IF(UX + 3.) 35,65,35
35 IF(UX + 4.) 40,75,40
40 IF(UX + 6.) 55,45,55
45 REAU(MIN) A(1), A(2)
  WRITE(6,9000) A(1), A(2)
  U1(M) = A(1)
  AMU(M) = A(2)
  M = M+1
  UX = A(1)
  UY = A(2)
  NHCU = NHCU + 1
  IF(UX .LE. 0.) GO TO 4500
  ULAST = UX
  AKLAST = UY
  GO TO 34
4500 WRITE(6,9000) UX, UY
  REWIND NIN
  CALL EXIT
55 U1(M) = UX
  AMU(M) = UY
  M = M+1
  GO TO 34
65 REAU(MIN) A(1), A(2), A(3)
  UX = A(1)
  UY = A(2)
  UZ = A(3)
  NHCU = NHCU + 1
  IF(UX + 4.) 70,74,70
70 UZ(J) = UX
  BMU(J) = UY
  IMU(J) = UZ
  J = J+1
  JJ = J-1
  IF (J .EQ. 801) WRITE (6,9004) JJ
9004 FORMAT ('42M 2ND SET OF DIAPHRANOUS DATA HAS MORE THAN ,13,19M ENTH
11ES. THE1A = ,F7.2,0M, GAMMA=1PE10.5,19M, NO 6000 ABOVE U 3,UPP6.
21)
  IF(J-10MU2) 65,65,72
72 WRITE(6,15) 10MU2, TK, GAMMA, UZ(J-1)

```

AFWL-TR-67-131, Vol IV

```

73 HEAD(MIN) A(1), A(2), A(3)
   UX = A(1)
   UY = A(2)
   UZ = A(3)
   NMCD = NMCD + 1
   IF(UX + 4.) 73, 74, 75
74 ULAST=U2(J-1)
   AKLAST=IMU(J-1)
75 CONTINUE
   M = M - 1
   WHILE (6.4484) (U1(1), I=1,M)
   IF(GANT(1) .NE. U.) WHILE(6.4002) GANT
   WHILE (6.4482) (AMU(1), I=1,M)
   IF(UAVE(1) .NE. U.) WHILE(6.4002) UAVE
   HEAD(MIN) (A(JM), JM=1,M)
   WHILE(6.4447) (A(JM), JM=1,M)
   IF(U2(2) .EQ. U.) GO TO 76
   J = J - 1
   WHILE (6.4484) (U2(1), I=1,J)
   WHILE (6.4486) (BMU(1), I=1,J)
   WHILE (6.4488) (IMU(1), I=1,J)
76 CONTINUE
   NMCD = NMCD + 1
   IF (LMN .EQ. 1) GO TO 13
   HEAD (MIN) A(1)
   WHILE(6.4446) A(1)
   UX = A(1)
   NMCD = NMCD + 1
   IF(UX + 2.) 77, 72, 444
77 IF(UX + 5.) 444, 135, 444
135 CONTINUE
C
   NMCD = NMCD + 1
C
   THE ABOVE RECORD COUNT INCLUDES THE EOF RECORD
   WHILE (6.4444) NMCD, LMN
   REWIND MIN
   CALL EXIT
444 CONTINUE
   WHILE (6.4401)
4401 FORMAT (5H THERE IS AN ERROR IN THIS RUN. MERR HAS BEEN CALLED.)
   CALL MERR
C
C ***** F O R M A T S *****
15 FORMAT (42H 2ND SET OF DIAPHRANOUS DATA HAS MORE THAN 13, 19H ENTH
21E5, 19H1A = 17.2, 19H1B GAMMA=1PE10.5, 20H1C NO GOOD ABOVE U = 4446.
31)
4400 FORMAT(44H ULAST = 1PE15.7, 3X 44HAKLAST = E15.7)
4402 FORMAT(1P10E12.5)
4480 FORMAT(10H0 U1 ANHAY // (1P10E12.5))
4482 FORMAT(11H0 AMU ANHAY // (1P10E12.5))
4484 FORMAT(10H0 U2 ANHAY // (1P10E12.5))
4486 FORMAT(11H0 BMU ANHAY // (1P10E12.5))
4488 FORMAT(11H0 IMU ANHAY // (1P10E12.5))
4490 FORMAT(1H1)
4494 FORMAT(45H0 TAPE EDITING ON UNIVAC 1108 IS SUCCESSFUL. / 35H0 TOTA
1L NUMBER OF WRITE RECORDS IS ,11U / 11H LMN WAS = ,11U)
4495 FORMAT(10H0 SIGNAL = F6.1)
4496 FORMAT(10H1 SIGNAL = F6.1)
4497 FORMAT(6H02BAR=F6.4, 1X 44HMOE=1PE11.5, 2X 24HPE=11.5, 2X 24HE=11.5,
1 2X 24HNOSE=11.5, 2X 24HPLNK=11.5, 2X 24HEION=11.5, 2X 24HEGANE
20H4.3)
4498 FORMAT(44H0 THETA = 1PE15.7, 3X 74HGAMMA : E15.7)
4499 FORMAT(10H0, 12A6)
   END

```

the run without rewinding the tape. These features are useful when the end of the DIAPHANOUS tape is reached before a DIAPHANOUS run is finished, a previous run is incomplete, or more data are to be added to the DIAPHANOUS tape.

Input for DAPHNE

CARD NO.	INPUT VARIABLE	COLUMNS	FORMAT
1	TKIN	1-10	F10.8
	GAMIN	11-20	F10.8
	TWRITE	21-30	F10.8
	ISPAC0	31-32	I2
TKIN	The temperature to which the tape is spaced; if TKIN is blank, the tape is not spaced. TKIN is in eV		
GAMIN	The Γ to which the tape is spaced; if GAMIN is blank, the tape is not spaced. Γ is the "dimensionless electron degeneracy factor." Both GAMIN and TKIN must be specified to space the tape		
TWRITE	The temperature on the tape at which editing is begun. If $TWRITE \leq 0$, then the entire tape is edited		
ISPAC0	If $ISPAC0 < 0$, then an end-of-file will be put on the DIAPHANOUS tape; if $ISPAC0 \geq 0$, the tape is spaced to the end of a specified temperature, gamma set, and the run is terminated without rewinding the tape		

ANDIMX: CONVERSION OF OPACITY DATA FROM ANN TO DIAPHANOUS FORM

The FORTRAN IV ANDIMX program complex was written to transform ANN opacity data (computed by W. Huebner and D. Koontz at Los Alamos Scientific Laboratory to DIAPHANOUS form.

ANN data tapes are IBM-7094 binary tapes. These are first converted by the ANHIST 1108 machine language program to a UNIVAC-1108 binary tape. In this step, none of the data present on the original ANN tape are modified; however, all the ANN input tape records are brought to a standard UNIVAC-1108 binary format.

BLANK PAGE

AFWL-TR-67-131, Vol IV

```

C          D) A BLANK CARD SIGNIFIES END OF DATA. IF NO THEIA-
C          NHO SETS ARE TO BE DELETED, A BLANK DATA CARD MUST
C          FOLLOW THE SIX CARDS DESCRIBED ABOVE IN 1) AND 2).
C
C          ***** WARNING *****
C          CAYT ASSUMED .GE. 100
C          CAYT ASSUMED TO BE CLOSE TO A MULTIPLE OF 100 EV
C          *****
C
C          DIMENSION TITLE(60),BI(14), INPUT(10),SIGNAL(7),B2(11),IB(13)
C          1,MU(2971),DTU(2971), MU2(2971), BB1(14), IB(13), BB2(11)
C          2,THETA(1000),DENSITY(1000),CAYTE(1000)
C
C          DIMENSION CAYDEL(100), RHOEL(100,25), NMHO(100), ISAVE(100)
C          1,CAYGON(50), NMOGON(50,25)
C
C          REAL MU, MU2
C          INTEGER ANIN, ANOUT, DONE
C
C          DATA X/-1967./, SIGNAL/-1.,-2.,-3.,-4.,-5.,-6.,-7./,DONE/0/,
C          1 NEXT/1/,CAYT/U./,MAXHMO/25/,ANUIMX/6MANUIMX/
C
C          B2(9) AND B2(10) ARE SET TO ZERO IN CASE ANMIST-OUTPUT-TAPES
C          CONTAIN 35-WORD FIRST RECORDS (RATHER THAN 37-WORD FIRST RECORDS)
C          AT EACH TEMPERATURE-DENSITY POINT.
C          DATA B2(9), B2(10)/2*0./
C
C          M COUNTS THE NUMBER OF TEMPERATURES FOR WHICH DATA ARE TO BE
C          DELETED.
C          IDELET COUNTS THE NUMBER OF DENSITY SETS TO BE DELETED, PER
C          TEMPERATURE.
C          ISAVE(M) IS SET TO NONE IF NO DATA FOR CAYTNO(M) IS TO BE WRITTEN
C          ON THE ANUIMX-OUTPUT-TAPE ANOUT.
C          KOUNT COUNTS TEMPERATURES FOR WHICH DATA ARE TO BE DELETED, AS
C          THEY ARE LOCATED ON ANIN.
C          J COUNTS RHOPTS, PER TEMPERATURE, FOR WHICH DATA ARE TO BE WRITTEN
C          ON ANUIMX-OUTPUT-TAPE ANOUT
C          KJ COUNTS TEMPERATURE-DENSITY SETS WRITTEN ON ANUIMX-OUTPUT-TAPE
C          ANOUT
C          JUELET IS SET TO NONE IF NO DELETIONS ARE TO BE MADE FOR A
C          TEMPERATURE THAT IS READ FROM ANIN.
C
C          DATA M/U/, IDELET/0/, NONE/1/, ISAVE/100 * U/, KOUNT/0/
C          DATA J/U/, KJ/1/
C
C          DATA MODIFY/6H THESE/, NOTDU/6H NO /, EPSILN/1.E-3/
C          DATA ISAVET/0/, JUELET/U/, NMHO/100*0/
C
C          EQUIVALENCE (ANIN,INPUT(1)),(ANOUT,INPUT(2)),(IMDONE,B1(1)),
C          1(CAYT,B1(3)),(MU(1),DTU(1)),(ANT,B1(2)),(RHO,B1(4)),
C          2(CAYTEE, B2(11))
C
C          HEAD (5,1) (TITLE(L1),L1=1:52)
C          1 FORMAT (12A6)
C
C          HEAD (5,2) ANIN,ANOUT
C          2 FORMAT (12,1X,12)
C          IF(ANIN.EQ.0) ANIN=14
C          IF(ANOUT.EQ.0) ANOUT=12
C
C          WHITE (6,3) (TITLE(L3),L3=1:52)
C          3 FORMAT(1X,12A6, //)
C
C          WHITE (6,6) ANIN,ANOUT
C          6 FORMAT (8H ANIN = , 12, 9H ANOUT = , 12)
C
C          REWIND ALL TAPES
C          REWIND ANOUT

```

AFWL-TR-67-131, Vol IV

```

      NEWINU ANIN
      NEWINU 2
C
      WRITE (ANOUT)ANDIMX,X,X
      HEAD (ANIN) (TITLE(KM),KM=53,60)
C
      WRITE (ANOUT)(TITLE(L2),L2=1,60)
      WRITE (6,12) (TITLE(KM),KM=53,60)
      12 FORMAT (1X,8A6, //)
C
C
C      HEAD ALL DATA CARDS NECESSARY TO PREVENT SPECIFIED THETA-RHO DATA
C      FROM BEING WRITTEN ON ANOUT, THE ANDIMX OUTPUT TAPE.
C      TEMPERATURES MAY BE SPECIFIED IN ANY ORDER
C      DENSITIES, PER TEMPERATURE, MAY BE SPECIFIED IN ANY ORDER.
C      IT IS, HOWEVER, MORE EFFICIENT TO INPUT TEMPERATURES IN INCREASING
C      ORDER, AND DENSITIES PER TEMPERATURE IN INCREASING ORDER, AS
C      THAT IS THE ORDER IN WHICH THESE QUANTITIES ARE WRITTEN ON ANIN.
C
      400 CONTINUE
      M = M + 1
      HEAD (5,500) CATUEL(M), NRHO(M)
      500 FORMAT (F10.4, 8X, I2)
      IF (CATUEL(M) .EQ. 0.) GO TO 410
      IF (NRHO(M) .NE. 0) GO TO 401
C
      NRHO(M) .EQ. 0. MEANS DELETE ALL DATA AT THAT TEMPERATURE.
      15AVE(M) = NONE
      GO TO 400
C
      401 CONTINUE
      NRHO = NRHO(M)
      HEAD (5,501) (NRHOEL(M,M1), M1=1,NRHO)
      501 FORMAT (7E10.5)
C
      GO TO 400
C
      ALL DATA CARDS HAVE BEEN READ
C
      410 CONTINUE
      IF (M.EQ.1), NORMAL RUN, NO DELETIONS
      IF (M .EQ. 1) MODIFY = NOID0
      WRITE (6,502) MODIFY
      502 FORMAT (31HALL DATA CARDS HAVE BEEN READ, A6, 75H DELETIONS WILL
      1BE MADE (IF NRHO.EQ.0, DELETE ALL DATA AT THE INPUT CAYTNO) )
      IF (MODIFY .EQ. NOTDU) GO TO 480
      WRITE (6,503)
      503 FORMAT ( / 31H CAYTNO NRHO MHONO /)
C
      DO 470 M3=1,M
      1NRHO = NRHO(M3)
      WRITE (6,504) CATUEL(M3), NRHO(M3), (NRHOEL(M3,M4), M4=1,NRHO)
      504 FORMAT (2X, F10.4, 3X, I2, 4X, 1PE10.5, / (21X,1PE10.5))
      470 CONTINUE
      WRITE (6,505)

```

AFWL-TR-67-131, Vol IV

```

SUB FORMAT (1H1)
480 CONTINUE
C
C
      HEAD (ANIN) B1:B*(B2(1C):LC=1:10)
C
C      CAYTE STORES THE TEMPERATURE TO BE WRITTEN ON ANOUT.
C      CAYTE STORES THE TEMPERATURE READ FROM ANIN THAT WILL BE
C      WRITTEN AS B2(11) ON ANOUT.
C
      CAYTE(KJ)=CAYT
      CAYTE = CAYT
C
      CAYT=      FLOAT (IFIX(CAYT/100. + .5 ) * 100 )
CAVEAT ASSUMES TEMPERATURE .6E. (100-EPSILON)
      ICAYT=      CAYT
C
415 CONTINUE
      DO 4 JK=1,MAXHMO
      IF (MODIFY .EQ. NOTDO) GO TO 450
      IF (ICAYT .EQ. ISAVET) GO TO 434
C
C      CHECK TO SEE WHETHER CAYT IS ONE FOR WHICH DATA ARE TO BE DELETED.
C
      DO 420 M2=1,M
      IF (ABS((CAYT-CAYDEL(M2))/CAYT) .LT. EPSILN) GO TO 430
420 CONTINUE
      M2=      M
      JDELET=      NONE
      GO TO 450
C
C
C      A TEMPERATURE FOR WHICH DATA ARE TO BE DELETED HAS BEEN LOCATED.
430 CONTINUE
      KOUNT=      KOUNT + 1
      JDELET=      0
      IDELET=      0
      IF (ISAVE(M2) .EQ. NONE) GO TO 431
      NNHMO=      NNHMO(M2)
C
434 CONTINUE
      IF (JDELET.EQ.NONE .OR. IDELET.EQ.NNHMO(M2)) GO TO 450
435 CONTINUE
      DO 440 M3=1,NNHMO
      IF (ABS((RHO-HMODEL(M2,M3))/RHO) .LT. EPSILN) GO TO 431
440 CONTINUE
      GO TO 450
C
431 CONTINUE
C      DELETE THETA-RHO DATA
      ISAVET=      CAYT
      HEAD (ANIN) NOTUSE
      HEAD (ANIN) NOTUSE
      IDELET=      IDELET + 1
      HEAD (ANIN) NOTUSE, NOTUSE, CAYCON(KOUNT), NNHOGON(KOUNT,IDELET)

```

AFWL-TR-67-131, Vol IV

```

      GO TO 14
C
      450 CONTINUE
CAVEAT ASSUMES .LE. 25=MAXIMO DENSITIES AT EACH TEMPERATURE
      THETA(KJ)=CAYT
      DENSITY(KJ)=RHO
      WRITE (2) B1,B2
C      ANDIMX OUTPUT TAPES ALL HAVE 30 WORD FIRST RECORDS
C      RECORD 1 SAYS ANDIMX
C
      J=J+1
C
      HEAD(ANIN) NOTUSE
      HEAD (ANIN) NMAX, (NOTUSE,I=1,NMAX),(DTU(I),I=1,NMAX)
C
      DO 5 I=1,NMAX
      U OF I = .3 + FLOAT(I-1) * .01
      MU(I)=RHO*DTU(I)*6.476L7/(CAYTEE*(U OF I+.3)*AWT)
C
C      CORRECTION FOR INDUCED EMISSION STILL PRESENT.
      5 CONTINUE
C
      ISAVE1=CAYT
      WRITE (2) NMAX,(MU(I),I=1,NMAX)
      WRITE (6,19) KJ, THETA(KJ), DENSITY(KJ)
19 FORMAT (14H DATA AT KJ = ,I4, 12H, FOR CAYT = ,E12.4,8H, RHO = ,
1      E12.5, 27H HAVE BEEN WRITTEN ON DRUM. )
      KJ=KJ+1
C
      14 CONTINUE
C
C
C
      HEAD (ANIN) B1,B2,(B2(LC),LC=1,10)
      IF (IMDUNE .EQ. 0) GO TO 101
C
      CAYTE(KJ)=CAYT
      CAYTEE = CAYT
      CAYT = FLOAT (IFIX (CAYT/100. +.5) * 100 )
      ICAYT=CAYT
      IF (ICAYT.NE.ISAVET .AND. ISAVE(M2) .EQ. NONE) GO TO 460
      IF (ICAYT .NE. ISAVET) GO TO 102
      IF (ISAVE(M2) .EQ. NONE) GO TO 431
      IF (MODIFY.EQ.NOTDO .OR. JOELET.EQ.NONE .OR. IDELET.EQ.NRHO(M2))
1      GO TO 99
      GO TO 435
C
      101 CONTINUE
      DONE = NEXT
      102 CONTINUE
C      WRITE OUT ALL RECORDS FOR A GIVEN TEMPERATURE ON THE ANDIMX OUTPUT
C      TAPE.
C
      IF (MODIFY .EQ. NOTDO) GO TO 461
      IF (JOELET.NE.NONE .AND. IDELET.NE.NRHO(M2)) GO TO 600

```


AFWL-TR-67-131, Vol IV

```

461 CONTINUE
  DO 7 I=1,J
    BACKSPACE 2
    READ (2) NMAX2, (MU2(K),K=1,NMAX2)
    BACKSPACE 2
    BACKSPACE 2
    READ (2) BB1,IBB,BB2
    BACKSPACE 2
    WRITE (ANOUT) SIGNAL (7), X, X
    WRITE (ANOUT) BB1, IBB, BB2
    WRITE (ANOUT) NMAX2, (MU2(K),K=1,NMAX2)
  7 CONTINUE

C
460 CONTINUE
  IF (ISAVE(M2) .EQ. NONE) BB1(3)=CAYDEL(M2)
  WRITE (6,20) J, BB1(3)
20 FORMAT (1H0,14,81H DATA (MMU) SETS HAVE BEEN WRITTEN ON ANOIMX OUT
  INPUT TAPE ANOUT FOR TEMPERATURE = ,F10.0,/)
  IF(DONE.EQ.NEXT) GO TO 100
  J=U
  REWIND 2
  GO TO 415
99 CONTINUE
9 CONTINUE

C
  WRITE (6,15) THETA(KJ), (DENSITY(LM), LM=1,25)
15 FORMAT (58H CHANGE MAXHMO=25. THERE ARE 100 MANY DENSITIES AT THEI
  1A= , F10.0 /37H0THE FOLLOWING DENSITIES WERE READ IN/(1P10E13.7))
999 CONTINUE
  CALL MEHN
  RETURN
100 CONTINUE
  IF (KOUNT .NE. M-1) GO TO 601
  WRITE (ANOUT) SIGNAL(5), X,X
  END FILE ANOUT
  REWIND 2
  REWIND ANIN
  REWIND ANOUT
  WRITE (6,16)
16 FORMAT (34H1 TAPE WRITING ON ANOUT COMPLETED. )
  WRITE (6,16)
16 FORMAT(1H1,1X,50H THE TEMPERATURES AND DENSITIES PUT ON ANOUT WERE
  1 /1H0,14X,16HANIN TEMPERATURE,5X,17HANOUT TEMPERATURE,5X,13HANOUT
  2DENSITY /)
  DO 498 LL=1,KJ
    WRITE (6,17) LL, CAYTE(LL), THETA(LL), DENSITY(LL)
17 FORMAT (8X,14,4X,1PE13.7,9X,1PE13.7,7X,1PE13.7)
498 CONTINUE
  WRITE(6,13)
13 FORMAT (36H0 ANOIMX RUN SUCCESSFULLY COMPLETED.
  RETURN

C
C E N H O W E X I T S
C A TEMPERATURE FOR WHICH DATA ARE TO BE DELETED HAS BEEN INPUT.
C HOWEVER, THE INPUT DENSITY CANNOT BE FOUND ON THE ANIN TAPE.

```

AFWL-TR-67-131, Vol IV

```
600 CONTINUE
    WRITE (6,650) CATDEL(M2), (KMODEL(M2,M5), M5=1,NNRHO)
650 FORMAT (64H1 A TEMPERATURE FOR WHICH DATA ARE TO BE DELETED HAS BE
1EN INPUT. / 61H0 HOWEVER, THE INPUT DENSITY CANNOT BE FOUND ON THE
2 ANIN TAPE / 11H0 CATDEL = 'E12.6, 14H0 KMODEL SET= 'E12.6,
3 (/37X'E12.6) )
    GO TO 499
C
601 CONTINUE
C    ALL TEMPERATURES ON ANIN HAVE BEEN CHECKED AGAINST INPUT TEMPERA-
C    TURES FOR WHICH DATA ARE TO BE DELETED. HOWEVER, NOT ALL THE
C    INPUT TEMPERATURES WERE FOUND. CHECK FOR INPUT ERROR.
    WRITE(6,651)
651 FORMAT(60H1 INPUT ERROR. ALL VALUES OF CATNO WERE NOT FOUND ON A
1NIN. )
    GO TO 499
END
```

The ANHIST output tape is next processed by the ANDIMX program. Both ANN and ANHIST tapes have three records at a given (temperature, density) point. The first contains some thermodynamic data as well as some data that specify the type of calculation done by the ANN code. The ANHIST tape contains a 38-word first record. (ANN tapes contain 38 or fewer words in the first record. If there are less than 38 words, the ANHIST program fills the record with zeros.) This first record is preserved by the ANDIMX program. The second record on the ANN and ANHIST output tapes contains data on the energy levels and occupation numbers used in the ANN calculation at this (temperature, density) point. These data are not needed by the DIANE or radiation transport-hydrodynamics codes and are not present on the ANDIMX output tapes. The third record on the ANN and ANHIST output tapes contains reduced absorption coefficients. Both the continuous and the total (i.e., the "continuous plus lines") absorption coefficients are present. The ANDIMX program transforms the reduced absorption coefficient to the form expected by the DIANE code by the formula

$$\mu_{\text{ANDIMX output}} = 6.476 \times 10^7 (\rho \mu_{\text{ANN output}}) / (A \theta u^3),$$

where ρ is the density in gm/cc, A is the atomic weight in gm/mole, μ is the absorption coefficient, and u is the frequency in units of $h\nu/kT$.

On the ANN and ANHIST output tapes, the data at a given temperature are arranged in order of increasing densities. The DIANE program could process these data. However, the General Atomic radiation transport-hydrodynamics codes expect to find opacity data in decreasing density order at a given temperature. Therefore, the ANDIMX code next re-orders the data, at a given temperature, into a decreasing density order.

The ANDIMX output tape is acceptable input to the DIANE program.

The FORTRAN IV program EDITAN can edit ANHIST output tapes or ANDIMX output tapes.

The ANHIST program was written by J. Clow of General Atomic.

Input for ANDIMX

CARD NO.	FORMAT	DESCRIPTION
1-5	12A6	52 words of TITLE information (these data are combined with the 8 word TITLE already on the ANN tape (the ANHIST output tape))
6	I2, 1X, I2	ANIN } integer variables specifying the ANOUT } input and output tape units. If ANIN=0, it is reset to 14; if ANOUT =0, it is reset to 12
7	F10.4, 8X, I2	CAYDEL: if nonzero, delete data at $\theta = \text{CAYDEL}$ NRHO: delete NRHO densities at $\theta = \text{CAYDEL}$. If NRHO=0, delete all densities at $\theta = \text{CAYDEL}$
8, 9, etc	7E10.5	RHODEL(I), I=1, NRHO; the densities to be deleted at $\theta = \text{CAYDEL}$

(Card types 7, 8, 9, etc., are repeated as required. If card 7 is blank, no data are to be deleted.)

The ANDIMX program produces a binary output tape.

COMBO: A PROGRAM TO COMBINE OPACITY TAPES

Purpose

COMBO is a FORTRAN IV code written for the UNIVAC-1108. Its purpose is to select temperature-density data sets from any of four possible types of input tapes and transmit these sets to one of two possible types of output tapes. Input tapes for COMBO can be output tapes from either DIAPHANOUS, ANDIMX, DENSER, or ANHIST.

The DENSER and ANDIMX codes have been incorporated into COMBO as subroutines. A DIAPHANOUS-type tape is first converted to a DENSER type and stored temporarily on a drum. An ANHIST-type tape is first converted to an ANDIMX type and similarly stored on a drum. Thus, all input is considered to be either DENSER or ANDIMX.

AFWL-TR-67-131, Vol IV

	PROGRAM COMBO: INPUT, OUTPUT, TAPE10, TAPE11, TAPE12, TAPE13, TAPE3, 1TAPE4, TAPE7, TAPE8, TAPE5=INPUT, TAPE6=OUTPUT)		
C		COM	10
C	PRUGHAM COMBO: COMBINES TEMPERATURE-DENSITY DATA SETS FROM FOUR	COM	20
C	POSSIBLE TYPES OF INPUT TAPES. THESE ARE DIAPHANOUS	COM	30
C	(BINARY), ANDIMX (BINARY), DENSER(BCD) AND ANHIST	COM	40
C	(BINARY).	COM	50
C		COM	60
C	FOUR OR FEWER INPUT TAPES MAY BE SUPPLIED FOR A GIVEN RUN.	COM	70
C	EACH OF THE FOUR TAPES CAN BE ANY ONE OF THE FOUR TYPES	COM	80
C	MENTIONED ABOVE. IF A DIAPHANOUS TAPE IS SPECIFIED IT IS	COM	90
C	FIRST CONVERTED TO A DENSER TAPE BY SUBROUTINE DENSER, WHICH	COM	100
C	IS SIMILAR TO THE DENSER CODE, AND STORED TEMPORARILY ON A	COM	110
C	UNUM. SIMILARLY, AN ANHIST TAPE IS FIRST CONVERTED TO	COM	120
C	ANDIMX TYPE BY SUBROUTINE ANDIMX (SIMILAR TO ANDIMX CODE) AND	COM	130
C	STORED ON A UNUM.	COM	140
C		COM	150
C	TWO TYPES OF OUTPUT TAPES MAY BE PRODUCED. THE FIRST OF	COM	160
C	THESE IS IDENTICAL TO A DENSER TAPE (EXCEPT FOR THE HEADER	COM	170
C	AND LAST RECORD) AND CAN BE PRODUCED ONLY IF ALL INPUT TAPES	COM	180
C	ARE OF DENSER OR DIAPHANOUS TYPES. THE SECOND TYPE IS A	COM	190
C	BINARY TAPE CONSISTING OF TEMPERATURE-DENSITY GROUPS	COM	200
C	IDENTICAL TO THOSE FOUND ON EITHER ANDIMX (3 RECORD GROUPS)	COM	210
C	OR DENSER (2 RECORD GROUPS) TAPES.	COM	220
C		COM	230
C	THE FIRST RECORD OF EACH OUTPUT TAPE CONTAINS EITHER THE	COM	240
C	WORD 'COMBO1' OR 'COMBO2' FOLLOWED BY TWO DUMMY WORDS.	COM	250
C	COMBO1 REFERS TO A BCD DENSER TYPE OUTPUT WHILE COMBO2	COM	260
C	INDICATES A BINARY ANDIMX-DENSER COMBINATION. THE SECOND	COM	270
C	RECORD IS 244 WORDS IN LENGTH GIVING THE ID INFORMATION	COM	280
C	FOUND ON EACH INPUT TAPE PRECEDED BY THE WORK 'TAPE I'	COM	290
C	WHERE I=1,2,3 OR 4. IF FEWER THAN FOUR TAPES WERE INPUT, THE	COM	300
C	REMAINING WORDS ARE BLANK.	COM	310
C		COM	320

AFWL-TR-67-131, Vol IV

C	THE LAST 3 RECORDS ON AN OUTPUT TAPE ARE AS FOLLOWS:	COM	330
C	(1) THE INTEGER -8 FOLLOWED BY DUMMY WORDS.	COM	340
C	(2) A LIST OF TEMPERATURE DENSITY PAIRS CONTAINED ON THIS	COM	350
C	TAPE AND THE INPUT TAPE 1,2,3 OR 4 FROM WHICH EACH	COM	360
C	CAME.	COM	370
C	(3) THE INTEGER -5 FOLLOWED BY DUMMY WORDS (INDICATES END	COM	380
C	OF TAPE)	COM	390
C		COM	400
	INTEGER DUNIT(4)	COM	480
	INTEGER TCLASS(2,2),CLASS(2),PO	COM	490
	INTEGER TYPE(4),UNIT(4), UOUT,TOUT,POPT,TOPT,DSB,DRUM(4),IU	COM	500
	.(4),HEAD(244),BLANK,UDAM(60),ID1(12),DENSON,ANDMIX,ID2(10),IU3(IUCOM	COM	510
),HEADIN(2,8),TTYPE(2,4),SITPE(2,4),SOUT	COM	520
	REAL MINUS7	COM	600
	LOGICAL FLAG(4),GLAG	COM	650
	DIMENSION RHO(4),IMENM(38),A(5000),NSV(3,1000),ASV(2,1000),B(2)	COM	700
	DIMENSION TMX(4)	COM	710
	DATA (DRUM(1),I=1,4)/3,4,7,8/,COMB01/6HCUMB01/,COMB02/6HCUMB02/,	COM	800
	(TID(1),I=1,4)/6HTAPE 1,6HTAPE 2,6HTAPE 3,6HTAPE 4/,BLANK/IM /,	COM	810
	DENSON/6HDENSER/,ANDMIX/6HANDIMX/,EPS/1.E-6/,MINUS7/-7./,IM7/-7/	COM	820
	DATA (HEADIN(1,I),I=1,6)/6HOUTPUT,6H TAPE ,6HIS OF ,6HDENSER,6H TCOM	COM	830
	TYPE ,6H(BCD) /,(HEADIN(2,I),I=1,8)/6HOUTPUT,6H TAPE ,6HIS OF ,6HANCOM	COM	840
	UIMX,6H - COM,6HNO TYP,6HE (BIN,6HARY) /,(HEADIN(1,I),I=7,8)/2*IMCOM	COM	850
	./	COM	860
	DATA (TTYPE(1,J),I=1,2),J=1,4)/6H DIAPH,6HANOUS ,6H AND,6HIMX,6HCOM	COM	870
	DEN,6HSEER,6H ANN,6HIST/,MB/-8/,MS/-5/	COM	880
	DATA TMX/1.E38/	COM	890
	DATA (TCLASS(I,J),J=1,2),I=1,2)/6HUNCLAS,6HNSIFIED,6HNEITHE,6HMM	COM	900
	./	COM	910
		COM	912
C	VARIABLE DEFINITIONS	COM	914
C		COM	916
C	NAME MEANING	COM	918
C	A(5000)	COM	920
C	HUFFER USED FOR TRANSMITTING DATA FROM I/P TAPES	COM	922
C	TO O/P TAPE.	COM	924
C	ALAST1	COM	924
C	SAME AS IN DENSER CODE	COM	926
C	ANDMIX	COM	926
C	CONTAINS THE ALPHANUMERIC WORD 'ANDMIX'	COM	928
C	ASV(2,1000)	COM	928
C	STORAGE FOR THE ITH TEMPERATURE (ASV(1,I)), AND	COM	930
C	THE ITH DENSITY (ASV(2,I)) PUT OUT ON O/P TAPE.	COM	931
C	USED IN SUMMARY PRINTOUT.	COM	932
C	B(2)	COM	932
C	SAME AS IN DENSER (B(1) = TEMPERATURE)	COM	933
C	BLANK	COM	933
C	CONTAINS ALPHANUMERIC BLANK.	COM	934
C	CLASS(2)	COM	934
C	SECURITY CLASSIFICATION AS READ FROM DATA CARD.	COM	935
C	COMB01	COM	935
C	ALPHANUMERIC WORD 'COMB01'	COM	936
C	COMB02	COM	936
C	ALPHANUMERIC WORD 'COMB02'	COM	937
C	U	COM	937
C	DUMMY WORD USED TO SKIP RECORDS WHILE READING	COM	938
C	BINARY TAPE.	COM	939
C	DENSON	COM	939
C	ALPHANUMERIC WORD 'DENSER'	COM	940
C	DRUM(4)	COM	940
C	THE LOGICAL DRUM UNITS USED FOR INTERMEDIATE	COM	941
C	CONVERSION. (3,4,7 AND 8).	COM	941
C	DSB	COM	942
C	SUBSCRIPT INDICATING CURRENT DRUM BEING USED.	COM	943
C	EPS	COM	943
C	AN EPSILON (1.E-6) TOLERANCE FOR COMPAIRING DATA	COM	944
C	CARD TEMPERATURES TO THOSE READ FROM TAPES.	COM	944
C	FLAG(4)	COM	945
C	FOR EACH I/P TAPE, INITIALLY .FALSE., SET TRUE IF	COM	945
C	END OF DATA IS REACHED BEFORE EXHAUSTING SPECIFIED	COM	946

AFWL-TR-67-131, Vol IV

C		THETA-RHO SETS.	COM 947
C	GLAG	INITIALLY FALSE FOR EACH THETA-RHO SET. SET TRUE	COM 948
C		IF ANY THETA-RHO SPECIFIED IS FOUND ON SOME I/P TAPE	COM 949
C	HEAD(244)	STORAGE FOR THE HEADER RECORD O/P ON COMBO TAPE.	COM 950
C	HEADIN(208)	PRINTER HEADING FOR SUMMARY OUTPUT LIST.	COM 951
C	ID	ID WORD ON I/P TAPE. SHOULD BE EITHER 'DENSER' OR	COM 952
C		'ANDIMX'.	COM 953
C	IDAM(60)	ID ARRAY FOUND ON ANDIMX TYPE TAPES.	COM 954
C	IDI(12)	ID ARRAY FOUND ON DENSER TYPE TAPES. EQUIVALENT TO	COM 955
C		ID IN DENSER.	COM 956
C	ID2(10)	EQUIVALENT TO COMP IN DENSER.	COM 957
C	ID3(10)	EQUIVALENT TO IZ IN DENSER.	COM 958
C	IL	LENGTH OF THERMODYNAMICS DATA ON DENSER TYPE TAPE.	COM 959
C		EITHER 8 OR 20.	COM 960
C	IM7	-7 (INTEGER)	COM 961
C	IPG	PAGE COUNTER FOR PRINTER O/P.	COM 962
C	ISV	COUNTER ON ASV AND NSV ARRAYS.	COM 963
C	ITP	SUBSCRIPT ON TAPES.	COM 964
C	JM	EQUIVALENT TO J IN DENSER.	COM 965
C	K	THE PRESENT LOGICAL I/P UNIT.	COM 966
C	LINE	LINE COUNTER FOR PRINTER O/P.	COM 967
C	LLF	THE NUMBER OF BLANK LINES BETWEEN THE LAST PRINTED	COM 968
C		LINE AND THE BOTTOM OF THE PAGE.	COM 969
C	MINUS7	-7. (REAL)	COM 970
C	MM	SAME AS M IN DENSER	COM 971
C	MS	-5	COM 972
C	MB	-8	COM 973
C	NSV(13,1000)	STORAGE FOR THE ITH TAPE UNIT (NSV(1,I)), THE ITH	COM 974
C		LOGICAL UNIT DESIGNATION (NSV(2,I)) AND THE ITH	COM 975
C		TAPE TYPE. (SEE ASV)	COM 976
C	NTAPES	THE NUMBER OF I/P TAPES (I.E. 4).	COM 977
C	NZ	SAME AS IZ IN DENSER.	COM 978
C	OUNIT(4)	THE LOGICAL UNITS OF INPUT TAPES.	COM 979
C	PO	FLAG INDICATING TYPE OF SECURITY CLASSIFICATION	COM 980
C		PRINTOUT: 1 SECRET RESTRICTED DATA	COM A981
C		2 UNCLASSIFIED	COM B981
C		3 NO HEADING	COM C981
C	POPT	PRINT OPTION: 0 COMPLETE PRINTOUT	COM D981
C		1 PRINTOUT WITH NO TITLES	COM E981
C		2 NO PRINTOUT	COM F981
C	RHO(4)	LOWER CUTOFF DENSITIES FOR EACH TAPE. IF RHO(I)<0,	COM G981
C		NO TEMP.-DENSITY PAIRS FOR THIS TEMP. ARE TAKEN	COM H981
C		FROM TAPE I.	COM I981
C	R1	UPPER DENSITY CUTOFF, PRESENT TAPE.	COM J981
C	R2	LOWER DENSITY CUTOFF, PRESENT TAPE.	COM K981
C	STYPE(2,4)	ALPHANUMERIC IDENTIFICATION OF I/P TAPES (EG, IF	COM L981
C		TAPE 3 IS DENSER, STYPE(1,3)= DEN AND	COM M981
C		STYPE(2,3)=SER).	COM N981
C	TCLASS(2,2)	DATA OF WORDS 'UNCLASSIFIED' AND 'NEITHER'	COM O981
C	THERM(30)	THERMODYNAMICS DATA FROM ANDIMX TYPE TAPES. SAME AS	COM P981
C		BB1,IBB AND BB2 IN ANDIMX CODE.	COM Q981
C		THERM(3)=TEMPERATURE	COM R981
C		THERM(4)=DENSITY	COM S981
C	THETA	TEMPERATURE AS READ FROM DATA CARD.	COM T981
C	TID(4)	ALPHANUMERIC 'TAPE I' IS IN TID(I).	COM U981

BLANK PAGE

AFWL-TR-67-131, Vol IV

C		COM 1200
C	NOTE: LEAVING POPT AND TOPT BLANK WILL RESULT IN COMPLETE	COM 1210
C	PRINTOUT.	COM 1220
C		COM 1230
C	USB=1	COM 1240
C		COM 1250
C	LOOP 10 DETERMINES TYPE OF TAPE AND CONVERTS TO DENSER OR	COM 1260
C	ANDIMX IF NECESSARY.	COM 1270
C		COM 1280
	DO 10 I=1,NTAPES	COM 1290
	11=TYPE(I)	COM 1300
	GO TO (11,10,10,12),11	COM 1310
	11 CALL DENSER(UNIT(I),DRUM(DSB),TMX(I))	COM 1320
	TYPE(I)=3	COM 1325
	14 UNIT(I)=DRUM(DSB)	COM 1330
	USB=USB+1	COM 1340
	GO TO 10	COM 1350
	12 CALL ANDIMX(UNIT(I),DRUM(DSB),TMX(I))	COM 1360
	TYPE(I)=2	COM 1365
	SOUT=1	COM 1367
	GO TO 14	COM 1370
	10 CONTINUE	COM 1380
	DO 15 I=1,NTAPES	COM 1382
	15 TYPE(I)=TYPE(I)-1	COM 1385
C		COM 1390
C	IF TYPE 1 OUTPUT IS SPECIFIED, LOOP 20 INSURES THAT ALL INPUT	COM 1400
C	TAPES ARE OF TYPE 1 OR 3.	COM 1410
C		COM 1420
	IF(TOUT.EQ.2)GO TO 25	COM 1430
	DO 20 I=1,NTAPES	COM 1440
	IF(TYPE(I).EQ.1.OR.TYPE(I).EQ.3) GO TO 20	COM 1450
	WRITE(6,200)1,UNIT(I),TYPE(I)	COM 1460
	CALL EXIT	COM 1470
	20 CONTINUE	COM 1480
C		COM 1490
C	REWIND ALL TAPES	COM 1500
C		COM 1510
	25 REWIND DOUT	COM 1520
	DO 30 I=1,NTAPES	COM 1530
	11=UNIT(I)	COM 1540
	30 REWIND 11	COM 1550
C		COM 1560
C	WRITE COMBO ID RECORD	COM 1570
C		COM 1580
	GO TO(40,41),TOUT	COM 1590
	40 WRITE(UNIT,500)COMB01,D,D	COM 1600
	GO TO 42	COM 1610
	41 WRITE(UNIT)COMB02,D,D	COM 1620
C		COM 1700
C	CONSTRUCTION OF HEADER (ID) RECORD	COM 1710
C		COM 1720
C	ALSO INSURES THAT FIRST WORD ON EACH I/P TAPE IS EITHER 'DENSER'	COM 1730
C	OR 'ANDIMX'.	COM 1740
C		COM 1750
	42 DO 43 I=1,244	COM 1760

AFWL-TR-67-131, Vol IV

43 HEAD(1)=BLANK	COM 1770
DO 50 I=1,NTAPES	COM 1780
J=ITPL(I)	COM 1790
K=UN1(I)	COM 1800
L=61*(I-1)+1	COM 1803
HEAD(L)=ID(1)	COM 1808
GO TO(45,46),J	COM 1810
45 HEAD(K)=ID	COM 1820
IF(ID.EQ.ANOMIX)GO TO 47	COM 1830
WRITE(6,201)I,K,1D	COM 1840
CALL EX11	COM 1850
47 HEAD(K)=IDAM	COM 1860
DO 48 LL=1,60	COM 1880
48 HEAD(L+LL)=IDAM(LL)	COM 1890
GO TO 50	COM 1900
46 HEAD(K,600)=ID,(ID1(M),M=1,12),NZ,(ID2(M),ID3(M),M=1,NZ)	COM 1910
IF(ID.EQ.DENSOR)GO TO 49	COM 1920
WRITE(6,202)I,K,1D	COM 1930
CALL EX11	COM 1940
49 DO 51 LL=1,12	COM 1950
51 HEAD(L+LL)=ID1(LL)	COM 1960
HEAD(L+13)=NZ	COM 1970
DO 52 LL=1,NZ	COM 1990
M=L+12+2*LL	COM 2000
N=M+1	COM 2010
HEAD(M)=ID2(LL)	COM 2020
52 HEAD(N)=ID3(LL)	COM 2030
50 CONTINUE	COM 2040
C	COM 2100
C WRITE THE HEADEN RECORD ON THE O/P TAPE.	COM 2110
C	COM 2120
GO TO(55,56),TOUT	COM 2130
55 WRITE(UOUT,501)(HEAD(I),I=1,244)	COM 2140
GO TO 57	COM 2150
56 WRITE(UOUT)(HEAD(I),I=1,244)	COM 2160
57 ISV=1	COM 2170
IF(TOPT.NE.U)GO TO 53	COM 2180
WRITE(6,208)	COM 2183
CALL SHEAD(P0)	COM 2185
WRITE(6,204)	COM 2190
LINE=7	COM 2192
C	COM 2200
C READ A TEMPERATURE (THETA) AND SET OF DENSITIES (RHO'S)	COM 2210
C	COM 2220
53 HEAD(5,101)THETA,(RHO(I),I=1,NTAPES)	COM 2230
EPI=EPS*THETA	COM 2233
IF(THETA.EQ.-5000.)GO TO 95	COM 2235
WRITE(6,214)THETA	COM 2237
LINE=LINE+3	COM 2237
GLAG=.FALSE.	COM 2238
C	COM 2240
C FIND THETA ON THE FIRST I/P TAPE ON WHICH IT EXISTS.	COM 2250
C	COM 2260
ITP=1	COM 2270
99 IF(FLAG(ITP)) GO TO 90	COM 2273

AFWL-TR-67-131, Vol IV

IF (NHO(1TP).LT.0.)GO TO 90	COM 2275
54 K=UNIT(1TP)	COM 2280
J=TYPE(1TP)	COM 2290
CALL KMOUET(1TP,NHO,N1,R2)	COM 2295
GO TO (60,80),J	COM 2300
C	COM 2303
C HEADS ANDIMX TYPE TAPES.	COM 2305
C	COM 2307
60 HEAD(K)U	COM 2310
IF (U.EQ.MINUS7)GO TO 62	COM 2320
IF (U.EQ.-5.)GO TO 70	COM 2330
WRITE(6,203)K,U	COM 2340
CALL EXIT	COM 2350
62 HEAD(K)(THERM(1),I=1,38)	COM 2360
IF (THERM(3)-EPT.LE.THETA) GO TO 65	COM 2362
66 BACKSPACE K	COM 2364
BACKSPACE K	COM 2366
GO TO 90	COM 2368
65 IF (THERM(3).GE.(THETA-EPT).AND.(THERM(3).LE.(THETA+EPT))) GO TO 64	COM 2370
61 HEAD(K)U	COM 2380
GO TO 60	COM 2390
64 IF (THERM(4).GT.N1) GO TO 61	COM 2400
IF (THERM(4).LT.N2) GO TO 66	COM 2405
IF (TOPT.NE.0)GO TO 67	COM 2410
LINE=LINE+9	COM 2412
IF (LINE.LE.46)GO TO 63	COM 2414
LINE=LINE-9	COM 2416
LLF=46-LINE	COM 2417
IF (LLF.EQ.0)GO TO 630	COM 2418
DO 631 I=1,LLF	COM 2419
631 WRITE(6,216)	COM 2420
630 CALL SHEAD(PO)	COM 2421
WRITE(6,208)	COM 2422
CALL SHEAD(PO)	COM 2423
WRITE(6,204)	COM 2424
WRITE(6,214)THETA	COM 2425
LINE=18	COM 2426
63 WRITE(6,212)1TP,OUNIT(1TP),(STYPE(J,1TP),J=1,2),(THERM(1),I=1,38)	COM 2428
67 WHILE(UOUT)IM7,D,U,U	COM 2430
WRITE(UOUT)(THERM(1),I=1,38)	COM 2440
HEAD(K)N,(A(1),I=1,N)	COM 2450
WRITE(UOUT)N,(A(1),I=1,N)	COM 2460
GLAG=.TRUE.	COM 2465
68 NSV(1,1SV)=1TP	COM 2470
NSV(2,1SV)=OUNIT(1TP)	COM 2480
NSV(3,1SV)=TYPE(1,1TP)	COM 2490
GO TO (69,87),J	COM 2495
69 ASV(1,1SV)=THERM(3)	COM 2500
ASV(2,1SV)=THERM(4)	COM 2510
1SV=1SV+1	COM 2520
GO TO 60	COM 2530
70 REWIND K	COM 2540
FLAG(1TP)=.TRUE.	COM 2545
GO TO 90	COM 2550
C	COM 2600

AFWL-TR-67-131, Vol IV

C	HEADS DENSER RECORDS FOR TEMP-RHO GROUPS.	COM 2610
C		COM 2620
	80 HEAD(K,601)JM,MM,ULAST1,ALAST1,B(1),B(2),(A(KM),KM=1,9)	COM 2630
	IF(JM.EQ.-5)GO TO 70	COM 2640
	LL=2*MM+3*JM-2	COM 2645
	IF(B(1)-EPS.LT.THETA)GO TO 81	COM 2650
	83 BACKSPACE K	COM 2660
	GO TO 90	COM 2670
	81 IF(B(1).GT.(THETA-EPS).AND.B(1).LT.(THETA+EPS))GO TO 82	COM 2680
	88 HEAD(K,602)(A(L),L=1,LL)	COM 2690
	GO TO 80	COM 2700
	82 IF(A(2).GT.H1) GO TO 88	COM 2710
	IF(A(2).LT.H2) GO TO 83	COM 2715
	LLL=LL+10	COM 2720
	HEAD(K,602)(A(L),L=1,LLL)	COM 2730
	IF(FOR1.NE.U)GO TO 84	COM 2740
	LL=20	COM 2750
	IF(A(9).EQ.U.)LL=8	COM 2760
	IF(LL.EQ.8)LINE=LINE+3	COM 2761
	IF(LL.EQ.20)LINE=LINE+5	COM 2762
	IF(LINE.LE.46)GO TO 810	COM 2763
	LINE=LINE-3	COM 2764
	IF(LL.EQ.20)LINE=LINE-2	COM 2765
	LL=46-LINE	COM 2766
	IF(LLF.EQ.U)GO TO 811	COM 2767
	DO 812 I=1,LLF	COM 2768
	812 WRITE(6,216)	COM 2769
	811 CALL SHEAD(P0)	COM 2770
	WRITE(6,208)	COM 2771
	CALL SHEAD(P0)	COM 2772
	WRITE(6,204)	COM 2773
	WRITE(6,214)THETA	COM 2774
	LINE=12	COMA2774
	IF(LL.EQ.20)LINE=14	COMB2774
	810 WRITE(6,205)ITP,UNIT(ITP),(STYPE(J,ITP),J=1,2),(A(I),I=1,IL)	COM 2775
	84 FLAG=TRUE.	COM 2780
	GO TO(85,86),TOUT	COM 2790
	85 WRITE(UNIT,502)JM,MM,ULAST1,ALAST1,H(1),B(2),(A(L),L=1,LLL)	COM 2800
	GO TO 88	COM 2810
	86 WRITE(UNIT)JM,MM,ULAST1,ALAST1	COM 2820
	WRITE(UNIT)B(1),B(2),(A(L),L=1,LLL)	COM 2825
	GO TO 88	COM 2830
	87 ASV(1,ISV)=B(1)	COM 2840
	ASV(2,ISV)=A(2)	COM 2850
	ISV=ISV+1	COM 2860
	GO TO 80	COM 2900
	90 ITP=ITP+1	COM 2910
	IF(ITP.LE.NTAPES)GO TO 89	COM 2920
	IF(FLAG)GO TO 92	COM 2930
	WRITE(6,206)THETA,(RHO(I),I=1,NTAPES)	COM 2940
	92 DO 91 I=1,NTAPES	COM 2950
	IF(.NOT.FLAG(I))GO TO 93	COM 2960
	91 CONTINUE	COM 2970
	WRITE(6,207)	COM 2973
	77 HEAD(5,101)THETA,(RHO(I),I=1,NTAPES)	

AFWL-TR-67-131, Vol IV

IF (THETA.EQ.-5000.) GO TO 95	COM 2976
WRITE (6,211) THETA, (RHO(1), I=1, NTAPES)	COM 2979
GO TO 77	COM 2990
C	COM 3000
C ALL INPUT GROUPS HAVE BEEN TRANSFERRED TO THE OUTPUT TAPE.	COM 3010
C	COM 3020
95 ISV=ISV-1	COM 3020
IF (IOP1.NE.0) GO TO 950	COM 3021
LLF=40-LINE	COM 3022
IF (LLF.EQ.0) GO TO 951	COM 3023
DO 952 I=1,LLF	COM 3024
952 WRITE (6,216)	COM 3025
951 CALL SHEAD(P0)	COM 3026
950 GO TO (96,97), IOUT	COM 3033
96 WRITE (UOUT,502) MB,MB, (A(I), I=1,30)	COM 3040
WRITE (UOUT,502) ISV,ISV, (A(I), I=1,30)	COM 3045
DO 96 I=1,ISV	COM 3050
98 WRITE (UOUT,504) (NSV(J,1), J=1,3), (ASV(J,1), J=1,2)	COM 3060
WRITE (UOUT,502) MS,MS, (A(I), I=1,30)	COM 3070
GO TO 99	COM 3080
97 WRITE (UOUT) MB,MB, (A(I), I=1,2)	COM 3090
WRITE (UOUT) ISV, (NSV(J,1), J=1,3), (ASV(J,1), J=1,2), I=1,ISV)	COM 3100
WRITE (UOUT) MS,MS, (A(I), I=1,2)	COM 3110
99 END FILE UOUT	COM 3120
REWIND UOUT	COM 3130
DO 94 I=1, NTAPES	COM 3140
K=UNIT(1)	COM 3150
94 REWIND K	COM 3160
IF (IOP1.EQ.2) CALL EXIT	COM 3170
C	COM 3200
C PRINTOUT OF GROUPS COPIED	COM 3210
C	COM 3220
LINE=0	COM 3222
IPG=1	COM 3225
WRITE (6,208)	COM 3225
CALL SHEAD(P0)	COM 3227
IF (IOP1.EQ.1) GO TO 75	COM 3230
WRITE (6,209) UOUT, (HEADIN(TOUT,1), I=1,8), IPG	COM 3240
LINE=0	COM 3245
75 DO 76 I=1,ISV	COM 3250
ITP=NSV(1,1)	COM 3255
LINE=LINE+2	COM 3260
IF (LINE.LE.46) GO TO 76	COM 3270
CALL SHEAD(P0)	COM 3272
WRITE (6,208)	COM 3280
CALL SHEAD(P0)	COM 3285
LINE=0	COM 3290
IF (IOP1.EQ.1) GO TO 76	COM 3300
IPG=IPG+1	COM 3310
WRITE (6,209) UOUT, (HEADIN(TOUT,J), J=1,8), IPG	COM 3320
LINE=0	COM 3325
76 WRITE (6,210) (NSV(J,1), J=1,2), (STPE(J,ITP), J=1,2), (ASV(J,1), J=1,2)	COM 3330
LLF=40-LINE	COM 3340
IF (LLF.EQ.0) GO TO 73	COM 3350
DO 72 I=1,LLF	COM 3360

AFWL-TR-67-131, Vol IV

72 WRITE(6,216)	COM 3370
73 CALL SHEAD(P0)	COM 3380
WRITE(6,208)	COM 3390
CALL EXIT	COM 3400
C	COM 6000
C FORMATS	COM 6010
C	COM 6020
100 FORMAT(1615)	COM 6030
101 FORMAT(5E12.8)	COM 6040
200 FORMAT(1H1,2UX,50HOUTPUT TAPE WAS SPECIFIED AS DENSER TYPE BUT TAPCOM	COM 6100
.E ,12. 9H ON UNIT ,12,20H IS BINARY, OF TYPE ,12)	COM 6110
201 FORMAT(1H1,2UX,21HFIRST RECORD ON TAPE ,12, 9H ON UNIT ,12,5H WAS	COM 6120
.A6,24H BUT SHOULD BE 'ANDIMX'.)	COM 6130
202 FORMAT(1H1,2UX,21HFIRST RECORD ON TAPE ,12, 9H ON UNIT ,12,5H WAS	COM 6140
.A6,24H BUT SHOULD BE 'DENSEX'.)	COM 6150
203 FORMAT(1H1,2UX,25HANDIMX TYPE TAPE ON UNIT ,12,32H SHOULD HAVE -7.COM	COM 6160
. AS FIRST RECORD/21X, 8H BUT HAS ,1PE16.8)	COM 6170
204 FORMAT(1HU,35X,61HTHERMODYNAMICS RECORDS OF TEMP.-DENSITY GROUPS UCOM	COM 6180
.N OUTPUT TAPE//10A,8H1/P TAPE,1UX,4HUNIT,10X,4HTYPE,36X,14HTHERMOUCOM	COM 6190
.NOMICS)	COM 6200
205 FORMAT(1HU,12X,12,14X,12,7X,2A6,2X,1P5E16.8/(52X,1P5E16.8/))	COM 6210
206 FORMAT(1HU,1UX,75HTHERE ARE NO TEMPERATURE-DENSITY GROUPS ON THESECOM	COM 6220
. 1/P TAPES FOR TEMPERATURE ,1PE14.7/11X,27HAND LOWER CUTOFF DENSITYCOM	COM 6230
.1LS ,1P4E16.7)	COM 6240
207 FORMAT(1H1,1UX,80HDATA HAS BEEN EXHAUSTED ON ALL 1/P TAPES, BUT THECOM	COM 6250
. DATA CARDS LISTED BELOW REMAIN:)	COM 6260
211 FORMAT(1HU,5X,1P5E16.8)	COM 6270
208 FORMAT(1H1)	COM 6280
209 FORMAT(1HU,44X,41HSUMMARY OF OUTPUT TAPE GENERATED ON UNIT ,12//41COM	COM 6300
.X,8A6,31X,5HPAGE ,12//2UX,8H1/P TAPE,10X,4HUNIT,14X,4HTYPE,15X,11HCOM	COM 6310
.TEMPERATURE,15X,7HDENSITY/)	COM 6320
210 FORMAT(1HU,22X,12,14X,12,11X,2A6,2(10X,1PE14.7))	COM 6330
212 FORMAT(1HU,12X,12,14X,12,7X,2A6,2X,1P5E16.8/52X,1P5E16.8/52X,1P4E1COM	COM 6340
.6.8,6X,18/52X,5(8X,18)/52X,5(8X,18)/52X,2(8X,18),1P3E16.8/52X,1P5ECCOM	COM 6350
.16.8/52X,1P3E16.8)	COM 6360
214 FORMAT(1HU,30X,22HTEMPERATURE (THETA) = ,1PE14.7)	COM 6370
216 FORMAT(1H)	COM 6375
500 FORMAT(A6,2E9.4)	COM 6450
501 FORMAT(13A6)	COM 6460
502 FORMAT(214,13E9.4/(14E9.4))	COM 6470
504 FORMAT(214,A6,2E9.4)	COM 6480
600 FORMAT(13A6/12,(F6.4,12))	COM 6500
601 FORMAT(214,13E9.4)	COM 6510
602 FORMAT(14E9.4)	COM 6520
END	COM 8000

Temperature-density groups to be transmitted to the output tape are specified by supplying a temperature and a lower cutoff density for each input tape. Temperatures are supplied in increasing magnitudes. For each temperature, all temperature-density groups with densities greater than the first lower cutoff density are transmitted to the output tape from the first input tape. For the second input tape, all groups with densities less than the first cutoff and greater than the second are transmitted, etc., until all input tapes are exhausted.

Two types of output tapes may be produced. The first is a BCD tape identical to a DENSER tape (except for the header and last records) and can be produced only if all input tapes are DENSER or DIAPHANOUS types. The second is a binary tape consisting of temperature-density groups identical to those found on either ANDIMX tapes (if input is ANDIMX or ANHIST) or DENSER tapes (if input is DENSER or DIAPHANOUS).

Input for COMBO

Input Data Cards

CARD NO.	COLUMNS	FORMAT	DESCRIPTION
1		(16I5)	
	1-5	I5	Number of input tapes (<u>≤</u> 4)
	6-10	I5	Logical unit, first I/P tape
	11-15	I5	Type*, first I/P tape
	16-20	I5	Logical unit, second I/P tape (if necessary)
	21-25	I5	Type*, second I/P tape
	etc.		
* Type designators:			
	1	DIAPHANOUS	
	2	ANDIMX	
	3	DENSER	
	4	ANHIST	

AFWL-TR-67-131, Vol IV

(continued)

CARD

NO.	COLUMNS	FORMAT	DESCRIPTION
2		(5E12.8)	
	1-12	E12.8	Maximum temperature to copy from first I/P tape
	13-24	E12.8	Maximum temperature to copy from second I/P tape
	etc.		
<p>NOTE: Data on card type 2 are applicable only when a tape is of type 1 or 4 (i. e., must first be converted to a type 3 or 2). Execution time can be reduced by converting only those temperature-density groups with temperatures less than some required maximum. If all temperatures are required, or if all tapes are of type 2 or 3, a blank card will suffice</p>			
3		(16I5)	
	1-5	I5	Logical unit, output tape
	6-10	I5	Type of output tape:
			1. BCD (similar to DENSER)
			2. Binary (combination of DENSER and ANDIMX types)
	11-15	I5	Print option:
		0. Complete printout	
		1. Complete printout without titles	
		2. No printout	
	16-20	I5	Thermodynamics print option:
			0. Print thermodynamics data for each group copied
			1. Do not print thermodynamics
4		(2A6)	
	1-12	2A6	Type of security classification:
			If UNCLASSIFIED, UNCLASSIFIED DATA will print at the top and bottom of each page. If NEITHER, no classification information will be printed. A blank card or any other alphanumeric information will cause the SECRET/RD clause to be printed at the top and bottom of each page

AFWL-TR-67-131, Vol IV

(continued)

CARD

NO.	COLUMNS	FORMAT	DESCRIPTION
		(5E12.8)	
5	1-12	E12.8	A temperature for conversion of data
	13-24	E12.8	A lowest density to convert at this temperature, first tape
	25-36	E12.8	A lowest density to convert at this temperature, second tape

etc.

NOTE: A negative density will cause the appropriate tape to be skipped for that temperature.

As many of card type 5 as required to specify all temperatures should be supplied. The last data card of a set should have -5000. as the temperature, signaling end-of-data

The code may be run using a deck setup as follows:

▽	ASG	X=2293
▽	ASG	A=(1st I/P tape)
▽	ASG	B=(2nd I/P tape)
	.	
	.	etc.
	.	
(3)▽	ASG	E=(output tape)
(1)▽F	ASG	2=100000
(2)▽F	ASG	3=100000
(2)▽F	ASG	4=100000
(2)▽F	ASG	7=100000
(2)▽F	ASG	8=100000
▽	XQT	CUR
	IN	X
	TRI	X
	TOC	
▽N	HDG	
▽	XQT	COMBO/A1

(DATA CARDS)

1. Drum 2 is required if any I/P tape is of ANHIST type
2. One scratch drum is required for each I/P tape of either DIAPHANOUS or ANHIST type. 3 being the first drum used, 4 the second, etc.
3. Of course, the output tape can be any logical unit not used for I/P

The COMBO Program was written by R. Korts of General Atomic.

AFWL-TR-67-131, Vol IV

SUBROUTINE ANDIMX(BIN,ROUT,IMX)
PROGRAM TO CONVERT HUEBNEIS TAPE TO AN ANY ACCEPTABLE FORMAT.

ORIGINALLY CODED BY LEW SCHALIT JANUARY, 1967
MODIFIED ON JULY 7, 1967, BY CHRIS IMLS, TO DELETE SPECIFIED
TEMPERATURE-DENSITY DATA

THIS PROGRAM DOES NOT ACHIEVE THE SAME RESULTS AS 'ANDIMX'
IT IS A MODIFICATION OF ANUIMX TO BE USED ONLY WITH COMBO.

THIS VERSION MODIFIED BY H. KOKIS, OCT, 1967 TO ACT AS A
SUBROUTINE TO COMBO PROGRAM.
MODIFICATIONS:

- (1) NO DATA CARDS READ BY ANDIMX. ANIN AND ANOUT ARE
SPECIFIED AS ARGUMENTS. (TITLE(1),I=1-52) IS
SPECIFIED IN DATA STATEMENT AS 'THIS PSEUDO-ANDIMX TAPE
GENERATED BY ANDIMX SUBROUTINE OF COMBO' FOLLOWED BY
BLANKS. NO THETA-RHO SETS ARE DELETED.
- (2) ALL PRINTER OUTPUT REMOVED EXCEPT FOR FRRON MESSAGES.
- (3) CERTAIN SECTIONS OF CODE RELATING TO DELETION OF THETA
RHO SETS HAVE BEEN REMOVED.

THIS PROGRAM USES ANHIST-OUTPUT-TAPES AS INPUT DATA.
THIS PROGRAM ASSUMES THE HUEBNER-MADE-AT-LASL ANN TAPE HAS BEEN
CONVERTED TO AN 1108 TAPE BY J. CLOWS ANHIST PROGRAM. THAT
PROGRAM READ ANN TAPES WITH ANY SIZE RECORD (E.G., EITHER A 35-
OR 37-WORD FIRST RECORD (AT EACH TEMPERATURE-DENSITY POINT),
AND VARIABLE SIZE SECOND RECORDS) AND PRODUCED LOGICAL OUTPUT
RECORDS WITH A MINIMUM OF 253 WORDS. THE FINAL RECORD OF THE
7094 TAPE WAS A 4-WORD ALL-ZERO RECORD. ANHIST CONVERTED THIS
TO A 253-ZERO-WORD RECORD.

THIS PROGRAM WILL PRODUCE AN OUTPUT TAPE WHICH HAS

- A) A FIRST RECORD OF: ANDIMX
- B) A SECOND RECORD OF: 60 IDENTIFICATION WORDS
- C) A SIGNAL RECORD OF: -7. (DATA FOLLOWS FOR A GIVEN
TEMPERATURE-DENSITY POINT
- D) A 38 WORD RECORD (CAYT IS WORD(3), RHO IS WORD(4))
- E) A RECORD WITH (NMAX+1) WORDS: NMAX, (MU(J), J=1, NMAX)

RECORDS (C,D, AND E) ARE THEN REPEATED. TEMPERATURES
AND DENSITIES ARE MONOTONIC. TEMPERATURES ARE LOWEST
AT THE BEGINNING OF THE TAPE. THE HIGHEST DENSITY FOR
A GIVEN TEMPERATURE IS THE FIRST DENSITY AT THAT

```

C          TEMPERATURE.
C
C          F) A SIGNAL RECORD OF: -5. SIGNIFIES END OF DATA.
C
C
C          CODE WILL READ ALL DATA ON THE ANHIST-OUTPUT-TAPE ANIN, THEN
C          PREVENT SPECIFIED (INPUT-CONTROLLED) TEMPERATURE-DENSITY DATA FROM
C          BEING WRITTEN ON THE ANDIMX-OUTPUT-TAPE ANOUT.
C
C          ***** NOTE *****
C          IF USE STANDARD INPUT UNIT=14, STANDARD OUTPUT UNIT=12, AND ALL
C          DATA ARE TO BE KEPT, TWO BLANK CARDS ARE REQUIRED TO END THE INPUT
C          SET AS SPECIFIED BELOW
C          *****
C
C          INPUT NEEDED IS AT LEAST SEVEN CARDS WITH THE FOLLOWING
C          INFORMATION
C
C          1) 52 TITLE WORDS (PUNCHED ON 5 CARDS WITH 12 WORDS IN 12A6
C             FORMAT ON FIRST 4 TITLE CARDS AND 4 WORDS IN 4A5 FORMAT ON
C             FIFTH TITLE CARD)
C          2) A CARD SPECIFYING THE INPUT TAPE UNIT AND THE OUTPUT TAPE UNIT
C             WRITTEN WITH A FORMAT OF (I2,IX,12)
C             IF THE INPUT TAPE UNIT SPECIFICATION FIELD IS BLANK, THE INPUT
C             TAPE IS ASSUMED TO BE ON UNIT 14
C             IF THE OUTPUT TAPE UNIT SPECIFICATION FIELD IS BLANK, THE OUTPUT
C             TAPE IS ASSUMED TO BE ON UNIT 12
C          3) IF DATA FOR ANY THETA-RHO SETS ARE TO BE DELETED, CARDS WITH
C             THE FOLLOWING INFORMATION MUST BE INPUT
C             A) TEMPERATURE FOR WHICH DATA ARE TO BE DELETED, AND
C                THE NUMBER OF RHO SETS WHICH ARE TO BE DELETED.
C                (IN FORMAT (F10.4,IX,12)).
C             B) IF NUMBER OF RHO SETS TO BE DELETED IS ZERO, ALL
C                DATA FOR THAT TEMPERATURE WILL BE DELETED.
C             C) IF NUMBER OF RHO SETS TO BE DELETED IS SPECIFIED,
C                CARDS (IN FORMAT (7E10.4)) CONTAINING THE DENSITIES
C                INVOLVED MUST FOLLOW.
C             D) A BLANK CARD SIGNIFIES END OF DATA. IF NO THETA-
C                RHO SETS ARE TO BE DELETED, A BLANK DATA CARD MUST
C                FOLLOW THE SIX CARDS DESCRIBED ABOVE IN 1) AND 2).
C
C          ***** WARNING *****
C          CATT ASSUMED .GE. 100
C          CATT ASSUMED TO BE CLOSE TO A MULTIPLE OF 100 EV
C          *****
C
C          DIMENSION TITLE(60),B1(14), INPUT(10),SIGNAL(7),B2(11),IB(13)
C          1,MU(2971),DTU(2971), MU2(2971), HB1(14), IBB(13), BB2(11)
C          2,THETA(1000),DENSITY(1000),CAYTE(1000)
C          DIMENSION CAYDEL(100), RHODEL(100,25), NMHO(100), ISAVE(100)
C          1 ,CAYGON(50), RHOGON(50,25)
C

```

AFWL-TR-67-131, Vol IV

```

REAL MU, MU2
INTEGER BIN, BOUT
INTEGER ANIN, ANOUT, DONE
C
C
DATA X/-1967./, SIGNAL/-1.,-2.,-3.,-4.,-5.,-6.,-7./, DONE/0/,
1 NEXT/1/, CATT/0./, MAXHMO/25/, AND MX/6HNDIMX/
DATA(TITLE(1), I=1, 11)/6HTHIS P, 6MSUDO-A, 6HNDIMX, 6HTAPE G, 6HENERAT
..6HED BY, 6HNDIMX, 6H SUDRU, 6HUTINE, 6HOF COM, 2HMO/, (TITLE(1)), I=12
..52/41.1H /
C
C B2(9) AND B2(10) ARE SET TO ZERO IN CASE ANHIST-OUTPUT-TAPES
C CONTAIN 35-WORD FIRST RECORDS (RATHER THAN 37-WORD FIRST RECORDS)
C AT EACH TEMPERATURE-DENSITY POINT.
DATA B2(9), B2(10)/2*0./
C
C M COUNTS THE NUMBER OF TEMPERATURES FOR WHICH DATA ARE TO BE
C DELETED.
C IDELET COUNTS THE NUMBER OF DENSITY SETS TO BE DELETED, PER
C TEMPERATURE.
C ISAVE(M) IS SET TO NONE IF NO DATA FOR CATTNO(M) IS TO BE WRITTEN
C ON THE ANDIMX-OUTPUT-TAPE ANOUT.
C KOUNT COUNTS TEMPERATURES FOR WHICH DATA ARE TO BE DELETED, AS
C THEY ARE LOCATED ON ANIN.
C J COUNTS RHOPTS, PER TEMPERATURE, FOR WHICH DATA ARE TO BE WRITTEN
C ON ANDIMX-OUTPUT-TAPE ANOUT
C KJ COUNTS TEMPERATURE-DENSITY SETS WRITTEN ON ANDIMX-OUTPUT-TAPE
C ANOUT
C JDELET IS SET TO NONE IF NO DELETIONS ARE TO BE MADE FOR A
C TEMPERATURE THAT IS READ FROM ANIN.
C
DATA M/0/, IDELET/0/, NONE/1/, ISAVE/100 * 0/, KOUNT/0/
DATA J/0/, KJ/1/
C
DATA MODIFY/6H THESE/, NOTUD/6H NO /, EPSILN/1.E-3/
DATA ISAVET/0/, JDELET/0/, NNMO/100*0/
C
EQUIVALENCE (ANIN, INPUT(1)), (ANOUT, INPUT(2)), (IMDONE, B1(1)),
1(CATT, B1(3)), (MU(1), DTU(1)), (AWT, B1(2)), (RHO, B1(4)),
2(CATTE, B2(11))
C
1 FORMAT (12A6)
C
2 FORMAT (12,1X,12)
C
ANIN=BIN
ANOUT=BOUT
C
REWIND ANOUT
REWIND ANIN
REWIND 2
C
WRITE(ANOUT) ANUMX, X, X
HEAD (ANIN) (TITLE(KM), KM=53, 60)
C
WRITE TAPE TITLE

```

AFWL-TR-67-131, Vol IV

```

WRITE (ANOUT) (TITLE(L2), L2=1,60)
400 CONTINUE
M= M + 1
C
410 CONTINUE
C IF (M.EQ.1), NORMAL RUN, NO DELETIONS
C IF (M.EQ.1) MODIFY = NOTDU
400 CONTINUE
C
C HEAD (ANIN) B1, B2, (B2(LC), LC=1,10)
C IF (H1(3).GT.TMX) GO TO 101
C
C CAYTE STORES THE TEMPERATURE TO BE WRITTEN ON ANOUT.
C CAYTE STORES THE TEMPERATURE READ FROM ANIN THAT WILL BE
C WRITTEN AS B2(11) ON ANOUT.
C
C CAYTE(KJ)=CAYT
C CAYTE = CAYT
C
C CAYTE= FLOAT (IFIX(CAYT/100. + .5) + 100 )
CAVEAT ASSUMES TEMPERATURE .GE. (100-EPSILON)
CAYTE= CAYT
C
415 CONTINUE
DO 9 JK=1,MAXRHU
C IF (MODIFY.EQ. NOTDU) GO TO 450
C IF (ICAYT.EQ. ISAVET) GO TO 434
C
C CHECK TO SEE WHETHER CAYT IS ONE FOR WHICH DATA ARE TO BE DELETED.
C
C DO 420 M2=1,M
C IF (ABS((CAYT-CAYDEL(M2))/CAYT) .LT. EPSILN) GO TO 430
420 CONTINUE
M2= M
JDELET= NONE
GO TO 450
C
C
C A TEMPERATURE FOR WHICH DATA ARE TO BE DELETED HAS BEEN LOCATED.
430 CONTINUE
KOUNT= KOUNT + 1
JDELET= 0
JDELET= 0
C IF (ISAVE(M2).EQ. NONE) GO TO 431
NNRHO= NNRHO(M2)
C
434 CONTINUE
C IF (JDELET.EQ. NONE .OR. JDELET.EQ. NNRHO(M2)) GO TO 450
435 CONTINUE
DO 440 M3=1,NNRHO
C IF (ABS((RHO-RHODEL(M2,M3))/RHO) .LT. EPSILN) GO TO 431
440 CONTINUE
GO TO 450
C

```

AFWL-TR-67-131, Vol IV

```

431 CONTINUE
C   DELETE THETA-RHO DATA
    ISAVET= CATT
    READ (ANIN) NOTUSE
    READ (ANIN) NOTUSE
    IDELET= IDELET + 1
    READ (ANIN) NOTUSE, NOTUSE, CATGON(KOUNT), RHOGON(KOUNT,IDELET)
    GO TO 14

C
450 CONTINUE
CAVEAT ASSUMES .LE. 25=MAXRHO DENSITIES AT EACH TEMPERATURE
    THETA(KJ)=CATT
    DENSITY(KJ)=RHO
    WRITE (2) B1,B,B2
C   ANUIMX OUTPUT TAPES ALL HAVE 30 WORD FIRST RECORDS
C   RECORD 1 SAYS ANUIMX
C
    J=J+1
C
    READ (ANIN) NOTUSE
    READ (ANIN) NMAX, (NOTUSE,I=1,NMAX),(DTU(I),I=1,NMAX)
C
    DO 5 I=1,NMAX
    U OF 1 = .3 + FLOAT(I-1) * .01
    MU(I)=RHO*DTU(I)*6.476E7/(CAYTEE*(U OF 1+.3)*AWT)
C
C   CONNECTION FOR INDUCED EMISSION STILL PRESENT.
5 CONTINUE
C
    ISAVET=CATT
    WRITE (2), NMAX,(MU(I),I=1,NMAX)
    KJ=KJ+1
C
14 CONTINUE
C
C
C
    READ (ANIN) B1,B,(B2(LC),LC=1,10)
    IF (IMDUNE.EQ. 0) GO TO 101
    IF (B1(3).GT.TMX)GO TO 101
C
    CAYTE(KJ)=CATT
    CAYTEE = CATT
    CATT = FLOAT (IFIX (CATT/100. +.5) * 100 )
    ICATT=CATT
    IF (ICATT.NE.ISAVET .AND. ISAVE(M2) .EQ. NONE) GO TO 460
    IF (ICATT.NE. ISAVET) GO TO 102
    IF (ISAVE(M2) .EQ. NONE) GO TO 431
    IF (MODIFY.EQ.NOTUO .OR. JOELET.EQ.NONE .OR. IDELET.EQ.NRHO(M2))
1      GO TO 49
    GO TO 435
C
101 CONTINUE
    DONE = NEXT
102 CONTINUE

```

AFWL-TR-67-131, Vol IV

```

C   WRITE OUT ALL RECORDS FOR A GIVEN TEMPERATURE ON THE ANDIMX OUTPUT
C   TAPE.
C
      IF (MODIFY .EQ. NOTDD) GO TO 461
      IF (JDELET.NE.NONE .AND. JDELET.NE.NNRHO(M2)) GO TO 600
461 CONTINUE
      DO / I=1,J
      BACKSPACE 2
      READ (2) NMAX2, (MU2(K),K=1,NMAX2)
      BACKSPACE 2
      BACKSPACE 2
      READ (2) BB1,IUB,BB2
      BACKSPACE 2
      WRITE (ANOUT) SIGNAL (I), X, X
      WRITE (ANOUT) BB1, IUB ,BB2
      WRITE (ANOUT) NMAX2, (MU2(K),K=1,NMAX2)
      7 CONTINUE
C
460 CONTINUE
      IF (ISAVE(M2) .EQ. NONE) BB1(3)=CAYDEL(M2)
      IF (IDONE.EQ.NEXT) GO TO 100
      REWIND 2
      J=0
      GO TO 415
99 CONTINUE
9 CONTINUE
C
      WRITE (6,15) THETA(KJ), (DENSITY(LM), LM=1,25)
15 FORMAT (5H CHANGE MAXHMO=25. THERE ARE 100 MANY DENSITIES AT THE
1A= , F10.0 /37H THE FOLLOWING DENSITIES WERE READ IN/(1P10E13.7))
499 CONTINUE
      CALL MEKK
      RETURN
100 CONTINUE
      IF (KOUNT .NE. M-1) GO TO 601
      WRITE (ANOUT) SIGNAL(5), X,X
      END FILE ANOUT
      REWIND 2
      REWIND ANIN
      REWIND ANOUT
      RETURN
C
C   E N D O F   E X I T S
C   A TEMPERATURE FOR WHICH DATA ARE TO BE DELETED HAS BEEN INPUT.
C   HOWEVER, THE INPUT DENSITY CANNOT BE FOUND ON THE ANIN TAPE.
600 CONTINUE
      WRITE (6,650) CAYDEL(M2), (RMODEL(M2,M5), M5=1,NNRHO)
650 FORMAT (64H1 A TEMPERATURE FOR WHICH DATA ARE TO BE DELETED HAS BE
1EN INPUT. / 61H HOWEVER, THE INPUT DENSITY CANNOT BE FOUND ON THE
2 ANIN TAPE / 11H CAYDEL = ,E12.6, 14H, RMODEL SET= ,E12.6,
3 (/37X,E12.6) )
      GO TO 499
C
601 CONTINUE
C   ALL TEMPERATURES ON ANIN HAVE BEEN CHECKED AGAINST INPUT TEMPERA-
C   TURES FOR WHICH DATA ARE TO BE DELETED. HOWEVER, NOT ALL THE
C   INPUT TEMPERATURES WERE FOUND. CHECK FOR INPUT ERROR.
      WRITE(6,651)
651 FORMAT(60H1 INPUT ENRON. ALL VALUES OF CAYTNO WERE NOT FOUND ON A
1ININ. )
      GO TO 499
      END

```

AFWL-TR-67-131, Vol IV

```

C      SUBROUTINE DENSER(MIN,MOUT,IMX)
C
C      DIAPHANOUS EDITOR
C*     ALL DENSER RUNS MUST WRITE ON A TAPE IN EVEN PARITY -
C*     THIS IS DONE BY SPECIFYING THE K AND E OPTIONS ON THE TAPE ASSIGN CARD
C      DAPHNE WAS ORIGINALLY MODIFIED BY L. R. NORRIS TO READ A DIAPHANOUS
C      TAPE AND MAKE THIS INTO A CONDENSED TAPE IN ORDER TO SAVE SPACE
C
C      DENSER WAS MODIFIED BY R. KORTS, OCT., 1967, TO BE A SUBROUTINE
C      TO COMBO.
C
C      THIS PROGRAM DOES NOT ACHIEVE THE SAME RESULTS AS 'DENSER'
C      IT IS A MODIFICATION OF DENSER TO BE USED ONLY WITH COMBO.
C
C      MIN, MOUT SPECIFIED AS SUBROUTINE ARGUMENTS.
C      IFILE=1
C      IWRITE=0
C      MENU=1
C
C      WRITE STATEMENTS, EXCEPT FOR ERROR MESSAGES, HAVE BEEN REMOVED.
C
C      VARIABLE NAME   MEANING
C
C      *** AUGLAS ***
C      DELEPJ (2000)   ENERGY CHANGE DURING A TRANSITION (EV)
C      DELEPS (1300)   IONIZATION POTENTIAL OF A STATE (EV)
C      EIN (15)        ENERGY OF GROUND STATE OF AN IONIZATION LEVEL
C      EPSD (1300)     SAME AS EPS IN DIAPHANOUS
C      FPC (3, 3, 3)   FRACTIONAL PERCENTAGE COEFFICIENT FOR TRANSITION BETWEEN
C                      SPLIT CONFIGURATIONS
C      IJU (2000)       IDENTIFICATION NUMBER OF INITIAL STATE ASSOCIATED WITH A
C                      TRANSITION
C      ISPLIT (15, 40) IDENTIFICATION OF A SPLIT CONFIGURATION
C      MERGED (15, 40) TRUE IF THIS CONFIGURATION IS THE AVERAGE OF SOME OTHER
C                      CONFIGURATIONS IN THE TABLE
C      MJU (2000)       NUMBER OF ELECTRONS IN LEVEL FROM WHICH ONE IS REMOVED IN
C                      THIS TRANSITION
C      NFD (1300)       SAME AS NF IN DIAPHANOUS
C      NJU (2000)       PRINCIPAL QUANTUM NUMBER (OR REDUCED QUANTUM NUMBER) OF
C                      ELECTRON REMOVED IN THIS TRANSITION.
C      NQ (6, 15, 40)  NUMBER OF ELECTRONS IN AN ELECTRON LEVEL IN A CONFIGURATION
C      NHMAX (15)       NUMBER OF CONFIGURATIONS AT AN IONIZATION LEVEL
C      NRSAVE (1300)    CONFIGURATION IDENTIFICATION OF A STATE
C      NSAVE (1300)     QUANTUM NUMBER OF OUTER ELECTRON, IF BEYOND TABLE, OF A
C                      STATE

```


AFWL-TR-67-131, Vol IV

C	QD (1500)	SAME AS G IN DIAPHANOUS
C	QWT (15, 40)	DEGENERACY OF A CONFIGURATION
C	WU (15, 40)	COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS CONFIGURATION
C	W1 (15, 40)	COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS CONFIGURATION
C	W2 (15, 40)	COEFFICIENTS IN QUADRATIC FOR DETERMINING ENERGY OF THIS CONFIGURATION
C	*** DIAPH2 ***	
C	UE (100)	SAME AS UEJ, INDEXED BY (NF + 1) FOR INITIAL STATE
C	UEJ (1600)	PARAMETER DETERMINING LINE WIDTH FOR A TRANSITION
C	C (10)	CONCENTRATION OF AN ELEMENT (ATOMS/ATOM)
C	COM (12)	COMMENT CARD IN FORMAT 12A6
C	UELE (100)	SUM OF UELI AT PREVIOUS IONIZATION LEVELS (EV)
C	UELEPJ (2200)	ENERGY CHANGE DURING A TRANSITION (EV)
C	UELEPS (1500)	IONIZATION POTENTIAL OF A STATE (EV)
C	UELI (100)	PRESSURE IONIZATION AT AN IONIZATION LEVEL (EV)
C	EPS (1500)	ENERGY OF A STATE, USUALLY REFERRED TO THE ENERGY OF THE GROUND STATE OF THE NEUTRAL ATOM (EV)
C	EPSPHM (1500)	ENERGY OF A STATE AFTER REDUCTION DUE TO PRESSURE IONIZATION (EV)
C	EX (100)	SAME AS EXJ, INDEXED BY (NF + 1) FOR INITIAL STATE
C	EXJ (1600)	PARAMETER DETERMINING LINE LOCATIONS FOR A TRANSITION
C	GAMBLK (10)	ARRAY OF GAMMA
C	IJ (2200)	IDENTIFICATION NUMBER OF INITIAL STATE ASSOCIATED WITH A TRANSITION
C	MAKEZ (1500)	IDENTIFICATION OF STATE TO BE ELIMINATED
C	MJ (2200)	NUMBER OF ELECTRONS IN LEVEL FROM WHICH ONE IS REMOVED IN THIS TRANSITION
C	NEW (2200)	ORIGINAL IDENTIFICATION NUMBER OF A TRANSITION
C	NF (1500)	NUMBER OF FREE ELECTRONS FOR A STATE
C	NJ (2200)	TOTAL QUANTUM NUMBER (OR REDUCED QUANTUM NUMBER) OF ELECTRON REMOVED DURING A TRANSITION
C	NLAST (10)	INDEX NUMBER OF LAST STATE IN TABLE FOR AN ELEMENT
C	PHI (2200)	STRENGTH OF EDGE DUE TO THIS TRANSITION
C	Q (1500)	DEGENERACY OF A STATE
C	R (1500)	FIRST PROPORTIONAL TO LOG POPULATION AND THEN TO POPULATION OF A STATE
C	RS (10)	FIRST MAXIMUM R, THEN SUM OF R'S, FOR AN ELEMENT
C	SMALLP (1500)	POPULATION OF A STATE
C	TESTJ (2200)	LOWEST VALUE OF MU AT WHICH THE ABSORPTION COEFFICIENT IS AFFECTED BY THE LINE SERIES FOR THIS TRANSITION
C	TKULK (10)	ARRAY OF KI
C	U (5)	COEFFICIENTS IN GAUSSIAN INTEGRATION
C	V (5)	COEFFICIENTS IN GAUSSIAN INTEGRATION
C	UOLD (2200)	LOCATION OF EDGE DUE TO THIS TRANSITION (EV/EV)
C	UPRM (2200)	LOWEST EDGE TO APPROXIMATE HIGH LINES (EV/EV)
C	W (10)	ATOMIC WEIGHT OF AN ELEMENT
C	Z (10)	ATOMIC NUMBER OF AN ELEMENT
C	*** DIAPER ***	
C	AMU (1000)	ABSORPTION COEFFICIENT AT A PARTICULAR VALUE OF MU(.6 .LE. MU .LE. 15) (PER CM)
C	BMU (1000)	BOTTOM OF EDGE OCCURRING AT A PARTICULAR VALUE OF MU(MU .GT. 15) (PER CM)
C	JD (12)	COMMENT CARD

AFWL-TR-67-131, Vol IV

```

C      TMU (1000)      TOP OF EDGE OCCURRING AT A PARTICULAR VALUE OF U (U>15) (PER
C                      CM)
C      *** SPECIHA ***
C      DEFECT (100, 4) QUANTUM DEFECT INDEXED BY THE IONIZATION LEVEL AND L + 1
C      DELEPJ (3500)   SAME AS DELEPJ IN DIAPHANOUS
C      EPSU (1750)     SAME AS EPS IN DIAPHANOUS
C      DELEPS (1750)   SAME AS DELEPS IN DIAPHANOUS
C      IJU (3500)      SAME AS IJ IN DIAPHANOUS
C      IONZC (100)     ZCOHE FOR AN IONIZATION LEVEL
C      L (19)          L FOR AN ELECTRON LEVEL
C      LIN (10)        LEVEL AT WHICH AN ELECTRON IS BEING ADDED
C      LOUT (10)       LEVEL AT WHICH AN ELECTRON IS BEING REMOVED
C      MJU (3500)      SAME AS MJ IN DIAPHANOUS
C      N (19)          N FOR AN ELECTRON LEVEL
C      NE (92, 19)     NUMBER OF ELECTRONS PER ELECTRON LEVEL IN THE GROUND STATE
C                      OF AN IONIZATION LEVEL
C      NFD (1750)      SAME AS NF IN DIAPHANOUS
C      NJU (3500)      SAME AS NJ IN DIAPHANOUS
C      QU (1750)       SAME AS Q IN DIAPHANOUS
C
C      REAL LONG
C      REAL LENGTH
C      INTEGER NEWID, BLANK
C      DIMENSION NEWID(12)
C      DIMENSION IU(12), A(20), B(2), U1(150), GARY(150), AMU(150),
1      DAVE (150), DUMMY(30)
C      DIMENSION THETA(5000), XGAMMA(5000), RHO(5000)
C      DIMENSION U2(1500), BMU(1500), TMU(1500), COMP(10), IZ(10)
C      DATA DENSOR/6H UENSER /
C      DATA IFILE/1/, IWHIT/0/, MENU/1/
C      DATA INDEXA / 1/
C      DATA LHN / 1 / , DUMMY / 30*0. /
C      DATA IFILE1 / 0 / , BLANK / 6H /
C
C      1 CONTINUE
C
C      MENU      IF (MENU .EQ. 0) ANOTHER SAUY TAPE IS READ
C                IF (MENU .NE. 0) THE RUN TERMINATES
C      IFILE     IF (IFILE .NE. 0) NO END OF FILE MARKER IS PUT ON AFTER
C                THIS DIAPHANOUS TAPE HAS BEEN READ
C                IF (IFILE .EQ. 0) AN END OF FILE MARKER IS PUT ON AFTER
C                THIS TAPE HAS BEEN READ
C      IWHIT     IF (IWHIT .NE. 0) THE DIAPHANOUS INPUT TAPE IS EDITED
C                IF (IWHIT .EQ. 0) THE DIAPHANOUS INPUT TAPE IS NOT EDITED
C
C      MIN       IS THE INPUT TAPE UNIT. MIN MUST BE READ FOR EVERY
C                INPUT TAPE TO BE READ
C
C      ALL DENSER TAPES MUST BE WRITTEN IN 556 BPI -
C      THIS IS ACCOMPLISHED BY SPECIFYING THE H OPTION ON THE TAPE
C      ASSIGNMENT CARD
C
C      READ (5, 8000) NZ, (IZ(K), COMP(K), K=1, NZ)

```

AFWL-TR-67-131, Vol IV

```

8000 FORMAT (12, 8X, 7(12, 2X, F6.4))
      READ (5,8005) (NEWID(I),I=1,12)
8005 FORMAT (12A6)
      REWIND MIN
      IRCD = 0
      NRCD = 0
      IDMU2 = 1500
C
      IF (IWRIT .NE. 0)
        1WRITE (6,9990)
        READ(MIN) A(1)
        IF (A(1))25,999,999
      25 IF(A(1)+1.) 999,2500,999
      2500 CONTINUE
        NRCD = NRCD + 1
        READ (MIN) (ID(I),I=1,12)
        IF (NEWID(1) .EQ. BLANK) GO TO 27
        DO 28 I=1,12
          ID(I) = NEWID(I)
      28 CONTINUE
      27 CONTINUE
        IF (IFILE1 .NE. 0) GO TO 26
        WRITE (MOUT,3) DENSON, (ID(K),K=1,12), NZ, (COMP(K),IZ(K),K=1,NZ)
      3 FORMAT (13A6/12,(F6.4,12))
        IRCD = IRCD + 2
      26 CONTINUE
        NRCD = NRCD + 1
        READ(MIN) A(1)
        IF (IWRIT .NE. 0)
          1WRITE (6,9995) A(1)
          IF(A(1)+2.) 999,3002,999
      3002 CONTINUE
        NRCD = NRCD + 1
      32 READ (MIN) (B(I),I=1,2)
        IF(B(1).GT.TMX) GO TO 155
        THETA (INDEXA)=B(1)
        XGAMMA(INDEXA)=B(2)
        J = 2
        M = 6
        ULAST1 = 0.
        ALAST1 = 0.
        U2(J) = 0.
        GANY(1) = 0.
        DAVE(1) = 0.
        TK = U(1)
        GAMMA = B(2)
        NRCD = NRCD + 1
      34 READ(MIN) A(1), A(2)
        UX = A(1)
        UY = A(2)
        NRCD = NRCD + 1
        IF(UX + 3.) 35,65,35
      35 IF(UX + 4.) 40,75,40
      40 IF(UX + 6.) 55,45,55
      45 READ(MIN) A(1), A(2)

```

AFWL-TR-67-131, Vol IV

```

      IF (1WHIT.NE. 0)
1WRITE (6,9000) A(1),A(2)
      U1(M) = A(1)
      AMU(M) = A(2)
      M = M+1
      UX = A(1)
      UY = A(2)
      NRCD = NRCD + 1
      IF (UX .LE. 0.) GO TO 4500
      ULAST = UX
      ULAST1 = UX
      ALAST1 = UY
      AKLAST = UY
      GO TO 34
4500 CONTINUE
      NEWIND MIN
      CALL EXIT
55 U1(M) = UX
      AMU(M) = UY
      M = M+1
      GO TO 34
65 HEAD(MIN) A(1), A(2), A(3)
      UX = A(1)
      UY = A(2)
      UZ = A(3)
      NRCD = NRCD + 1
      IF (UX + 4.) 70,74,70
70 U2(J) = UX
      BMU(J) = UY
      TMU(J) = UZ
      J = J+1
      IF (J-1UMU2) 65,65,72
72 CONTINUE
73 HEAD(MIN) A(1), A(2), A(3)
      UX = A(1)
      UY = A(2)
      UZ = A(3)
      NRCD = NRCD + 1
      IF (UX + 4.) 73,74,73
74 ULAST=U2(J-1)
      AKLAST=TMU(J-1)
75 CONTINUE
      M = M - 1
      IF (1WHIT.NE. 0)
1WRITE (6,9980) (U1(K),K=6,M)
      IF (1WHIT.NE. 0)
1WRITE (6,9982) (AMU(K),K=6,M)
      IF (DAVE(1).NE. 0.) CALL MERR
      HEAD(MIN) (A(JM), JM=1,8)
4 FORMAT (1H)
      RMU(INDEXA)=A(2)
      INDEXA=INDEXA+1
      IF (U2(2).EQ. 0.) GO TO 76
      J = J - 1
      IF (1WHIT.NE. 0)

```

AFWL-TR-67-131, Vol IV

```

1WRITE (6,9984) (U2(K),K=2,J)
IF (1WRITE.NE. 0)
1WRITE (6,9986) (BMU(K),K=2,J)
IF (1WRITE.NE. 0)
1WRITE (6,9988) (TMU(K),K=2,J)
76 CONTINUE
WRITE (MOUT,2) J, M, ULAST1, ALAST1, B(1), B(2), (A(JM),JM=1,20),
1 (U1(K),K=6,M), (AMU(K),K=6,M), (U2(K),K=2,J),
2 (BMU(K),K=2,J), (TMU(K),K=2,J)
NRCD = NRCD + 1
IRCD1 = 11 + 2 * (M - 5) + 3 * (J - 1)
IRCD2 = IRCD1 / 14
IRCD14 = IRCD2 * 14
IF (IRCD1.GT. IRCD14) IRCD2 = IRCD2 + 1
IRCD = IRCD + 1 + IRCD2
READ (MIN) A(1)
IF (1WRITE.NE.0) WRITE (6,9996) A(1)
UX = A(1)
NRCD = NRCD + 1
IF(UX + 2.) 77,32,999
77 IF(UX + 5.) 999,155,999
155 CONTINUE
C
NRCD = NRCD + 1
C THE ABOVE RECORD COUNT INCLUDES THE EOF RECORD
IFILE1 = IFILE
LONG = FLOAT(NRCD) * .0625
LENGTH = FLOAT(IRCD) * .0658
I = -5
WRITE (MOUT,2) I, LKN, DUMMY
IRCD = IRCD + 2
8007 FORMAT (50H THE DIAPHANOUS TAPE HAS BEEN CONDENSED SUCCESSFULLY FR
10M , F10.2,10H FEET WITH, 16, 21H PHYSICAL RECORDS TO ,F9.2,10H0F
2LET WITH,15,18H PHYSICAL RECORDS.)
ENDFILE MOUT
IF (MENU.EQ. 0) GO TO 1
REWIND MIN
REWIND MOUT
INDEXA=INDEXA-1
RETURN
999 CONTINUE
WRITE (6,9901)
9901 FORMAT (53H THERE IS AN ERROR IN THIS RUN. MERR HAS BEEN CALLED.)
CALL MERR
C
***** F O R M A T S *****
C 15 FORMAT (42H 2ND SET OF DIAPHANOUS DATA HAS MORE THAN 13, 19H ENTH
21E5, THETA = F7.2, 8H, GAMMA=1PE10.5,20H, NO GOOD ABOVE U = UPF6.
31)
9000 FORMAT(9H0 ULAST = 1PE15.7, 3X 8HAKLAST = E15.7)
9002 FORMAT(1P10E12.5)
9980 FORMAT(10H0 U1 ARRAY // (1P10E12.5))
9982 FORMAT(11H0 AMU ARRAY // (1P10E12.5))
9984 FORMAT(10H0 U2 ARRAY // (1P10E12.5))
9986 FORMAT(11H0 BMU ARRAY // (1P10E12.5))
9988 FORMAT(11H0 TMU ARRAY // (1P10E12.5))
9990 FORMAT(1H1)
2 FORMAT (214, 15E9.4, / (14E9.4))
9995 FORMAT(10H SIGNAL = F6.1)
9996 FORMAT(10H1 SIGNAL = F6.1)
9997 FORMAT(10H ZBAR=F6.4, 1X 4HMO=1PE11.5, 2X 2HP=E11.5, 2X 2HE=E11.5,
1 2X 5HMO5=E11.5, 2X 6HPLNK=E11.5, 2X 5HEION=E11.5, 2X 5HEGAM=
20PF9.3)
9998 FORMAT(9H0 THETA = 1PE15.7, 3X 7HGAMMA = E15.7)
9999 FORMAT(1H0, 12A6)
END

```

AFWL-TR-67-131, Vol IV

	SUBROUTINE RHOUE(IIP,RHO,R1,R2)	RDT	10
C		RDT	20
C	DETERMINES THE UPPER (R2) AND LOWER (R1) RANGES FOR RHO ON TAPE	RDT	30
C	IIP.	RDT	40
C		RDT	50
	DATA RMAX/1.E30/	RDT	65
	DIMENSION RHO(1)	RDT	60
	R2=RHO(IIP)	RDT	70
	IF(IIP.GT.1)GO TO 9	RDT	80
6	R1=RMAX	RDT	90
	RETURN	RDT	100
9	I1=IIP	RDT	110
8	I1=I1-1	RDT	120
	IF(I1.LT.1)GO TO 6	RDT	130
	IF(RHO(I1).LT.0.)GO TO 8	RDT	140
	R1=RHO(I1)	RDT	150
	RETURN	RDT	160
	END	RDT	500

	SUBROUTINE SHEAD(1)	SHD	10
C		SHD	20
C	PRINTS APPROPRIATE CLASSIFICATION HEADING	SHD	30
C		SHD	40
	GO TO (10,20,30),1	SHD	100
10	WRITE(6,200)	SHD	110
	GO TO 30	SHD	120
20	WRITE(6,201)	SHD	130
30	RETURN	SHD	140
200	FORMAT(1H0,32X,67H*** SECRET / RESTRICTED DATA	SHD	150
	• GROUP 1 ***)	SHD	160
201	FORMAT(1H0,47X,40H*** UNCLASSIFIED DATA ***)	SHD	170
	END	SHD	500

DIANTC: A DIANE TRANSFER PROGRAM (TAPE TO CARDS
OR TAPE)

The DIANTC program was coded to read a DIANE binary data tape file and do one of two input-controlled operations: (1) punch DIANE data cards or (2) write a DIANE BCD card-image data tape. The card image tape is written in even parity at 556 BPI in IBM-compatible BCD format, and it may contain several files (written by repeated executions of the DIANTC program).

The DIANTC program contains five formatted (BCD) write statements. They and their respective formats are as follows, where MOUT is defined as the logical tape unit on which the output tape is mounted:

```
WRITE(MOUT, 3) IDA
3  FORMAT(I12)
WRITE(MOUT, 4)(ID(II), II=1, 12)
4  FORMAT(12A6)
```

The two above write statements are used once to write identification data at the beginning of each file on the DIANTC output tape. The named variables are discussed below or are clear from context.

```
WRITE(MOUT, 5)HNUT, FNWD
5  FORMAT(6E12. 7)
```

The above write statement is used to write the first of two records preceding each frequency group.

Name variables are discussed below.

```
WRITE(MOUT, 7)X1, X2, IX
7  FORMAT(2E12. 7, 49X, I3, 4H  0)
```

The above write statement is used to write the second of two records preceding each frequency group.

```
WRITE(MOUT, 6)((BUFS(IWD), IWD=KMIN, KMAX), IX, KK)
6  FORMAT(6E12. 7, 1X, I3, I4)
```

The above write statement is used repetitively to write the data for each frequency group.

The code punches data cards, if it does not write a card-image tape, in the same manner and with the same formats that it uses to write the card-image tape. One may edit any file of the DIANTC card image output tape by using the EDIANE program, which is in FORTRAN IV language. One may also use either the output data cards or the output card image tape to write a binary DIANE-format tape using the program DIANTC, which is in FORTRAN IV language.

Input for DIANTC

DIANTC requires no card input. It is a subroutine with two input parameters, the meaning of which follows:

PARAMETER	VALUE	MEANING
UNIT	Variable	UNIT specifies the logical unit on which the input DIANE binary tape is mounted
IBIN0	0	If IBIN0 = 0, the code assumes the input DIANE tape is written in binary with a binary identification record (ID array), and it punches cards
	1	If IBIN0 = 1, the code assumes the input DIANE tape is written in binary with a BCD (formatted) identification record, and it punches cards
	>1	If IBIN0 > 1 the code assumes the input DIANE tape is written in binary with a binary identification record, and it does one of two things:
	2	1. If IBIN0 = 2, the code writes a BCD card image tape on unit MOUT = IBIN0 + 10 = 12
	>2	2. If IBIN0 > 2, the code writes two BCD card image tapes on units MOUT = IBIN0 + 10 and MOUT2 = MOUT + 1

The code rewinds the input DIANE binary tape and the output BCD tape, if written, only when $IBIN0 \leq 2$.

AFWL-TR-67-131, Vol IV

```

SUBROUTINE DIANTC(M,N)
C
C NO EXTRA DATA CARDS ARE REQUIRED TO RUN DIANTC
C
C OUTPUT CARD FORM IS AS FOLLOWS
C
C 1      112      1 - 12      10A      12-DIGIT IDENTIFICATION
C                                     NUMBER
C 2      12A6     1 - 72      10        HEADING FROM IDENTIFICATION
C                                     (HEADING) CARD
C 3      E12.7    1 - 12      MNUT      NUMBER OF FREQUENCY GROUPS
C 3      E12.7    13 - 24     FNWD      NUMBER OF WUMUS/FREQUENCY
C                                     GROUP
C 4      E12.7    1 - 12      X1        IF X1 .LT. 0., INDICATES
C                                     THAT THE GNET ABSORPTION
C                                     COEFFICIENTS FOLLOW
C                                     IF X1.GT.0., THEN X1 IS THE
C                                     VALUE OF THE LOWER END
C                                     OF A FREQUENCY BAND
C                                     NUMBER OF TEMPERATURES
C 4      E12.7    13 - 24     X2
C 5      E12.7    1 - 12      BUFS(1WD), LN THETA
C                                     1WD=1
C 5      E12.7    13 - 24     BUFS(1WD), NUMBER OF 1AU'S
C                                     1WD=2
C 5      6E12.7   1ST CARD: BUFS(1WD), LN KH, LN KP, LN TAU,
C                                     5 - 72 1WD=3,NWD LN KH, LN KP,...
C                                     SUCCEEDING
C                                     CARDS:
C 12     75 - 76      1X        2-DIGIT SEQUENCING NUMBER;
C                                     INDICATES THE ORDER
C                                     NUMBER OF EACH FREQUENCY
C                                     GROUPING SET
C 13     78 - 80      KK        3-DIGIT SEQUENCING NUMBER;
C                                     INDICATES CARD NUMBER
C                                     WITHIN A PARTICULAR
C                                     FREQUENCY GROUPING SET
C
C DIMENSION ID(12), BUFS(1000)
C DIMENSION IDENT(2)
C DATA IDENT/6MBINARY,5M BCD /
C INTEGER UNIT
C IBINU = N
C UNIT = M
C 3 FORMAT (112)
C 4 FORMAT (12A6)
C 5 FORMAT (6E12.7)
C 6 FORMAT(6E12.7, 1X 13, 14)
C 7 FORMAT(2E12.7, 49X 13, 4M U)
C 8 FORMAT(38H PUNCHING IS COMPLETED NO. OF CARDS = ,15)
C 7004 FORMAT (46H THE CARD COUNT DOES NOT INCLUDE THE RUN CARD.)
C 7000 FORMAT (112,12A6)
C 7001 FORMAT (1H0,25X,20H DIANTC, RUN ON UNIT,13,6H WITH ,A6,45H TAPE 10

```

AFWL-TR-67-131, Vol IV

```

IDENTIFICATION: COMPLETED SUCCESSFULLY./IM1)
  IF (IBINU.EQ. 1) READ (UNIT,7000) IDA, (ID(I), I=1,12)
  IF (IBINU.EQ. 0) READ (UNIT) IDA, (ID(I), I=1,12)
C
C  IF (IBINU.GT.1) WRITE CARD IMAGE (BCD) TAPE ON UNIT MOUT=IBINU+10
C  IF (IBINU.GT. 2) WRITE BCD (CARD IMAGE) TAPES ON UNITS
C  MOUT = IBINU+10 AND MOUT2 = MOUT+1.
C
  IF (IBINU.GT. 1) GO TO 100
  PUNCH 3, IDA
  PUNCH 4, (ID(I), I=1,12)
101 CONTINUE
  READ (UNIT) MNUT, FNWD
  IF (IBINU.GT. 1) GO TO 102
  PUNCH 5, MNUT, FNWD
103 CONTINUE
  NWD = FNWD
  NVECES = MNUT + 1.
  IF (NWD.GT. 1000) CALL DUMP
  XX=      FNWD/6.
  KK=      NWD/6
  AX=      KK
  IF (XX.GT. AX) KK= KK+ 1.
  DO 20 I = 1, NVECES
  IX = 1
  READ (UNIT) X1,X2
  IF (IBINU.GT. 1) GO TO 104
  PUNCH 7, X1, X2, IX
  GO TO 105
104 CONTINUE
  WRITE (MOUT,7) X1, X2, IX
  IF (MOUT2.GT.13) WRITE (MOUT2,7) X1, X2, IX
C
105 CONTINUE
  READ (UNIT) (BUFS(IWD), IWD = 1, NWD)
  KMAX = 0
  DO 10 K=1,KK
  KK = K
  KMIN = KMAX + 1
  KMAX = KMAX + 6
  IF (IBINU.GT. 1) GO TO 106
  PUNCH 6, ((BUFS(IWD), IWD=KMIN,KMAX), IX, KK)
  GO TO 107
106 CONTINUE
  WRITE (MOUT,6) ((BUFS(IWD),IWD=KMIN,KMAX), IX, KK)
  IF (MOUT2.GT.13) WRITE (MOUT2,6) (BUFS(IWD),IWD=KMIN,KMAX), IX,
1  KK
C
107 CONTINUE
10 CONTINUE
20 CONTINUE
  NOC = NVECES * (KK+1) + 3
  IF (IBINU.GT. 1) GO TO 120
  WRITE(6,8) NOC
  WRITE (6,7009)

```

AFWL-TR-67-131, Vol IV

```

REWIND UNIT
WRITE (6,7001) UNIT, IDENT(1BINU*1)
RETURN

C
C
100 CONTINUE
MOU1=      1BINU + 10
MOU12=     MOU1 + 1
READ (UNIT) IDA, (ID(11), 1=1,12)
WRITE (MOU1,3) IDA
IF (MOU12.GT.13) WRITE (MOU12,3) IDA
WRITE (MOU1,4) (ID(11), 11=1,12)
IF (MOU12.GT.13) WRITE (MOU12,4) (ID(11),11=1,12)
GO TO 101

C
102 CONTINUE
WRITE (MOU1,5) MNUT, FNWD
IF (MOU12.GT.13) WRITE (MOU12,5) MNUT, FNWD
GO TO 103

C
120 CONTINUE
END FILE MOU1
IF (MOU12.GT.13) END FILE MOU12
IF (1BINU.EQ. 2) REWIND UNIT
IF (1BINU.EQ. 2) REWIND MOU1
WRITE (6,7002) UNIT, MOU1
7002 FORMAT (28HDIANTC, INPUT TAPE ON UNIT ,13, 25H, COMPLETED SUCCESS
1FULLY. / 44H A BCD DATA TAPE WAS WRITTEN ON UNIT MOU1 = ,13)
IF (MOU12.GT.13) WRITE (6,7003) MOU12
7003 FORMAT (64H A SECOND COPY OF THE BCD DATA TAPE WAS WRITTEN ON UNIT
1 MOU12 = ,13)
WRITE (6,7004) (ID(11),11=1,12)
7004 FORMAT (14H 10 RECORDS IS ,5A, 12A6)
RETURN
END

```

AFWL-TR-67-131, Vol IV

```

C      SUBROUTINE DIANCT(M,N)
C      *****WARNING - THIS PROGRAM ALLOWS ONLY 17 DENSITY SETS PER *****
C      THETA SET, 25 THETA SETS PER FREQUENCY GROUP.
C      DIMENSION THETAK(25), NUMBER(17), JHHO(25,17)
C      THE LNTHIK ARRAY STORES LN THETAK
C      REAL LNTHIK(25)
C
C      DATA TEST/1.E-3/, LN/0/, KOUNT/1/, XX2/0./
C
C      ASSUMES ALL DELETIONS AT A GIVEN THETA ARE SPECIFIED IN ORDER OF
C      DECREASING RHO. THAT IS, THE FIRST RHO SET TO BE DELETED AT
C      A GIVEN THETA MUST BE THAT FOR THE HIGHEST RHO.
C
C      DESCRIPTION OF INPUT CARDS CONTROLLING DELETIONS OF THETA-RHO
C      POINTS
C
C      IF BLANK INPUT CARD IS USED, NO DELETIONS, DO NORMAL DIANCT RUN.
C      OTHERWISE READ DELETION CARDS UNTIL A BLANK CARD IS READ.
C
C      READ ONE INPUT CARD PER MODIFIED THETA SET .
C
C      COLUMNS  FORMAT  VARIABLE NAME  MEANING
C      1-10      E10.6   THETAK(1C)    TEMPERATURE AT WHICH DATA IS TO BE
C      DELETED
C      13-14     12      NM             NUMBER OF DENSITY SETS TO BE
C      DELETED

```

```

C                                     IF (THETAK(IC).EQ.-THETAK(IC)),
C                                     DELETE ENTIRE THETA-RHO SET
C                                     (NUMBER OF RHO SETS TO BE
C                                     DELETED MUST BE SPECIFIED)
C                                     IF (THETAK(IC).EQ.0., IC.EQ.1),
C                                     DO NOT DELETE ANY POINTS
C                                     IF (THETAK(IC).EQ.0., IC.GT.1),
C                                     DO NOT DELETE ANY MORE POINTS
C                                     1ST,2ND,...,JTH,...,NM-TM NUMBERED
C      17-16, 22(12, JRHO(IC,J) RHO(IC) SETS TO BE DELETED
C      20-21, 1X) (IF ENTIRE THETA SET IS TO BE
C      ... DELETED, THESE NEED NOT BE
C      62-63 SPECIFIED)
C
C      DIMENSION IDENT(2)
C      DATA IDENT/6MBINARY,5M BCD /
C      INTEGER UNIT
C      UNIT = M
C      IBINO = N
C      MIN= 5
C      IF (IBINO .LE. 1) GO TO 400
C      MIN= IBINO + 10
C      IBINU= 0
C      N= 0
C      400 CONTINUE
C      4 FORMAT (12A6)
C      5 FORMAT (6E12.7)
C      6 FORMAT (112)
C      7000 FORMAT (112,12A6)
C      7001 FORMAT (1MU,26X,19MUIANCT, MUN ON UNIT,13.6M WITH ,A6.45M TAPE IDE
C      INTIFICATION, COMPLETED SUCCESSFULLY./1H1)
C      7002 FORMAT (28M NWU.GT.1000 .OK. HNU.GE.0. )
C
C      WRITE (6,7004)
C      7004 FORMAT (43H1BEGIN DIANCT. THE FOLLOWING DATA IS INPUT ,//)
C
C      READ INPUT CARDS CONTROLLING DELETIONS OF THETA-RHO POINTS.
C      DO 700 IC=1,25
C      READ (5,7003) THETAK(IC), NM, (JRHO(IC,J), J=1,NM)
C      7003 FORMAT (E10.6, 2X, 12, 2X, 17(12,1X) )
C      NUMBER(IC)= NM
C      IF (THETAK(IC)) 51,701,52
C      51 CONTINUE
C      XX2= XX2 + 1.
C      LN= LN + 2
C      52 CONTINUE
C      LN= LN + 3 * NUMBER(IC)
C      LNTHTK(IC)= ALOG(ABS(THETAK(IC)))
C
C      WRITE (6,7005) IC, THETAK(IC), LNTHTK(IC), NM, (JRHO(IC,J),
C      J=1,NM)
C      7005 FORMAT (10H0THETA SET ,12 /10H THETAK = ,E12.6, 11H, LNTHTK = ,
C      1 E12.6, 23H, DELETE THE FOLLOWING ,12, 14H RHO SET(S) = ,
C      2 10(12,2X) / (84X, 10(12,2X)) )
C
C      700 CONTINUE

```

```

      IC=      25
701 CONTINUE
C
C      IC1 COUNTS THE NUMBER OF TEMPERATURES FOR WHICH DENSITY SETS ARE
C      TO BE REMOVED.
      IC1=      IC - 1
C
      HEAD (MIN,6) IDA
      HEAD (MIN,4) (ID(1), I=1,12)
      IF (IBINO .EQ. 1) WRITE (UNIT,7000) IDA, (ID(1), I=1,12)
      IF (IBINO .EQ. 0) WRITE (UNIT) IDA, (ID(1), I=1,12)
      HEAD (MIN,5) MNUT, FNWD
      NWU=      IFIX(FNWD + .5)
      IF (MIN .EQ. 5) GO TO 403
      XX=      FNWD/6.
      KX=      NWU/6
      AX=      KX
      IF (XX .GT. AX) KX= KX+1
403 CONTINUE
C      LN IS THE TOTAL NUMBER OF CELLS IN THE BUFS ARRAY THAT ARE TO BE
C      REMOVED.
      NEWNWU=    NWU - LN
      FFNWU=      FLOAT(NEWNWU)
      WRITE (UNIT) MNUT, FFNWU
      WRITE (6,7006) LN, NEWNWU
7006 FORMAT (55H0LN IS THE TOTAL NUMBER OF POINTS TO BE REMOVED. LN =
1, 14,23H. NEWNWU = NWU - LN = , 14)
      NVECES = MNUT + 1.
      IF (NWU.GT.1000) GO TO 40
      DO 200 I = 1, NVECES
      HEAD (MIN,5) X1,X2
      X2=      X2 - XX2
      WRITE (6,7012) XX2,X2
7012 FORMAT (118H1XX2 IS THE TOTAL NUMBER OF TEMPERATURE SETS TO BE REM
MOVED. X2 IS THE NUMBER OF TEMPERATURE SETS PER FREQUENCY GROUP. /
2/H XX2 = ,F12.3, 10X, 6H X2 = ,F12.3)
      WRITE (UNIT) X1,X2
      IF (MIN .NE. 5) GO TO 401
      HEAD (MIN,5) (BUFS(IWD),IWD=1,NWU)
      GO TO 402
401 CONTINUE
      KMAX=      0
      DO 404 K=1,KX
      KMIN=      KMAX + 1
      KMAX=      KMAX + 6
      HEAD (MIN,409) ((BUFS(IWD),IWD=KMIN,KMAX), IX, KK)
409 FORMAT (6E12.7, 1X, 13, 14)
404 CONTINUE
402 CONTINUE
C
      I1=      1
      I2=      1
      NOWNWU=    NWU
      IF (LN .EQ. 0) GO TO 450
C

```

AFWL-TR-67-131, Vol IV

```

710 CONTINUE
C   FIND THETAK(I1), I1=1,IC1
C
      WRITE (6,7014) LNTHIK(I1), BUFS(I2), I2
7014 FORMAT (32H DIANCY IS COMPARING LNTHIK = ,E12.6, 18H WITH BUFS
1(I2) = , E12.6, 8H, I2 = ,I4)
      IF (ABS( (LNTHIK(I1)-BUFS(I2))/BUFS(I2)) .LT. TEST) GO TO 720
      I2LAST= I2
      I2= I2 + (IFIX(BUFS(I2+1)+.5)) * 3 + 2
C
C   CHECK THE VALUE OF I2. THE FOLLOWING IF TEST SHOULD BE PASSED
C   ONLY IF THETA(I1) IS INPUT INCORRECTLY, OR IF THE BUFS ARRAY
C   CARDS ARE OUT OF ORDER.
      IF (I2.GT.(NWD-1) .OR. I2.LT.(I2LAST + 5)) GO TO 999
      GO TO 710
C
720 CONTINUE
C   THETAK(I1) HAS BEEN LOCATED AS BUFS(I2)
      WRITE (6,7011) THETAK(I1), I2
7011 FORMAT (14H THETAK(I1) = ,E12.6,39H HAS BEEN LOCATED AS BUFS(I2),
1 I2 = ,I4)
      IF (THETAK(I1) .GT. 0.) GO TO 761
      ISKIP= IFIX(BUFS(I2+1) + .5) * 3 + 2
      I3= I2
      GO TO 751
C
761 CONTINUE
C   THETAK .GT. 0., DELETE WHO SET(S), ONE AT A TIME
C
      IF (NUMBER(I1) .GT. IFIX(BUFS(I2+1) + .5)) GO TO 999
      ISKIP= 3
      BUFS(I2+1)= FLOAT(IFIX(BUFS(I2+1)+.5) - NUMBER(I1))
      WRITE (6,7013) THETAK(I1), BUFS(I2 + 1)
7013 FORMAT (14H FOR THETAK = , E12.6, 32H, BUFS(I2+1) WAS MODIFIED TO
1BE , E12.6)
C
750 CONTINUE
      I3= I2 + 2 + 3*(JWHO(I1,KOUNT) - KOUNT)
751 CONTINUE
C
      NOWNWD= NOWNWD - ISKIP
      DO 752 I4=I3,NOWNWD
      BUFS(I4)= BUFS(I4 + ISKIP)
752 CONTINUE
C
      IF (THETAK(I1) .LT. 0.) GO TO 709
      KOUNT= KOUNT + 1
      IF (KOUNT .GT. NUMBER(I1)) GO TO 709
      GO TO 750
709 CONTINUE
      I1= I1 + 1
      I2= 1
      KOUNT= 1
450 CONTINUE

```

AFWL-TR-67-131, Vol IV

```

      IF (I1 .LT. 10) GO TO 710
      WRITE (UNIT) (BUFS(IWD), IWD=1,NOWNWD)
      LRNI=      I
      WRITE (6,7008) LRNI, NOWNWD
7008 FORMAT (7/HOLRNI COUNTS THE NUMBER OF FREQUENCY GROUPS THAT HAVE B
      BEEN WRITTEN.  LRNI = , 14, 15H, AND NOWNWD = , 15)
      200 CONTINUE
      END FILE UNIT
      REWIND UNIT
      IF (MIN .NE. 5) WRITE (6,410) MIN
      410 FORMAT (40HMODIANCT, RUN USING BCD INPUT TAPE MIN = ,13, 12H, COMPL
      ETED. )
      WRITE (6,7001) UNIT, IDENT(1BINU+1)
      RETURN
      40 WRITE (6,7002)
      REWIND UNIT
      RETURN
      999 CONTINUE
      E R R O R   E X I T
C
C
      WRITE (6,7007)
      7007 FORMAT (85H112 TOO LARGE, OR LESS THAN (12LAST+5), OR THETAK(11).E
      10.0., OR NUMBER(11) TOO LARGE. )
      CALL MEHH
      RETURN
      END

```


DIANE TAPE AND DIANE CARD FORMAT

The DIANE cards, together with the DIANTC (tape to cards), DIANCT (card to tape), and DYPDIN (refer to later writeup) programs form an effective mechanism for transfer of opacity data from one user to another or from one computer to another. Data have been transferred this way between the IBM-7044, the UNIVAC-1108, and the CDC 3600, 6400, 6600 computers. This is possible because the cards are in decimal format and the programs are all in compatible FORTRAN IV.

The DIANE cards punched by the DIANTC (tape to cards) program have the following format:

CARD PUNCHED	FORMAT	COLUMNS USED	NAME IN PROGRAM	DESCRIPTION
1	I12	1 - 12	IDA	12-digit identification number
2	12A6	1 - 72	ID	Heading from identification (header) card
3	E12.7	1 - 12	HNUT	Number of frequency groups
3	E12.7	13 - 24	FNWD	Number of words/frequency grouping
4	E12.7	1 - 12	X1	If $X1 < 0$, indicates that the grey absorption coefficients follow If $X1 > 0$, then $X1$ is the value of the lower end of a frequency band
4	E12.7	13 - 24	X2	Number of temperatures
5	E12.7	1 - 12	BUFS(IWD), IWD=1	$\ln \theta_1$
5	E12.7	13 - 24	BUFS(IWD), IWD=2	Number of τ 's at θ_1 (τ is the specific volume in cc/gm)
5	6E12.7	1st card: 25 - 72	BUFS(IWD), IWD=3, LAST	$\ln K_R$, $\ln K_P$, $\ln \tau$, $\ln K_R$, $\ln K_P$, ...
			LAST=(3* BUFS(2))+2	
		succeeding cards: 1 - 72		$\ln \theta_2$, No. of τ 's at θ_2 , $\ln K_R$, $\ln K_P$, $\ln \tau$, ...

AFWL-TR-67-131, Vol IV

```

SUBROUTINE DIANE(M,N)
  U I A N E   F U N I K A N
C
C   MODIFIED BY BILL LINDLEY ON FEB. 27, 1967, TO ACCEPT DATA FROM
C   LAST (ANDIMX TAPES) AND UIAPHANOUS OPACITY DATA. (CODE WAS
C   CALLED ANUT FROM FEB. 27, 1967 UNTIL JUNE 12, 1967.)
C
C   MODIFIED BY C. IMES TO COMBINE UIANE WITH SCATTERING AND DIANE WITHOUT
C   SCATTERING ON JANUARY 30, 1967
C
C*  ALL DIANE RUNS USING CONDENSED UIAPHANOUS TAPES (DENSEN TAPES)
C*  MUST READ THESE TAPES IN EVEN PARITY -
C*  THIS IS DONE BY SPECIFYING THE K AND E OPTIONS ON THE TAPE ASSIGN CARD
C
  REAL LOWLIM
  INTEGER SCAT
  INTEGER HUBID
  INTEGER DENSEN
  DIMENSION A(20), IZ(10), COMP(10)
  DIMENSION NUSCAT(3)
  DATA NUSCAT / 6H WITH , 6H NO , 6H.397 /
  DATA DENSEN / 6HDENSEN /
  DATA HUBID/6HNDIMA/
  DATA DIMHNU/15.0/, IUMHNU/17/, IUMU2/500/, DIMCMU/2000./,
1  IUMBUF/1000/, IUMIH/25/
C
  COMMON/WWL/AMU(150), U1(150), U2(150), BMU(150), TMU(150),
1  CMU(2000), UR(300)
C
  DIMENSION AK(15,25,17), MU(25,17), AKT(15), ID(15)
1,KAMAX(25), PK(15,25,17), IMETA(25), BUFS(1000), ANUK(5)
2,AKLW(5), AKUP(5), IP(5), BKLW(5), BKUP(5), PCNA(20), BMNU(152)
3,PKI(15), SKP(25,17), SKK(25,17), JDID(25,12)
  DIMENSION HUBMU(3000)
  EQUIVALENCE (HUBMU, AMU)
  EQUIVALENCE(1UX,UX)
  EQUIVALENCE (A(1),ZBAR), (A(2),KHO), (A(3),BIGP), (A(4),EPSMAL),
1  (A(5),AKAPPA), (A(6),WAMBDA), (A(7),EIPART),
2  (A(8),GAMNEW)
C
C   NOTE ID(15) IS USED AS KAMAX(0)
C
  SCAT = M
  LOWLIM = .2
  IBCDU = N
  IF (SCAT.EQ. 2) LOWLIM = .3977
  IF (SCAT.EQ. 1) LOWLIM = 1.E-10
C
C   TO RUN UIANE, THESE DATA CARDS ARE REQUIRED:
C   (ALL INPUT TEMPERATURES AND FREQUENCIES ARE IN UNITS OF ELECTRON
C   VOLTS)
C
C   THE FIRST DATA CARD REQUIRED HAS AN IDENTIFICATION NUMBER IN COLUMNS
C   1-12 (FORMAT (I12)). THIS IS AN OPTIONAL NUMBER, BUT IT IS HELPFUL

```

AFWL-TR-67-131, Vol IV

C TO USE IT AS A SEQUENCING NUMBER, INCREASING ITS VALUE BY ONE EACH TIME
C A RUN IS MADE.

C THE SECOND DATA CARD REQUIRED HAS A HEADER IN (12A6) FORMAT WITH ANY
C TITLE INFORMATION DESIRED FOR THE RUN. SUGGESTED DATA INCLUDE MATERIAL,
C RUN TYPE, DIAPHRANOUS TAPES USED, DATE, TEMPERATURE RANGE, NUMBER OF
C FREQUENCY SETS, USER/REQUESTER, ETC.

C THE THIRD DATA CARD REQUIRED CONTAINS THE FOLLOWING INFORMATION:

COLUMNS	VARIABLE NAME	FORMAT	DATA
1-10	MNUT	F10.4	NUMBER OF FREQUENCY GROUPS
11-20	TP(1)	F10.4	TP(1).EQ.2. - DESIGNATES SCHATCH TAPE 2
21-30	TP(2)	F10.4	TP(2).EQ.3. - DESIGNATES SCHATCH TAPE 3
31-40	TP(3)	F10.4	TP(3).EQ.4. - DESIGNATES SCHATCH TAPE 4
41-50	TP(4)	F10.4	TP(4).EQ.7. - DESIGNATES SCHATCH TAPE 7
51-60	TP(5)	F10.4	TP(5).EQ.8. - DESIGNATES SCHATCH TAPE 8

C THE FOURTH, ETC., DATA CARD(S) REQUIRED CONTAIN THE FREQUENCY INPUT VALUES
C THEY MUST BE SPECIFIED IN DESCENDING ORDER, FORMAT (7F10.4).
C EACH FREQUENCY GIVEN IS AT THE LOWER END OF ITS GROUP, AND THE LAST
C FREQUENCY IN THE INPUT MUST BE .001 OR SOME OTHER SMALL BUT FINITE NUMBER.

C FOLLOWING THE FREQUENCY INPUT CARDS IS A DATA CARD (NEXT-TO-LAST DATA
C CARD IF ONLY DIAPHRANOUS (AND/OR ANDIMX) OR SILVIA OR ZSAZSU DATA
C ARE USED. THIRD-FROM-LAST CARD, OTHERWISE) CONTAINING THE
C FOLLOWING INFORMATION:

COLUMNS	VARIABLE NAME	FORMAT	DATA
1-10	THN	F10.4	THN.EQ.0. IS THE NORMAL CASE: SIGNALS THAT DATA IS TO BE READ FROM DIAPHRANOUS AND/OR ANDIMX DATA THN.L1.0. SIGNALS THAT SPECIAL LOW TEMPERATURE DATA WILL BE READ FROM TAPE H; A DATA TAPE MADE BY ZSAZSU, SILVIA, OR ALUETO THN.G1.0. SIGNALS THAT CARD INPUT FOR LOW TEMPERATURE POINTS WILL BE READ (TO DATE, CH2 IS THE ONLY MATERIAL THAT HAS BEEN TREATED THIS WAY)
11-20	THSKIP	F10.4	THSKIP.EQ.0 IS THE NORMAL CASE: IF(THN.EQ.0.), THSKIP IS NOT USED IF(THN.NE.0. AND THSKIP.NE.0.): THSKIP.GT.0. MEANS SKIP THSKIP TEMPERATURES AT LOW END THSKIP.LT.0. MEANS PICK UP EACH THSKIP' TH TEMPERATURE

C NEXT DATA CARD REQUIRED ONLY IF SILVIA, ZSAZSU, OR ALUETO DATA
C ARE USED

AFWL-TR-67-131, Vol IV

COLUMNS	VARIABLE NAME	FORMAT	DATA
1-10	ANUK(K)	F10.4	THIS IS A HIGHER FREQUENCY THAN THE LAST ONE AVAILABLE ON INPUT TAPE OR CARDS. IT IS THE FREQUENCY OF AN 'EDGE' FOR WHICH OPACITY DATA ARE TO BE PROVIDED AS INDICATED BELOW.
11-20	AKLW(K)	F10.4	WHEN $KAPPA=A+B \cdot KMO$, THIS IS A FOR THE LOWER KAPPA VALUE AT THE INPUT ANUK(K). OTHERWISE, IT IS THE LOWER VALUE OF KAPPA AT THE INPUT ANUK(K).
21-30	AKUP(K)	F10.4	WHEN $KAPPA=A+B \cdot KMO$, THIS IS A FOR THE UPPER KAPPA VALUE AT THE INPUT ANUK(K). OTHERWISE, IT IS THE UPPER VALUE OF KAPPA AT THE INPUT ANUK(K).
31-40	BKLW(K)	F10.4	WHEN $KAPPA=A+B \cdot KMO$ THIS IS B FOR THE LOWER KAPPA VALUE AT THE INPUT ANUK(K). OTHERWISE, IT IS ZERO.
41-50	BKUP(K)	F10.4	WHEN $KAPPA=A+B \cdot KMO$, THIS IS B FOR THE UPPER KAPPA VALUE AT THE INPUT ANUK(K). OTHERWISE, IT IS ZERO.

LAST DATA CARD MUST CONTAIN THE FOLLOWING INFORMATION (ALL COMMENTS REFERRING TO DIAPHANOUS TAPES ARE APPLICABLE TO ANDIMX TAPES, AS WELL)

COLUMNS	VARIABLE NAME	FORMAT	DATA
1-10	TAPES	F10.4	IF (TAPES.GT.0.), INDICATES THE NUMBER OF DIAPHANOUS (AND/OR ANDIMX) TAPES THAT ARE TO BE USED. IF (TAPES.LE.0.), INDICATES THAT NO DIAPHANOUS OR ANDIMX TAPES WILL BE USED.
11-20	THMAX	F10.4	HIGHEST TEMPERATURE TO BE ACCEPTED FROM DIAPHANOUS
21-30	THMIN	F10.4	LOWEST TEMPERATURE TO BE ACCEPTED FROM DIAPHANOUS
31-40	THM1	F10.4	HIGHEST TEMPERATURE TO BE ACCEPTED FROM FIRST DIAPHANOUS TAPE (ON UNIT D), IF MORE THAN ONE SUCH TAPE IS USED.

```
C
C      41-50      THM2      F10.4      THM1.EQ.U. OTHERWISE
C                                     HIGHEST TEMPERATURE TO BE ACCEPTED FROM
C                                     SECOND DIAPHANOUS TAPE (ON UNIT E),
C                                     IF MORE THAN TWO SUCH TAPES ARE USED,
C                                     THM2.EQ.U. OTHERWISE
C      51-60      THM3      F10.4      HIGHEST TEMPERATURE TO BE ACCEPTED FROM
C                                     THIRD DIAPHANOUS TAPE (ON UNIT F),
C                                     IF MORE THAN THREE SUCH TAPES ARE USED
C                                     THM3.EQ.U. OTHERWISE
C      61-70      THM4      F10.4      HIGHEST TEMPERATURE TO BE ACCEPTED FROM
C                                     FOURTH DIAPHANOUS TAPE (ON UNIT G),
C                                     IF FIVE SUCH TAPES ARE USED,
C                                     THM4.EQ.U. OTHERWISE
C
C ***** NOTE: TAPES MUST BE .LE. 4 IF SILVIA, ZSAZSU, ALUETO, OR ANY OTHER
C          LOW TEMPERATURE DATA IS USED. *****
C
C ***** PLEASE NOTE: *****
C *** THE NUMBER OF SCRATCH TAPES WHICH MUST BE ASSIGNED BY DRUM ASG ***
C CANUS IS DETERMINED BY THIS EQUATION:
C     INT ((HNU1/(OIMHNU+.001 .EQ. 15.001)) + 1
C   THREE SCRATCH TAPES MAY BE ASSIGNED FOR EVERY MUN, BUT
C   1. 1-30 FREQUENCY GROUPS REQUIRE 1 SCRATCH TAPE
C   2. 31-45 FREQUENCY GROUPS REQUIRE 2 SCRATCH TAPES
C   3. 46-60 FREQUENCY GROUPS REQUIRE 3 SCRATCH TAPES
C
C PROGRAM NEEDS MORE SCRATCH TAPE ASSIGNMENTS IF MORE THAN 60 FREQUENCY
C GROUPS ARE SPECIFIED.
C TO ADD TWO MORE (MAXIMUM ALLOWED) SCRATCH AREAS, ADD ASG DRUM/ AND
C ASG DRUMB CANUS.
C *****
C
C FORMATS
C 3003 FORMAT (1X,8HTAPES = ,F10.4,12H WHEN THN = ,F10.4,/120H THIS COMBI
C NATION OF LOW TEMPERATURE INPUT (USING TAPE M) AND 5 DIAPHANOUS TA
C PIES (FIFTH ONE ON TAPE M) IS NOT POSSIBLE. )
C /0000 FORMAT (1HU, 42X, 7HDUIANE, , A6, 35HSCATTERING, COMPLETED SUCCESSF
C ULLY. / 1H1)
C 1 FORMAT (39H TOO MUCH DATA FOR BUFS STORAGE. TILT.)
C 2 FORMAT (13H FOR THEIA = F7.2, 8H, RHO = 1PE10.5, 28H, DIAPHANOUS U
C 2ATA ABOVE U = UPFB.1,43H ARE BEING REJECTED DUE TO LACK OF STORAGE
C 2.)
C 3 FORMAT (7F10.4)
C 7003 FORMAT (1X,7F10.4)
C 4 FORMAT (112)
C 7004 FORMAT (1X,112)
C 5 FORMAT (10H1HNU FROM ,F12.4, 5H TO , F12.4)
C 6 FORMAT (79H THEIA = ,F12.4)
C 7 FORMAT (1PBE15.8)
C 9 FORMAT (12A6)
C 7009 FORMAT (1X,12A6)
C 10 FORMAT (41H DIAPHANOUS TAPE SEEMS TO HAVE MORE THAN 12, 11H DENSIT
C YIES.)
C
C *****
```

AFWL-TR-67-131, Vol IV

```

11 FOMMAI (10M DENSITIES)
12 FOMMAI (1M1)
13 FOMMAI (112, 12A6)
14 FOMMAI (15M1 AVERAGE KAPPAS)
15 FOMMAI (42M 2ND SET OF DIAPHANOUS DATA HAS MORE THAN 13, 19M ENTH
    ZIES. THETA = 17.2, 8M, RMO = 1PE10.5, 20M, NO GOOD ABOVE U = UP+6.
    31)
16 FOMMAI (23M WARNING. FOR THETA = F10.4, 11M AND RMO = E10.4, 8P,
    2 GROUP 12, 24M HAS A U DISCREPANCY OF 1PE9.3, 8M VERSUS 1PE9.3)

C
C   GENERALLY FOR LOW TEMPERATURES, DATA FROM CARD INPUT. BUT FOR AIR,
C   DATA FROM ZSAZSU - FIXED TABLES IN FREQUENCY, DENSITY, TEMPERATURE
C   UP TO FIVE DIAPHANOUS TAPES (D,E,F,G,H RESPECTIVELY)
C   *** NOTE: NUMBER OF DIAPHANOUS INPUT TAPES MUST BE .LE. 4 IF SILVIA,
C   ZSAZSU, ALUETO, OR ANY OTHER LOW TEMPERATURE DATA IS USED. ***
C   DIANE TAPE ON C
C   INPUT TAPE FROM ZSAZSU OR SILVIA ON H
C   CALL OVCKON
C   CALL OVCHK(KUMT)
C   DIMHNU = DIMHNU                                00000240
C   DIMCMU = DIMCMU
C   P R O C E S S   I N P U T                        00000250
C   READ (5,4) IDA
C   WRITE (6,7004) IDA
C   READ (5,9) (ID(1), I = 1, 12)
C   WRITE (6,7009) (ID(1), I=1,12)
C   READ (5,3) HNUT, (IP(1), I = 1, 5)
C   WRITE (6,7003) HNUT, (IP(1), I=1,5)
C   HNNU = HNUT + .5
C   BHNU(1) = 1.E6
C   FREQUENCY RANGE LIMITED BY CMU STORAGE
C   NPI = HNNU + 1
C   READ (5,3) (BHNU(1), I = 2, NPI)
C   WRITE (6,7003) (BHNU(1), I=2,NPI)
C
C   BHNU(1) .EQ. 1.E6 IS THE PRESENT UPPER FREQUENCY LIMIT IN DIANE
C
C   IF (BHNU(NPI) .LT. .001) BHNU(NPI) = .001
C   NSCT = INT(HNUT / (DIMHNU + .001)) + 1
C   IF (NSCT .GT. 6) CALL DUMP
C   DO 501 I = 2, NSCT
C   IIP = IP(I-1)
C   501 REWIND IIP
C   CARD INPUT FOR LOW-TEMPERATURE POINTS
C   READ (5,3) THN, THSKIP
C   WRITE (6,7003) THN, THSKIP
C   IF (THN) 507, 506, 508
C   506 JA = 0
C   NIMETA = 0
C   GO TO 20
C
C   NEGATIVE THN SIGNALS THAT DATA SHALL BE READ FROM TAPE H,
C   A DATA TAPE MADE BY ZSAZSU, SILVIA, OR ALUETO
C   DATA TAPE MATERIALS INCLUDE AIR, REFRAZIL, CARBON PHENOLIC,
C   POLYATOMIC CARBON, ALUMINUM, AND IRON.

```

AFWL-TR-67-131, Vol IV

```

C      POSITIVE THSKIP MEANS SKIP THSKIP TEMPERATURES AT LOW END
C      NEGATIVE THSKIP MEANS PICK UP EACH THSKIP)TH TEMPERATURE
507 READ (16) THSN, TNHNU, HNUMIN, DHNU
      CBIM = HNUMIN
      FBIM = HNUMIN - 0.5 * DHNU
      HW = 0.5 * DHNU
      W = DHNU
      WI = 1. / DHNU
      HTP = DHNU * TNHNU + FBIM
      IF (THSKIP .GT. 0.0) GO TO 500
      NTHETA = THSN
      GO TO 502
500 NSK = THSKIP
      NTHETA = THSN - THSKIP
      DO 504 I = 1, NSK
      READ (16) XX, RHON
      MRP = RHON
      DO 503 J = 1, MRP
503 READ (16)
504 CONTINUE
502 NTHNU = TNHNU
      NUP = 2
      ANUK(1) = HTP
      BKUP(1) = 0.
      DO 510 K = 2, NUP
      READ (5,3) ANUK(K), AKLW(K), AKUP(K), BKLW(K), BKUP(K)
510 WRITE (6,7) ANUK(K), AKLW(K), AKUP(K), BKLW(K), BKUP(K)
      GO TO 509
508 NTHETA = THN
C      BEGIN TEMPERATURE LOOP
509 JA = 0
      DO 580 JAG = 1, NTHETA
      IF (THN) 1500, 1504, 1502
1504 CALL DUMP
1500 IF (THSKIP .GT. (-.5)) GO TO 1505
      IF (AMOD(FLOAT(JAG), -THSKIP) .EQ. 0.0) GO TO 1501
      READ (16) XX, RHON
      MRP = RHON
      DO 1503 J = 1, MRP
1503 READ (16)
      GO TO 580
1501 JA = JA + 1
      GO TO 1506
1505 JA = JAG
1506 READ (16) THETA(JA), RHON
      PTHET = THETA(JA)
      MRP = RHON
      GO TO 1508
1502 READ (5,3) PTHET, PHM, PNU, PA, PB, PC, PU
      WRITE (6,7) PTHET, PHM, PNU, PA, PB, PC, PU
      IF (PHM .GT. FLOAT(100000)) CALL DUMP
      MRP = PHM
      READ (5,3) (RU(JA,J), J = 1, MRP)
      WRITE (6,7) (RU(JA,J), J = 1, MRP)

```

AFWL-TR-67-131, Vol IV

```

      IF (PNU .LT. 0.5 .OR. PNU .GT. 5.0) CALL DUMP
      NUP = PNU
      DO 1509 K = 1, NUP
      READ (5,3) ANUK(K), AKLW(K), AKUP(K), BKLW(K), BKUP(K)
1509 WRITE (6,7) ANUK(K), AKLW(K), AKUP(K), BKLW(K), BKUP(K)
C      B E G I N   U E N S I I Y   L O O P
1508 DO 575 KA = 1, MNP
      IF (IMN) 1510, 1504, 1511
1510 READ (16) RU(JA,KA), (UK(N), N=1,NTMNU)
      AKUP(1) = AMAX1(UK(NTMNU), 1.E-10)
      GO TO 1512
1511 AKLPNU = PA + PB * SQRT(RU(JA,KA)) + PC * RU(JA,KA) + PD *
      2 RU(JA,KA)**2
1512 ANUTSI = ANUK(1)
CONSTRUCT TABLE OF ABS COEFFS(CMU) FOR HIGH FREQUENCIES FROM EDGE DATA
      IX = 1
      CMU(1) = AKUP(1) + BKUP(1) * RU(JA,KA)
      DO 520 K = 2, NUP
      CKUP = AKUP(K-1) + BKUP(K-1) * RU(JA,KA)
      CKLW = AKLW(K) + BKLW(K) * RU(JA,KA)
      517 IX = IX + 1
      IF (IX - 200) 1516, 1516, 1517
1516 UNU = 0.5
      GO TO 1518
1517 UNU = 5.0
1518 ANUTSI = ANUTSI + UNU
      IF (ANUTSI - ANUK(K)) 516, 519, 519
      516 CMU(IX) = EXP(ALOG(CKUP) + ALOG(CKLW/ CKUP) / ALOG(ANUK(K) /
      ANUK(K-1)) * ALOG(ANUTSI/ ANUK(K-1)))
      IF (IX - 100CMU) 517, 521, 521
      519 IX = IX - 1
      ANUTSI = ANUTSI - UNU
      520 CONTINUE
      CKUP = AKUP(NUP) + BKUP(NUP) * RU(JA,KA)
C      KAPPA GOES AS MNU**-.3 BEYOND LAST EDGE
      514 IX = IX + 1
      IF (IX - 200) 1513, 1513, 1514
1513 UNU = 0.5
      GO TO 1515
1514 UNU = 5.0
1515 ANUTSI = ANUTSI + UNU
      CMU(IX) = AMAX1(CKUP * (ANUK(NUP) / ANUTSI)**3, LOWLIM)
      IF (IX - 100CMU) 514, 521, 521
      521 CALL DVCHK (K000FX)
      GO TO(1522,522),K000FX
1522 CALL DUMP
      522 SKP(JA,KA) = 0.0
      SKR(JA,KA) = 0.0
      DO 570 I = 1, NSCT
      ITP = IP(I-1)
      IF (I - NSCT) 524, 525, 505
      505 CALL DUMP
      524 MNU = 10MNU
      GO TO 530
      525 MNU = MNU - 10MNU * (I - 1)

```

00000740

00000760

00000770

00000780

00000790

00000810

A00000820

00000830

00000850

00000870

00000880

00000890

00000900

00000920

00000930

00000940

00000950

00000960

AFWL-TR-67-131, Vol IV

```

C      BEGIN FREQUENCY LOOP
550  DO 565 IA = 1, MNNU
      IA1 = IA + 1
      MNUL = BMNU(IA1)
      UTL = MNUL / PTHET
      ULU = BMNU(IA1) / PTHET
      IF (BMNU(IA1) .GE. ANUK(1)) GO TO 554
      IF (BMNU(IA1) .LE. ANUK(1)) GO TO 544
      MNNU = ANUK(1)
      GO TO 546
80000970
80000980
544  MNNU = BMNU(IA1)
C      SUM OVER FREQUENCIES BELOW FIRST EDGE
546  IF (IMN) 1544, 505, 1540
C      GENERAL LOW-FREQUENCY INTEGRATION(CONSTANT KAPPA)
1540  ULL = MNUL / PTHET
      ULU = MNNU / PTHET
      ULM = 0.5 * (ULL + ULU)
      ELM = 1.0 - EXP(-ULM)
      IF (ULL .GT. 15.) GO TO 1542
      PLN = PLNKUT(ULL,ULU)
      ELL = EXP(-ULL)
      ELU = EXP(-ULU)
      SUMKAP = (PLN + .038497433 * (ULL**4 * ELL / (1.0 - ELL) - ULU**4
2 * ELU / (1.0 - ELU))) / ELM / AKLHNU
      GO TO 1543
CASE OF LARGE U. ULL HERE IS UTL, SO NORMALIZATION IS SIMPLER.
1542  ELU = EXP(-ULU)
      PLN = .153989733 * (((ULL + 3.) * ULL + 6.) * ULL + 6. - ELU *
2 * ((ULU + 3.) * ULU + 6.) * ULU + 6.))
      SUMKAP = (PLN + .038497433 * (ULL**4 - ULU**4 * ELU)) / ELM /
2 AKLHNU
1543  SUMPKA = AKLHNU * ELM * PLN
      GO TO 551
C      LOW-FREQUENCY INTEGRATION FOR MATERIALS WHOSE KAPPAS COME FROM A DATA TAPE
1544  IL = MAX1(W1 * (MNUL - FBTM) + 1.0, 1.0)
      IU = MAX1(W1 * (MNNU - FBTM) + 1.0, 1.0)
      SUMKAP = 0.0
      SUMPKA = 0.0
      DO 550 L = IL, IU
80001190
80001200
C      ZERO INPUT OPACITIES NOW POSSIBLE
      UK(L) = AMAX1(UK(L), 1.E-20)
      MNUL = AMAX1(MNUL, FLOAT(L-1) * W + FBTM)
      MNNU = AMIN1(MNNU, FLOAT(L) * W + FBTM)
      ULL = MNUL / PTHET
      ULU = MNNU / PTHET
      ULM = 0.5 * (ULL + ULU)
      ELM = 1.0 - EXP(-ULM)
      IF (UTL .LE. 15.) GO TO 548
80001220
80001230
80001240
80001250
80001260
CASE OF LARGE U FOR DATA TAPE MATERIALS
      ELLP = EXP(-ULLP + UTL)
      ELL = EXP(-ULL + UTL)
      PLN = .153989733 * (((ULL + 3.) * ULL + 6.) * ULL + 6.) * ELL -
2 * ELLP * (((ULLP + 3.) * ULLP + 6.) * ULLP + 6.))
      SUMKAP = SUMKAP + (PLN + .038497433 * (ULL**4 * ELL - ULLP**4 *
2 * ELLP)) / ELM / UK(L)

```

AFWL-TR-67-131, Vol IV

```

GO TO 549
548 ELL = EXP(-ULL)
ELLF = EXP(-ULLF)
PLN = PLNKUT(ULL, ULLF)
SUMKAP = SUMKAP + (PLN + .038497433 * (ULL**4 * ELL / (1.0 - ELL)
2 - ULLF**4 * ELLF / (1.0 - ELLF))) / ELM / UR(L)
549 SUMPKA = UR(L) * ELM * PLN + SUMPKA
CALL UVCHK (K000FX)
GO TO ( 547,550),K000FX
547 CALL JUMP
550 CONTINUE
551 IF (BMNU(IAT) .LE. ANUK(1)) GO TO 560
HNUL = ANUK(1)
GO TO 555
554 SUMKAP = 0.0
SUMPKA = 0.0
555 HNUL = BMNU(IAT)
C SUM OVER FREQUENCIES ABOVE FIRST EDGE
IF (HNUL - ANUK(1) .GT. 100.) GO TO 557
IL = 2.0 * (HNUL - ANUK(1)) + 1.0
GO TO 558
557 IL = 201. + 0.2 * (HNUL - ANUK(1) - 100.)
GO TO 559
558 IF (HNUL - ANUK(1) .GT. 100.) GO TO 559
IU = 2.0 * (HNUL - ANUK(1))
GO TO 1548
559 IU = 200. + 0.2 * (HNUL - ANUK(1) - 100.)
IF (IU .LT. 10MCMU) GO TO 1548
IF (IL .LT. 10MCMU) GO TO 1545
AKI(1A) = LOWLIM
PKI(1A) = LOWLIM
GO TO 561
1545 IU = 10MCMU
UTUP = ((FLOAT(10MCMU) - 200.) * 5.0 + 100. + ANUK(1)) / PTHET
IF (UTUP .LT. 1000.) WRITE (6,16) PTHET, RO(JA,KA), IAT,UTU,UTUP
1548 DO 561 IX = IL, IU
IF (IX .GT. 200) GO TO 1552
UNU = 0.5
HNUU = 0.25
GO TO 1553
1552 UNU = 5.0
HNUU = 2.5
1553 IF (IX .GT. IL) GO TO 1554
HNULL = HNUL
GO TO 1560
1554 HNULL = HNULL + UNU
1560 ULL = HNULL / PTHET
ULLF = (HNULL + UNU) / PTHET
ELM = 1. - EXP((-HNULL - HNUU) / PTHET)
IF (UTL .LE. 15.0) GO TO 1555
ELLF = EXP(-ULLF + UTL)
ELL = EXP(-ULL + UTL)
PLN = .153989733 * (((ULL + 3.) * ULL + 6.) * ULL + 6.) * ELL -
2 ELLF * (((ULLF + 3.) * ULLF + 6.) * ULLF + 6.))
SUMKAP = SUMKAP + (PLN + .038497433 * (ULL**4 * ELL - ULLF**4 *

```

00001270
00001280

00001320

00001410

00001560

AFWL-TR-67-131, Vol IV

```

      2 ELLP)) / ELM / CMU(IX)
      GO TO 1556
1555 ELL = EXP(-ULL)
      ELLP = EXP(-ULLP)
      PLN = PLNKUT(ULL,ULLP)
      SUMKAP = SUMKAP + (PLN
      + .038497433 * (ULL**4 *
      1 ELL / (1.0- ELL) - ULLP**4 * ELLP / (1.0- ELLP))) / CMU(IX) / ELM
1556 SUMPKA = SUMPKA + PLN * CMU(IX) * ELM
      CALL UVCHK (KOUUFX)
      GO TO(1561,561),KOUUFX
1561 CALL DUMP
      561 CONTINUE
CALCULATE NORMALIZING FACTOR, FORM AVERAGE ABS COEFF, AND DO BOOKKEEPING
      560 IF (UTL - 15.0) 1558, 1558, 1557
1557 ETU = EXP(-UTU + UTL)
      FR = EXP(-UTL)
      PLN = .153989733 * ((UTL + 3.) * UTL + 6.) * UTL + 6. - ETU *
      2 ((UTU + 3.) * UTU + 6.) * UTU + 6.)
      UENOM = PLN + .038497433 * (UTL**4 - UTU**4 * ETU)
      GO TO 1559
1558 ETL = EXP(-UTL)
      ETU = EXP(-UTU)
      FR = 1.
      PLN = PLNKUT(UTL, UTU)
      IF (PLN) 562, 562, 563
      563 UENOM = PLN
      + .038497433 * (UTL**4 * ETL / (1.0 -
      1 ETL) - UTU**4 * ETU / (1.0- ETU))
1559 IF (SUMPKA) 562, 562, 566
      562 CALL DUMP
      566 AKI(IA) = UENOM / SUMKAP
      PKI(IA) = SUMPKA / PLN
      567 CALL UVCHK (KOUUFX)
      GO TO(1565,564),KOUUFX
1565 CALL DUMP
      564 PKI(IA) = ALOG(PKI(IA))
      SKP(JA,KA) = SKP(JA,KA) + SUMPKA * FR
      SKK(JA,KA) = SKK(JA,KA) + SUMKAP * FR
      565 AKI(IA) = ALOG(AKI(IA))
      IF (I - 1) 568, 568, 571
      568 DO 569 IA = 1, MNNU
      AK(IA,JA,KA) = AKI(IA)
      569 PK(IA,JA,KA) = PKI(IA)
      GO TO 570
      571 WRITE (1P) (AKI(IA), PKI(IA), IA = 1, MNNU)
      570 CONTINUE
      SKK(JA,KA) = -ALOG(SKK(JA,KA))
      SKP(JA,KA) = ALOG(SKP(JA,KA))
      575 RO(JA,KA) = -ALOG(RO(JA,KA))
      THETA(JA) = ALOG(PTMET)
      KAMAX(JA) = MRP
      580 CONTINUE
      IF (THN .LT. 0.0 .AND. THSKIP .LT. 0.0) NTHETA = JA
      JA = NTHETA
      KA = KAMAX(JA)

```

C

AFWL-TR-67-131, Vol IV

```

C   U I A P H A N O U S   S E C T I O N
20 CONTINUE
  READ (5,3) TAPES, THMAX, THMIN, THM1, THM2, THM3, THM4
  WRITE (6,7003) TAPES, THMAX, THMIN, THM1, THM2, THM3, THM4
    IF (TAPES .LT. .001) GO TO 160
    IF (THMAX .LT. .001) THMAX = 1.E5
    IF (THM1 .LT. .001) THM1 = 1.E5
    IF (THM2 .LT. .001) THM2 = 1.E5
    IF (THM3 .LT. .001) THM3 = 1.E5
    IF (THM4 .LT. .001) THM4 = 1.E5
C   ***** NOTE: TAPES MUST BE .LE. 4 IF SILVIA, ZSAZSU, ALUETO, OR ANY OTHER
C   LOW TEMPERATURE DATA IS USED. *****
    IF (THN.LT.0. .AND. TAPES.GT.4.5) GO TO 3002
  MEDIA = 12
  TEST1 = 0.0
  TAPEN = 1.0
  KA = 0
  MID = 1
  GO TO 22
3002 CONTINUE
  WRITE (6,3003) TAPES, THN
  999 CALL UUMP
C   22 CONTINUE
  IF (IBCDU .EQ. 0) GO TO 350
  READ (MEDIA) UX
  IF (IUX .EQ. HUBIU) GO TO 300
  IUX=UX-.5
  IF (IUX .EQ. (-1)) GO TO 30
  WRITE(6,7999) UX, IUX, IUX, IUX
  7999 FORMAT (26H PROBLEM WITH FIRST RECORD /5X,1PE15.8,2X,14,2X,A6, 2X
  112)
  CALL MEHR
C   350 CONTINUE
  LHUB=1
  READ (MEDIA,7350) IUX, (IU(I),I=1,12), NZ, (COMP(I),IZ(I),I=1,NZ)
  7350 FORMAT (13A6/12, (F6.4,12))
  IF (IUX .NE. UENSER) CALL MEHR
  WRITE (6,7351)
  7351 FORMAT (47H WE ARE PROCESSING A CONDENSED DIAPHANOUS TAPE.)
  WRITE (6,1001) IUX, (IU(I),I=1,12)
  1001 FORMAT (1H0, 13A6)
  WRITE (6,1002) NZ, (1,COMP(I),IZ(I),I=1,NZ)
  1002 FORMAT (1H0,5HNZ = ,12,/(1H ,12,2X,F5.4,2X,12/))
C   355 CONTINUE
  READ (MEDIA,7352) JJ, II, ULAST, AKLAST, TK, GAMMA, (A(K),K=1,20),
  1 (U1(K),K=6,11), (AMU(K),K=6,11), (U2(K),K=2,JJ),
  2 (BMU(K), K=2,JJ), (TMU(K), K=2,JJ)
  7352 FORMAT (214, 13E9.4, / (14E9.4))
  IF (JJ .EQ. (-5)) GO TO 79
  IF ((11 .GT. 150).OR.(JJ .GT. 1000)) GO TO 353
  IF (11 .LT. 6) WRITE (6,8) TK, GAMMA
  IF (ULAST .GT. 0.) GO TO 351

```

00001920

00001930

00001940

00001970

AFWL-TR-67-131, Vol IV

```

C      ULAST .GT. U. IMPLIES TRANSITIONS EXHAUSTED AT ULAST . LT. (U=15.)
      IF (U2(2) .EQ. U.) GO TO 356
354 CONTINUE
      U2(1) = U1(11)
      TMU(1) = AMU(11)
      ULAST = U2(JJ)
      AKLAST = TMU(JJ)
352 CONTINUE
      TMU(1) = AMAX1(TMU(1), LOWLIM+RHO)
      IMAX = 11
      JMAX = JJ
      JLESS = JJ-1
      NEND = 4
      GO TO 80
356 CONTINUE
      ULAST = U1(11)
      AKLAST = AMU(11)
351 CONTINUE
      U2(1) = 15.
      TMU(1) = AKLAST * (ULAST / 15.)**3
C      U2(2) .EQ. U. IMPLIES THERE IS NO EDGE DATA
      IF (U2(2) .EQ. U.) GO TO 352
      GO TO 354
353 CONTINUE
      WRITE (6,7353) 11, JJ, 1DMU2, TK, GAMMA
7353 FORMAT (9H 15U .LT. , 13, 6H .OK. , 13, 6H .GT. , 14, 9H FOR TK =,
      1 1PE15.8, 12H AND GAMMA = , 1PE15.8)
      CALL MERR
      CALL DUMP
C      READ START OF ANDIMX TAPE
300 MIP = MID + 4
      WRITE (6,7700) UX
7700 FORMAT (22H WE ARE PROCESSING AN ,A6,7H TAPE. )
      READ (MEDIA) ((JDIJ(MX,J), J=1,12), MX=MID+MTP)
      MID = MID + 5
      READ (MEDIA) UX
      IF (ABS(UX + 2.0) .LT. 1.E-4) GO TO 32
      IF (ABS(UX + 7.0) .LT. 1.E-4) GO TO 310
      CALL DUMP
C      PROCESS HUEBNER DATA SET FOR GIVEN T, RHO
310 READ (MEDIA) XX, XX, IK, RHO, (XX,I=1,24), UISTR, DUI,
      2 (XX,I=1,7)
      READ (MEDIA) NMAX, (HUBMU(I), I=1,NMAX)
      LHUB = 2
      IF (NMAX .GT. 2971) CALL DUMP
CODE ASSUMES START AT .3, DELTA U = .01
      IF (ABS(UISTR - 0.3) .GT. 1.E-4 .OR. ABS(DUI - 0.01) .GT. 1.E-5)
      2 CALL DUMP
      DO 315 I = 1, 2971
      IBK = 2972-I
315 HUBMU(IBK+29) = HUBMU(IBK)
      DO 320 I = 1, 29
      HUBMU(1)=HUBMU(30)*(30./FLOAT(I))**3
320 CONTINUE
      GO TO 76

```

AFWL-TR-67-131, Vol IV

```

30 HEAD (MEUIA) (JUID(MIU,1), I=1,12)
MIU = MIU + 1
HEAD (MEUIA)UX
IF (UX + 2.0) 999, 32, 999
C HEAD IN MU VERSUS U FOR GIVEN T, GAMMA
C THIS IS A DIAPHANOUS DATA SET ON EITHER A DIAPHANOUS OR AN ANUIMX TAPE.
32 HEAD (MEUIA)TK,GAMMA
LMUB = 1
J = 2
CAVEAI. THIS ASSUMES FIRST MU ALWAYS GIVEN AT .6
I = 6
M6 = 1
C HEAD FIRST SET OF DATA
34 HEAD (MEUIA)UX,UY
IF (UX + 3.0) 35, 60, 35
35 IF (UX + 4.0) 40, 50, 40
40 IF (UX + 6.0) 55, 45, 55
45 HEAD (MEUIA) UX, UY
IF (UX .LE. 0.0) CALL DUMP
ULAST = UX
AKLAST = UY
M6 = 2
GO TO 34
C WHEN (-4.) FOUND, TEST IF ULAST, AKLAST ALREADY SET
50 GO TO (51, 52), M6
51 ULAST = UI(I-1)
AKLAST = AMU(I-1)
52 UZ(I) = 15.
IMU(I) = AKLAST * (ULAST / 15.)**3
GO TO 75
55 UI(I) = UX
AMU(I) = UY
I = I + 1
GO TO 34
60 IF (I = 6) 61, 61, 64
CASE OF NO FIRST FRAME
61 CONTINUE
WRITE (6,8) TK, GAMMA
8 FORMAT (5UX,28M***** CAVEAI ***** /43X,56H DIANE FOUND N
10 DATA ON THE DIAPHANOUS TAPE FOR U.LT.15 /5UX,28M*****
2***** )
CALL DUMP
C HEAD SECOND SET OF DATA
64 UZ(I) = UI(I-1)
IMU(I) = AMU(I-1)
65 HEAD (MEUIA)UX,UY,UZ
IF (UX + 4.0) 70, 74, 70
70 UZ(J) = UX
BMU(J) = UY
IMU(J) = UZ
J = J + 1
IF (J = 10MU2) 65, 65, 72
72 WRITE (6,15) 10MU2, TK, NMO, UZ(J-1)
73 HEAD (MEUIA) UX, UY, UZ
IF (UX + 4.0) 75, 74, 75

```

UU002030

UU002040

UU002050

UU002060

UU002020

UU002040

UU002110

UU002120

UU002130

UU002170

UU002190

UU002200

UU002210

UU002220

UU002230

UU002260

UU002270

UU002280

UU002290

UU002300

UU002310

AFWL-TR-67-131, Vol IV

```

74 ULAST = U2(J-1)
AKLAST = IMU(J-1)
75 REAU (MEDIA)ZBAK,RHO,BIGP,EPSPAL,AKAPPA,WAMUDA,EIPART,GAMNEW
IMU(1) = AMAXI(IMU(1), LOWLIM * RHO)
IMAX = 1 - 1
JMAX = J - 1
JLESS = JMAX - 1
76 REAU (MEDIA)UX
IF (ABS(UX + 2.) .LT. 1.E-4) GO TO 78
IF (ABS(UX + 5.) .LT. 1.E-4) GO TO 79
IF (ABS(UX + 7.) .LT. 1.E-4) GO TO 77
CALL UUMP
77 NENU = 3
GO TO 80
78 NENU = 1
GO TO 80
79 NENU = 2
CHECK STATUS OF TEMPERATURE-DENSITY TABLE BEING BUILT FROM DIAPHANOUS DATA
80 IF (TK .LT. THMIN) GO TO 133
IF (TK .GT. TEST1) GO TO 585
KA = KA + 1
IF (KA .LE. 10MMHU) GO TO 150
WRITE (6,10) 10MMHU
GO TO 133
585 IF (NTHETA .LE. 0) GO TO 588
C REJECT DIAPHANOUS TEMPERATURES WHICH OVERLAP THE LOW-THETA RANGE
C WHERE DATA ARE PROVIDED BY ZSAZSA(FOR AIR) OR CARD INPUT(FOR ALL ELSE)
IF (TK .LT. 1.001 * THETA(NTHETA)) GO TO 133
C REJECT HIGHER TEMPERATURES IF STORAGE FULL
IF (JA .LE. NTHETA) GO TO 589
588 KAMAX(JA) = KA
C JA.EQ.0 INITIALLY AND KAMAX(0) USES ID(13)
589 IF (JA = 10MTH) 141, 160, 143
141 IF (TK = 1HMAX) 140, 140, 160
143 CALL UUMP
140 NTP = TAPEN
GO TO (142,144,3000,3001,147), NTP
142 THM = 1HM1
GO TO 146
144 THM = 1HM2
GO TO 146
3000 CONTINUE
THM = 1HM3
GO TO 146
3001 CONTINUE
THM = 1HM4
GO TO 146
147 THM = 1.E5
146 IF (TK .LE. THM) GO TO 145
NENU = 2
GO TO 133
145 JA = JA + 1
TEST1 = TK
THETA(JA) = ALUG(TK)
KA = 1

```

00002330
 00002340
 00002350
 00002360
 00002370
 00002380
 00002390

00002420
 00002430
 00002440

00002530

00002550

00002570
 00002580

00002600
 00002610
 00002620

AFWL-TR-67-131, Vol IV

```

150 GU TO (151, 640), LMUB
C   FILL IN MU VS U FOR U = 0.--.6 -- USED LATER ONLY IF UTU .GT. .6
151 UU 149 IX = 1, 5
149 AMU(IX) = AMU(6) * 216.U / FLOAT(IX)**3
                                U0002640
    FLINI = U.1
    UTP = BMNU(1) / TK
    IF (ULAST.GT.14.9 .AND. JLESS.EE.1) GO TO 154
CONSTRUCT TABLE OF MU = U**3 AS FAR AS NEEDED FOR ULAST LESS THAN 14.9
    II = 10.0 * (ULAST - .05) + 1.0
    UU 152 IX = 11, 150
    UGH = (FLOAT(IX) - 1.0) * U.1 + .05
                                00002680
152 AMU(IX) = AMAX1((ULAST / UGH)**3 * AKLAST, LOWLIM * RHO)
    IF (UTP - 14.9) 640, 640, 628
628 IIL = 1
627 IF (UTP - 100.) 621, 621, 622
621 ITU = (UTP - 15.) * 2. + 1.
    GU TO 623
622 ITU = MIN1(171. + (UTP - 100.) * 0.2, DIMCMU)
623 UU 626 IX = 11L, ITU
    IF (IX - 170) 624, 624, 625
624 UGH = (FLOAT(IX) - 1.) * U.5 + 15.25
    GU TO 626
625 UGH = (FLOAT(IX) - 171.) * 5. + 102.5
626 CMU(IX) = AMAX1((ULAST / UGH)**3 * AKLAST / RHO, LOWLIM)
    GU TO 640
CONSTRUCT TABLE OF MU VS U ABOVE U = 15, USING AVAILABLE DIAPHANOUS DATA
CONNECTION FOR INDUCED EMISSION UNNECESSARY FOR LARGE U
154 UTST = U2(1)
                                U0002700
    IX = 1
                                U0002710
    CMU(1) = TMU(1) / RHO
    UU 638 JX = 1, JLESS
                                U0002730
632 IX = IX + 1
                                U0002740
    IF (UTST - UTP) 633, 633, 640
633 IF (IX - 170) 635, 635, 637
635 UU = U.5
    GU TO 631
637 UU = 5.U
631 UTST = UTST + UU
    IF (UTST - U2(JX+1)) 634, 636, 636
                                U0002760
634 CMU(IX) = EXP(ALOG(TMU(JX)) + ALOG(BMU(JX+1) / TMU(JX)) / ALOG(U2(10002770
    JX+1)/U2(JX)) + ALOG(UTST/U2(JX))) / RHO
    IF (IX - DIMCMU) 632, 639, 639
                                U0002800
636 IX = IX - 1
    UTST = UTST - UU
                                U0002820
638 CONTINUE
    IIL = IX
    GU TO 627
639 WHILE (6.2) TK, RHO, UTST
640 SKP(JA,KA) = 0.0
    SKN(JA,KA) = 0.0
C   BEGIN DIAPHANOUS FREQUENCY LOOP
    UU 152 I = 1, NSCT
    ITP = TP(1-1)
    IF (I - NSCT) 81, 82, 143
                                U0002840
    81 MMNU = 10MMNU
                                00002850

```



```

      GO TO 83
82  MNNU = NHNU - 10MNNU * (1 - 1)
83  DO 130 IA = 1, MNNU
      1A1 = 1A + 10MNNU * (1 - 1)
      UTL = BMNU(1A1+1) / TK
      UTU = BMNU(1A1) / TK
      GO TO (88, 325), LMUB
C    PROCESS HUEBNER DATA
325  IL = AMAX1(100. * (UTL - .005) + 1., 1.)
      IU = AMIN1(100. * (UTU - .005) + 1., 3000.)
      FLINT = 0.01
      FK = 1.
      SUMKAP = 0.0
      SUMPKA = 0.0
      UTL1 = UTL
      UTU1 = UTU
      ETL = EXP(-UTL1)
      ETU = EXP(-UTU1)
      IF (UTU .LT. 30.01) GO TO 105
      IF (UTL .LT. 80.) GO TO 330
      AK1(1A) = LOWLIM
      PK1(1A) = LOWLIM
      GO TO 125
C    4157.7227 IS 30003 * 15 / PI**4
330  SUMPKA = HUBMU(3000) / MHU * 4157.7227 * (ETL - ETU)
      TERML = ETL * (1. + UTL * (2. + UTL * (3. + UTL * (4. + UTL * (5.
      2. + UTL * (6. + UTL * (7. + UTL))))))
      IF (UTU .LT. 80.) GO TO 335
      TERMU = 0.0
      GO TO 340
335  TERMU = ETU * (1. + UTU * (2. + UTU * (3. + UTU * (4. + UTU * (5. +
      2UTU * (6. + UTU * (7. + UTU))))))
C    5.7033233E-6 IS 15 / PI**4 / (30003)
340  SUMKAP = 5.7033233E-6 / HUBMU(3000) * MHU * (TERML - TERMU)
      IF (IL .GT. 3000) GO TO 117
      GO TO 105
88  IF (UTL - 14.9) 90, 91, 91
90  IL = AMAX1(10.0 * (UTL - .05) + 1.0, 1.0)
      GO TO 94
91  UTL2 = UTL
      UTU2 = UTU
C    DO ROSSELAND AND PLANCK AVERAGES FOR U OVER 15
93  SUMKAP = 0.
      SUMPKA = 0.
      IF (UTL2 - U2(1)) 650, 650, 652
650  IL = 1
      GO TO 654
652  IF (UTL2 - U2(1) - 85.) 653, 653, 655
653  IL = 2. * (UTL2 - .5 - U2(1))
      GO TO 654
655  IL = 1/1. + 0.2 * (UTL2 - U2(1) - 85.)
654  IF (UTU2 - U2(1)) 656, 656, 658
656  IU = 1
      GO TO 660
658  IF (UTU2 - U2(1) - 85.) 657, 657, 659

```

00002860
 00002870
 00002880
 00002890

00002980

```

657 IU = 2. * (UTU2 + .5 - U2(1))
GO TO 660
659 IU = 170. + 0.2 * (UTU2 - U2(1) - 85.)
660 IF (IU .LT. 10MCMU) GO TO 667
IF (IL .LT. 10MCMU) GO TO 661
AKI(1A) = LOWLIM
PKI(1A) = LOWLIM
GO TO 125
661 IU = 10MCMU
UTUP = (FLOAT(10MCMU) - 170.) * 5. + 85. + U2(1)
IF (UTUP .LT. 1000.) WRITE (6,16) TK, RHO, IAT, UTU, UTUP
667 UU 675 IX = IL, IU
IF (IX .GT. 170) GO TO 663
DUX = 0.5
AUU = 0.
IADU = 0
GO TO 665
663 UUX = 5.0
AUU = 85.0
IADU = 170
665 IF (IX .GT. IL) GO TO 664
UXL = UTL2
GO TO 666
664 UXL = (FLOAT(IX - IADU) - 1.0) * DUX + AUU + U2(1)
666 IF (IX - IU) 668, 670, 670
668 UXU = (FLOAT(IX - IADU)) * UUX + AUU + U2(1)
GO TO 672
670 UXU = UTU2
672 EXL = EXP(-UXL + UTL2)
EXU = EXP(-UXU + UTL2)
PLN = .153989733 * (EXL * (((UTL2 + 3.) * UTL2 + 6.) * UTL2 + 6.) -
2 EXU * (((UXU + 3.) * UXU + 6.) * UXU + 6.))
NOTE = .153989733 = 15. / PI**4
C
C
SUMPKA = SUMPKA + CMU(IX) * PLN
675 SUMKAP = SUMKAP + (PLN + .038497433 * (UXL**4 * EXL - UXU**4 * EXU
2)) / CMU(IX)
C
NOTE = .038497433 = 15. / (4 * PI**4)
C
IF (SUMKAP) 120, 120, 677
677 EIL = 1.
ETU = EXP(-UTU2 + UTL2)
PLN2 = .153989733 * (EIL * (((UTL2 + 3.) * UTL2 + 6.) * UTL2 + 6.) -
2 ETU * (((UTU2 + 3.) * UTU2 + 6.) * UTU2 + 6.))
UENOM2 = PLN2 + .038497433 * (UTL2**4 * ETL - UTU2**4 * ETU)
IF (UTL - 14.9) 676, 680, 680
676 EIS = EXP(-UTL2)
UENOM = UENOM1 + UENOM2 * EIS
PLN = PLN1 + PLN2 * EIS
SUMKAP = SUMKAP + EIS + SUMKP1
SUMPKA = SUMPKA + EIS + SUMP1
GO TO 126
680 FH = EXP(-UTL2)
UENOM = UENOM2
PLN = PLN2

```

AFWL-TR-67-131, Vol IV

```

      GO TO 126
C      DO ROSSELANO AND PLANCK AVERAGES FOR U UNDER 15
CORRECTION FOR INDUCED EMISSION POSTPONED TO WITHIN INTEGRATION LOOP (NEAR 116)
      94 UTL1 = UTL
      PR = 1.
      IF (UTU - .1) 96, 96, 98
      96 IU = 1
      UTU1 = UTU
      GO TO 104
      98 IF (UTU - 15.0) 100, 100, 102
      100 IU = 10.0 * (UTU - .05) + 1.0
      UTU1 = UTU
      GO TO 104
      102 UTU1 = 15.0
      UTL2 = 15.0
      UTU2 = UTU
      IU = 15.0
      104 SUMKAP = 0.0
      SUMPKA = 0.0
      ETL = EXP(-UTL1)
      EIU = EXP(-UTU1)
      IF (UTU .LE. 0.6) GO TO 107
      105 DO 118 IX = IL, IU
      IF (IX - IL) 106, 106, 108
      106 UXL = UTL1
      GO TO 110
      108 UXL = (FLOAT(IX) - 0.5) * PLINT
      110 CONTINUE
      IF (IX .GE. IU) GO TO 114
      UXU = (FLOAT(IX) + 0.5) * PLINT
      GO TO 116
      114 UXU = UTU1
      116 UBAK = 0.5 * (UXL + UXU)
      EXL = EXP(-UXL)
      EXU = EXP(-UXU)
      CIE = 1. - EXP(-UBAK)
C      THE HUEBNER AND DIAPHRANOUS DATA ARE STORED IN THE SAME PLACE.
C      CIE IS THE CORRECTION FOR INDUCED EMISSION
      AKNP = AMU(IX) / RHO * CIE
      PLN = PLNKUT(UXL, UXU)
      SUMPKA = SUMPKA + PLN * AKNP
      118 SUMKAP = SUMKAP + (PLN
      + .038497433 * (UXL**4 *
      1 EXL / (1.0 - EXL) - UXU**4 * EXU / (1.0 - EXU))) / AKNP
      GO TO 117
C      ANALYTIC FIT FOR WHOLE BAND UNDER U=6
      107 SUMKAP = RHO / AMU(6) * .048285 * (UTU**5 * (1. - .416666667 *
      2 UTU) - UTL**5 * (1. - .416666667 * UTL))
      SUMPKA = AMU(6) * .0182548 / RHO * (UTU - UTL)
      117 PLN = PLNKUT(UTL1, UTU1)
      IF (PLN) 120, 120, 119
      119 DENOM = PLN
      + .038497433 * (UTL1**4 * ETL / (1.0 -
      1 ETL) - UTU1**4 * EIU / (1.0 - EIU))
      121 IF (SUMKAP) 120, 120, 122
      120 CALL DUMP

```

```

122 IF (U10 .LE. 15.0 .OR. LH08 .EQ. 2) GO TO 126
DENOM1 = DENOM
SUMK1 = SUMKAP
SUMP1 = SUMPKA
PLN1 = PLN
GO TO 93
126 AK1(1A) = DENOM / SUMKAP
PK1(1A) = SUMPKA / PLN
125 CALL DVCHK (KUUFEX)
SKP(JA,KA) = SUMPKA * FM + SKP(JA,KA)
SKH(JA,KA) = SUMKAP * FM + SKH(JA,KA)
GO TO (1130, 1131), KUUFEX
1130 CALL DUMP
1131 IF (AMINI(PK1(1A), AK1(1A))) 1130, 1130, 129
129 PK1(1A) = ALOG(PK1(1A))
130 AK1(1A) = ALOG(AK1(1A))
C S I U M I N G L O G K A P P A
IF (1 - 1) 131, 131, 134
131 DO 127 1A = 1, MNNU
PK1(1A,JA,KA) = PK1(1A)
127 AK1(1A,JA,KA) = AK1(1A)
GO TO 132
134 WHILE (1TP) (AK1(1A), PK1(1A), 1A = 1, MNNU)
132 CONTINUE
IF (AMINI(SKP(JA,KA), SKH(JA,KA))) 1320, 1320, 1321
1320 CALL DUMP
1321 SKP(JA,KA) = ALOG(SKP(JA,KA))
SKH(JA,KA) = -ALOG(SKH(JA,KA))
MU(JA,KA) = -ALOG(MHO)
133 GO TO (132, 155, 310, 355), MEND
155 IF (IAPEN - TAPES) 156, 160, 160
156 IAPEN = IAPEN + 1.0
WHILE (6.7012) MEDIA, THM
7012 FORMAT (55HDIANE HAS FINISHED HEADING FROM THE INPUT TAPE ON UNIT
1, 13, 1H./50H THE HIGHEST TEMPERATURE TAKEN FROM THIS TAPE WAS ,
2 F12.4)
MEDIA = MEDIA + 1
GO TO 22
160 JAMAX = JA
KAMAX(JA) = KA
WHILE (6.7012) MEDIA, THMAX
W H I L E D I A N E T A P E A N D E U I T R E S U L T S
NEWIND 11
DO 596 1 = 2, NSCI
1TP = 1P(1-1)
596 NEWIND 1TP
NWU = 0
DO 166 JA = 1, JAMAX
166 NWU = NWU + 3 * KAMAX(JA) + 2
FNWU = NWU
WHILE (11) 10A, (1U(1), 1=1,12)
WHILE (11) MNNU, FNWU
WHILE (6.12)
WHILE (6.7009) (10(1), 1=1,12)
WHILE (6.11)

```

00003390

00003410

00003460

00003480

00003490

00003500

00003530

00003540

00003580

00003760

00003770

AFWL-TR-67-131, Vol IV

```

      IWD = 1
      DO 160 JA = 1, JAMAX
      KAM = KAMAX(JA)
      PRIME1 = EXP(THETA(JA))
      WRITE (6,6) PRIME1
      DO 174 KA = 1, KAM
179 PCHA(KA) = EXP(-HU(JA,KA))
180 WRITE (6,7) (PCHA(KA), KA = 1, KAM)
      FJAMAX = JAMAX
      DO 175 I = 1, NSCT
      IF (I - NSCT) 161, 162, 143
161 MMNU = IUMHNU
      GO TO 163
162 MMNU = MMNU - IUMHNU * (I - 1)
163 IF (I - 1) 172, 172, 164
164 IIP = IP(I-1)
      DO 165 JA = 1, JAMAX
      KAM = KAMAX(JA)
      DO 165 KA = 1, KAM
165 READ (11P) (AK(IA,JA,KA), PK(IA,JA,KA), IA = 1, MMNU)
172 DO 171 IA = 1, MMNU
      IAI = IA + IUMHNU * (I - 1)
      WRITE (11) MMNU(IAI+1), FJAMAX
      WRITE (6,5) MMNU(IAI+1), MMNU(IAI)
      IWD = 1
      DO 170 JA = 1, JAMAX
      PRIME1 = EXP(THETA(JA))
      WRITE (6,6) PRIME1
      KAM = KAMAX(JA)
      BUFS(IWD) = THETA(JA)
      BUFS(IWD + 1) = KAM
      IWD = IWD + 2
      DO 167 KA = 1, KAM
      BUFS(IWD) = AK(IA,JA,KA)
      BUFS(IWD+1) = PK(IA,JA,KA)
      BUFS(IWD+2) = HU(JA,KA)
      IWD = IWD + 3
      IF (IWD .LE. IUMBUF) GO TO 167
      WRITE (6,1)
      CALL DUMP
167 CONTINUE
      DO 168 KA = 1, KAM
168 PCHA(KA) = EXP(PK(IA,JA,KA))
      WRITE (6,7) (PCHA(KA), KA = 1, KAM)
      DO 169 KA = 1, KAM
169 PCHA(KA) = EXP(AK(IA,JA,KA))
170 WRITE (6,7) (PCHA(KA), KA = 1, KAM)
171 WRITE (11) (BUFS(IWD), IWD = 1, NWD)
175 CONTINUE
      IWD = 1
      SILLY = -MMNU(1)
      WRITE (11) SILLY, FJAMAX
      WRITE (6,14)
      DO 178 JA = 1, JAMAX
      PRIME1 = EXP(THETA(JA))

```

00003640
00003660
00003670
00003680
00003690

00003710
00003720
00003740
00003750

00003820
00003830
00003840
00003850
00003860

00003880
00003900

00003930
00003950
00003960
00003970
00003980
00003990
00004000

AFWL-TR-67-131, Vol IV

```

WRITE (6,6)PMTHEI
KAM = KAMAX(JA)
BUFS(IWD) = THEIA(JA)
BUFS(IWD + 1) = KAM
IWD = IWD + 2
DO 177 KA = 1, KAM
  BUFS(IWD) = SKR(JA,KA)
  BUFS(IWD+1) = SKP(JA,KA)
  BUFS(IWD+2) = MUI(JA,KA)
177 IWD = IWD + 3
DO 176 KA = 1, KAM
176 PCHA(KA) = EXP(SKP(JA,KA))
  WRITE (6,7)(PCHA(KA), KA = 1, KAM)
DO 174 KA = 1, KAM
174 PCHA(KA) = EXP(SKH(JA,KA))
178 WRITE (6,7)(PCHA(KA),KA = 1, KAM)
  WRITE (11)(BUFS(IWD), IWD = 1, NWD)
END FILE 11
REWIND 11
WRITE (6,7000) NUSCAT(SCAT+1)
RETURN
END

```

00004020

(continued)

CARD PUNCHED	FORMAT	COLUMNS USED	NAME IN PROGRAM	DESCRIPTION
1st card of each set	I2	75 - 76	IX	2-digit sequencing number; indicates the order number of each frequency grouping set
1st card of each set	I3	78 - 80	KK	3-digit sequencing number; indicates card number with- in a particular frequency grouping

1. Let there be M θ values: $\theta_1, \theta_2, \dots, \theta_M$
2. Let there be N τ values ($N = n_1 \tau$ values at $\theta_1 + n_2 \tau$ values at $\theta_2 + \dots + n_M \tau$ values at θ_M)
3. Then $FNWD = 3N + 2M$
Thus FNWD counts all the words on records of card type 5 only

The total number of groups of cards that will be punched by the DIANTC program is HNUT (the number of frequency groups) plus the group of grey absorption coefficients. This number is indicated in the routine by this arithmetic statement:

$$NVECES = HNUT + 1.$$

Each set of cards punched for a frequency group consists of X1, X2, and (BUFS (IWD), IWD = 3, LAST).

The cards are sequenced numerically in two ways: (1) by the order number of the frequency group set, and (2) within each frequency group set.

A number (IX in the program) is punched in columns 75 and 76; this is the order number of the frequency grouping. It ranges in value from 1 to NVECES, as there are NVECES groups punched.

Another number (KK in the program) is punched in columns 78 through 80, and this indicates the card number within the frequency group set. The card numbers within each particular frequency grouping range from 0 to KX.

where KX is determined this way:

$$KX = NWD/6, \quad NWD \text{ is a multiple of } 6$$

or

$$KX = (NWD/6)+1; \quad NWD \text{ is not a multiple of } 6$$

There is also a counter (NOC in the program) that indicates the number of cards punched by the routine; it calculates that number in this way:

$$NOC = NVECES * (KX+1) + 3$$

Before using the DIANE cards-to-tape program, remove the run card; then, the output cards punched by DIANE tape-to-cards may be read in by the cards-to-tape program.

NOTE: The run card must be removed before using the DIANE cards-to-tape program.

The DIANCT (card-to-tape) program can read the DIANE cards and recreate a binary DIANE tape. Cards 1 and 2 form the first tape record. Card 3 forms the second tape record. Card 4 forms the third tape record. The fourth tape record contains BUFS (IWD), IWD = 1, LAST. Records of type 3 and 4 are repeated until the tape is complete

GREYS: A GREY OPACITY TAPE FROM DIANE DATA

Grey opacities are defined to be those Rosseland and Planck means over the entire frequency spectrum: $0 \leq h\nu \leq \infty$. The DIANE code calculates an approximation to these (as well as to the Rosseland and Planck means over specific frequency bands as determined by input parameters) from data produced by the GA DIAPHANOUS code or the LASL ANN code. (The grey frequency band is taken to be $10^{-3} \text{ eV} \leq h\nu \leq 10^6 \text{ eV}$.)

AFWL-TR-67-131, Vol IV

```

SUBROUTINE GREYS
C
C   CODED BY LAURA H. NORRIS   JANUARY, 1967
C
C   USER MUST WRITE ON A TAPE ON LOGICAL UNIT 11
C   THIS PROGRAM WILL ADD A SET OF GREYS TO THE GREY OPACITY DIANE
C   TAPE FROM INPUT CARDS
C
C   COMMON/GREYAP/ARRAT(1025),TITLE(36),ID(12)
C
C   FORMATS
C
C   1 FORMAT (112/12A6)
C   2 FORMAT (10E12.7)
C   3 FORMAT (3I4)
C   4 FORMAT (12A6)
C   5 FORMAT (13.9X,E12.7)
C   6 FORMAT (1H0,12A6)
C   7 FORMAT (1H0,27H THE NUMBER OF GREY SETS IS,13)
C
C
C   L = 11
C   REWIND L
C
C   KSET IS THE NUMBER OF SETS OF GREYS TO BE ADDED TO THE TAPE
C
C   READ (5,3) KSET,NEWIAP
C   INITIALIZE ISGN AND READ AND WRITE A TITLE
C   IF (NEWIAP.EQ.0) GO TO 10
C   ISGN = -1
C   READ (5,4) (TITLE(I),I=1,36)
C   WRITE (L) (TITLE(I),I=1,36)
C   GO TO 100
C
C
C   SPACE TAPE TO PROPER POINT
C
C   10 CONTINUE
C   READ (L) (TITLE(I),I=1,36)
C   20 CONTINUE
C   READ (L) IDNO,(ID(I),I=1,12),ISGN
C   IF (ISGN.GT.0) GO TO 60
C   READ (L) HNU,XNWU
C   READ (L) XMATNU,TEMPNU
C   NWU = XNWU
C   READ (L) (ARRAT(I),I=1,NWU)
C   GO TO 20
C
C   60 CONTINUE
C   BACKSPACE L
C   100 CONTINUE
C
C   READ DIANE INPUT CARDS
C

```

AFWL-TR-67-131, Vol IV

```

DO 150 J=1,KSET
HEAD (5,1) IDNO,(ID(I),I=1,12)
HEAD (5,2) MNU,XNWU
NWU = XNWU
C
C MNU IS THE NUMBER OF FREQUENCY GROUPS ON THE ORIGINAL DIANE TAPE
C XNWU IS THE NUMBER OF WORDS IN A FREQUENCY GROUP
C
HEAD (5,2) XMAINU,TEMPNU
C
C XMAINU IS THE SPOTTER-ELONGS MATERIAL NUMBER
C JMAX IS THE NUMBER OF TEMPERATURES IN THE FREQUENCY GROUP
C
HEAD (5,2) (AKMAT(I),I=1,NWU)
WRITE (L) IDNO,(ID(I),I=1,12),ISGN
WRITE (L) MNU,XNWU
WRITE (L) XMAINU,TEMPNU
WRITE (L) (AKMAT(I),I=1,NWU)
ISGN = ISGN - 1
150 CONTINUE
C
C ESTABLISH A SIGNAL = POSITIVE NUMBER OF GREYS ON THE TAPE
ISGN = -ISGN - 1
HEAD (5,1) IDNO, (ID(I),I=1,12)
WRITE (L) IDNO,(ID(I),I=1,12),ISGN
END FILE L
REWIND L
WRITE (6,6) (TITLE(I),I=1,36)
WRITE (6,7) ISGN
RETURN
END

```

DIANE results are available as magnetic tape files and as card decks. The FORTRAN IV GREYS program can read these card decks, select the grey opacities from each given (input) DIANE card deck, and produce a data tape (called the GREY tape) which contains only the grey opacity set for each material present.

The GREY tape has an initial heading record. Then, for each set of grey opacities, the heading record of the DIANE input card deck is written and is followed by its concomitant grey opacities. The set of grey opacities for each material is in standard DIANE tape format.

The GREYS program either writes a new tape or adds grey sets to an old tape. This feature of the program allows grey sets from later DIANE runs on new materials to be added to the GREY tape without completely rewriting the tape.

A program, EGREY, has been written in FORTRAN IV language to edit the GREY tape, and may be used as a subroutine of GREYS.

Input for GREYS

CARD NO.	INPUT VARIABLE	COLUMNS	FORMAT
1	KSET	1-4	I4
	NEWTAP	5-8	I4
2-4	TITLE Array	1-72	12A6
KSET	The number of grey sets to be added to the tape		
NEWTAP	If NEWTAP \neq 0, the program writes a new tape; if NEWTAP = 0, the program adds new grey sets to the previous GREY tape, and cards 2 through 4 are not read		
TITLE	An array of 36 alphanumeric words that are written on the GREY tape as a header record		

The DIANE tape format is specified in a separate writeup.

EGREY: AN EDITING CODE FOR THE GREY OPACITY TAPE

The program EGREY was written in FORTRAN IV language to edit the GREY tape. EGREY is an adaptation of EDIANE, a routine that edits a DIANE tape.

EGREY reads the GREY tape and edits either the entire tape or only specified grey sets, as determined by input. Also refer to the GREYS code writeup.

Input for EGREY

CARD NO.	INPUT VARIABLE	COLUMNS	FORMAT
1	NSET	1-5	I5
2	XMAT(1)	1-15	E15.8
	XMAT(2)	16-30	E15.8
subsequent cards	up to NSET	etc.	
NSET	The number of grey sets to be edited; if NSET = 0, the whole tape is to be edited		
XMAT	The array of material numbers corresponding to the grey sets to be edited; this array must be in the same order as the grey sets on the tape; if NSET = 0, the XMAT array is not used. (Only the first input card is required in this case.)		

REDGRE: TRANSFER OF GREY OPACITY DATA

REDGRE is a FORTRAN IV program written to obtain opacity data from the GREY tape for use in other programs (refer to GREYS writeup).

The GREY tape contains opacity data for many materials. For each material, there is a set of data containing temperatures and densities, and Rosseland and Planck opacities at these temperatures. (The Rosseland and Planck opacities are computed at the given temperature and at the specified densities.) REDGRE reads desired opacity sets for desired materials from the GREY tape as determined by input. REDGRE either

AFWL-TR-67-131, Vol IV

```

C      SUBROUTINE EGRET
C
C      CODED BY LAURA K. NORRIS   JANUARY, 1967
C
C      USER MUST READ FROM A TAPE ON LOGICAL UNIT 10
C
C      THIS PROGRAM READS ANY NUMBER OF SETS OF GREYS ACCORDING TO THE
C      MATERIAL NUMBER
C
C      EDITS THE TAPE MADE BY GREYS IN THE FOLLOWING MANNER
C          THETA RATHER THAN LN THETA
C          XMO  RATHER THAN LN XAU
C
C
C      INPUT VARIABLES
C      NSET      IS THE NUMBER OF SETS OF GREYS TO BE READ
C      XMAT      IS AN ARRAY OF MATERIAL NUMBERS WHICH INDICATE WHICH
C                MATERIALS ARE TO BE READ FROM THE TAPE
C
C      DIMENSION KCNT(40),FKAPK(40),FKAPP(40),DENS(40)
C      DIMENSION XMAT(100)
C
C      COMMON/GREYAP/BUFS(1000),TITLE(36),ID(12)
C
C      11 = 11
C      REWIND 11
C
C      READ (5,1020) NSET
C      READ (5,1130) (XMAT(I),I=1,NSET)
C      J = 1
C      KSET = 1
C      MLINE = 3
C      READ (11)      (TITLE(I),I=1,36)
C      WRITE (6,1000) (TITLE(I),I=1,36)
C      IF (NSET.EQ. 0) GO TO 90
C 10 CONTINUE
C
C      READ (11) IDA,(ID(I),I=1,12),ISGN
C      READ (11) HNU, XNWU
C      READ (11) XNO, FJAMAX
C      IF (XNO.EQ.XMAT(J)) GO TO 100
C      NX = XNWU
C      J = J + 1
C      READ (11)
C      READ (11) (BUFS(I),I=1,NX)
C      GO TO 10
C 90 CONTINUE
C
C      READ (11) IDA,(ID(I),I=1,12),ISGN
C 95 CONTINUE
C      READ (11) HNU,XNWU
C      READ (11) XNO,FJAMAX
C 100 CONTINUE
C

```

0030
0040

0080

0150

AFWL-TR-67-131, Vol IV

NX=XNU	0130
MATEML = XNU	
JAMAX=JAMAX	0170
IF (MLINE .EQ. 0) WHILE (6,1090)	0180
WHILE (6,1010) DOA, (1011), I=1,12, MATEML,NX	
NLINE=MLINE+6	0190
MLINE=0	0200
WHILE (6,1030) JAMAX	0220
HEAD (11) (BUFS(1),I=1,NX)	
KCNT(1)=0	0260
NCNT=1	0270
C	
DO 130 JA=1,JAMAX	0280
THEIA=EXP(BUFS(NCNT))	0290
KAMAX=BUFS(NCNT+1)	0300
IF (NLINE .LE. 50) GO TO 112	0310
WHILE (6,1110)	
NLINE=0	0340
C	
112 WHILE (6,1050) THETA, KAMAX	0350
NLINE=NLINE+3	0360
C	
DO 115 I=1,25	0370
UENS(I)=0.0	0380
FKAPP(I)=0.0	0390
FKAPP(I)=0.0	0400
115 CONTINUE	0410
C	
DO 120 KA=1,KAMAX	0420
IKAPH=NCNT-1+3*KA	0430
IKAPH=IKAPH+1	0440
IUENS=IKAPH+2	0450
FKAPH(KA)=EXP(BUFS(IKAPH))	0460
FKAPP(KA)=EXP(BUFS(IKAPP))	0470
UENS(KA)=EXP(-BUFS(IUENS))	0480
120 CONTINUE	0490
C	
DO 125 I=1,3	0500
KMB=0+1	0510
KL=KMB-1	0520
IF (KL .GT. KAMAX) GO TO 127	0530
KM=KAMAX	0540
IF (KMB .LT. KAMAX) KM=KMB	0550
IF (NLINE .LE. 55) GO TO 122	0560
WHILE (6,1110)	
WHILE (6,1120) THETA	0590
NLINE=9	0600
122 WHILE (6,1060) (UENS(K), K=KL,KM)	0610
WHILE (6,1070) (FKAPP(K), K=KL,KM)	0620
WHILE (6,1080) (FKAPP(K), K=KL,KM)	0630
NLINE=NLINE+4	0640
125 CONTINUE	0650
C	
127 KCNT(JA+1)=KCNT(JA)+3*KAMAX+2	0660
NCNT=NCNT+3*KAMAX+2	0670

AFWL-TR-67-131, Vol IV

```

130 CONTINUE
C
  IF (NSEI .EQ. 0) GO TO 140
  IF (KSET .EQ. NSET) GO TO 150
  KSET = KSET + 1
  J = J + 1
  GO TO 10

140 CONTINUE
  READ (11) IDA, (ID(I), I=1,12), ISGN
  IF (ISGN.LT.0) GO TO 150
C
150 CONTINUE
  WRITE (6,1035)
  WRITE(6,1040) ISGN,NSET
  REWIND 11
  RETURN
C
160 CONTINUE
  GO TO 95
C
1000 FORMAT (1H 12A6)
1010 FORMAT (113,9X,12A6,9X,9HDATEXL = ,14,5X,9HMX = ,14)
1020 FORMAT (15)
1030 FORMAT (11H)
1    29H GREY ABSORPTION COEFFICIENTS,115,15H TEMPERATURES ) 0750
1035 FORMAT (27H TAPE EDITING IS SUCCESSFUL)
1040 FORMAT (34H THE NUMBER OF GREY SETS EDITED IS ,15,30H THE NUMBER O
  IF GREY SETS REQUESTED IS ,15)
1050 FORMAT (17H THEIA = , F12.5, 20X, 15, 12H DENSITIES/) 0780
1060 FORMAT (19H DENSITY, 1PE15.8) 0790
1070 FORMAT (19H KAPPA(P), 1PE15.8) 0800
1080 FORMAT (19H KAPPA(K), 1PE15.8) 0810
1090 FORMAT (11H) 0820
1100 FORMAT (11H1///13H HNU FROM, F13.4, 7H TO, F13.4, 0830
  14H CONTINUED//) 0840
1110 FORMAT (11H1///42H GREY ABSORPTION COEFFICIENTS CONTINUED//) 0850
1120 FORMAT (17H THEIA = ,F12.5, 12H CONTINUED/) 0860
1130 FORMAT (1PE15.8)
      ENU 0870

```

AFWL-TR-67-131, Vol IV

```

C      SUBROUTINE REDONE
C      CODED BY LAURA K. NORRIS    JANUARY, 1967
C
C      USER MUST READ FROM A TAPE ON LOGICAL UNIT 10
C      USER MUST WRITE ON A TAPE ON LOGICAL UNIT 11
C      PATH OPTION IS DESIGNATED BY LKN AND LKN IS AN INPUT VARIABLE
C      IF LKN = 0, DATA IS WRITTEN ON THE MOTET PROGRAM TAPE
C      IF LKN = 1, DATA STATEMENTS ARE PUNCHED
C      ISGN      IS THE NUMBER OF EACH SET ON THE TAPE
C      TITLE     IS THE HEADING WRITTEN ON THE TAPE
C      IDNO      IS THE IDENTIFICATION NUMBER FROM THE HEADING ON THE
C               DIANE TAPE
C      ID        IS THE TITLE FROM THE HEADING ON THE DIANE TAPE
C      NNU       IS THE NUMBER OF FREQUENCIES ON THE DIANE TAPE
C      XNNU      IS THE NUMBER OF ELEMENTS IN THE BUFS ARRAY
C      XMAIND    IS THE E10X-SPUTTER MATERIAL NUMBER
C      TEMPO     IS THE NUMBER OF TEMPERATURES
C
C      DIMENSION BUFS(1000),TITLE(36),ID(12),XMAI(100)
C      DIMENSION THETAT(25),KAMAX(25),KC(25)
C
C      FORMATS
C      2 FORMAT (12,1P5E15.8)
C      3 FORMAT (6X11HDATA KAMAX/,15.6H/,NNU/,15.1H/)
C      4 FORMAT (6X11HDATA KAMAX/,4(112.1H,))
C      5 FORMAT (5X11.5(E12.7,1H,))
C      6 FORMAT (5X11.E12.7,4(1H.,E12.7),1H/)
C      7 FORMAT (6X11HDATA BUFS,12.1H/)
C      8 FORMAT (6X16HCOMMON/LKN/BUFS(,15.1H))
C      9 FORMAT (6X14HDIMENSION BUFS,12.1H(,12.1H))
C      11 FORMAT (6X18HEQUIVALENCE (BUFS(,15.6H),BUFS,12.4H(1)))
C      12 FORMAT (6X12HDATA THETAT/,4(E12.7,1H,))
C      13 FORMAT (6X,10HDATA KCNT/,4(112.1H,))
C      14 FORMAT (6X19HCOMMON/LKNA/THETAT(,12.8H),KAMAX(,12.7H),KCNT(,
C               12.1H))
C      15 FORMAT (5X,11.5(112.1H,))
C      16 FORMAT (5X,11.112.4(1H.,112),1H/)
C      18 FORMAT (11)
C      19 FORMAT (5X,11.,E12.7,1H/)
C      21 FORMAT (5X,11.,E12.7,1H.,E12.7,1H/)
C      22 FORMAT (5X,11.,E12.7,2(1H.,E12.7),1H/)
C      23 FORMAT (5X,11.,E12.7,3(1H.,E12.7),1H/)
C      24 FORMAT (5X,11.112.1H/)
C      25 FORMAT (5X,11.112.1H.,112.1H/)
C      26 FORMAT (5X,11.112.2(1H.,112),1H/)
C      27 FORMAT (5X,11.112.3(1H.,112),1H/)
C
C      PATH IS DETERMINED BY INPUT VARIABLE
C
C      READ (5,18)LKN
C
C      11 = 10
C      11 = 11
C

```


AFWL-TR-67-131, Vol IV

```

C      INITIALIZE COUNTER
C
C      J = 1
C
C      READ NUMBER OF MATERIALS AND MATERIAL ATOMIC NUMBERS
C
C      READ (5,2) NSET,(XMAT(I),I=1,NSET)
C
C      READ FIRST PHYSICAL RECORD ON GREY TAPE
C
1  CONTINUE
  REWIND 11
  READ(11) (TITLE(I),I=1,36)
C
C      SEARCH FOR REQUIRED OPACITY SETS
C
10  CONTINUE
  READ (11) IDA,( ID(I),I=1,12),ISGN
  IF (ISGN .EQ. 29) GO TO 20
  READ (11) HNU,FNUW
  READ (11) XNO,FJAMAX
  NX = FNUW
  IF (INT(XNO+.1) .EQ. INT(XMAT(J)+.1)) GO TO 50
  READ (11) (BUFS(I),I=1,NX)
  GO TO 10
20  CONTINUE
  GO TO 1

C
C      READ GREYAP AND STORE THE BUFS ARRAY IN A SMALLER ARRAY FOR MOTET
C
50  CONTINUE
  READ (11) (BUFS(I),I=1,NX)
  K = 1
  K1 = 1
  SUM = 0.
  JAMAX = FJAMAX
  DO 60 JA = 1,JAMAX
    BUFS(K1) = BUFS(K)
    BUFS(K1+1) = BUFS(K+1)
    KK = BUFS(K+1)
    DO 60 I = 1,KK
      I2 = 2 * (I - 1)
      I3 = I2 + I - 1
      BUFS(K1+2+I2) = BUFS(K+2+I3)
      BUFS(K1+3+I2) = BUFS(K+4+I3)
60  CONTINUE
    SUM = SUM + KK
    K2 = KK + KK + 2
    K1 = K1 + K2
    K = K + KK + K2
80  CONTINUE

C
C      ESTABLISH THETA1, KAMAX, AND KCNT ARRAYS
C
  NWU = FNUW - SUM

```

AFWL-TR-67-131, Vol IV

```

      FNWD = NWD
      KC(1) = 0
      NC = 1
      DO 120 JA = 1, JAMAX
        IMETAT(JA) = BUFS(NC)
        KAMAX(JA) = BUFS(NC+1)
        K2 = 2 * KAMAX(JA) + 2
        IF (JA - JAMAX) 100, 110, 110
      100 KC(JA+1) = KC(JA) + K2
      110 NC = NC + K2
      120 CONTINUE
        IF (LNN .EQ. 1) GO TO 200
C
C      WRITE ON MOTET PROGRAM TAPE
C
      WRITE (L) JAMAX, NWD, XND
      WRITE (L) (IMETAT(I), I=1, JAMAX), (KAMAX(I), I=1, JAMAX), (KC(I), I=1, JAMAX)
      WRITE (L) (BUFS(I), I=1, NWD)
      IF (J .NE. NSET) GO TO 150
      END FILE L
      RETURN
      150 CONTINUE
      J = J + 1
      IF ((-J) .LE. (-29)) GO TO 1
      GO TO 10
C
      200 CONTINUE
      WRITE (6,8) NWD
      WRITE (6,9) JAMAX, NWD
      WRITE (6,4) (KAMAX(I), I=1,4)
      WRITE (6,13) (KC(I), I=1,4)
      WRITE (6,12) (IMETAT(I), I=1,4)
C
      N = 1
      JA = JAMAX / 5
      JMAX = (JA - 1) * 5
      IF ((JMAX+5) .EQ. JAMAX) JMAX = JMAX - 5
      IF (JAMAX .LT. 10) GO TO 220
      DO 210 M = 5, JMAX, 5
        MM = M + 4
        WRITE (6,5) N, (IMETAT(I), I=M, MM)
        WRITE (6,15) N, (KAMAX(I), I=M, MM)
        WRITE (6,15) N, (KC(I), I=M, MM)
        N = N + 1
      210 CONTINUE
      220 CONTINUE
      JM = JMAX + 5
      WRITE (6,14) JAMAX, JAMAX, JAMAX
      NU = JAMAX - JM + 1
      GO TO (225, 226, 227, 228, 229), NU
      225 CONTINUE
      WRITE (6,19) N, (IMETAT(I), I=JM, JAMAX)
      WRITE (6,24) N, (KAMAX(I), I=JM, JAMAX)
      WRITE (6,24) N, (KC(I), I=JM, JAMAX)

```

AFWL-TR-67-131, Vol IV

```

GO TO 230
226 CONTINUE
WRITE (6,21) N, (THETAT(I), I=JM, JAMAX)
WRITE (6,25) N, (KAMAX(I), I=JM, JAMAX)
WRITE (6,25) N, (KC(I), I=JM, JAMAX)
GO TO 230
227 CONTINUE
WRITE (6,22) N, (THETAT(I), I=JM, JAMAX)
WRITE (6,26) N, (KAMAX(I), I=JM, JAMAX)
WRITE (6,26) N, (KC(I), I=JM, JAMAX)
GO TO 230
228 CONTINUE
WRITE (6,23) N, (THETAT(I), I=JM, JAMAX)
WRITE (6,27) N, (KAMAX(I), I=JM, JAMAX)
WRITE (6,27) N, (KC(I), I=JM, JAMAX)
GO TO 230
229 CONTINUE
WRITE (6,6) N, (THETAT(I), I=JM, JAMAX)
WRITE (6,16) N, (KAMAX(I), I=JM, JAMAX)
WRITE (6,16) N, (KC(I), I=JM, JAMAX)

```

```

C
230 CONTINUE
NX = NWU / 5
NZ = NX * 5
NY = NX / 8
N1 = NY * 8
LK = 1
IL = 45
IK = 1
NY = 9
IF (NZ .NE. NWU) GO TO 235
NZ = NZ - 5
IF (NX .EQ. N1) NY = NY - 1
N1 = NY * 8

```

```

C
235 CONTINUE
DO 260 JJ = 1, NY
WRITE (6,7) IK
DO 240 JJ = 1, 8
LN = LK + 4
WRITE (6,5) JJ, (BUPS(I), I=LK, LN)
LN = LK + 5

```

```

240 CONTINUE
LN = LK + 4
WRITE (6,6) NY, (BUPS(I), I=LK, LN)
LN = LK + 5
LS = LK - 44
WRITE (6,9) IK, IL
WRITE (6,11) LS, IK
IK = IK + 1

```

```

260 CONTINUE
C
N = 1
NS = N1 * 5
NU = NWU - NS

```

AFWL-TR-67-131, Vol IV

```

      WRITE (6,7) IK
      IF ((IX - NI) .EQ. 1) GO TO 280
      N15 = N5 + 1
      DO 270 JJ = N15,N2,5
      J4 = JJ + 4
      WRITE (6,5) N,(BUFS(1),I=JJ,J4)
      N = N + 1
270  CONTINUE
280  CONTINUE
      N3 = N2 + 1
      NK = NWD - N3 + 1
      GO TO (281,282,283,284,285),NK
281  CONTINUE
      WRITE (6,19) N,(BUFS(1),I=N3,NWD)
      GO TO 300
282  CONTINUE
      WRITE (6,21) N,(BUFS(1),I=N3,NWD)
      GO TO 300
283  CONTINUE
      WRITE (6,22) N,(BUFS(1),I=N3,NWD)
      GO TO 300
284  CONTINUE
      WRITE (6,23) N,(BUFS(1),I=N3,NWD)
      GO TO 300
285  CONTINUE
      WRITE (6,6) N,(BUFS(1),I=N3,NWD)
300  CONTINUE
      IK = IK + 1
      WRITE (6,9) IK,NU
      WRITE (6,11) N5,IK
      IF ((-J) .LE. (-29)) GO TO 1
      IF (J .EQ. NSET) RETURN
      J = J + 1
      GO TO 10
      END

```

punches the opacity data in the form of DATA statements for use in a FORTRAN IV program or writes the data on a binary tape.

All of the data in each material opacity set are read by REDGRE. However, the information punched on DATA statements or written on a tape by REDGRE contains all of the data from the opacity sets except the Planck opacities.

Input for REDGRE

CARD NO.	INPUT VARIABLE	COLUMNS	FORMAT
1	LRN	1	I1
2	NSET (1)	1-2	I2
and others needed	XMAT	3-18	E15.8
	XMAT (2) up to NSET	19-32	E15.8

LRN If LRN = 0, sets of grey opacities, temperatures, and densities are written on a tape; if LRN = 1, similar sets are punched in the form of DATA statements for use in a FORTRAN program

XMAT An array of material numbers corresponding to the grey sets to be obtained from the GREY tape

To use the REDGRE program, the following tapes must be mounted:

1. The GREY tape must be mounted on unit 10
2. The output tape must be mounted on unit 11 unless the user intends to punch DATA statements rather than write a tape.

TEDIUS: A GOLEM ADJUNCT

TEDIUS is a FORTRAN IV program, which converts weight fractions to number fractions. One input card is read (for each compound present) by:

```

      READ (5,201) (KA1,NO(N), ISTOIC (N), N = 1, 10), WTFRCT
201  FORMAT (20 (I2,IX), F10.5)

```

AFWL-TR-67-131, Vol IV

```

PROGRAM TEDIUS(INPUT,OUTPUT,TAPE5=INPUT,TAPE6=OUTPUT)
C
C
C   TEDIUS WRITTEN 7JULY1967 BY A.KNOPP
C
C   TEDIUS INPUTS COMPOUND FORMULAS AND WEIGHT FRACTIONS FOR MATERIALS
C   AND COMPUTES WEIGHT AND NUMBER FRACTIONS FOR THE ELEMENTS PRESENT.
C
C   A BLANK DATA CARD IS USED TO COMPLETE AND TERMINATE CALCULATIONS.
C
C   TEDIUS COMPUTES ONLY ONE MATERIAL PER RUN.
C
C
C   ALPHABETICAL DICTIONARY OF TERMS:
C
C   ATNO (KATNO) THE ATOMIC NUMBER (ATNO IS USED FOR PRINTOUT)
C   ATWT: THE ATOMIC WEIGHT
C   COEF (ISTOIC): THE SUBSCRIPT SPECIFYING THE NUMBER OF MOLES OF AN
C   ELEMENT IN A COMPOUND (COEF IS USED FOR PRINTOUT).
C   CUOMOL IS THE NUMBER OF MOLES OF THE COMPOUND.
C   FRAC12 IS THE WEIGHT FRACTION OF AN ELEMENT.
C   FRCTN IS THE NUMBER FRACTION OF AN ELEMENT.
C   ISTOIC (COEF): THE SUBSCRIPT SPECIFYING THE NUMBER OF MOLES OF AN
C   ELEMENT IN A COMPOUND.
C   KATNO IS THE ATOMIC NUMBER (INPUT DATA)
C   KNTR COUNTS THE NUMBER OF COMPOUNDS IN A MATERIAL.
C   NOLMNT 'COUNTS' THE NUMBER OF ELEMENTS PER COMPOUND.
C   SUMMOL IS THE SUM OF THE MOLES OF ALL ELEMENTS COMPUTED.
C   SUMOL IS THE SUM OF THE MOLES OF AN ELEMENT.
C   SUMWT IS THE SUM OF THE GRAM MOLECULAR WEIGHTS FOR ALL ELEMENTS.
C   WEIGHT IS THE GRAM MOLECULAR WEIGHT OF AN ELEMENT.
C   WIFRCT IS THE WEIGHT FRACTION OF A COMPOUND IN THE MATERIAL (INPUT)
C   WTMOL IS THE GRAM MOLECULAR WEIGHT OF A COMPOUND.
C
C
C
C   DIMENSION SUMOL(100), FRAC12(100), FRCTN(100), WEIGHT(100)
C   DATA SUMOL/100*0./
C   DATA SUMMOL/0./
C   DATA SUMWT/0./
C   COMMON /LMSB/U(1)
C   DIMENSION ATWT(100)
C   DATA ATWT /100*0./
C   DIMENSION KATNO(10), ISTOIC(10)
C   KNTR=0
C   KNTR COUNTS THE NUMBER OF DATA CARDS
C
C
C
105 CONTINUE
   KNTR=KNTR+1
   READ (5,201) (KATNO(N),ISTOIC(N),N=1,10),WTFRCT
201 FORMAT(20(12,1X),F10.5)
C   WEIGHT FRACTIONS ARE READ FROM COLUMNS 61 THRU 70
   WRITE(6,202)

```

AFWL-TR-67-131, Vol IV

```

202 FORMAT (///10(1X,4HATNO,1X,4HCOEF),6X,6HWIFRCT)
      WRITE(6,203)((KAINO(N),15IOIC(N),N=1,10),WTFRCT)
203 FORMAT (10(2X,12,4X,12),3X,F10.5/)
      IF(KAINO(1).EQ.0) GO TO 3000
C      IF KAINO(1).EQ.0, ALL DATA CARDS ARE READ, BEGIN FINAL CALCULATION
      WIMOL=0.
C      WIMOL IS THE GRAM MOLECULAR WEIGHT OF A COMPOUND.
      DO 1000 N=1,10
      IF (KATNO(N).EQ.0) GO TO 1001
      K=1
C
C
      101 CONTINUE
      IF ((1+IX(U(K)+.5).EQ.KATNO(N)) GO TO 102
      K=K+1+IX(U(K)+.5)+2
      GO TO 101
C
C
      102 ATWT(N)=U(K+1)
      WIMOL=ATWT(N)+FLOAT(15IOIC(N))+WIMOL
      WRITE(6,302) (ATWT(N),15IOIC(N),WIMOL)
      302 FORMAT (26H USING AN ATOMIC WEIGHT OF,F10.5,20H WITH THE SUBSCRIPT
      1,12,50H, THE CURRENT MOLECULAR WEIGHT OF THIS COMPOUND IS ,F13.6)
C
C
      1000 CONTINUE
      N=11
C
C
      1001 CONTINUE
      NOLMNI=N-1
      COEMOL=WTFRCT/WIMOL
C      COEMOL IS THE NUMBER OF MOLES OF THE COMPOUND.
C
C
      WRITE (6,303)
      303 FORMAT (1H )
      DO 2000 N=1,NOLMNI
C      12 IS THE ATOMIC NUMBER.
      12=KAINO(N)
C      SUMOL IS THE TOTAL MOLES FOR EACH ELEMENT.
      SUMOL(12)=SUMOL(12)+COEMOL*FLOAT(15IOIC(N))
C      WEIGHT(12) CONTAINS WEIGHT FRACTIONS OF ELEMENTS
      WEIGHT(12)=SUMOL(12)*ATWT(N)
      WRITE (6,402) (12,SUMOL(12),ATWT(N),WEIGHT(12))
      402 FORMAT (13H FOR ELEMENT ,12,13H, SUMOL = ,F13.6,12H, ATWT =
      1,F10.5,37H, AND THE GRAM MOLECULAR WEIGHT = ,F13.6)
      2000 CONTINUE
C
C
C
      GO TO 105
      3000 CONTINUE
      KNIX=KNIX-1
C

```

AFWL-TR-67-131, Vol IV


```

C
  DO 3001 I=1,100
    SUMMOL=SUMOL(I)+SUMMOL
  C
  SUMMOL IS THE TOTAL NUMBER OF MOLES OF ALL ELEMENTS
  SUMWT=WEIGHT(I)+SUMWT
3001 CONTINUE
  C
  FRCIN(I) CONTAINS NUMBER FRACTIONS OF ELEMENTS
  C
  C
  DO 4000 J=1,100
    IF (SUMOL(J).EQ.0.) GO TO 4040
    FRCIN(J)=SUMOL(J)/SUMMOL
    FRACTZ(J)=WEIGHT(J)/SUMWT
    WRITE (6,502) (J,FRCIN(J), FRACTZ(J))
  502 FORMAT (5HJZ = ,I3,10X,19H NUMBER FRACTION = ,F13.6,10X,19H WEIGHT
    1 FRACTION = ,F13.6)
  4040 CONTINUE
  4000 CONTINUE
    WRITE(6,602) KNTH, SUMMOL
  602 FORMAT (17/45HTHE NUMBER OF COMPOUNDS IN THIS MATERIAL IS ,I3,42H
    1 AND THE TOTAL MOLES OF THIS MATERIAL IS ,F13.6)
    WRITE (6,702)
  702 FORMAT (47HTEDEIUS COMPLETED SUCCESSFULLY (AND TEDIOUSLY).)
    CALL EXIT
    CALL NAME
    RETURN
  END

```


AFWL-TR-67-131, Vol IV

where KATNO (N) is the atomic number for the Nth element, ISTOIC (N) is the smallest integer subscript (for the Nth element) when the compound is written as



and WFRCT is the number of grams of this compound. (WFRCT can thus be the weight-percent if 100 grams are considered present.)

TEDIUS uses the MARIE subprogram (previously described) as its data source for atomic weights for all the elements. The compound molecular weight is calculated as

$$A = \sum_{N=1}^{N=M \leq 10} (M_N^O) (I_N),$$

where M_N^O is the atomic weight of the Nth element in the compound and $I_N = \text{ISTOIC}(N)$ as defined above. The number of moles of the compound is then calculated as

$$B = \text{WFRCT}/A$$

In addition, a cumulative summation is made of the number of moles and of the weight of each element present.

When all compound cards have been read, a blank final card signals the final computation phase. The total number of moles (of all elements) and the total weight (of all compounds present) is calculated. The total weight will ordinarily equal 100 gm if the several variables WFRCT were the weight-percents of the compounds read in. However, this calculation allows the variables WFRCT to sum to any number since the renormalization is then done. Finally, the number fraction and weight fraction are calculated for each element present in the total mixture.

EDSILV: A SILVIA TAPE EDIT PROGRAM

EDSILV can edit tapes written in SILVIA format. SILVIA, ZSASIL and ALOUETTE tapes are assumed to have the following SILVIA-tape format:

1. A first binary record containing:
 - a. FNTH, the number of temperatures
 - b. FIH, the number of absorption coefficients for each temperature-density point
 - c. HNUMIN, a number specifying the middle of the first frequency band, in eV
 - d. DHNV, a $\Delta h\nu$ in eV used as a frequency increment
2. A second binary record containing:
 - a. DIANET, the temperature in eV
 - b. FNRHO, the number of densities at that temperature
3. Third, fourth, . . . , FNRHO-th binary records containing, per record,
 - a. RHO, the density in gm/cc
 - b. SMU(k), the array of absorption coefficients for the lth temperature and Jth density point
$$1 \leq K \leq FIH$$
4. Binary records of types 2 and 3 follow until all temperature-density points have been completed

EDSILV was used to prepare the SILVIA, ZSAZSA, and ALOUETTE data for the DASLAC. The EDSILV output tapes are written in IBM compatible BCD format in even parity at 556 BPI. As each binary record is read from the SILVIA-type data tape, the data are written with the formats specified below onto a new data tape. All of the data are preserved in the transfer.

AFWL-TR-67-131, Vol IV

```

00101  1.  SUBROUTINE EUSILV
00101  2.  PROGRAM TO READ AND EDIT SILVIA-TYPE-FORMAT TAPE MADE BY ZSASIL
00101  3.  1 ON SILVIA OR ALUETO
00101  4.  C
00101  5.  C THIS PROGRAM HAS BEEN MODIFIED TO WRITE A SILVIA BCD TAPE
00101  6.  C BY L. R. MORRIS
00101  7.  C
00101  8.  C THE BCD TAPE MUST BE WRITTEN IN EVEN PARITY AT 556 BPI - THIS IS
00101  9.  C ACCOMPLISHED BY SPECIFYING THE K,E, AND M OPTIONS ON THE ASSIGN-
00101 10.  C MENT CARD
00101 11.  C
00101 12.  C
00101 13.  C COPIED BY CHRIS INLS APRIL 28, 1967
00101 14.  C
00101 15.  C ZSASIL, SILVIA, AND ALUETO WRITE DATA TAPES IN THE FOLLOWING
00101 16.  C FORMAT
00101 17.  C
00101 18.  C 1) A FIRST RECORD CONTAINING
00101 19.  C A) FNTH, NUMBER OF THETAS
00101 20.  C B) FFIN, NUMBER OF ABSORPTION COEFFICIENTS FOR EACH THETA-RHO
00101 21.  C POINT
00101 22.  C C) HNUMIN, VALUE IN THE MIDDLE OF THE FIRST FREQUENCY BAND
00101 23.  C (WAVES/CM CONVERTED TO EV)
00101 24.  C D) DMNU, A CONSTANT USED TO INCREMENT THE FREQUENCY
00101 25.  C (WAVES/CM CONVERTED TO EV)
00101 26.  C
00101 27.  C 2) A SECOND RECORD CONTAINING
00101 28.  C A) DIANT, TEMPERATURE IN EV
00101 29.  C B) FHRHO, THE NUMBER OF DENSITIES FOR THAT TEMPERATURE
00101 30.  C
00101 31.  C 3) THIRD, FOURTH, ..., FHRHO-TH RECORDS CONTAINING, PER RECORD,
00101 32.  C A) RHO
00101 33.  C B) SMU(K), THE ARRAY OF ABSORPTION COEFFICIENTS FOR THE
00101 34.  C I-TH THETA, J-TH RHO POINT. THE VALUE OF K RANGES FROM
00101 35.  C 1 TO (I*FIFA(FIN)), THE NUMBER OF ABSORPTION COEFFICIENTS
00101 36.  C
00101 37.  C 4) RECORDS OF TYPES 2 AND 3 FOLLOW UNTIL ALL THETA-RHO POINTS
00101 38.  C ARE COMPLETED
00101 39.  C
00101 40.  C
00101 41.  C DIMENSION THETA(16), RHO(20), SMU(300)
00101 42.  C INTEGER SILOUT
00101 43.  C SILOUT= 16
00101 44.  C NERIND SILOUT
00101 45.  C
00101 46.  C HEAD (5,30) IEDITO, IBCD1
00101 47.  C 30 FORMAT (2I2)
00101 48.  C IBCD1 IS THE UNIT ON WHICH THE BCD TAPE IS MOUNTED, UNLESS
00101 49.  C IBCD1 = 0
00101 50.  C IF IBCD1 IS 6, THEN SILVIA DATA CARDS ARE PUNCHED
00101 51.  C IF IBCD1 IS 0 AND IEDITO IS .NE. 0, THEN IBCD IS SET TO 15
00101 52.  C IF ((IBCD1 .EQ. 6) .AND. (IEDITO .NE. 0)) IBCD = 15
00101 53.  C IF IEDITO IS 0, THEN A SILVIA, ZSASIL, OR ALUETO TAPE IS EDITED
00101 54.  C IS .LT. 0, THEN A SILVIA, ZSASIL, OR ALUETO TAPE IS
00101 55.  C WRITTEN IN BCD ONLY
00101 56.  C IS .GT. 0, THEN A SILVIA, ZSASIL, OR ALUETO TAPE IS
00101 57.  C WRITTEN IN BCD AND THE BCD TAPE IS EDITED
00101 58.  C
00101 59.  C RHO IN GN/CM3
00101 60.  C THETA IN EV
00101 61.  C
00101 62.  C READ RECORD 1 OF THE ZSASIL (OR SILVIA) TAPE
00101 63.  C READ (SILOUT) FNTH,FIN, HNUMIN,DMNU
00101 64.  C
00101 65.  C FNTH IS WORD 1 OF RECORD 1, NUMBER OF TEMPERATURES
00101 66.  C FIN IS WORD 2 OF RECORD 1, THE NUMBER OF ABSORPTION COEFFICIENTS
00101 67.  C HNUMIN IS WORD 3 OF RECORD 1, THE FREQUENCY VALUE AT THE MIDDLE
00101 68.  C OF THE FIRST BAND (WAVES/CM CONVERTED TO EV)
00101 69.  C DMNU IS WORD 4 OF RECORD 1, THE FREQUENCY INCREMENT (WAVES/CM
00101 70.  C CONVERTED TO EV)
00101 71.  C
00101 72.  C I=1
00101 73.  C IFIX(FIN+.5)
00101 74.  C IFIX(FNTH+.5)
00101 75.  C
00101 76.  C IF (IEDITO .NE. 0)
00101 77.  C WRITE (IBCD,3) FNTH, FIN, HNUMIN, DMNU
00101 78.  C IF (IBCD1 .NE. 6) GO TO 77
00101 79.  C XA = FIN / 9.
00101 80.  C KA = IX / 9
00101 81.  C KA = KX
00101 82.  C IF (XA .GT. XA) KA = KX + 1

```

AFWL-TR-67-131, Vol IV

```

00144 52. 77 CONTINUE
00145 53. IF (IUCD1 .EQ. 6) PUNCH 3, FNTH, FIM, HNUMIN, DMNU
00154 54. IF (ICDIT0 .EQ. 0)
00154 55. 1WRITE (6,8002) FNTH, FIM, HNUMIN, DMNU
00163 55. 3 FORMAT (2F6.2,2L15.8)
00164 56. 8002 FORMAT (41)THE FOLLOWING DATA WAS READ FROM SILOUT /2IM RECORD 1
00164 57. 1 CONTAINING 2X,6FNTH =,F10.0,6M FIM =,F10.0,9M HNUMIN =,F10.4,
00164 58. 27M DMNU =,F10.4)
00165 59. IF (ICDIT0 .EQ. 0)
00165 60. 1WRITE (6,8005)
00170 60. 8005 FORMAT (24)RECORDS 2,3,...,N CONTAINING 1
00170 61. C
00170 62. C
00170 63. C READ RECORDS CONTAINING TEMPERATURE, NUMBER OF RHO'S, AND
00170 64. C ABSORPTION COEFFICIENTS
00170 65. C
00170 66. C
00171 67. DO 10 I=1, FNTH
00174 100. READ (SILOUT) DIANET, FNRHO
00174 101. C
00174 102. C FNRHO IS THE NUMBER OF DENSITIES AT EACH THETA
00174 103. C
00174 104. C NTHO= IFIX(FNRHO + .5)
00174 105. C THETA(I)= DIANET
00174 106. C IF (ICDIT0 .EQ. 0)
00174 107. C 1WRITE (IBCU,1) DIANET, FNRHO
00174 108. C 1 FORMAT (F10.4, F6.2)
00174 109. C IF (ICDIT0 .EQ. 0)
00174 110. C 1WRITE (6,8003) DIANET, FNRHO
00174 111. C IF (IUCD1 .EQ. 6) PUNCH 6, DIANET, FNRHO, I
00174 112. C 6 FORMAT (F10.4, F6.2, 57X, I3, 4H 0)
00174 113. C 8003 FORMAT (10)1 DIANET = , F10.5,5X, 7MFNRHO = ,1PE10.4)
00174 114. C DO 20 J=1, NTHO
00174 115. C READ (SILOUT) RHO(J), (SMU(K), K=1,IM)
00174 116. C IF (ICDIT0 .EQ. 0)
00174 117. C 1WRITE (IUCD,2) RHO(J), (SMU(K), K=1,IM)
00174 118. C IF (IUCD1 .EQ. 6) GO TO 75

```

AFWL-TR-67-131, Vol IV

```

00251 110.      KMAX = 0
00252 111.      KA = 1
00253 112.      PUNCH 7, RHO(J), J, KA
00254 113.      7 FORMAT (E10.3, 6X, I3, I4)
00255 114.      DO 70 L=1,KX
00256 115.      KA = L + 1
00257 116.      KMIN = KMAX + 1
00258 117.      KMAX = KMAX + 9
00259 118.      PUNCH 5, (SMU(K), K=KMIN,KMAX), J, KA
00260 119.      5 FORMAT (E10.3, I3, I3, I4)
00261 120.      70 CONTINUE
00262 121.      75 CONTINUE
00263 122.      2 FORMAT (E10.3, 15E5.3, / (16E8.3))
00264 123.      IF (IEDITO.EQ. 0)
00265 124.      1 WRITE (6,9004) RHO(J), (SMU(K), K=1,IM)
00266 125.      8004 FORMAT (1E40 FOR RHO = 1PE10.4,14H, SMU ARRAY IS / (36X,0P4E15.8))
00267 126.      20 CONTINUE
00268 127.      10 CONTINUE
00269 128.      C
00270 129.      IF (IEDITO.NE.0) END FILE IBCO
00271 130.      REWIND SILOUT
00272 131.      IF (IEDITO.NE.0) REWIND IBCO
00273 132.      IF (IEDITO.EQ. 0) GO TO 31
00274 133.      READ (IBCO,3) FNTH, FTH, MNMIN, DMNU
00275 134.      WRITE (6,9002) FNTH, FTH, MNMIN, DMNU
00276 135.      WRITE (6,9003)
00277 136.      IF (FTH) IFIX(FNTH + .5)
00278 137.      IF (FTH) IFIX(FTH + .5)
00279 138.      DO 50 I=1,MFNTH
00280 139.      READ (IBCO,1) DIAMET, FNRHO
00281 140.      WRITE (6,9003) DIAMET, FNRHO
00282 141.      IF (FNRHO) IFIX(FNRHO + .5)
00283 142.      DO 40 J=1,MRHO
00284 143.      READ (IBCO,2) RHO(J), (SMU(K), K=1,IM)
00285 144.      WRITE (6,9004) RHO(J), (SMU(K), K=1,IM)
00286 145.      40 CONTINUE
00287 146.      50 CONTINUE
00288 147.      WRITE (6,92)
00289 148.      42 FORMAT (30H0 A BCU DATA TAPE HAS BEEN WRITTEN AND EDITED SUCCESSFU
00290 149.      LLY.)
00291 150.      RETURN
00292 151.      31 CONTINUE
00293 152.      IF (IEDITO.EQ. 0) GO TO 7700
00294 153.      WRITE (6,94)
00295 154.      41 FORMAT (48H0 A BCU DATA TAPE HAS BEEN WRITTEN SUCCESSFULLY.)
00296 155.      RETURN
00297 156.      7700 CONTINUE
00298 157.      WRITE (6,7777) SILOUT
00299 158.      7777 FORMAT (66H1 EOSIL RUN COMPLETED SUCCESSFULLY. SILOUT DATA TAPE W
00300 159.      AS ON UNIT = I3, I4.)
00301 160.      RETURN
00302 161.      END

```

END OF LISTING. 3 *DIAGNOSTIC* MESSAGE(S).

EDSILV contains three write statements. These statements and their respective formats are:

```

WRITE(BCD,3) FNTH, FIH, HNUMIN, DHNU
3  FORMAT(2F6.2, 2E15.8)
WRITE(BCD,1) DIANET, FNRHO
1  FORMAT(F10.4, F6.2)
WRITE(BCD,2) RHO(J), (SMU(K), K=1, IH)
2  FORMAT(E10.5, 15E8.3, / (16E8.3))
    
```

The first write statement is used once to write the number of temperatures, the number of absorption coefficients for each temperature and density, the frequency value at the center of the first band, and the frequency increment used. The second write statement writes the temperature and the number of densities before a given set of densities and opacity values at that temperature. The last write statement writes the density and all of the absorption coefficient data at that density for each of the densities for a given temperature.

LEVELS: PARTIAL SUMS OF IONIZATION POTENTIALS

LEVELS is a FORTRAN IV subroutine used by AUGIAS in the preparation of tables of the possible states of a group of elements and tables of the transitions between the allowed states for each element. These tables are used by DIAPHANOUS (Ref. 3). LEVELS uses the MARI block data program as the source of the required ionization potentials. These are assembled into partial sums of the form:

$$S_n^i = \sum_{j=\ell}^n \phi_j^i; \quad n = \ell, \ell+1, \ell+2, \dots, Z^i,$$

where $\ell = \max(1, Z^i - 14)$, Z^i is the atomic number of the i th element in

AFWL-TR-67-131, Vol IV

```

SUBROUTINE LEVELS(NEL,NZ,WI,EIN)
C THIS PROGRAM SUMS THE IONIZATION POTENTIALS FOR ONE ELEMENT IN
C THE MAKI DECK EACH TIME THIS ROUTINE IS CALLED UNTIL THE ELEMENTS
C IN THE MAKI DECK HAVE BEEN EXHAUSTED
COMMON / LMSB / POTENL(5350)
COMMON/LHNA/K,L
DIMENSION SUM(100),SUMP(15),EIN(15),Z(100)
C
C INITIALIZE VARIABLES
DO 5 I = 1,15
SUMP(I) = 0.
EIN(I) = 0.
5 CONTINUE
C
C TEST TO SEE IF FIRST TIME THROUGH ROUTINE. IF SO,SKIP TO 10
IF (NZ .GT. 0) GO TO 10
C
L = 1
K = 1
Z(1) = POTENL(1)
NZ = Z(1) + .5
IZ = NZ
GO TO 60
10 CONTINUE
C
C TEST TO SEE IF ARE AT END OF MAKI DECK
IF (K .NE. (-NEL + 1)) GO TO 30
RETURN
30 CONTINUE
C FIND THE NEXT ELEMENT
Z(K) = POTENL(L)
NZ = Z(K) + .5
IZ = NZ
J = K - 1
DO 50 I = 1,J
IF ((I*IX(Z(I)+.5) .NE. IZ) GO TO 40
L = L + IZ + 2
GO TO 10
40 CONTINUE
50 CONTINUE
60 CONTINUE
WI = POTENL(L+1)
C
C CHECK HIGHEST IONIZATION POTENTIAL TO MAKE SURE THIS ELEMENT HAS A
C COMPLETE SET OF IONIZATION POTENTIALS
IF (POTENL(L+IZ+1) .GT. 0.) GO TO 70
L = L + IZ + 2
GO TO 10
C
70 CONTINUE
C SUM UP THE POTENTIALS TO OBTAIN THE DESIRED SUMS
M1 = MAX(1,IZ-14)
SUM(1) = 0.
DO 200 I = 1,M1

```

AFWL-TR-67-131, Vol IV

```

      SUM(I+1) = SUM(I) + POTENL(L+1+1)
200 CONTINUE
      SUMP(I) = SUM(MI+1)
      LZ = MINU(I2,14)
      IF (I2 .EQ. 1) GO TO 350
      DO 300 I = 1,LZ
      SUMP(I+1) = SUMP(I) + POTENL(MI+1+1+L)
300 CONTINUE
350 CONTINUE
C
C      STORE SUMS IN EIN ARRAY
      M = 1
      IF (I2 .GE. 15) LZ = 15
      DO 400 I1 = 1,LZ
      I = LZ + 1 - I1
      EIN(I) = SUMP(M)
      M = M + 1
400 CONTINUE
      L = L + I2 + 2
      K = K + 1
      WRITE (6,110) NZ,WT,EIN
110 FORMAT (17H1ATOMIC NUMBER = ,I3,3X,22H GRAM ATOMIC WEIGHT = ,F10.6
1      , // 3(1X,1P5E15.8/ ))
      RETURN
C
      CALL MARI
      RETURN
      END
      SUBROUTINE MERR
      RETURN
      END

```


the material.

$$\phi_{\ell}^1 \equiv \sum_{k=1}^{k=\ell} v_k^i \quad \phi_{j>\ell}^i \equiv v_j^i$$

and v_m^i is the m th ionization potential of the i th element where $1 \leq m \leq Z^i$.

AUGEAS was modified to call LEVELS if a blank card replaces the former input set of data cards, on which these partial sums were entered for the several elements (Ref. 3). (AUGEAS can thus be run in either mode.)

DLISTR: A DIAPHANOUS CARD EDIT CODE

The FORTRAN IV program DLISTR was written to prepare edits of DIAPHANOUS data from DYPER4 output cards. These cards contain summaries of the DIAPHANOUS thermodynamic data and approximations to the grey Rosseland and Planck opacities.

Tabular data prepared by DLISTR for most of the presently available DIAPHANOUS tapes are presented in reference 1. The table captions are self-explanatory.

DYPDIN: A RAPID TECHNIQUE FOR MAKING PSEUDO-DIANE TAPES

The DYPDIN program was written to provide extremely rapid response to the need for grey opacities for hydro code usage. DIAPHANOUS or ANN-ANHIST-ANDIMX code summary output is available in card form. These cards are read by DYPDIN and a pseudo-DIANE tape file is created in DIANE-tape format. At the same time, a set of DIANE cards can be punched (refer to DIANE card writeup).

AFWL-TR-67-131, Vol IV

```

00101 1. SUBROUTINE OLISTR
00101 2. C OLISTR IS A PROGRAM THAT ADS AND LISTS DIAPHANOUS OUTPUT CARDS.
00101 3. C CODED BY CHRIS IMES FEBR. 1967
00101 4. C
00101 5. C THIS PROGRAM ASSUMES DIAPHANOUS CARDS OCCUR IN SETS. ONE SET PER
00101 6. C DIAPHANOUS RUN.
00101 7. C THIS PROGRAM ASSUMES AT LEAST ONE SUCH SET IS INPUT.
00101 8. C
00101 9. C THE FIRST TWO CARDS OF A GIVEN SET CONTAIN COMMENTS ABOUT THAT SET.
00101 10. C THESE CARDS MAY SPECIFY ANY MESSAGE THE PROGRAMMER DESIRES, OR
00101 11. C THEY MAY BE LEFT BLANK.
00101 12. C
00101 13. C THE THIRD CARD OF A GIVEN SET IS A TITLE CARD WHICH IS IDENTICAL TO
00101 14. C THE TITLE ON THE CORRESPONDING DIAPHANOUS OUTPUT TAPE, THE DIAPHANOUS
00101 15. C OUTPUT PRINTOUT, AND THE DIAPHANOUS OUTPUT PLOTS FROM THE RUN WHICH
00101 16. C PRODUCED THIS CARD SET.
00101 17. C
00101 18. C THE FOURTH CARD OF A GIVEN SET IS A 'THETA' CARD. IT CONTAINS ONLY
00101 19. C A VALUE FOR THETA. IT IS FOLLOWED BY ONE OR MORE 'RHO' CARDS, EACH OF
00101 20. C WHICH CONTAINS THE FOLLOWING DATA
00101 21. C 1. RHO
00101 22. C 2. PRESSURE (PRESHR)
00101 23. C 3. ENERGY
00101 24. C 4. EION
00101 25. C 5. KROS (CAPAR)
00101 26. C 6. KPLK (CAPAC)
00101 27. C 7. ZBAR
00101 28. C 8. EGAM
00101 29. C THESE CARDS CONTINUE UNTIL THE NEXT THETA CARD FOR THAT MATERIAL,
00101 30. C OR UNTIL A NEW OLISTR CONTROL CARD IS ENCOUNTERED.
00101 31. C
00101 32. C
00101 33. C D L I S T R C O N T R O L C A R D S
00101 34. C THERE ARE TWO TYPES OF OLISTR CONTROL CARDS
00101 35. C
00101 36. C VARIABLE NAME COLUMNS FORMAT MEANING
00101 37. C
00101 38. C DO ME 1-6 A6 DO ME HAS ONLY THREE VALUES
00101 39. C 1. IF(DO ME.EQ.START) THE RUN BEGINS.
00101 40. C OLISTR PRINTS MESSAGES AND EXPECTS
00101 41. C TO READ ANOTHER CONTROL CARD.
00101 42. C 2. IF(DO ME.EQ.NLWSET) CODE EXPECTS TO
00101 43. C BEGIN READING AND LISTING DIAPHANOUS
00101 44. C OUTPUT CARDS.
00101 45. C 3. IF(DO ME.EQ.ENDRUN) CODE CALLS EXIT.
00101 46. C ICHECK 67-72 F6.3 ICHECK HAS ONLY THREE VALUES
00101 47. C 1. IF(ICHECK.LT.0) OLISTR EXPECTS
00101 48. C READ ANOTHER 'DO ME' CARD.
00101 49. C 2. IF(ICHECK.EQ.0) CODE ASSUMES IT
00101 50. C IS READING A THETA CARD
00101 51. C 3. IF(ICHECK.GT.0) CODE ASSUMES IT
00101 52. C IS READING A RHO CARD
00101 53. C
00101 54. C
00101 55. C TO RUN OLISTR, THE CONTROL CARDS MUST BE PLACED CORRECTLY.
00101 56. C THE FIRST DATA CARD OF ANY RUN MUST CONTAIN THE WORD 'START' AS
00101 57. C THE VALUE OF THE VARIABLE 'DO ME'. IT ALSO CONTAINS THE NAME OF THE
00101 58. C PERSON DOING THE RUN AND THE DATE OF THE RUN
00101 59. C
00101 60. C VARIABLE NAME COLUMNS FORMAT VALUE
00101 61. C
00101 62. C DO ME 1-6 A6 START
00101 63. C LISTER 7-24 JAB (NAME OF PERSON DOING RUN)

```

AFWL-TR-67-131, Vol IV

00101	64.	C	MONTH	25-30	A6	(CURRENT MONTH)
00101	65.	C	DAY	31-33	A3	(CURRENT DAY)
00101	66.	C	YEAR	34-37	A4	(CURRENT YEAR)
00101	67.	C	TYPE	41-47	A6	TYPE.EQ,NORMAL IF STANDARD GAMMA SET; TYPE.EQ,0 IF NON-STANDARD GAMMA SET

00101 68. C
00101 69. C
00101 70. C
00101 71. C
00101 72. C
00101 73. C
00101 74. C
00101 75. C
00101 76. C
00101 77. C
00101 78. C
00101 79. C
00101 80. C
00101 81. C
00101 82. C
00101 83. C
00101 84. C
00101 85. C
00101 86. C
00101 87. C
00101 88. C
00101 89. C
00101 90. C
00101 91. C
00101 92. C
00101 93. C
00101 94. C
00101 95. C
00101 96. C
00101 97. C
00101 98. C
00101 99. C
00103 100. C
00104 101. C
00105 102. C
00106 103. C
00107 104. C
00110 105. C
00110 106. C
00110 107. C
00111 108. C
00113 109. C
00115 110. C
00117 111. C
00121 112. C
00121 113. C
00121 114. C
00121 115. C
00121 116. C
00123 117. C

THE SECOND DATA CARD OF ANY RUN MUST CONTAIN THE WORD 'NEWSET' AS THE VALUE OF THE VARIABLE 'DO ME'. 'NEWSET' MEANS A SET OF DIAPHANOUS OUTPUT CARDS WILL BE READ IN NEXT.

FOLLOWING THE SECOND DATA CARD IS THE SET OF DIAPHANOUS OUTPUT CARDS.

***** NOTE - TWO HEADER CARDS, FORMAT(12A6/9A6), MUST PRECEDE EACH COMPLETE DIAPHANOUS OUTPUT CARD SET *****

FOLLOWING THE LAST DATA CARD OF ANY PARTICULAR DIAPHANOUS OUTPUT CARD SET IS A CONTROL CARD WITH A NEGATIVE NUMBER IN COLUMNS 67-72 AS THE VALUE OF 'ICHECK'. WHEN THIS CARD IS READ, CODE EXPECTS THE NEXT CARD READ TO BE A DLISTR CONTROL CARD WITH A VALUE FOR 'DO ME'. IF THE FOLLOWING CARD CONTAINS 'NEWSET' AS THE VALUE OF 'DO ME', THE PRDGHAM WILL EXPECT TO READ ANOTHER DIAPHANOUS OUTPUT CARD SET. IF THAT CARD, HOWEVER, CONTAINS 'ENDRUN' AS THE VALUE OF 'DO ME', THE PROGRAM WILL EXIT NORMALLY.

CODE WILL EXPECT TO READ A CONTROL CARD HAVING 'START' AS THE VALUE OF 'DO ME' ONLY ONCE; AS THE FIRST DATA CARD OF ANY DLISTR RUN. CODE WILL EXPECT TO READ A CONTROL CARD HAVING 'ENDRUN' AS THE VALUE OF 'DO ME' ONLY ONCE; AS THE LAST DATA CARD OF ANY DLISTR RUN.

EACH DIAPHANOUS OUTPUT CARD SET MUST BE PRECEDED BY A DLISTR CONTROL CARD HAVING 'NEWSET' AS THE VALUE OF 'DO ME'. EACH DIAPHANOUS OUTPUT CARD SET MUST BE FOLLOWED BY A DLISTR CONTROL CARD HAVING A NEGATIVE NUMBER AS THE VALUE OF 'ICHECK'.

INTEGER DO ME, ENDRUN, START, TYPE
INTEGER HEADER,REMARK
DIMENSION LISTER(3)
DIMENSION REMARK(24), HEADER(12), WORD(8)
DIMENSION TEMSTO(500)
DIMENSION GAMMA(13)

DLISTR CONTROL CARDS
DATA ENDRUN/6HENDRUN/
DATA NEWSET/6HNEWSET/
DATA START/6HSTART /
DATA NORMAL/6HNORMAL/
DATA GAMMA/20., 100., 500., 2.5E3, 1.25E4, 6.25E4, 3.4E5, 2.E6,
1.3E7, 1.E8, 8.5E8, 8.E9, 8.5E10/
1

F D R M A T S

7000 FORMAT (126H ***** CURRENT DIAPHA

AFWL-TR-67-131, Vol IV

```

00123 118. INOUS DATA VALUES FOR SELECTED MATERIALS *****
00123 119. 2*****
00124 120. 7002 FORMAT (1M1,12A6,9A6)
00125 121. 7003 FORMAT ( 122H THETA SETS DONE FOR GAMMA VALUES OF 20.,100.
00125 122. 1.500.,2.5+03,1.25+04,6.25+04,3.4+05,2.+06,1.3+07,1.+08,8.5+08,8.+0
00125 123. 29+8.5+10 )
00126 124. 7004 FORMAT (1X,12A6)
00127 125. 7500 FORMAT (5A6,A3,A4,3X,A6)
00130 126. 7501 FORMAT (42X,13HLIST MADE BY ,3A6,3HON ,A6,A3,1X,A4)
00131 127. 7502 FORMAT (1M1)
00132 128. 7503 FORMAT (12A6/9A6/12A6)
00133 129. 7505 FORMAT (1/8H THETA = ,1PE10.4, 15H ELECTRON VOLTS)
00134 130. 7506 FORMAT (1P6E10.4,0P2F6,3)
00135 131. 7507 FORMAT (13H RHO(G/CM3),9X,7H(1BARS),10X,11HENG(ERGS/G),6X, 12HE
00135 132. 110H(ERGS/G),6X,11HROS(CM2/G),7X,11HPLK(CM2/G),10X,4H2BAR, 8X,
00135 133. 24H6AM/(6(1PE12.4,6X),2(2X,0PF8,3,2X)))
00136 134. 7600 FORMAT (80HDLISTR CONTROL CARD ERROR. CHECK FOR MISPELLED WORD O
00136 135. 1R MISPLACED CARD IN NSET= ,13,1H.)
00137 136. 7601 FORMAT (88HDIAPHANOUS CARD ERROR. DLISTR WAS EXPECTING TO READ A
00137 137. 1THETA CARD, BUT IT FOUND WORD(2)= ,E12.4 / 46HOCHECK FOR MISPLACED
00137 138. 2 OR MISSING CARD IN NSET= ,13,1H.)
00140 139. 7602 FORMAT (100HDIAPHANOUS CARD ERROR. DLISTR WAS EXPECTING TO READ A
00140 140. 1 THETA CARD, BUT IT FOUND A CARD WITH THETA=0./36HOCHECK FOR AN IN
00140 141. 2VALID CARD IN NSET= ,13,1H.)
00141 142. 7603 FORMAT (119HDIAPHANOUS CARD INPUT ERROR. DLISTR WAS EXPECTING TO
00141 143. 1READ THE FIRST RHO CARD, BUT THE CARD IT READ HAS A VALUE OF ZERO/
00141 144. 255HOFOR THE PRESSURE. CHECK FOR AN INVALID CARD IN NSET= ,13,1H.)
00142 145. 7604 FORMAT (121HDIAPHANOUS CARD INPUT ERROR. DLISTR WAS EXPECTING TO
00142 146. 1READ THE FIRST RHO CARD, BUT THE CARD IT READ HAS A VALUE LESS THA
00142 147. 2N/46H01 FOR K. CHECK FOR AN INVALID CARD IN NSET= ,13,1H.)
00143 148. 7605 FORMAT (111HDIAPHANOUS CARD INPUT ERROR. DLISTR WAS EXPECTING TO
00143 149. 1READ A RHO CARD, BUT THE CARD IT READ HAS A VALUE OF ZERO/47HOFOR
00143 150. 2RHO. CHECK FOR AN INVALID CARD IN NSET= ,13,1H.)
00144 151. 7900 FORMAT (1M1,42X,48HDLISTING OF DIAPHANOUS OUTPUT CARDS IS COMPLETED
00144 152. 1.)
00144 153. C
00144 154. C
00144 155. C
00145 156. B E G I N T H E R U N
00146 157. NSET= -1
00147 158. 500 CONTINUE
00147 159. NSET= NSET+1
00150 159. READ (5,7500) DD ME, (DLISTR(L),L=1,3), MONTH, DAY, YEAR, TYPE
00163 160. IF (DD ME .EQ. ENDRUN) GO TO 530
00165 161. IF (DD ME .EQ. START) GO TO 510
00167 162. IF (DD ME .EQ. NEWSET) GO TO 520
00171 163. GO TO 600
00171 164. DO ME .EQ. START
00172 165. C
00173 166. 510 CONTINUE
00173 166. WRITE (6,7502)
00175 167. WRITE (6,7000)
00177 168. WRITE (6,7501)(DLISTR(L),L=1,3), MONTH, DAY, YEAR
00210 169. GO TO 500
00210 170. C
00211 171. DO ME .EQ. NEWSET. START READING DIAPHANOUS OUTPUT CARD SET
540 CONTINUE

```

AFWL-TR-67-131, Vol IV

```

00212 172.      IF (NSET .EQ. 0) GO TO 600
00214 173.      KOUNTY = 1
00215 174.      READ (5,7503) (REMARK(II),II=1,21), (HEADER(JJ),JJ=1,12)
00227 175.      WRITE (6,7002) (REMARK(II),II=1,21)
00227 176.      C
00227 177.      C      K COUNTS THE NUMBER OF RHO CARDS FOR A GIVEN THETA.  K=0 FOR THE
00227 178.      C      THETA CARD.  AND K=1,2,...,N FOR THE NTH RHO CARD.
00235 179.      K=
00236 180.      IF (TYPE .EQ. NORMAL) GO TO 1
00240 181.      GO TO 550
00240 182.      C
00240 183.      C      TYPE .EQ. NORMAL:  PRINT OUT STANDARD GAMMA SET
00241 184.      1 CONTINUE
00242 185.      WRITE (6,7003)
00242 186.      C
00244 187.      550 CONTINUE
00245 188.      WRITE (6,7004) (HEADER(JJ), JJ=1,12)
00253 189.      540 CONTINUE
00253 190.      C      READ DATA CARD AND CHECK TO SEE WHETHER IT IS A CONTROL CARD, OR A
00253 191.      C      DIAPHANOUS THETA OR RHO CARD
00254 192.      K= K + 1
00255 193.      READ (5,7506) (WORD(I), I=1,8)
00263 194.      IF (WORD(8) .LT. 0.) GO TO 521
00263 195.      C      WORD(8) .LT. 0. MEANS A CONTROL CARD SIGNALING THE END OF THAT
00263 196.      C      DIAPHANOUS OUTPUT CARD SET WAS READ
00263 197.      C
00265 198.      IF (WORD(8) .GT. 0.) GO TO 524
00265 199.      C      WORD(8) .GT. 0. MEANS A RHO CARD WAS JUST READ
00265 200.      C
00265 201.      C      PAST THIS POINT WE SHOULD HAVE ONLY THETA CARDS.  WORD(1).LE.0. .OR,
00265 202.      C      WORD(2).NE.0. IS AN ERROR ON A THETA CARD.
00265 203.      C
00267 204.      *DIAGNOSTIC* THE TEST FOR EQUALITY BETWEEN NON-INTEGERS MAY NOT BE MEANINGFUL.
00267 204.      IF (WORD(2) .NE. 0.) GO TO 523
00271 205.      *DIAGNOSTIC* THE TEST FOR EQUALITY BETWEEN NON-INTEGERS MAY NOT BE MEANINGFUL.
00271 205.      IF (WORD(1) .LE. 0.) GO TO 522
00273 206.      IF (K .GE. 1) GO TO 520
00275 207.      WRITE (6,7505) WORD(1)
00300 208.      GO TO 540
00301 209.      400 CONTINUE
00302 210.      M = 1
00303 211.      GO TO 529
00303 212.      C
00303 213.      C      ICHECK.GT.0., CHECK VALUES OF K, WORD(1), AND WORD(2)
00303 214.      C      EXPECT THAT A RHO CARD IS BEING READ
00304 215.      524 CONTINUE
00305 216.      IF (K .EQ. 1) GO TO 400
00307 217.      529 CONTINUE
00310 218.      IF (K .LT. 1) GO TO 531
00312 219.      *DIAGNOSTIC* THE TEST FOR EQUALITY BETWEEN NON-INTEGERS MAY NOT BE MEANINGFUL.
00312 219.      IF (WORD(2) .EQ. 0.) GO TO 525
00312 220.      C
00312 221.      C
00312 222.      C      PUT THE VALUES FROM THE RHO CARD INTO TEMPORARY STORAGE

```

AFWL-TR-67-131, Vol IV

```

00314 223. 546 CONTINUE
00315 224. DU 527 NN=1.8
00320 225. TENSTO(M)= WORD(MN)
00321 226. M= M+1
00322 227. 527 CONTINUE
00324 228. GO TO 540
00324 229. C
00324 230. C WRITE DIAPHANOUS OUTPUT CARD SET
00325 231. 526 CONTINUE
00326 232. 701 CONTINUE
00327 233. K= 0 * (K-1)
00330 234. WRITE (6.7507) (TENSTO(L), L=1,KK)
00336 235. K= 0
00336 236. C K COUNTS THE NUMBER OF RHO CARDS FOR A GIVEN THETA. K=0 FOR THE
00336 237. C THETA CARD, AND K=1,2,...,N FOR THE NTH RHO CARD.
00337 238. IF (WORD(8) .LT. 0.) GO TO 500
00341 239. KOUNTT = KOUNTT+1
00342 240. IF (KOUNTT.GT.3) WRITE (6.7502)
00345 241. IF (KOUNTT.GT.3) KOUNTT=1
00347 242. WRITE (6.7505) WORD(1)
00352 243. GO TO 540
00352 244. C
00352 245. C NORMAL EXIT POINT
00353 246. 530 CONTINUE
00354 247. IF (NSET .EQ. 0) GO TO 600
00356 248. WRITE (6.7502)
00360 249. WRITE (6.7900)
00362 250. RETURN
00362 251. C
00363 252. 541 CONTINUE
00364 253. IF (K .LE. 1) GO TO 600
00366 254. GO TO 701
00366 255. C
00366 256. C E R R O R E X I T S
00366 257. C
00366 258. C ERROR FOUND IN CHECKING THE VALUES OF A THETA CARD) THETA.EQ.0.
00367 259. 542 CONTINUE
00370 260. WRITE (6.7502)
00372 261. WRITE (6.7602) NSET
00375 262. RETURN
00375 263. C
00375 264. C ERROR FOUND IN CHECKING THE VALUES OF A THETA CARD) WORD(2) .NE. 0
00376 265. 543 CONTINUE
00377 266. WRITE (6.7502)
00401 267. WRITE (6.7601) WORD(2), NSET
00405 268. RETURN
00405 269. C
00405 270. C ERROR FOUND IN CHECKING A RHO CARD) WORD(2) .EQ. 0.
00406 271. 545 CONTINUE
00407 272. WRITE (6.7502)
00411 273. WRITE (6.7603) NSET
00414 274. RETURN
00414 275. C
00414 276. C ERROR FOUND IN CHECKING A RHO CARD) K.LT.1
00415 277. 531 CONTINUE
00416 278. WRITE (6.7502)
00420 279. WRITE (6.7604) NSET
00423 280. RETURN
00423 281. C
00423 282. C ERROR FOUND IN CHECKING A RHO CARD) WORD(1).EQ.0.
00424 283. 532 CONTINUE
00425 284. WRITE (6.7502)
00427 285. WRITE (6.7605) NSET
00432 286. RETURN
00432 287. C
00432 288. C OLIST CONTROL CARD ERROR
00433 289. 600 CONTINUE
00434 290. WRITE (6.7502)
00436 291. WRITE (6.7600) NSET
00441 292. RETURN
00442 293. END

```

END OF LISTING: 3 *DIAGNOSTIC* MESSAGE(S).

Input for DYPDIN

CARD NO.	COLUMNS	FORMAT	DESCRIPTION
1	1-12	I12	IDA: a right-justified DIANE run identification number
2	1-72	12A6	The DIANE tape title
3	1-2	I2	UNIT: tape mounting unit
3	5-6	I2	ID0 : if 0, write tape and punch DIANE cards. If 1, only punch DIANE cards. If 2, only write tape

AFWL-TR-67-131, Vol IV

```

00101 1. SUBROUTINE DYPDIN
00101 2. C
00101 3. C PROGRAM TO READ DIAPHANOUS-TYPE OUTPUT DATA CARDS AND PUNCH
00101 4. C DIANTC-FORMAT DATA CARDS AND/OR WRITE A DIANE NEW-FORMAT-STYLE
00101 5. C DATA TAPE (ONE FREQUENCY GROUP ONLY)
00101 6. C
00101 7. C
00103 8. DIMENSION ID(12),WORD(8),BUFS(1000),TEMSTO (100)
00104 9. DATA K/-1/,M/1/, IWD/1/,KCOUNT/0/,KK/0/,MMUT/1./,X1/-1.E6/
00114 10. INTEGER UNIT
00114 11. C
00115 12. READ(5,7000) IDA, ID,UNIT, IDO
00126 13. 7000 FORMAT ( I12/ 12A6/ 12,2X,12)
00127 14. WRITE (6,700) IDA, ID, UNIT, IDO
00140 15. 700 FORMAT ( 18H INPUT AS READ IS / 5X,7H IDA = ,112 / 5X,6H ID = ,
00140 16. 1 12A6 / 5X, 6H UNIT = ,12 / 5X, 7H IDO = ,12)
00140 17. C
00140 18. C IDA IS A 12 DIGIT IDENTIFICATION NUMBER, RIGHT JUSTIFIED
00140 19. C ID IS A HEADER CARD ARRAY
00140 20. C
00140 21. C IDO=0 IF WRITE TAPE AND PUNCH CARDS
00140 22. C IDO=1 IF PUNCH CARDS ONLY
00140 23. C IDO=2 IF WRITE TAPE ONLY
00140 24. C
00140 25. C READ DIAPHANOUS-TYPE DATA CARDS
00140 26. C
00141 27. 1 CONTINUE
00142 28. READ(5,7001) (WORD(N), N=1,8)
00150 29. 7001 FORMAT(6E10,4,2F6.3)
00151 30. K=K+1
00151 31. C
00151 32. C WORD(8).GT.0. MEANS A RHO CARD WAS JUST READ
00152 33. C IF(WORD(8).GT.0.) GO TO 10
00152 34. C
00154 35. C IF (K .GE. 1) GO TO 20
00156 36. C BUFS(IWD)= ALOG(WORD(1))
00157 37. C GO TO 1
00157 38. C
00157 39. C
00160 40. 10 CONTINUE
00161 41. C IF (K.EQ.1) M=2
00163 42. 11 CONTINUE
00163 43. C
00164 44. C TEMSTO (M) = ALOG(WORD(5))
00165 45. C TEMSTO (M+1) = ALOG (WORD(6))
00166 46. C TEMSTO (M+2) =ALOG (WORD(1))
00167 47. C M=M+3
00170 48. C GO TO 1
00170 49. C
00170 50. C
00171 51. 20 CONTINUE
00172 52. C KK= 3 *(K-1) +KK
00173 53. C TEMSTO(1)= K-1
00174 54. C MM= M - 1
00174 55. C
00175 56. C DO 21 MMM=1,MM
00200 57. C 11WD = IWD + MMM
00201 58. C BUFS(11WD) = TEMSTO (MMM)

```


AFWL-TR-67-131, Vol IV

```

00402 59. 21 CONTINUE
00404 60. IWD = IWD+1
00405 61. K=0
00406 62. KCOUNT = KCOUNT + 1
00406 63. C
00407 64. KWORD= WORD(1) * .5
00410 65. IF (KWORD .EQ. 0) GO TO 30
00412 66. BUFS(IWD)= ALOG(WORD(1))
00413 67. GO TO 1
00413 68. C
00414 69. 30 CONTINUE
00415 70. FNWD= 2 * KCOUNT + KK
00416 71. X= KCOUNT
00417 72. IF (ID0.EQ.2) GO TO 40
00421 73. PUNCH 7503,IDA
00424 74. 7503 FORMAT (I12)
00425 75. PUNCH 7504, (ID(1),I=1,12)
00433 76. 7504 FORMAT (12A6)
00434 77. PUNCH 7505, MNUT,FNWD
00440 78. 7505 FORMAT (6E12.7)
00441 79. NWD= FNWD
00442 80. IF (NWD.GT.1000)CALL MERR
00444 81. XX= FNWD/6.
00445 82. KX = NWD/6
00446 83. AA= KX
00447 84. IF (XX.GT.AX) KX= KX+1
00451 85. DO 31 I=1,2
00454 86. IX=I
00455 87. IF (I.EQ.2) XI=.001
00457 88. PUNCH 7507,X1,X2,IX
00459 89. 7507 FORMAT(2E12.7,49X,I3,4H 0)
00465 90. KMAX=0
00466 91. DO 31 KLIND=1,KX
00471 92. KKLIND= KLIND
00472 93. KMIN= KMAX +1
00473 94. KMAX= KMAX +6
00474 95. PUNCH 7506,((BUFS(IWD),IWD=KMIN,KMAX),IX,KKLIND)
00484 96. 7506 FORMAT (6E12.7,IX,I3,I4)
00485 97. 31 CONTINUE
00486 98. NOC = 2*(KX+1) + 3
00487 99. WRITE (6,7508) NOC
00488 100. 7508 FORMAT (30H PUNCHING IS COMPLETED NO. OF CARDS = ,I5)
00489 101. IF (ID0.EQ.1) GO TO 50
00490 102. 40 CONTINUE
00491 103. REWIND UNIT
00492 104. WRITE (UNIT) IDA,(ID(1),I=1,12)
00493 105. WRITE (UNIT) MNUT,FNWD
00494 106. DO 41 I=1,2
00495 107. XI= -1.E6
00496 108. IF (I.EQ. 2) XI = .001
00497 109. WRITE (UNIT) X1,X2
00498 110. WRITE (UNIT) (BUFS(IWD),IWD=1,NWD)
00499 111. 41 CONTINUE
00500 112. END FILE UNIT
00501 113. REWIND UNIT
00502 114. WRITE (6,7601) UNIT
00503 115. 7601 FORMAT (30H DIANE TAPE WRITTEN ON UNIT = ,I2)
00504 116. CALL EDIANE(10.0)
00505 117. C
00506 118. C
00507 119. 50 CONTINUE
00508 120. WRITE (6,7602)
00509 121. 7602 FORMAT ( 22H DYPDIN RUN COMPLETED.)
00510 122. C
00511 123. RETURN
00512 124. END

```

END OF LISTING. 0 =DIAGNOSTIC MESSAGE(S).

This page intentionally left blank.

APPENDIX I

AIRMOL AND CMOL DATA TABULATED BY GOLEMAIRMOL RESULTS

The following output illustrates AIRMOL/EIONX answers for selected temperature-density rectangles (TRAIL = 7.) done by GOLEM. The column captions refer to:

<u>COLUMN</u>	<u>NAME</u>	<u>UNITS</u>	<u>MEANING</u>
1	THETA	$^{\circ}\text{K}$	temperature; ordinarily given in eV (1 eV = 11605.4 $^{\circ}\text{K}$)
2	RHO	gm/cc	ρ , density
3	P1	atm	
4	E	ergs/gm	specific internal energy; includes $E_0 \simeq 2.9 \times 10^{11}$ ergs/gm
5	NBAR EIONIZ		NBAR, the mean no. of atoms/molecule, is printed when NBAR \neq 1. EIONIZ, the ionization contribution to the specific internal energy, is printed when NBAR = 1
6	SYNPOT		$\text{SYNPOT} = \theta_{\text{eV}} \ln \Gamma$ [$\Gamma \simeq 0.01 A \theta^{3/2} / (\rho \bar{Z})$] ($A \simeq 14.549$ for AIRMOL)
7	FEW		$\text{FEW} \equiv \text{ZBAR} \equiv \bar{Z}$, the mean ion charge
8	CV	ergs/gm/eV	$\text{CV} \equiv \left(\frac{\partial E}{\partial \theta} \right)_{\rho}$; θ in eV
9	PB1	ergs/cc	$\text{PB1} \equiv \left(\frac{\partial E}{\partial \tau} \right)_{\theta}$; $\tau = 1/\rho$
10	ASQ	cm/sec	equilibrium sound speed
11	EGAM		$1 + P/[\rho(E - E_0)]$; $E_0 \simeq 2.9 \times 10^{11}$ ergs/gm for AIRMOL
12	EGAM2		$1 + P/(\rho E)$

244

THETA	HMO	PI	E	CAPAC/ EIONIZ	CAPAC/ SYMPT	FEW	CV	P81	ASO	EGM	EGM2/ BAYM
2.500+03	1.293-03	9.169+00	2.261+10	1.988+00	7.230+00	.00000	1.613+11	1.268+05	9.497+08	9.731-01	1.321+00
2.500+03	1.293-02	9.161+01	2.228+10	1.990+00	6.982+00	.00000	1.361+11	9.026+05	9.475+08	9.732-01	1.322+00
2.500+03	1.293-01	9.159+02	2.224+10	1.990+00	6.734+00	.00000	1.318+11	1.276+06	9.485+08	9.732-01	1.323+00
2.500+03	1.293+00	9.158+03	2.222+10	1.991+00	6.486+00	.00000	1.311+11	4.043+06	9.488+08	9.732-01	1.323+00
3.000+03	1.293-10	1.338-06	6.423+10	1.635+00	9.427+00	.00000	2.941+11	1.635+01	1.107+05	9.536-01	1.163+00
3.000+03	1.293-09	1.331-05	6.245+10	1.643+00	9.129+00	.00000	1.722+11	1.633+01	1.144+05	9.541-01	1.167+00
3.000+03	1.293-08	1.327-04	6.159+10	1.649+00	8.832+00	.00000	1.495+11	1.158+05	1.158+05	9.543-01	1.169+00
3.000+03	1.293-07	1.311-03	5.944+10	1.668+00	8.534+00	.00000	2.497+11	2.412+02	1.116+05	9.554-01	1.173+00
3.000+03	1.293-06	1.258-02	5.096+10	1.743+00	8.236+00	.00000	5.176+11	6.950+03	1.061+05	9.589-01	1.193+00
3.000+03	1.293-05	1.172-01	3.879+10	1.867+00	7.939+00	.00000	4.557+11	5.640+04	1.025+05	9.634-01	1.237+00
3.000+03	1.293-04	1.123+00	3.184+10	1.944+00	7.641+00	.00000	3.752+11	2.397+05	1.016+05	9.658-01	1.277+00
3.000+03	1.293-03	1.108+01	2.919+10	1.975+00	7.344+00	.00000	1.870+11	8.304+05	1.022+05	9.667-01	1.297+00
3.000+03	1.293-02	1.102+02	2.829+10	1.984+00	7.046+00	.00000	1.553+11	2.703+06	1.028+05	9.676-01	1.303+00
3.000+03	1.293-01	1.100+03	2.801+10	1.989+00	6.748+00	.00000	1.451+11	8.633+06	1.031+05	9.671-01	1.308+00
3.000+03	1.293+00	1.099+04	2.792+10	1.990+00	6.451+00	.00000	1.418+11	2.747+07	1.032+05	9.671-01	1.309+00
3.500+03	1.293-10	1.688-06	1.012+11	1.512+00	9.889+00	.00000	1.827+12	2.074+00	1.195+05	9.299-01	1.131+00
3.500+03	1.293-09	1.596-05	7.893+10	1.599+00	9.542+00	.00000	7.137+11	7.287+00	1.177+05	9.410-01	1.160+00
3.500+03	1.293-08	1.564-04	7.015+10	1.631+00	9.195+00	.00000	3.108+11	2.443+01	1.197+05	9.442-01	1.173+00
3.500+03	1.293-07	1.551-03	6.733+10	1.643+00	8.847+00	.00000	1.867+11	1.081+02	1.230+05	9.454-01	1.181+00
3.500+03	1.293-06	1.534-02	6.502+10	1.663+00	8.500+00	.00000	2.022+11	2.001+03	1.222+05	9.465-01	1.185+00
3.500+03	1.293-05	1.477-01	5.895+10	1.728+00	8.153+00	.00000	3.720+11	6.081+04	1.168+05	9.501-01	1.199+00
3.500+03	1.293-04	1.381+00	4.619+10	1.845+00	7.626+00	.00000	2.843+11	6.025+05	1.122+05	9.556-01	1.234+00
3.500+03	1.293-03	1.319+01	3.845+10	1.935+00	7.459+00	.00000	2.573+11	2.774+06	1.105+05	9.589-01	1.269+00
3.500+03	1.293-02	1.295+02	3.534+10	1.972+00	7.111+00	.00000	1.858+11	9.459+06	1.105+05	9.601-01	1.287+00
3.500+03	1.293-01	1.286+03	3.424+10	1.984+00	6.764+00	.00000	1.592+11	3.238+07	1.108+05	9.606-01	1.294+00
3.500+03	1.293+00	1.283+04	3.393+10	1.989+00	6.417+00	.00000	1.503+11	1.040+08	1.110+05	9.607-01	1.296+00
4.000+03	1.293-10	2.518-06	2.360+11	1.158+00	1.035+01	.00002	3.583+12	5.502+00	1.462+05	6.341-01	1.084+00
4.000+03	1.293-09	2.108-05	1.455+11	1.384+00	9.935+00	.00001	2.617+12	3.968+01	1.336+05	8.856-01	1.114+00
4.000+03	1.293-08	1.891-04	9.773+10	1.542+00	9.559+00	.00000	1.131+12	1.618+02	1.276+05	9.229-01	1.152+00
4.000+03	1.293-07	1.810-03	7.991+10	1.612+00	9.162+00	.00000	4.632+11	5.609+02	1.272+05	9.325-01	1.177+00
4.000+03	1.293-06	1.778-02	7.340+10	1.641+00	8.765+00	.00000	2.361+11	2.238+03	1.290+05	9.356-01	1.194+00
4.000+03	1.293-05	1.748-01	6.973+10	1.669+00	8.368+00	.00000	2.143+11	2.745+04	1.301+05	9.378-01	1.196+00
4.000+03	1.293-04	1.671+00	6.173+10	1.745+00	7.971+00	.00000	3.212+11	6.276+05	1.251+05	9.426-01	1.212+00
4.000+03	1.293-03	1.565+01	5.047+10	1.864+00	7.574+00	.00000	3.060+11	5.376+06	1.205+05	9.488-01	1.243+00
4.000+03	1.293-02	1.502+02	4.373+10	1.942+00	7.178+00	.00000	2.192+11	2.364+07	1.187+05	9.522-01	1.269+00
4.000+03	1.293-01	1.477+03	4.109+10	1.974+00	6.781+00	.00000	1.738+11	8.287+07	1.184+05	9.535-01	1.282+00
4.000+03	1.293+00	1.469+04	4.020+10	1.985+00	6.384+00	.00000	1.572+11	2.706+08	1.185+05	9.539-01	1.286+00
4.500+03	1.293-10	3.239-06	3.200+11	1.013+00	1.037+01	.00021	6.207+11	1.639+00	1.723+05	1.842+00	1.079+00
4.500+03	1.293-09	2.999-05	2.750+11	1.094+00	1.037+01	.00007	2.387+12	4.584+01	1.607+05	3.942-01	1.086+00
4.500+03	1.293-08	2.516-04	1.786+11	1.304+00	9.933+00	.00002	2.564+12	2.256+02	1.469+05	8.228-01	1.110+00
4.500+03	1.293-07	2.190-03	1.148+11	1.498+00	9.477+00	.00001	1.525+12	2.256+03	1.377+05	9.028-01	1.149+00
4.500+03	1.293-06	2.056-02	8.893+10	1.596+00	9.031+00	.00000	5.226+11	8.342+03	1.355+05	9.198-01	1.181+00
4.500+03	1.293-05	2.000-01	7.938+10	1.641+00	8.584+00	.00000	2.646+11	3.504+04	1.372+05	9.256-01	1.197+00
4.500+03	1.293-04	1.944+00	7.322+10	1.688+00	8.138+00	.00000	2.365+11	4.214+05	1.367+05	9.297-01	1.209+00
4.500+03	1.293-03	1.836+01	6.321+10	1.788+00	7.691+00	.00000	2.846+11	6.449+06	1.316+05	9.345-01	1.228+00
4.500+03	1.293-02	1.729+02	5.335+10	1.898+00	7.283+00	.00000	2.423+11	4.113+07	1.275+05	9.427-01	1.254+00
4.500+03	1.293-01	1.677+03	4.847+10	1.957+00	6.799+00	.00000	1.870+11	1.633+08	1.261+05	9.456-01	1.271+00
4.500+03	1.293+00	1.658+04	4.648+10	1.979+00	6.352+00	.00000	1.693+11	5.944+08	1.257+05	9.466-01	1.279+00
5.000+03	1.293-10	3.647-06	3.332+11	1.001+00	1.128+01	.00135	1.893+11	1.798-01	1.908+05	1.688+00	1.604+00
5.000+03	1.293-09	3.607-05	3.260+11	1.011+00	1.079+01	.00063	4.638+11	8.994+01	1.840+05	1.784+00	1.607+00
5.000+03	1.293-08	3.370-04	2.461+11	1.062+00	1.029+01	.00016	1.819+12	4.240+02	1.716+05	3.345+00	1.693+00

[illegible]

THETA	HMO	PI	E	CAPAR/ E10N12	CAPAC/ SYNPOY	FEW	CV	PBI	ASO	EGAM	EGAM2/ GAMMA
6.000+03	1.293-10	4.474-06	3.632+11	1.000+00	1.223+01	-02249	6.987+11	1.395+00	2.012+05	1.478+00	1.097+00
6.000+03	1.293-09	4.406-05	3.481+11	1.000+00	1.162+01	-00722	3.006+11	4.766+00	2.093+05	1.593+00	1.099+00
6.000+03	1.293-08	4.371-04	3.417+11	1.003+00	1.103+01	-00229	2.843+11	3.698+01	2.145+05	1.662+00	1.100+00
6.000+03	1.293-07	4.270-03	3.262+11	1.025+00	1.043+01	-00073	1.835+11	1.839+03	1.995+05	1.922+00	1.103+00
6.000+03	1.293-06	3.816-02	2.599+11	1.147+00	0.834+00	-00023	1.601+12	5.379+04	1.840+05	2.243+03	1.115+00
6.000+03	1.293-05	3.186-01	1.685+11	1.374+00	0.233+00	-00007	1.254+12	4.125+05	1.680+05	7.944-01	1.148+00
6.000+03	1.293-04	2.829+00	1.179+11	1.547+00	0.644+00	-00002	5.928+11	1.767+06	1.599+05	8.711-01	1.188+00
6.000+03	1.293-03	2.634+01	9.673+10	1.849+00	0.443+00	-00001	3.057+11	8.191+06	1.579+05	9.923-01	1.215+03
6.000+03	1.293-02	2.493+02	8.372+10	1.755+00	0.453+00	-00000	2.993+11	6.949+07	1.548+05	9.052-01	1.233+00
6.000+03	1.293-01	2.336+03	7.248+10	1.571+00	0.658+00	-00000	2.059+11	4.782+08	1.498+05	9.157-01	1.251+00
6.000+03	1.293+00	2.249+04	6.698+10	1.346+00	0.263+00	-00000	1.722+11	2.083+09	1.469+05	9.210-01	1.263+00
6.500+03	1.293-10	5.048-06	4.097+11	1.000+00	1.272+01	-00508	1.349+12	3.921+00	2.099+05	1.330+00	1.097+00
6.500+03	1.293-09	4.841-05	3.665+11	1.000+00	1.205+01	-02143	5.945+11	1.345+01	2.111+05	1.495+00	1.103+00
6.500+03	1.293-08	4.769-04	3.518+11	1.001+00	1.140+01	-00687	2.726+11	4.895+01	2.198+05	1.604+00	1.106+00
6.500+03	1.293-07	4.719-03	3.435+11	1.007+00	1.075+01	-00218	2.732+11	6.570+02	2.197+05	1.690+00	1.108+00
6.500+03	1.293-06	4.501-02	3.137+11	1.054+00	1.011+01	-00069	8.805+11	3.276+04	2.031+05	2.881+00	1.112+00
6.500+03	1.293-05	3.854-01	2.271+11	1.230+00	0.460+00	-00022	1.803+12	5.488+05	1.855+05	5.188-01	1.133+00
6.500+03	1.293-04	3.281+00	1.486+11	1.454+00	0.815+00	-00007	8.357+11	3.096+06	1.713+05	8.191-01	1.172+00
6.500+03	1.293-03	2.960+01	1.117+11	1.601+00	0.170+00	-00002	4.011+11	1.314+07	1.656+05	8.698-01	1.208+00
6.500+03	1.293-02	2.762+02	9.404+10	1.716+00	0.523+00	-00001	2.547+11	8.108+07	1.626+05	8.893-01	1.230+00
6.500+03	1.293-01	2.574+03	8.142+10	1.841+00	0.881+00	-00000	2.074+11	5.795+08	1.575+05	9.032-01	1.248+00
6.500+03	1.293+00	2.455+04	7.398+10	1.930+00	0.236+00	-00000	1.745+11	2.693+09	1.537+05	9.109-01	1.260+00
7.000+03	1.293-10	5.900-06	5.048+11	1.000+00	1.324+01	-15376	2.948+12	8.827+00	2.255+05	1.215+00	1.092+00
7.000+03	1.293-09	5.379-05	4.032+11	1.000+00	1.248+01	-00390	1.160+12	3.309+01	2.184+05	1.372+00	1.105+00
7.000+03	1.293-08	5.193-04	3.671+11	1.000+00	1.177+01	-01759	4.581+11	1.127+02	2.218+05	1.527+00	1.111+00
7.000+03	1.293-07	5.123-03	3.541+11	1.002+00	1.107+01	-00562	2.466+11	5.182+02	2.304+05	1.625+00	1.113+00
7.000+03	1.293-06	5.021-02	3.400+11	1.019+00	1.036+01	-00178	4.116+11	1.465+04	2.214+05	1.785+00	1.116+00
7.000+03	1.293-05	4.563-01	2.830+11	1.119+00	0.682+00	-00856	1.131+12	5.044+05	2.037+05	4.173+00	1.126+00
7.000+03	1.293-04	3.802+00	1.891+11	1.343+00	0.980+00	-00014	1.029+12	4.546+06	1.853+05	7.043-01	1.157+00
7.000+03	1.293-03	3.315+01	1.315+11	1.540+00	0.293+00	-00006	5.235+11	2.097+07	1.745+05	8.360-01	1.198+00
7.000+03	1.293-02	3.044+02	1.055+11	1.677+00	0.599+00	-00002	2.886+11	1.043+08	1.700+05	8.707-01	1.226+00
7.000+03	1.293-01	2.820+03	9.021+10	1.810+00	0.905+00	-00001	2.161+11	6.908+08	1.649+05	8.893-01	1.245+00
7.000+03	1.293+00	2.667+04	8.110+10	1.914+00	0.210+00	-00000	1.774+11	3.407+09	1.604+05	8.999-01	1.258+00
7.500+03	1.293-10	7.128-06	6.593+11	1.000+00	1.382+01	-30328	4.003+12	1.352+01	2.479+05	1.151+00	1.085+00
7.500+03	1.293-09	6.110-05	4.713+11	1.000+00	1.294+01	-11729	2.052+12	6.920+01	2.310+05	1.264+00	1.102+00
7.500+03	1.293-08	5.645-04	3.935+11	1.000+00	1.216+01	-03956	7.953+11	2.479+02	2.272+05	1.430+00	1.113+00
7.500+03	1.293-07	5.535-03	3.664+11	1.001+00	1.148+01	-01274	3.382+11	8.720+02	2.336+05	1.567+00	1.118+00
7.500+03	1.293-06	5.454-02	3.539+11	1.007+00	1.065+01	-00407	2.665+11	7.920+03	2.372+05	1.668+00	1.121+00
7.500+03	1.293-05	5.169-01	3.223+11	1.055+00	0.907+00	-00124	7.011+11	3.356+05	2.207+05	2.256+00	1.126+00
7.500+03	1.293-04	4.431+00	2.350+11	1.235+00	0.162+00	-00041	1.072+12	5.479+06	2.010+05	3.670-01	1.148+00
7.500+03	1.293-03	3.733+01	1.567+11	1.465+00	0.418+00	-00013	6.498+11	3.108+07	1.851+05	7.803-01	1.187+00
7.500+03	1.293-02	3.347+02	1.187+11	1.634+00	0.374+00	-00004	3.374+11	1.422+08	1.776+05	8.467-01	1.221+00
7.500+03	1.293-01	3.075+03	9.942+10	1.779+00	0.930+00	-00001	2.275+11	8.309+08	1.721+05	8.735-01	1.242+00
7.500+03	1.293+00	2.844+04	8.438+10	1.896+00	0.186+00	-00000	1.812+11	4.205+09	1.669+05	8.878-01	1.256+00
8.000+03	1.293-10	4.697-06	5.584+11	1.000+00	1.487+01	-49084	5.007+12	1.918+01	2.742+05	1.120+00	1.079+00
8.000+03	1.293-09	7.138-05	5.836+11	1.000+00	1.343+01	-22357	3.181+12	1.229+02	2.491+05	1.198+00	1.096+00
8.000+03	1.293-08	6.296-04	4.382+11	1.000+00	1.255+01	-07955	1.312+12	4.870+02	2.367+05	1.333+00	1.113+00
8.000+03	1.293-07	5.985-03	3.845+11	1.000+00	1.173+01	-02623	2.168+11	1.690+03	2.375+05	1.496+00	1.128+00
8.000+03	1.293-06	5.867-02	3.650+11	1.003+00	1.093+01	-00841	2.678+11	7.614+03	2.454+05	1.612+00	1.128+00
8.000+03	1.293-05	5.706-01	3.456+11	1.025+00	0.813+01	-00267	4.145+11	1.932+05	2.369+05	1.802+00	1.129+00
8.000+03	1.293-04	5.069+00	2.789+11	1.147+00	0.338+00	-00085	9.377+11	5.377+05	2.171+05	2.628+00	1.163+00

THETA	KNO	P1	E	CAPAC/ EUNIZ	CAPAC/ SYNPO	FEM	CV	P81	ASO	EGM	EGM2/ GAWA
8.000+03	1.293-03	4.421+01	1.870+11	1.582+00	8.548+00	-00027	7.506+11	4.185+07	1.972+05	6.785-01	1.177+00
8.000+03	1.293-02	3.680+02	1.344+11	1.585+00	7.750+00	-00008	5.951+11	1.950+08	1.859+05	8.186-01	1.215+00
8.000+03	1.293-01	3.340+03	1.093+11	1.747+00	6.957+00	-00003	2.439+11	1.017+09	1.791+05	8.551-01	1.250+00
8.000+03	1.293+00	3.107+04	9.588+10	1.877+00	6.163+00	-00001	1.864+11	5.116+09	1.732+05	8.745-01	1.254+00
8.500+03	1.293-10	9.684+04	9.378+11	1.060+00	1.535+01	-00010	1.591+12	6.049+00	2.942+05	1.117+00	1.081+00
8.500+03	1.293-09	8.439+05	7.308+11	1.000+00	1.398+01	-00156	3.738+12	1.601+02	2.711+05	1.150+00	1.090+00
8.500+03	1.293-08	7.095+04	5.089+11	1.000+00	1.297+01	-00156	1.995+12	8.521+02	2.501+05	1.250+00	1.109+00
8.500+03	1.293-07	6.503+03	4.122+11	1.000+00	1.207+01	-00024	7.874+11	3.111+03	2.840+05	1.417+00	1.124+00
8.500+03	1.293-06	6.289+02	3.779+11	1.001+00	1.121+01	-01596	3.404+11	1.128+04	2.997+05	1.560+00	1.130+00
8.500+03	1.293-05	6.157+01	3.604+11	1.012+00	1.036+01	-00509	2.945+11	1.224+05	2.511+05	1.684+00	1.134+00
8.500+03	1.293-04	5.712+00	3.145+11	1.087+00	9.515+00	-00161	7.090+11	4.395+06	2.325+05	2.823+00	1.142+00
8.500+03	1.293-03	4.772+01	2.206+11	1.300+00	8.671+00	-00051	7.985+11	5.081+07	2.105+05	6.607-01	1.170+00
8.500+03	1.293-02	4.050+02	1.525+11	1.531+00	7.828+00	-00016	4.543+11	2.685+08	1.949+05	7.689-01	1.208+00
8.500+03	1.293-01	3.619+03	1.199+11	1.713+00	6.985+00	-00005	2.646+11	1.262+09	1.862+05	8.332-01	1.236+00
8.500+03	1.293-00	3.336+04	1.037+11	1.858+00	6.181+00	-00002	1.929+12	6.177+09	1.794+05	8.596-01	1.252+00
9.000+03	1.293-10	1.060+05	1.007+12	1.000+00	1.625+01	-01535	1.657+12	6.686+00	3.681+05	1.116+00	1.083+00
9.000+03	1.293-09	9.923+05	8.931+11	1.000+00	1.460+01	-01196	1.372+12	6.019+01	3.000+05	1.129+00	1.087+00
9.000+03	1.293-08	8.139+04	6.113+11	1.000+00	1.340+01	-04014	2.759+12	1.327+03	2.575+05	1.198+00	1.104+00
9.000+03	1.293-07	7.124+03	4.537+11	1.000+00	1.282+01	-08555	1.153+12	5.295+03	2.534+05	1.341+00	1.123+00
9.000+03	1.293-06	6.744+02	3.951+11	1.001+00	1.149+01	-02820	4.651+11	1.861+04	2.542+05	1.520+00	1.134+00
9.000+03	1.293-05	6.583+01	3.724+11	1.006+00	1.059+01	-00904	2.723+11	1.031+05	2.607+05	1.625+00	1.139+00
9.000+03	1.293-04	6.269+00	3.403+11	1.050+00	9.684+00	-00287	5.015+11	3.193+06	2.472+05	1.975+00	1.144+00
9.000+03	1.293-03	5.364+01	2.588+11	1.225+00	8.800+00	-00091	7.804+11	5.555+07	2.244+05	1.970-01	1.165+00
9.000+03	1.293-02	4.460+02	1.732+11	1.472+00	7.907+00	-00029	5.073+11	3.336+08	2.044+05	7.005-01	1.202+00
9.000+03	1.293-01	3.913+03	1.116+11	1.677+00	7.014+00	-00009	2.680+11	1.568+09	1.934+05	8.063-01	1.233+00
9.000+03	1.293+00	3.572+04	1.118+11	1.834+00	6.121+00	-00003	2.009+11	7.818+09	1.856+05	8.429-01	1.250+00
9.500+03	1.293-10	1.158+05	1.080+12	1.000+00	1.714+01	-07124	1.749+12	7.465+00	3.218+05	1.115+00	1.084+00
9.500+03	1.293-09	9.582+04	9.541+11	1.000+00	1.540+01	-05289	1.453+12	6.766+01	3.131+05	1.128+00	1.089+00
9.500+03	1.293-08	7.362+11	7.362+11	1.000+00	1.389+01	-05552	3.037+12	1.598+03	2.877+05	1.155+00	1.100+00
9.500+03	1.293-07	7.888+03	5.127+11	1.000+00	1.378+01	-13855	1.598+12	8.326+03	2.658+05	1.277+00	1.121+00
9.500+03	1.293-06	7.250+02	4.187+11	1.003+00	1.178+01	-04682	6.383+11	3.016+04	2.603+05	1.441+00	1.136+03
9.500+03	1.293-05	7.010+01	3.846+11	1.003+00	1.042+01	-01513	3.034+11	1.238+05	2.667+05	1.491+00	1.143+00
9.500+03	1.293-04	6.765+00	3.587+11	1.023+00	9.875+00	-00442	3.677+11	2.267+06	2.604+05	1.770+00	1.144+00
9.500+03	1.293-03	5.967+01	2.869+11	1.163+00	8.931+00	-00153	7.049+11	5.500+07	2.383+05	1.471+01	1.163+00
9.500+03	1.293-02	4.910+02	1.959+11	1.413+00	7.988+00	-00048	5.472+11	4.072+08	2.154+05	5.907-01	1.196+00
9.500+03	1.293-01	4.240+03	1.443+11	1.640+00	7.045+00	-00015	3.124+11	1.934+09	2.004+05	7.725-01	1.229+00
9.500+03	1.293+00	3.815+04	1.203+11	1.816+00	6.102+00	-00005	2.099+11	8.661+09	1.914+05	8.238-01	1.249+00
1.000+04	1.293-10	1.260+05	1.158+12	1.010+12	1.404+01	-72737	1.841+12	8.287+00	3.353+05	1.114+00	1.085+00
1.000+04	1.293-09	1.176+04	1.018+12	1.000+00	1.421+01	-61287	1.510+12	7.805+01	3.264+05	1.127+00	1.091+00
1.000+04	1.293-08	1.041+03	8.757+11	1.000+00	1.443+01	-48300	3.361+12	1.950+03	3.093+05	1.145+00	1.097+00
1.000+04	1.293-07	9.823+03	5.920+11	1.000+00	1.316+01	-21084	2.083+12	1.210+04	2.807+05	1.229+00	1.117+00
1.000+04	1.293-06	7.828+02	4.508+11	1.000+00	1.208+01	-07362	8.583+11	4.662+04	2.686+05	1.381+00	1.136+00
1.000+04	1.293-05	7.454+01	3.990+11	1.002+00	1.106+01	-02407	3.686+11	1.712+05	2.717+05	1.535+00	1.146+00
1.000+04	1.293-04	7.244+00	3.730+11	1.017+00	1.006+01	-00778	3.022+11	1.742+06	2.727+05	1.661+00	1.152+00
1.000+04	1.293-03	6.556+01	3.150+11	1.115+00	9.062+00	-00244	5.987+11	5.001+07	2.520+05	3.043+00	1.163+00
1.000+04	1.293-02	5.559+02	2.199+11	1.352+00	8.070+00	-00077	5.691+11	4.730+09	2.264+05	3.954-01	1.192+00
1.000+04	1.293-01	4.581+03	1.581+11	1.600+00	7.077+00	-00024	3.342+11	2.348+09	2.088+05	7.289-01	1.226+00
1.000+04	1.293+00	4.045+04	1.292+11	1.784+00	6.085+00	-00008	2.188+11	1.051+10	1.977+05	8.017-01	1.267+00
1.050+04	1.293-10	1.345+05	1.239+12	1.078+12	1.894+01	-78340	1.933+12	9.152+00	3.492+05	1.113+00	1.084+00
1.050+04	1.293-09	1.273+04	1.085+12	1.000+00	1.701+01	-66303	1.545+12	8.101+01	3.344+05	1.126+00	1.092+00
1.050+04	1.293-08	1.162+03	9.469+11	1.000+00	1.511+01	-54388	1.289+12	7.293+02	3.293+05	1.141+00	1.099+00

THETA	KHO	PI	E	CAPAC/ ETONIZ	CAPAC/ SYNPOI	FEM	CV	P81	ASB	EGAM	EGAM2/ GAMMA
1.050+04	1.293-07	9.968-03	6.915+11	1.000+00	1.356+01	.30186	2.532+12	1.623+04	2.983+05	1.194+00	1.113+00
1.050+04	1.293-06	8.500-02	6.932+11	1.000+00	1.238+01	.11021	1.117+12	6.882+04	2.787+05	1.328+00	1.135+00
1.050+04	1.293-05	7.929-01	6.168+11	1.001+00	1.130+01	.03662	6.603+11	2.467+05	2.772+05	1.490+00	1.189+00
1.050+04	1.293-04	7.666+00	3.655+11	1.011+00	1.024+01	.01177	2.839+11	1.564+06	2.818+05	1.629+00	1.156+00
1.050+04	1.293-03	7.113+01	3.385+11	1.081+00	9.196+00	.02374	6.919+11	4.280+07	2.651+05	1.655+00	1.165+00
1.050+04	1.293-02	5.914+02	2.445+11	1.297+00	6.153+00	.00116	5.711+11	5.237+08	2.383+05	2.103-02	1.190+00
1.050+04	1.293-01	4.914+03	1.729+11	1.559+00	7.111+00	.00037	3.576+11	2.796+09	2.170+05	6.709-01	1.223+00
1.050+04	1.293+00	4.325+04	1.386+11	1.771+00	6.069+00	.00012	2.302+11	1.237+10	2.037+05	7.760-01	1.285+00
1.100+04	1.293-10	1.476-05	1.324+12	1.151+12	1.985+01	.83961	2.025+12	1.006+01	3.629+05	1.112+00	1.087+00
1.100+04	1.293-09	1.374-04	1.154+12	1.000+00	1.782+01	.71330	1.660+12	6.996+01	3.525+05	1.125+00	1.093+00
1.100+04	1.293-08	1.274-03	1.004+12	1.000+00	1.582+01	.58869	1.335+12	7.932+02	3.421+05	1.190+00	1.099+00
1.100+04	1.293-07	1.121-02	7.975+11	1.000+00	1.401+01	.39696	2.563+12	1.767+04	3.169+05	1.173+00	1.110+00
1.100+04	1.293-06	9.286-02	5.474+11	1.000+00	1.270+01	.13778	1.402+12	9.537+04	2.906+05	1.283+00	1.133+00
1.100+04	1.293-05	8.445-01	4.390+11	1.001+00	1.154+01	.03354	5.749+11	3.516+05	2.837+05	1.444+00	1.151+00
1.100+04	1.293-04	6.105+00	3.979+11	1.007+00	1.043+01	.01733	2.961+11	1.659+06	2.687+05	1.508+00	1.160+00
1.100+04	1.293-03	7.636+01	3.577+11	1.057+00	9.331+00	.00552	4.044+11	3.559+07	2.774+05	1.603+00	1.167+00
1.100+04	1.293-02	6.456+02	2.688+11	1.246+00	8.238+00	.00175	5.344+11	5.542+08	2.501+05	1.391+00	1.188+00
1.100+04	1.293-01	5.296+03	1.865+11	1.518+00	7.146+00	.00055	3.753+11	3.259+09	2.255+05	5.910-01	1.220+00
1.100+04	1.293+00	4.594+04	1.463+11	1.747+00	6.054+00	.00018	2.405+11	1.442+10	2.099+05	7.455-01	1.242+00

CMOL RESULTS

The following output illustrates CMOL/EIONX answers for a portion of the molecular checkout set (TRAIL = 6.) done by GOLEM. The column captions refer to:

<u>COLUMN</u>	<u>NAME</u>	<u>UNITS</u>	<u>MEANING</u>
1	THETA	$^{\circ}\text{K}$	temperature; ordinarily given in eV (1 eV = 11605.4 $^{\circ}\text{K}$)
2	RHO	gm/cc	density, ρ
3	P1	dynes/cm ²	pressure
4	E	ergs/gm	specific internal energy; includes $E_0 \simeq 6 \times 10^{11}$ ergs/gm
5	NBAR EIONIZ	ergs/gm	NBAR, the mean no. of atoms/molecule, is printed when NBAR \neq 1. EIONIZ is printed when NBAR = 1. EIONIZ is the ionization contribution to the specific internal energy
6	SYNPOT		$\theta_{\text{eV}} \ln \Gamma$ [$\Gamma \simeq 0.01 A \theta^{3/2} / (\rho \bar{Z})$] where A is the mean atomic weight. (A \simeq 12. for CMOL)
7	FEW		FEW = ZBAR = \bar{Z} , the mean ion charge
8	CV	ergs/gm/eV	$CV \equiv \left(\frac{\partial E}{\partial \theta} \right)_{\rho}$; θ in eV
9	PB1	ergs/cc	$PB1 \equiv \left(\frac{\partial E}{\partial \tau} \right)_{\theta}$; $\tau = 1/\rho$
10	ASQ	cm/sec	equilibrium sound speed
11	EGAM		$1 + \frac{P}{\rho(E-E_0)}$; $E_0 \simeq 6 \times 10^{11}$ ergs/gm for CMOL
12	EGAM2		$1 + \frac{P}{\rho E}$

THETA	MHD	P1	E	CAPAR/ E10W12	CAPAC/ SYNPO1	FEW	CV	P01	ASO	EGAW	EGAW2/ GAUWA
5.000+02	1.000-10	3.795-08	1.351+11	9.000+00	7.275-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-09	3.795-07	1.351+11	9.000+00	6.283-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-08	3.795-06	1.351+11	9.000+00	5.291-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-07	3.795-05	1.351+11	9.000+00	4.299-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-06	3.795-04	1.351+11	9.000+00	3.307-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-05	3.795-03	1.351+11	9.000+00	2.315-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-04	3.795-02	1.351+11	9.000+00	1.323-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-03	3.795-01	1.351+11	9.000+00	3.305-02	.00001	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-02	3.795+00	1.351+11	9.000+00	-6.615-02	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000-01	3.795+01	1.351+11	9.000+00	-1.654-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000+00	3.795+02	1.351+11	9.000+00	-2.646-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
5.000+02	1.000+01	3.795+03	1.351+11	9.000+00	-3.638-01	.00000	1.492+11	0.000	2.019+08	9.992-01	1.003+00
1.000+03	1.000-10	7.590-07	1.421+11	9.000+00	1.545+00	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-09	7.590-06	1.421+11	9.000+00	1.346+00	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-08	7.590-05	1.421+11	9.000+00	1.148+00	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-07	7.590-04	1.421+11	9.000+00	9.493-01	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-06	7.590-03	1.421+11	9.000+00	7.509-01	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-05	7.590-02	1.421+11	9.000+00	5.525-01	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-04	7.590-01	1.421+11	9.000+00	3.541-01	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-03	7.590+00	1.421+11	9.000+00	1.557-01	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-02	7.590+01	1.421+11	9.000+00	-4.271-02	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000-01	7.590+02	1.421+11	9.000+00	-2.411-01	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.000+03	1.000+00	7.590+03	1.421+11	9.000+00	-4.395-01	.00000	1.735+11	0.000	2.844+08	9.983-01	1.003+00
1.500+03	1.000-10	1.139-07	1.500+11	9.000+00	-6.379-01	.00000	1.919+11	0.000	3.475+08	9.974-01	1.008+00
1.500+03	1.000-09	1.139-06	1.500+11	9.000+00	6.781+00	.00000	1.919+11	4.225-14	3.475+08	9.974-01	1.008+00
1.500+03	1.000-08	1.139-05	1.500+11	9.000+00	6.632+00	.00000	1.919+11	1.336-13	3.475+08	9.974-01	1.008+00
1.500+03	1.000-07	1.139-04	1.500+11	9.000+00	6.483+00	.00000	1.919+11	4.225-13	3.475+08	9.974-01	1.008+00
1.500+03	1.000-06	1.139-03	1.500+11	9.000+00	6.335+00	.00000	1.919+11	4.225-12	3.475+08	9.974-01	1.008+00
1.500+03	1.000-05	1.139-02	1.500+11	9.000+00	6.186+00	.00000	1.919+11	4.225-12	3.475+08	9.974-01	1.008+00
1.500+03	1.000-04	1.139-01	1.500+11	9.000+00	6.037+00	.00000	1.919+11	1.336-11	3.475+08	9.974-01	1.008+00
1.500+03	1.000-03	1.139+00	1.500+11	9.000+00	6.098-01	.00000	1.919+11	0.000	3.475+08	9.974-01	1.008+00
1.500+03	1.000-02	1.139+01	1.500+11	9.000+00	3.122-01	.00000	1.919+11	0.000	3.475+08	9.974-01	1.008+00
1.500+03	1.000-01	1.139+02	1.500+11	9.000+00	1.454-02	.00000	1.919+11	0.000	3.475+08	9.974-01	1.008+00
1.500+03	1.000+00	1.139+03	1.500+11	9.000+00	-2.831-01	.00000	1.919+11	0.000	3.475+08	9.974-01	1.008+00
1.500+03	1.000+01	1.139+04	1.500+11	9.000+00	-5.807-01	.00000	1.919+11	0.000	3.475+08	9.974-01	1.008+00
2.000+03	1.000-10	4.476-07	2.406+11	9.000+00	-8.783-01	.00000	1.919+11	0.000	3.475+08	9.974-01	1.008+00
2.000+03	1.000-09	4.476-06	2.406+11	9.000+00	7.202+00	.00000	1.919+11	1.948-01	3.475+08	9.974-01	1.008+00
2.000+03	1.000-08	2.841-05	1.958+11	8.809+00	7.004+00	.00000	1.919+11	1.028+01	6.626+08	9.869-01	1.018+00
2.000+03	1.000-07	2.088-04	1.726+11	6.803+00	6.806+00	.00000	2.471+12	1.438+02	5.524+08	9.929-01	1.015+00
2.000+03	1.000-06	1.704-03	1.640+11	6.018+00	6.607+00	.00000	5.425+11	6.090+02	4.626+08	9.952-01	1.011+00
2.000+03	1.000-05	1.600-02	1.610+11	8.591+00	6.409+00	.00000	3.316+11	7.690+03	4.251+08	9.960-01	1.011+00
2.000+03	1.000-04	1.559-01	1.598+11	8.765+00	6.210+00	.00000	2.603+11	3.523+04	4.115+08	9.963-01	1.010+00
2.000+03	1.000-03	1.540+00	1.593+11	8.671+00	6.012+00	.00000	2.325+11	1.638+05	4.061+08	9.964-01	1.010+00
2.000+03	1.000-02	1.530+01	1.590+11	8.928+00	5.615+00	.00000	2.199+11	8.674+05	4.036+08	9.964-01	1.010+00
2.000+03	1.000-01	1.525+02	1.588+11	8.961+00	5.417+00	.00000	2.137+11	4.658+06	4.023+08	9.965-01	1.010+00
2.000+03	1.000+00	1.521+03	1.588+11	8.980+00	5.216+00	.00000	2.104+11	2.363+07	4.018+08	9.965-01	1.010+00
2.500+03	1.000-01	1.519+04	1.587+11	8.993+00	5.020+00	.00000	2.089+11	9.339+07	4.008+08	9.965-01	1.010+00
2.500+03	1.000-10	7.222-07	3.012+11	2.963+00	7.632+00	.00000	4.654+12	2.962+08	8.812+08	9.734-01	1.034+00
2.500+03	1.000-09	6.073-06	2.632+11	2.812+00	7.304+00	.00000	1.399+12	7.962+00	8.104+08	9.617-01	1.033+00
2.500+03	1.000-08	5.725-05	2.522+11	2.963+00	7.136+00	.00000	6.051+11	3.112+01	7.936+08	9.833-01	1.023+00

TIMEA	RMO	P1	E	CAPAC/ EIONIZ	CAPAC/ SYMPT	FEM	CV	PBI	ASO	EGAM	ESAM2/ BAWMA
2.500+03	1.000-07	9.334-04	2.430+11	3.202+00	6.880+00	.00000	8.523+11	6.550+02	7.667+04	9.848-01	1.022+00
2.500+03	1.000-06	9.095-03	2.162+11	4.170+00	6.640+00	.00000	1.692+11	6.675+04	9.891-01	9.891-01	1.019+00
2.500+03	1.000-05	2.798-02	1.878+11	6.103+00	6.392+00	.00000	1.085+12	8.478+04	9.931-01	9.931-01	1.015+00
2.500+03	1.000-04	2.239-01	1.754+11	7.626+00	6.144+00	.00000	5.294+11	3.086+05	9.879+04	9.944-01	1.013+00
2.500+03	1.000-03	2.042-00	1.710+11	8.363+00	5.896+00	.00000	3.313+11	1.131+06	9.650+04	9.952-01	1.012+00
2.500+03	1.000-02	1.965+01	1.693+11	8.644+00	5.648+00	.00000	2.633+11	6.690+06	9.559+04	9.954-01	1.012+00
2.500+03	1.000-01	1.933+02	1.685+11	8.837+00	5.400+00	.00000	2.376+11	2.176+07	9.517+04	9.954-01	1.012+00
2.500+03	1.000+00	1.915+03	1.682+11	8.918+00	5.152+00	.00000	2.257+11	1.046+08	9.495+04	9.955-01	1.012+00
2.500+03	1.000+01	1.903+04	1.680+11	8.967+00	4.904+00	.00000	2.218+11	4.495+08	9.481+04	9.955-01	1.011+00
2.500+03	1.000+02	1.896+05	1.678+11	9.027+00	4.648+00	.00000	1.590+12	1.522+09	9.466+04	2.731+00	1.033+00
2.500+03	1.000+03	1.891+06	1.675+11	9.082+00	4.392+00	.00000	8.591+12	8.316+01	1.299+05	8.512-01	1.032+00
2.500+03	1.000+04	1.886+07	1.672+11	9.137+00	4.135+00	.00000	4.656+12	2.774+02	1.027+05	9.622-01	1.029+00
2.500+03	1.000+05	1.881+08	1.669+11	9.192+00	3.879+00	.00000	1.578+12	1.307+03	9.094+04	9.758-01	1.027+00
2.500+03	1.000+06	1.876+09	1.666+11	9.247+00	3.622+00	.00000	7.510+11	6.120+03	8.683+04	9.794-01	1.027+00
2.500+03	1.000+07	1.871+10	1.663+11	9.296+00	3.365+00	.00000	1.291+12	1.198+05	8.491+04	9.833-01	1.025+00
2.500+03	1.000+08	1.866+11	1.660+11	9.345+00	3.108+00	.00000	1.080+12	1.255+06	8.273+04	9.893-01	1.025+00
2.500+03	1.000+09	1.861+12	1.657+11	9.394+00	2.851+00	.00000	5.909+11	5.431+06	8.050+04	9.928-01	1.016+00
2.500+03	1.000+10	1.856+13	1.654+11	9.443+00	2.594+00	.00000	3.611+11	1.989+07	7.509+04	9.938-01	1.014+00
2.500+03	1.000+11	1.851+14	1.651+11	9.492+00	2.337+00	.00000	2.761+11	7.762+07	6.937+04	9.942-01	1.014+00
2.500+03	1.000+12	1.846+15	1.648+11	9.541+00	2.080+00	.00000	2.452+11	3.312+08	6.961+04	9.944-01	1.013+00
2.500+03	1.000+13	1.841+16	1.645+11	9.590+00	1.823+00	.00000	2.329+11	1.406+09	6.922+04	9.945-01	1.013+00
2.500+03	1.000+14	1.836+17	1.642+11	9.639+00	1.566+00	.00000	1.631+11	4.153+02	1.911+05	1.805+00	1.039+00
2.500+03	1.000+15	1.831+18	1.639+11	9.688+00	1.309+00	.00000	3.921+11	3.849+00	1.744+05	1.802+00	1.039+00
2.500+03	1.000+16	1.826+19	1.636+11	9.737+00	1.052+00	.00000	2.994+12	6.023+02	1.572+05	1.126+00	1.038+00
2.500+03	1.000+17	1.821+20	1.633+11	9.786+00	8.268+00	.00000	5.497+12	7.096+03	1.288+05	9.074-01	1.035+00
2.500+03	1.000+18	1.816+21	1.630+11	9.835+00	7.011+00	.00000	2.825+12	2.877+04	1.058+05	9.627-01	1.032+00
2.500+03	1.000+19	1.811+22	1.627+11	9.884+00	5.756+00	.00000	1.012+12	1.112+05	9.622+04	9.733-01	1.030+00
2.500+03	1.000+20	1.806+23	1.624+11	9.933+00	4.501+00	.00000	8.902+11	1.250+06	8.833+04	9.792-01	1.028+00
2.500+03	1.000+21	1.801+24	1.621+11	9.982+00	3.246+00	.00000	8.832+11	1.307+07	7.365+04	9.868-01	1.023+00
2.500+03	1.000+22	1.796+25	1.618+11	1.001+00	2.000+00	.00000	5.274+11	3.967+07	6.187+04	9.908-01	1.019+00
2.500+03	1.000+23	1.791+26	1.615+11	1.006+00	1.742+00	.00000	3.383+11	2.230+08	5.657+04	9.924-01	1.016+00
2.500+03	1.000+24	1.786+27	1.612+11	1.011+00	1.487+00	.00000	2.686+11	8.624+08	5.445+04	9.930-01	1.015+00
2.500+03	1.000+25	1.781+28	1.609+11	1.016+00	1.230+00	.00000	2.431+11	3.483+09	5.350+04	9.933-01	1.015+00
2.500+03	1.000+26	1.776+29	1.606+11	1.021+00	1.000+00	.00000	1.965+11	6.275+02	1.989+05	1.744+00	1.044+00
2.500+03	1.000+27	1.771+30	1.603+11	1.026+00	8.956+00	.00000	2.695+11	4.873+01	1.912+05	1.765+00	1.044+00
2.500+03	1.000+28	1.766+31	1.600+11	1.031+00	8.701+00	.00000	1.695+11	3.057+01	1.912+05	1.628+00	1.044+00
2.500+03	1.000+29	1.761+32	1.597+11	1.036+00	8.446+00	.00000	2.941+11	2.791+03	1.724+05	1.648+00	1.043+00
2.500+03	1.000+30	1.756+33	1.594+11	1.041+00	8.191+00	.00000	1.178+12	2.119+04	1.556+05	8.418-01	1.040+00
2.500+03	1.000+31	1.751+34	1.591+11	1.046+00	7.936+00	.00000	2.340+12	3.651+05	1.481+05	9.488-01	1.037+00
2.500+03	1.000+32	1.746+35	1.588+11	1.051+00	7.681+00	.00000	1.065+12	1.554+06	1.403+05	9.672-01	1.034+00
2.500+03	1.000+33	1.741+36	1.585+11	1.056+00	7.426+00	.00000	8.576+11	1.521+07	9.264+04	9.767-01	1.030+00
2.500+03	1.000+34	1.736+37	1.582+11	1.061+00	7.171+00	.00000	6.877+11	1.189+08	7.803+04	9.854-01	1.024+00
2.500+03	1.000+35	1.731+38	1.579+11	1.066+00	6.916+00	.00000	4.208+11	5.051+08	6.873+04	9.897-01	1.019+00
2.500+03	1.000+36	1.726+39	1.576+11	1.071+00	6.661+00	.00000	2.982+11	1.893+09	5.986+04	9.913-01	1.017+00
2.500+03	1.000+37	1.721+40	1.573+11	1.076+00	6.406+00	.00000	2.533+11	7.298+09	5.782+04	9.919-01	1.016+00
2.500+03	1.000+38	1.716+41	1.570+11	1.081+00	6.151+00	.00000	4.544+11	4.000+01	1.959+05	1.628+00	1.048+00
2.500+03	1.000+39	1.711+42	1.567+11	1.086+00	5.896+00	.00000	2.807+11	1.314+00	2.062+05	1.701+00	1.044+00
2.500+03	1.000+40	1.706+43	1.564+11	1.091+00	5.641+00	.00000	1.875+11	9.335+00	2.125+05	1.735+00	1.049+00
2.500+03	1.000+41	1.701+44	1.561+11	1.096+00	5.386+00	.00000	3.177+11	4.349+02	2.017+05	1.812+00	1.049+00
2.500+03	1.000+42	1.696+45	1.558+11	1.101+00	5.131+00	.00000	1.507+12	3.295+03	1.822+05	8.898+00	1.048+00
2.500+03	1.000+43	1.691+46	1.555+11	1.106+00	4.876+00	.00000	3.085+12	6.589+05	1.530+05	8.318-01	1.044+00

THETA	NMO	P1	E	CAPAC/ EIONIZ	CAPAC/ SYNPUT	FEW	CV	PBI	ASO	EGAM	EGAM2/ GAMMA
4.500+03	1.000-04	1.399+00	3.555+11	2.197+00	6.728+00	.00001	1.804+12	3.499+06	1.251+05	9.417-01	1.040+00
4.500+03	1.000-03	1.070+01	2.991+11	2.873+00	6.281+00	.00000	9.509+11	1.812+07	1.092+05	9.638-01	1.036+00
4.500+03	1.000-02	7.767+01	2.593+11	3.958+00	5.835+00	.00000	7.598+11	1.856+08	9.250+04	9.768-01	1.030+00
4.500+03	1.000-01	5.298+02	2.290+11	5.803+00	5.389+00	.00000	5.069+11	9.179+08	7.535+04	9.855-01	1.023+00
4.500+03	1.000+00	4.153+03	2.151+11	7.403+00	4.942+00	.00000	3.331+11	3.572+09	6.613+04	9.490-01	1.020+00
4.500+03	1.000+01	3.705+04	2.099+11	8.294+00	4.996+00	.00000	2.648+11	1.337+10	6.233+04	9.903-01	1.018+00
4.500+03	1.000+02	3.547+06	6.833+11	1.000+00	9.869+00	.03840	1.300+12	1.800+00	2.012+05	1.424+00	1.053+00
4.500+03	1.000+03	3.458+08	6.584+11	1.000+00	9.367+00	.01231	5.175+11	5.857+00	2.057+05	1.506+00	1.053+00
4.500+03	1.000+04	3.428+04	6.503+11	1.000+00	8.869+00	.00391	2.638+11	1.957+01	2.157+05	1.672+00	1.053+00
4.500+03	1.000+05	3.413+03	6.469+11	1.000+00	8.372+00	.03124	2.084+11	1.509+02	2.214+05	1.716+00	1.053+00
4.500+03	1.000+06	3.354+02	6.361+11	1.013+00	7.876+00	.00039	4.296+11	8.724+03	2.079+05	1.860+00	1.053+00
4.500+03	1.000+07	2.959+01	5.811+11	1.154+00	7.380+00	.00012	1.732+12	4.891+05	1.862+05	1.792-01	1.052+00
4.500+03	1.000+08	2.065+00	4.854+11	1.654+00	6.884+00	.00004	2.282+12	5.725+06	1.534+05	8.633-01	1.047+00
4.500+03	1.000+09	1.441+01	3.868+11	2.370+00	6.388+00	.00001	1.279+12	2.974+07	1.274+05	9.420-01	1.042+00
4.500+03	1.000+10	1.062+02	2.930+11	3.216+00	5.892+00	.00000	6.110+11	2.001+08	1.084+05	9.648-01	1.037+00
4.500+03	1.000+11	7.141+02	2.525+11	4.783+00	5.396+00	.00000	5.810+11	1.395+09	8.808+04	9.791-01	1.029+00
4.500+03	1.000+12	5.124+03	2.303+11	6.665+00	4.900+00	.00000	3.715+11	5.944+09	7.355+04	9.850-01	1.023+00
4.500+03	1.000+13	4.307+04	2.216+11	7.930+00	4.404+00	.00000	2.787+11	2.203+10	6.713+04	9.884-01	1.020+00
4.500+03	1.000+14	4.241+06	7.765+11	1.000+00	1.035+01	.12875	3.228+12	5.763+00	2.175+05	1.242+00	1.055+00
4.500+03	1.000+15	6.937+11	1.000+00	9.782+00	9.782+00	.04268	1.217+12	2.007+01	2.123+05	1.417+00	1.057+00
4.500+03	1.000+16	6.659+11	6.566+11	1.000+00	9.229+00	.01370	4.931+11	6.566+01	2.169+05	1.573+00	1.058+00
4.500+03	1.000+17	3.771+03	6.566+11	1.001+00	8.681+00	.00435	2.610+11	2.350+02	2.267+05	1.658+00	1.058+00
4.500+03	1.000+18	3.742+02	6.514+11	1.005+00	8.135+00	.00136	2.457+11	3.223+03	2.285+05	1.717+00	1.058+00
4.500+03	1.000+19	3.578+01	6.301+11	1.050+00	7.589+00	.00044	6.995+11	2.047+05	2.106+05	2.151+00	1.058+00
4.500+03	1.000+20	4.863+00	5.355+11	1.312+00	7.043+00	.00014	1.820+12	5.843+06	1.030+05	5.399-01	1.054+00
4.500+03	1.000+21	1.952+01	4.083+11	1.924+00	6.498+00	.00004	1.541+12	4.502+07	1.995+05	8.960-01	1.048+00
4.500+03	1.000+22	1.390+02	3.301+11	2.702+00	5.952+00	.00001	9.221+11	2.584+08	1.253+05	9.475-01	1.043+00
4.500+03	1.000+23	9.458+02	2.788+11	3.972+00	5.407+00	.00000	6.418+11	1.871+09	1.021+05	9.700-01	1.034+00
4.500+03	1.000+24	6.362+03	2.472+11	5.906+00	4.861+00	.00000	4.122+11	8.958+09	8.213+04	9.817-01	1.022+00
4.500+03	1.000+25	5.007+04	2.340+11	7.504+00	4.315+00	.00000	2.958+11	3.344+10	7.225+04	9.861-01	1.022+00
4.500+03	1.000+26	5.432+06	9.733+11	1.000+00	1.088+01	.32534	5.084+12	1.267+01	2.459+05	1.147+00	1.057+00
4.500+03	1.000+27	5.581+05	7.726+11	1.000+00	1.021+01	.11766	2.557+12	5.338+01	2.273+05	1.267+00	1.060+00
4.500+03	1.000+28	4.258+04	6.964+11	1.000+00	9.597+00	.02683	9.761+11	1.840+02	2.233+05	1.441+00	1.062+00
4.500+03	1.000+29	4.149+03	6.708+11	1.000+00	8.995+00	.01245	4.158+11	4.070+02	2.292+05	1.542+00	1.063+00
4.500+03	1.000+30	4.107+02	6.618+11	1.002+00	8.397+00	.00395	2.999+11	2.822+03	2.302+05	1.658+00	1.063+00
4.500+03	1.000+31	4.028+01	6.513+11	1.019+00	7.801+00	.00125	3.558+11	8.897+04	2.313+05	1.774+00	1.063+00
4.500+03	1.000+32	3.580+00	5.984+11	1.145+00	7.206+00	.00040	1.115+12	4.167+06	2.061+05	1.676+02	1.061+00
4.500+03	1.000+33	2.543+01	4.754+11	1.587+00	6.811+00	.00013	1.526+12	5.878+07	1.735+05	7.875-01	1.053+00
4.500+03	1.000+34	1.764+02	3.077+11	2.297+00	6.015+00	.00004	1.050+12	3.439+08	1.428+05	9.200-01	1.049+00
4.500+03	1.000+35	1.240+03	3.077+11	3.359+00	5.420+00	.00001	7.001+11	2.350+09	1.166+05	9.575-01	1.040+00
4.500+03	1.000+36	2.658+11	2.658+11	5.193+00	4.825+00	.00000	4.548+11	1.251+10	9.173+04	9.760-01	1.030+00
4.500+03	1.000+37	2.472+11	2.472+11	7.041+00	4.230+00	.00000	3.171+11	4.746+10	7.770+04	9.832-01	1.024+00
4.500+03	1.000+38	1.176+12	1.176+12	1.873+12	1.150+00	.52505	1.768+12	3.940+00	2.604+05	1.119+00	1.058+00
4.500+03	1.000+39	9.212+11	9.212+11	1.000+00	9.668+01	.26367	4.365+12	1.084+02	2.511+05	1.174+00	1.062+00
4.500+03	1.000+40	7.559+11	1.000+00	1.000+00	9.977+00	.09256	1.805+12	4.279+02	2.357+05	1.314+00	1.065+00
4.500+03	1.000+41	6.944+11	1.000+00	1.000+00	9.314+00	.03026	7.062+11	1.451+03	2.346+05	1.484+00	1.067+00
4.500+03	1.000+42	6.741+11	1.001+00	1.001+00	8.663+00	.00967	3.323+11	5.856+03	2.425+05	1.481+00	1.067+00
4.500+03	1.000+43	6.643+11	1.005+00	1.005+00	8.017+00	.00307	2.704+11	5.139+04	2.466+05	1.681+00	1.067+00
4.500+03	1.000+44	6.553+11	1.070+00	1.070+00	7.371+00	.00097	6.443+11	2.550+06	2.282+05	2.149+00	1.066+00
4.500+03	1.000+45	3.254+01	1.345+00	1.345+00	6.728+00	.00031	1.284+12	4.442+07	1.968+05	8.493-01	1.061+00
4.500+03	1.000+46	2.250+02	4.198+11	1.973+00	6.081+00	.00010	1.122+12	4.277+08	1.612+05	8.725-01	1.054+00

TMETA	HMO	P1	E	CAPAR/ EIONIZ	CAPAC/ SYMPTOT	FEW	CV	PBI	ASQ	ESAM	ESAM2/ GAMMA
6.500+03	1.000-01	1.535+03	3.393+11	2.892+00	5.437+00	.00003	7.663+11	2.873+09	1.315+05	9.400-01	1.086+00
6.500+03	1.000-00	9.737+03	2.864+11	4.561+00	5.792+00	.00001	5.013+11	1.653+10	1.021+05	9.684-01	1.039+00
6.500+03	1.000-01	6.760+04	2.614+11	6.548+00	4.147+00	.00000	3.436+11	6.394+10	8.361+04	9.797-01	1.026+00
7.000+03	1.000-10	7.615-06	1.255+12	1.000+00	1.247+01	.59253	1.900+12	4.584+00	2.971+05	1.118+00	1.062+00
7.000+03	1.000-09	7.078-05	1.140+12	1.000+00	1.121+01	.48011	1.504+12	1.604+02	2.825+05	1.132+00	1.063+00
7.000+03	1.000-08	5.648-04	8.564+11	1.000+00	1.038+01	.19356	2.936+12	2.899+02	2.843+05	1.224+00	1.067+00
7.000+03	1.000-07	5.090-03	7.341+11	1.000+00	9.642+00	.06441	1.169+12	3.043+03	2.441+05	1.380+00	1.070+00
7.000+03	1.000-06	4.840-02	6.914+11	1.000+00	8.934+00	.02044	4.860+11	1.025+04	2.471+05	1.532+00	1.072+00
7.000+03	1.000-05	4.795-01	6.759+11	1.000+00	8.235+00	.00644	2.813+11	1.985+04	2.552+05	1.628+00	1.072+00
7.000+03	1.000-04	4.625+00	6.573+11	1.036+00	7.539+00	.00210	4.129+11	1.525+06	2.466+05	1.797+00	1.071+00
7.000+03	1.000-03	3.894+01	5.852+11	1.225+00	6.844+00	.00067	9.819+11	4.735+07	2.177+05	1.952+00	1.067+00
7.000+03	1.000-02	2.770+02	4.681+11	1.727+00	6.150+00	.00021	1.110+12	4.806+08	1.795+05	7.848-01	1.060+00
7.000+03	1.000-01	1.892+03	3.739+11	2.528+00	5.455+00	.00007	8.416+11	3.435+09	1.62+05	9.147-01	1.051+00
7.000+03	1.000+00	1.190+04	3.092+11	4.018+00	4.761+00	.00002	5.575+11	2.101+10	1.130+05	9.583-01	1.039+00
7.000+03	1.000+01	7.833+04	2.769+11	6.105+00	4.066+00	.00001	3.771+11	8.278+10	8.929+04	9.753-01	1.029+00
7.500+03	1.000-10	4.506-06	1.338+12	1.209+12	1.336+01	.66019	2.010+12	5.275+00	3.191+05	1.117+00	1.064+00
7.500+03	1.000-09	7.968-05	1.223+12	1.102+12	1.198+01	.55329	1.447+12	4.707+01	3.082+05	1.129+00	1.066+00
7.500+03	1.000-08	6.847-04	1.007+12	1.000+00	1.082+01	.33647	4.019+12	1.373+03	2.793+05	1.170+00	1.069+00
7.500+03	1.000-07	5.750-03	7.966+11	1.000+00	9.983+00	.12237	1.780+12	6.158+03	2.582+05	1.294+00	1.073+00
7.500+03	1.000-06	5.330-02	7.161+11	1.000+00	9.210+00	.04046	6.977+11	2.483+04	2.549+05	1.459+00	1.075+00
7.500+03	1.000-05	5.143-01	6.886+11	1.001+00	8.457+00	.01398	3.350+11	1.325+05	2.629+05	1.583+00	1.076+00
7.500+03	1.000-04	5.073+00	6.742+11	1.014+00	7.710+00	.00412	4.134+11	1.274+06	2.612+05	1.680+00	1.076+00
7.500+03	1.000-03	4.563+01	6.257+11	1.124+00	6.965+00	.00131	1.030+12	5.974+07	2.423+05	2.706+00	1.074+00
7.500+03	1.000-02	3.381+02	5.106+11	1.516+00	6.221+00	.00041	1.123+12	6.278+08	2.084+05	6.106-01	1.067+00
7.500+03	1.000-01	2.324+03	4.048+11	2.205+00	5.476+00	.00013	8.231+11	4.656+09	1.714+05	8.785-01	1.059+00
7.500+03	1.000+00	1.456+04	3.277+11	3.519+00	4.732+00	.00004	4.909+11	2.969+10	1.339+05	9.455-01	1.045+00
7.500+03	1.000+01	9.067+04	2.840+11	5.651+00	3.988+00	.00001	1.789+11	1.044+11	1.085+05	9.708-01	1.032+00
8.000+03	1.000-10	9.443-06	1.928+12	1.284+12	1.425+01	.72801	2.143+12	6.015+00	3.308+05	1.115+00	1.057+00
8.000+03	1.000-09	8.830-05	1.297+12	1.162+12	1.278+01	.61562	1.795+12	5.370+01	3.221+05	1.128+00	1.069+00
8.000+03	1.000-08	8.226-04	1.180+12	1.055+12	1.132+01	.50524	1.410+12	4.725+02	3.135+05	1.143+00	1.071+00
8.000+03	1.000-07	6.613-03	8.889+11	7.484+11	1.034+01	.21000	2.512+12	9.150+03	2.744+05	1.231+00	1.075+00
8.000+03	1.000-06	5.858-02	7.527+11	6.636+11	9.494+00	.07198	1.014+12	3.420+04	2.685+05	1.385+00	1.079+00
8.000+03	1.000-05	5.592-01	7.047+11	6.197+11	8.682+00	.02335	4.179+11	1.139+05	2.685+05	1.534+00	1.080+00
8.000+03	1.000-04	5.506+00	6.090+11	6.053+11	7.883+00	.00744	2.161+11	3.661+05	2.816+05	1.617+00	1.081+00
8.000+03	1.000-03	5.372+01	6.747+11	1.020+00	7.088+00	.00075	1.259+12	7.600+07	2.657+05	1.715+00	1.081+00
8.000+03	1.000-02	4.189+02	5.668+11	1.308+00	6.294+00	.00036	1.516+12	8.516+08	2.359+05	3.369-01	1.075+00
8.000+03	1.000-01	2.903+03	4.463+11	1.882+00	5.500+00	.00024	1.130+12	6.551+09	1.949+05	8.066-01	1.066+00
8.000+03	1.000+00	1.810+04	3.523+11	3.025+00	4.706+00	.00007	6.669+11	4.296+10	1.514+05	9.255-01	1.052+00
8.000+03	1.000+01	1.052+05	2.924+11	5.197+00	3.912+00	.00002	2.116+11	1.319+11	1.156+05	9.652-01	1.036+00
8.500+03	1.000-10	1.043-05	1.523+12	1.364+12	1.514+01	.79598	2.276+12	6.804+00	3.474+05	1.114+00	1.069+00
8.500+03	1.000-09	9.733-05	1.375+12	1.227+12	1.357+01	.67651	1.864+12	6.077+01	3.380+05	1.127+00	1.072+00
8.500+03	1.000-08	9.050-04	1.243+12	1.106+12	1.203+01	.55866	1.497+12	5.351+02	3.286+05	1.142+00	1.074+00
8.500+03	1.000-07	7.709-03	1.012+12	8.949+11	1.073+01	.32772	3.171+12	1.308+04	2.986+05	1.189+00	1.077+00
8.500+03	1.000-06	6.445-02	8.046+11	7.050+11	9.787+00	.11866	1.405+12	5.517+04	2.771+05	1.319+00	1.082+00
8.500+03	1.000-05	6.038-01	7.257+11	6.304+11	8.913+00	.03918	5.684+11	1.905+05	2.749+05	1.481+00	1.084+00
8.500+03	1.000-04	5.879+00	6.993+11	6.099+11	8.059+00	.01256	2.648+11	6.193+05	2.855+05	1.591+00	1.085+00
8.500+03	1.000-03	5.830+01	6.008+11	6.022+11	7.213+00	.00399	1.465+11	1.975+06	2.992+05	1.641+00	1.088+00
8.500+03	1.000-02	5.309+02	6.447+11	1.095+00	6.369+00	.00126	2.157+12	1.216+09	2.713+05	2.185+00	1.083+00
8.500+03	1.000-01	3.726+03	5.051+11	1.559+00	5.525+00	.00040	1.447+12	9.729+09	2.258+05	5.960-01	1.075+00
8.500+03	1.000+00	2.303+04	3.868+11	2.520+00	4.682+00	.00013	9.574+11	8.477+10	1.742+05	8.898-01	1.068+00
8.500+03	1.000+01	1.223+05	3.024+11	4.743+00	3.839+00	.00004	2.542+11	1.675+11	1.280+05	9.581-01	1.041+00

TMETA	RHO	PI	E	CAPAR/ EIONIZ	CAPAC/ SYNPOI	FEW	CV	PBI	ASO	EGAM	EGAMZ/ GAWMA
9.000+03	1.000-10	1.146-05	1.624+12	1.450+12	1.603+01	.86508	2.409+12	7.642+00	3.440+05	1.113+00	1.072+00
9.000+03	1.000-09	1.067-04	1.457+12	1.295+12	1.437+01	.73734	1.973+12	6.828+01	3.538+05	1.126+00	1.078+00
9.000+03	1.000-08	9.942-03	1.309+12	1.159+12	1.273+01	.61223	1.584+12	6.015+02	3.336+05	1.141+00	1.077+00
9.000+03	1.000-07	7.018-03	1.158+12	1.021+12	1.115+01	.46665	3.521+12	1.620+04	3.237+05	1.163+00	1.079+00
9.000+03	1.000-06	7.272-02	8.743+11	7.634+11	1.009+01	.18278	1.836+12	8.200+04	2.925+05	1.267+00	1.084+00
9.000+03	1.000-05	6.525-01	7.538+11	6.546+11	9.148+00	.06193	7.454+11	2.990+05	2.833+05	1.426+00	1.088+00
9.000+03	1.000-04	6.271+00	7.120+11	6.167+11	8.238+00	.02002	3.270+11	9.883+05	2.901+05	1.560+00	1.089+00
9.000+03	1.000-03	6.187+01	6.984+11	6.043+11	7.340+00	.00637	1.867+11	3.169+06	3.041+05	1.628+00	1.090+00
9.000+03	1.000-02	6.160+02	6.940+11	6.004+11	6.446+00	.00202	1.415+11	1.006+07	3.147+05	1.654+00	1.090+00
9.000+03	1.000-01	4.976+03	5.845+11	1.237+00	5.552+00	.00064	2.618+12	1.568+10	2.697+05	1.154+01	1.085+00
9.000+03	1.000+00	3.043+04	4.382+11	2.021+00	4.659+00	.00020	1.489+12	1.045+11	2.059+05	9.077-01	1.070+00
9.000+03	1.000+01	1.434+05	3.145+11	4.289+00	3.767+00	.00006	3.110+11	2.150+11	1.379+05	9.489-01	1.046+00
9.500+03	1.000-10	1.254-05	1.731+12	1.540+12	1.693+01	.93228	2.544+12	8.528+00	3.806+05	1.112+00	1.073+00
9.500+03	1.000-09	1.167-04	1.545+12	1.367+12	1.517+01	.79630	2.082+12	7.622+01	3.694+05	1.125+00	1.077+00
9.500+03	1.000-08	1.081+03	1.380+12	1.215+12	1.343+01	.66594	1.671+12	6.718+02	3.587+05	1.140+00	1.079+00
9.500+03	1.000-07	9.967-03	1.235+12	1.084+12	1.173+01	.53584	1.309+12	5.815+03	3.478+05	1.159+00	1.082+00
9.500+03	1.000-06	8.206-02	9.625+11	8.378+11	1.042+01	.26456	2.247+12	1.124+05	3.104+05	1.228+00	1.086+00
9.500+03	1.000-05	7.092-01	7.904+11	6.826+11	9.391+00	.09291	9.573+11	4.432+05	2.936+05	1.375+00	1.091+00
9.500+03	1.000-04	6.687+00	7.277+11	6.260+11	8.421+00	.03038	4.035+11	1.500+06	2.958+05	1.525+00	1.093+00
9.500+03	1.000-03	6.553+01	7.069+11	6.073+11	7.470+00	.00971	2.119+11	4.844+06	3.088+05	1.613+00	1.094+00
9.500+03	1.000-02	6.510+02	7.003+11	6.014+11	6.525+00	.00308	1.436+11	1.542+07	3.210+05	1.648+00	1.094+00
9.500+03	1.000-01	6.446+03	6.982+11	5.994+11	5.582+00	.00098	1.297+11	4.887+07	3.274+05	1.661+00	1.094+00
9.500+03	1.000+00	4.267+04	5.233+11	1.522+00	4.639+00	.00031	2.625+12	1.890+11	2.544+05	4.253-01	1.083+00
9.500+03	1.000+01	1.693+05	3.295+11	3.834+00	3.696+00	.00010	3.891+11	2.802+11	1.519+05	9.363-01	1.052+00
1.000+04	1.000-10	1.367-05	1.843+12	1.635+12	1.782+01	.100059	2.678+12	9.464+00	3.972+05	1.111+00	1.075+00
1.000+04	1.000-09	1.270-04	1.637+12	1.444+12	1.577+01	.85937	2.191+12	8.460+01	3.455+05	1.124+00	1.079+00
1.000+04	1.000-08	1.175-03	1.453+12	1.275+12	1.414+01	.71978	1.758+12	7.460+02	3.737+05	1.139+00	1.082+00
1.000+04	1.000-07	1.081-02	1.293+12	1.129+12	1.234+01	.58245	1.377+12	6.462+03	3.619+05	1.158+00	1.085+00
1.000+04	1.000-06	9.249-02	1.067+12	9.253+11	1.077+01	.36132	2.563+12	1.420+05	3.313+05	1.201+00	1.088+00
1.000+04	1.000-05	7.740-01	8.366+11	7.189+11	9.842+00	.13312	1.190+12	6.231+05	3.057+05	1.330+00	1.094+00
1.000+04	1.000-04	7.133+00	7.469+11	6.385+11	8.607+00	.04420	4.938+11	2.177+06	3.026+05	1.487+00	1.097+00
1.000+04	1.000-03	6.926+01	7.167+11	6.114+11	7.602+00	.01420	2.423+11	7.103+06	3.136+05	1.594+00	1.099+00
1.000+04	1.000-02	6.862+02	7.069+11	6.026+11	6.606+00	.00451	1.594+11	2.268+07	3.270+05	1.642+00	1.094+00
1.000+04	1.000-01	6.841+03	7.038+11	5.999+11	5.612+00	.00113	1.328+11	7.195+07	3.748+05	1.658+00	1.094+00
1.000+04	1.000+00	6.685+04	6.916+11	1.022+00	4.620+00	.00045	5.813+12	4.250+11	3.433+05	1.728+00	1.094+00
1.050+04	1.000+01	2.022+05	3.485+11	3.380+00	3.628+00	.00014	5.007+11	3.731+11	1.689+05	9.181-01	1.059+00
1.050+04	1.000+02	1.464+05	1.961+12	1.736+12	1.672+01	.106900	2.612+12	1.045+01	4.137+05	1.110+00	1.077+00
1.050+04	1.000+03	1.376+04	1.733+12	1.524+12	1.577+01	.92053	2.301+12	9.343+01	4.012+05	1.123+00	1.081+00
1.050+04	1.000+04	1.272+03	1.531+12	1.338+12	1.485+01	.77373	1.843+12	8.241+02	3.887+05	1.136+00	1.084+00
1.050+04	1.000+05	1.169+02	1.354+12	1.176+12	1.295+01	.62920	1.443+12	7.143+03	3.761+05	1.157+00	1.087+00
1.050+04	1.000+06	1.052+01	1.181+12	1.021+12	1.144+01	.46720	2.712+12	1.645+05	3.533+05	1.183+00	1.090+00
1.050+04	1.000+07	8.465-01	8.929+11	7.640+11	9.902+00	.18295	1.427+12	8.335+05	3.197+05	1.292+00	1.096+00
1.050+04	1.000+08	7.617+00	7.784+11	6.545+11	8.798+00	.06199	5.964+11	3.040+06	3.104+05	1.449+00	1.100+00
1.050+04	1.000+09	7.316+01	7.279+11	6.167+11	7.737+00	.02004	2.777+11	1.005+07	3.188+05	1.573+00	1.102+00
1.050+04	1.000+10	7.218+02	7.140+11	6.043+11	6.689+00	.00638	1.709+11	3.222+07	3.326+05	1.633+00	1.103+00
1.050+04	1.000+01	7.187+03	7.096+11	6.004+11	5.445+00	.00202	1.365+11	1.023+08	3.419+05	1.656+00	1.103+00
1.050+04	1.000+02	7.177+04	7.082+11	5.991+11	4.603+00	.00084	1.258+11	3.280+08	3.450+05	1.663+00	1.103+00
1.050+04	1.000+03	2.452+05	3.734+11	2.926+00	3.561+00	.00020	6.861+11	5.122+11	4.301+05	8.896-01	1.067+00
1.100+04	1.000+04	1.606+05	2.085+12	1.841+12	1.942+01	.113751	2.661+12	1.448+01	4.303+05	1.109+00	1.078+00
1.100+04	1.000+05	1.449+04	1.635+12	1.609+12	1.758+01	.94179	2.411+12	1.027+02	4.170+05	1.122+00	1.082+00
1.100+04	1.000+06	1.373+03	1.612+12	1.404+12	1.536+01	.82779	1.933+12	9.061+02	4.034+05	1.137+00	1.086+00

THETA	NMO	P1	E	CAPAR/ E1012	CAPAC/ SYMPTOT	FEW	CV	PBI	ASO	EGAM	EGAM2/ GAMMA
1.100+04	1.000-07	1.459-02	1.410+12	1.224+12	1.357+01	.67606	1.513+12	7.850+03	3.902+05	1.156+00	1.090+00
1.100+04	1.000-06	1.148-01	1.250+12	1.076+12	1.162+01	.52762	1.150+12	6.654+04	3.770+05	1.178+00	1.093+00
1.100+04	1.000-05	9.333-01	9.593+11	8.175+11	1.017+01	.24209	1.650+12	1.063+06	3.353+05	1.262+00	1.099+00
1.100+04	1.000-04	6.147+00	7.985+11	6.787+11	8.993+00	.08415	7.088+11	4.897+06	3.197+05	1.413+00	1.103+00
1.100+04	1.000-03	7.720+01	7.407+11	6.234+11	7.874+00	.02782	3.181+11	1.377+07	3.284+05	1.550+00	1.106+00
1.100+04	1.000-02	7.580+02	7.217+11	6.065+11	6.773+00	.00876	1.862+11	4.438+07	3.381+05	1.624+00	1.106+00
1.100+04	1.000-01	7.535+03	7.156+11	6.011+11	5.679+00	.00278	1.408+11	1.412+08	3.467+05	1.624+00	1.107+00
1.100+04	1.000+00	7.521+04	7.137+11	5.994+11	4.587+00	.00088	1.289+11	4.474+08	3.536+05	1.662+00	1.107+00
1.100+04	1.000+01	3.041+05	4.074+11	2.872+00	3.996+00	.00028	9.358+11	7.392+11	2.176+05	8.388+01	1.076+00
1.150+04	1.000-04	1.733-05	2.215+12	1.952+12	2.052+01	1.20610	3.082+12	1.256+01	4.468+05	1.109+00	1.079+00
1.150+04	1.000-03	1.941+12	1.941+12	1.697+12	1.838+01	1.04315	2.521+12	1.124+02	4.328+05	1.121+00	1.084+00
1.150+04	1.000-02	1.698+12	1.698+12	1.473+12	1.627+01	.88192	2.020+12	9.921+02	4.186+05	1.136+00	1.084+00
1.150+04	1.000-01	1.484+12	1.484+12	1.279+12	1.418+01	.72302	1.501+12	8.607+03	4.084+05	1.155+00	1.092+00
1.150+04	1.000-00	1.301+12	1.301+12	1.114+12	1.218+01	.56741	1.201+12	7.296+04	3.903+05	1.178+00	1.096+00
1.150+04	1.000-05	1.029+00	1.035+12	8.782+11	1.046+01	.30932	1.836+12	1.293+06	3.523+05	1.239+00	1.101+00
1.150+04	1.000-04	8.728+00	8.316+11	6.983+11	9.194+00	.11097	8.276+11	5.386+06	3.299+05	1.380+00	1.106+00
1.150+04	1.000-03	8.143+01	7.554+11	6.316+11	8.013+00	.03653	3.630+11	1.835+07	3.307+05	1.526+00	1.109+00
1.150+04	1.000-02	7.948+02	7.299+11	6.091+11	6.860+00	.01170	1.992+11	5.953+07	3.435+05	1.613+00	1.110+00
1.150+04	1.000-01	7.865+03	7.218+11	6.019+11	5.715+00	.00371	1.456+11	1.898+08	3.551+05	1.648+00	1.111+00
1.150+04	1.000+00	7.865+04	7.192+11	5.994+11	4.573+00	.00118	1.284+11	6.016+08	3.610+05	1.661+00	1.111+00
1.150+04	1.000+01	3.895+05	4.568+11	2.018+00	3.432+00	.00037	1.484+12	1.121+12	2.537+05	7.216+01	1.086+00
1.200+04	1.000-10	1.865-05	2.351+12	2.067+12	2.142+01	1.27477	3.217+12	1.370+01	4.634+05	1.108+00	1.080+00
1.200+04	1.000-09	1.725-04	2.052+12	1.790+12	1.919+01	1.10459	2.631+12	1.225+02	4.486+05	1.120+00	1.085+00
1.200+04	1.000-08	1.587-03	1.786+12	1.545+12	1.698+01	.93615	2.108+12	1.082+03	4.336+05	1.135+00	1.090+00
1.200+04	1.000-07	1.451-02	1.554+12	1.333+12	1.480+01	.77008	1.689+12	9.390+03	4.185+05	1.154+00	1.095+00
1.200+04	1.000-06	1.318-01	1.354+12	1.134+12	1.266+01	.60732	1.233+12	7.965+04	4.035+05	1.177+00	1.099+00
1.200+04	1.000-05	1.133+00	1.117+12	9.485+11	1.076+01	.38256	1.966+12	1.502+06	3.705+05	1.222+00	1.103+00
1.200+04	1.000-04	9.336+00	8.698+11	7.275+11	9.401+00	.14256	9.487+11	6.770+06	3.412+05	1.350+00	1.109+00
1.200+04	1.000-03	8.587+01	7.720+11	6.415+11	8.156+00	.04751	4.119+11	2.385+07	3.375+05	1.502+00	1.113+00
1.200+04	1.000-02	8.323+02	7.389+11	6.124+11	6.948+00	.01528	2.137+11	7.798+07	3.489+05	1.601+00	1.114+00
1.200+04	1.000-01	8.237+03	7.282+11	6.039+11	5.753+00	.00886	1.509+11	2.492+08	3.614+05	1.644+00	1.115+00
1.200+04	1.000+00	8.210+04	7.247+11	6.000+11	4.560+00	.00154	1.301+11	7.907+08	3.681+05	1.659+00	1.115+00
1.250+04	1.000+01	5.244+05	5.348+11	1.564+00	3.369+00	.00849	2.336+12	1.890+12	3.133+05	1.666+01	1.099+00
1.250+04	1.000-10	2.001-05	2.492+12	2.168+12	2.232+01	.134353	3.332+12	1.488+01	4.799+05	1.107+00	1.081+00
1.250+04	1.000-09	1.850-04	2.168+12	1.887+12	2.000+01	1.16811	2.741+12	1.331+02	4.633+05	1.119+00	1.086+00
1.250+04	1.000-08	1.700-03	1.879+12	1.621+12	1.769+01	.99047	2.196+12	1.176+03	4.485+05	1.134+00	1.092+00
1.250+04	1.000-07	1.552-02	1.626+12	1.391+12	1.542+01	.81724	1.718+12	1.021+04	4.326+05	1.153+00	1.097+00
1.250+04	1.000-06	1.407-01	1.409+12	1.193+12	1.319+01	.64733	1.304+12	8.664+04	4.167+05	1.176+00	1.101+00
1.250+04	1.000-05	1.246+00	1.203+12	1.018+12	1.108+01	.45903	2.024+12	1.666+06	3.894+05	1.209+00	1.105+00
1.250+04	1.000-04	1.007+01	9.133+11	7.603+11	9.614+00	.17884	1.067+12	8.338+06	3.534+05	1.324+00	1.112+00
1.250+04	1.000-03	9.055+01	7.909+11	6.533+11	8.302+00	.06049	4.639+11	3.030+07	3.450+05	1.477+00	1.116+00
1.250+04	1.000-02	8.706+02	7.486+11	6.162+11	7.039+00	.01954	2.338+11	1.000+08	3.545+05	1.588+00	1.118+00
1.250+04	1.000-01	8.542+03	7.348+11	6.042+11	5.791+00	.00622	1.588+11	3.206+08	3.675+05	1.639+00	1.118+00
1.250+04	1.000+00	8.556+04	7.304+11	6.003+11	4.549+00	.00197	1.320+11	1.018+09	3.751+05	1.658+00	1.119+00
1.300+04	1.000-09	7.697+05	6.765+11	1.110+00	3.308+00	.00062	4.635+12	3.782+12	4.137+05	2.000+00	1.115+00
1.300+04	1.000-08	2.142-05	2.640+12	2.314+12	2.323+01	1.41235	3.488+12	1.611+01	4.964+05	1.106+00	1.082+00
1.300+04	1.000-07	1.978-04	2.488+12	1.988+12	2.080+01	1.22770	2.832+12	1.442+02	4.800+05	1.119+00	1.088+00
1.300+04	1.000-06	1.816-03	1.976+12	1.700+12	1.840+01	.10487	2.285+12	1.273+03	4.634+05	1.134+00	1.093+00
1.300+04	1.000-05	1.656-02	1.702+12	1.450+12	1.604+01	.86446	1.786+12	1.106+04	4.467+05	1.152+00	1.099+00
1.300+04	1.000-04	1.499-01	1.466+12	1.239+12	1.371+01	.68743	1.356+12	9.392+04	4.299+05	1.175+00	1.104+00
1.300+04	1.000-03	1.348+00	1.269+12	1.045+12	1.146+01	.51342	9.920+11	7.750+05	4.133+05	1.203+00	1.107+00

THETA	RHO	P1	E	CAPAR/ E10M12	CAPAC/ SYNPO	FEW	CV	PBI	ASO	EGAM	EGAM2/ GAMMA
1.300+04	1.000-04	1.043+01	9.617+11	7.971+11	9.305+00	-21953	1.178+12	1.000+07	3.666+05	1.302+00	1.114+00
1.300+04	1.000-03	9.551+01	8.120+11	6.669+11	8.551+00	-07555	5.184+11	3.771+07	3.531+05	1.553+00	1.119+00
1.300+04	1.000-02	9.098+02	7.590+11	6.208+11	7.131+00	-02454	2.533+11	1.259+08	3.603+05	1.574+00	1.121+00
1.300+04	1.000-01	8.950+03	7.417+11	6.050+11	5.832+00	-00783	1.632+11	9.051+08	3.734+05	1.634+00	1.122+00
1.300+04	1.000+00	8.802+04	7.361+11	5.908+11	5.639+00	-00248	1.344+11	1.288+09	3.819+05	1.656+00	1.123+00
1.300+04	1.000+01	8.687+05	7.344+11	5.993+11	5.499+00	-00079	1.240+11	4.080+09	3.854+05	1.663+00	1.123+00
1.350+04	1.000-10	2.268-05	2.793+12	2.453+12	2.813+01	1.48125	3.624+12	1.739+01	5.129+05	1.106+00	1.083+00
1.350+04	1.000-09	2.111-04	2.414+12	2.093+12	2.161+01	1.28934	2.963+12	1.356+02	4.958+05	1.118+00	1.089+00
1.350+04	1.000-08	1.936-03	2.076+12	1.782+12	1.912+01	1.09934	2.373+12	1.375+03	4.784+05	1.133+00	1.094+00
1.350+04	1.000-07	1.763-02	1.780+12	1.512+12	1.666+01	91177	1.855+12	1.195+04	4.607+05	1.151+00	1.100+00
1.350+04	1.000-06	1.593-01	1.526+12	1.284+12	1.424+01	72762	1.407+12	1.615+05	4.430+05	1.174+00	1.104+00
1.350+04	1.000-05	1.428+00	1.313+12	1.096+12	1.189+01	54851	1.023+12	8.361+05	4.256+05	1.203+00	1.110+00
1.350+04	1.000-04	1.166+01	1.015+12	8.374+11	1.006+01	26413	1.276+12	1.169+07	3.806+05	1.284+00	1.116+00
1.350+04	1.000-03	1.008+02	8.356+11	6.824+11	8.003+00	09274	5.743+11	4.607+07	3.617+05	1.431+00	1.122+00
1.350+04	1.000-02	4.502+02	7.704+11	6.260+11	7.325+00	-03032	2.733+11	1.559+08	3.663+05	1.560+00	1.125+00
1.350+04	1.000-01	7.311+03	7.488+11	6.073+11	5.874+00	-00969	1.708+11	5.035+08	3.793+05	1.628+00	1.126+00
1.350+04	1.000+00	9.250+04	7.419+11	6.013+11	4.531+00	-00307	1.363+11	1.603+09	3.885+05	1.654+00	1.126+00
1.350+04	1.000+01	9.231+05	7.397+11	5.994+11	3.190+00	-00097	1.255+11	5.079+09	3.925+05	1.663+00	1.126+00
1.400+04	1.000-10	2.418-05	2.906+12	2.539+12	2.505+01	1.52872	2.282+12	1.072+01	5.341+05	1.104+00	1.084+00
1.400+04	1.000-09	2.248-04	2.544+12	2.202+12	2.242+01	1.35110	3.074+12	1.676+02	5.115+05	1.117+00	1.090+00
1.400+04	1.000-08	2.060-03	2.180+12	1.867+12	1.983+01	1.15388	2.462+12	1.481+03	4.933+05	1.132+00	1.096+00
1.400+04	1.000-07	1.878-02	1.862+12	1.577+12	1.728+01	95915	1.924+12	1.287+04	4.744+05	1.150+00	1.102+00
1.400+04	1.000-06	1.691-01	1.588+12	1.331+12	1.477+01	76730	1.453+12	1.094+05	4.562+05	1.173+00	1.104+00
1.400+04	1.000-05	1.513+00	1.358+12	1.124+12	1.233+01	58170	1.067+12	9.016+05	4.378+05	1.202+00	1.113+00
1.400+04	1.000-04	1.255+01	1.071+12	8.806+11	1.030+01	31197	1.356+12	1.335+07	3.954+05	1.259+00	1.119+00
1.400+04	1.000-03	1.064+02	8.615+11	6.999+11	8.759+00	-11207	1.356+12	5.532+07	3.710+05	1.410+00	1.125+00
1.400+04	1.000-02	9.917+02	7.827+11	6.319+11	7.321+00	-03691	2.956+11	1.900+08	3.725+05	1.546+00	1.128+00
1.400+04	1.000-01	9.677+03	7.563+11	6.093+11	5.917+00	-01182	1.773+11	6.167+08	3.850+05	1.621+00	1.130+00
1.400+04	1.000+00	9.599+04	7.479+11	6.020+11	4.523+00	-00375	1.388+11	1.966+09	3.949+05	1.652+00	1.130+00
1.400+04	1.000+01	9.575+05	7.452+11	5.996+11	3.133+00	-00119	1.262+11	6.234+09	3.995+05	1.662+00	1.130+00
1.450+04	1.000-10	2.544-05	3.006+12	2.620+12	2.598+01	1.56824	2.363+12	1.151+01	5.474+05	1.107+00	1.086+00
1.450+04	1.000-09	2.390-04	2.678+12	2.315+12	2.323+01	1.41290	3.185+12	1.799+02	5.272+05	1.116+00	1.090+00
1.450+04	1.000-08	2.188-03	2.288+12	1.954+12	2.055+01	1.20848	2.553+12	1.590+03	5.082+05	1.131+00	1.097+00
1.450+04	1.000-07	1.988-02	1.946+12	1.644+12	1.790+01	1.00660	1.993+12	1.382+04	4.889+05	1.159+00	1.103+00
1.450+04	1.000-06	1.791-01	1.652+12	1.379+12	1.530+01	80825	1.511+12	1.175+05	4.694+05	1.172+00	1.110+00
1.450+04	1.000-05	1.600+00	1.405+12	1.162+12	1.276+01	61498	1.104+12	9.696+05	4.500+05	1.201+00	1.115+00
1.450+04	1.000-04	1.349+01	1.131+12	9.261+11	1.055+01	36220	1.415+12	1.488+07	4.107+05	1.257+00	1.121+00
1.450+04	1.000-03	1.123+02	8.899+11	7.133+11	8.319+00	13350	6.864+11	6.537+07	3.807+05	1.396+00	1.128+00
1.450+04	1.000-02	1.034+03	7.959+11	6.382+11	7.920+00	04434	3.180+11	2.285+08	3.790+05	1.531+00	1.132+00
1.450+04	1.000-01	1.005+04	7.841+11	6.114+11	5.962+00	-01424	1.949+11	7.455+08	3.908+05	1.615+00	1.133+00
1.450+04	1.000+00	9.950+04	7.539+11	6.027+11	4.517+00	-00452	1.411+11	2.381+09	4.013+05	1.649+00	1.134+00
1.450+04	1.000+01	9.915+05	7.506+11	5.993+11	3.077+00	-00183	1.270+11	7.552+09	4.063+05	1.661+00	1.134+00
1.500+04	1.000-10	2.672-05	3.110+12	2.704+12	2.691+01	1.60780	2.443+12	1.233+01	5.607+05	1.108+00	1.087+00
1.500+04	1.000-09	2.536-04	2.818+12	2.433+12	2.404+01	1.47477	3.294+12	1.927+02	5.430+05	1.116+00	1.091+00
1.500+04	1.000-08	2.319-03	2.400+12	2.044+12	2.127+01	1.26315	2.639+12	1.704+03	5.231+05	1.136+00	1.098+00
1.500+04	1.000-07	2.105-02	2.033+12	1.713+12	1.853+01	1.05412	2.062+12	1.481+04	5.029+05	1.189+00	1.105+00
1.500+04	1.000-06	1.894-01	1.718+12	1.430+12	1.383+01	84864	1.563+12	1.280+05	4.825+05	1.171+00	1.112+00
1.500+04	1.000-05	1.689+00	1.453+12	1.194+12	1.320+01	64833	1.141+12	1.040+06	4.621+05	1.200+00	1.118+00
1.500+04	1.000-04	1.449+01	1.193+12	9.724+11	1.081+01	41386	1.451+12	1.621+07	4.234+05	1.247+00	1.123+00
1.500+04	1.000-03	1.185+02	9.207+11	7.403+11	9.083+00	-15696	7.404+11	7.618+07	3.910+05	1.373+00	1.130+00
1.500+04	1.000-02	1.079+03	8.101+11	6.461+11	7.320+00	-05262	3.411+11	2.713+08	3.858+05	1.517+00	1.135+00

THETA	NHO	P1	E	EWLZ	CAPAC/ SYNPUT	FEM	CV	P81	ASO	EGAM	EGAM2/ GAWA
1.500+04	1.000-01	1.042+04	7.723+11	6.139+11	6.008+00	.0195	1.929+11	8.905+08	3.966+05	1.608+00	1.137+00
1.500+04	1.000+00	1.030+05	7.600+11	6.034+11	5.512+00	.00339	1.436+11	2.849+09	4.125+05	1.647+00	1.137+00
1.500+04	1.000+01	1.026+06	7.561+11	6.001+11	3.022+00	.00171	1.278+11	9.044+09	4.129+05	1.660+00	1.136+00
1.500+04	1.000-01	1.020+05	7.517+12	2.791+12	2.784+01	1.64739	2.533+12	1.317+01	3.740+05	1.108+00	1.088+00
1.500+04	1.000-09	2.869+04	2.929+12	2.523+12	2.487+01	1.52103	2.086+12	1.183+02	3.647+05	1.116+00	1.092+00
1.500+04	1.000-08	4.454+03	2.516+12	2.143+12	2.199+01	1.31749	2.728+12	1.821+03	3.380+05	1.130+00	1.099+00
1.500+04	1.000-07	2.225+02	2.124+12	1.785+12	1.915+01	1.10171	2.131+12	1.583+04	3.178+05	1.148+00	1.106+00
1.500+04	1.000-06	2.600+01	1.786+12	1.682+12	1.636+01	.80913	1.615+12	1.347+05	4.956+05	1.171+00	1.113+00
1.500+04	1.000-05	1.781+00	1.503+12	1.238+12	1.364+01	.60176	1.179+12	1.113+06	4.783+05	1.199+00	1.128+00
1.500+04	1.000-04	1.552+01	1.256+12	.020+12	1.107+01	.46594	1.461+12	1.728+07	4.424+05	1.239+00	1.125+00
1.500+04	1.000-03	1.252+02	9.537+11	7.634+11	9.252+00	.18232	7.918+11	8.735+07	4.018+05	1.357+00	1.133+00
1.500+04	1.000-02	1.124+03	8.253+11	6.544+11	7.622+00	.06176	3.646+11	3.184+08	3.928+05	1.502+00	1.138+00
1.500+04	1.000-01	1.080+04	7.808+11	6.166+11	6.055+00	.01996	2.011+11	1.052+09	4.024+05	1.601+00	1.140+00
1.500+04	1.000+00	1.064+05	7.663+11	6.043+11	4.509+00	.00634	1.463+11	3.374+09	4.156+05	1.644+00	1.141+00
1.500+04	1.000+01	1.061+06	7.616+11	6.003+11	2.877+01	.168701	1.287+11	1.072+10	4.195+05	1.659+00	1.141+00
1.600+04	1.000-10	2.937+05	3.327+12	2.481+12	2.571+01	1.55641	2.153+12	1.262+02	3.774+05	1.117+00	1.094+00
1.600+04	1.000-09	2.794+04	3.020+12	2.596+12	2.271+01	1.37268	2.810+12	1.942+03	3.524+05	1.129+00	1.100+00
1.600+04	1.000-08	2.543+03	2.635+12	2.241+12	1.978+01	1.14935	2.200+12	1.689+04	3.310+05	1.170+00	1.107+00
1.600+04	1.000-07	2.349+02	2.217+12	1.860+12	1.578+01	.94457	1.667+12	1.438+05	3.084+05	1.170+00	1.115+00
1.600+04	1.000-06	2.109+01	1.857+12	1.536+12	1.608+01	.71527	1.216+12	1.188+06	2.863+05	1.199+00	1.122+00
1.600+04	1.000-05	1.555+00	1.310+12	1.270+12	1.137+01	.50904	8.470+11	9.405+07	2.130+05	1.235+00	1.138+00
1.600+04	1.000-04	1.449+01	1.310+12	1.059+12	9.425+00	.20934	8.393+11	9.617+07	1.300+05	1.343+00	1.150+00
1.600+04	1.000-03	1.322+02	9.888+11	7.879+11	7.727+00	.07176	3.683+11	3.697+08	1.083+05	1.489+00	1.141+00
1.600+04	1.000-02	1.171+03	8.415+11	6.635+11	6.104+00	.02328	2.094+11	1.231+09	1.063+05	1.593+00	1.144+00
1.600+04	1.000-01	1.116+04	7.896+11	6.196+11	4.506+00	.00782	1.491+11	3.956+09	1.194+05	1.641+00	1.144+00
1.600+04	1.000+00	1.101+05	7.726+11	6.003+11	2.915+00	.00235	1.296+11	1.258+10	1.250+05	1.658+00	1.145+00
1.600+04	1.000+01	1.096+06	7.672+11	6.007+11	2.976+01	.172666	2.663+12	1.495+01	1.003+05	1.110+00	1.090+00
1.600+04	1.000-10	3.073+05	3.441+12	2.974+12	2.634+01	1.59223	2.217+12	1.343+02	3.900+05	1.118+00	1.093+00
1.600+04	1.000-09	2.922+04	3.114+12	2.670+12	2.342+01	1.42753	2.907+12	2.068+03	3.674+05	1.128+00	1.101+00
1.600+04	1.000-08	2.736+03	2.758+12	2.343+12	2.040+01	1.19703	2.270+12	1.799+04	3.450+05	1.146+00	1.108+00
1.600+04	1.000-07	2.476+02	2.313+12	1.937+12	1.743+01	.97028	1.719+12	1.531+05	3.214+05	1.169+00	1.117+00
1.600+04	1.000-06	2.221+01	1.930+12	1.592+12	1.432+01	.74884	1.254+12	1.266+06	2.987+05	1.198+00	1.124+00
1.600+04	1.000-05	1.971+00	1.608+12	1.308+12	1.172+01	.53562	8.727+11	1.003+07	2.758+05	1.234+00	1.130+00
1.600+04	1.000-04	1.731+01	1.347+12	1.084+12	9.602+00	.23810	8.826+11	1.107+08	2.446+05	1.231+00	1.136+00
1.600+04	1.000-03	1.595+02	1.026+12	8.138+11	7.602+00	.08262	4.120+11	4.251+08	2.077+05	1.475+00	1.144+00
1.600+04	1.000-02	1.220+03	8.587+11	6.733+11	6.133+00	.08262	4.120+11	4.251+08	1.842+05	1.586+00	1.147+00
1.600+04	1.000-01	1.157+04	7.988+11	6.229+11	6.155+00	.02691	2.183+11	1.427+09	1.250+05	1.836+00	1.148+00
1.600+04	1.000+00	1.137+05	7.791+11	6.063+11	4.505+00	.00859	1.520+11	4.599+09	1.323+05	1.836+00	1.148+00
1.600+04	1.000+01	1.130+06	7.728+11	6.010+11	3.844+00	.00272	1.305+11	4.643+10	1.323+05	1.836+00	1.148+00
1.700+04	1.000-10	3.213+05	3.559+12	3.070+12	3.063+01	1.76634	2.763+12	1.588+01	6.135+05	1.110+00	1.091+00
1.700+04	1.000-09	3.052+04	3.211+12	2.748+12	2.738+01	1.62788	2.283+12	1.427+02	6.027+05	1.118+00	1.094+00
1.700+04	1.000-08	2.843+03	2.848+12	2.448+12	2.415+01	1.48243	2.996+12	2.197+03	5.827+05	1.128+00	1.101+00
1.700+04	1.000-07	2.607+02	2.413+12	2.016+12	2.103+01	1.24481	2.339+12	1.911+04	5.591+05	1.146+00	1.109+00
1.700+04	1.000-06	2.335+01	2.003+12	1.650+12	1.794+01	1.01095	1.772+12	1.628+05	5.350+05	1.168+00	1.114+00
1.700+04	1.000-05	2.076+00	1.603+12	1.348+12	1.486+01	.82440	1.292+12	1.347+06	5.108+05	1.197+00	1.124+00
1.700+04	1.000-04	1.814+01	1.385+12	1.109+12	1.207+01	.56228	8.984+11	1.088+07	4.869+05	1.234+00	1.134+00
1.700+04	1.000-03	1.473+02	8.410+11	6.102+11	9.785+00	.76811	9.205+11	1.234+08	4.564+05	1.329+00	1.148+00
1.700+04	1.000-02	1.271+03	8.770+11	6.438+11	7.942+00	.09432	2.354+11	4.444+09	4.154+05	1.462+00	1.167+00
1.700+04	1.000-01	1.197+04	8.084+11	6.265+11	6.264+00	.03065	2.271+11	1.441+09	4.201+05	1.578+00	1.194+00
1.700+04	1.000+00	1.173+05	7.857+11	6.875+11	4.584+00	.00986	1.549+11	5.382+09	4.318+05	1.833+00	1.151+00
1.700+04	1.000+01	1.165+06	7.784+11	6.016+11	2.813+00	.00313	1.315+11	1.648+10	4.365+05	1.856+00	1.151+00

APPENDIX II
EGREY OUTPUT AND CARD INPUT
USED WITH GREYS

EGREY OUTPUT

(Edit output of GREY tape made by using card input.
A listing of the card input follows this edit.)

BEGIN INES2 RUN. INPUT IS

RENAME OF GREY TAPE TO ADD NEW OPACITY SETS

INPUT JPATH VALUES ARE 5 Y

DIANE GREY TAPE 1A/11/67 A.KHOPP MATERIALS ARE AIR-WET ALLUVIUM,AL,BE,
C,CF2,CH2,C-PHENOL,GC,FE,BINA-IRONIC,GRANITE,GROUT,M-H-M-LIM,LIMESTONE,
ME,PHENALIC,PLYCA,PLYFE,WET TUFF,NEFRASIL,SEAWATER,S,SHALE,V,XE

THE NUMBER OF ONLY SETS IS 31

DIANE GREY TAPE 1A/11/67 A.KHOPP MATERIALS ARE AIR-WET ALLUVIUM,AL,BE,
C,CF2,CH2,C-PHENOL,GC,FE,BINA-IRONIC,GRANITE,GROUT,M-H-M-LIM,LIMESTONE,
ME,PHENALIC,PLYCA,PLYFE,WET TUFF,NEFRASIL,SEAWATER,S,SHALE,V,XE
1001801 DIANE AIR-184 ,12 FREQUENCIES DECEMBER 81,1965 COMBINED WITH AIR-11F

MATERL = 1102 NR = 702

GREY ABSORPTION COEFFICIENTS 23 TEMPERATURES

THETA = 1.2940 0 DENSITIES

DENSITY 1.29299564-02 1.29300025-03 1.29299390-04 1.29294804-05 1.29303687-06 1.29303950-07 1.29302039-08 1.29300121-09
KAPPA(P) 1.03073-20+06 9.39018160+03 6.15770600+03 2.96072650+03 7.2560028+02 9.02559900+01 6.9269940+00 9.3372030-01
KAPPA(R) 0.73379330+02 4.63877240+02 2.78921370+02 1.50523120+02 4.2176340+01 5.40563330+00 6.36704570-01 1.29737770-01

THETA = 1.5000 10 DENSITIES

DENSITY 1.23166417+00 1.13442406-01 7.62805460-03 4.76015950-04 3.64331450-05 5.04203940-06 0.16048090-07 1.36754080-07
KAPPA(P) 5.74544770+04 2.60090520+04 2.34517300+04 1.07552800+04 0.44204000+03 2.1100900+03 3.78507900+02 5.63715470+01
KAPPA(R) 9.87019430+02 8.73361000+02 6.50340640+02 6.99703790+02 3.02955900+02 1.16125351+02 2.35873370+01 4.97600030+00

DENSITY 2.03015570-06 2.41105850-09
KAPPA(P) 6.67764320+00 1.66729739+00
KAPPA(R) 1.21260595+00 5.30003320-01

THETA = 1.6500 10 DENSITIES

DENSITY 3.00151430-01 3.39549710-02 2.59530610-03 2.96151900-04 3.37037990-05 0.04050150-06 1.06077227-06 1.67099540-07
KAPPA(P) 0.3181430+04 5.66443150+04 4.35733040+04 2.20401390+04 0.21107930+03 1.19971570+03 2.09979500+02 4.97007370+01
KAPPA(R) 4.40193410+03 3.57557000+03 2.92292950+03 1.56250990+03 4.94726000+02 1.17377707+02 2.97229600+01 1.01753721+01

DENSITY 2.04190600-06 2.06259730-09
KAPPA(P) 1.32609719+01 2.67504900+00
KAPPA(R) 3.70470440+00 4.40712600-01

THETA = 2.2800 10 DENSITIES

DENSITY 1.7708430-01 1.72927140-02 1.72444403-03 2.31194350-04 4.00930340-05 7.82540030-06 1.17047200-06 1.83034000-07
KAPPA(P) 9.9087070+04 7.01500610+04 4.00330100+04 1.73120200+04 4.30390400+03 1.00762300+03 2.01040100+02 7.97300000+01

KAPPA(R)	1.24423-70+04	1.01171772+04	6.26210190+03	2.52910290+03	6.95986300+02	2.36386920+02	8.61939470+01	2.28042740+01
DENSITY	1.99966730-08	2.47081590-09						
KAPPA(P)	1.50133527-01	2.13962800+00						
KAPPA(R)	3.73653400+00	6.65189040-01						
TRGTA =	2.75000		10	DENSITIES				
DENSITY	1.14246146-01	1.30435702-02	1.69690376-03	2.75328380-04	4.79879830-05	7.68607800-06	1.11644820-06	1.70650740-07
KAPPA(P)	1.81127818+05	7.81902270+04	3.97951330+04	1.54172140+04	4.86596290+03	1.33184670+03	3.735350870+02	6.54823000+01
KAPPA(R)	3.40805700+04	2.22545090+04	1.14106217+04	4.57311510+03	1.58072670+03	4.62492340+02	8.57417570+01	1.33307003+01

GRAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 4.7500 CONTINUED		
DENSITY	2.4967270-08	2.86356120-09
KAPPA(P)	1.04268918+01	1.96861252+00
KAPPA(R)	2.84160770+00	7.70564430-01
THETA = 3.40002 10 DENSITIES		
DENSITY	9.5449440-02	1.28886270-02
KAPPA(P)	1.23271497+05	7.45253940+04
KAPPA(R)	6.88234020+04	3.91243360+04
DENSITY	2.65483040-08	3.11542580-09
KAPPA(P)	1.27658631+01	2.11569884+00
KAPPA(R)	4.15087650+00	7.98070770-01
THETA = 5.00001 10 DENSITIES		
DENSITY	9.30023460-02	1.49107922-02
KAPPA(P)	1.26033403+05	8.45839650+04
KAPPA(R)	9.33582660+04	1.74864610+04
DENSITY	3.43653200-08	4.07905700-09
KAPPA(P)	1.17390291+01	1.82944506+00
KAPPA(R)	3.45550780+00	7.24204030-01
THETA = 7.00000 10 DENSITIES		
DENSITY	1.04353015-01	1.69616560-02
KAPPA(P)	1.24155533+05	8.60255760+04
KAPPA(R)	9.17203480+04	4.98513070+04
DENSITY	4.42601730-08	5.45791040-09
KAPPA(P)	9.29466510+00	1.45799614+00
KAPPA(R)	2.86681080+00	5.80127710-01
THETA = 10.00005 10 DENSITIES		
DENSITY	1.25508730-01	2.05943900-02
KAPPA(P)	1.15832440+05	7.53651250+04
KAPPA(R)	6.89988310+04	4.95481360+04
DENSITY	6.84988920-08	6.87524430-09
KAPPA(P)	4.14573450+00	7.10340390-01
KAPPA(R)	1.65859687+00	4.01694670-01

GREY ABSORPTION COEFFICIENTS CONTINUED

10 DENSITIES		
THETA = 10.00000		
DENSITY	1.61304410-01	2.7659760-02
KAPPA(P)	0.66905180+04	5.92961670+04
KAPPA(R)	3.12539180+04	2.74906140+04
DENSITY	1.25244260-07	1.6278360-08
KAPPA(P)	1.4009457+00	3.3518310-01
KAPPA(R)	6.26197190-01	3.11981930-01
10 DENSITIES		
THETA = 22.50611		
DENSITY	2.29957880-01	4.02007350-02
KAPPA(P)	5.6364720+04	3.39620820+04
KAPPA(R)	1.01698609+04	7.95996580+03
DENSITY	2.3002200-07	2.98852780-08
KAPPA(P)	5.07352420-01	1.92451710-01
KAPPA(R)	4.29318160-01	1.87008720-01
11 DENSITIES		
THETA = 33.99498		
DENSITY	3.61815410-01	6.49290580-02
KAPPA(P)	2.65962190+04	1.28520672+04
KAPPA(R)	3.06991640+03	1.72074040+03
DENSITY	3.85816430-07	4.77159640-08
KAPPA(P)	5.4259160-01	2.65492150-01
KAPPA(R)	3.11961530-01	2.19524820-01
11 DENSITIES		
THETA = 49.99465		
DENSITY	5.85767100-01	1.09169880-01
KAPPA(P)	1.19490615+04	4.52986120+03
KAPPA(R)	1.52361130+03	6.08201050+02
DENSITY	5.72759460-07	7.26799820-08
KAPPA(P)	6.50124418-01	2.73632310-01
KAPPA(R)	2.71300620-01	2.11658750-01
11 DENSITIES		
THETA = 70.00633		
DENSITY	9.22436440-01	1.72375510-01
KAPPA(P)	8.82289400+03	3.43282890+03
KAPPA(R)	1.54288510+03	5.19008350+02

264

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 500.0074			11 DENSITIES		
DENSITY	1.1794450-01	2.3134880-03	4.5785530-01	9.11909160-02	1.01784220-02
KAPPA(P)	3.5494060-02	6.90760030-01	1.9376120-01	3.92336610-00	8.90362140-01
KAPPA(R)	2.5264240-01	7.30734490-00	1.74220925-00	5.21146540-01	2.75532410-01
DENSITY	1.7423350-03	2.26508130-06	2.26504740-07		
KAPPA(P)	1.96267130-01	1.87922450-01	1.97876930-01		
KAPPA(R)	1.9576560-01	1.95641760-01	1.95624160-01		
THETA = 699.99476			9 DENSITIES		
DENSITY	3.01110540-02	6.21349000-03	1.10469050-03	1.07657890-04	2.88615600-05
KAPPA(P)	4.17686130-01	2.29675000-01	2.00047590-01	1.95366110-01	1.94477270-01
KAPPA(R)	2.1454230-01	2.00570390-01	1.95319230-01	1.94090410-01	1.93877260-01
DENSITY	3.7519180-09				
KAPPA(P)	1.94459760-01				
KAPPA(R)	1.93834010-01				
THETA = 1000.00468			9 DENSITIES		
DENSITY	5.1568560-02	1.02442324-02	1.88546250-03	3.20419340-04	4.92820850-05
KAPPA(P)	2.70974650-01	2.04319570-01	1.93762910-01	1.92144030-01	1.91847350-01
KAPPA(R)	2.0157970-01	1.94745820-01	1.92869780-01	1.92469030-01	1.92390160-01
DENSITY	6.40619760-09				
KAPPA(P)	1.91817660-01				
KAPPA(R)	1.92374740-01				
THETA = 1494.99430			9 DENSITIES		
DENSITY	7.4345640-02	1.48547570-02	3.44442030-03	5.84649300-04	9.05371790-05
KAPPA(P)	2.2044420-01	1.96456770-01	1.91717950-01	1.90948780-01	1.90815170-01
KAPPA(R)	1.94440070-01	1.91976940-01	1.91340390-01	1.91271770-01	1.91250730-01
DENSITY	1.17400440-04				
KAPPA(P)	1.9674470-01				
KAPPA(R)	1.91844440-01				
THETA = 2250.01110			9 DENSITIES		
DENSITY	1.7321840-01	3.44244360-02	6.36373360-03	1.04142024-03	1.66327090-04
KAPPA(P)	1.97262440-01	1.91401440-01	1.90342340-01	1.90142780-01	1.90102860-01
KAPPA(R)	1.9631740-01	1.91344960-01	1.91220130-01	1.91179980-01	1.91172320-01

NEUTRON ABSORPTION COEFFICIENTS CONTINUED

WATER = 2250.01010 CONTINUED

DENSITY 2.16216-10-08
KAPPA(P) 1.90162858-01
KAPPA(R) 1.91178420-01

ONLY ABSORPTION COEFFICIENTS		JANIS/SCAT ALLUWIUM-19		INPUT TABLES (4407, 2404, 3403)		11-7-67 CI/LN		MATERIAL # 113A		NR # 900	
TEMPERATURES		TEMPERATURES		TEMPERATURES		TEMPERATURES		TEMPERATURES		TEMPERATURES	
24		24		24		24		24		24	
13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES	
THETA = 1.50000		THETA = 1.50000		THETA = 1.50000		THETA = 1.50000		THETA = 1.50000		THETA = 1.50000	
DENSITY	4.4049420-02	DENSITY	4.4049420-02	DENSITY	4.4049420-02	DENSITY	4.4049420-02	DENSITY	4.4049420-02	DENSITY	4.4049420-02
KAPPA(P)	3.13774010-05	KAPPA(P)	3.13774010-05	KAPPA(P)	3.13774010-05	KAPPA(P)	3.13774010-05	KAPPA(P)	3.13774010-05	KAPPA(P)	3.13774010-05
KAPPA(R)	1.80251140-05	KAPPA(R)	1.80251140-05	KAPPA(R)	1.80251140-05	KAPPA(R)	1.80251140-05	KAPPA(R)	1.80251140-05	KAPPA(R)	1.80251140-05
DENSITY	1.70469270-08	DENSITY	1.70469270-08	DENSITY	1.70469270-08	DENSITY	1.70469270-08	DENSITY	1.70469270-08	DENSITY	1.70469270-08
KAPPA(P)	1.70905550-01	KAPPA(P)	1.70905550-01	KAPPA(P)	1.70905550-01	KAPPA(P)	1.70905550-01	KAPPA(P)	1.70905550-01	KAPPA(P)	1.70905550-01
KAPPA(R)	3.01373490-00	KAPPA(R)	3.01373490-00	KAPPA(R)	3.01373490-00	KAPPA(R)	3.01373490-00	KAPPA(R)	3.01373490-00	KAPPA(R)	3.01373490-00
THETA = 4.25000		THETA = 4.25000		THETA = 4.25000		THETA = 4.25000		THETA = 4.25000		THETA = 4.25000	
DENSITY	1.16728405-01	DENSITY	1.16728405-01	DENSITY	1.16728405-01	DENSITY	1.16728405-01	DENSITY	1.16728405-01	DENSITY	1.16728405-01
KAPPA(P)	6.83714405-05	KAPPA(P)	6.83714405-05	KAPPA(P)	6.83714405-05	KAPPA(P)	6.83714405-05	KAPPA(P)	6.83714405-05	KAPPA(P)	6.83714405-05
KAPPA(R)	5.09364205-05	KAPPA(R)	5.09364205-05	KAPPA(R)	5.09364205-05	KAPPA(R)	5.09364205-05	KAPPA(R)	5.09364205-05	KAPPA(R)	5.09364205-05
DENSITY	4.10661510-08	DENSITY	4.10661510-08	DENSITY	4.10661510-08	DENSITY	4.10661510-08	DENSITY	4.10661510-08	DENSITY	4.10661510-08
KAPPA(P)	1.77177250-01	KAPPA(P)	1.77177250-01	KAPPA(P)	1.77177250-01	KAPPA(P)	1.77177250-01	KAPPA(P)	1.77177250-01	KAPPA(P)	1.77177250-01
KAPPA(R)	5.31711040-00	KAPPA(R)	5.31711040-00	KAPPA(R)	5.31711040-00	KAPPA(R)	5.31711040-00	KAPPA(R)	5.31711040-00	KAPPA(R)	5.31711040-00
THETA = 3.40000		THETA = 3.40000		THETA = 3.40000		THETA = 3.40000		THETA = 3.40000		THETA = 3.40000	
DENSITY	8.56537740-02	DENSITY	8.56537740-02	DENSITY	8.56537740-02	DENSITY	8.56537740-02	DENSITY	8.56537740-02	DENSITY	8.56537740-02
KAPPA(P)	3.60096550-05	KAPPA(P)	3.60096550-05	KAPPA(P)	3.60096550-05	KAPPA(P)	3.60096550-05	KAPPA(P)	3.60096550-05	KAPPA(P)	3.60096550-05
KAPPA(R)	4.75803580-05	KAPPA(R)	4.75803580-05	KAPPA(R)	4.75803580-05	KAPPA(R)	4.75803580-05	KAPPA(R)	4.75803580-05	KAPPA(R)	4.75803580-05
DENSITY	3.07424450-08	DENSITY	3.07424450-08	DENSITY	3.07424450-08	DENSITY	3.07424450-08	DENSITY	3.07424450-08	DENSITY	3.07424450-08
KAPPA(P)	1.16545420-01	KAPPA(P)	1.16545420-01	KAPPA(P)	1.16545420-01	KAPPA(P)	1.16545420-01	KAPPA(P)	1.16545420-01	KAPPA(P)	1.16545420-01
KAPPA(R)	4.38133650-00	KAPPA(R)	4.38133650-00	KAPPA(R)	4.38133650-00	KAPPA(R)	4.38133650-00	KAPPA(R)	4.38133650-00	KAPPA(R)	4.38133650-00
THETA = 5.60000		THETA = 5.60000		THETA = 5.60000		THETA = 5.60000		THETA = 5.60000		THETA = 5.60000	
DENSITY	9.03826790-02	DENSITY	9.03826790-02	DENSITY	9.03826790-02	DENSITY	9.03826790-02	DENSITY	9.03826790-02	DENSITY	9.03826790-02
KAPPA(P)	4.15002240-05	KAPPA(P)	4.15002240-05	KAPPA(P)	4.15002240-05	KAPPA(P)	4.15002240-05	KAPPA(P)	4.15002240-05	KAPPA(P)	4.15002240-05
KAPPA(R)	3.41365000-05	KAPPA(R)	3.41365000-05	KAPPA(R)	3.41365000-05	KAPPA(R)	3.41365000-05	KAPPA(R)	3.41365000-05	KAPPA(R)	3.41365000-05
DENSITY	4.49817110-08	DENSITY	4.49817110-08	DENSITY	4.49817110-08	DENSITY	4.49817110-08	DENSITY	4.49817110-08	DENSITY	4.49817110-08
KAPPA(P)	7.25328280-00	KAPPA(P)	7.25328280-00	KAPPA(P)	7.25328280-00	KAPPA(P)	7.25328280-00	KAPPA(P)	7.25328280-00	KAPPA(P)	7.25328280-00
KAPPA(R)	2.66871560-00	KAPPA(R)	2.66871560-00	KAPPA(R)	2.66871560-00	KAPPA(R)	2.66871560-00	KAPPA(R)	2.66871560-00	KAPPA(R)	2.66871560-00
THETA = 7.60000		THETA = 7.60000		THETA = 7.60000		THETA = 7.60000		THETA = 7.60000		THETA = 7.60000	
DENSITY	1.00022038-01	DENSITY	1.00022038-01	DENSITY	1.00022038-01	DENSITY	1.00022038-01	DENSITY	1.00022038-01	DENSITY	1.00022038-01
KAPPA(P)	3.04169370-05	KAPPA(P)	3.04169370-05	KAPPA(P)	3.04169370-05	KAPPA(P)	3.04169370-05	KAPPA(P)	3.04169370-05	KAPPA(P)	3.04169370-05
KAPPA(R)	2.06626410-05	KAPPA(R)	2.06626410-05	KAPPA(R)	2.06626410-05	KAPPA(R)	2.06626410-05	KAPPA(R)	2.06626410-05	KAPPA(R)	2.06626410-05

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 7.0000 CONTINUED					
DENSITY	6.21795+20-06	7.56290970-09	0.30319980-10	0.10139300-11	7.40474710-12
KAPPA(P)	3.32659+30+00	6.63697140-01	2.07924020-01	1.29488+20-01	1.21230570-01
KAPPA(R)	2.00251+30+00	3.72981740-01	1.51257090-01	1.22323879-01	1.1869655+01
THETA = 10.0000			13 DENSITIES		
DENSITY	1.40382130-01	2.4273590-02	4.07865500-03	7.07515520-04	1.25235710-04
KAPPA(P)	2.12432+20+05	1.47047260+05	7.69768030+04	2.03792170+04	3.82310030+03
KAPPA(R)	1.2098577+05	9.22216300+04	3.5+100+60+04	9.06549650+03	1.66071070+04
DENSITY	8.54000+90-08	1.06690382-08	1.21737387-09	1.26821570-10	1.16318981-11
KAPPA(P)	4.00961+00+00	6.65767950-01	1.93841400-01	1.34279070-01	1.31086350-01
KAPPA(R)	1.45681+95+00	3.06753+30-01	1.51975900-01	1.28933690-01	1.28741850-01
THETA = 15.0000			13 DENSITIES		
DENSITY	1.93620730-01	3.45468120-02	5.94434400-03	1.04135142-03	1.83502930-04
KAPPA(P)	1.35698+90+05	9.51995010+04	4.44419460+04	1.13563462+04	2.11735080+03
KAPPA(R)	8.42816680+04	5.74557240+04	2.44858320+04	6.34372400+03	1.16682300+03
DENSITY	1.40473060-07	1.77645700-06	2.03123900-09	2.10345440-10	1.92319150-11
KAPPA(P)	1.7808452+00	3.63376420-01	1.67016110-01	1.44376030-01	1.45258840-01
KAPPA(R)	5.25365+50+01	2.39042240-01	1.54648800-01	1.41710070-01	1.42636900-01
THETA = 24.4999			13 DENSITIES		
DENSITY	2.93266+50+01	5.02109570-02	8.71794900-03	1.54022163-03	2.81927110-04
KAPPA(P)	3.35396+30+04	6.35835440+04	2.48350160+04	5.61578090+03	1.03651450+03
KAPPA(R)	5.94266070+04	4.05913340+04	1.71151090+04	3.80722130+03	5.89307410+02
DENSITY	2.33015710-07	2.93272140-08	3.34145400-09	3.44161500-10	3.14947630-11
KAPPA(P)	1.10421+00+00	2.87673250-01	1.71835370-01	1.60242010-01	1.62730470-01
KAPPA(R)	3.54603030-01	2.21964670-01	1.63783400-01	1.55979030-01	1.59730530-01
THETA = 33.9998			13 DENSITIES		
DENSITY	4.26860+20-01	7.59262090-02	1.35642257-02	2.49733030-03	4.70001350-04
KAPPA(P)	5.84595+20+04	3.71611780+04	1.40417307+04	3.35713320+03	5.63635040+02
KAPPA(R)	2.61231+50+04	2.05187230+04	8.84681590+03	1.90811840+03	3.25224910+02
DENSITY	3.80291+40-07	4.90787360-08	5.58875200-09	5.70304450-10	5.22730690-11
KAPPA(P)	7.51971760-01	2.49205600-01	1.8174230-01	1.78610510-01	1.82005930-01
KAPPA(R)	4.25600+60-01	2.03172600-01	1.72953070-01	1.74696170-01	1.78644600-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 50.00-00			13 DENSITIES		
DENSITY	6.52368030-01	1.19955313-01	2.19763150-02	9.11955370-03	7.78968480-04
KAPPA(P)	2.49985500-04	1.13710500-01	4.06741870-03	9.47615690-02	2.28635710-02
KAPPA(R)	1.03437104-04	6.35175790-03	2.53813020-03	5.44001480-02	1.19967986-02
DENSITY	6.32067310-07	7.90907460-06	9.95994320-09	9.54049500-10	8.99380650-11
KAPPA(P)	5.51215740-01	2.42241290-01	1.94942990-01	1.04877230-01	1.88562450-01
KAPPA(R)	3.01037330-01	2.02118930-01	1.38130010-01	1.45235920-01	1.65128520-01
THETA = 59.99-98			13 DENSITIES		
DENSITY	9.62621450-01	1.80661990-01	3.34227650-02	6.27083380-03	1.17386335-03
KAPPA(P)	1.56517480-04	9.27060460-03	2.14536500-03	5.25977760-02	1.30687110-02
KAPPA(R)	6.16488360-03	5.70147590-03	1.42974720-03	3.13266090-02	6.62764710-01
DENSITY	4.77908450-07	1.26535900-07	1.44359900-08	1.57011024-09	1.47223420-10
KAPPA(P)	3.97947480-01	2.16649590-01	1.92697240-01	1.90369940-01	1.90765750-01
KAPPA(R)	2.64921770-01	2.00195280-01	1.48663650-01	1.87145450-01	1.87330240-01
THETA = 99.99-98			13 DENSITIES		
DENSITY	1.53846476-00	2.62546370-01	5.17074710-02	9.54358090-03	1.81048052-03
KAPPA(P)	8.92735910-03	4.32292230-03	1.36745410-03	3.25844530-02	7.58321970-01
KAPPA(R)	4.55051460-03	2.67444340-03	9.01803150-02	1.85075890-02	3.34604110-01
DENSITY	1.64449439-06	2.13429350-07	2.50120070-08	2.63261070-09	2.43245520-10
KAPPA(P)	2.74410400-01	2.02088410-01	1.93119320-01	1.93681730-01	1.97128790-01
KAPPA(R)	2.33704210-01	1.98663470-01	1.90180060-01	1.90206490-01	1.935539050-01
THETA = 149.99-95			13 DENSITIES		
DENSITY	2.55366070-00	4.63977930-01	8.56885490-02	1.62699240-02	3.18195030-03
KAPPA(P)	6.02158050-03	2.60822180-03	6.71945780-02	1.45613950-02	3.02858870-01
KAPPA(R)	2.68462700-03	1.48486470-03	4.49013510-02	8.86213650-01	1.56216596-01
DENSITY	2.93304360-06	3.74123470-07	4.34654300-08	4.60547560-09	4.33313410-10
KAPPA(P)	2.51480390-01	2.07766380-01	2.03595773-01	2.03328050-01	2.03282830-01
KAPPA(R)	2.29144400-01	2.01462100-01	1.93694420-01	1.99595390-01	1.99583220-01
THETA = 229.99-90			13 DENSITIES		
DENSITY	4.26256900-00	7.85758790-01	1.49380290-01	2.90611220-02	5.70548070-03
KAPPA(P)	3.04871430-03	9.58170220-02	2.12867200-02	5.07012700-01	1.28773115-01
KAPPA(R)	1.17636440-03	5.62865890-02	1.56245800-02	3.57314040-01	7.68800240-00

GRAY ABSORPTION COEFFICIENTS CONTINUED

TETA = 220.9990 CONTINUED			TETA = 300.00012		
DENSITY			DENSITY		
5.2079200-06	6.7667140-07	7.9603340-08	8.4577730-09	7.9602550-10	
KAPPA(P)	2.070150-01	2.8635980-01	2.9331710-01	2.0328220-01	
KAPPA(R)	2.117400-01	2.0219690-01	2.0020080-01	1.9558080-01	
TETA = 300.00012			DENSITY		
DENSITY			DENSITY		
7.3169650-00	1.3080350-00	2.6791460-01	5.1793270-02	1.0155270-02	6.2805310-03
KAPPA(P)	1.38690-00-03	3.92396170-02	1.12300670-02	7.6061220-00	2.5639610-01
KAPPA(R)	5.66899370-02	2.1620490-02	6.00878920-01	3.13172190-00	2.3302620-01
TETA = 300.00012			DENSITY		
DENSITY			DENSITY		
9.6083760-06	1.2560650-06	1.47859990-07	1.37052620-08	1.47619220-09	
KAPPA(P)	2.10668770-01	2.0421040-01	2.03362130-01	2.03621580-01	
KAPPA(R)	2.0823140-01	2.00958870-01	1.99749930-01	1.99909800-01	
TETA = 300.00012			DENSITY		
DENSITY			DENSITY		
1.24303350-01	2.37112000-00	8.59805080-01	9.03905110-02	1.79648180-02	1.12039610-00
KAPPA(P)	8.74428150-02	2.42348080-02	6.22127500-01	2.08283040-01	2.1909100-01
KAPPA(R)	2.81651020-02	1.30496700-02	3.42786930-01	1.53108850-00	2.15080330-01
TETA = 300.00012			DENSITY		
DENSITY			DENSITY		
1.7220340-00	2.23497620-06	2.02553630-07	2.74835240-08	2.62417340-09	
KAPPA(P)	2.06231-00-01	2.04268290-01	2.04218450-01	2.04263790-01	
KAPPA(R)	2.02876300-01	2.00516650-01	2.00499390-01	2.00543110-01	
TETA = 300.00012			DENSITY		
DENSITY			DENSITY		
1.97766-00-01	3.83007130-00	7.52578060-01	1.49214560-01	2.97265700-02	1.80922600-00
KAPPA(P)	3.81631000-02	1.05067280-02	2.03025500-01	1.19945016-00	2.12839490-01
KAPPA(R)	1.127534670-02	4.70054690-01	1.22808060-01	7.4877080-01	2.86426050-01
TETA = 300.00012			DENSITY		
DENSITY			DENSITY		
2.8427800-05	3.69500030-06	4.44695560-07	4.61859610-08	4.34691290-09	
KAPPA(P)	2.0567040-01	2.04433610-01	2.04287890-01	2.04273600-01	
KAPPA(R)	2.01403460-01	2.00756210-01	2.00565580-01	2.00549730-01	
TETA = 300.00012			DENSITY		
DENSITY			DENSITY		
3.30795410-04	6.40020190-00	1.27989910-00	2.54153720-01	5.06054510-02	3.15435100-00
KAPPA(P)	1.57107800-02	3.91434450-01	8.6985560-00	6.58060710-01	2.22756950-01
KAPPA(R)	3.79485510-01	1.42875130-01	9.92690140-01	4.03468010-01	2.82978930-01
TETA = 300.00012			DENSITY		
DENSITY			DENSITY		
4.85343120-05	6.30889530-06	7.42227580-07	7.88617240-08	7.42227800-09	
KAPPA(P)	2.04635680-01	2.04316500-01	2.04276670-01	2.04271550-01	
KAPPA(R)	2.00831100-01	2.00577620-01	2.00548930-01	2.00545120-01	

ONLY ABSORPTION CUFFS CLEARLY CONTINUED

[illegible]

GRAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 6999.99690 CONTINUED

DENSITY 0.96790140-06 1.16042501-04 1.37461740-05 1.46053187-06 1.37461770-07
 KAPPA(P) 1.96117400-01 1.96115200-01 1.96115010-01 1.96115010-01 1.96115010-01
 KAPPA(N) 1.96257630-01 1.96257400-01 1.96257240-01 1.96257240-01 1.96257240-01

THETA = 9999.99220 13 DENSITIES

DENSITY 1.30811541-03 2.00448220+02 3.99885420+01 7.99204740+00 1.59694458+00 3.19244410-01 5.86793740-02 9.97350200-03
 KAPPA(P) 1.01460030+00 3.61623510-01 2.17700500-01 1.96276400-01 1.80417490-01 1.80172530-01 1.80131100-01 1.80123030-01
 KAPPA(N) 4.30029400-01 2.02259450-01 1.99450020-01 1.92347430-01 1.91089100-01 1.90978200-01 1.90962720-01 1.90959000-01

DENSITY 1.33465006-03 1.94505270-04 2.34711160-05 2.49300740-06 2.34711200-07
 KAPPA(P) 1.80122110-01 1.80121730-01 1.80121730-01 1.80121730-01 1.80121730-01
 KAPPA(N) 1.90959490-01 1.90959290-01 1.90959100-01 1.90959100-01 1.90959100-01

1050301			JANÉ ALUMINUM 3A -- 12 FREQUENCIES -- OCTOBER 15, 1965			MATERL = 1013			MX = 990		
GREY ABSORPTION COEFFICIENTS			25 TEMPERATURES								
THETA = .1000			17 DENSITIES								
DENSITY	2.7000060+00	0.53814770-01	2.70000900-01	0.53811480-02	2.69999570-02	0.53815780-03	2.70000940-03	0.53811480-04	2.70000940-03	0.53811480-04	2.70000940-03
KAPPA(P)	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16
KAPPA(R)	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10
DENSITY	2.69999650-04	0.53815990-05	2.699992910-05	0.53786220-06	2.69988880-06	0.53773490-07	2.70011850-07	0.53806130-08	2.70011850-07	0.53806130-08	2.70011850-07
KAPPA(P)	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16
KAPPA(R)	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10	0.43600190-10
DENSITY	2.70007650-04										
KAPPA(P)	1.40531550-16										
KAPPA(R)	0.43600190-10										
THETA = .2000			17 DENSITIES								
DENSITY	2.7000060+00	0.53814770-01	2.70000900-01	0.53811480-02	2.69999570-02	0.53815780-03	2.70000940-03	0.53811480-04	2.70000940-03	0.53811480-04	2.70000940-03
KAPPA(P)	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16
KAPPA(R)	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05
DENSITY	2.69999650-04	0.53815990-05	2.699992910-05	0.53786220-06	2.69988880-06	0.53773490-07	2.70011850-07	0.53806130-08	2.70011850-07	0.53806130-08	2.70011850-07
KAPPA(P)	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16
KAPPA(R)	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05
DENSITY	2.70007650-04										
KAPPA(P)	1.40531550-16										
KAPPA(R)	1.50063310-05										
THETA = .3000			17 DENSITIES								
DENSITY	2.7000060+00	0.53814770-01	2.70000900-01	0.53811480-02	2.69999570-02	0.53815780-03	2.70000940-03	0.53811480-04	2.70000940-03	0.53811480-04	2.70000940-03
KAPPA(P)	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16
KAPPA(R)	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05
DENSITY	2.69999650-04	0.53815990-05	2.699992910-05	0.53786220-06	2.69988880-06	0.53773490-07	2.70011850-07	0.53806130-08	2.70011850-07	0.53806130-08	2.70011850-07
KAPPA(P)	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16	1.40531550-16
KAPPA(R)	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05	1.50063310-05
DENSITY	2.70007650-04										
KAPPA(P)	1.40531550-16										
KAPPA(R)	1.50063310-05										

RAY ABSORPTION COEFFICIENTS CONTINUED

TALTA = .6000		17 DENSITIES	
DENSITY	2.7000000-00	0.53014770-01	2.7000000-01
KAPPA(P)	7.29489570+01	7.29431170+01	7.2935530+01
KAPPA(R)	1.2306415+01	1.23900590+01	1.2374539+01
DENSITY	4.8999950-00	6.53015990-05	2.8992910-05
KAPPA(P)	7.20446490+01	7.24770800+01	7.21105210+01
KAPPA(R)	1.23535450+01	1.23103493+01	1.22599310+01
DENSITY	2.7000700-00		
KAPPA(P)	5.00530700+01		
KAPPA(R)	8.80901500+00		
TALTA = .5000		17 DENSITIES	
DENSITY	2.7000000-00	6.53014770-01	2.7000000-01
KAPPA(P)	7.29489570+01	7.24770800+01	7.21105210+01
KAPPA(R)	1.5006600+02	1.50022900+02	1.57960230+02
DENSITY	4.6999950-00	6.53015990-05	2.8992910-05
KAPPA(P)	7.3003470+02	7.22906550+02	7.03004030+02
KAPPA(R)	1.55007450+02	1.52720210+02	1.40092430+02
DENSITY	2.7000700-00		
KAPPA(P)	1.34393420+02		
KAPPA(R)	4.83932000+01		
TALTA = .6000		17 DENSITIES	
DENSITY	2.7000000-00	6.53014770-01	2.7000000-01
KAPPA(P)	5.19224550+03	5.19074500+03	5.1800000+03
KAPPA(R)	8.0063500+02	6.00464570+02	8.05787020+02
DENSITY	4.6999950-00	6.53015990-05	2.8992910-05
KAPPA(P)	5.0070600+03	4.87020000+03	2.6410000+03
KAPPA(R)	7.8019120+02	7.25041100+02	6.67033000+02
DENSITY	2.7000700-00		
KAPPA(P)	8.3069950+01		
KAPPA(R)	2.11070700+01		

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = .7000									
17 DENSITIES									
DENSITY	4.7000060+00	6.53014770-01	2.70000900-01	8.53011440-02	2.69999570-02	8.53015780-03	2.70000940-03	8.53011640-04	
KAPPA(P)	8.37251750+03	6.36356390+03	8.34760510+03	8.31903720+03	8.26942280+03	8.18124740+03	8.02686970+03	7.75947670+03	
KAPPA(R)	4.40910240+03	2.46643710+03	2.46175540+03	2.45342420+03	2.43867450+03	2.41269570+03	2.36714520+03	2.26826970+03	
DENSITY	2.6999950-04	8.53015990-05	2.69992910-05	8.53786220-06	2.69988800-06	8.53773490-07	2.70011050-07	8.53046130-08	
KAPPA(P)	7.30428-30+03	6.56698360+03	5.44247930+03	3.95572310+03	2.31598800+03	1.06537260+03	4.00663100+02	1.35346780+02	
KAPPA(R)	2.15464430+03	1.93664030+03	1.60500150+03	1.16065520+03	6.82989820+02	3.14178070+02	1.18213221+02	3.99113190+01	
DENSITY	4.70007150-06								
KAPPA(P)	4.37713710+01								
KAPPA(R)	1.29054537+01								
THETA = .80000									
17 DENSITIES									
DENSITY	4.7000060+00	6.53014770-01	2.70000900-01	8.53011440-02	2.69999570-02	8.53015780-03	2.70000940-03	8.53011640-04	
KAPPA(P)	1.63519495+04	1.63189111+04	1.52662606+04	1.61566972+04	1.59740367+04	1.56545981+04	1.51021128+04	1.41885893+04	
KAPPA(R)	5.54042430+03	5.52904260+03	5.50917380+03	5.47008250+03	5.41224860+03	5.30396480+03	5.11677670+03	4.80047410+03	
DENSITY	4.6999950-04	8.53015990-05	2.69992910-05	8.53786220-06	2.69988800-06	8.53773490-07	2.70011050-07	8.53046130-08	
KAPPA(P)	1.26537631+04	1.03720893+04	7.36813550+03	4.23115370+03	1.90013450+03	7.04289820+02	2.36377460+02	7.84168830+01	
KAPPA(R)	4.20724050+03	3.51417460+03	2.49638740+03	1.43352250+03	6.43736820+02	2.38564550+02	8.00282690+01	2.58290590+01	
DENSITY	2.70007050-08								
KAPPA(P)	2.45048030+01								
KAPPA(R)	8.23917310+00								
THETA = .90000									
17 DENSITIES									
DENSITY	2.7000060+00	8.53014770-01	2.70000900-01	8.53011440-02	2.69999570-02	8.53015780-03	2.70000940-03	8.53011640-04	
KAPPA(P)	2.63467420+04	2.62599420+04	2.61024543+04	2.58276250+04	2.53446810+04	2.45140080+04	2.31032760+04	2.07913080+04	
KAPPA(R)	1.01786735+04	1.014066317+04	1.00845505+04	9.97841900+03	9.79247888+03	9.47052780+03	8.92427120+03	8.03232960+03	
DENSITY	2.6999950-04	8.53015990-05	2.69992910-05	8.53786220-06	2.69988800-06	8.53773490-07	2.70011050-07	8.53046130-08	
KAPPA(P)	1.72719650+04	1.25587601+04	7.41092830+03	3.43258052+03	1.29771440+03	4.40539450+02	1.44271930+02	4.77543410+01	
KAPPA(R)	8.67263370+03	4.84401870+03	2.80587780+03	1.32570530+03	5.00811590+02	1.49585940+02	5.50662420+01	1.77753480+01	
DENSITY	2.70007650-08								
KAPPA(P)	1.71478010+01								
KAPPA(R)	5.93863900+00								

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 1.0000			11 DENSITIES		
DENSITY	1.7085200-01	2.0013640-02	1.70950193-03	1.77629630-04	2.51111160-05
KAPPA(P)	4.34807170+04	4.25822560+04	3.41572290+04	1.98092300+04	6.24439750+03
KAPPA(R)	9.21320690+03	7.05167290+03	5.60814790+03	3.10063000+03	1.00272030+03
DENSITY			1.67992020-10		
KAPPA(P)	1.04426490+08	1.75806017-09	5.97536400-01	1.44910340-01	1.67992020-10
KAPPA(R)	1.06575051+01	3.35227760+00	1.44910340-01	1.44910340-01	1.44910340-01
THETA = 1.5000			11 DENSITIES		
DENSITY	7.76524400-02	9.79767660-03	1.30135002-03	2.12204550-04	3.00427550-05
KAPPA(P)	4.15270100+04	5.20000500+04	2.82514460+04	1.26769405+04	4.90503560+03
KAPPA(R)	4.74674720+04	3.15774930+04	1.77734310+04	7.13722910+03	2.30900060+03
DENSITY			2.18092900-10		
KAPPA(P)	1.91033400+08	2.26045470-09	4.38144410-01	1.76077600-01	1.76077600-01
KAPPA(R)	1.41035540+01	2.39089400+00	1.76077600-01	1.76077600-01	1.76077600-01
THETA = 4.2500			11 DENSITIES		
DENSITY	7.29019430-02	1.07401098-02	1.48341630-03	2.63412330-04	4.18424170-05
KAPPA(P)	7.61750000+04	4.94540860+04	3.42263100+04	2.20952200+04	7.91860200+03
KAPPA(R)	4.80360900+04	3.36914690+04	2.04646780+04	1.12325400+04	4.40094170+03
DENSITY			3.51666010-10		
KAPPA(P)	2.80463420+08	3.08042000-09	2.08367900-01	1.24574660-01	1.24574660-01
KAPPA(R)	1.23260056+01	1.52070035+00	1.24574660-01	1.24574660-01	1.24574660-01
THETA = 3.4000			11 DENSITIES		
DENSITY	4.7191390-02	1.36250756-02	2.04495290-03	3.31709050-04	5.46435160-05
KAPPA(P)	4.78530450+04	4.69575820+04	3.96240920+04	2.05757800+04	6.09479200+03
KAPPA(R)	3.53373000+04	3.14766090+04	2.57554090+04	1.40950636+04	4.27679800+03
DENSITY			6.71639000-10		
KAPPA(P)	4.39286400+08	5.70912540-09	9.60920060-02	8.53265200-02	8.53265200-02
KAPPA(R)	3.73007400+00	4.97261110-01	8.53265200-02	8.53265200-02	8.53265200-02
THETA = 5.0000			11 DENSITIES		
DENSITY	1.14333005-01	1.79303040-02	2.80370300-03	4.64000590-04	8.46318500-05
KAPPA(P)	5.01914400+04	3.45720190+04	2.26036570+04	8.99241130+03	1.96615130+03
KAPPA(R)	1.30731409+04	1.17556583+04	8.20697670+03	3.64579570+03	9.02234020+02

GLEY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.00001 CONTINUED			11 DENSITIES		
DENSITY	7.8238840-08	1.01053597-08	1.13605988-09		
KAPPA(P)	1.2305357+00	1.95861620-01	7.28516563-02		
KAPPA(R)	8.8807400-01	1.61264010-01	6.56206960-02		
THETA = 7.00000			11 DENSITIES		
DENSITY	1.55545030-01	2.50400180-02	4.11770220-03	7.23304700-04	1.37226190-04
KAPPA(P)	2.85867460+04	1.72888990+04	9.03231540+03	2.95918750+03	6.20173910+02
KAPPA(R)	4.33536020+03	2.89777923+03	1.33520810+03	5.63676200+02	1.50645580+02
THETA = 10.00005			11 DENSITIES		
DENSITY	1.03883066-07	1.26197855-08	1.37873438-09		
KAPPA(P)	1.39676460+00	2.77107430-01	1.01751673-01		
KAPPA(R)	5.82993660-01	1.93292633-01	8.71678260-02		
THETA = 15.00000			11 DENSITIES		
DENSITY	4.3387460-01	3.91858320-02	6.50373440-03	1.16366509-03	2.08560800-04
KAPPA(P)	1.33339-13+04	8.98426490+02	4.63743390+03	1.76726770+03	5.46842040+02
KAPPA(R)	1.74566340+03	9.75041830+02	4.817522240+02	2.30423730+02	1.12830863+02
THETA = 22.50011			11 DENSITIES		
DENSITY	1.35817450-07	1.62902340-08	1.74327589-09		
KAPPA(P)	1.53903059+00	3.29038460-01	1.25807390-01		
KAPPA(R)	7.54042620-01	1.94525890-01	1.07250292-01		
THETA = 28.50011			11 DENSITIES		
DENSITY	3.61082470-01	5.85227330-02	9.71844670-03	1.64361047-03	2.84729760-04
KAPPA(P)	1.30532175+04	9.02216830+03	5.94011700+03	2.14406080+03	6.37930880+02
KAPPA(R)	1.6100410+03	6.90987110+02	6.36089940+02	3.78474970+02	1.59599890+02
THETA = 35.00011			11 DENSITIES		
DENSITY	4.84263430-07	4.20599970-08	2.38539770-09		
KAPPA(P)	1.64226265+00	3.54507580-01	1.58844430-01		
KAPPA(R)	7.07165480-01	2.14436880-01	1.36550610-01		
THETA = 42.50011			11 DENSITIES		
DENSITY	4.67714120-01	7.99303230-02	1.36090540-02	2.24689120-03	3.94532120-04
KAPPA(P)	1.45990492+04	9.11220390+03	5.76011000+03	2.33507650+03	7.33670450+02
KAPPA(R)	3.64363630+03	1.80122000+03	9.42108050+02	4.50109090+02	1.88208880+02
THETA = 50.00011			11 DENSITIES		
DENSITY	2.53957450-07	3.04184950-08	3.33197770-09		
KAPPA(P)	1.89050358+00	3.89291480-01	1.88433520-01		
KAPPA(R)	6.91347970-01	2.40749090-01	1.70547740-01		

ONEY ABSORPTION COEFFICIENTS CONTINUED

THETA = 33.9999			10 DENSITIES		
DENSITY	5.8055360-01	1.03600697-01	1.7739620-02	3.69010760-03	5.40703020-04
KAPPA(P)	2.5301940-04	1.50860230-04	7.9020170-03	2.4105530-03	6.4119390-02
KAPPA(R)	1.37306793-04	6.52920650-03	2.52010510-03	8.10056310-02	2.3350710-02
THETA = 34.0000			10 DENSITIES		
DENSITY	3.04131650-07	4.93351120-08			
KAPPA(P)	1.13576455-08	2.91713540-01			
KAPPA(R)	4.65097470-01	2.00451070-01			
THETA = 34.0000			10 DENSITIES		
DENSITY	0.34217170-01	1.40756020-01	2.49805390-02	4.30070900-03	7.91002160-04
KAPPA(P)	1.89913040-04	1.24110016-04	5.00736300-03	1.50344420-03	3.33602010-02
KAPPA(R)	9.79597570-03	6.20624900-03	2.67921460-03	7.99070750-02	1.70724470-02
THETA = 60.9999			10 DENSITIES		
DENSITY	6.75563970-07	0.70056600-00			
KAPPA(P)	4.77236450-01	2.04025270-01			
KAPPA(R)	2.03105000-01	1.07100070-01			
THETA = 60.9999			10 DENSITIES		
DENSITY	1.14990500-00	1.97017260-01	3.50670970-02	6.35031430-03	1.20061100-03
KAPPA(P)	1.44607153-04	5.56262060-03	3.45016110-03	7.90510500-02	1.40561340-02
KAPPA(R)	4.87304750-03	3.70100910-03	1.95501460-03	4.92040400-02	7.50053500-01
THETA = 94.9999			10 DENSITIES		
DENSITY	1.1109477-06	1.45444680-07			
KAPPA(P)	4.74693100-01	1.79774670-01			
KAPPA(R)	4.40063560-01	1.7762990-01			
THETA = 94.9999			10 DENSITIES		
DENSITY	1.6440672-08	2.97550450-01	5.40655790-02	1.02623237-02	2.01001330-03
KAPPA(P)	0.95321760-03	5.40106100-03	1.32263330-03	2.76400400-02	5.06736400-01
KAPPA(R)	1.67274450-03	1.16709600-03	5.11750000-02	1.359006010-02	2.70361590-01
THETA = 149.9999			10 DENSITIES		
DENSITY	1.94663632-06	2.44902260-07			
KAPPA(P)	2.10829150-01	1.75514960-01			
KAPPA(R)	1.97666500-01	1.69065300-01			
THETA = 149.9999			10 DENSITIES		
DENSITY	2.73900570-08	5.02317630-01	9.47805570-02	1.05007400-02	3.67271170-03
KAPPA(P)	4.10229500-03	1.77150000-03	4.23433000-02	7.97921370-01	1.6012000-01
KAPPA(R)	4.05403330-02	1.79349360-00	0.53964115-00	1.90537500-01	4.53009000-00

GRAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 144.9945 CONTINUED

DENSITY 3.0732030-06 3.88555450-07
KAPPA(P) 2.94798460-01 2.11936200-01
KAPPA(R) 2.0.233620-01 1.93296040-01

THETA = 224.9940 10 DENSITIES

DENSITY 4.60203110+00 5.62442330-01 1.70160360-01 3.27691910-02 6.22727770-03 1.18471622-03 2.11227460-04 3.55667270-05
KAPPA(P) 1.65719200+02 5.71463940+02 1.68152610+02 5.31154570+01 1.67145250+01 5.71935470+00 1.45933723+00 9.24167500+01
KAPPA(R) 2.49423430+02 8.60944860+01 2.73453600+01 7.24057170+00 2.15797540+00 7.40909100+01 3.40268930+01 2.27160690+01

DENSITY 5.85793560-06 7.09241390-07
KAPPA(P) 2.31151620-01 1.99711590-01
KAPPA(R) 2.01313470-01 1.95448760-01

THETA = 699.99476 4 DENSITIES

DENSITY 7.9124430-01 1.56805360-01 3.12251940-02 6.23728710-03
KAPPA(P) 3.22146070+01 6.78626010+00 1.51332162+00 4.08052270-01
KAPPA(R) 1.15405076+01 2.37506540+00 6.22305590-01 2.77481630-01

52	JANE/SCAT	AL-109	TEMP(1.-7000.EV)	10 FREQ.	C1/WBL	10-26-67	MATRL = 3013	MM = 943
KEY ABSORPTION COEFFICIENTS								
23 TEMPERATURES								
13 DENSITIES								
THETA =	1.00000							
DENSITY	1.6412030-01	1.96609050-02	1.76598254-03	1.74294100-04	2.49242340-05	9.47608830-06	7.90908040-07	1.3840470-07
KAPPA(P)	7.9305000+05	6.58773070+05	5.07564050+05	1.2473332+05	2.03132550+04	2.74630900+03	9.18169280+02	7.86731420+01
KAPPA(R)	1.50363700+05	1.26366505+05	7.97952990+04	2.76141300+04	5.23498030+03	6.50021040+02	7.37836350+01	1.10710000+01
DENSITY	1.8114300-06	1.74662616-09	1.66759250-10	1.70159710-11	1.50105340-12			
KAPPA(P)	1.59366412+01	4.49754080+00	7.60429320-01	1.11836870-01	3.83167560-02			
KAPPA(R)	2.84306100+00	3.01550100-01	1.57464690-01	5.11299430-02	3.39506250-02			
THETA =	1.50000							
13 DENSITIES								
DENSITY	7.36293170-02	9.61303400-03	1.24440091-03	2.10277620-04	3.77494390-05	6.35117990-06	9.93923580-07	1.30023590-07
KAPPA(P)	7.17407430+05	3.15942160+05	2.59408340+05	7.11166740+04	1.61487177+04	3.75204640+03	7.75301320+02	1.03180420+02
KAPPA(R)	4.78140500+05	3.34437250+05	1.40642330+05	3.44612320+04	6.74061070+03	1.40271990+03	2.01574610+02	4.75444000+01
DENSITY	1.84608400-06	2.24374410-09	2.164874510-10	2.10510640-11	1.95609710-12			
KAPPA(P)	2.04449540+04	3.20461190+00	5.50400610-01	1.09321521-01	5.12900470-02			
KAPPA(R)	6.76514100+00	1.03244444+00	1.99458870-01	6.67116550-02	4.85023020-02			
THETA =	2.25000							
13 DENSITIES								
DENSITY	9.53896700-04	1.05407490-02	1.66526173-03	2.61341910-04	4.15326830-05	7.24144410-06	1.15012116-06	1.66743350-07
KAPPA(P)	5.34157400+05	3.22223270+05	1.09330050+05	1.11042020+05	2.77397900+04	9.81126310+03	7.69641750+02	1.14013020+02
KAPPA(R)	2.74380500+05	2.26446740+05	1.19159701+05	4.13900170+04	9.34172190+03	1.04705040+03	3.62904080+02	5.25910000+01
DENSITY	2.36096050-08	3.05746410-09	3.59943600-10	3.01303790-11	3.50863260-12			
KAPPA(P)	1.51301570+01	1.76540574+00	2.35629700-01	6.48004320-02	4.69200340-02			
KAPPA(R)	5.04435400+00	7.00902100-01	1.29531260-01	5.74443670-02	4.62456290-02			
THETA =	3.00000							
13 DENSITIES								
DENSITY	7.74791610-02	1.29069006-02	2.00421500-03	3.29237540-04	5.42375540-05	9.59250740-06	1.60714976-06	2.83937900-07
KAPPA(P)	3.75250610+05	2.53700540+05	1.89618590+05	7.19034910+04	1.39118459+04	1.80842703+03	2.30073030+02	3.14545420+01
KAPPA(R)	4.87058400+04	4.12063640+04	6.83707220+04	2.95139900+04	7.06964910+03	1.14247400+03	1.52743190+02	2.81225000+01
DENSITY	4.30012510-08	5.66646750-09	6.66614000-10	7.08270580-11	6.44540000-12			
KAPPA(P)	4.31785170+00	5.84632040-01	1.03574512-01	5.09297010-02	4.59853580-02			
KAPPA(R)	2.64490430+00	3.65741540-01	8.90595520-02	5.07089930-02	4.49964400-02			
THETA =	5.00000							
13 DENSITIES								
DENSITY	4.55439500-02	1.71717270-02	2.77031590-03	4.01425020-04	6.40027550-05	1.03132990-05	2.07716220-06	5.05316940-07
KAPPA(P)	1.94356450+05	1.40497100+05	8.07012990+04	1.99702290+04	3.00477770+03	9.55763400+02	6.76011300+01	9.92874340+00
KAPPA(R)	3.13299550+04	2.40049493+04	1.51206097+04	5.03044270+03	1.42710030+03	2.73790070+02	4.87747330+01	6.78800700+00

ONLY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.00000 CONTINUED

DENSITY 7.76557e-07 1.002995e-10 1.1276388e-09 1.03905e-10 9.0111630-12
 KAPPA(P) 1.4003240e+00 2.2411370-01 7.77144e-02 6.12402e-02 6.01325e-02
 KAPPA(R) 1.00411487e+00 1.01287520-01 6.98303190-02 5.84364180-02 5.90237130-02

THETA = 7.00000 13 DENSITIES

DENSITY 1.24562e-07 2.30755930-02 3.95715e-03 7.17936e-04 1.36206300-04 2.67581890-05 4.01189330-06 7.59261200-07
 KAPPA(P) 1.07649e-05 6.35022700+04 2.76013e+04 5.53593360+03 9.56385390+02 1.75216600+02 3.32989330+01 7.69808020+00
 KAPPA(R) 1.51049e-21+04 8.72478390+03 4.020107e+03 1.17664080+03 2.97807090+02 7.02561570+01 1.73882540+01 4.73449820+00

DENSITY 1.02107e-07 1.25261192-06 1.56951e-09 1.30090590-10 1.16571676-11
 KAPPA(P) 1.78508e+00 3.35221e-01 1.1059318-01 7.97483680-02 7.66817930-02
 KAPPA(R) 1.04155e-06+00 2.10447950-01 8.94944160-02 7.59429140-02 7.50005280-02

THETA = 10.00000 13 DENSITIES

DENSITY 4.04709e-01 3.41e-20e-02 6.2498030-03 1.15830982-03 2.06661700-04 3.67493530-05 6.28050800-06 9.59983290-07
 KAPPA(P) 1.34773e-05 7.08627330+04 2.25735390+04 5.61088603+03 1.30488980+03 3.14812228+02 5.89844550+01 1.08844862+01
 KAPPA(R) 1.09355e-08+04 4.51327770+03 2.00878640+03 7.74372470+02 3.09900460+02 9.63783830+01 2.12462280+01 4.43380430+00

DENSITY 1.34403e-07 1.61641940-06 1.72943e-09 1.72347220-10 1.40519490-11
 KAPPA(P) 1.90784e+00 3.76239640-01 1.31582400-01 9.91406220-02 1.02469918-01
 KAPPA(R) 4.40589e-02-01 2.02464300-01 1.08788664-01 9.55854180-02 1.00814811-01

THETA = 15.00000 13 DENSITIES

DENSITY 4.80045e-01 5.34384910-02 9.15923160-03 1.58592885-03 2.79243800-04 5.02672930-05 8.36503520-06 1.29830839-06
 KAPPA(P) 2.321827e-05 1.42143150+05 4.2316330+04 9.0941640+03 1.58502580+03 2.68888960+02 5.11276770+01 9.67257890+00
 KAPPA(R) 1.82405e-05+04 8.81621530+03 4.82369700+03 1.74518330+03 4.24769200+02 8.97313290+01 1.94680350+01 3.08960280+00

DENSITY 1.24594e-07 2.10638790-08 2.36532590-09 2.33310740-10 2.04225820-11
 KAPPA(P) 4.80160e+00 3.48291750-01 1.61982660-01 1.32353620-01 1.36503360-01
 KAPPA(R) 7.44401e-02-01 2.17604440-01 1.26597340-01 1.24310260-01 1.34470430-01

THETA = 24.09559 13 DENSITIES

DENSITY 3.98036e-01 7.35050500-02 1.25930776-02 2.14920680-03 3.84363440-04 6.09548920-05 1.44934401-05 1.78471834-06
 KAPPA(P) 4.29427e-05 1.13434937+05 2.61052030+04 5.4517210+03 1.17854500+03 2.23122940+02 4.55795850+01 1.047215-7+01
 KAPPA(R) 4.82335e-05+04 4.41740380+04 9.90276120+03 1.93108630+03 3.30368920+02 7.27288350+01 1.62223500+01 3.28989926+00

DENSITY 2.52037e-07 3.01939760-08 3.30718010-09 3.33928000-10 3.09973320-11
 KAPPA(P) 1.99748018+00 3.94807490-01 1.84471050-01 1.64449230-01 1.64449230-01
 KAPPA(R) 6.94375e-05-01 2.41817730-01 1.70785400-01 1.62904800-01 1.62378910-01

GREY ABSORPTION COEFFICIENTS CONTINUED

TMEYA = 33.99998									
13 DENSITIES									
UENSITY	3.75733620-01	1.02791459-01	1.75928440-02	3.07219620-03	5.40958490-04	9.75609800-05	1.63999760-05	2.30866750-06	
KAPPA(P)	1.06620762-05	5.39622190-04	1.21003656-04	2.76694000-03	7.02625470-02	1.66075850-02	3.20643950-01	6.22070050-00	
KAPPA(R)	3.63431610-04	2.27167900-04	5.95063900-03	1.05959380-03	2.60340300-02	6.62065870-01	1.22272055-01	2.13764600-00	
13 DENSITIES									
UENSITY	3.01231.70-07	4.89674550-08	5.75055220-09	6.10862140-10	5.74911650-11				
KAPPA(P)	1.14377693-06	2.91781510-01	1.79253950-01	1.66170490-07	1.63777700-01				
KAPPA(R)	4.71018550-01	2.08695080-01	1.69261400-01	1.63725990-01	1.62335620-01				
13 DENSITIES									
TMEYA = 50.00000									
13 DENSITIES									
UENSITY	4.25393030-01	1.43522280-01	2.47888660-02	4.36627510-03	7.01925110-04	1.45475050-04	2.50945000-05	4.36597010-06	
KAPPA(P)	3.81762490-04	1.79813240-04	5.03949540-03	1.62354770-03	3.00857470-02	7.41701630-01	1.20401005-01	2.21264350-00	
KAPPA(R)	1.89170510-04	1.00538602-04	3.26865850-03	8.53811090-02	1.07972370-02	3.13927010-01	4.79127710-00	0.02722500-01	
13 DENSITIES									
UENSITY	6.70508500-07	4.71513320-08	1.02927509-08	1.04935524-09	1.02527427-10				
KAPPA(P)	4.7732400-01	2.40190680-01	1.60136700-01	1.65120790-01	1.64892468-01				
KAPPA(R)	2.83744490-01	1.87255170-01	1.60054320-01	1.63171090-01	1.62471120-01				
13 DENSITIES									
TMEYA = 69.99998									
13 DENSITIES									
UENSITY	1.14011.98-00	1.96253280-01	3.46049330-02	6.31096210-03	1.18624787-03	2.32424420-04	4.25104470-05	7.21940750-06	
KAPPA(P)	1.80089650-04	1.06146804-04	3.66943500-03	8.14846660-02	1.51173010-02	2.71162170-01	4.78927020-00	9.13711700-01	
KAPPA(R)	5.90197470-03	4.37865320-03	2.10470150-03	5.10761600-02	7.96355770-01	1.20527670-01	1.07663044-00	4.95074310-01	
13 DENSITIES									
UENSITY	1.11050429-08	1.40360020-07	1.69433930-08	1.40421544-09	1.6950410-10				
KAPPA(P)	4.7802210-01	1.79195300-01	1.66440060-01	1.64466780-01	1.65068950-01				
KAPPA(R)	2.40669410-01	1.77489620-01	1.64423640-01	1.44394610-01	1.62640960-01				
13 DENSITIES									
TMEYA = 99.99998									
13 DENSITIES									
UENSITY	1.67097443-00	2.95342670-01	5.36637750-02	1.01059000-02	1.99015650-03	3.95177710-04	7.25213920-05	1.23219377-05	
KAPPA(P)	4.01247404-04	5.68362250-03	1.58231450-03	2.80153860-02	5.10759110-01	9.44692290-00	1.03130610-00	4.46430050-01	
KAPPA(R)	1.86432170-03	1.26247950-03	5.37233580-02	1.40034550-02	2.73815300-01	4.90000040-00	1.05173205-00	3.44191190-01	
13 DENSITIES									
UENSITY	1.89225752-06	2.43156640-07	2.74173490-08	2.77102140-09	2.48962220-10				
KAPPA(P)	2.10874440-01	1.75247640-01	1.76527780-01	1.41940360-01	1.02322430-01				
KAPPA(R)	1.9812940-01	1.69880000-01	1.72470680-01	1.80601920-01	1.89089000-01				
13 DENSITIES									
TMEYA = 149.99995									
13 DENSITIES									
UENSITY	2.71916610-00	4.98576620-01	9.40765600-02	1.84467330-02	3.63922440-03	7.16305200-04	1.20390520-04	2.88097200-05	
KAPPA(P)	4.46192720-03	1.88072930-03	4.35339850-02	8.11325320-01	1.64150270-01	4.22416770-00	1.42015320-00	5.75099110-01	
KAPPA(R)	5.21066450-02	2.54610000-02	8.14493370-01	1.44162430-01	4.67430660-00	1.26357190-00	4.73330440-01	2.55303700-01	

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 149.9995 CONTINUED				
DENSITY	3.0898840-06	3.8585600-07	4.5115030-08	4.7900260-09
KAPPA(P)	2.9413420-01	2.1195140-01	1.9750140-01	1.9550500-01
KAPPA(R)	2.0169570-01	1.9325060-01	1.92121360-01	1.91071500-01
THETA = 224.9990				
DENSITY	4.5677920+00	6.7629670-01	1.68920350-01	3.2506290-02
KAPPA(P)	5.9778120+02	5.9778120+02	1.7086250+02	5.3289802+01
KAPPA(R)	2.6459510+02	4.1971240+01	2.61854010+01	7.4669150+00
THETA = 299.9990				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 374.9993				
DENSITY	1.3588140+01	2.5335680+00	4.82847560-01	9.41847300-02
KAPPA(P)	1.0047702+03	3.5396580+02	8.28153960+01	1.84167310+01
KAPPA(R)	3.3345807+02	1.2043082+02	2.60776800+01	5.0492010+00
THETA = 449.9996				
DENSITY	1.7437640-05	2.3318930-06	2.74339360-07	2.91885720-08
KAPPA(P)	1.9431460-01	1.98708620-01	1.98558900-01	1.98542120-01
KAPPA(R)	1.9623940-01	1.95628850-01	1.95551980-01	1.95542600-01
THETA = 524.9999				
DENSITY	2.1297270+01	4.8403040+00	7.85335860-01	1.54322450-01
KAPPA(P)	3.4326730+02	1.55349110+02	3.28088720+01	6.76285400+00
KAPPA(R)	1.91102410+02	5.0601170+01	1.16596013+01	2.3292710+00
THETA = 600.0002				
DENSITY	2.9713740+05	3.8627540-06	4.5444520-07	4.82847560-08
KAPPA(P)	1.9949840-01	1.9952610-01	1.99477070-01	1.99471080-01
KAPPA(R)	1.9640520-01	1.96696560-01	1.96676700-01	1.96573400-01
THETA = 675.0005				
DENSITY	3.5156050+01	6.7900840+00	1.3345751+00	2.6400910-01
KAPPA(P)	2.3941330+02	5.7796024+01	1.25902283+01	2.54009750+00
KAPPA(R)	3.2537820+01	9.81964670+00	2.37229650+00	6.31351450-01
THETA = 750.0008				
DENSITY	5.8735040+05	6.5955850-06	7.75940330-07	8.24445550-08
KAPPA(P)	1.9600270-01	1.9641770-01	1.98596330-01	1.98593400-01
KAPPA(R)	1.9615420-01	1.9608050-01	1.96078140-01	1.96077350-01
THETA = 825.0011				
DENSITY	8.5115050+06	4.7900260-09	1.68920350-01	3.2506290-02
KAPPA(P)	2.9413420-01	2.1195140-01	1.9750140-01	1.9550500-01
KAPPA(R)	2.0169570-01	1.9325060-01	1.92121360-01	1.91071500-01
THETA = 900.0014				
DENSITY	4.5677920+00	6.7629670-01	1.68920350-01	3.2506290-02
KAPPA(P)	5.9778120+02	5.9778120+02	1.7086250+02	5.3289802+01
KAPPA(R)	2.6459510+02	4.1971240+01	2.61854010+01	7.4669150+00
THETA = 975.0017				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1050.0020				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1125.0023				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1200.0026				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1275.0029				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1350.0032				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1425.0035				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1500.0038				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1575.0041				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1650.0044				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1725.0047				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1800.0050				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1875.0053				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 1950.0056				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2025.0059				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2100.0062				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2175.0065				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2250.0068				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2325.0071				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2400.0074				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2475.0077				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2550.0080				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2625.0083				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2700.0086				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2775.0089				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2850.0092				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 2925.0095				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3000.0098				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3075.0101				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3150.0104				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3225.0107				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3300.0110				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3375.0113				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3450.0116				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3525.0119				
DENSITY	5.4165570+06	7.0395600-07	8.28147260-08	8.79906820-09
KAPPA(P)	2.3162230-01	4.0022810-01	1.96282570-01	1.9610110-01
KAPPA(R)	2.0129770-01	1.9543070-01	1.92437660-01	1.9204720-01
THETA = 3600.0122				
DENSITY				

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 1499.99430			13 DENSITIES		
DENSITY	0.33517760-01	1.2707572-01	2.43799670-00	0.0495180-01	9.7009250-02
KAPPA(P)	8.63906530-01	2.07007920-01	0.37708330-00	9.7389430-01	3.27502340-01
KAPPA(R)	6.00391160-00	1.76322513-00	5.43722960-01	2.7877780-01	1.99661070-01
DENSITY	9.32063350-05	1.21167713-05	1.42551137-06	1.51960650-07	1.02551162-08
KAPPA(P)	1.96402520-01	1.96325350-01	1.96318950-01	1.96313780-01	1.96313570-01
KAPPA(R)	1.94550790-01	1.94526080-01	1.94522780-01	1.94522390-01	1.94522390-01
THETA = 2249.99670			13 DENSITIES		
DENSITY	1.1297172-02	2.29031240-01	4.47393780-00	0.93999860-01	1.78210070-01
KAPPA(P)	3.2892160-01	7.22119990-00	1.64033795-00	0.9306900-01	2.34753090-01
KAPPA(R)	1.63065510-00	5.31793820-01	2.02502180-01	2.14460070-01	1.99172500-01
DENSITY	1.7231020-04	2.22599040-05	2.61883760-06	2.78208060-07	2.61883040-08
KAPPA(P)	1.93507650-01	1.93559170-01	1.9355500-01	1.93555110-01	1.93555110-01
KAPPA(R)	1.9280450-01	1.92877310-01	1.92876380-01	1.92876150-01	1.92876150-01
THETA = 3000.00050			13 DENSITIES		
DENSITY	2.0912240-02	4.17105030-01	0.30761010-00	1.65718203-00	3.31029760-01
KAPPA(P)	5.8602710-00	1.25960900-00	3.73009080-01	2.15155560-01	1.91752650-01
KAPPA(R)	4.39128450-01	2.56615350-01	2.09152420-01	1.95020500-01	1.02077170-01
DENSITY	3.18072400-04	4.13495113-05	4.06462990-06	5.16867153-07	8.86463130-08
KAPPA(P)	1.8002850-01	1.80026380-01	1.80026190-01	1.80026000-01	1.80026000-01
KAPPA(R)	1.90915100-01	1.90914030-01	1.90914030-01	1.90914030-01	1.90914030-01
THETA = 4999.99070			13 DENSITIES		
DENSITY	3.72295410-02	7.423373060-01	1.48116563-01	2.94510710-00	5.90330600-01
KAPPA(P)	4.65282570-00	6.50523100-01	2.62316630-01	1.98270490-01	1.8940260-01
KAPPA(R)	3.19424450-01	2.26158990-01	2.00602540-01	1.93400320-01	1.91408770-01
DENSITY	2.6723500-04	7.37406050-05	0.67539230-06	9.21760930-07	8.67539590-08
KAPPA(P)	1.87992720-01	1.87991780-01	1.87991600-01	1.87991600-01	1.87991600-01
KAPPA(R)	1.90914030-01	1.90914030-01	1.90914030-01	1.90914030-01	1.90914030-01
THETA = 6999.99090			13 DENSITIES		
DENSITY	6.16102020-02	1.23099950-02	2.466713240-01	0.095114050-00	9.77802490-01
KAPPA(P)	1.92826930-00	4.06735370-01	2.26741260-01	1.92455170-01	1.80678260-01
KAPPA(R)	2.64920070-01	2.11462750-01	1.96544770-01	1.92290120-01	1.91213820-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 6999.99090 CONTINUED	
DENSITY	9.3962600-04 1.2215140-04 1.4370680-05 1.4370680-07
KAPPA(P)	1.8797070-01 1.8797070-01 1.8797070-01 1.8797070-01
KAPPA(R)	1.9091030-01 1.9091030-01 1.9091030-01 1.9091030-01

7			DIAPH/SCAT BE (M/L/O)-2 10 FREQ. TEMP (1.-2250.)			CI/P 12-9-66			000000			MATERL 2 1000			NR 2 001		
WNEY ABSORPTION COEFFICIENTS			21 TEMPERATURES														
THETA = 1.0000			13 DENSITIES														
DENSITY	1.6240940-06	1.8036304-02	1.43322087-03	1.04590304-04	1.05555377-05	1.59352834-06	2.70920760-07	4.48943310-08									
KAPPA(P)	4.094813-0405	1.96005800-05	1.62260750-05	1.15344265-05	4.02234270-04	7.01108560-03	1.09431390-03	1.81421510-02									
KAPPA(R)	7.37150410-04	6.65913470-04	5.68544590-04	3.73508100-04	1.40367040-04	2.81765420-03	3.95105960-02	5.54581640-01									
DENSITY	0.5010630-09	6.59266800-10	5.80221630-11	5.71949900-12	5.3301300-13												
KAPPA(P)	3.5412444-0401	9.26267200-04	1.96335390-03	3.09774700-01	1.10755525-01												
KAPPA(R)	1.03314612-04	4.57662470-04	5.2636160-01	1.51621800-01	9.71952920-02												
THETA = 1.5000			13 DENSITIES														
DENSITY	0.67113150-06	4.50643070-02	3.2021560-04	7.54324400-05	1.32032063-05	2.354021130-06	3.30067620-07	4.54342130-08									
KAPPA(P)	4.6072410-0405	1.46721070-05	4.28219520-05	1.12955576-05	3.02723470-04	7.34763620-03	1.67729550-03	3.18977110-02									
KAPPA(R)	5.23075000-0405	1.46611600-05	1.39514450-05	4.63242050-04	1.18546193-04	2.92655370-03	6.54694650-02	1.10632280-02									
DENSITY	0.5059410-09	6.23707900-10	9.79024040-11	1.03996400-11	9.78769820-13												
KAPPA(P)	4.7497810-0401	5.63272110-04	7.53715670-01	1.57384250-01	9.61781590-02												
KAPPA(R)	1.4460445-04	1.73654379-04	2.43760130-01	1.15455659-01	9.30847420-02												
THETA = 4.2500			13 DENSITIES														
DENSITY	4.72233040-06	4.34444920-03	6.34491940-04	9.90146250-05	1.53086900-05	2.41271680-06	4.55837290-07	7.64091000-08									
KAPPA(P)	5.10061440-0405	3.50443110-05	2.88321050-05	1.43040040-05	3.30220230-04	5.01713280-03	6.82471630-02	9.93059990-01									
KAPPA(R)	2.7310540-0405	2.40057300-05	1.53877220-05	5.70292700-04	1.30326054-04	2.09435930-03	2.83593240-02	3.72340350-01									
DENSITY	1.1761440-06	1.52644816-05	1.79811090-10	1.91048310-11	1.79810130-12												
KAPPA(P)	1.5567400-0401	1.77925352-04	2.75373470-01	1.09321084-01	9.18435210-02												
KAPPA(R)	4.6243400-0401	6.66687610-01	1.79856490-01	1.06346142-01	9.07842010-02												
THETA = 5.4000			13 DENSITIES														
DENSITY	5.2756940-06	5.12410500-03	6.06719940-04	1.20587670-04	2.35319870-05	4.57499940-06	8.36323930-07	1.41992750-07									
KAPPA(P)	5.2421840-0405	4.83717320-05	1.50768290-05	4.75382764-04	8.05355540-03	1.24709100-03	1.49122690-02	2.89575210-01									
KAPPA(R)	4.1301130-0404	7.83115120-04	4.64174140-04	1.77113500-04	3.94608140-03	7.19008190-02	1.13392922-02	1.65623680-01									
DENSITY	4.1648660-09	2.63409700-09	3.34610050-10	3.54885430-11	3.34010120-12												
KAPPA(P)	4.5090240-0401	8.00859760-01	1.48787970-01	9.62226030-02	9.05679400-02												
KAPPA(R)	4.3799740-0401	4.61346470-01	1.36110660-01	9.42093950-02	8.09104140-02												
THETA = 5.0000			13 DENSITIES														
DENSITY	4.31768420-06	4.97711360-03	1.18344010-03	2.13992224-04	4.10430130-05	8.12414540-06	1.48996193-06	2.53178790-07									
KAPPA(P)	2.1491640-0405	1.17076305-05	4.53261720-04	1.41349606-04	2.15622860-03	3.57057540-02	5.73665250-01	9.13254840-08									
KAPPA(R)	4.4498840-0404	1.436651079-04	6.34793520-03	1.91390110-03	4.61327380-02	9.83646980-01	1.85077570-01	3.30475710-08									

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.0000 CONTINUED		
DENSITY	5.0630000-04	5.95636010-10
KAPPA(P)	4.80479520-01	9.21669200-02
KAPPA(R)	1.81897300-01	8.88211000-02
THETA = 7.0000 13 DENSITIES		
DENSITY	1.03565920-02	1.65421107-03
KAPPA(P)	4.10682210-04	1.41374597-04
KAPPA(R)	3.37227170-03	1.20182670-03
DENSITY	8.16466260-09	8.40221030-10
KAPPA(P)	2.07407880-01	1.49239140-01
KAPPA(R)	1.33511450-01	1.15301826-01
THETA = 10.0000 13 DENSITIES		
DENSITY	1.67567520-02	3.07122140-03
KAPPA(P)	1.91198620-04	5.26216020-03
KAPPA(R)	1.10019520-03	3.46615790-02
DENSITY	9.56638980-09	1.07735177-09
KAPPA(P)	4.08455450-01	1.99724570-01
KAPPA(R)	1.97777230-01	1.49767970-01
THETA = 15.0000 13 DENSITIES		
DENSITY	2.81416670-02	5.32831120-03
KAPPA(P)	1.28477750-04	4.84496300-03
KAPPA(R)	6.15763490-02	2.17720240-02
DENSITY	1.32820925-08	1.54939162-09
KAPPA(P)	5.74236240-01	2.27466360-01
KAPPA(R)	2.34558090-01	1.84176820-01
THETA = 22.0000 13 DENSITIES		
DENSITY	4.40194990-02	7.68294800-03
KAPPA(P)	2.56161940-04	8.79861990-03
KAPPA(R)	1.81610970-03	7.51418130-02
DENSITY	2.41679130-06	2.84307450-09
KAPPA(P)	3.02593300-01	1.93829920-01
KAPPA(R)	1.99703000-01	1.83684620-01

GRAY ABSORPTION COEFFICIENTS CONTINUED

THERMAL = 33.99998			13 DENSITIES		
DENSITY	3.7000760-01	6.4607870-02	1.11181390-02	1.95486630-03	3.67223030-04
KAPPA(P)	3.92590-70+04	2.34747330+04	7.30608850+03	1.67752330+03	3.59665480+02
KAPPA(R)	1.0814739+04	4.85446660+03	1.52531600+03	3.31105790+02	5.26564890+01
THERMAL = 50.00000			13 DENSITIES		
DENSITY	3.4531400-07	4.48900350-06	5.28118050-09	5.61113540-10	5.28118150-11
KAPPA(P)	4.6542410-01	2.12032550-01	1.84023220-01	1.82743620-01	1.82645890-01
KAPPA(R)	2.6357510-01	2.00632500-01	1.82391090-01	1.81497390-01	1.81498940-01
THERMAL = 64.99998			13 DENSITIES		
DENSITY	5.4523050-01	9.66093280-02	1.71916920-02	3.24079910-03	8.42943970-04
KAPPA(P)	2.8021220+04	1.16442730+04	3.09372180+03	6.09151490+02	1.13443617+02
KAPPA(R)	9.0411070+03	4.40216570+03	1.24931700+03	2.14003220+02	3.24034200+01
THERMAL = 69.99998			13 DENSITIES		
DENSITY	6.1580810-07	6.00543500-06	9.41812390-09	1.00047600-09	9.41812550-11
KAPPA(P)	2.5456650-01	1.92991910-01	1.80465780-01	1.67759780-01	1.67719200-01
KAPPA(R)	2.25456570-01	1.91088620-01	1.80409120-01	1.67946460-01	1.67927510-01
THERMAL = 90.99998			13 DENSITIES		
DENSITY	8.0234820-01	1.45313470-01	2.74452540-02	5.34674600-03	1.06265693-03
KAPPA(P)	1.36730630+04	4.82976390+03	1.00866373+03	1.93254110+02	3.85675390+01
KAPPA(R)	4.0748160+03	1.15784640+03	3.11356010+02	6.55501800+01	1.25957563+01
THERMAL = 99.99998			13 DENSITIES		
DENSITY	1.02067950-06	1.32810460-07	1.56011690-08	1.65742531-09	1.56011720-10
KAPPA(P)	2.06364570-01	1.93779760-01	1.92449790-01	1.99316660-01	1.92303200-01
KAPPA(R)	1.9906470-01	1.93140370-01	1.92521010-01	1.92521010-01	1.92518390-01
THERMAL = 109.99998			13 DENSITIES		
DENSITY	1.24680751+00	2.38987020-01	4.63091830-02	9.10273060-03	1.81332163-03
KAPPA(P)	5.36213470+03	1.73131400+03	3.62038980+02	7.19491010+01	1.45608501+01
KAPPA(R)	5.45480450+02	2.15595260+02	5.42048460+01	1.19803306+01	2.33029930+00
THERMAL = 129.99998			13 DENSITIES		
DENSITY	1.74175434+06	2.26427750-07	2.66347250-08	2.83036570-09	2.6634620-10
KAPPA(P)	1.99549130-01	1.94448290-01	1.94072200-01	1.94122670-01	1.94115370-01
KAPPA(R)	1.95904600-01	1.94143340-01	1.93930770-01	1.93985800-01	1.93982370-01
THERMAL = 149.99998			13 DENSITIES		
DENSITY	2.21080700+00	4.31883670-01	8.46507780-02	1.67034800-02	3.33044290-03
KAPPA(P)	2.30182560+03	5.46666120+02	1.20749917+02	2.52291220+01	5.10877870+00
KAPPA(R)	1.45500000+02	3.98676400+01	9.16031000+00	2.07507160+00	5.74954400-01

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 149.99495 CONTINUED

DENSITY 3.19980740-00 4.15473300-07 4.40360900-04 5.19967420-09 4.69360990-10
 KAPPA(P) 1.92469430-01 1.93623630-01 1.93623630-01 1.93623630-01 1.93623630-01
 KAPPA(R) 1.94191400-01 1.93582790-01 1.93582790-01 1.93582790-01 1.93582790-01

THETA = 224.99490 13 DENSITIES

DENSITY 3.98863070-00 7.87060850-01 1.55211740-01 3.06712050-02 6.11780460-03 1.22288312-03 2.24768660-04 3.02097470-05
 KAPPA(P) 2.86243000-02 6.94267320-01 2.27787700-01 4.90883660-00 1.08919459-00 2.76458100-01 1.98194170-01 1.88779890-01
 KAPPA(R) 1.42557678-01 3.44444420-00 8.02561500-01 3.51691110-01 2.32752870-01 2.02006100-01 1.93464160-01 1.91321500-01

DENSITY 7.64197170-07 8.99052080-08 9.55243470-09 9.99052230-10 1.08919459-00 2.76458100-01 1.98194170-01 1.88779890-01
 KAPPA(P) 1.87717230-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01
 KAPPA(R) 1.90393400-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01

THETA = 340.00412 13 DENSITIES

DENSITY 7.34373400-00 1.45713837-00 2.44841990-01 5.49990320-02 1.13636116-02 2.27156100-03 4.17322260-04 7.09774820-05
 KAPPA(P) 1.38032740-02 3.18701230-01 6.59424730-00 1.52589554-00 4.12771340-01 2.19518450-01 1.91319010-01 1.88779890-01
 KAPPA(R) 6.82491600-00 1.63369901-00 5.06966500-01 2.67813850-01 2.11909700-01 1.96452220-01 1.92852790-01 1.91823890-01

DENSITY 1.04146448-05 1.11753360-06 1.67005330-07 1.77432700-08 1.67005330-09 2.76458100-01 1.98194170-01 1.88779890-01
 KAPPA(P) 1.87717230-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01
 KAPPA(R) 1.90393400-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01

THETA = 499.99493 13 DENSITIES

DENSITY 1.30368400-01 2.54093030-00 5.09166910-01 1.01544423-01 2.02644960-02 4.05045700-03 7.44567440-04 1.28977410-05
 KAPPA(P) 6.80065200-01 1.57279430-01 3.35722920-00 7.66510100-01 2.77483450-01 1.99597800-01 1.89344670-01 1.87779890-01
 KAPPA(R) 3.37094200-00 8.69034470-01 3.51289670-01 2.32000090-01 2.02644960-02 1.93722410-01 1.91390810-01 1.90012800-01

DENSITY 1.94734440-05 2.53158720-06 2.97847810-07 3.16442330-08 2.97847810-09 4.05045700-03 7.44567440-04 1.28977410-05
 KAPPA(P) 1.87779890-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01
 KAPPA(R) 1.90393400-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01

THETA = 699.99476 13 DENSITIES

DENSITY 2.12500000-01 4.21452660-00 8.43236000-01 1.64230200-01 3.35670600-02 6.71041100-03 1.23341870-04 2.09676880-05
 KAPPA(P) 3.62349450-01 8.21701480-00 1.76334400-00 4.37992540-01 2.26712410-01 1.92713820-01 1.88779890-01 1.87779890-01
 KAPPA(R) 1.84185473-00 5.59447940-01 2.80736360-01 2.18840320-01 1.97247100-01 1.92402490-01 1.91180890-01 1.90072400-01

DENSITY 2.24378448-05 1.19352020-06 4.93353490-07 5.26180310-08 4.93353490-09 6.71041100-03 1.23341870-04 2.09676880-05
 KAPPA(P) 1.87779890-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01 1.87564660-01
 KAPPA(R) 1.90393400-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01 1.90834450-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 99.997		13 DENSITIES									
DENSITY	3.6742000-01	7.20154070-00	1.43954989+00	2.87234020-01	5.73154260-02	1.14577940-02	2.10601020-03	3.94013450-04			
KAPPA(P)	1.84468150+01	4.12048550+00	9.20145120-01	3.04287280-01	2.03449940-01	1.09709180-01	1.07059470-01	1.07614070-01			
KAPPA(R)	1.01150710+00	3.84103420-01	2.40148770-01	2.04222950-01	1.94330570-01	1.91426710-01	1.90942220-01	1.90000370-01			
THETA = 99.997		13 DENSITIES									
DENSITY	5.50791140-05	7.13029090-06	8.42343940-07	8.95033440-08	8.42304200-09						
KAPPA(P)	1.87572400-01	1.87565710-01	1.87564960-01	1.87564780-01	1.87564780-01						
KAPPA(R)	1.90428550-01	1.90425280-01	1.90424900-01	1.90424710-01	1.90424710-01						
THETA = 99.997		13 DENSITIES									
DENSITY	6.74335000+01	1.32259920+01	2.64433600+00	5.27644080-01	1.05294722-01	2.10492780-02	3.04098950-03	6.97716220-04			
KAPPA(P)	8.44721150+00	1.89481307+00	4.82946640-01	2.30819100-01	1.97262670-01	1.88402620-01	1.87495330-01	1.87567280-01			
KAPPA(R)	5.71081670-01	2.86760180-01	2.16365110-01	1.97725210-01	1.92514840-01	1.91189910-01	1.90804350-01	1.900395700-01			
THETA = 99.997		13 DENSITIES									
DENSITY	1.01186623-04	1.31543324-05	1.54756163-06	1.64428520-07	1.54754200-08						
KAPPA(P)	1.87569548-01	1.87565340-01	1.87564960-01	1.87564960-01	1.87564960-01						
KAPPA(R)	1.90426610-01	1.90425280-01	1.90425090-01	1.90425090-01	1.90425090-01						
THETA = 99.997		13 DENSITIES									
DENSITY	1.23216166+02	2.42931390+01	4.85723430+00	9.49357130-01	1.93437540-01	3.84499290-02	7.19778340-03	1.20030280-03			
KAPPA(P)	3.84492370+00	9.04814710-01	3.01605920-01	2.03091430-01	1.89671620-01	1.87802038-01	1.87623070-01	1.87579370-01			
KAPPA(R)	3.74161780-01	2.39642640-01	2.04030860-01	1.94256070-01	1.91614440-01	1.90956410-01	1.90853150-01	1.90030280-01			
THETA = 99.997		13 DENSITIES									
DENSITY	1.85092130-04	2.41658530-05	2.84305920-06	3.02075170-07	2.84305970-08						
KAPPA(P)	1.87567200-01	1.87565990-01	1.87565710-01	1.87565710-01	1.87565710-01						
KAPPA(R)	1.90426610-01	1.90425480-01	1.90425480-01	1.90425480-01	1.90425480-01						

1060000	C-4A.14	FREQ. TEMP.	1.12925-101.2-3-66	REMADE 3-28-67, & DENSITIES DELETED	MATERL = 1006	NX = 700
KEY ABSORPTION COEFFICIENTS						
21 TEMPERATURES						
12 DENSITIES						
THETA = .12x25						
DENSITY	2.63360e90-01	0.77757520-02	2.63277960-02	0.77410940-03	2.63145070-03	0.76845290-04
KAPPA(P)	1.59510e60+05	1.59547970+05	1.59563930+05	1.59579930+05	1.59595850+05	1.59611010+05
KAPPA(R)	5.22080e30+02	5.22131750+02	5.22173520+02	5.22241410+02	5.22293630+02	5.22377200+02
DENSITY	4.62504e30-03	0.74349990-06	2.61930910-06	0.71543590-07		
KAPPA(P)	1.59627770+05	1.59627770+05	1.59627770+05	1.59643720+05		
KAPPA(R)	5.22628000+02	5.22638940+02	5.23412540+02	5.24276900+02		
THETA = .17x34						
12 DENSITIES						
DENSITY	1.96974e60-01	0.55396490-02	1.96260010-02	6.52770430-03	1.95207949-03	6.48116580-04
KAPPA(P)	1.29430001+05	1.29430571+05	1.29530158+05	1.29598952+05	1.29702066+05	1.29715633+05
KAPPA(R)	1.27101e60+03	1.27301060+03	1.27474310+03	1.27679710+03	1.28058200+03	1.28639620+03
DENSITY	1.89292e20-05	0.19604160-06	1.79986310-06	5.71100860-07		
KAPPA(P)	1.29409412+05	1.29055766+05	1.28001843+05	1.24881960+05		
KAPPA(R)	1.32099420+03	1.32740330+03	1.32440820+03	1.30637310+03		
THETA = .21x42						
12 DENSITIES						
DENSITY	4.555461e0-01	5.15362420-02	1.53173369-02	5.04292020-03	1.48197445-03	4.79522380-04
KAPPA(P)	8.590480e0+04	8.90897800+04	9.32324400+04	8.92681460+04	8.86720460+04	8.73431540+04
KAPPA(R)	2.27691420+03	2.28360350+03	2.30376480+03	2.33001490+03	2.36444820+03	2.38928620+03
DENSITY	1.08374e17-05	2.94942600-06	6.89292650-07	1.95756300-07		
KAPPA(P)	7.6991740+04	8.47312880+04	4.19108470+04	2.2372720+04		
KAPPA(R)	4.15994420+03	1.81739590+03	1.20659780+03	6.74951670+02		
THETA = .25x51						
12 DENSITIES						
DENSITY	1.25255450-01	4.08209440-02	1.17802608-02	3.70830660-03	1.00331072-03	2.87723680-04
KAPPA(P)	6.12443e60+04	6.13464030+04	6.11631370+04	6.04093950+04	5.81976320+04	5.35461800+04
KAPPA(R)	3.70052470+03	3.75202120+03	3.81143090+03	3.84782050+03	3.76769980+03	3.55123660+03
DENSITY	4.76506e40-06	1.44425149-06	4.23589930-07	1.33909720-07		
KAPPA(P)	1.67923700+04	1.08578105+04	8.36607380+03	8.06637850+03		
KAPPA(R)	1.14143440+03	7.93378160+02	6.19182440+02	5.97407810+02		
THETA = .30x60						
12 DENSITIES						
DENSITY	9.89718e30-02	3.07913950-02	0.17618180-03	2.29817490-03	5.42300660-04	1.48434820-04
KAPPA(P)	4.60786170+04	4.57204040+04	4.41787850+04	4.06396490+04	2.82434050+04	1.72792200+04
KAPPA(R)	5.76000470+03	5.82619760+03	5.75451470+03	5.37191580+03	4.39134080+03	3.18020160+03
						2.19395750+03
						1.77719280+03
						1.48005900+04
						1.28200443-05
						3.09707200-05
						6.85032080-05
						1.843636478-05
						2.93838380+04
						2.00650500+03

GRAY ABSORPTION COEFFICIENTS CONTINUED

.30160 CONTINUED		
THETA =		
DENSITY	3.30458-10-06	4.7746270-07
KAPPA(P)	1.36850-03-04	1.8169602-04
KAPPA(R)	1.67998-06-03	1.7749530-03
THETA =		
DENSITY	7.37156-10-04	2.10309520-02
KAPPA(P)	4.06392-10-04	3.9374720-04
KAPPA(R)	6.35077-10-03	6.14231150-03
DENSITY	1.76616-10-06	4.58686020-07
KAPPA(P)	1.63321-09-04	1.23795349-04
KAPPA(R)	3.64444-00-03	2.56714570-03
THETA =		
DENSITY	3.10979-06-02	1.35658389-02
KAPPA(P)	4.80949-02-04	4.10686320-04
KAPPA(R)	1.06162-07-04	9.92071150-03
DENSITY	1.06248-05-06	3.34684400-07
KAPPA(P)	7.32047-03-03	2.75212460-02
KAPPA(R)	1.80755-04-03	7.03283-10-02
THETA =		
DENSITY	3.47435-06-02	4.31434130-03
KAPPA(P)	5.46442-06-04	5.64733070-04
KAPPA(R)	1.14442-08-04	1.08929376-04
DENSITY	6.92981-00-07	2.94379360-07
KAPPA(P)	2.10365150-03	7.19078090-02
KAPPA(R)	3.11777-90-02	1.78124350-02
THETA =		
DENSITY	2.87715-07-02	1.66429452-03
KAPPA(P)	7.06357930-04	6.12427000-04
KAPPA(R)	1.07873-06-04	1.04624705-04
DENSITY	2.64497-07-07	7.98672620-08
KAPPA(P)	2.55685-00-02	7.69557010-01
KAPPA(R)	8.23011-030-01	2.01466890-01

THETA = .30160 CONTINUED

DENSITY 3.30458-10-06 4.7746270-07 2.35960850-07 5.96960880-08
KAPPA(P) 1.36850-03-04 1.8169602-04 1.77576956-04 1.25532238-04
KAPPA(R) 1.67998-06-03 1.7749530-03 1.90038160-03 1.70516980-03

THETA = .30448 12 DENSITIES

DENSITY 7.37156-10-04 2.10309520-02 5.0273770-03 1.34367041-03 3.40328240-04 1.0180005-04 2.69615190-05 7.03475300-06
KAPPA(P) 4.06392-10-04 3.9374720-04 3.5396420-04 2.97385660-04 2.43893040-04 2.19111280-04 2.10429300-04 2.06493000-04
KAPPA(R) 6.35077-10-03 6.14231150-03 7.33747000-03 5.93682490-03 5.53700400-03 3.89558810-03 3.75269460-03 3.03689300-03DENSITY 1.76616-10-06 4.58686020-07 1.17950597-07 3.74522160-08
KAPPA(P) 1.63321-09-04 1.23795349-04 5.26249200-03 1.93807390-03
KAPPA(R) 3.64444-00-03 2.56714570-03 1.11018060-03 8.07872430-02

THETA = .38776 12 DENSITIES

DENSITY 3.10979-06-02 1.35658389-02 3.23841920-03 9.26774760-04 2.39621490-04 6.74603890-05 1.57715950-05 8.14939450-06
KAPPA(P) 4.80949-02-04 4.10686320-04 3.63700120-04 3.31235570-04 3.12195550-04 2.96139230-04 2.32050570-04 1.67932110-04
KAPPA(R) 1.06162-07-04 9.92071150-03 8.42295780-03 7.31827400-03 6.83950040-03 6.72179150-03 6.08533400-03 4.25623350-03DENSITY 1.06248-05-06 3.34684400-07 9.84319950-04 3.26213170-08
KAPPA(P) 7.32047-03-03 2.75212460-02 8.61185520-02 2.90496400-02
KAPPA(R) 1.80755-04-03 7.03283-10-02 2.17468130-02 7.33578800-01

THETA = .43005 12 DENSITIES

DENSITY 3.47435-06-02 4.31434130-03 2.31765360-03 6.54741590-04 1.57173500-04 9.14550870-05 1.01544353-05 3.08919330-06
KAPPA(P) 5.46442-06-04 5.64733070-04 4.61779480-04 4.41655320-04 3.93047280-04 2.97177560-04 1.55142237-04 8.44003910-05
KAPPA(R) 1.14442-08-04 1.08929376-04 1.01475733-04 9.76617280-03 9.03995890-03 7.07866000-03 3.76046000-03 1.36077840-03DENSITY 6.92981-00-07 2.94379360-07 8.79673600-08 2.92076510-04
KAPPA(P) 2.10365150-03 7.19078090-02 2.17602490-02 7.27835300-01
KAPPA(R) 3.11777-90-02 1.78124350-02 5.59260320-01 1.93826820-01

THETA = .47493 11 DENSITIES

DENSITY 2.87715-07-02 1.66429452-03 4.47568930-04 1.05842479-04 3.01025700-05 8.32373120-06 2.69988880-06 8.01805550-07
KAPPA(P) 7.06357930-04 6.12427000-04 5.31673600-04 3.62393160-04 1.87704640-04 1.07704380-03 2.47598180-03 7.81107670-02
KAPPA(R) 1.07873-06-04 1.04624705-04 9.33550330-03 6.47620510-03 3.38791500-03 1.28848320-03 9.86195090-02 1.66769660-02DENSITY 2.64497-07-07 7.98672620-08 2.66147600-08
KAPPA(P) 2.55685-00-02 7.69557010-01 2.57336420-01
KAPPA(R) 8.23011-030-01 2.01466890-01 7.48011390-00

ONLY ASSUMPTION COEFFICIENTS CONTINUED									
TMETA = .5102		12 DENSITIES		10 DENSITIES		11 DENSITIES		12 DENSITIES	
DENSITY	1.045800-50-02	5.04105466-03	1.19862524-03	3.23177161-04	8.22662270-05	2.54052330-05	7.41201740-06	2.44613859-06	
KAPPA(P)	9.05310150-04	0.39339370-04	7.11111860-04	4.94062150-04	2.43990610-04	9.90336560-03	3.21139240-03	1.09421220-03	
KAPPA(R)	0.87307420-03	0.43105600-03	7.75916490-03	5.56120430-03	2.403398730-03	1.25986510-03	4.99610200-02	2.11325580-02	
DENSITY	7.30307400-07	2.42588320-07	7.233998480-08	2.30355750-08					
KAPPA(P)	3.29367430-02	1.09815311-02	3.29064920-01	1.11086052-01					
KAPPA(R)	7.65404400-01	2.81190690-01	9.09222800-00	3.15037020-00					
TMETA = .56010		10 DENSITIES		11 DENSITIES		12 DENSITIES		10 DENSITIES	
DENSITY	9.08977700-04	2.59119420-04	7.09051450-05	2.24079510-05	6.77277310-06	2.24478600-06	6.69050050-07	2.21779550-07	
KAPPA(P)	0.80501490-04	3.722336620-04	1.44529946-04	5.25033900-03	1.62537751-03	5.45634850-02	1.44002220-02	5.53457370-01	
KAPPA(R)	4.50030450-03	4.66093240-03	1.27566120-03	6.35092060-02	2.86692420-02	1.19952993-02	4.22422100-01	1.59419550-01	
DENSITY	6.58912000-08	2.14659090-08							
KAPPA(P)	1.77514590-01	7.22220270-00							
KAPPA(R)	3.13751750-00	1.99465221-00							
TMETA = .60319		11 DENSITIES		12 DENSITIES		10 DENSITIES		11 DENSITIES	
DENSITY	1.09952423-02	7.444553620-04	2.24310360-04	6.40901470-05	2.10039500-05	6.24760230-06	2.06950730-06	6.14903060-07	
KAPPA(P)	1.26500174-05	5.50006330-04	2.48173890-04	0.50883190-03	2.95197570-03	8.97568960-02	3.02031090-02	9.43272410-01	
KAPPA(R)	4.67437430-03	2.55834100-03	1.51319710-03	8.32997170-02	4.54732780-02	1.89697360-02	7.79626560-01	2.75919040-01	
DENSITY	2.01979430-07	5.69368200-08	1.98208620-08						
KAPPA(P)	3.57146400-01	1.56363750-01	9.48996420-03						
KAPPA(R)	1.07251414-01	4.22306000-00	2.11567510-00						
TMETA = .86400		12 DENSITIES		10 DENSITIES		11 DENSITIES		12 DENSITIES	
DENSITY	1.40017171-01	4.47985180-00	1.64719070-00	2.94890880-01	3.73411260-02	5.10676070-03	5.37436460-04	6.49516410-05	
KAPPA(P)	6.63603520-03	6.59904350-03	6.58604380-03	6.02853900-03	5.70836740-03	5.22113430-03	3.52434520-03	2.25984000-03	
KAPPA(R)	2.58338490-02	2.52370920-02	2.52307040-02	2.51947310-02	2.50137300-02	2.44160030-02	2.26166160-02	1.94436640-02	
DENSITY	7.03579450-06	1.60993800-07	1.03725008-08	9.74891960-10					
KAPPA(P)	1.43364750-03	4.71297710-02	5.94318320-01	5.72418390-00					
KAPPA(R)	1.53377150-02	5.46004530-01	7.30240080-00	7.50606970-01					
TMETA = 1.10000		12 DENSITIES		10 DENSITIES		11 DENSITIES		12 DENSITIES	
DENSITY	1.77578447-00	5.24595390-01	1.96655610-01	3.14473670-02	3.04691320-03	5.45422410-04	6.40859160-05	1.07425300-05	
KAPPA(P)	3.95097000-04	3.00104200-04	2.97054490-04	2.74422280-04	2.54379370-04	2.20475690-04	1.44536200-04	7.97253730-03	
KAPPA(R)	1.46270670-03	1.75669960-03	1.75441360-03	1.75559550-03	1.67058830-03	1.51339300-03	1.16015360-03	7.52017600-02	

GREY ABSORPTION COEFFICIENTS

CONTINUED									
1.1000		1.2000		1.3000		1.4000		1.5000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	1.9746050-05	1.46140120-07	1.40717034-08	1.34677496-09	2.29662650-02	7.20391980-03	9.43931040-04	1.65296450-04	2.94909170-05
KAPPA(P)	2.0005070-03	3.00500590-02	2.69987340-01	2.6140910-00	7.25440150-04	6.87366050-04	5.82409250-04	4.93000600-04	1.77500720-04
KAPPA(R)	3.33742-70-02	3.7571210-01	3.50825930-00	3.94960400-01	7.4427440-03	7.04927440-03	6.03089740-03	4.24119340-03	2.00206570-03
1.3000		1.4000		1.5000		1.6000		1.7000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	4.4501440-01	1.23444819-01	4.29662650-02	7.20391980-03	1.90347430-04	1.55002949-09	1.36049750-04	2.04716990-05	7.74703450-06
KAPPA(P)	7.67032560-04	7.35580200-04	7.25440150-04	6.87366050-04	1.53537537-01	2.83854040-00	4.95463040-04	1.63795472-04	6.15510420-03
KAPPA(R)	8.37335-30-03	7.55450930-03	7.4427440-03	7.04927440-03	3.11964740-00	7.53077180-01	0.36607380-03	5.13405970-03	8.15053760-02
1.5000		1.6000		1.7000		1.8000		1.9000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	2.07967-70-06	1.97367160-07	1.90347430-04	1.55002949-09	1.97147260-00	1.34273002-09	1.62224130-04	4.02421030-05	1.23210676-03
KAPPA(P)	1.71433-00-03	1.50310020-02	1.53537537-01	2.83854040-00	1.71731940-01	3.95760070-00	2.21909400-04	8.29153140-03	3.47350450-03
KAPPA(R)	2.40879780-02	2.29307770-01	3.11964740-00	7.53077180-01	4.73087600-00	1.17131492-00	7.66730070-03	3.08362130-03	1.37621100-03
1.5000		1.6000		1.7000		1.8000		1.9000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	3.00201-10-01	6.23999880-02	2.44974690-02	4.07351420-03	1.97147260-00	1.34273002-09	1.62224130-04	4.02421030-05	1.23210676-03
KAPPA(P)	9.49255-10-04	5.41175630-04	9.14634931-04	8.17056310-04	1.71731940-01	3.95760070-00	2.21909400-04	8.29153140-03	3.47350450-03
KAPPA(R)	1.36920-00-04	1.20841501-04	1.17721277-04	1.07438625-04	4.73087600-00	1.17131492-00	7.66730070-03	3.08362130-03	1.37621100-03
1.5000		1.6000		1.7000		1.8000		1.9000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	2.24609-00-06	2.20515040-07	1.97147260-00	1.34273002-09	1.97147260-00	1.34273002-09	1.62224130-04	4.02421030-05	1.23210676-03
KAPPA(P)	1.37913-50-03	1.26775774-02	1.71731940-01	3.95760070-00	1.71731940-01	3.95760070-00	2.21909400-04	8.29153140-03	3.47350450-03
KAPPA(R)	2.25545-60-02	2.44440600-01	4.73087600-00	1.17131492-00	4.73087600-00	1.17131492-00	7.66730070-03	3.08362130-03	1.37621100-03
2.0000		2.1000		2.2000		2.3000		2.4000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	9.76039420-02	2.70743090-02	1.00996959-02	2.24286770-03	1.00996959-02	2.24286770-03	1.62224130-04	4.02421030-05	1.23210676-03
KAPPA(P)	1.67527-10-05	1.42343710-05	1.24119404-05	0.64293460-04	1.24119404-05	0.64293460-04	2.21909400-04	8.29153140-03	3.47350450-03
KAPPA(R)	7.14247-60-04	5.69369610-04	4.48944640-04	3.28026350-04	4.48944640-04	3.28026350-04	7.66730070-03	3.08362130-03	1.37621100-03
2.0000		2.1000		2.2000		2.3000		2.4000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	3.14201-00-04	2.27367110-07	2.06572400-00	1.96671770-09	2.06572400-00	1.96671770-09	1.62224130-04	4.02421030-05	1.23210676-03
KAPPA(P)	1.45316-10-03	2.21205050-02	2.22393550-01	2.47639520-00	2.22393550-01	2.47639520-00	2.21909400-04	8.29153140-03	3.47350450-03
KAPPA(R)	5.39764-70-02	5.74267360-01	5.47531600-00	7.70752430-01	5.47531600-00	7.70752430-01	7.66730070-03	3.08362130-03	1.37621100-03
2.4000		2.5000		2.6000		2.7000		2.8000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	4.25291540-04	2.44433300-02	1.31586472-02	2.66425610-03	1.31586472-02	2.66425610-03	1.62224130-04	4.02421030-05	1.23210676-03
KAPPA(P)	1.59204-00-03	1.33572940-05	1.16378120-05	9.41175630-04	1.16378120-05	9.41175630-04	2.21909400-04	8.29153140-03	3.47350450-03
KAPPA(R)	1.17113636-05	9.52633020-04	7.70146230-04	4.72732500-04	7.70146230-04	4.72732500-04	7.66730070-03	3.08362130-03	1.37621100-03
2.4000		2.5000		2.6000		2.7000		2.8000	
DENSITY		DENSITY		DENSITY		DENSITY		DENSITY	
KAPPA(P)	3.74279400-06	3.06392160-07	2.60382340-08	2.39903350-09	2.60382340-08	2.39903350-09	1.62224130-04	4.02421030-05	1.23210676-03
KAPPA(P)	1.36825-50-03	1.07395250-02	2.27300980-01	2.69828250-00	1.07395250-02	2.27300980-01	2.21909400-04	8.29153140-03	3.47350450-03
KAPPA(R)	3.85254-70-02	6.05621390-01	6.92261210-00	8.9497370-01	6.92261210-00	8.9497370-01	7.66730070-03	3.08362130-03	1.37621100-03

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.00001		12 DENSITIES									
DENSITY	0.75303450-02	2.75404340-02	1.17109931-02	3.11130280-03	7.62719680-04	2.19857720-04	5.71392150-05	1.69270110-05			
KAPPA(P)	1.07140650-05	1.31334130-05	1.23632001-05	1.60117518-05	6.67680250-04	3.51710010-04	1.20000015-04	8.50020260-03			
KAPPA(R)	1.09309.34+05	9.40422970-04	7.76000000-04	8.63599913-04	2.49103670-04	1.30051399-04	6.70062220-03	1.65540330-03			
THETA = 5.00000		12 DENSITIES									
DENSITY	4.62377090-06	3.95505970-07	3.49006690-08	3.40672430-09							
KAPPA(P)	1.34062440-03	1.45637400-02	1.67157260-01	1.74040815-00							
KAPPA(R)	4.8622700-02	5.4259602-01	5.20167130-00	6.01424060-01							
THETA = 7.00000		12 DENSITIES									
DENSITY	3.23456400-02	3.25561170-02	1.41194790-02	3.83042310-03	9.47073080-04	2.74047260-04	7.27115770-05	2.19751140-05			
KAPPA(P)	1.24051090-05	1.04423480-05	1.00669677-05	9.37231000-04	5.90809900-04	2.72579350-04	9.16016950-03	2.99032740-03			
KAPPA(R)	7.63970910-04	7.11105750-04	6.37950520-04	5.21719310-04	2.89261100-04	1.25505515-04	8.09339490-03	1.43049100-03			
THETA = 10.00005		12 DENSITIES									
DENSITY	6.05213430-06	5.68025250-07	5.63096460-08	5.02637980-09							
KAPPA(P)	6.32314460-02	7.7764830+01	6.62432870+00	7.27326350-01							
KAPPA(R)	3.88168470-02	4.47518430+01	2.00541090+00	3.33600200-01							
THETA = 10.00005		12 DENSITIES									
DENSITY	1.21023742-01	9.09169850-02	1.40640700-02	5.03075730-03	1.27932003-03	3.77730110-04	1.03300175-04	3.29034030-03			
KAPPA(P)	8.63271530-04	7.87446135-04	7.40329010-04	6.10207260-04	3.27200460-04	1.27474935-04	3.31050130-03	1.02473500-03			
KAPPA(R)	3.61560240-04	3.54026790-04	3.37251790-04	2.71000070-04	1.63504520-04	7.42203570-03	2.10932610-03	5.65000000-02			
THETA = 10.00005		12 DENSITIES									
DENSITY	9.70082410-06	9.41508540-07	9.60609360-06	9.60576960-09							
KAPPA(P)	2.71041710-02	2.35472720-01	2.30112000-00	3.42630200-01							
KAPPA(R)	1.30406650-02	9.37859510+00	9.98402870-01	2.56922710-01							

SN	WAVE/SCAT C-1A	TEMP(11-2250 EV)	11-7-67	SADY INPUT TAPES(1363-1150)	MATERL = 3006	MX = 001
GREY ABSORPTION COEFFICIENTS						
21 TEMPERATURES						
13 DENSITIES						
THETA =	1.0000					
DENSITY	0.6551000000	0.02441910-01	2.08954030-02	1.43568764-03	0.54257240-05	5.25080120-06
KAPPA(P)	1.0408201000	1.7949076000	1.5993519700	1.4587116000	0.9707800000	3.7217746000
KAPPA(R)	9.0395302000	6.6671044000	8.5794323000	6.1398280000	6.6000739000	3.9525652000
DENSITY	9.3534101000	1.2067562700	1.4137010000	1.4386715000	1.1105250700	1.2071131000
KAPPA(P)	2.8629200000	3.5025930000	4.3370739000	0.3624991000	5.2452907000	1.0552616000
KAPPA(R)	3.5750403000	6.7892129000	9.3113083000	4.5041724000	4.5783707000	1.2071131000
THETA =	1.5000					
DENSITY	0.9555007000	2.60663100-02	2.1074007100	1.7492650000	2.1683262000	3.7106262000
KAPPA(P)	1.0019200000	9.2397013000	7.4134773000	4.4650502000	1.3192238000	3.0555178000
KAPPA(R)	1.3803001700	1.1662792500	9.9190302000	5.6978693000	1.7486360000	3.6579825000
DENSITY	1.4624175400	1.3823090600	1.3518999000	1.3901200000	1.3021558300	1.3021558300
KAPPA(P)	1.4495807400	3.9830943000	6.9572612000	1.3703991000	7.4270530000	1.4495807400
KAPPA(R)	4.0644909000	1.1712464000	2.4403290000	0.9160360000	6.8853240000	1.4495807400
THETA =	2.2500					
DENSITY	0.7086500000	4.6710146000	1.1540237100	1.7719313000	3.1497463000	5.3044639000
KAPPA(P)	1.8010500000	1.2200440300	6.7017005000	2.5414240000	6.9119140000	2.0237064000
KAPPA(R)	0.9133000000	5.0400150000	2.4707076000	0.8878379000	2.0027800000	7.7310000000
DENSITY	1.4704000000	1.4704000000	1.4704000000	1.7494000000	1.5991074000	1.5991074000
KAPPA(P)	1.7140000000	2.4747414000	2.0241575000	1.5477831000	1.0777400000	1.0777400000
KAPPA(R)	4.2636752000	7.6574050000	2.3431170000	1.2131024000	1.0299117100	1.0299117100
THETA =	3.0000					
DENSITY	0.7638900000	9.5447407000	1.4497240700	2.2033774000	3.4032777000	6.0036447000
KAPPA(P)	1.8501700000	1.2376720000	6.7416792000	4.2132721000	1.0078095000	2.1635614000
KAPPA(R)	1.3042300000	6.2442798000	3.4666101000	9.9446060000	2.3211474000	5.6323333000
DENSITY	1.9690000000	2.3809414000	2.0314092000	2.3937616000	2.2263044000	2.2263044000
KAPPA(P)	1.7016000000	2.6759790000	5.2918193000	1.8325200000	1.3976567000	1.3976567000
KAPPA(R)	5.2679045000	8.7180453000	2.4509142000	1.5319724000	1.3531593000	1.3531593000
THETA =	5.0000					
DENSITY	6.9454500000	1.0948574900	1.4602069800	2.6779010000	4.4166676000	7.5785400000
KAPPA(P)	1.9496700000	1.3924775000	9.5369132000	4.0700675000	1.0633324000	2.1945800000
KAPPA(R)	1.3077310000	6.6364429000	3.8175524000	1.4445094300	3.9213643000	7.6022413000

ONLY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.00000 CONTINUED					
DENSITY	2.6515900-09	3.30115000-09	3.96680530-10	4.21330180-11	3.96533850-12
KAPPA(P)	1.30163-30-01	1.70109151-00	3.20717690-01	1.54929210-01	1.37168660-01
KAPPA(R)	3.9726130-00	6.01428690-01	1.98381360-01	1.42524980-01	1.34674160-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.58527810-03
KAPPA(R)	9.15913500-04	7.93782690-04	4.65918050-04	1.44260740-04	3.38745740-03
DENSITY	4.29413360-08	5.58343600-09	6.56866770-10	6.97907250-11	6.56853720-12
KAPPA(P)	5.10202700-00	7.33444750-01	2.03572100-01	1.42497200-01	1.35860990-01
KAPPA(R)	1.55206430-00	3.33644920-01	1.67794880-01	1.40659100-01	1.33804030-01
13 DENSITIES					
DENSITY	7.86757070-02	1.27176056-02	2.03996220-03	3.31046070-04	5.63290530-05
KAPPA(P)	1.83100000-05	1.35000030-05	9.12903080-04	3.21882400-04	7.

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 33.99450			13 DENSITIES		
DENSITY	3.5705210-01	6.57716750-02	1.24599110-02	2.1059180-03	4.5996324-04
KAPPA(P)	1.7227840-04	6.10854530-03	1.74105230-03	4.36839220-02	1.56897530-02
KAPPA(R)	1.72392160-03	6.32984500-02	1.96090230-02	5.23801660-01	1.69213970-01
THETA = 33.99450			13 DENSITIES		
DENSITY	3.1665610-07	4.00775310-08	4.69090660-09	4.94095100-10	4.68762490-11
KAPPA(P)	1.07385125-00	3.31343730-01	2.18171460-01	2.04403560-01	2.02916850-01
KAPPA(R)	3.16098610-01	2.19084520-01	2.01651360-01	1.99563850-01	1.99255970-01
THETA = 50.00000			13 DENSITIES		
DENSITY	5.9526440-01	1.10880630-01	2.02032060-02	3.60821890-03	6.57595800-04
KAPPA(P)	1.40862740-04	6.39185970-03	2.34700880-03	7.58893900-02	2.14843950-02
KAPPA(R)	1.42073390-03	6.61183370-02	2.52211810-02	7.35517210-01	2.65369140-01
THETA = 50.00000			13 DENSITIES		
DENSITY	5.4603920-07	7.13604050-08	8.35972800-09	8.89212590-10	8.35964580-11
KAPPA(P)	5.36889140-01	2.45787140-01	2.07242430-01	2.03054700-01	2.02804460-01
KAPPA(R)	2.49397070-01	2.11392220-01	2.03252550-01	1.99504000-01	1.99135060-01
THETA = 69.99498			13 DENSITIES		
DENSITY	9.15697790-01	1.59828640-01	2.93762190-02	5.12326170-03	9.65467630-04
KAPPA(P)	1.47031010-04	7.07436710-03	2.20362920-03	5.74795290-02	1.29204440-02
KAPPA(R)	2.67292220-03	1.17764620-03	3.75621480-02	8.72543000-01	1.68437720-01
THETA = 69.99498			13 DENSITIES		
DENSITY	9.05453440-07	1.17706698-07	1.38477925-08	1.47132892-09	1.38477940-10
KAPPA(P)	3.19441420-01	2.14473730-01	2.03609770-01	2.02935110-01	2.02881340-01
KAPPA(R)	2.45976210-01	2.09440800-01	1.99946580-01	1.99332890-01	1.99291040-01
THETA = 99.99496			13 DENSITIES		
DENSITY	1.36320613-00	2.40521910-01	4.20407480-02	8.14653170-03	1.61434336-03
KAPPA(P)	1.16254616-04	4.65241540-03	1.20624670-03	2.45797960-02	4.80244880-01
KAPPA(R)	3.64270170-03	1.51376310-03	4.00849160-02	7.16333770-01	1.10212251-01
THETA = 99.99496			13 DENSITIES		
DENSITY	1.54599552-06	2.00980100-07	2.36446280-08	2.51224280-09	2.36446320-10
KAPPA(P)	2.3352290-01	2.05524330-01	2.03249290-01	2.03045130-01	2.03023610-01
KAPPA(R)	2.16575400-01	2.01040690-01	1.99610760-01	1.99494820-01	1.99402450-01
THETA = 149.99495			13 DENSITIES		
DENSITY	2.2041170-00	4.00272030-01	7.57305230-02	1.44854357-02	2.95739060-03
KAPPA(P)	5.49543480-03	1.51911440-03	3.61311270-02	7.18036960-01	1.43434725-01
KAPPA(R)	1.18354790-03	4.48653980-02	1.26792891-02	2.53375890-01	4.78978240-00
THETA = 149.99495			13 DENSITIES		
DENSITY	2.2041170-00	4.00272030-01	7.57305230-02	1.44854357-02	2.95739060-03
KAPPA(P)	5.49543480-03	1.51911440-03	3.61311270-02	7.18036960-01	1.43434725-01
KAPPA(R)	1.18354790-03	4.48653980-02	1.26792891-02	2.53375890-01	4.78978240-00

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 144.99° ± 5			CONTINUED		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
2.8401650-00	3.69221170-07	4.34360600-00	4.61529560-09	4.34360670-10	2.02319730-01
2.04417500-01	2.02804930-01	2.02385070-01	2.42326000-01	2.02319730-01	1.98749710-01
2.01716500-01	1.98924350-01	1.98778140-01	1.98752280-01	1.98749710-01	
THETA = 224.99° ± 0			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
3.72025420-00	7.03422280-01	1.37719670-01	2.72229480-02	5.43022360-03	1.08544094-03
1.99172730-00	5.43122060-02	1.15629018-02	2.37078440-01	4.90743790-00	1.02397479-00
1.95470730-02	7.50516420-01	1.04021950-01	4.43798570-00	4.43810310-01	3.53170260-01
THETA = 340.00° ± 12			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
5.21772490-00	6.78304240-07	7.98001860-08	8.47877530-09	7.98002000-10	1.99506650-04
2.01657410-01	1.99326190-01	1.99957180-01	1.99930590-01	1.99927790-01	3.39154400-05
1.97397430-01	1.96748050-01	1.96661900-01	1.96456740-01	1.96855760-01	2.14416470-01
THETA = 499.99° ± 33			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
6.56434450-00	1.29235132-00	2.54979280-01	5.05293470-02	1.08853341-02	3.70594540-04
7.95407430-02	1.87547080-02	3.94975620-01	8.19512830-00	1.71355386-00	2.33932420-01
5.02476130-01	1.33888185-01	3.11143170-00	7.88113460-01	3.29422220-01	2.01914710-01
9.6922610-06	1.25999860-06	1.48234560-07	1.57499290-04	1.48234590-09	1.99907800-01
1.97349300-01	1.96658810-01	1.96567770-01	1.96556960-01	1.96555790-01	
1.94799490-01	1.94605470-01	1.94579200-01	1.94576080-01	1.94575700-01	
THETA = 699.99° ± 76			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
1.15742450-01	2.29412970-00	4.54122950-01	9.00435550-02	1.79844650-02	6.40898040-04
1.04099154-02	3.57540700-01	7.32521780-00	1.74347404-00	4.73173900-01	1.91016780-01
5.15401450-00	1.29704077-00	4.40009390-11	2.55999420-01	2.08695080-01	1.91928760-01
1.74046010-05	2.24701040-06	2.64355770-07	2.80878160-04	2.64355850-09	
1.88139600-01	1.88094270-01	1.88088250-01	1.88087490-01	1.88087490-01	1.12391870-04
1.90971510-11	1.90954510-01	1.90952230-01	1.90951850-01	1.90951850-01	1.86109760-04
THETA = 899.99° ± 76			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
1.90688440-01	3.79238840-00	7.51741390-01	1.42201730-01	2.97903430-02	1.09477762-03
5.66027470-01	1.29192440-01	2.83699500-00	6.74994730-01	2.63204230-01	1.86009670-01
2.62315490-00	7.64288630-01	3.26631900-01	2.27443820-01	2.00821660-01	1.80269450-01
4.86321610-05	3.72218400-06	4.37902330-07	4.63271430-08	4.37902410-09	1.91023270-01
1.88116620-01	1.88090880-01	1.88087490-01	1.88087490-01	1.88087490-01	
1.90961460-01	1.90953100-01	1.90952030-01	1.90951850-01	1.90951850-01	

ONLY ABSORPTION COEFFICIENTS CONTINUED

THETA = 999.99567		13 DENSITIES						
DENSITY	3.24666750+01	6.46293780+00	1.27599280+00	2.54733590-01	5.08650620-02	1.01696654-02	1.00929859-03	3.1776410-04
KAPPA(P)	2.9291620+01	6.53625900+00	1.46201359+00	8.04399790-01	2.19275570-01	1.92335320-01	1.0070400-01	1.00172150-01
KAPPA(R)	1.51200094+00	4.67332130-01	2.64814930-01	2.11376270-01	1.96356240-01	1.92270096-01	1.91221080-01	1.90963160-01
DENSITY	4.8086640+00	6.35549990-06	7.47710520-07	7.94442060-00	7.47710740-09			
KAPPA(P)	1.86110+00	1.08009190-01	1.68087690-01	1.08007490-01	1.00087490-01			
KAPPA(R)	1.90956010-01	1.90952410-01	1.90951850-01	1.90951850-01	1.90951050-01			
THETA = 1499.99730		13 DENSITIES						
DENSITY	5.94780050+01	1.17249609+01	2.34303460+00	4.67945330-01	9.34437160-02	1.64820170-02	3.43411060-03	3.03793050-04
KAPPA(P)	1.36761017+01	3.06334130+00	7.17594950-01	2.70746310-01	1.99410250-01	1.89705390-01	1.84335190-01	1.80125120-01
KAPPA(R)	7.97775550-01	3.38708980-01	2.29802970-01	2.01406290-01	1.93650560-01	1.91550060-01	1.91094310-01	1.90946170-01
DENSITY	8.96140000+00	1.16758270-05	1.37362132-06	1.45947340-07	1.37362156-08			
KAPPA(P)	1.86053140-01	1.80087490-01	1.80087490-01	1.80087490-01	1.80087490-01			
KAPPA(R)	1.90954130-01	1.90952030-01	1.90951050-01	1.90951050-01	1.90951050-01			
THETA = 2299.99170		13 DENSITIES						
DENSITY	1.09122461+02	2.15324900+01	4.30497780+01	8.59637320-01	1.71665580-01	3.43220710-02	6.30887440-03	1.07209543-03
KAPPA(P)	6.32650210+00	1.43120963+00	3.99303220-01	2.14564680-01	1.92259550-01	1.88758460-01	1.80182500-01	1.80104230-01
KAPPA(R)	4.76306120-01	2.65345110-01	2.11050670-01	1.96305140-01	1.92252050-01	1.91240010-01	1.90960120-01	1.90950300-01
DENSITY	1.44999130+00	2.14499130+00	2.52350960+06	2.64123000+07	2.52351000+08			
KAPPA(P)	1.80087490-01	1.80087490-01	1.80087490-01	1.80087490-01	1.80087490-01			
KAPPA(R)	1.90952030-01	1.90952030-01	1.90951050-01	1.90951050-01	1.90951050-01			

10 JIANE/SCAT CF2-10A CI/JT, REGR OF RUN 1-6-67, TEMP(1-2250), TAPE 1032									
GREY ABSORPTION COEFFICIENTS					TEMPERATURES		MATERL = 1103		NR = 855
THETA = 1.00L00					21	13			
					DENSITIES				
DENSITY	1.5040836+01	1.65445286+00	1.18931093-01	6.73166340-03	3.51395220-04	2.15391160-05	1.90175153-06	2.31763400-07	
KAPPA(P)	1.1549076+05	4.59718290+04	8.42943390+04	4.08901530+04	1.06987157+04	2.52259800+03	5.15940260+02	9.22286410+01	
KAPPA(R)	1.8995422+03	1.81689170+03	1.52447740+03	1.04419746+03	5.37082620+02	2.32125450+02	6.20957750+01	1.12740203+01	
DENSITY	2.35065330-04	1.95465950-09	2.01011320-10	2.07550430-11	1.80890430-12				
KAPPA(P)	1.7424422+01	3.33345730+00	4.56761270-01	7.27607240-02	3.26682043-02				
KAPPA(R)	2.13248710+03	4.01599320-01	7.43899070-02	3.13399380-02	2.76817750-02				
THETA = 1.50L00					DENSITIES				
DENSITY	1.12461443+00	1.06421185-01	7.91111160-03	6.23696300-04	6.47193300-05	7.76495500-06	1.02505931-06	1.56056150-07	
KAPPA(P)	3.06480050+05	2.50276070+05	1.99029810+05	6.47714340+04	1.44453795+04	2.96958330+03	5.77438510+02	9.73979410+01	
KAPPA(R)	3.63951100+04	3.27035840+04	2.13000770+04	8.41605030+03	1.97822240+03	3.96921660+02	6.96996280+01	1.14822341+01	
DENSITY	2.25078530-04	4.55797400-09	2.72163030-10	2.54694080-11	1.96362290-12				
KAPPA(P)	1.53256424+01	2.44131210+00	3.56999000-01	7.64758070-02	5.01732130-02				
KAPPA(R)	2.20956100+00	4.62494440-01	9.56302580-02	4.46515170-02	4.54529750-02				
THETA = 2.25L00					DENSITIES				
DENSITY	4.45060200-01	2.45959130-02	2.42440300-03	2.96514410-04	4.76055640-05	8.53239950-06	1.36791902-06	2.00061710-07	
KAPPA(P)	3.26897480+05	3.42329820+05	2.95454450+05	8.45436600+04	1.54708500+04	2.78564030+03	4.63469000+02	7.37935220+01	
KAPPA(R)	2.24612050+05	1.57782050+05	6.75470690+04	1.52088524+04	2.47553280+03	4.39560700+02	8.44697910+01	1.42209093+01	
DENSITY	2.53593050-04	2.47026930-09	3.10403610-10	3.07079410-11	2.76760170-12				
KAPPA(P)	1.32571448+01	2.07944360+00	3.29678260-01	8.99711710-02	6.20525910-02				
KAPPA(R)	2.76344420+00	4.74012350-01	1.16554185-01	6.56214940-12	5.87834060-02				
THETA = 3.40L00					DENSITIES				
DENSITY	1.1715746-01	1.54203045-02	2.24940400-03	3.65701560-04	5.93507440-05	9.65475570-06	1.53642849-06	2.36159120-07	
KAPPA(P)	6.32616630+05	4.64622260+05	2.49389190+05	6.12090280+04	1.24101407+04	2.34644050+03	4.08306020+02	6.77213168+01	
KAPPA(R)	4.07134420+05	2.23154570+05	6.98901410+04	1.31428468+04	2.06430150+03	4.14724710+02	8.60944460+01	1.61594660+01	
DENSITY	3.3426730-08	3.77672010-09	3.89767810-10	3.94041490-11	3.52419220-12				
KAPPA(P)	1.0593430+01	1.75794339+00	3.25512640-01	1.09892243-01	8.81287030-02				
KAPPA(R)	2.61591710+00	5.40354660-01	1.56835870-01	9.22753710-02	8.54312780-02				
THETA = 5.00L00					DENSITIES				
DENSITY	1.1560413-01	1.74922040-02	2.64711750-03	4.17288730-04	7.06045240-05	1.23768842-05	1.94037950-06	2.94689430-07	
KAPPA(P)	5.7727840+05	4.27034440+05	2.16971200+05	5.70520910+04	1.12786657+04	2.09979700+03	3.40851370+02	5.51294660+01	
KAPPA(R)	4.00568430+05	2.10424020+05	6.20297870+04	1.23245808+04	2.65454210+03	5.31411640+02	1.07706715+02	1.80557820+01	

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.0000 CONTINUED

DENSITY 4.2321160-08 5.0184740-09 5.53390370-10 5.68343660-11 4.92473090-12
 KAPPA(P) 4.62056010-00 1.37146086-00 2.63587210-01 1.19673031-01 1.10989019-01
 KAPPA(R) 2.74236-00-00 4.73108600-01 1.54420630-01 1.07786379-01 1.08616776-01

THETA = 7.0000 13 DENSITIES

DENSITY 1.21094749-01 1.97640430-02 3.16674520-03 5.20335160-04 6.7206690-05 1.53405200-05 2.33874600-06 3.46080690-07
 KAPPA(P) 4.9374790-00 4.68017040-05 2.19269010-05 8.95288140-04 9.36791400-03 1.31724530-03 2.22639100-02 3.82236970-01
 KAPPA(R) 3.21955110-05 2.03848010-05 6.74680820-04 1.46336494-04 2.74538660-03 4.60837490-02 7.29933210-01 1.28489587-01

DENSITY 5.75544730-08 6.91439760-09 7.71341510-10 7.64067720-11 6.81612640-12 1.03920507-11
 KAPPA(P) 6.1595840-00 1.02454359-00 2.38068220-01 1.39192690-01 1.31563980-01 1.46129650-01
 KAPPA(R) 2.21082110-00 4.28407340-01 1.65536260-01 1.30208660-01 1.29231740-01 1.43899370-01

THETA = 10.0000 13 DENSITIES

DENSITY 1.44804750-01 2.40732740-02 4.02920180-03 6.71746200-04 1.15750110-04 2.09489030-05 3.53974610-06 5.6895540-07
 KAPPA(P) 4.06870-00-05 3.47444390-05 1.19434086-05 2.24202530-04 3.94749680-03 7.14993140-02 1.38913240-02 2.49958790-01
 KAPPA(R) 1.74786-00-05 1.26341013-05 5.16543440-04 1.04055529-04 1.61376290-03 2.89037000-02 5.48510610-01 9.08992780-00

DENSITY 4.04879450-08 9.76979870-09 1.07652243-09 1.10926875-10 1.03920507-11 1.03920507-11
 KAPPA(P) 4.39101150-00 7.48670810-01 2.25017070-01 1.53843550-01 1.46129650-01 1.46129650-01
 KAPPA(R) 1.5004140-00 3.47057780-01 1.77965070-01 1.49531680-01 1.43899370-01 1.43899370-01

THETA = 15.0000 13 DENSITIES

DENSITY 1.91084410-01 3.26830680-02 5.51972100-03 9.59340050-04 1.70243470-04 3.10503450-05 5.28853150-06 8.43429100-07
 KAPPA(P) 2.81469150-05 1.40262160-05 4.47148040-04 9.70883960-03 2.13598670-03 4.44555090-02 8.25357650-01 1.47124780-01
 KAPPA(R) 7.31911040-04 5.95070450-04 2.67609730-04 5.65045273-03 1.03697580-03 1.98599840-02 3.46075800-01 5.68164400-00

DENSITY 1.25772650-07 1.62368920-06 1.90763800-09 2.01998690-10 1.86344360-11 1.86344360-11
 KAPPA(P) 2.39348130-00 4.28526450-01 1.76770320-01 1.49273950-01 1.49190240-01 1.49190240-01
 KAPPA(R) 9.46314-00-01 2.52332660-01 1.52146100-01 1.46509350-01 1.47333280-01 1.47333280-01

THETA = 22.4999 13 DENSITIES

DENSITY 2.76282120-01 4.68799490-02 8.15712910-03 1.43958259-03 2.60925930-04 4.90935460-05 8.81223050-06 1.48343950-06
 KAPPA(P) 1.00533171-05 5.09128120-04 1.9049970-04 4.7116940-03 9.89120280-02 1.78823510-02 2.92010530-01 4.87444350-00
 KAPPA(R) 2.66091-00-04 2.2324880-04 1.21749150-04 2.99804260-03 5.81202920-02 8.53468020-01 1.19103471-01 1.81830700-00

DENSITY 2.28064420-07 2.8436540-08 3.30215720-09 3.42369760-10 3.16501000-11 3.16501000-11
 KAPPA(P) 9.29794130-01 2.66449090-01 1.69452260-01 1.60019110-01 1.61247150-01 1.61247150-01
 KAPPA(R) 4.34013-00-01 2.07009620-01 1.64322550-01 1.57611050-01 1.58928480-01 1.58928480-01

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 35.00000		11 DENSITIES		11 DENSITIES		11 DENSITIES	
UENSI/	4.0609740-01	7.2602350-02	2.34009630-03	4.4602650-04	0.6167110-04	1.84698750-04	2.57644508-04
KAPPA(P)	4.0745440-04	7.66454170-03	1.62866970-03	3.0127180-02	6.0762210-01	1.81001395-01	2.00034490-00
KAPPA(R)	1.1357760-04	4.1736310-03	1.12797180-03	1.6347710-04	2.93396180-01	8.26744450-00	1.11931890-00
UENSI/	3.8749440-01	4.5702730-02	5.06132710-03	5.06132710-03			
KAPPA(P)	3.8749440-01	4.5702730-02	5.06132710-03	5.06132710-03			
KAPPA(R)	3.8749440-01	4.5702730-02	5.06132710-03	5.06132710-03			
THETA = 50.00000		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSI/	3.29613710-01	1.14197371-01	2.0707700-02	3.06671770-03	7.46690350-04	2.8252420-05	4.93692600-06
KAPPA(P)	1.9217440-04	9.71490270-03	2.0532220-03	6.44115920-02	1.34920260-02	5.74122710-00	1.10753920-00
KAPPA(R)	6.6796130-03	3.9105550-03	1.4781660-03	3.44609650-02	6.46382240-01	2.30259070-00	5.2022750-01
UENSI/	9.7335310-07	8.4412340-06	9.50070340-09	9.44906570-10	8.76876600-11		
KAPPA(P)	3.2466520-01	2.00709330-01	1.83131640-01	1.84828350-01	1.92626340-01		
KAPPA(R)	2.3249720-01	1.82290750-01	1.78549590-01	1.83799270-01	1.89909990-01		
THETA = 65.99998		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSI/	9.3069660-01	1.72316230-01	3.22218340-02	6.12534620-03	1.18926830-03	4.13400040-05	6.71339140-06
KAPPA(P)	1.0972053-04	4.67305830-03	1.33507080-03	2.35909800-02	6.82900540-01	4.25100020-00	1.25319950-00
KAPPA(R)	5.8105650-07	7.74941550-04	7.03837130-02	1.41676310-02	2.56571670-01	1.26828105-00	4.05366650-01
UENSI/	9.8749950-07	1.43090210-07	1.444608420-08	1.53315223-09	1.48277890-10		
KAPPA(P)	4.3356700-01	2.35237400-01	1.9073730-01	1.9449300-01	1.93994980-01		
KAPPA(R)	2.40669430-01	2.01089540-01	1.92401870-01	1.91302370-01	1.91153980-01		
THETA = 99.99998		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSI/	1.4674245-00	2.7635990-01	5.22525800-02	9.89488260-03	1.8723796-03	3.5722770-04	1.03203010-05
KAPPA(P)	7.0650800-03	2.50144030-03	6.42409070-02	1.85178640-02	5.53115900-01	1.61917030-01	8.97388900-01
KAPPA(R)	3.35895750-03	1.40528530-03	3.59455350-02	7.89384370-01	1.64408080-01	4.20042610-00	3.57619750-01
UENSI/	1.61199174-06	2.09416660-07	2.46344420-08	2.61743010-09	2.46347000-10		
KAPPA(P)	3.04161030-01	2.08062030-01	1.95367870-01	1.93991870-01	1.93915070-01		
KAPPA(R)	2.20426490-01	1.97050790-01	1.92848320-01	1.91336420-01	1.91224910-01		
THETA = 149.99995		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSI/	2.53746430-00	4.69619250-01	8.70237700-02	1.62935500-02	3.13319200-03	1.13233900-04	1.92369000-05
KAPPA(P)	4.84076950-03	1.82645260-03	5.47506300-02	1.43742990-02	3.47562000-01	1.50213470-00	4.18052510-01
KAPPA(R)	2.36503400-03	8.70269500-02	2.29510670-02	4.81741600-01	8.41345050-00	4.40128150-01	2.69181800-01

CHEY ABORPTION COEFFICIENTS CONTINUED

THETA = 149.99595 CONTINUED

DENSITY 2.9917500-06 3.8469410-07 4.5256930-08 4.8085510-09 4.5256930-10
 KAPPA(P) 2.2466930-01 1.9704010-01 1.94906170-01 1.94746610-01 1.94732780-01
 KAPPA(R) 2.1167020-01 1.94660550-01 1.92447670-01 1.92314740-01 1.92306080-01

THETA = 224.59590

13 DENSITIES

DENSITY 4.26502500-00 7.65047810-01 1.47652750-01 2.86441000-02 5.67040910-03 1.13143111-03 2.07079710-04 3.53342930-05
 KAPPA(P) 3.04333670-03 1.11626540-03 2.72546690-02 5.51336300-01 1.14749452-01 2.36110650-00 5.76221770-01 2.47401010-01
 KAPPA(R) 1.23651830-03 5.52110910-02 1.30806920-02 2.34460030-01 1.07450800-00 9.63055660-01 3.60910020-01 2.87260300-01

THETA = 340.0012

13 DENSITIES

DENSITY 5.43625000-06 7.06704780-07 8.31425000-08 8.83094400-09 6.31425190-10 0.31425190-10
 KAPPA(P) 2.01780450-01 1.97391740-01 1.94831960-01 1.94884890-01 1.94879980-01 1.94754590-01
 KAPPA(R) 1.97913120-01 1.95044950-01 1.94779910-01 1.94757130-01 1.94754590-01

THETA = 499.99593

13 DENSITIES

DENSITY 7.31996100-00 1.30316312-00 2.67903080-01 5.23659930-02 1.05173080-02 2.10104380-03 3.84127470-04 6.56306410-05
 KAPPA(P) 1.42123300-03 3.80572450-02 6.29935570-01 1.63369420-01 3.43400590-00 8.11074630-01 2.85246900-01 2.09306620-01
 KAPPA(R) 3.06731350-02 1.13795993-02 2.96405250-01 6.10264910-00 1.30882627-00 4.07474070-01 2.32250670-01 2.01378110-01

THETA = 699.99593

13 DENSITIES

DENSITY 1.00961290-05 1.31275050-06 1.54443110-07 1.64095920-08 1.54443110-09 1.54443110-09
 KAPPA(P) 2.00323040-01 1.99081900-01 1.98939310-01 1.98922490-01 1.98920700-01 1.98920700-01
 KAPPA(R) 1.97275000-01 1.96695780-01 1.96636590-01 1.96629310-01 1.96628520-01 1.96628520-01

THETA = 899.99593

13 DENSITIES

DENSITY 1.25440206-01 2.41878900-00 4.73077560-01 9.41567420-02 1.87506470-02 3.74666440-03 6.88592460-04 1.17056000-04
 KAPPA(P) 5.17238470-02 1.12204590-02 2.69047800-01 5.63942170-00 1.22648626-00 3.67597010-01 2.21038410-01 2.02074090-01
 KAPPA(R) 5.76409490-01 1.60103750-01 4.12589920-00 1.02441253-00 3.74182990-01 2.35129460-01 2.02714030-01 1.96924240-01

THETA = 1099.99593

13 DENSITIES

DENSITY 1.00060100-05 1.31275050-06 1.54443110-07 1.64095920-08 1.54443110-09 1.54443110-09
 KAPPA(P) 1.94142410-01 1.94084760-01 1.94084760-01 1.94084760-01 1.94084760-01 1.94084760-01
 KAPPA(R) 1.94084760-01 1.94084760-01 1.94084760-01 1.94084760-01 1.94084760-01 1.94084760-01

THETA = 1299.99593

13 DENSITIES

DENSITY 2.00323040-01 1.99081900-01 1.98939310-01 1.98922490-01 1.98920700-01 1.98920700-01
 KAPPA(P) 1.97275000-01 1.96695780-01 1.96636590-01 1.96629310-01 1.96628520-01 1.96628520-01
 KAPPA(R) 1.97275000-01 1.96695780-01 1.96636590-01 1.96629310-01 1.96628520-01 1.96628520-01

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 999.9967		13 DENSITIES						
DENSITY	3.30435-40-01	6.72335300-00	1.33279107-00	2.65141800-01	5.30268450-02	1.05960342-02	1.94762229-03	3.31085190-04
KAPPA(P)	9.92580410-01	2.30718200-01	4.46502650-00	1.06477850-00	3.41737970-01	2.17961860-01	1.97052700-01	1.94527490-01
KAPPA(R)	4.74396360-00	1.27997979-00	4.41314460-01	2.54773330-01	2.04422610-01	1.97137070-01	1.93799530-01	1.93053100-01
DENSITY	5.09359-20-05	6.62164990-06	7.79019390-07	8.27708460-08	7.79019520-09			
KAPPA(P)	1.93986500-01	1.94557410-01	1.94545340-01	1.94545390-01	1.94545370-01			
KAPPA(R)	1.92927000-01	1.93209720-01	1.93206870-01	1.93206440-01	1.93206440-01			
THETA = 1499.99350		13 DENSITIES						
DENSITY	0.10484-10-01	1.22944256-01	2.44730390-00	4.87856970-01	9.74132540-02	1.94674780-02	3.57800480-03	6.08242450-04
KAPPA(P)	1.77367030-01	3.99421070-00	9.21066520-01	3.09294920-01	2.06210660-01	1.90751450-01	1.88660900-01	1.88353330-01
KAPPA(R)	9.54179-10-01	3.73177950-01	2.39041690-01	2.04131070-01	1.94486350-01	1.91707210-01	1.91042180-01	1.90930260-01
DENSITY	9.35752-80-05	1.21647273-05	1.43115326-06	1.52860100-07	1.43115369-08			
KAPPA(P)	1.84306-60-01	1.88294940-01	1.88297900-01	1.88297710-01	1.88297710-01			
KAPPA(R)	1.90913090-01	1.90910220-01	1.90909840-01	1.90909440-01	1.90909400-01			
THETA = 2249.99070		13 DENSITIES						
DENSITY	1.13421-57-02	2.25066460-01	4.49466420-00	6.96185190-01	1.78956050-01	3.57639100-02	6.37321000-03	1.11741-97-03
KAPPA(P)	8.24313060-00	1.83946333-06	4.02568260-01	2.32318440-01	1.94263070-01	1.89117830-01	1.88312400-01	1.88193420-01
KAPPA(R)	5.51336-90-01	2.82347130-01	2.15747250-01	1.97666700-01	1.92562790-01	1.91273400-01	1.90480620-01	1.90019000-01
DENSITY	1.71908710-04	2.23440840-05	2.62920250-06	2.79356120-07	2.62920290-08			
KAPPA(P)	1.88172720-01	1.88169330-01	1.88168960-01	1.88168940-01	1.88168940-01			
KAPPA(R)	1.90911570-01	1.90910030-01	1.90909840-01	1.90909440-01	1.90909400-01			

49	DIANE/SCAT CM2-16A		TEMP(1.5-1.6)		8-19-67		INPUT TAPES(1032,1000)		MATERL = 1101		NR = 900	
GREY ABSORPTION COEFFICIENTS			24		TEMPERATURES							
THETA = 1.5000			13		DENSITIES							
DENSITY	2.506070-01	2.35045130-02	1.70459002-03	1.25594270-04	1.20363082-05	1.62017645-06	2.42010040-07	4.29130000-08				
KAPPA(P)	4.229790-05	3.23611010-05	2.77013060-05	1.51036560-05	3.00910700-06	7.21348190-06	1.13135440-06	1.70944320-06				
KAPPA(R)	1.79067010-04	1.52707909-04	1.31105022-04	8.31179500-05	3.21105010-05	6.14242300-05	1.53940930-05	2.02000000-05				
DENSITY	6.26604000-09	7.17491540-10	7.74135040-11	8.09293900-12	7.59076950-13							
KAPPA(P)	3.02541000-01	5.63614020-00	9.01893980-01	2.04676330-01	1.23963761-01							
KAPPA(R)	6.52307060-00	1.53657050-00	3.32352070-01	1.44029230-01	1.18740201-01							
THETA = 2.2500			13 <td colspan="2">DENSITIES</td> <td colspan="2"></td> <td colspan="2"></td> <td colspan="2"></td>		DENSITIES							
DENSITY	5.79339000-02	5.77043620-03	5.89222730-04	7.71702080-05	1.30555139-05	2.30815380-06	3.90240070-07	6.18210050-08				
KAPPA(P)	7.00441700-05	5.28428760-05	3.14007010-05	8.30958330-06	1.52120526-06	3.19213710-06	7.23996100-06	1.32049700-06				
KAPPA(R)	1.27363032-05	9.39670920-06	5.04914010-06	1.74250280-06	4.46251120-06	1.13179000-06	2.56540340-06	4.24470310-06				
DENSITY	9.14635070-09	1.16234076-09	1.25579760-10	1.21943246-11	1.11682642-12							
KAPPA(P)	1.90680650-01	2.82820710-00	5.63322460-01	2.02019680-01	1.51045220-01							
KAPPA(R)	6.19079070-00	9.43562740-01	2.71248740-01	1.70272470-01	1.46204490-01							
THETA = 3.0000			13 <td colspan="2">DENSITIES</td> <td colspan="2"></td> <td colspan="2"></td> <td colspan="2"></td>		DENSITIES							
DENSITY	3.00707010-04	4.47439460-05	6.61264940-06	1.07976451-06	1.87015000-06	3.54344930-06	6.12761930-07	9.47178290-08				
KAPPA(P)	6.04329400-05	3.06037440-05	1.44639260-05	5.16182190-06	1.16550974-06	2.20586270-06	4.58051200-06	9.81609010-06				
KAPPA(R)	2.71028090-05	1.70430000-05	7.80020930-06	2.43012550-06	5.03963470-06	8.54367920-06	1.79735610-06	3.39322530-06				
DENSITY	1.36995010-08	1.70430237-09	1.83390790-10	1.85363040-11	1.73089961-12							
KAPPA(P)	1.67524000-01	2.54093390-00	5.33811440-01	2.17354590-01	1.77944060-01							
KAPPA(R)	5.47728000-00	9.43102620-01	2.95361270-01	1.92807060-01	1.73120000-01							
THETA = 3.6000			13 <td colspan="2">DENSITIES</td> <td colspan="2"></td> <td colspan="2"></td> <td colspan="2"></td>		DENSITIES							
DENSITY	3.54160000-02	5.63444160-03	9.27662120-04	1.59312550-06	2.84165170-05	5.19499530-06	8.94125310-07	1.46171390-07				
KAPPA(P)	3.54510000-05	1.87412170-05	9.70866990-06	3.84559970-06	9.85584500-06	2.01970750-06	3.66063910-06	7.02790190-06				
KAPPA(R)	1.90012070-05	1.42764510-05	6.96804520-06	2.09522830-06	4.37925960-06	8.06729140-06	1.52327520-06	2.80437090-06				
DENSITY	2.04680800-08	2.62703550-09	3.08490340-10	3.27699300-11	3.08413530-12							
KAPPA(P)	1.17523042-01	1.63420735-00	3.40882440-01	1.91040170-01	1.75603260-01							
KAPPA(R)	4.12772000-00	6.51054410-01	2.36293440-01	1.80596680-01	1.72653430-01							
THETA = 7.0000			13 <td colspan="2">DENSITIES</td> <td colspan="2"></td> <td colspan="2"></td> <td colspan="2"></td>		DENSITIES							
DENSITY	4.45676000-02	7.55845070-03	1.27119743-03	2.23717390-06	4.03003190-05	7.42491070-06	1.29946242-06	2.17033290-07				
KAPPA(P)	2.40915130-05	1.42824230-05	8.41511560-06	2.94076000-06	6.77398540-06	1.24587020-06	2.15303340-06	3.32500210-06				
KAPPA(R)	9.30206640-06	8.31606410-06	4.80151240-06	1.50850266-06	3.22525300-06	6.30233720-06	9.40704020-06	1.95213750-06				

GREY ABSORPTION COEFFICIENTS CONTINUED

7.0000 CONTINUED			13 DENSITIES		
THETA =	7.0000	CONTINUED	THETA =	13.0000	CONTINUED
DENSITY	3.34213e-06	4.34282e-09	5.10893e-10	5.42819e-11	5.10885e-12
KAPPA(P)	4.64015e-06	7.13202e-01	2.35449e-01	1.80324e-01	1.74412e-01
KAPPA(R)	1.52663e-06	3.69415e-01	2.06456e-01	1.74423e-01	1.71593e-01
THETA =	10.0000		13 DENSITIES		
DENSITY	5.16114e-02	1.04308e-02	1.06944e-03	3.31405e-04	6.14842e-05
KAPPA(P)	1.55361e-05	1.03869e-05	5.36867e-04	1.49593e-04	2.55044e-05
KAPPA(R)	3.75355e-05	3.45927e-04	2.31072e-04	0.52237e-03	1.57865e-03
DENSITY	3.70396e-09	7.41478e-09	6.72324e-10	9.26844e-11	0.72324e-12
KAPPA(P)	1.69454e-09	3.65904e-10	1.95996e-10	1.74121e-10	1.74020e-10
KAPPA(R)	6.28590e-10	2.95571e-10	1.93094e-10	1.73320e-10	1.70911e-10
THETA =	15.0000		13 DENSITIES		
DENSITY	9.47068e-02	1.66446e-02	3.03019e-03	5.67351e-04	1.100461e-04
KAPPA(P)	0.10879e-04	4.66752e-04	1.80537e-04	3.72424e-04	6.49081e-05
KAPPA(R)	1.04629e-04	7.44461e-04	3.96225e-04	1.25544e-03	2.79236e-02
DENSITY	1.04762e-11	1.36198e-12	1.40054e-09	1.64394e-10	1.49400e-11
KAPPA(P)	6.26932e-11	2.32697e-10	1.91209e-10	1.75644e-10	1.86542e-10
KAPPA(R)	4.40256e-10	2.15637e-10	1.76782e-10	1.73234e-10	1.83044e-10
THETA =	20.0000		13 DENSITIES		
DENSITY	1.56057e-01	2.81217e-02	5.32926e-03	1.02530e-03	2.01274e-04
KAPPA(P)	3.62573e-04	1.69104e-04	4.49530e-04	1.05075e-04	1.96854e-05
KAPPA(R)	3.27074e-04	1.62141e-04	5.30648e-04	1.50606e-04	3.49361e-05
DENSITY	1.80074e-07	2.18824e-08	2.44443e-09	2.47527e-10	2.22554e-11
KAPPA(P)	7.05407e-08	3.19449e-08	2.26876e-08	2.23440e-08	2.30433e-08
KAPPA(R)	3.24421e-07	2.25919e-07	2.07473e-07	2.16431e-07	2.25030e-07
THETA =	35.0000		13 DENSITIES		
DENSITY	2.71031e-01	4.99767e-02	9.52744e-03	1.07741e-03	3.60556e-04
KAPPA(P)	1.67956e-04	5.75029e-04	1.60335e-04	4.14642e-04	1.30859e-04
KAPPA(R)	1.61924e-04	5.76950e-04	1.75430e-04	4.66276e-04	1.40734e-04
DENSITY	4.75708e-07	3.50167e-08	4.10341e-09	4.35825e-10	4.10167e-11
KAPPA(P)	9.82478e-07	3.42423e-07	2.44940e-07	2.33140e-07	2.31841e-07
KAPPA(R)	3.32549e-07	2.45527e-07	2.29017e-07	2.24006e-07	2.27640e-07
DENSITY	3.70844e-07	2.18444e-07	2.18444e-07	2.18444e-07	2.18444e-07
KAPPA(P)	1.74444e-07	1.74444e-07	1.74444e-07	1.74444e-07	1.74444e-07
KAPPA(R)	1.74444e-07	1.74444e-07	1.74444e-07	1.74444e-07	1.74444e-07

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 50.0000			13 DENSITIES			13 DENSITIES			13 DENSITIES			13 DENSITIES		
DENSITY	4.6528200-01	5.6046100-02	1.6081610-02	2.9752320-03	5.55367800-04	1.04515620-04	1.05461190-05	3.12223060-06	DENSITY	4.6528200-01	5.6046100-02	1.6081610-02	2.9752320-03	5.55367800-04
KAPPA(P)	1.2455022+04	5.7072360+03	2.0653317+03	6.5720170+02	1.86254670+02	5.25801670+01	1.13923260+01	2.8899780+00	KAPPA(P)	1.2455022+04	5.7072360+03	2.0653317+03	6.5720170+02	1.86254670+02
KAPPA(R)	1.7070000+03	6.1344950+02	2.0703322+02	6.3084760+01	1.79105150+01	4.89861730+00	1.26772123+00	4.46682830-01	KAPPA(R)	1.7070000+03	6.1344950+02	2.0703322+02	6.3084760+01	1.79105150+01
DENSITY	4.79449190-07	6.23046320-08	7.33029690-09	7.74036570-10	7.33022470-11	2.31030390-01	2.26296770-01		DENSITY	4.79449190-07	6.23046320-08	7.33029690-09	7.74036570-10	7.33022470-11
KAPPA(P)	3.19129490-01	2.68051730-01	2.34969630-01	2.31308720-01	2.31030390-01	2.26296770-01			KAPPA(P)	3.19129490-01	2.68051730-01	2.34969630-01	2.31308720-01	2.31030390-01
KAPPA(R)	2.73378740-01	2.39215610-01	2.30996090-01	2.26809460-01	2.26296770-01				KAPPA(R)	2.73378740-01	2.39215610-01	2.30996090-01	2.26809460-01	2.26296770-01
THETA = 69.9998			13 DENSITIES			13 DENSITIES			13 DENSITIES			13 DENSITIES		
DENSITY	7.05973460-01	1.29404210-01	2.37663390-02	4.40167110-03	8.44816950-04	1.65855560-04	3.03820070-05	5.16131070-06	DENSITY	7.05973460-01	1.29404210-01	2.37663390-02	4.40167110-03	8.44816950-04
KAPPA(P)	1.3140548+04	6.25036970+03	1.40465260+03	5.00204470+02	1.11956220+02	2.33637330+01	4.25837230+00	9.11877990-01	KAPPA(P)	1.3140548+04	6.25036970+03	1.40465260+03	5.00204470+02	1.11956220+02
KAPPA(R)	2.83482620+03	1.11046030+03	3.31299220+02	7.64239130+01	1.47719180+01	2.75922540+00	6.88062960-01	3.55965950-01	KAPPA(R)	2.83482620+03	1.11046030+03	3.31299220+02	7.64239130+01	1.47719180+01
DENSITY	7.93754430-07	1.03212020-07	1.21425514-08	1.24014660-09	1.21425540-10	2.22786580-01			DENSITY	7.93754430-07	1.03212020-07	1.21425514-08	1.24014660-09	1.21425540-10
KAPPA(P)	3.30305430-01	2.40050010-01	2.30355380-01	2.249566160-01	2.249566160-01	2.22786580-01			KAPPA(P)	3.30305430-01	2.40050010-01	2.30355380-01	2.249566160-01	2.249566160-01
KAPPA(R)	2.73323330-01	2.34274600-01	2.23851580-01	2.22976160-01	2.22786580-01				KAPPA(R)	2.73323330-01	2.34274600-01	2.23851580-01	2.22976160-01	2.22786580-01
THETA = 99.9998			13 DENSITIES			13 DENSITIES			13 DENSITIES			13 DENSITIES		
DENSITY	1.03194370+00	2.02155340-01	3.71332040-02	7.11369730-03	1.41494728-03	2.82180120-04	5.18399240-05	8.01170218-06	DENSITY	1.03194370+00	2.02155340-01	3.71332040-02	7.11369730-03	1.41494728-03
KAPPA(P)	1.0436348+04	4.06430450+03	1.05566800+03	2.13705930+02	4.23994330+01	8.32844000+00	1.68853403+00	4.58225760-01	KAPPA(P)	1.0436348+04	4.06430450+03	1.05566800+03	2.13705930+02	4.23994330+01
KAPPA(R)	3.42533120+03	1.36067970+03	3.54279690+02	6.24909420+01	9.75122560+00	1.93209013+00	6.51963370-01	3.58961610-01	KAPPA(R)	3.42533120+03	1.36067970+03	3.54279690+02	6.24909420+01	9.75122560+00
DENSITY	1.35502435-06	1.76231040-07	2.07349830-08	2.20286090-09	2.07329910-10				DENSITY	1.35502435-06	1.76231040-07	2.07349830-08	2.20286090-09	2.07329910-10
KAPPA(P)	2.52700320-01	2.27591930-01	2.25145550-01	2.24882550-01	2.24856690-01				KAPPA(P)	2.52700320-01	2.27591930-01	2.25145550-01	2.24882550-01	2.24856690-01
KAPPA(R)	2.35555520-01	2.17447240-01	2.15531790-01	2.15460430-01	2.15441900-01				KAPPA(R)	2.35555520-01	2.17447240-01	2.15531790-01	2.15460430-01	2.15441900-01
THETA = 149.9995			13 DENSITIES			13 DENSITIES			13 DENSITIES			13 DENSITIES		
DENSITY	1.34499493+00	3.45724670-01	6.40630390-02	1.30199434-02	2.59390460-03	5.18167000-04	9.52278710-05	1.61800050-05	DENSITY	1.34499493+00	3.45724670-01	6.40630390-02	1.30199434-02	2.59390460-03
KAPPA(P)	4.57093370+03	1.34343150+03	3.16588600+02	6.27629510+01	1.25556720+01	2.65208170+00	6.24426250-01	2.70898790-01	KAPPA(P)	4.57093370+03	1.34343150+03	3.16588600+02	6.27629510+01	1.25556720+01
KAPPA(R)	1.02795740+03	3.91751190+02	1.10647660+02	2.21906710+01	4.24467760+00	9.75810440-01	3.50908420-01	2.29934750-01	KAPPA(R)	1.02795740+03	3.91751190+02	1.10647660+02	2.21906710+01	4.24467760+00
DENSITY	2.49044450-06	3.23757850-07	3.00990140-08	4.04695940-09	3.80890210-10				DENSITY	2.49044450-06	3.23757850-07	3.00990140-08	4.04695940-09	3.80890210-10
KAPPA(P)	2.24261130-01	2.17092240-01	2.16470720-01	2.16399290-01	2.16391720-01				KAPPA(P)	2.24261130-01	2.17092240-01	2.16470720-01	2.16399290-01	2.16391720-01
KAPPA(R)	2.09508410-01	2.06944700-01	2.05550160-01	2.06515660-01	2.06511940-01				KAPPA(R)	2.09508410-01	2.06944700-01	2.05550160-01	2.06515660-01	2.06511940-01
THETA = 224.9990			13 DENSITIES			13 DENSITIES			13 DENSITIES			13 DENSITIES		
DENSITY	3.20305480+00	6.14466540-01	1.20438260-01	2.30751520-02	4.76340760-03	9.51850890-04	1.74942020-04	2.97340340-05	DENSITY	3.20305480+00	6.14466540-01	1.20438260-01	2.30751520-02	4.76340760-03
KAPPA(P)	1.76944470+03	4.84567540+02	1.01878806+02	2.08281000+01	4.31615950+00	9.23270450-01	3.11285150-01	2.21319710-01	KAPPA(P)	1.76944470+03	4.84567540+02	1.01878806+02	2.08281000+01	4.31615950+00
KAPPA(R)	1.79240630+02	6.51423540+01	1.59313520+01	3.49597740+00	8.41206170-01	3.35010440-01	2.26179380-01	2.64190150-01	KAPPA(R)	1.79240630+02	6.51423540+01	1.59313520+01	3.49597740+00	8.41206170-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 220.99450 CONTINUED		
DENSITY	4.57528030-03	5.99776520-07
KAPPA(P)	2.09280120-04	2.07546170-01
KAPPA(R)	2.00304520-01	1.99440390-01
13 DENSITIES		
THETA = 340.00012		
DENSITY	5.70034000-00	1.12613970-00
KAPPA(P)	7.13099060-02	1.67027740-02
KAPPA(R)	4.43731400-01	1.17243745-01
DENSITY	1.49370000-00	1.10434070-00
KAPPA(P)	4.01227330-01	2.00553950-01
KAPPA(R)	1.95400030-01	1.95783660-01
13 DENSITIES		
THETA = 499.99993		
DENSITY	1.00749431-01	2.00134320-00
KAPPA(P)	4.99387470-01	3.33044820-01
KAPPA(R)	4.90201610-00	1.20958773-00
DENSITY	1.51503062-03	1.97030950-06
KAPPA(P)	1.80944940-01	1.88789430-01
KAPPA(R)	1.91147.00-01	1.91121300-01
13 DENSITIES		
THETA = 61.99976		
DENSITY	1.60195110-01	3.31030630-00
KAPPA(P)	5.33099000-01	1.19770089-01
KAPPA(R)	2.60739000-00	7.22829200-01
DENSITY	2.51063450-03	3.26332750-06
KAPPA(P)	1.80913730-01	1.88785060-01
KAPPA(R)	1.91132370-01	1.91110360-01
13 DENSITIES		
THETA = 999.99967		
DENSITY	2.53050590-01	5.64432710-00
KAPPA(P)	2.74009750-01	5.03461190-00
KAPPA(R)	1.82602492-00	4.65843070-01
DENSITY	4.28686420-03	5.57292790-06
KAPPA(P)	1.88797350-01	1.88783560-01
KAPPA(R)	1.91125300-01	1.91110620-01

GRAY ABSORPTION COEFFICIENTS CONTINUED

TETA = 1099.9900			13 DENSITIES		
DENSITY	1.03623205-01	2.03523350-00	9.10204290-01	0.19454910-02	1.03037300-02
KAPPA(P)	1.27337031-01	2.76750000-00	6.63333330-01	1.90599900-01	1.90300000-01
KAPPA(R)	1.50021540-01	3.25557230-01	2.24963330-01	1.93561360-01	1.91235620-01
DENSITY			1.20049316-06		
KAPPA(P)	1.02340445-05	1.80742630-01	1.91117660-01	1.80701690-01	1.91117660-01
KAPPA(R)	1.91120100-01	1.91117660-01	1.91117660-01	1.91117660-01	1.91117660-01
TETA = 2249.9900			13 DENSITIES		
DENSITY	1.03623205-01	2.03523350-00	9.10204290-01	0.19454910-02	1.03037300-02
KAPPA(P)	1.27337031-01	2.76750000-00	6.63333330-01	1.90599900-01	1.90300000-01
KAPPA(R)	1.50021540-01	3.25557230-01	2.24963330-01	1.93561360-01	1.91235620-01
DENSITY			1.20049316-06		
KAPPA(P)	1.02340445-05	1.80742630-01	1.91117660-01	1.80701690-01	1.91117660-01
KAPPA(R)	1.91120100-01	1.91117660-01	1.91117660-01	1.91117660-01	1.91117660-01
TETA = 3400.0000			13 DENSITIES		
DENSITY	1.03623205-01	2.03523350-00	9.10204290-01	0.19454910-02	1.03037300-02
KAPPA(P)	1.27337031-01	2.76750000-00	6.63333330-01	1.90599900-01	1.90300000-01
KAPPA(R)	1.50021540-01	3.25557230-01	2.24963330-01	1.93561360-01	1.91235620-01
DENSITY			1.20049316-06		
KAPPA(P)	1.02340445-05	1.80742630-01	1.91117660-01	1.80701690-01	1.91117660-01
KAPPA(R)	1.91120100-01	1.91117660-01	1.91117660-01	1.91117660-01	1.91117660-01
TETA = 4599.9900			13 DENSITIES		
DENSITY	1.03623205-01	2.03523350-00	9.10204290-01	0.19454910-02	1.03037300-02
KAPPA(P)	1.27337031-01	2.76750000-00	6.63333330-01	1.90599900-01	1.90300000-01
KAPPA(R)	1.50021540-01	3.25557230-01	2.24963330-01	1.93561360-01	1.91235620-01
DENSITY			1.20049316-06		
KAPPA(P)	1.02340445-05	1.80742630-01	1.91117660-01	1.80701690-01	1.91117660-01
KAPPA(R)	1.91120100-01	1.91117660-01	1.91117660-01	1.91117660-01	1.91117660-01
TETA = 5799.9900			13 DENSITIES		
DENSITY	1.03623205-01	2.03523350-00	9.10204290-01	0.19454910-02	1.03037300-02
KAPPA(P)	1.27337031-01	2.76750000-00	6.63333330-01	1.90599900-01	1.90300000-01
KAPPA(R)	1.50021540-01	3.25557230-01	2.24963330-01	1.93561360-01	1.91235620-01
DENSITY			1.20049316-06		
KAPPA(P)	1.02340445-05	1.80742630-01	1.91117660-01	1.80701690-01	1.91117660-01
KAPPA(R)	1.91120100-01	1.91117660-01	1.91117660-01	1.91117660-01	1.91117660-01
TETA = 7199.9900			13 DENSITIES		
DENSITY	1.03623205-01	2.03523350-00	9.10204290-01	0.19454910-02	1.03037300-02
KAPPA(P)	1.27337031-01	2.76750000-00	6.63333330-01	1.90599900-01	1.90300000-01
KAPPA(R)	1.50021540-01	3.25557230-01	2.24963330-01	1.93561360-01	1.91235620-01
DENSITY			1.20049316-06		
KAPPA(P)	1.02340445-05	1.80742630-01	1.91117660-01	1.80701690-01	1.91117660-01
KAPPA(R)	1.91120100-01	1.91117660-01	1.91117660-01	1.91117660-01	1.91117660-01

ONEY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5994.9940 CONTINUED

DENSITY 7.93935/80-04 1.03211636-04 1.21428862-05 1.29013980-06 1.21428862-07
KAPPA(P) 1.90725890-01 1.90725890-01 1.90725890-01 1.90725890-01 1.90725890-01
KAPPA(R) 1.91275890-01 1.91275890-01 1.91275890-01 1.91275890-01 1.91275890-01

THETA = 5999.99320 13 DENSITIES

DENSITY 9.91900900-02 1.76679950-02 3.53541870-01 7.0408670-00 1.41029950-00 2.81996390-01 5.18341550-02 8.01138000-03
KAPPA(P) 6.03308350-01 2.63239240-01 2.03127790-01 1.93030510-01 1.91203300-01 1.90335590-01 1.90766610-01 1.90766600-01
KAPPA(R) 4.13003600-01 1.97192270-01 1.92753250-01 1.91617310-01 1.91375000-01 1.91313000-01 1.91299890-01 1.91297800-01

DENSITY 1.35582191-03 1.76230600-04 2.07330020-05 2.20299100-06 2.07330050-07
KAPPA(P) 1.90744390-01 1.90744390-01 1.90744390-01 1.90744390-01 1.90744390-01 1.90744390-01 1.90744390-01 1.90744390-01
KAPPA(R) 1.91296020-01 1.91296020-01 1.91296020-01 1.91296020-01 1.91296020-01 1.91296020-01 1.91296020-01 1.91296020-01

1															DIANE/NOSCT CM2 TEMP(100.-2250.) 11 FREQ. CL/MT 11/18/66															000000															WATERL = 2101															NR = 309																																																											
WAVELENGTH COEFFICIENTS															9 TEMPERATURES															13 DENSITIES															9 TEMPERATURES															13 DENSITIES															9 TEMPERATURES															13 DENSITIES																													
THETA = 94.9990															13 DENSITIES															9 TEMPERATURES															13 DENSITIES															9 TEMPERATURES															13 DENSITIES																																												
DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY																													
KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)														
1.0966299+00															2.01927610-01															3.70605570-02															7.13051890-03															1.41194511-03															2.81561120-04															5.17297800-05															8.79344090-06														
1.04591759+00															4.07342670+03															1.05769460+03															2.18156970+02															4.29911570+01															8.34448070+00															1.69217090+00															4.50697930-01														
3.8276020+03															1.36356100+03															3.65051310+02															6.31215330+01															9.77154870+00															1.93619264+00															6.53204400-01															3.27952400-01														
1.35275180+06															1.75856870-07															2.746990810-08															2.14021560-09															2.06090800-10																																																											
2.48187870+01															2.09836040-01															2.0267970-01															2.04738240-01															2.04601320-01																																																											
1.7464040-01															1.23306891-01															1.11456435-01															1.14495433-01															1.14392243-01																																																											
THETA = 100.9995															13 DENSITIES															9 TEMPERATURES															13 DENSITIES															9 TEMPERATURES															13 DENSITIES																																												
DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY																													
KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)														
1.84109142+00															3.445959810-01															6.59228010-02															1.24923187-02															2.58039450-03															5.17067570-04															9.50297240-05															1.61339430-05														
4.08149050+03															1.35178730+03															3.17239000+02															6.24972190+01															1.25617185+01															2.65760220+00															6.21845200-01															2.37060000-01														
1.03020490+03															3.92602240+02															1.10987031+02															2.22357460+01															4.24078700+00															9.51150100-01															2.49971000-01															8.22672700-02														
2.80531490+05															3.23068070-07															3.60063500-08															4.03930450-09															3.00083570-10																																																											
1.69458400+01															1.56884660-01															1.57549130-01															1.57414000-01															1.57997310-01																																																											
4.82683300+02															4.27070190-02															4.19684130-02															4.14803310-02															4.10706670-02																																																											
THETA = 226.99950															13 DENSITIES															9 TEMPERATURES															13 DENSITIES															9 TEMPERATURES															13 DENSITIES																																												
DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY																													
KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)														
3.17446430+00															6.13342940-01															1.20182405-01															2.34244450-02															4.75330070-03															9.49035290-04															1.74570640-04															2.96760500-05														
1.77356700+03															4.06015710+02															1.32099309+02															2.04687950+01															4.32415600+00															2.50437340-01															1.27055570-01															1.27055570-01														
1.74622940+02															6.52636740+01															1.59454160+01															3.44918430+00															7.34015590-01															1.60596060-01															4.11076200-02															1.83773940-02														
4.35531490+06															5.93517030-07															6.94252670-08															7.41893780-09															6.98352790-10																																																											
1.0610725+01															1.02671443-01															1.35803977+01															1.03750635-01															1.03744920-01																																																											
1.45917426+02															1.37594559-02															1.41053235-02															1.40075082+00															1.40943115-02																																																											
THETA = 340.00012															13 DENSITIES															9 TEMPERATURES															13 DENSITIES															9 TEMPERATURES															13 DENSITIES																																												
DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY																													
KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)														
3.68448410+00															1.12375043+00															2.22687910-01															4.422995370-02															4.028445750-03															1.74433362-03															3.24275230-04															5.51251020-05														
7.16493000+02															1.67399420+02															3.50554400+01															7.17351560+00															1.50566790+00															3.52455400-01															1.14000773-01															6.92944230-02														
4.44624070+01															1.17495152+01															2.70040740+00															5.80395450-01															1.23301641-01															2.07749300-02															9.15341750-03															5.46157950-03														
4.84074400+05															1.10250027-06															1.23705420-07															1.37812040-08															1.29705461-09																																																											
9.25084500+02															6.02774430-02															6.01153530-02															6.04960000-02															6.00930940-02																																																											
4.01967400+03															4.71600140-03															4.70458040-03															4.74248910-03															4.70281500-03																																																											
THETA = 499.99953															13 DENSITIES															9 TEMPERATURES															13 DENSITIES															9 TEMPERATURES															13 DENSITIES																																												
DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY															DENSITY																													
KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)															KAPPA(P)														
1.00535190+01															1.99709713+00															3.96734250-01															7.07951370-02															1.57377650-02															3.14639480-03															5.78295250-04															9.03079330-05														
9.92020700+01															3.33760430+01															7.29494900+00															1.58277708+00															3.35886300-01															2.05374600-02															1.39368066-02															1.39368066-02														
4.90612480+00															1.12900079+00															2.44677510-01															5.266443250-02															1.15066591-02															2.59627440-03															8.50627850-04															5.31336050-04														

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 999.9993 CONTINUED		
DENSITY	1.51241169-05	1.94613680-06
KAPPA(P)	1.2796450-02	1.25821193-02
KAPPA(R)	4.7483640-04	4.65859260-04
THETA = 699.9976 13 DENSITIES		
DENSITY	1.6594340-01	3.30304370-03
KAPPA(P)	5.3515040-01	1.20014679-01
KAPPA(R)	2.44655420-00	5.93405320-01
DENSITY	2.54531760-05	3.25691540-06
KAPPA(P)	1.26982563-02	1.25956219-02
KAPPA(R)	4.69782250-04	4.65201940-04
THETA = 999.99967 13 DENSITIES		
DENSITY	2.84453620-01	5.63235130-00
KAPPA(P)	2.75059420-01	6.04063410-00
KAPPA(R)	1.36518423-00	2.98591160-01
DENSITY	4.27774270-05	5.56107070-06
KAPPA(P)	1.26341608-02	1.25687443-02
KAPPA(R)	4.57097500-04	4.64852690-04
THETA = 1494.99220 13 DENSITIES		
DENSITY	5.14002410-01	1.03403422-01
KAPPA(P)	1.27544233-01	2.75213500-00
KAPPA(R)	6.30259453-01	1.35944740-01
DENSITY	7.85873310-05	1.02163626-05
KAPPA(P)	1.28055431-02	1.25853461-02
KAPPA(R)	4.65266420-04	4.64866310-04
THETA = 2249.99070 13 DENSITIES		
DENSITY	9.54810760-01	1.68230270-01
KAPPA(P)	4.83636440-00	1.83305814-00
KAPPA(R)	2.89945560-01	6.29885060-02
DENSITY	1.44374400-04	1.87686960-05
KAPPA(P)	1.1065931-02	1.40937054-02
KAPPA(R)	4.89827060-04	4.68888888-04

1180302			JIANE CARBON PHEMOLIC 30 -- 12 FREQUENCIES -- JANUARY 21, 1966			MATERL = 1115			NR = 070		
GREY ABSORPTION COEFFICIENTS			23 TEMPERATURES								
THETA = .1245			12 DENSITIES								
DENSITY	1.10916457-01	3.69182230-02	1.10640656-02	3.64774440-03	1.10563527-03	3.68359950-04	1.10436493-04	3.67899300-05			
KAPPA(P)	1.12536238-05	1.78322840-05	2.95064990-05	4.65970340-05	7.71954440-05	1.22123230-04	2.01831150-04	3.19500950-04			
KAPPA(R)	9.58679530-07	1.59346452-06	2.79216020-06	4.64193090-06	8.30543910-06	1.41117097-05	2.54447700-05	4.30401950-05			
DENSITY	1.10277449-05	3.67263950-06	1.10044048-06	3.66344190-07							
KAPPA(P)	5.29709440-04	8.42017620-04	1.40435914-03	2.26556750-03							
KAPPA(R)	8.07930450-05	1.42084300-04	2.64046280-04	4.74964750-04							
THETA = .17430			12 DENSITIES								
DENSITY	8.26792470-02	2.75988820-02	8.24934440-03	2.75288600-03	8.24420660-04	2.74280240-04	8.20657350-05	2.72706300-05			
KAPPA(P)	1.20030642-02	1.80163730-02	3.10930800-02	4.56933910-02	8.3854570-02	1.36785670-01	2.54733540-01	3.94765200-01			
KAPPA(R)	2.30412440-05	3.92711540-05	6.99171090-05	1.17593100-02	2.06134810-02	3.41180060-02	5.86692230-02	9.53129110-02			
DENSITY	8.14423720-06	2.69988880-06	8.03490900-07	2.65195120-07							
KAPPA(P)	6.94393410-01	1.18313652-00	2.11485450-00	3.58049520-00							
KAPPA(R)	1.60596440-01	2.56237630-01	4.23861300-01	6.65566320-01							
THETA = .21542			12 DENSITIES								
DENSITY	6.59525450-02	2.19321870-02	6.55785640-03	2.17727760-03	6.49366660-04	2.14407380-04	6.37800600-05	2.09804400-05			
KAPPA(P)	1.42338144-00	2.2909540-00	3.70532130-00	5.89135510-00	9.80428930-00	1.55461028-01	2.55789560-01	3.94803400-01			
KAPPA(R)	1.64343630-01	2.59055540-01	4.30382470-01	6.41592030-01	1.12332606-00	1.76463111-00	2.88028710-00	4.47497148-00			
DENSITY	8.17069400-06	2.00573500-06	5.77706430-07	1.81828460-07							
KAPPA(P)	6.44372440-01	1.01404719-02	1.70732830-02	2.8507260-02							
KAPPA(R)	7.1336720-00	1.10023619-01	1.73900810-01	2.625300-01							
THETA = .25051			12 DENSITIES								
DENSITY	5.44408760-02	1.80449400-02	5.36799400-03	1.77052359-03	5.22706750-04	1.70698900-04	4.95462700-05	1.57952710-05			
KAPPA(P)	2.7319450-01	4.24484950-01	6.06143590-01	1.05253314-02	1.66422360-02	2.52451700-02	4.01762000-02	6.28519000-02			
KAPPA(R)	2.6415250-00	4.15474000-00	6.79753470-00	1.05731734-01	1.70324440-01	2.61704900-01	4.18511790-01	6.45441170-01			
DENSITY	4.36772470-06	1.31417493-06	3.35816050-07	9.53129840-08							
KAPPA(P)	1.06693490-03	1.70838400-03	3.16750640-03	5.03853130-03							
KAPPA(R)	1.04959420-02	1.65274870-02	2.69497230-02	4.00282200-02							
THETA = .30460			12 DENSITIES								
DENSITY	4.59119430-02	1.51210123-02	4.45232000-03	1.44794493-03	4.17101920-04	1.31260070-04	3.54379350-05	1.03450751-05			
KAPPA(P)	1.94792450-02	2.95509190-02	4.62899480-02	6.95193340-02	1.09643570-03	1.69754460-03	2.82485470-03	4.57599130-03			
KAPPA(R)	2.22450400-01	3.45344450-01	5.55959280-01	8.56043920-01	1.36212170-02	2.16902930-02	3.62842900-02	5.66464550-02			

GREY ABSORPTION COEFFICIENTS CONTINUED

.30460 CONTINUED		
THETA =		
DENSITY	2.5363160-06	6.92747740-07
KAPPA(P)	7.84712-20+03	1.03943738+04
KAPPA(R)	9.57456600+02	1.33316550+03
12 DENSITIES		
THETA =		
DENSITY	3.91353450+02	1.27347605-02
KAPPA(P)	7.74735845+02	1.16225960+03
KAPPA(R)	1.16950407+02	1.80952430+02
DENSITY	1.32393795+06	3.71357770-07
KAPPA(P)	1.39228756+06	8.91419280+03
KAPPA(R)	2.84829070+03	1.87974220+03
12 DENSITIES		
THETA =		
DENSITY	3.3509470-02	1.05975759-02
KAPPA(P)	2.24414510+03	3.43241220+03
KAPPA(R)	4.45101900+02	6.95639330+02
DENSITY	9.10363410-07	2.93408530-07
KAPPA(P)	5.04102160+03	1.85472130+03
KAPPA(R)	4.35599550+03	4.93501300+02
12 DENSITIES		
THETA =		
DENSITY	2.60210490-02	8.51224150-03
KAPPA(P)	5.52301900+03	8.56577550+03
KAPPA(R)	1.33496450+03	2.13713100+03
DENSITY	7.86065780-07	2.60151950-07
KAPPA(P)	1.41473600+03	4.93523510+02
KAPPA(R)	4.06566210+02	1.39159660+02
12 DENSITIES		
THETA =		
DENSITY	4.26249490-02	8.93501600-03
KAPPA(P)	1.23489464+04	1.94401230+04
KAPPA(R)	3.36862430+03	5.44890480+03
DENSITY	7.07489210-07	2.34361750-07
KAPPA(P)	5.16987000+02	1.60548950+02
KAPPA(R)	1.67562430+02	4.98520670+01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = .5102		DENSITIES											
DENSITY	1.77328370-02	4.56777070-03	9.44595210-04	2.83665780-04	6.98996450-05	2.22048470-05	6.52675940-06	2.15507000-06					
KAPPA(P)	2.55552990+04	3.64197120+04	4.54763990+04	3.55466040+04	1.69850680+04	6.75285000+03	2.18799300+03	7.03082320+02					
KAPPA(R)	7.45581010+03	1.13218252+04	1.37535544+04	1.04222676+04	4.87300360+03	1.92382360+03	6.21173220+02	2.13667500+02					
DENSITY	5.39486740-07	2.10422340-07	6.21012430-08	2.04476070-08	6.98996450-05	2.22048470-05	6.52675940-06	2.15507000-06					
KAPPA(P)	2.66233000+02	9.00621480+01	2.93193330+01	1.03107400+01	1.69850680+04	6.75285000+03	2.18799300+03	7.03082320+02					
KAPPA(R)	6.56271000+01	2.23779130+01	6.44634080+00	2.34833500+00	4.87300360+03	1.92382360+03	6.21173220+02	2.13667500+02					
THETA = .5610		DENSITIES											
DENSITY	1.34018478-02	3.23193110-03	7.445003700-04	2.14903420-04	6.17053500-05	2.01019260-05	5.94714110-06	1.95401770-06					
KAPPA(P)	4.60020440+04	5.90594590+04	6.21944900+04	2.81028540+04	9.89910810+03	3.60513400+03	1.15729410+03	6.17034920+02					
KAPPA(R)	1.41449074+04	1.79790430+04	1.43537992+04	7.55209260+03	2.82467880+03	1.02810230+03	3.24663710+02	1.11917272+02					
DENSITY	3.77071330-07	1.89740070-07	5.61016840-08	1.83583390-08	6.17053500-05	2.01019260-05	5.94714110-06	1.95401770-06					
KAPPA(P)	1.37127330+02	4.87458340+01	1.50521050+01	6.50958240+00	9.89910810+03	3.60513400+03	1.15729410+03	6.17034920+02					
KAPPA(R)	3.87187330+01	1.20138407+01	3.91634450+00	1.54894400+00	2.82467880+03	1.02810230+03	3.24663710+02	1.11917272+02					
THETA = .6019		DENSITIES											
DENSITY	9.73575410-03	2.47258770-03	6.23061320-04	1.93614400-04	5.61131730-05	1.83882270-05	5.42062220-06	1.77857163-06					
KAPPA(P)	7.03657350+04	6.70973560+04	3.37699160+04	1.71184120+04	5.87146760+03	2.11136510+03	6.91871320+02	2.49183400+02					
KAPPA(R)	2.22369630+04	2.00302170+04	1.15646884+04	4.94788730+03	1.70962610+03	6.11949590+02	1.93916940+02	6.76447670+01					
DENSITY	5.25611550-07	1.72546360-07	5.34693340-08	1.61992650-08	5.61131730-05	1.83882270-05	5.42062220-06	1.77857163-06					
KAPPA(P)	8.12710730+01	3.14695370+01	1.40154650+01	8.93574910+00	5.87146760+03	2.11136510+03	6.91871320+02	2.49183400+02					
KAPPA(R)	2.18559870+01	8.36779130+00	3.35976150+00	1.74872332+00	1.70962610+03	6.11949590+02	1.93916940+02	6.76447670+01					
THETA = .6427		DENSITIES											
DENSITY	7.53135730-03	2.05929820-03	5.53073320-04	1.74134970-04	5.14953010-05	1.68476390-05	4.96399350-06	1.63119130-06					
KAPPA(P)	8.50414500+04	8.10348300+04	2.31302260+04	1.11833339+04	3.72696650+03	1.35002710+03	4.40623140+02	1.61785270+02					
KAPPA(R)	4.41449074+04	1.93111131+04	9.11305500+03	3.34007940+03	1.12938660+03	4.05804440+02	1.31017130+02	4.82594900+01					
DENSITY	4.46437440-07	1.33001340-07	4.44444440-08	1.33001340-08	5.14953010-05	1.68476390-05	4.96399350-06	1.63119130-06					
KAPPA(P)	8.17533400+01	3.31306000+01	2.24444440+01	1.70453318+01	3.72696650+03	1.35002710+03	4.40623140+02	1.61785270+02					
KAPPA(R)	1.76147430+01	8.26715130+00	4.39053010+00	2.45852240+00	1.12938660+03	4.05804440+02	1.31017130+02	4.82594900+01					
THETA = .6836		DENSITIES											
DENSITY	6.23965760-03	1.80824239-03	5.02733850-04	1.61974400-04	4.74022240-05	1.55243630-05	4.58234380-06	1.50111863-06					
KAPPA(P)	8.62409140+04	4.94762370+04	2.01200060+04	7.63512400+03	2.53601690+03	9.16076570+02	3.11970910+02	1.35493000+02					
KAPPA(R)	2.93241420+04	1.57599927+04	6.12975430+03	2.39955840+03	8.15849540+02	2.90374650+02	1.02403322+02	4.20163400+01					

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = .6836 CONTINUED			12 DENSITIES		
DENSITY	4.3727650-07	1.39514123-07	3.87942560-08	1.1711381-08	
KAPPA(P)	7.3405130+01	5.40343510+01	8.29243900+01	3.31045260+01	
KAPPA(R)	1.9229550+01	1.11450714+01	7.42061900+00	5.35097400+00	
THETA = .86400			12 DENSITIES		
DENSITY	1.40017471+01	4.47933140+00	1.06719070+00	2.94690840+01	5.37436460-04
KAPPA(P)	6.6565120+03	6.59904350+03	6.50604380+03	6.02853900+03	3.52430520+03
KAPPA(R)	2.53350450+02	2.52370920+02	2.52307440+02	2.51947310+02	2.26166160+02
DENSITY	7.03579450+00	1.60993400-07	1.03725800-08	9.74891460-10	
KAPPA(P)	1.43306170+03	4.71297710+02	5.94319320+01	5.72418390+00	
KAPPA(R)	1.5337750+02	5.46406530+01	7.38240880+00	7.54686970-01	
THETA = 1.10000			12 DENSITIES		
DENSITY	1.77573457+03	5.24595390+01	1.46655610-01	3.144073470-02	5.45422410-04
KAPPA(P)	3.05359700+04	3.00104200+04	2.97036690+04	2.76422280+04	6.40859160-05
KAPPA(R)	1.86278670+03	1.75069960+03	1.75441360+03	1.73555050+03	1.45336280+04
DENSITY	1.9746030-06	1.46140120-07	1.40717034-08	1.36677496-09	1.18015360+03
KAPPA(P)	4.88061750+03	3.00230590+02	2.69987340+01	2.62141430+00	
KAPPA(R)	3.33742570+02	3.75712810+01	3.50925930+00	3.99660840-01	
THETA = 1.38000			12 DENSITIES		
DENSITY	4.45014080-01	1.23905419-01	4.29642650-02	7.20391980-03	1.65299450-04
KAPPA(P)	7.6705250+04	7.38654080+04	7.25947140+04	6.87360040+04	4.03804060+04
KAPPA(R)	4.3733550+03	7.55450930+03	7.44243280+03	7.04927440+03	4.24119340+03
DENSITY	2.07967270-06	1.97447180-07	1.90347430-08	1.55482949-09	2.96889170-05
KAPPA(P)	1.71833400+03	1.50310920+02	1.53539070+01	2.83856880+00	1.77508720+04
KAPPA(R)	2.86379740+02	2.29307770+01	3.11968740+00	7.53097430-01	2.04286570+03
THETA = 1.50000			12 DENSITIES		
DENSITY	3.00201410-01	8.23999880-02	2.80497460-02	4.07351420-03	1.36049750-04
KAPPA(P)	9.89925010+04	5.44175630+04	9.14639310+04	8.12836310+04	4.05463040+04
KAPPA(R)	1.36920400+04	1.20041501+04	1.17721277+04	1.07438625+04	1.63797312+04
DENSITY	2.29609000-06	2.20515040-07	1.97147260-08	1.36273002-09	2.12975010+03
KAPPA(P)	1.37913450+03	1.26775774+02	1.71733710+01	3.95760470+00	2.88716990-05
KAPPA(R)	2.25585500+02	2.44444860+01	4.73887600+00	1.17131492+00	1.6094170-04
					5.18201338+03
					7.69553090+02

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 4.25000		12 DENSITIES						
DENSITY	9.70039E-02	2.70743090-02	1.00996959-02	2.24286770-03	5.03322400-04	1.46224130-04	4.02621030-05	1.23210676-05
KAPPA(P)	1.667081E+05	1.41874760+05	1.23722931+05	8.65605880+04	4.71978780+04	2.21390850+04	8.25705100+03	3.46805950+03
KAPPA(R)	7.14247600+04	5.69369610+04	4.48446641+04	3.25982635+04	1.68539400+04	7.66760770+03	3.08374450+03	1.37826490+03
THETA = 4.50000		12 DENSITIES						
DENSITY	3.16201E-02	2.27357170-07	2.06572400-08	1.96671770-09				
KAPPA(P)	1.44059900+03	2.20392470+02	2.21531560+01	2.46640300+00				
KAPPA(R)	5.39406090+02	5.74278830+01	5.47542560+00	7.70750930-01				
THETA = 5.00000		12 DENSITIES						
DENSITY	9.23291E-02	2.45433050-02	1.01538647-02	2.65625610-03	6.49957649-04	1.79300040-04	4.47956290-05	1.34034290-05
KAPPA(P)	1.55542500+03	1.33310110+05	1.16331592+05	9.40893280+04	6.94040120+04	3.67465610+04	1.33269022+04	4.46822870+03
KAPPA(R)	1.17113E+05	9.52633020+04	7.70184230+04	4.72732500+04	2.14356330+04	8.43883930+03	2.77942660+03	1.04350260+03
THETA = 5.00001		12 DENSITIES						
DENSITY	3.74479E-05	3.06392160-07	2.60382340-08	2.39903350-09				
KAPPA(P)	1.30758E+05	1.87327790+02	2.27223720+01	2.69109450+00				
KAPPA(R)	3.85245E+04	6.05627450+01	6.42619080+00	8.95509000-01				
THETA = 5.00002		12 DENSITIES						
DENSITY	4.75303E-02	4.75430E-02	1.17104931-02	3.11430240-03	7.62719660-04	2.19957720-04	5.71392150-05	1.69270110-05
KAPPA(P)	1.47428E+05	1.31557580+05	1.20401004+05	1.00207667+05	6.08234620+04	3.52105130+04	1.28844880+04	4.54645590+03
KAPPA(R)	1.09409E+05	9.40422970+04	7.76448080+04	4.60599910+04	2.49143670+04	1.30044795+04	4.74036730+03	1.65537820+03
THETA = 7.00000		12 DENSITIES						
DENSITY	4.62377E-05	3.95505970-07	3.49446690-08	3.40677430-09				
KAPPA(P)	1.34277E+05	1.45813720+02	1.57336800+01	1.75270970+00				
KAPPA(R)	4.80222E+04	5.42565170+01	5.20161930+00	6.01414430-01				
THETA = 7.00001		12 DENSITIES						
DENSITY	9.94456E-02	3.25561170-02	1.41194786-02	3.80423100-03	9.47873080-04	2.74047260-04	7.27115770-05	2.19751100-05
KAPPA(P)	1.24051E+05	1.03423480+05	1.00609677+05	9.37231000+04	5.90830840+04	2.72579350+04	9.15908420+03	2.99026770+03
KAPPA(R)	7.63970E+04	7.13105750+04	6.57950520+04	5.21719310+04	2.89261100+04	1.25505515+04	4.09333940+03	1.43849100+03
THETA = 10.00000		12 DENSITIES						
DENSITY	0.02213E-06	5.60252500-07	5.63096460-08	5.62637800-09				
KAPPA(P)	4.32269E+04	7.77633260+01	6.62519620+00	7.27308160-01				
KAPPA(R)	3.83168E+04	2.47515960+01	2.00541090+00	3.33644240-01				
THETA = 10.00005		12 DENSITIES						
DENSITY	1.216237E-01	4.09164450-02	1.80440780-02	5.03475730-03	1.27932880-03	3.77341100-04	1.03388175-04	3.29036030-05
KAPPA(P)	8.63444E+04	7.89103750+04	7.40503070+04	6.10348300+04	3.27517200+04	1.27492776+04	5.51508040+03	1.02487910+03
KAPPA(R)	3.61360E+04	3.54026790+04	3.37231790+04	2.71444070+04	1.63573051+04	7.42323310+03	2.18941560+03	5.05110040+02

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA =	10.00005	CONTINUED	
DENSITY	9.70082410-06	9.61568560-07	9.60609380-08
KAPPA(P)	2.71883620-02	2.35519820-01	2.30160100-00
KAPPA(R)	1.30409560-02	9.37870270-00	9.98400850-01
			9.60578940-09
			3.42085050-01
			2.56932900-01

21	DIAM/SCAT	FE-16A	THETA(50-10000)	10	FREQ	CI/PCT	5-20-67	TRY 2	MATERL = 1026	NR = 720
GREY ABSORPTION COEFFICIENTS										
10 TEMPERATURES										
13 DENSITIES										
THETA =	50.0000									
DENSITY	4.2342460-01	1.63902920-01	3.22322780-02	6.13555960-03	1.13376195-03	2.11691190-04	3.71905790-05	6.22323110-06		
KAPPA(P)	2.23485497-04	6.06176130-03	2.61292810-03	8.40121020-02	2.68516320-02	6.53582010-01	1.23571089-01	2.10194200-00		
KAPPA(R)	2.91357650-03	2.69803220-03	1.19982730-03	4.66248590-02	1.40382650-02	3.12301810-01	6.05377990-00	1.03249120-00		
DENSITY	4.54951700-07	1.23975740-07	1.45938164-08	1.51633697-09	1.36368560-10					
KAPPA(P)	4.14743367-01	1.53669850-01	1.20946255-01	1.19276733-01	1.24381476-01					
KAPPA(R)	2.64168150-01	1.81135330-01	1.19747610-01	1.17369757-01	1.22161178-01					
THETA =	69.9998									
13 DENSITIES										
DENSITY	1.32450805-00	2.60314430-01	4.85779780-02	9.03612380-03	1.71016921-03	3.32271920-04	6.08435940-05	1.01734422-05		
KAPPA(P)	4.22362940-03	4.37305430-03	1.57822220-03	5.86022950-02	1.31936130-02	2.62545940-01	4.71723100-00	9.36977080-01		
KAPPA(R)	2.24394770-03	1.80619610-03	1.13142470-03	3.92525303-02	8.42356260-01	1.64469970-01	2.01204650-00	6.07981200-01		
DENSITY	1.51940767-06	1.87444450-07	2.06725330-08	2.03436980-09	1.78784500-10					
KAPPA(P)	2.70361310-01	1.54130590-01	1.40101790-01	1.47291300-01	1.57145370-01					
KAPPA(R)	2.20535350-01	1.46102030-01	1.37071440-01	1.44528970-01	1.54279710-01					
THETA =	99.9998									
12 DENSITIES										
DENSITY	4.04181440-01	7.59531330-02	1.45211222-02	2.80199120-03	5.36661520-04	9.33027520-05	1.47865880-05	2.10370620-06		
KAPPA(P)	2.70212550-03	9.79419420-02	2.23482570-02	5.54007950-01	1.46444287-01	3.72464100-00	9.38554600-01	3.06994020-01		
KAPPA(R)	4.34337690-02	4.41512790-02	1.35262440-02	3.54642140-01	8.97061270-00	2.03864680-00	5.12136490-01	2.26430250-01		
DENSITY	2.54954700-07	2.86157120-08	2.95242260-09	2.75423660-10						
KAPPA(P)	1.87210930-01	1.71463020-01	1.73039560-01	1.74129670-01						
KAPPA(R)	1.73503410-01	1.67132350-01	1.69732940-01	1.70947980-01						
THETA =	149.9995									
11 DENSITIES										
DENSITY	1.27654420-01	2.37112140-02	4.35502480-03	8.00346340-04	1.37133870-04	2.22570890-05	3.33422720-06	4.30215370-07		
KAPPA(P)	6.22406410-02	1.93083740-02	6.27531620-01	1.47080354-01	3.58398740-00	8.41024150-01	2.84712610-01	1.88477990-01		
KAPPA(R)	2.10403600-02	7.77650510-01	2.30007770-01	5.94047230-00	1.40200071-00	4.16320280-01	2.14954050-01	1.76134570-01		
DENSITY	3.05496440-03	5.37009660-09	5.05410620-10							
KAPPA(P)	1.75287600-01	1.74456130-01	1.74296390-01							
KAPPA(R)	1.72419440-01	1.71413070-01	1.71131010-01							
THETA =	224.9990									
13 DENSITIES										
DENSITY	3.92392440-00	1.09257642-00	1.98633450-01	3.61042610-02	6.71507020-03	1.29099893-03	2.33362630-04	3.94995990-05		
KAPPA(P)	2.65292730-03	1.41671310-03	4.21520440-02	1.35154150-02	3.67659060-01	7.66675910-00	1.50610235-00	3.90411370-01		
KAPPA(R)	1.04455700-03	3.37003680-02	1.53720550-02	4.94594680-01	1.36395677-01	2.93428450-00	6.54694530-01	2.63312440-01		

GRAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 224.99990 CONTINUED

DENSITY 6.0718958-06 7.39236370-07 9.28500670-08 9.84522500-09 9.28491540-10
 KAPPA(P) 2.09443970-01 1.79166810-01 1.74791570-01 1.74335370-01 1.74286280-01
 KAPPA(R) 1.93673600-01 1.77123330-01 1.71944760-01 1.71206130-01 1.71124990-01

THETA = 380.00012

13 DENSITIES

DENSITY 9.50176090-00 1.74153446-00 3.20625020-01 6.00113410-02 1.18455620-02 2.35090288-03 8.31371450-04 7.33868920-05
 KAPPA(P) 1.74180060-03 7.94118800-02 2.43910980-02 5.74248330-01 1.18688932-01 2.42358358-00 5.76387610-01 2.41932460-01
 KAPPA(R) 6.49491900-02 3.23804510-02 1.33963220-02 3.09850850-01 5.70420700-00 1.17094701-00 3.86801630-01 2.25634690-01

DENSITY 1.14277125-05 1.45590183-06 1.72349770-07 1.02161030-08 1.67668032-09
 KAPPA(P) 1.84791490-01 1.75611700-01 1.74568510-01 1.74346720-01 1.79280260-01
 KAPPA(R) 1.84278070-01 1.72635820-01 1.71417870-01 1.72158790-01 1.76020120-01

THETA = 699.99993

13 DENSITIES

DENSITY 1.52232306-01 2.84563970-00 5.43006710-01 1.04144702-01 2.09923130-02 9.18569300-03 7.48328670-04 1.30059968-04
 KAPPA(P) 9.07516710-02 4.37739600-02 9.12446200-01 1.84539970-01 3.84357140-00 8.68383910-01 3.09619230-01 2.02317710-01
 KAPPA(R) 1.84038276-02 1.03399998-02 3.59196670-01 8.73971830-00 1.99729683-00 5.62415880-01 2.57779680-01 1.89825518-01

DENSITY 1.96927310-05 2.49917134-06 2.86341700-07 3.01992130-08 2.63952280-09
 KAPPA(P) 1.85123140-01 1.84459900-01 1.87534590-01 1.86636190-01 1.88784710-01
 KAPPA(R) 1.77425410-01 1.80021490-01 1.83485500-01 1.85180730-01 1.85350250-01

THETA = 699.99976

13 DENSITIES

DENSITY 2.34615060-01 4.53439160-00 8.44544180-01 1.74580730-01 3.45733320-02 6.81631690-03 1.22314606-03 2.02495668-04
 KAPPA(P) 5.10036300-02 1.52332540-02 3.55074560-01 7.74098520-00 2.01232600-00 7.48721040-01 3.73456890-01 2.36073790-01
 KAPPA(R) 7.05989200-01 2.67415610-01 9.08603610-00 2.37867610-00 7.11076190-01 3.20295590-01 2.16307430-01 1.92377430-01

THETA = 994.99967

13 DENSITIES

DENSITY 3.04488030-05 3.97942510-06 4.70340040-07 4.93716600-08 4.70316570-09
 KAPPA(P) 1.97460440-01 1.90006110-01 1.88903190-01 1.88613680-01 1.88811140-01
 KAPPA(R) 1.87085410-01 1.845943370-01 1.83524840-01 1.83399930-01 1.83396960-01

DENSITY 3.96113610-01 7.61190120-00 1.49044135-00 2.90300700-01 5.63252710-02 1.10361392-02 2.01263370-03 3.41437140-04
 KAPPA(P) 4.29455010-02 7.99932260-01 1.79822460-01 6.20272060-00 2.31129750-00 7.91798810-01 3.85382568-01 2.80533280-01
 KAPPA(R) 4.14739670-01 1.41736413-01 3.76977300-00 1.07874630-00 4.48175858-01 2.73799730-01 2.12287448-01 1.95181570-01

DENSITY 5.25106300-05 6.82601220-06 8.03057128-07 8.53240100-08 8.03049318-09
 KAPPA(P) 1.91305020-01 1.89164936-01 1.89045220-01 1.89045220-01 1.89045220-01
 KAPPA(R) 1.88391138-01 1.86068940-01 1.85967198-01 1.85961240-01 1.85960688-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 1099.99750									
13 DENSITIES									
DENSITY	6.90218450+01	1.35637255+01	2.03755700+00	5.00024000+01	1.00528376+01	2.00771800+02	3.60870430+03	6.27016300+00	
KAPPA(P)	1.41616450+02	5.00804190+01	1.62753750+01	4.63279900+00	1.19455148+00	3.78115350+01	2.18275110+01	1.93294500+01	
KAPPA(R)	3.96932230+01	1.27307600+01	3.26861050+00	9.22924600+01	4.02195170+01	2.63061890+01	2.08529200+01	1.98748210+01	
DENSITY									
DENSITY	3.64623350+05	1.25400802+05	1.47529091+06	1.56759570+07	1.47529930+08				
KAPPA(P)	1.90914030+01	1.90711390+01	1.90549700+01	1.90691460+01	1.90681070+01				
KAPPA(R)	1.80893100+01	1.80794340+01	1.80781310+01	1.80779900+01	1.80779610+01				
THETA = 2299.99070									
13 DENSITIES									
DENSITY	1.23156076+02	2.30501280+01	4.06663020+00	9.24270160+01	1.04418060+01	3.60449140+02	6.77920800+03	1.15188334+03	
KAPPA(P)	4.80528170+01	2.85102590+01	7.59902800+00	1.73302472+00	4.77465470+01	2.35475360+01	1.99092650+01	1.90808770+01	
KAPPA(R)	3.10822500+01	1.08443064+01	2.63210700+00	7.70400780+01	3.28401300+01	2.15919530+01	1.09467070+01	1.93515800+01	
DENSITY									
DENSITY	1.77212140+04	2.30376600+05	2.71030330+06	2.87669990+07	2.71030390+08				
KAPPA(P)	1.94280030+01	1.94202340+01	1.94192760+01	1.94191390+01	1.94191400+01				
KAPPA(R)	1.93196190+01	1.93161230+01	1.93156990+01	1.93154410+01	1.93154410+01				
THETA = 2499.99990									
13 DENSITIES									
DENSITY	1.42974730+02	2.77594020+01	5.45130090+00	1.09194417+00	2.15943900+01	4.31755040+02	7.93400750+03	1.34910082+03	
KAPPA(P)	6.80501700+01	2.25840390+01	5.30503820+00	1.20062144+00	3.68173310+01	2.17627350+01	1.97007890+01	1.95457360+01	
KAPPA(R)	4.33031030+01	8.49642060+00	1.95924361+00	5.34644030+01	2.68040280+01	2.03480530+01	1.95358100+01	1.94207520+01	
DENSITY									
DENSITY	2.07533100+04	2.69820160+05	3.17434240+06	3.37274060+07	3.17434330+08				
KAPPA(P)	1.95097100+01	1.95039920+01	1.95032310+01	1.95033340+01	1.95033340+01				
KAPPA(R)	1.94039050+01	1.94011950+01	1.94008370+01	1.94007480+01	1.94007780+01				
THETA = 2799.99400									
13 DENSITIES									
DENSITY	1.63227350+02	3.18905900+01	6.28039940+00	1.24766111+00	2.49135840+01	4.98103240+02	9.15566940+03	1.55444170+03	
KAPPA(P)	5.69469100+01	1.74645520+01	4.01773370+00	9.65843560+01	3.12148200+01	2.09454240+01	1.96545950+01	1.94979910+01	
KAPPA(R)	1.67512100+01	6.47515790+00	1.54332841+00	4.61066770+01	2.45154410+01	2.01784290+01	1.95322540+01	1.94615000+01	
DENSITY									
DENSITY	4.39452460+04	3.11287130+05	3.66222390+06	3.89111500+07	3.66222490+08				
KAPPA(P)	1.94769700+01	1.94736670+01	1.94732390+01	1.94731610+01	1.94731610+01				
KAPPA(R)	1.94543590+01	1.94532120+01	1.94530760+01	1.94530560+01	1.94530560+01				
THETA = 3000.00100									
13 DENSITIES									
DENSITY	1.85947750+02	3.62277700+01	7.14905370+00	1.42127504+00	2.43855490+01	5.67541790+02	1.04321071+02	1.77343474+03	
KAPPA(P)	5.37822610+01	1.45622415+01	3.20550070+00	7.65773070+01	2.82114290+01	2.86580730+01	1.94340400+01	1.95437700+01	
KAPPA(R)	1.37773366+01	4.65735170+00	1.11892101+00	3.49730640+01	2.30895510+01	2.00154400+01	1.95421030+01	1.95070150+01	

GREY ABSORPTION COEFFICIENTS CONTINUED

TMETA = 3000.00400 CONTINUED			13 DENSITIES		
DENSITY	2.72435920-04	3.54687010-05	4.17277190-06	4.43357260-07	4.17277370-08
KAPPA(P)	1.95319010-01	1.95284260-01	1.95279580-01	1.95278990-01	1.95278990-01
KAPPA(R)	1.94971060-01	1.94955290-01	1.94953150-01	1.94952950-01	1.94952760-01
TMETA = 3400.00000			13 DENSITIES		
DENSITY	4.22616010-02	4.35697400-01	6.61710330-00	1.71440775+00	3.42461850-01
KAPPA(P)	4.24357640-01	1.04201852+01	2.31576290+00	5.84120600-01	2.53210530-01
KAPPA(R)	8.32713100+00	2.69516090+00	7.54616200-01	3.10900300-01	2.16917540-01
TMETA = 3800.00000			13 DENSITIES		
DENSITY	3.29103440-04	4.27936870-05	5.03458280-06	5.34924400-07	5.03458370-08
KAPPA(P)	1.95902050-01	1.95935040-01	1.95932510-01	1.95932120-01	1.95932120-01
KAPPA(R)	1.95442420-01	1.95444370-01	1.95441300-01	1.95441281-01	1.95441281-01
TMETA = 4994.99670			10 DENSITIES		
DENSITY	3.92145400+02	7.72306940+01	1.53447283+01	3.04633040+00	6.10684330-01
KAPPA(P)	1.66583400+01	3.62899060+00	9.27543170-01	3.14449740-01	2.13271980-01
KAPPA(R)	1.74394519+00	5.66216300-01	3.01162590-01	2.21325460-01	2.00413810-01
TMETA = 5870.99400			13 DENSITIES		
DENSITY	5.87049100-04	7.63143950-05	1.44727494-05	1.50023029-06	1.44727410-07
KAPPA(P)	1.94963460-01	1.93644690-01	1.93657910-01	1.93657910-01	1.93657910-01
KAPPA(R)	1.94762150-01	1.94757510-01	1.93621700-01	1.93621700-01	1.93621700-01
TMETA = 6994.99650			13 DENSITIES		
DENSITY	6.45964700+02	1.27731315+02	2.54052530+01	5.06218380+00	1.01157251+00
KAPPA(P)	7.34033130+00	1.50115208+00	4.64959630-01	2.37374070-01	2.01033640-01
KAPPA(R)	0.26364610-01	3.02741490-01	2.25349280-01	2.02255000-01	1.93615360-01
TMETA = 9994.99400			13 DENSITIES		
DENSITY	4.72440450-04	1.26418350-04	1.44727494-05	1.50023029-06	1.44727410-07
KAPPA(P)	1.93644690-01	1.93644690-01	1.93657910-01	1.93657910-01	1.93657910-01
KAPPA(R)	1.93621700-01	1.93621700-01	1.93621700-01	1.93621700-01	1.93621700-01
TMETA = 9994.99400			13 DENSITIES		
DENSITY	1.04944450+03	2.16915730+02	4.32744220+01	8.44292440+00	1.72720292+00
KAPPA(P)	1.83567464+00	4.92213600-01	2.43174490-01	1.99397490-01	1.91801740-01
KAPPA(R)	2.50715730-01	2.10407320-01	1.96761600-01	1.92072490-01	1.91860060-01
TMETA = 16004.2019-03			13 DENSITIES		
DENSITY	1.60042019-03	2.15855360-04	2.53947030-05	2.69818630-06	2.53947070-07
KAPPA(P)	1.89184410-01	1.89182900-01	1.89182710-01	1.89182710-01	1.89182710-01
KAPPA(R)	1.90992520-01	1.90992520-01	1.90992520-01	1.90992520-01	1.90992520-01

0		JARE DIANE LIVEWORE IRON DATA, BINA IRONIC		APRIL 9, 1966		MATERL = 3026		MTE # 010	
GLEY ASSUMPTION COEFFICIENTS		JA TEMPRATINGS							
THETA = 69.99+05		7 DENSITIES							
DENSITY	1.00000+07+01	1.99999961+00	1.000000000+00	1.999999580-01	9.99995100-02	2.00000600-02	1.00000020-02		
KAPPA(P)	2.959980+00+03	4.9870000+00+03	5.55797930+03	4.58098790+03	3.81799200+03	1.47800720+03	7.81996270+02		
KAPPA(R)	2.959980+00+03	4.9870000+00+03	5.55797930+03	4.58098790+03	3.81799200+03	1.47800720+03	7.81996270+02		
THETA = 75.00+14		7 DENSITIES							
DENSITY	1.00000+07+01	1.99999961+00	1.000000000+00	1.999999580-01	9.99995100-02	2.00000600-02	1.00000020-02		
KAPPA(P)	3.07100+00+03	3.94301090+03	3.34001290+03	2.33199620+03	1.77500750+03	6.59802110+02	3.47999130+02		
KAPPA(R)	3.07100+00+03	3.94301090+03	3.34001290+03	2.33199620+03	1.77500750+03	6.59802110+02	3.47999130+02		
THETA = 94.99+98		7 DENSITIES							
DENSITY	1.00000+07+01	1.99999961+00	1.000000000+00	1.999999580-01	9.99995100-02	2.00000600-02	1.00000020-02		
KAPPA(P)	3.09799+00+03	2.8540090+03	2.29000650+03	1.40499630+03	1.05699990+03	3.73699740+02	1.969999350+02		
KAPPA(R)	3.09799+00+03	2.8540090+03	2.29000650+03	1.40499630+03	1.05699990+03	3.73699740+02	1.969999350+02		
THETA = 150.00+59		7 DENSITIES							
DENSITY	1.00000+07+01	1.99999961+00	1.000000000+00	1.999999580-01	9.99995100-02	2.00000600-02	1.00000020-02		
KAPPA(P)	2.61298+00+03	1.5013743+03	1.55200040+03	6.97498020+02	4.81102330+02	1.50000600+02	7.729994920+01		
KAPPA(R)	2.61298+00+03	1.5013743+03	1.55200040+03	6.97498020+02	4.81102330+02	1.50000600+02	7.729994920+01		
THETA = 200.00+22		7 DENSITIES							
DENSITY	1.00000+07+01	1.99999961+00	1.000000000+00	1.999999580-01	9.99995100-02	2.00000600-02	1.00000020-02		
KAPPA(P)	2.11900+00+03	1.58799960+03	1.24200420+03	5.07501180+02	2.83899390+02	8.86698540+01	3.899999380+01		
KAPPA(R)	2.11900+00+03	1.58799960+03	1.24200420+03	5.07501180+02	2.83899390+02	8.86698540+01	3.899999380+01		
THETA = 299.99+25		7 DENSITIES							
DENSITY	1.00000+07+01	1.99999961+00	1.000000000+00	1.999999580-01	9.99995100-02	2.00000600-02	1.00000020-02		
KAPPA(P)	9.44900+00+02	7.63001460+02	6.25999730+02	2.10399980+02	1.07499906+02	1.86799350+01	8.11001710+00		
KAPPA(R)	9.44900+00+02	7.63001460+02	6.25999730+02	2.10399980+02	1.07499906+02	1.86799350+01	8.11001710+00		
THETA = 399.99+17		7 DENSITIES							
DENSITY	1.00000+07+01	1.99999961+00	1.000000000+00	1.999999580-01	9.99995100-02	2.00000600-02	1.00000020-02		
KAPPA(P)	4.02380+00+02	2.58700220+02	1.70000260+02	4.91998260+01	2.55999390+01	5.25999460+00	2.68999998+00		
KAPPA(R)	4.02380+00+02	2.58700220+02	1.70000260+02	4.91998260+01	2.55999390+01	5.25999460+00	2.68999998+00		

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 500.00054			7 DENSITIES		
DENSITY	1.00000487+01	1.99999961+00	1.00000000+00	1.9999580-01	9.99995100-02
KAPPA(P)	1.77599710+02	9.82701150+01	6.36997020+01	1.7200100+01	9.36004390+00
KAPPA(R)	1.77599710+02	9.82701150+01	6.36997020+01	1.7200100+01	9.36004390+00
THETA = 699.99976			7 DENSITIES		
DENSITY	1.00000487+01	1.99999961+00	1.00000000+00	1.9999580-01	9.99995100-02
KAPPA(P)	4.78002070+01	1.81400090+01	1.01499621+01	2.71999490+00	1.58000023+00
KAPPA(R)	4.78002070+01	1.81400090+01	1.01499621+01	2.71999490+00	1.58000023+00
THETA = 799.99957			7 DENSITIES		
DENSITY	1.00000487+01	1.99999961+00	1.00000000+00	1.9999580-01	9.99995100-02
KAPPA(P)	3.12300625+01	1.04699577+01	5.84999020+00	1.63999959+00	1.01099994+00
KAPPA(R)	3.12300625+01	1.04699577+01	5.84999020+00	1.63999959+00	1.01099994+00
THETA = 1000.00068			7 DENSITIES		
DENSITY	1.00000487+01	1.99999961+00	1.00000000+00	1.9999580-01	9.99995100-02
KAPPA(P)	1.74200170+01	5.07400270+00	2.89999780+00	9.16000010-01	6.19000000-01
KAPPA(R)	1.74200170+01	5.07400270+00	2.89999780+00	9.16000010-01	6.19000000-01
THETA = 1499.99930			7 DENSITIES		
DENSITY	1.00000487+01	1.99999961+00	1.00000000+00	1.9999580-01	9.99995100-02
KAPPA(P)	1.02799771+01	2.34999920+00	1.39000034+00	5.3000140-01	3.84999980-01
KAPPA(R)	1.02799771+01	2.34999920+00	1.39000034+00	5.3000140-01	3.84999980-01
THETA = 1999.99900			7 DENSITIES		
DENSITY	1.00000487+01	1.99999961+00	1.00000000+00	1.9999580-01	9.99995100-02
KAPPA(P)	7.53003710+00	1.70599922+00	1.01999996+00	4.16000010-01	3.21001330-01
KAPPA(R)	7.53003710+00	1.70599922+00	1.01999996+00	4.16000010-01	3.21001330-01
THETA = 2500.00080			7 DENSITIES		
DENSITY	1.00000487+01	1.99999961+00	1.00000000+00	1.9999580-01	9.99995100-02
KAPPA(P)	3.22999310+00	8.65499910-01	5.75999770-01	3.06999240-01	2.649998790-01
KAPPA(R)	3.22999310+00	8.65499910-01	5.75999770-01	3.06999240-01	2.649998790-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THERIA = 3500.0000		7 DENSITIES	
DEMSITY	1.0000000000	1.0000000000	1.9999999999
KAPPA(P)	0.6900000000	2.0399999999	2.0100000000
KAPPA(R)	0.6900000000	2.0399999999	2.0100000000
THERIA = 4999.9999		7 DENSITIES	
DEMSITY	1.0000000000	1.0000000000	1.9999999999
KAPPA(P)	2.9400000000	1.9199999999	1.7499999999
KAPPA(R)	2.9400000000	1.9199999999	1.7499999999
THERIA = 7500.01270		7 DENSITIES	
DEMSITY	1.0000000000	1.0000000000	1.9999999999
KAPPA(P)	1.9299999999	1.7699999999	1.6999999999
KAPPA(R)	1.9299999999	1.7699999999	1.6999999999
THERIA = 9999.9999		7 DENSITIES	
DEMSITY	1.0000000000	1.0000000000	1.9999999999
KAPPA(P)	1.6400000000	1.5800000000	1.5800000000
KAPPA(R)	1.6400000000	1.5800000000	1.5800000000

16			DIANE/SCAT GRANITE-1A			TEMP(1-2250)			1 FREQ C1/KDP			2-16-67			MATERL = 1128			NX = 861				
GREY ABSORPTION COEFFICIENTS			21			TEMPERATURES																
THETA = 1.00000			13			DENSITIES																
DENSITY	9.64634e+00	-0.1	1.09456413	-0.1	8.511194e-03	6.27154300	-0.4	6.22404780	-0.5	8.94997430	-0.6	1.24496902	-0.6	1.38146670	-0.7	9.82785600	+0.2	2.48106720	+0.2	7.03545850	+0.1	
KAPPA(P)	1.21313217	+0.4	1.18916995	+0.4	1.08551172	+0.4	8.08056360	+0.3	3.73197170	+0.3	9.82785600	+0.2	2.48106720	+0.2	7.03545850	+0.1	1.10715153	+0.2	2.93934820	+0.1	7.97682900	+0.0
KAPPA(R)	6.74282510	+0.2	1.01114732	+0.3	9.28097570	+0.2	7.14716460	+0.2	3.61072210	+0.2	1.10715153	+0.2	2.93934820	+0.1	7.97682900	+0.0						
DENSITY	1.57126460	-0.3	1.67631180	-0.9	1.77262410	-1.0	1.84597250	-1.1	1.73309935	-1.2	1.73309935	-1.2	3.22825970	-0.2	2.95705890	-0.2						
KAPPA(P)	1.57975044	+0.1	3.13602160	+0.3	4.77266130	-0.1	7.63845370	-0.2	3.22825970	-0.2	1.73309935	-1.2	3.22825970	-0.2	2.95705890	-0.2						
KAPPA(R)	1.98499738	+0.0	4.57933350	-0.1	9.74900460	-0.2	3.97113990	-0.2	2.95705890	-0.2												
THETA = 1.50000			13			DENSITIES																
DENSITY	2.24553340	-0.1	2.64007460	-0.2	2.79690460	-0.3	3.43011020	-0.4	4.40026850	-0.5	6.25962670	-0.6	9.27549290	-0.7	1.40558790	-0.7	2.01973560	+0.3	4.32063240	+0.2	7.33910490	+0.1
KAPPA(P)	4.14009620	+0.4	3.26761220	+0.4	2.24430090	+0.4	1.31340304	+0.4	5.65107450	+0.3	2.01973560	+0.3	4.32063240	+0.2	7.33910490	+0.1	5.36235790	+0.2	1.51956980	+0.2	2.25210620	+0.1
KAPPA(R)	1.03182531	+0.4	6.87695560	+0.3	6.74603360	+0.3	4.01358030	+0.3	1.66628850	+0.3	6.25962670	-0.6	9.27549290	-0.7	1.40558790	-0.7						
DENSITY	2.04104400	-0.3	2.66849980	-0.9	2.87859100	-1.0	2.34020390	-1.1	1.91068390	-1.2	1.91068390	-1.2	5.15666060	-0.2	4.82477050	-0.2						
KAPPA(P)	1.07270433	+0.1	1.41147781	+0.0	2.47540270	-0.1	8.26621840	-0.2	5.15666060	-0.2	1.91068390	-1.2	5.15666060	-0.2	4.82477050	-0.2						
KAPPA(R)	3.03153400	+0.0	4.26540270	-0.1	1.61236896	-0.1	5.36058550	-0.2	4.82477050	-0.2												
THETA = 4.25000			13			DENSITIES																
DENSITY	1.19328489	-0.1	1.56334010	-0.2	1.91901164	-0.3	2.72109230	-0.4	4.45084620	-0.5	8.07191400	-0.6	1.36835676	-0.6	1.94104340	-0.7	1.20409430	+0.3	2.60114250	+0.2	6.52594550	+0.1
KAPPA(P)	7.84408404	+0.4	5.56579330	+0.4	3.57390770	+0.4	1.73353130	+0.4	5.41935940	+0.3	1.20409430	+0.3	2.60114250	+0.2	6.52594550	+0.1	6.39042130	+0.2	1.33717850	+0.2	2.71740510	+0.1
KAPPA(R)	4.98129420	+0.4	3.39658200	+0.4	1.98210920	+0.4	8.05746620	+0.3	2.50519010	+0.3	8.07191400	-0.6	1.36835676	-0.6	1.94104340	-0.7						
DENSITY	2.42336750	-0.3	2.90219070	-0.9	3.10057440	-1.0	3.11368270	-1.1	2.62775870	-1.2	2.62775870	-1.2	6.55180890	-0.2	6.31718170	-0.2						
KAPPA(P)	1.31304200	+0.1	1.85169991	+0.0	2.34020390	-1.1	8.45296650	-0.2	6.55180890	-0.2	2.62775870	-1.2	6.55180890	-0.2	6.31718170	-0.2						
KAPPA(R)	4.52275000	+0.0	6.45069430	-0.1	1.35494400	-0.1	6.82575650	-0.2	6.31718170	-0.2												
THETA = 5.40000			13			DENSITIES																
DENSITY	9.54239420	-0.2	1.40501670	-0.2	2.14979570	-0.3	3.59647910	-0.4	5.85604510	-0.5	9.60026350	-0.6	1.56972523	-0.6	2.42001980	-0.7	1.53783660	+0.3	3.00954160	+0.2	5.55105980	+0.1
KAPPA(P)	8.94029440	+0.4	5.55284040	+0.4	3.11664370	+0.4	1.67201000	+0.4	6.21158200	+0.3	1.53783660	+0.3	3.00954160	+0.2	5.55105980	+0.1	7.06155140	+0.2	1.32117000	+0.2	2.34435630	+0.1
KAPPA(R)	7.19128440	+0.4	4.56167370	+0.4	2.43517600	+0.4	1.02607673	+0.4	3.07608160	+0.3	9.60026350	-0.6	1.56972523	-0.6	2.42001980	-0.7						
DENSITY	3.32217490	-0.3	3.92519420	-0.9	4.48191720	-1.0	4.61608120	-1.1	3.97757000	-1.2	3.97757000	-1.2	7.79614360	-0.2	7.60670570	-0.2						
KAPPA(P)	2.36271480	+0.0	1.39442940	+0.0	2.26933940	-0.1	8.79726790	-0.2	7.79614360	-0.2	3.97757000	-1.2	7.79614360	-0.2	7.60670570	-0.2						
KAPPA(R)	3.74242340	+0.0	5.42256790	-0.1	1.39442940	-0.1	7.91501180	-0.2	7.60670570	-0.2												
THETA = 5.00000			13			DENSITIES																
DENSITY	1.01475366	-0.1	1.73274730	-0.2	2.71256670	-0.3	4.30893760	-0.4	7.30887690	-0.5	1.27144688	-0.5	2.09530800	-0.6	3.37346290	-0.7	1.09348700	+0.2	1.99443730	+0.2	3.30223900	+0.1
KAPPA(P)	6.51363530	+0.4	5.18445090	+0.4	3.32639630	+0.4	1.71219740	+0.4	4.96324460	+0.3	1.09348700	+0.2	1.99443730	+0.2	3.30223900	+0.1	5.91094520	+0.2	9.88224650	+0.1	1.58879183	+0.1
KAPPA(R)	7.14931030	+0.4	4.25910740	+0.4	2.27236150	+0.4	9.39292450	+0.3	2.77921580	+0.3												

RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.0000 CONTINUED			13 DENSITIES		
DENSITY	0.07563770-08	5.87876100-09	6.65461770-10	6.60189940-11	5.87808420-12
KAPPA(P)	5.86517210+00	9.53633750-01	1.87870030-01	1.00559972-01	9.28099898-02
KAPPA(R)	2.45508700+03	4.15216290-01	1.31013100-01	9.30345820-02	9.07177740-02
THETA = 7.0000			13 DENSITIES		
DENSITY	1.19963249-01	2.05367160-02	3.33289830-03	5.50464030-04	9.51732150-05
KAPPA(P)	7.95634410+04	5.02914260+04	3.16444260+04	1.37028870+04	3.15523720+03
KAPPA(R)	6.22360673+04	4.26140750+04	2.37070130+04	7.96733180+03	1.62284970+03
DENSITY	6.77575490-08	8.25266380-09	9.05078020-10	8.77991000-11	7.99527940-12
KAPPA(P)	5.20169210+00	8.24149770-01	1.86918080-01	1.19071157-01	1.12191392-01
KAPPA(R)	1.79346240+00	3.28534580-01	1.37434750-01	1.12945251-01	1.09899277-01
THETA = 10.0000			13 DENSITIES		
DENSITY	1.54582460-01	2.60062820-02	4.46014070-03	7.60231170-04	1.35302160-04
KAPPA(P)	6.90564150+04	4.22817140+04	2.51942220+04	9.56708570+03	2.26426610+03
KAPPA(R)	4.69345760+04	3.36790050+04	1.61136555+04	4.60926300+03	1.00533394+03
DENSITY	9.25020030-08	1.14901030-08	1.30259160-09	1.35079190-10	1.23154087-11
KAPPA(P)	3.32916590+00	5.74640000-01	1.76205730-01	1.25566350-01	1.23798255-01
KAPPA(R)	1.27902060+00	2.77204670-01	1.41529660-01	1.21067021-01	1.21619738-01
THETA = 15.0000			13 DENSITIES		
DENSITY	2.14093730-01	3.78476260-02	6.46847130-03	1.12101989-03	1.97471750-04
KAPPA(P)	5.27049410+04	3.46873350+04	1.93027710+04	6.59913550+03	1.58046900+03
KAPPA(R)	3.37403550+04	2.49049010+04	1.16065777+04	3.47128070+03	8.18479170+02
DENSITY	1.44691400-07	1.67140750-08	2.12853950-09	2.19021780-10	1.99067980-11
KAPPA(P)	1.62354391+03	3.41451380-01	1.59149380-01	1.39024930-01	1.40382270-01
KAPPA(R)	7.75671440-01	2.28297880-01	1.47756440-01	1.36467470-01	1.37846020-01
THETA = 22.4999			13 DENSITIES		
DENSITY	3.00306210-01	5.44090930-02	9.39981770-03	1.63198959-03	2.98681430-04
KAPPA(P)	4.01051870+04	2.79300918+04	1.32081571+04	4.52082120+03	9.26288100+02
KAPPA(R)	2.60320520+04	2.01060006+04	9.53058020+03	2.51949430+03	4.28587080+02
DENSITY	4.41610240-07	3.02140200-08	3.42135260-09	3.50377530-10	3.19039930-11
KAPPA(P)	9.71446160-01	2.69764218-01	1.67281580-01	1.57435570-01	1.40648908-01
KAPPA(R)	4.90281580-01	2.07156688-01	1.59425100-01	1.54226340-01	1.57690970-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 33.99998			13 DENSITIES		
DENSITY	0.5452790-01	0.10723760-02	1.43059103-02	2.59011270-03	4.07043450-04
KAPPA(P)	2.7306240+04	1.00057590-04	6.76850850+03	1.03377310+03	4.01935640+02
KAPPA(R)	1.5389176+04	1.09634785+04	4.61684490+03	1.12126290+03	2.24120070+02
DENSITY	3.9445510-07	4.96776830-08	5.66454130-09	5.00096790-10	5.32965270-11
KAPPA(P)	7.0334310-01	2.49788930-01	1.79488520-01	1.75578330-01	1.78506550-01
KAPPA(R)	3.04055190-01	1.99054420-01	1.70614100-01	1.71730480-01	1.75257320-01
THETA = 50.00000			13 DENSITIES		
DENSITY	7.0459970-01	1.24912099-01	2.27003710-02	4.20319230-03	7.92993300-04
KAPPA(P)	1.39068517+04	6.93044450+03	3.00806180+03	9.99713730+02	2.20233410+02
KAPPA(R)	5.51306730+03	4.36209140+03	2.40530810+03	7.50733790+02	1.40863670+02
DENSITY	6.5990410-07	8.23382840-08	9.40532450-09	9.04087820-10	9.25104100-11
KAPPA(P)	5.07045070-01	2.31975150-01	1.88652800-01	1.03037360-01	1.03317250-01
KAPPA(R)	3.04477220-01	1.98494670-01	1.02269300-01	1.74486730-01	1.79971100-01
THETA = 69.99998			13 DENSITIES		
DENSITY	1.0738445+00	1.08303730-01	3.44780980-02	6.44909780-03	1.21687890-03
KAPPA(P)	9.13196450+03	4.46290360+03	1.89194360+03	5.40554690+02	1.25797055+02
KAPPA(R)	4.33511730+03	2.05079430+03	1.40800590+03	4.09719560+02	7.63265580+01
DENSITY	1.00979033-06	1.30152370-07	1.51937770-08	1.60349565-09	1.49771560-10
KAPPA(P)	3.91241430-01	2.11257400-01	1.30196610-01	1.06441270-01	1.07521640-01
KAPPA(R)	2.61939430-01	1.94505270-01	1.34050250-01	1.03226350-01	1.04137230-01
THETA = 99.99998			13 DENSITIES		
DENSITY	1.63687740+00	2.93965460-01	5.34092140-02	9.04083440-03	1.07360677-03
KAPPA(P)	6.44695070+03	3.36020710+03	1.18195550+03	3.03497680+02	7.05400480+01
KAPPA(R)	3.40256480+03	2.12082390+03	8.34112210+02	1.9127940+02	3.58685900+01
DENSITY	1.60223062-06	2.16782800-07	2.53043430-08	2.66204750-09	2.47233000-10
KAPPA(P)	2.7958470-01	2.01215460-01	1.91204030-01	1.91302760-01	1.93940810-01
KAPPA(R)	2.3032210-01	1.94081280-01	1.80172530-01	1.08094650-01	1.90420780-01
THETA = 149.99995			13 DENSITIES		
DENSITY	2.65504400+00	4.00097440-01	8.79104150-02	1.67023400-02	3.26232220-03
KAPPA(P)	4.73418400+03	2.09160900+03	6.02595320+02	1.41328220+02	3.24061030+01
KAPPA(R)	2.43669460+03	1.30131160+03	4.05951940+02	8.63408620+01	1.09401000+01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 149.99995 CONTINUED

DENSITY 2.97400960-06 3.81664530-07 4.45172150-08 4.72045910-09 4.44171730-10
 KAPPA(P) 2.40651400-01 4.03524270-01 1.94802680-01 1.99342320-01 1.98311130-01
 KAPPA(R) 2.21442790-01 1.98162080-01 1.95200900-01 1.94769000-01 1.94707080-01

THETA = 226.99990 13 DENSITIES

DENSITY 4.37765470+00 8.10319950-01 1.52349880-01 2.95126590-02 5.78629000-03 1.13750892-03 2.06163730-04 3.47690470-05
 KAPPA(P) 2.84429010+03 8.78007330+02 2.50737340+02 6.13940510+01 1.93327760+01 3.63706480+00 9.53924700+01 3.39060500-01
 KAPPA(R) 1.29967080+03 5.00671370+02 1.97097380+02 6.66540660+01 8.99759200+00 1.92261451+00 5.38334960-01 2.60287330-01

DENSITY 5.33757600-06 8.93621100-07 8.15944720-08 8.66824190-09 8.14627710-10
 KAPPA(P) 2.24422000-01 2.01152890-01 1.98449160-01 1.96379180-01 1.98639230-01
 KAPPA(R) 2.10072100-01 1.97788500-01 1.95298910-01 1.94001340-01 1.95021200-01

THETA = 300.00012 13 DENSITIES

DENSITY 7.54038450+00 1.42053093+00 2.71163040-01 5.26926140-02 1.03024752-02 2.06501460-03 3.79436900-04 6.43770350-05
 KAPPA(P) 1.29293420+03 4.30807760+02 1.29284570+02 3.12160600+01 7.13683930+00 1.63789370+00 9.64903000-01 2.40157440-01
 KAPPA(R) 6.55875490+02 3.12543320+02 9.67730910+01 2.04568130+01 4.09897100+00 9.82309800-01 3.59292660-01 2.33259460-01

DENSITY 9.80453710-06 1.27280808-06 1.50840890-07 1.59380110-08 1.49950120-09
 KAPPA(P) 2.08035040-01 2.00833110-01 2.09466320-01 2.00446800-01 2.00445670-01
 KAPPA(R) 2.03353480-01 1.97298390-01 1.96849380-01 1.96801430-01 1.96792380-01

THETA = 499.99993 13 DENSITIES

DENSITY 1.27580469+01 2.42239490+00 4.66913060-01 9.23629820-02 1.83070710-02 3.46649550-03 6.71005450-04 1.13753470-04
 KAPPA(P) 6.71293400+02 2.38731850+02 5.91345270+01 1.25441695+01 2.78101800+00 7.69264120-01 3.19457510-01 2.21988910-01
 KAPPA(R) 4.97705440+02 1.49060450+02 4.08634460+01 8.55056750+00 1.85582137+00 5.50460650-01 2.72814550-01 2.12256890-01

DENSITY 1.74479230-05 2.27315930-06 2.67426800-07 2.84136250-08 2.67424170-09
 KAPPA(P) 2.03706100-01 2.00830730-01 2.00491990-01 2.00447000-01 2.00453290-01
 KAPPA(R) 1.99964480-01 1.97339650-01 1.96866390-01 1.96813830-01 1.96815600-01

THETA = 699.99976 13 DENSITIES

DENSITY 2.02958013+01 3.92767240+00 7.68449750-01 1.52052560-01 3.02333700-02 6.03036970-03 1.10760391-03 1.80277060-04
 KAPPA(P) 5.67461410+02 1.06063286+02 2.41185910+01 5.65795410+00 1.45261268+00 4.67111340-01 2.09732230-01 2.80297690-01
 KAPPA(R) 1.32371010+02 5.82853590+01 1.54742595+01 3.45994940+00 8.72591500-01 3.50164230-01 2.33311920-01 2.80471040-01

DENSITY 2.89447780-05 4.76542460-06 4.42989000-07 4.70676550-08 4.42989400-09
 KAPPA(P) 2.01625450-01 2.00445820-01 2.00526670-01 2.00546320-01 2.00504920-01
 KAPPA(R) 1.90120400-01 1.97097250-01 1.96975090-01 1.97033200-01 1.97032920-01

GRAY ABSORPTION COEFFICIENTS CONTINUED

999.99-07			13 DENSITIES			1.0203313-02			1.09103120-03			3.21408330-04		
THETA =	DENSITY		1.30109822-00	2.57944460-01	5.14685168-02	1.0203313-02	1.09103120-03	3.21408330-04	1.0203313-02	1.09103120-03	3.21408330-04	1.0203313-02	1.09103120-03	3.21408330-04
	KAPPA(P)	1.5941748-02	1.07510775-01	2.53460060-00	6.75604728-01	2.01455868-01	2.15533010-01	2.03145440-01	2.01455868-01	2.15533010-01	2.03145440-01	2.01455868-01	2.15533010-01	2.03145440-01
	KAPPA(R)	5.33193050-01	6.23402370-00	1.49742577-00	4.83995870-01	2.60067938-01	2.00320010-01	1.99210510-01	2.60067938-01	2.00320010-01	1.99210510-01	2.60067938-01	2.00320010-01	1.99210510-01
1099.99-30			13 DENSITIES			1.08995530-07			3.47399000-03			5.90573770-04		
THETA =	DENSITY		2.37850710-00	4.73178420-01	9.45214950-02	1.08995530-07	3.47399000-03	5.90573770-04	1.08995530-07	3.47399000-03	5.90573770-04	1.08995530-07	3.47399000-03	5.90573770-04
	KAPPA(P)	6.14110020-01	4.08156290-00	9.70217400-01	3.45176980-01	2.2015790-01	2.04215200-01	2.02340370-01	2.2015790-01	2.04215200-01	2.02340370-01	2.2015790-01	2.04215200-01	2.02340370-01
	KAPPA(R)	1.5251255-01	1.63496400-00	4.91180400-01	2.60894460-01	2.11247690-01	2.0001900-01	1.98045520-01	2.11247690-01	2.0001900-01	1.98045520-01	2.11247690-01	2.0001900-01	1.98045520-01
2209.99-70			13 DENSITIES			1.30957913-08			3.47202550-02			1.00493259-03		
THETA =	DENSITY		2.55292500-06	2.71237400-07	2.58282540-08	1.30957913-08	3.47202550-02	1.00493259-03	1.30957913-08	3.47202550-02	1.00493259-03	1.30957913-08	3.47202550-02	1.00493259-03
	KAPPA(P)	1.11191010-02	1.51051671-00	4.45020310-01	2.4826920-01	2.01543910-01	2.0759210-01	2.01177030-01	2.01543910-01	2.0759210-01	2.01177030-01	2.01543910-01	2.0759210-01	2.01177030-01
	KAPPA(R)	2.97698000-00	3.91351320-01	2.48463420-01	2.11961210-01	1.98419850-01	2.00947420-01	1.97806430-01	2.11961210-01	2.00947420-01	1.97806430-01	2.11961210-01	2.00947420-01	1.97806430-01
999.99-07			13 DENSITIES			1.08995530-07			3.47399000-03			5.90573770-04		
THETA =	DENSITY		2.37850710-00	4.73178420-01	9.45214950-02	1.08995530-07	3.47399000-03	5.90573770-04	1.08995530-07	3.47399000-03	5.90573770-04	1.08995530-07	3.47399000-03	5.90573770-04
	KAPPA(P)	6.14110020-01	4.08156290-00	9.70217400-01	3.45176980-01	2.2015790-01	2.04215200-01	2.02340370-01	2.2015790-01	2.04215200-01	2.02340370-01	2.2015790-01	2.04215200-01	2.02340370-01
	KAPPA(R)	1.5251255-01	1.63496400-00	4.91180400-01	2.60894460-01	2.11247690-01	2.0001900-01	1.98045520-01	2.11247690-01	2.0001900-01	1.98045520-01	2.11247690-01	2.0001900-01	1.98045520-01
2209.99-70			13 DENSITIES			1.30957913-08			3.47202550-02			1.00493259-03		
THETA =	DENSITY		2.55292500-06	2.71237400-07	2.58282540-08	1.30957913-08	3.47202550-02	1.00493259-03	1.30957913-08	3.47202550-02	1.00493259-03	1.30957913-08	3.47202550-02	1.00493259-03
	KAPPA(P)	1.11191010-02	1.51051671-00	4.45020310-01	2.4826920-01	2.01543910-01	2.0759210-01	2.01177030-01	2.01543910-01	2.0759210-01	2.01177030-01	2.01543910-01	2.0759210-01	2.01177030-01
	KAPPA(R)	2.97698000-00	3.91351320-01	2.48463420-01	2.11961210-01	1.98419850-01	2.00947420-01	1.97806430-01	2.11961210-01	2.00947420-01	1.97806430-01	2.11961210-01	2.00947420-01	1.97806430-01

3			DIANE GROUT 1A/INT		LWS/RP	7/27/66	MATERL = 1119		NR = 491
GREY ABSORPTION COEFFICIENTS			11 TEMPERATURES		13 DENSITIES				
THETA = 49.99485									
UNSAT	5.5920130-01	1.05251768-01	1.4604240-02	3.74651200-03	7.11460970-04	1.33501110-04	2.31074370-05	3.72444540-06	
KAPPA(P)	1.16349790-04	5.00644030-03	1.92233520-03	5.65039190-02	1.52071370-02	4.17200070-01	1.01500444-01	2.45001200-00	
KAPPA(R)	3.74379600-03	2.30073420-03	1.00106540-03	5.91630690-02	5.95543070-01	1.14564166-01	2.40006580-00	6.61633030-01	
UNSAT	5.5433000-07	7.11055560-08	8.33752040-09	8.83703070-10	8.29569010-11				
KAPPA(P)	6.45210270-01	2.61447970-01	2.10190710-01	2.04544400-01	2.08417640-01				
KAPPA(R)	2.9366620-01	2.16007140-01	2.02497040-01	2.00767050-01	2.00773070-01				
THETA = 70.00033			13 DENSITIES						
UNSAT	6.73510470-01	1.62947040-01	3.01349390-02	5.34150050-03	1.03312190-03	1.95400100-04	3.40073400-05	5.0705270-06	
KAPPA(P)	9.04122530-03	4.25717020-03	1.56794320-03	4.74840970-02	1.52112079-02	3.13257340-01	6.55004410-00	1.30528095-00	
KAPPA(R)	3.54318000-03	2.07247730-03	8.35927710-02	1.74856790-02	3.36075240-01	7.22473090-00	1.57506099-00	4.72023000-01	
UNSAT	9.01034600-07	1.16700651-07	1.37091045-08	1.45465105-09	1.36854900-10				
KAPPA(P)	3.74001300-01	2.26722150-01	2.07480070-01	2.05378600-01	2.05214400-01				
KAPPA(R)	2.55106050-01	2.13535460-01	2.04543540-01	2.01878350-01	2.01501180-01				
THETA = 94.99498			13 DENSITIES						
UNSAT	1.37804366-00	2.51931480-01	4.55174270-02	8.44399290-03	1.62647530-03	3.21134690-04	5.87274450-05	9.93435900-06	
KAPPA(P)	8.64900640-03	4.21305260-03	1.27321430-03	3.04327050-02	6.57631690-01	1.39650804-01	2.77631330-00	6.41534000-01	
KAPPA(R)	3.66578030-03	1.94218700-03	5.80374410-02	1.17974671-02	2.09657460-01	4.14076260-00	9.53308690-01	3.73599460-01	
UNSAT	1.52468417-00	1.98356500-07	2.3212070-08	2.45239730-09	2.29450280-10				
KAPPA(P)	2.71500060-01	2.14477590-01	2.07725030-01	2.07874660-01	2.08944680-01				
KAPPA(R)	2.47496410-01	2.12105810-01	2.04295050-01	2.04123510-01	2.05158990-01				
THETA = 150.00069			13 DENSITIES						
UNSAT	2.26027610-00	4.13029180-01	7.65462610-02	1.44340511-02	2.93522840-03	5.84280130-04	1.04922450-04	1.80492320-05	
KAPPA(P)	5.64971450-03	2.04241850-03	5.24539060-02	1.19969055-02	2.45632140-01	5.07537280-00	1.14686138-00	3.83343430-01	
KAPPA(R)	2.17118040-03	1.04636720-03	3.03894300-02	6.36233130-01	1.25080193-01	2.60692920-00	7.01936740-01	3.19004320-01	
UNSAT	2.76323450-06	3.57940190-07	4.20797240-08	4.47034690-09	4.20742550-10				
KAPPA(P)	2.36503510-01	2.13380140-01	2.09852580-01	2.09395590-01	2.09447440-01				
KAPPA(R)	2.2776220-01	2.08764170-01	2.05993640-01	2.05610840-01	2.05536830-01				
THETA = 224.99490			13 DENSITIES						
UNSAT	3.80741310-00	7.12234540-01	1.36762420-01	2.68580420-02	5.32102170-03	1.05697947-03	1.93523010-04	3.26505040-05	
KAPPA(P)	2.53327440-03	6.73925790-02	1.82142620-02	4.18499020-01	9.29763410-00	2.25392240-00	6.07539700-01	2.77121280-01	
KAPPA(R)	7.60850480-02	3.12404850-02	1.07917813-02	2.68504360-01	5.53216920-00	1.27331906-00	4.15624940-01	2.47533820-01	

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 224.93490 CONTINUED			13 DENSITIES		
DENSITY	5.0541540-06	6.57053740-07	7.72978370-08	8.21174930-09	7.72491750-10
KAPPA(P)	2.1973340-01	2.10674921-01	2.09500320-01	2.09374660-01	2.09473090-01
KAPPA(R)	2.14602420-01	2.07291340-01	2.05763050-01	2.05567670-01	2.05654030-01
THETA = 340.00148			13 DENSITIES		
DENSITY	6.6233480+03	1.27644005+00	2.49561470-01	4.91597540-02	9.78132610-03
KAPPA(P)	9.83488440+01	2.91255240+02	7.60575250+01	1.73409370+01	3.76583640+00
KAPPA(R)	2.7140740+02	1.42229210+02	4.29170840+01	9.02708910+00	1.92855301+00
DENSITY	9.34122490-00	1.21787868-06	1.43074550-07	1.51809160-08	1.42927308-09
KAPPA(P)	2.19056450-01	2.10337900-01	2.10184410-01	2.10281110-01	2.10300040-01
KAPPA(R)	2.09100460-01	2.06439060-01	2.06335860-01	2.06447320-01	2.06467960-01
THETA = 503.00094			13 DENSITIES		
DENSITY	1.14201472+01	2.23076190+00	4.40447510-01	8.72855000-02	1.74174970-02
KAPPA(P)	4.75173470+02	1.33809370+02	3.29850430+01	6.73023450+00	1.55224360+00
KAPPA(R)	1.13523040+02	5.44367770+01	1.50530400+01	3.36817140+00	8.69278520-01
DENSITY	1.64403310-03	2.16571140-06	2.54898600-07	2.70819100-08	2.54891050-09
KAPPA(P)	2.14264960-01	2.10520970-01	2.10321070-01	2.10302140-01	2.10300040-01
KAPPA(R)	2.04078470-01	2.06734440-01	2.06480350-01	2.06455580-01	2.06453510-01
THETA = 699.99976			13 DENSITIES		
DENSITY	1.84509730+01	3.67892270+00	7.27161270-01	1.44301560-01	2.87789810-02
KAPPA(P)	1.67512830+02	4.51644360+01	1.02456167+01	2.37069130+00	7.41380710-01
KAPPA(R)	4.34669410+01	1.75162460+01	4.50676670+00	1.16444198+00	4.38372620-01
DENSITY	2.73061490-03	3.56077300-06	4.22236600-07	4.44608700-08	4.22224070-09
KAPPA(P)	2.10683400-01	2.10283220-01	2.10232760-01	2.10228550-01	2.10224450-01
KAPPA(R)	2.04655730-01	2.06296670-01	2.06257480-01	2.06253350-01	2.06253350-01
THETA = 1000.00468			13 DENSITIES		
DENSITY	3.13539470+01	6.25149100+00	1.23776456+00	2.45750120-01	4.90554640-02
KAPPA(P)	8.42597460+01	2.17103690+01	5.34809270+00	1.39063572+00	4.54713040-01
KAPPA(R)	2.04662470+01	8.74629310+00	2.33279230+00	7.12444010-01	3.34951340-01
DENSITY	4.71305430-03	6.12825430-06	7.20947180-07	7.65976200-08	7.28925820-09
KAPPA(P)	2.09555300-01	2.09790020-01	2.09806410-01	2.09804320-01	2.09804320-01
KAPPA(R)	2.03444470-01	2.05349800-01	2.05302740-01	2.05302740-01	2.05300690-01
DENSITY	6.10130320-03	3.58977810-04	1.95354430-03	3.58977810-04	6.10130320-03
KAPPA(P)	9.12254460-01	3.38903790-01	9.12254460-01	3.38903790-01	9.12254460-01
KAPPA(R)	5.74101540-01	2.95150460-01	5.74101540-01	2.95150460-01	5.74101540-01
DENSITY	1.00425205-04	6.30453350-04	3.47931450-03	6.30453350-04	1.00425205-04
KAPPA(P)	2.21001900-01	2.71370560-01	5.02449490-01	2.71370560-01	2.21001900-01
KAPPA(R)	2.13747470-01	2.441412060-01	3.63713070-01	2.441412060-01	2.13747470-01
DENSITY	1.79453200-04	1.05574463-03	5.74704210-03	1.05574463-03	1.79453200-04
KAPPA(P)	2.33753060-01	2.33753060-01	3.32447780-01	2.33753060-01	2.33753060-01
KAPPA(R)	2.09504830-01	2.22070580-01	2.64972400-01	2.22070580-01	2.09504830-01
DENSITY	3.04399750-04	1.80241113-03	9.80430230-03	1.80241113-03	3.04399750-04
KAPPA(P)	2.17551430-01	2.17551430-01	2.54265830-01	2.17551430-01	2.17551430-01
KAPPA(R)	2.10917910-01	2.10917910-01	2.35260440-01	2.10917910-01	2.10917910-01

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 1099.9930		13 DENSITIES	
DENSITY	5.7525730-01	1.10324977-01	2.26105500-00
KAPPA(P)	3.80434890-01	9.71975090-00	2.42873430-00
KAPPA(R)	6.03741370-00	3.05759900-00	9.59283330-01
DENSITY	0.65903370-05	1.12503567-05	1.32946773-06
KAPPA(P)	2.08334570-01	2.08274160-01	2.08267910-01
KAPPA(R)	2.03225310-01	2.03190990-01	2.03196460-01
THETA = 2250.0140		13 DENSITIES	
DENSITY	1.05204997-02	2.07662140-01	4.14959100-00
KAPPA(P)	1.05437760-01	4.02626440-00	9.74510440-01
KAPPA(R)	1.62754260-00	6.52964440-01	3.22994490-01
DENSITY	1.59091670-04	2.36429690-05	2.43320020-06
KAPPA(P)	2.05403280-01	2.05300090-01	2.05370440-01
KAPPA(R)	2.00293790-01	2.00207790-01	2.00205700-01
DENSITY	9.00906590-02	1.00144900-02	3.30944400-02
KAPPA(P)	2.90085300-01	2.23201370-01	2.10403140-01
KAPPA(R)	2.34546630-01	2.09370850-01	2.01936900-01
DENSITY	1.32742817-08	1.00719120-07	1.65515570-01
KAPPA(P)	2.08265830-01	2.08265830-01	2.31925290-01
KAPPA(R)	2.03196460-01	2.03196460-01	2.07351470-01
DENSITY	1.05515570-01	1.05515570-01	6.04304430-03
KAPPA(P)	2.31925290-01	2.10403140-01	2.04335040-01
KAPPA(R)	2.07351470-01	2.01936900-01	2.00500430-01
DENSITY	2.43313570-08	2.43313570-08	1.03610390-03
KAPPA(P)	2.05370440-01	2.05370440-01	2.04335040-01
KAPPA(R)	2.00205700-01	2.00205700-01	2.00500430-01

47	DIANE/SCAT	4-21A	TEMP(1.-34.)	INPUT TAVE 1505	8-9-67	C1/BEF	MATERL = 1001	NK = 533
GREY ABSORPTION COEFFICIENTS								
13 TEMPERATURES								
13 DENSITIES								
THETA =	1.0000							
DENSITY	4.20519E+00	4.62270570-01	3.30261040-02	1.83250089-03	8.8059540-05	3.98788350-06	1.65226270-07	9.88580280-09
KAPPA(P)	4.5281040+05	2.87164340+05	2.31262770+05	1.0574951+05	3.01382370+04	9.72236290+03	4.23479880+03	1.7088590+03
KAPPA(R)	6.21207980+02	6.07605590+02	6.06969760+02	6.00828160+02	5.74649800+02	5.10586950+02	3.74853750+02	1.62838830+02
DENSITY	4.74752510-10	1.02914772-10	1.19393695-11	1.26641632-12	1.19170640-13			
KAPPA(P)	3.91622350+02	5.20129110+01	6.52259290+00	1.05386140+00	4.63631880-01			
KAPPA(R)	3.36720780+01	4.78511000+00	1.00152730+00	4.82587220-01	4.05304430-01			
THETA =	1.2500							
DENSITY	5.02813E+00	4.96381790-02	3.34264470-03	1.82448620-04	9.38798400-06	5.83944460-07	5.42056980-08	7.44815220-09
KAPPA(P)	1.29288470+05	8.95297270+05	7.28097270+05	2.91335250+05	9.47929080+04	3.13095280+04	7.91305280+03	1.49281340+03
KAPPA(R)	4.75843380+03	4.49794550+03	4.46568870+03	4.32260230+03	3.75385670+03	2.27756910+03	6.65123670+02	1.09225633+02
DENSITY	1.09776461-09	1.31711200-10	1.65563840-11	1.76954282-12	1.66543490-13			
KAPPA(P)	2.10057530+02	2.32094610+01	3.42634460+00	7.2305470-01	4.32092280-01			
KAPPA(R)	1.49333109+01	2.30461940+00	7.00162240-01	4.42825940-01	4.04888880-01			
THETA =	1.5000							
DENSITY	1.31655450-01	1.20998120-02	7.97815870-04	4.68942270-05	3.30144430-06	3.75532810-07	5.74546340-08	9.38637470-09
KAPPA(P)	2.33984770+06	1.69176000+06	1.47254070+06	7.71807110+05	1.83633180+05	3.81268580+04	5.42085580+03	8.18517820+02
KAPPA(R)	2.13748070+04	1.93007440+04	1.85744280+04	1.59063531+04	9.21645640+03	2.84806620+03	4.34039180+02	5.86136120+01
DENSITY	1.43335441-09	1.86119410-10	2.18930930-11	2.32609560-12	2.18926590-13			
KAPPA(P)	1.24908235+02	1.61777200+01	2.25307550+00	5.83684300-01	4.17612880-01			
KAPPA(R)	8.04424470+00	1.43995926+00	5.96079160-01	4.39262250-01	4.08111070-01			
THETA =	1.7500							
DENSITY	3.34572E+00	4.73022280-03	3.25955730-04	2.35425790-05	2.31869440-06	4.02588990-07	6.99251910-08	1.17328527-08
KAPPA(P)	3.25622760+06	2.40309740+06	1.94432370+06	7.27456820+05	1.82392110+05	2.18534470+04	3.39436490+03	5.22610780+02
KAPPA(R)	6.94089750+04	5.91498350+04	5.19273210+04	3.34166970+04	1.13436946+04	2.09471320+03	2.89882380+02	3.75611810+01
DENSITY	1.80459434-09	2.34504360-10	2.75440080-11	2.93122720-12	2.75880140-13			
KAPPA(P)	7.64111E+01	1.02279889+01	1.46391388+00	5.09177860-01	4.07585680-01			
KAPPA(R)	5.37781400+00	1.18014308+00	5.65445330-01	4.46634540-01	4.02995530-01			
THETA =	2.0000							
DENSITY	2.92211E+00	2.54046280-03	1.94690790-04	1.83118900-05	2.59984170-06	4.71451340-07	8.47186700-08	1.43383230-08
KAPPA(P)	3.82576660+06	2.79854430+06	2.04941478+06	6.99436290+05	9.88196120+04	1.42644524+04	2.16209490+03	3.83941980+02
KAPPA(R)	1.75750370+05	1.39896760+05	1.05214866+05	4.83141570+04	1.08749133+04	1.67821990+03	2.18555060+02	2.85171820+01

OREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 2.0000 CONTINUED					
DENSITY	2.201870-09	2.66586480-10	3.37061800-11	3.58128310-12	3.37081850-13
KAPPA(P)	4.84952350+01	8.83386430+00	1.12229150+00	4.67416100-01	4.0476150-01
KAPPA(I)	4.28398360+00	1.06203030+00	5.69299110-01	4.43025780-01	3.99167870-01
THETA = 4.25000			13 DENSITIES		
DENSITY	1.92001010-02	1.70275628-03	1.50817070-04	1.77270300-05	2.91549790-06
KAPPA(P)	4.10341730+00	2.90510450+06	1.78364560+06	4.19540990+05	8.19584930+04
KAPPA(I)	3.49528340+05	2.63276440+05	1.63644200+05	5.56813200+04	1.01410818+04
DENSITY	4.62992440-09	3.41870230-10	4.02194720-11	4.27332070-12	4.02194800-13
KAPPA(P)	3.80437110+01	4.99512270+00	9.24109650-01	4.43070710-01	4.03794820-01
KAPPA(I)	3.80474750+00	1.05080200+00	5.64971760-01	4.29554650-01	3.98343730-01
THETA = 5.40000			13 DENSITIES		
DENSITY	6.62846440-03	1.08172315-03	1.56280370-04	2.67780000-05	5.14014140-06
KAPPA(P)	3.14249468+06	1.41137610+06	5.11375740+05	1.83124260+05	1.45520101+04
KAPPA(I)	6.69709480+05	3.42844190+05	1.21212437+05	2.78319490+04	4.65443500+03
DENSITY	4.08498420-09	6.35042120-10	7.47103360-11	7.93799960-12	7.47105490-13
KAPPA(P)	1.01640973+01	1.59553054+00	4.99836060-01	4.07887800-01	4.02577280-01
KAPPA(I)	2.57608430+00	8.46132250-01	4.50003440-01	4.00647860-01	3.97641190-01
THETA = 5.00000			13 DENSITIES		
DENSITY	9.06059070-03	1.45193959-03	2.51338900-04	4.64290610-05	9.10815910-06
KAPPA(P)	1.34816010+06	4.62175530+05	1.29633951+05	2.41871870+04	4.24559380+03
KAPPA(I)	1.86973070+05	7.20849480+04	2.10851010+04	5.16841330+03	1.07832800+03
DENSITY	8.71151010-09	1.13249801-09	1.33234550-10	1.41561807-11	1.33234576-12
KAPPA(P)	3.71814480+00	7.40273280-01	4.25747490-01	4.02617740-01	4.00591690-01
KAPPA(I)	1.25262191+00	5.04649530-01	4.05074460-01	3.94671700-01	3.95827250-01
THETA = 7.00000			13 DENSITIES		
DENSITY	1.24311441-02	2.21494430-03	4.05437030-04	7.63811960-05	1.50643434-05
KAPPA(P)	5.66575790+05	1.72187620+05	4.35783990+04	8.63797200+03	1.63751968+03
KAPPA(I)	4.82079420+04	1.55632380+04	4.14688500+03	9.75597360+02	2.03787700+02
DENSITY	1.44306734-08	1.87598910-09	2.20703750-10	2.34497840-11	2.20703800-12
KAPPA(P)	1.65447422+00	5.13765570-01	4.86714170-01	3.97214590-01	3.96259816-01
KAPPA(I)	5.97828630-01	4.22759290-01	3.45772780-01	3.92647150-01	3.92316800-01
DENSITY	1.71809050-08	5.54608830-07	1.08812859-07	1.04631290+02	1.04631290+02
KAPPA(P)	1.71809050-08	5.54608830-07	1.08812859-07	1.04631290+02	1.04631290+02
KAPPA(I)	1.71809050-08	5.54608830-07	1.08812859-07	1.04631290+02	1.04631290+02
DENSITY	3.17545450-08	2.41452280+03	4.11789378+02	9.35482180+01	1.35811052+01
KAPPA(P)	3.17545450-08	2.41452280+03	4.11789378+02	9.35482180+01	1.35811052+01
KAPPA(I)	3.17545450-08	2.41452280+03	4.11789378+02	9.35482180+01	1.35811052+01
DENSITY	5.66269970-08	7.09706980+02	1.34226510+02	3.85484360+01	8.48846000+00
KAPPA(P)	5.66269970-08	7.09706980+02	1.34226510+02	3.85484360+01	8.48846000+00
KAPPA(I)	5.66269970-08	7.09706980+02	1.34226510+02	3.85484360+01	8.48846000+00
DENSITY	9.30018400-08	3.09187210+02	5.51838730+07	7.44519218+08	1.60043213+08
KAPPA(P)	9.30018400-08	3.09187210+02	5.51838730+07	7.44519218+08	1.60043213+08
KAPPA(I)	9.30018400-08	3.09187210+02	5.51838730+07	7.44519218+08	1.60043213+08

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 10.0000			13 DENSITIES		
DENSITY	1.93791020-02	3.69600580-03	6.61445510-04	1.30025750-04	2.57046170-05
KAPPA(P)	2.41491380-03	6.39994570-04	1.59300236-04	3.24207760-03	6.29761380-02
KAPPA(R)	1.33650700-04	3.6304020-03	9.92149660-02	2.14279490-02	4.61948800-01
DENSITY	2.4039810-03	3.20314580-09	3.76443960-10	4.00396880-11	3.76944030-12
KAPPA(P)	6.37021340-01	4.29758270-01	3.94084900-01	3.90041590-01	3.87666980-01
KAPPA(R)	4.40392080-01	3.9749910-01	3.89807050-01	3.84602730-01	3.88499800-01
THETA = 15.0000			13 DENSITIES		
DENSITY	3.34140120-02	6.11246530-03	1.20420443-03	2.34448630-04	4.72049450-05
KAPPA(P)	4.50221320-04	1.26735951-04	2.90704520-03	6.24127990-02	1.30882230-02
KAPPA(R)	1.43400190-03	4.10422030-02	9.42079870-01	2.03423100-01	4.31517970-00
DENSITY	7.54604420-08	5.68464210-09	6.92308220-10	7.35577900-11	6.92308340-12
KAPPA(P)	4.64499230-04	3.88225570-01	3.80346720-01	3.74453730-01	3.79359680-01
KAPPA(R)	3.90385170-01	3.83533800-01	3.82310220-01	3.62201790-01	3.82189200-01
THETA = 20.0000			13 DENSITIES		
DENSITY	6.04430400-02	1.11385077-02	2.21335230-03	4.37759960-04	8.67044020-05
KAPPA(P)	2.31148500-04	6.09571270-03	1.35314380-03	2.87221290-02	5.93698750-01
KAPPA(R)	7.36660160-02	1.94795040-02	4.32411670-01	9.19405390-00	2.08986880-00
DENSITY	8.31599070-04	1.03106900-06	1.27185419-09	1.35134590-10	1.27185471-11
KAPPA(P)	4.14955290-01	3.83562230-01	3.79940390-01	3.79541810-01	3.79498850-01
KAPPA(R)	3.86350380-01	3.42901123-01	3.92320890-01	3.82270770-01	3.82265140-01
THETA = 30.0000			13 DENSITIES		
DENSITY	1.11618776-01	2.00011580-02	4.10509680-03	8.12807720-04	1.61041570-04
KAPPA(P)	1.11019423-04	2.80744130-03	6.07467050-02	1.27207710-02	2.61664210-01
KAPPA(R)	3.57170400-02	8.96795820-01	1.94056440-01	4.44766270-00	1.13931998-00
DENSITY	1.54474610-07	2.00815380-08	2.36256030-09	2.51019630-10	2.36256070-11
KAPPA(P)	3.93980410-01	3.912233020-01	3.79699790-01	3.79525000-01	3.79506228-01
KAPPA(R)	3.84208770-01	3.82528960-01	3.92303150-01	3.82280890-01	3.82278498-01

9		JIANE/SCAT MMX/LO-HI/JM2 10 FREQ. TEMP. (1.-2250.) C1/JP 12-9-66 000003		MATERL = 1111		NW = 001	
WEY ABSORPTION COEFFICIENTS		21 TEMPERATURES					
THERMATA = 1.0000		13 DENSITIES					
DENSITY	1.492221+01	1.6469306+00	1.1814136+01	6.4450230+03	3.3720470+04	1.0410724+05	1.1176749+06
KAPPA(P)	1.6053398+04	1.19026916+04	9.9309780+03	6.4297803+03	3.1902734+03	1.6072115+03	7.0994103+02
KAPPA(R)	2.1440204+02	4.0687040+02	2.0412795+02	1.9069407+02	1.5765482+02	1.0437225+02	4.0363995+01
DENSITY	0.9420810+09	1.0757152+09	1.2512090+10	1.3210021+11	1.2011002+12		
KAPPA(P)	3.8709470+01	4.4801662+01	5.3933073+01	9.1941021+02	4.5737900+02		
KAPPA(R)	3.1433630+00	4.6075041+00	9.4237460+02	4.6237783+02	4.0096124+02		
THERMATA = 1.5000		13 DENSITIES					
DENSITY	7.5394120+01	7.0206150+02	4.9073362+03	3.3184669+04	2.8507531+05	3.7107471+06	3.9440140+07
KAPPA(P)	9.8939110+04	7.9344339+04	6.3574560+04	4.2169392+04	1.4277267+04	3.2690470+03	5.0444375+02
KAPPA(R)	4.7035740+03	4.2202552+03	3.6714242+03	2.4950461+03	1.0022271+03	2.0029222+02	4.9066228+01
DENSITY	1.4549203+08	1.7266190+09	1.7307260+10	1.5762459+11	1.3611110+12		
KAPPA(P)	1.2326101+01	2.1005433+00	4.2215830+01	1.1433301+01	7.0883140+02		
KAPPA(R)	1.9001205+00	5.1196757+01	1.4992277+01	7.6970042+02	6.6109337+02		
THERMATA = 2.2500		13 DENSITIES					
DENSITY	1.3403740+01	1.3102742+02	1.3045691+03	1.7206926+04	2.9520025+05	5.4809490+06	9.9919970+07
KAPPA(P)	2.1358000+03	1.5707359+05	9.3709973+04	2.6434559+04	6.2392166+03	1.4092450+03	3.6204262+02
KAPPA(R)	4.2676700+04	3.2144214+04	1.7053981+04	5.6431404+03	1.4303035+03	4.0046812+02	1.1240406+02
DENSITY	1.6442040+09	2.0097504+09	2.3333176+10	2.2246446+11	1.8521576+12		
KAPPA(P)	1.5041572+01	2.0713162+00	3.3972392+01	1.1630756+01	9.2592511+02		
KAPPA(R)	4.3997217+00	6.5296999+01	1.5439871+01	9.2475457+02	8.0030693+02		
THERMATA = 3.4000		13 DENSITIES					
DENSITY	7.3105442+02	4.7506533+03	1.4533735+03	2.3729760+04	3.0611370+05	6.6670700+06	1.1231001+06
KAPPA(P)	2.0706330+03	1.1307650+05	5.7454573+04	2.4704843+04	7.6743350+03	1.9379111+03	3.6037430+02
KAPPA(R)	1.4103170+03	7.9721926+04	3.2658485+04	1.0514346+04	2.4546071+03	4.5722600+02	9.2262975+01
DENSITY	4.3554479+08	2.7741263+09	3.0607533+10	2.9494406+11	2.5774310+12		
KAPPA(P)	1.2640012+01	2.0165582+00	3.5415557+01	1.4071980+01	1.2070274+01		
KAPPA(R)	4.1276770+00	7.0664292+01	1.6757666+01	1.2027414+01	1.1690162+01		
THERMATA = 5.0000		13 DENSITIES					
DENSITY	7.3096704+02	1.1743340+02	1.8205500+03	2.9751677+04	5.1946193+05	8.9725544+06	1.4408200+06
KAPPA(P)	1.5922441+05	9.0423540+04	5.4743281+04	2.3171560+04	7.3772729+03	1.7302531+03	3.3243700+02
KAPPA(R)	1.4171170+05	8.2140779+04	3.2601056+04	8.5366729+03	2.1609127+03	4.8049535+02	1.0400177+02

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 0.0000 CONTINUED		
DENSITY	0.1716760-03	0.1521000-09
KAPPA(P)	1.07567657-01	1.0101073-00
KAPPA(R)	3.4073660-00	5.79524330-01
THETA = 7.0000		
13 DENSITIES		
DENSITY	5.60253730-02	1.41104477-02
KAPPA(P)	1.39303450-03	0.4572110-04
KAPPA(R)	1.09173690-03	0.94734540-04
DENSITY	4.31528030-03	5.32542230-09
KAPPA(P)	8.5797510-03	1.29233454-00
KAPPA(R)	2.61795630-00	4.80564080-01
THETA = 10.0000		
13 DENSITIES		
DENSITY	1.07801470-01	1.01434440-02
KAPPA(P)	1.11185349-05	7.30103710-04
KAPPA(R)	6.93443510-04	5.44604440-04
DENSITY	0.57149430-00	0.42266110-09
KAPPA(P)	4.1332050-00	6.80036710-01
KAPPA(R)	1.57415186-00	3.59077510-01
THETA = 15.0000		
13 DENSITIES		
DENSITY	1.45782660-01	2.52117780-02
KAPPA(P)	0.35681580-04	5.58720750-04
KAPPA(R)	3.16257470-04	2.06924700-04
DENSITY	1.1078236-07	1.54321940-08
KAPPA(P)	1.8151864-03	3.12400390-01
KAPPA(R)	8.34739450-01	2.56309440-01
THETA = 22.4999		
13 DENSITIES		
DENSITY	2.14401700-04	3.77296130-02
KAPPA(P)	3.34965250-04	3.30107940-04
KAPPA(R)	1.13737751-04	9.30420730-03
DENSITY	2.1468120-07	2.74958780-08
KAPPA(P)	4.0599410-01	2.25401950-01
KAPPA(R)	0.61504730-01	2.03018570-01
DENSITY	4.23331790-10	4.14950050-11
KAPPA(P)	3.23289190-01	1.6273350-01
KAPPA(R)	2.02291610-01	1.44259820-01
DENSITY	4.55809040-05	1.16511002-05
KAPPA(P)	7.21849610-03	1.41044130-03
KAPPA(R)	2.01422740-03	4.76882440-02
DENSITY	5.79335340-12	1.54567910-01
KAPPA(P)	1.54567910-01	1.51934370-01
DENSITY	8.06442010-05	1.60081120-05
KAPPA(P)	4.33124320-03	0.94178920-02
KAPPA(R)	1.75382070-03	3.03372450-02
DENSITY	9.88265640-12	1.54020430-01
KAPPA(P)	1.54020430-01	1.51526000-01
DENSITY	1.35501070-04	2.56271050-05
KAPPA(P)	2.01845590-03	3.76548160-02
KAPPA(R)	1.26543720-03	2.18748700-02
DENSITY	1.70794300-11	1.55982780-01
KAPPA(P)	1.55982780-01	1.53216850-01
DENSITY	2.30923750-04	4.55431690-05
KAPPA(P)	5.01013490-02	1.80893040-02
KAPPA(R)	0.43797770-02	7.07153700-01
DENSITY	2.96182680-11	0.33954890-06
KAPPA(P)	1.64564900-01	1.72934900-01
KAPPA(R)	1.02771640-01	1.69789010-01
DENSITY	3.09233336-03	8.55431690-05
KAPPA(P)	3.21265700-03	5.01013490-02
KAPPA(R)	2.11379450-03	0.43797770-02
DENSITY	3.24574140-10	2.96182680-11
KAPPA(P)	1.64564900-01	1.72934900-01
KAPPA(R)	1.02771640-01	1.69789010-01
DENSITY	2.73019960-06	1.60081120-05
KAPPA(P)	2.56080360-02	0.94178920-02
KAPPA(R)	4.94020890-01	3.03372450-02
DENSITY	7.72997540-07	1.54020430-01
KAPPA(P)	8.97625300-08	1.51526000-01
KAPPA(R)	0.83064639-08	1.53216850-01
DENSITY	0.33954890-06	4.55431690-05
KAPPA(P)	1.80893040-02	7.07153700-01
KAPPA(R)	1.21500787-01	2.06011790-08

ONLY ASSASSINATION COEFFICIENTS

[illegible]

GREY ABSORPTION COEFFICIENTS CONTINUED

189.9995 CONTINUED		
THETA =	189.9995	CONTINUED
DENSITY	4.7650570-00	3.5935320-07
KAPPA(P)	2.2950020-01	2.0765470-01
KAPPA(R)	2.1651020-01	2.0347700-01
13 DENSITIES		
THETA =	224.9990	
DENSITY	3.9102040-00	7.6611490-01
KAPPA(P)	2.9498070-03	6.5549970-02
KAPPA(R)	7.2662910-02	3.0703475-02
DENSITY	3.0615240-00	8.6059220-07
KAPPA(P)	4.0566340-01	2.0649510-01
KAPPA(R)	2.0346730-01	2.0157930-01
13 DENSITIES		
THETA =	340.6012	
DENSITY	6.6359270-00	1.26953461-00
KAPPA(P)	1.0209210-03	2.7313370-02
KAPPA(R)	1.2635849-02	4.06840030-01
DENSITY	5.4928010-00	1.2271087-00
KAPPA(P)	4.0410800-01	4.03001280-01
KAPPA(R)	1.9900340-01	1.94037050-01
13 DENSITIES		
THETA =	499.9993	
DENSITY	1.13560030-01	2.23336350-00
KAPPA(P)	3.5182540-02	1.00073100-02
KAPPA(R)	4.6434740-01	7.9747080-00
DENSITY	1.64336340-00	2.18835600-06
KAPPA(P)	1.9473230-01	1.94322330-01
KAPPA(R)	1.9616500-01	1.94041290-01
13 DENSITIES		
THETA =	699.9976	
DENSITY	1.8500660-01	3.68673030-00
KAPPA(P)	1.5174230-02	3.48633790-01
KAPPA(R)	7.5714940-00	1.89667120-00
DENSITY	2.7687670-00	3.42502270-06
KAPPA(P)	1.9600090-01	1.95800430-01
KAPPA(R)	1.9402340-01	1.93989930-01

GRAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 99.9967			13 DENSITIES		
DENSITY	3.1262240-01	6.2621810-00	1.2667671-00	2.4909900-01	6.95359310-02
KAPPA(P)	3.3756064-01	1.11742718-01	2.44431900-00	6.17578700-01	2.65158910-01
KAPPA(R)	1.72310-07-00	5.39448920-01	2.77966410-01	2.16035000-01	1.97007220-01
THETA = 99.9967			13 DENSITIES		
DENSITY	4.76123-90-05	6.18960110-06	7.20105510-07	7.73447450-08	7.20192930-09
KAPPA(P)	1.8622708-01	1.88218120-01	1.88212930-01	1.83212250-01	1.80212240-01
KAPPA(R)	1.9098340-01	1.90978580-01	1.90978010-01	1.90977010-01	1.90977010-01
THETA = 199.99730			13 DENSITIES		
DENSITY	5.7799040-01	1.15042499-01	2.28563320-00	6.5583890-01	9.10016190-02
KAPPA(P)	1.56760132-01	3.53100478-03	8.22453170-01	2.49071650-01	2.82296470-01
KAPPA(R)	8.95786-00-01	3.58775650-01	2.35416020-01	2.03087700-01	1.94102090-01
THETA = 199.99730			13 DENSITIES		
DENSITY	8.74695-10-05	1.13710494-05	1.33776344-06	1.42137630-07	1.33776567-08
KAPPA(P)	1.86219-00-01	1.88213100-01	1.88212930-01	1.88212930-01	1.88212930-01
KAPPA(R)	1.9098340-01	1.90978580-01	1.90978200-01	1.90978200-01	1.90978200-01
THETA = 299.99770			13 DENSITIES		
DENSITY	1.0400333-02	2.10390460-01	4.19817950-00	6.36191320-01	1.67176690-01
KAPPA(P)	7.36990150-00	1.6598923-00	4.48823100-01	2.24014000-01	1.93482050-01
KAPPA(R)	5.23400000-01	2.73740000-01	2.13910750-01	1.97102000-01	1.92498290-01
THETA = 299.99770			13 DENSITIES		
DENSITY	1.00091850-04	2.88980000-05	2.43763760-05	2.61120100-07	2.65763000-08
KAPPA(P)	1.88218100-01	1.88213540-01	1.88213100-01	1.88213100-01	1.88213100-01
KAPPA(R)	1.90978770-01	1.90978770-01	1.90978500-01	1.90978500-01	1.90978500-01

16	DIAM/SCAT	110A	10	FREQ.	TEMP(50.-22500.)	CI/ML	1/1000000	MATLNL	= 1100	NK	= 0.97
GREY ABSORPTION COEFFICIENTS											
17 TEMPERATURES											
13 DENSITIES											
TMETA =	50.00000										
DENSITY	9.02079090-01	7.50340070-02	1.05355000-02	2.00002330-03	5.65109210-04	1.12070700-04	2.07030600-05	3.50230500-06			
KAPPA(P)	1.74100-00-04	3.37023000-03	1.10703020-03	2.10005090-02	9.17306030-01	0.30090200-00	1.02037702-00	9.01501210-01			
KAPPA(R)	2.10075550-03	7.39362200-02	1.00022000-02	0.33021000-01	9.00972000-00	1.07000301-00	0.99100010-01	2.50003000-01			
DENSITY	5.02003300-07	7.05201970-08	0.29093000-09	0.01500000-10	0.29093000-11						
KAPPA(P)	2.23600-00-01	2.03900100-01	2.01005000-01	2.01012000-01	2.01507000-01						
KAPPA(R)	2.00003300-01	1.00767700-01	1.07077013-01	1.07002700-01	1.07000000-01						
TMETA =	67.39790										
13 DENSITIES											
DENSITY	0.27932-00-01	1.22397020-01	2.30373170-02	0.69706570-03	9.35952300-04	1.00972330-04	3.03610320-05	5.00122570-06			
KAPPA(P)	7.03032-00-03	2.13737530-03	0.30009110-02	0.70001270-01	1.73951600-01	3.53106300-01	7.01013000-01	2.09503000-01			
KAPPA(R)	5.70567100-02	1.69242720-02	0.02960000-01	0.00000000-01	1.93020000-01	5.02010070-01	2.70070570-01	2.10000220-01			
DENSITY	0.90003300-07	1.00022520-07	1.37039100-08	1.00000000-09	1.37039120-10						
KAPPA(P)	2.07200720-01	1.99010350-01	1.90000000-01	1.90000000-01	1.90000000-01						
KAPPA(R)	1.90100000-01	1.00079120-01	1.05702000-01	1.05702000-01	1.05702000-01						
TMETA =	99.99790										
13 DENSITIES											
DENSITY	1.00000000-01	2.07120000-01	0.05350000-02	0.01597390-03	1.59707700-03	3.19230000-04	5.00710000-05	9.97300000-06			
KAPPA(P)	3.23123070-03	7.99022000-02	1.72303000-02	3.51252730-01	7.00002220-00	1.07507700-00	3.01050700-01	2.21502000-01			
KAPPA(R)	1.67072530-02	0.31356150-01	1.00000000-01	2.25000000-00	0.05953000-01	2.00071910-01	2.10000000-01	1.90700000-01			
DENSITY	1.50000170-06	1.99072010-07	2.30072530-08	2.00000000-09	2.30072500-10						
KAPPA(P)	1.70973000-01	1.93970000-01	1.95500000-01	1.95500000-01	1.95500000-01						
KAPPA(R)	1.90000000-01	1.00079000-01	1.05702000-01	1.05702000-01	1.05702000-01						
TMETA =	100.99995										
13 DENSITIES											
DENSITY	1.00000000-01	3.70039270-01	7.00020000-02	1.07000121-02	2.93500000-03	5.00070000-04	1.07000000-05	1.03200000-06			
KAPPA(P)	2.10000000-02	1.17377500-02	2.50000000-01	5.00000000-00	1.10000000-00	3.07000000-01	2.07000000-01	1.90000000-01			
KAPPA(R)	2.50000000-01	5.00000000-00	1.30020000-01	0.00000000-01	2.52570000-01	2.07000000-01	1.00000000-01	1.91700000-01			
DENSITY	2.01000200-05	3.00051100-07	0.31122010-08	0.50000000-09	0.31122000-10						
KAPPA(P)	1.00000000-01	1.00100000-01	1.00120000-01	1.00120000-01	1.00120000-01						
KAPPA(R)	1.01000200-01	1.00071100-01	1.00000000-01	1.00000000-01	1.00000000-01						
TMETA =	220.99990										
13 DENSITIES											
DENSITY	3.07002100-08	0.00030000-01	1.35575500-01	2.70000000-02	5.39210510-03	1.07700000-03	1.00013700-04	3.30010250-05			
KAPPA(P)	2.03930000-02	5.30020000-01	1.17037000-01	2.07000000-01	5.05000000-01	2.07270000-01	1.95000000-01	1.00027000-01			
KAPPA(R)	1.20377011-01	2.00130100-00	7.10000000-01	3.11001020-01	2.20031070-01	1.99350000-01	1.00000000-01	1.91300000-01			

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 22°, 9990 CONTINUED			13 DENSITIES		
DENSITY	5.1785730-06	6.73215730-07	7.92023430-08	8.41525350-09	7.92023548-10
KAPPA(P)	1.8323070-01	1.8313670-01	1.90124370-01	1.88122860-01	1.88122670-01
KAPPA(R)	1.9099840-01	1.9036440-01	1.90959860-01	1.90959230-01	1.90959290-01
THETA = 340.0012			13 DENSITIES		
DENSITY	4.90749900	1.25437776+00	2.51742880-01	5.02199450-02	1.00160044-02
KAPPA(P)	1.19985344	2.50817620+01	5.23529340+00	1.12880131+00	3.40346100-01
KAPPA(R)	3.53317450+00	1.31593963+00	4.31765740-01	2.50861570-01	2.06959950-01
THETA = 494.99933			13 DENSITIES		
DENSITY	9.61956750-05	1.25054648-06	1.47122330-07	1.56317780-08	1.47122579-09
KAPPA(P)	1.80170400-01	1.88123680-01	1.28123430-01	1.89122670-01	1.89122670-01
KAPPA(R)	1.90976460-01	1.90951590-01	1.90959480-01	1.90959290-01	1.90959290-01
THETA = 694.99976			13 DENSITIES		
DENSITY	1.14472466+01	2.25440130+00	4.46849160-01	4.95339540-02	1.78617630-02
KAPPA(P)	5.32493770+01	1.18051512+01	2.46848180+00	5.87800910-01	2.49022200-01
KAPPA(R)	2.67857490+00	7.15230360-01	5.12349350-01	2.22583050-01	1.99422420-01
THETA = 894.99976			13 DENSITIES		
DENSITY	1.74551070-05	2.23015400-06	2.62372680-07	2.78771100-08	2.62372740-09
KAPPA(P)	1.88144300-01	1.88125430-01	1.88123050-01	1.88122670-01	1.88122670-01
KAPPA(R)	1.90967300-01	1.90960240-01	1.90959290-01	1.90959290-01	1.90959290-01
THETA = 1094.99976			13 DENSITIES		
DENSITY	1.84442780+01	3.71465900+00	7.43431750-01	1.48340940-01	2.95878050-02
KAPPA(P)	4.80253400+01	6.11519030+00	1.30362871+00	3.71766280-01	2.14100870-01
KAPPA(R)	1.45312739+00	4.69337710-01	2.59325020-01	2.09177730-01	1.95766630-01
THETA = 1294.99976			13 DENSITIES		
DENSITY	2.84173710-05	3.69426120-06	4.34621680-07	4.61785730-08	4.34621740-09
KAPPA(P)	1.98133770-01	1.88124150-01	1.88122860-01	1.88122670-01	1.88122670-01
KAPPA(R)	1.90963430-01	1.90959670-01	1.90959290-01	1.90959290-01	1.90959290-01
THETA = 1494.99976			13 DENSITIES		
DENSITY	3.23267790+01	6.34164900+00	1.26924988+00	2.53280170-01	5.05199400-02
KAPPA(P)	1.40197470+01	3.04660230+00	6.97819780-01	2.66210480-01	1.98735790-01
KAPPA(R)	3.12723660-01	3.37731530-01	2.28743720-01	2.61061790-01	1.93528590-01
THETA = 1694.99976			13 DENSITIES		
DENSITY	4.83219640-05	6.30782290-06	7.42101420-07	7.88883200-08	7.42101600-09
KAPPA(P)	1.88128130-01	1.88123230-01	1.88122670-01	1.88122490-01	1.88122490-01
KAPPA(R)	1.90961400-01	1.90959460-01	1.90959100-01	1.90959100-01	1.90959100-01

345

GRAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 6999.99200 CONTINUED

DENSITY 0.9477150-04 1.16970127-04 1.37611670-05 1.44212461-06 1.37611690-07
 KAPPA(P) 1.8968750-01 1.89687150-01 1.89686960-01 1.89686980-01 1.89686980-01
 KAPPA(R) 1.91159520-01 1.91159520-01 1.91159520-01 1.91159520-01 1.91159520-01

THETA = 9999.99520 13 DENSITIES

DENSITY 9.9618050-02 2.03720010-02 9.00267000-01 7.99851570-00 1.59699933-00 3.19428040-01 9.07440000-02 9.96421150-03
 KAPPA(P) 2.6994470-01 2.19290490-01 1.94677520-01 1.94684120-01 1.89896780-01 1.89732350-01 1.89732350-01 1.89717720-01
 KAPPA(R) 2.03169430-01 1.94218260-01 1.91839150-01 1.91245560-01 1.91118760-01 1.91092440-01 1.91080420-01 1.91087090-01

DENSITY 1.5363323-03 1.99723050-04 2.34967150-05 2.44652780-06 2.34967190-07
 KAPPA(P) 1.89716760-01 1.89716560-01 1.89716580-01 1.89716580-01 1.89716580-01
 KAPPA(R) 1.91087660-01 1.91087660-01 1.91087660-01 1.91087660-01 1.91087660-01

THETA = 14999.99100 13 DENSITIES

DENSITY 1.83457100-03 3.43742600-02 7.34563410-01 1.449942016-01 2.93750730-00 5.07194590-01 1.07020430-01 1.03450400-02
 KAPPA(P) 2.6376350-01 2.02060720-01 1.92030510-01 1.90177200-01 1.89844110-01 1.89780230-01 1.89780230-01 1.89780230-01
 KAPPA(R) 1.97279460-01 1.92652580-01 1.91400660-01 1.91155890-01 1.91115360-01 1.91107150-01 1.91105430-01 1.91105430-01

DENSITY 2.82242170-03 3.66914390-04 9.31663210-05 9.58642410-06 9.31663280-07
 KAPPA(P) 1.89764780-01 1.89764780-01 1.89764780-01 1.89764780-01 1.89764780-01
 KAPPA(R) 1.91105050-01 1.91105050-01 1.91105050-01 1.91105050-01 1.91105050-01

THETA = 24999.98500 13 DENSITIES

DENSITY 4.37042430-03 6.77420330-02 1.34648850-02 2.44999270-01 5.39461150-00 1.07070850-00 1.00048570-01 3.37834070-02
 KAPPA(P) 2.20349450-01 1.95100200-01 1.90843320-01 1.89820450-01 1.89678480-01 1.89640400-01 1.89640400-01 1.89640400-01
 KAPPA(R) 1.94257440-01 1.91087280-01 1.91300000-01 1.91172140-01 1.91153790-01 1.91150360-01 1.91107770-01 1.91107770-01

DENSITY 5.10512130-03 6.74065020-04 7.03617010-05 8.47501030-06 7.93010000-07
 KAPPA(P) 1.89442410-01 1.89442410-01 1.89442410-01 1.89442410-01 1.89442410-01
 KAPPA(R) 1.91109980-01 1.91109980-01 1.91109980-01 1.91109980-01 1.91109980-01

111	DIAVE	L1/MH	50. EV - 22+0. EV	11 FREQ.	CRO/GAL	9/30/66	Q50000	MATERL = 210A	NK = 519
GREY ABSORPTION COEFFICIENTS									
13 TEMPERATURES									
13 DENSITIES									
THETA = 50.0000									
DENSITY	7.54340480-02	1.45355048-02	2.84002330-03	5.65189210-04	1.12070780-00	2.07434400-05	3.52423450-06		
KAPPA(1)	5.37432300+03	1.10708930+03	2.19085100+02	4.17339030+01	8.36091600+00	1.64453400+00	3.64110100-01		
KAPPA(2)	7.39361490+02	1.94022860+02	4.37621090+01	9.01191070+00	1.03601240+00	3.50190900-01	7.60420900-02		
DENSITY	7.05241970-08	8.24969320-09	8.61549490-10	8.29493430-11					
KAPPA(1)	1.09295170-01	1.04710173-01	1.04163968-01	1.04105132-01					
KAPPA(2)	1.74567400-02	1.67061590-02	1.64706930-02	1.66569780-02					
THETA = 64.9999									
DENSITY	1.22397924-01	2.33437370-02	4.60746570-03	9.35952730-04	1.86972330-00	3.43616320-03	5.84122570-04		
KAPPA(1)	2.13737700+03	4.34009720+02	8.78941270+01	1.73950400+01	3.52745970+00	7.04397030-01	1.74012050-01		
KAPPA(2)	1.69242720+02	4.02465340+01	9.04254790+00	1.37314792+00	3.88924750-01	7.75740430-02	1.88447100-02		
DENSITY	1.10422526-07	1.37449100-08	1.48029147-09	1.37439120-10					
KAPPA(1)	7.07581900-02	6.80447100-02	6.46121260-02	6.05074900-02					
KAPPA(2)	6.99362030-03	6.77453360-03	6.74096630-03	6.74023730-03					
THETA = 94.9999									
DENSITY	2.07124480-01	4.05945610-02	8.01597390-03	1.59787765-03	3.19239830-04	5.86710440-05	9.97349020-06		
KAPPA(1)	7.99422410+02	1.72363550+02	3.51252750+01	7.06592210+00	1.44487915+00	3.01170340-01	8.60459070-02		
KAPPA(2)	3.31956150+01	1.00935800+01	2.21934620+00	4.59505300-01	9.51636720-02	1.99717000-02	5.76040300-03		
DENSITY	1.99472410-07	2.34672530-06	2.44339670-09	2.34672580-10					
KAPPA(1)	4.37817900-02	4.30092540-02	4.25165390-02	4.29065410-02					
KAPPA(2)	2.90855470-03	2.85697470-03	2.85082450-03	2.85016330-03					
THETA = 149.9995									
DENSITY	3.78630270-01	7.44726570-02	1.47200121-02	2.93524610-03	5.86470430-04	1.07705230-04	1.83228010-05		
KAPPA(1)	1.17377580+02	2.54497030+01	5.42445130+00	1.11502330+00	2.33438320-01	5.21407230-02	1.80093770-02		
KAPPA(2)	5.80506020+00	1.26803212+00	2.68042150-01	5.50074320-02	1.14162331-02	2.43973220-03	7.55161400-04		
DENSITY	3.65451380-07	4.31122010-08	4.58067330-09	4.31122080-10					
KAPPA(1)	1.12321500-02	1.11067189-02	1.10940095-02	1.10924232-02					
KAPPA(2)	4.15442990-04	4.10330150-04	4.04610856-04	4.09532220-04					
THETA = 224.9990									
DENSITY	8.94036400-01	1.35575500-01	2.70304060-02	5.39214510-03	1.07704090-03	1.90013760-04	3.34410250-05		
KAPPA(1)	5.39020490+01	1.17816930+01	2.43303730+00	5.03314030-01	1.10144290-01	2.93471740-02	1.01092570-02		
KAPPA(2)	2.66529000+00	5.82556990-01	1.20213253+01	2.47339060-02	5.50849980-03	1.31249443-03	5.63179030-04		

GREY ABSORPTION COEFFICIENTS CONTINUED

TABLE 2. 225.99990 CONTINUED									
DENSITY	5.1785730-06	6.73215730-07	7.92023430-08	9.41325250-09	7.92023250-10				
(MAGPA(1))	1.15706237-02	1.11544289-02	1.10995094-02	1.10933035-02	1.10923233-02				
(MAGPA(4))	4.3174920-04	4.12399170-04	4.09945008-04	4.09562510-04	4.09527700-04				
TABLE 3. 340.00012									
DENSITY	6.43074400+00	1.204467776+00	2.51742020-01	5.02199900-02	1.00100000-02	2.00130000-03	3.07823650-04	6.28377300-05	
(MAGPA(1))	1.11990163+02	2.50814460+01	5.22627610+00	1.07763930+00	2.27171510-01	5.2518050-02	1.40991040-02	1.20559030-02	
(MAGPA(4))	3.53581430+00	3.24337402+00	2.54339930-01	5.31380060-02	1.10965172-02	2.35725220-03	8.03099200-04	4.70823900-04	
DENSITY	3.63958150+06	1.25050404+06	1.47122530-07	1.54317700-08	1.47122570-09				
(MAGPA(1))	1.12016178+02	1.11196771+02	1.10754510-02	1.10925097-02	1.10922903-02				
(MAGPA(4))	4.19481420+04	4.10470700+04	4.09482530-04	4.06941230-04	4.09525670-04				
TABLE 4. 499.99993									
DENSITY	1.16472460+01	4.23440180+00	4.44849160-01	6.54339550-02	1.70647630-02	3.34907790-03	4.35957090-04	1.11500010-04	
(MAGPA(1))	5.33037460+01	1.18024277+01	2.40221440+00	5.04110120-01	1.11172303-01	3.11061250-02	1.47917312-02	1.17217170-02	
(MAGPA(4))	2.63223110+00	5.63615150-01	1.20444508-01	2.44918960-02	5.359393710-03	1.463304023-03	5.92400550-04	4.40647210-04	
DENSITY	1.71551170-03	2.23015400-06	2.62372680-07	2.74771100-08	2.62372740-09				
(MAGPA(1))	1.11892111-02	1.11350926-02	1.10539320-02	1.10926117-02	1.10924674-02				
(MAGPA(4))	4.12313150-04	4.10146980-04	4.37597350-04	4.04531900-04	4.09524800-04				
TABLE 5. 699.99976									
DENSITY	1.49440270+01	3.71495590+00	7.43431750-01	1.44340940-01	2.95870050-02	5.91217420-03	1.00459337-03	1.44710730-04	
(MAGPA(1))	2.80278130+01	6.10372550+00	1.25933937+00	2.40428420-01	6.2201000-02	2.13495210-02	1.27007217-02	1.18100078-02	
(MAGPA(4))	1.34591144+00	3.01955380-01	6.28063310-02	1.24311140-02	2.93737450-03	9.16784630-04	5.02005020-04	4.23403260-04	
DENSITY	4.0417310+03	3.63425120-06	4.39422160-07	6.61745730-08	4.34621740-09				
(MAGPA(1))	1.11424032+02	1.10994358-02	1.10537766-02	1.10511003-02	1.10930223-02				
(MAGPA(4))	4.11967150+00	4.09841950-04	4.09561700-04	4.09326110-04	4.09524430-04				
TABLE 6. 899.99967									
DENSITY	3.23267140+01	6.34166400+00	1.24924980+00	2.5380170-01	5.05199400-02	1.00940491-02	1.05933760-03	3.13390480-04	
(MAGPA(1))	4.09366350+01	4.51949590+00	4.29465170-01	1.94350360-01	5.00078010-02	2.01481090-02	1.40140727-02	1.20723130-02	
(MAGPA(4))	4.92494750+01	1.47033340-01	3.07784330-02	4.56714000-03	1.64919330-03	6.50192700-04	4.50270000-04	4.17300400-04	
DENSITY	4.03219440+03	4.30742220-06	7.42101020-07	7.80483900-08	7.42101040-09				
(MAGPA(1))	1.26736192+02	1.24421728-02	1.26302069-02	1.24375352-02	1.26334003-02				
(MAGPA(4))	4.10721190+00	4.06001010-04	4.09542000-04	4.09326000-04	4.09524400-04				

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 499.9 M30								
13 DENSITIES								
DENSITY	5.9298E00+01	1.1546E22+01	2.331E2550+00	4.64925080-01	9.2772320-02	1.85454090-02	3.40845220-03	3.79017040-04
KAPPA(P)	0.9470E10+00	1.8037E14+00	3.7627E510-01	8.57273820-02	2.69599190-02	1.51078620-02	1.26842907-02	1.22308343-02
KAPPA(R)	3.1415E90-01	0.72751720-02	1.37544202-02	3.14644550-03	9.60892520-04	5.20007150-04	4.29844490-04	4.12980590-04
DENSITY	0.9130E750-02	1.1538E2386-05	1.36333088-06	1.44853920-07	1.36333073-08			
KAPPA(P)	1.2152E23+02	1.21397753-02	1.21381372-02	1.21379424-02	1.21379188-04			
KAPPA(R)	4.1005E930-04	4.09593250-04	4.09532220-04	4.09525260-04	4.09524430-04			
THETA = 499.9 M30								
10 DENSITIES								
DENSITY	4.5504E90+01	1.64185690+01	1.20255312+01	8.02566070+00	4.02129090+00	1.80304051+00	8.08820310-01	4.23921200-01
KAPPA(P)	2.7949E150+00	1.05224428+00	7.78869940-01	5.25619610-01	2.68444730-01	1.28843470-01	6.47720560-02	4.00954270-02
KAPPA(R)	9.2506E100-02	3.44222750-02	2.57726350-02	1.73898080-02	8.87874540-03	4.25610860-03	2.13527250-03	1.31843614-03
DENSITY	0.0735E760-02	0.56328070-03						
KAPPA(P)	1.7270E170-02	1.31921944-02						
KAPPA(R)	5.8275E20-04	4.27388440-04						
THETA = 2249.9 M70								
13 DENSITIES								
DENSITY	4.0444E53+02	2.13979040+01	4.24328390+00	3.54112040+01	1.70442210-01	3.40700690-02	6.26172060-03	1.06445644-03
KAPPA(P)	4.2424E53+00	0.82390310-01	1.82024310-01	4.74427340-02	1.95512310-02	1.36507909-02	1.24660161-02	1.24661240-02
KAPPA(R)	1.4591E20-01	3.03136250-02	6.444566190-03	1.62707550-03	6.54547770-04	4.58589540-04	4.18544480-04	4.11059340-04
DENSITY	1.63761460-04	2.12890020-05	2.50457900-06	2.6611630-07	2.50457940-08			
KAPPA(P)	1.2430E104-02	1.24243628-02	1.24235801-02	1.24234934-02	1.24234808-02			
KAPPA(R)	4.0976E110-04	4.09555160-04	4.09524810-04	4.09524840-04	4.09524430-04			
THETA = 2494.9 M90								
10 DENSITIES								
DENSITY	0.3590E400+01	2.29447410+01	1.68054970+01	1.11911913+01	5.61983330+00	2.51965780+00	1.13035447+00	5.92445250-01
KAPPA(P)	1.8820E435+00	0.35456030-01	4.71408760-01	3.19019020-01	1.65441770-01	8.18378030-02	4.34941840-02	2.87379130-02
KAPPA(R)	5.9420E480-02	2.24955030-02	1.66811320-02	1.13082019-02	5.83662250-03	2.87327730-03	1.51423035-03	9.91174500-04
DENSITY	1.14831108-01	1.19475540-02						
KAPPA(P)	1.5450E40-02	1.26592518-02						
KAPPA(R)	5.2018E60-04	4.21224360-04						

JO		DIANE/SCAT		LIMESTONE-18		5-25-67		TEMP(50-1.54)		AK/RW INPUT TAPE(3971)		MATEML = 1131		ME = 015	
GREY ABSORPTION COEFFICIENTS		13		TEMPERATURES		13		TEMPERATURES		13		TEMPERATURES		13	
TMCETA = 50.0 H00		13		DENSITIES		13		DENSITIES		13		DENSITIES		13	
DENSITY	6.44501E-01	1.2294939-01	2.2708522-02	4.3013560-03	8.2956305-04	1.5049619-04	2.0089505-05	0.3100179-06	2.0089505-05	0.3100179-06	2.0089505-05	0.3100179-06	2.0089505-05	0.3100179-06	2.0089505-05
KAPPA(P)	1.4919E-03	7.1919526-03	2.7561331-03	6.8802275-02	1.9249980-02	3.7203452-01	0.0377315-00	2.0826271-00	0.0377315-00	2.0826271-00	0.0377315-00	2.0826271-00	0.0377315-00	2.0826271-00	0.0377315-00
KAPPA(R)	3.8590E-03	3.5101151-03	1.4998072-03	4.2590107-02	9.1223356-01	1.9042945-01	0.2100025-00	9.3171010-01	0.2100025-00	9.3171010-01	0.2100025-00	9.3171010-01	0.2100025-00	9.3171010-01	0.2100025-00
DENSITY	6.5974E-07	8.1155419-08	9.1573416-09	9.5009432-10	8.0045280-11	0.0045280-11	0.0045280-11	0.0045280-11	0.0045280-11	0.0045280-11	0.0045280-11	0.0045280-11	0.0045280-11	0.0045280-11	0.0045280-11
KAPPA(P)	5.3590E-01	2.4139610-01	1.9424200-01	1.9065670-01	1.9264214-01	1.9264214-01	1.9264214-01	1.9264214-01	1.9264214-01	1.9264214-01	1.9264214-01	1.9264214-01	1.9264214-01	1.9264214-01	1.9264214-01
KAPPA(R)	3.1529E-01	2.0278763-01	1.8644465-01	1.8674317-01	1.8910019-01	1.8910019-01	1.8910019-01	1.8910019-01	1.8910019-01	1.8910019-01	1.8910019-01	1.8910019-01	1.8910019-01	1.8910019-01	1.8910019-01
TMCETA = 69.9 P99		13		DENSITIES		13		DENSITIES		13		DENSITIES		13	
DENSITY	1.0174E-03	1.8007750-01	3.5015621-02	6.5049112-03	1.2373454-03	2.3230344-04	0.0341000-05	0.3259114-06	0.0341000-05	0.3259114-06	0.0341000-05	0.3259114-06	0.0341000-05	0.3259114-06	0.0341000-05
KAPPA(P)	1.2008E-03	5.5577627-03	1.7675810-03	9.0030760-02	1.2312424-02	3.2516251-01	0.0929161-00	1.7749422-00	0.0929161-00	1.7749422-00	0.0929161-00	1.7749422-00	0.0929161-00	1.7749422-00	0.0929161-00
KAPPA(R)	3.9650E-03	2.6629210-03	9.0633050-02	2.2424966-02	5.7293945-01	1.3647500-01	2.9697892-00	0.9421000-01	2.9697892-00	0.9421000-01	2.9697892-00	0.9421000-01	2.9697892-00	0.9421000-01	2.9697892-00
DENSITY	9.75361E-07	1.2423015-07	1.4505761-08	1.5378356-09	1.4422085-10	1.4422085-10	1.4422085-10	1.4422085-10	1.4422085-10	1.4422085-10	1.4422085-10	1.4422085-10	1.4422085-10	1.4422085-10	1.4422085-10
KAPPA(P)	4.7177E-01	2.3007043-01	1.9831890-01	1.9450780-01	1.9473786-01	1.9473786-01	1.9473786-01	1.9473786-01	1.9473786-01	1.9473786-01	1.9473786-01	1.9473786-01	1.9473786-01	1.9473786-01	1.9473786-01
KAPPA(R)	2.82521E-01	2.0526058-01	1.9303070-01	1.9109893-01	1.9124307-01	1.9124307-01	1.9124307-01	1.9124307-01	1.9124307-01	1.9124307-01	1.9124307-01	1.9124307-01	1.9124307-01	1.9124307-01	1.9124307-01
TMCETA = 99.9 P99		13		DENSITIES		13		DENSITIES		13		DENSITIES		13	
DENSITY	1.5901E-12	2.9410065-01	5.3053171-02	9.9020351-03	1.8475978-03	3.5217195-04	6.2944342-05	1.0594302-05	6.2944342-05	1.0594302-05	6.2944342-05	1.0594302-05	6.2944342-05	1.0594302-05	6.2944342-05
KAPPA(P)	3.6212E-03	4.4049401-03	1.3572705-03	3.2377160-02	8.9307310-01	2.2312164-01	0.5091695-00	9.8934010-01	0.5091695-00	9.8934010-01	0.5091695-00	9.8934010-01	0.5091695-00	9.8934010-01	0.5091695-00
KAPPA(R)	3.1030E-03	2.1937791-03	6.5596235-02	1.4422590-02	5.5037003-01	7.9001232-00	1.0063134-00	0.3633061-01	1.0063134-00	0.3633061-01	1.0063134-00	0.3633061-01	1.0063134-00	0.3633061-01	1.0063134-00
DENSITY	1.61470E-25	2.0400461-07	2.4493945-08	2.5443745-09	2.4426194-10	2.4426194-10	2.4426194-10	2.4426194-10	2.4426194-10	2.4426194-10	2.4426194-10	2.4426194-10	2.4426194-10	2.4426194-10	2.4426194-10
KAPPA(P)	3.0741E-01	2.1057129-01	1.9756110-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01	1.9639640-01
KAPPA(R)	2.01301E-01	2.0440049-01	1.9442706-01	1.9297293-01	1.9274581-01	1.9274581-01	1.9274581-01	1.9274581-01	1.9274581-01	1.9274581-01	1.9274581-01	1.9274581-01	1.9274581-01	1.9274581-01	1.9274581-01
TMCETA = 109.9 P95		13		DENSITIES		13		DENSITIES		13		DENSITIES		13	
DENSITY	2.6104E-03	4.7469665-01	8.0216440-02	1.6267924-02	3.1407458-03	6.1056883-04	1.1209993-04	1.9113910-05	1.1209993-04	1.9113910-05	1.1209993-04	1.9113910-05	1.1209993-04	1.9113910-05	1.1209993-04
KAPPA(P)	6.0140E-03	2.4778743-03	6.7191239-02	1.9059620-02	4.3233600-01	0.5599125-00	1.7362004-00	0.3727020-01	1.7362004-00	0.3727020-01	1.7362004-00	0.3727020-01	1.7362004-00	0.3727020-01	1.7362004-00
KAPPA(R)	3.2153E-03	1.2297369-03	3.6778530-02	9.7472642-01	1.7977310-01	3.5629039-00	0.4910995-01	3.0931190-01	0.4910995-01	3.0931190-01	0.4910995-01	3.0931190-01	0.4910995-01	3.0931190-01	0.4910995-01
DENSITY	2.93521E-06	3.0143327-07	4.4072090-08	9.7476139-09	0.4071640-10	0.4071640-10	0.4071640-10	0.4071640-10	0.4071640-10	0.4071640-10	0.4071640-10	0.4071640-10	0.4071640-10	0.4071640-10	0.4071640-10
KAPPA(P)	2.36261E-01	2.0140010-01	1.9449769-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01	1.9435795-01
KAPPA(R)	2.2964E-01	1.9900707-01	1.9363797-01	1.9282041-01	1.9273154-01	1.9273154-01	1.9273154-01	1.9273154-01	1.9273154-01	1.9273154-01	1.9273154-01	1.9273154-01	1.9273154-01	1.9273154-01	1.9273154-01
TMCETA = 229.0 P90		13		DENSITIES		13		DENSITIES		13		DENSITIES		13	
DENSITY	2.2491E-03	7.6708640-01	1.4205120-01	2.6450450-02	5.4447880-03	1.1231184-03	0.0410979-04	3.8030000-05	0.0410979-04	3.8030000-05	0.0410979-04	3.8030000-05	0.0410979-04	3.8030000-05	0.0410979-04
KAPPA(P)	3.23765E-03	1.0029608-03	2.8220510-02	6.5902730-01	1.3452200-01	2.8372200-00	6.7261182-01	2.7603130-01	6.7261182-01	2.7603130-01	6.7261182-01	2.7603130-01	6.7261182-01	2.7603130-01	6.7261182-01
KAPPA(R)	1.2110E-03	5.7807247-02	1.9363764-02	0.4300610-01	0.6410730-00	1.0044530-00	0.4333350-01	2.0004000-01	0.4333350-01	2.0004000-01	0.4333350-01	2.0004000-01	0.4333350-01	2.0004000-01	0.4333350-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 224.9 M90 CONTINUED

DENSITY 2.36970-70-03 7.00402960-07 8.21477340-08 8.65161510-09 8.0430130-10
 KAPPA(P) 2.06381-19-01 1.97966390-01 1.97102770-01 1.94762030-01 2.01040790-01
 KAPPA(R) 2.03981750-01 1.94610090-01 1.93519300-01 1.95129960-01 1.97393120-01

THETA = 340.00012 13 DENSITIES

DENSITY 7.35384-30-00 1.30124330-00 2.67340810-01 5.25375000-02 1.04338707-02 2.08226090-03 3.01791850-04 6.44019340-05
 KAPPA(P) 1.32144-30-03 4.12234230-02 1.04152382-02 2.10854230-01 4.46653080-00 1.06258927-00 3.68628950-01 2.32828360-01
 KAPPA(R) 3.33503-30-02 1.60235870-02 5.55214250-01 1.33796510-01 3.00144840-00 7.82527590-01 3.11087110-01 2.17686160-01

DENSITY 9.80733-30-00 1.28433515-06 1.48409580-07 1.57636370-08 1.48357668-09 2.02606420-01 1.98914140-01
 KAPPA(P) 2.09470-60-04 2.63790050-01 4.02750530-01 2.02618990-01 2.02606420-01 1.98914140-01
 KAPPA(R) 2.00604000-01 1.99026550-01 1.92971630-01 1.94941590-01 1.98914140-01

THETA = 494.9 M93 13 DENSITIES

DENSITY 1.25107-36-04 2.39769500-00 4.70779570-01 9.31353950-02 1.84256230-02 3.64440930-03 6.64184240-04 1.12530860-04
 KAPPA(P) 5.25713-70-02 1.54510030-02 3.56991530-01 8.51604450-00 2.48847050-00 8.73902470-01 3.61988080-01 2.32899060-01
 KAPPA(R) 4.18795-95-02 4.84152100-01 1.31677803-01 3.12033390-00 4.79195580-01 3.77222450-01 2.41295000-01 2.09035120-01

DENSITY 1.73014-60-05 2.24892110-06 2.64575300-07 2.81108550-08 2.64572690-09 2.02614720-01 1.98937610-01
 KAPPA(P) 2.07047420-01 2.03051020-01 2.02647750-01 2.02617350-01 2.02614720-01 1.98937610-01
 KAPPA(R) 2.02101-70-01 1.99551200-01 1.94978000-01 1.94940400-01 1.98937610-01

THETA = 694.9 M76 13 DENSITIES

DENSITY 2.04010000-01 3.02813030-00 7.70052630-01 1.51542370-01 2.99634190-02 5.96810400-03 1.09594093-03 1.08271550-04
 KAPPA(P) 2.94501-20-02 8.40237890-01 4.33962310-01 6.82718420-00 1.84104415-00 5.51044650-01 2.68810930-01 2.11993080-01
 KAPPA(R) 6.09614-50-01 2.66055300-01 6.55742500-00 1.55552300-00 5.33135800-01 2.98178490-01 2.32450020-01 2.07818330-01

DENSITY 4.06561-00-05 3.72527490-06 4.38265910-07 4.65657850-08 4.38265990-09 2.02687270-01 1.99086260-01
 KAPPA(P) 4.03644-00-01 4.02784400-01 2.02697000-01 2.02687270-01 2.02686260-01 1.99086260-01
 KAPPA(R) 4.00817-50-01 1.99173690-01 1.99096230-01 1.99086230-01 1.99086260-01

THETA = 994.9 M67 13 DENSITIES

DENSITY 3.35574-90-01 6.59316710-00 1.29242699-00 2.55757900-01 5.49463580-02 1.01797279-02 1.87690314-03 3.18861730-04
 KAPPA(P) 1.51464-50-02 6.79714310-01 1.33943054-01 3.11202620-00 6.20352160-01 3.17026470-01 2.17427020-01 2.84482880-01
 KAPPA(R) 5.47960-60-01 1.77958260-01 4.23239060-00 1.04856766-00 4.27136180-01 2.53802910-01 2.09475180-01 2.08427830-01

DENSITY 4.89291440-05 6.36077750-06 7.48323920-07 7.95094510-08 7.48324050-09 7.48324050-09 2.02623730-01 2.02623730-01
 KAPPA(P) 2.03074420-01 2.02856380-01 2.02827180-01 2.02823730-01 2.02823730-01 2.02823730-01 1.99301080-01
 KAPPA(R) 1.99462460-01 1.99319340-01 1.99303190-01 1.99301210-01 1.99301080-01

ONLY ABSORPTION COEFFICIENTS CONTINUED

THERMAL = 499.9470			13 DENSITIES		
DENSITY	6.019450+01	1.1913130+01	4.3560410+00	9.6001530+01	9.3546040+02
KAPPA(P)	7.5337790+01	2.0857540+01	9.7470401+00	1.1123460+00	3.6172103+01
KAPPA(R)	2.1313070+01	7.8935770+00	1.9366192+00	5.3499030+01	2.6044673+01
THERMAL = 499.9470			13 DENSITIES		
DENSITY	4.9404350+01	1.1635521+01	1.3747619+00	1.4604652+07	1.3747623+00
KAPPA(P)	4.0941013+01	2.6426024+01	2.0204920+01	2.0204920+01	2.0204920+01
KAPPA(R)	1.9329430+01	1.9925875+01	1.9725390+01	1.9925337+01	1.4925337+01
THERMAL = 229.9470			13 DENSITIES		
DENSITY	1.1001065+02	2.1763430+01	9.2134990+00	9.6015231+01	1.7104090+01
KAPPA(P)	3.2495490+01	7.7457760+01	1.7318522+00	9.6439300+01	2.4308731+01
KAPPA(R)	4.2030430+01	1.3303170+01	4.6363090+01	2.5709360+01	2.0772930+01
THERMAL = 161.3400-04			13 DENSITIES		
DENSITY	1.6313400+04	2.1467725+05	2.5256040+06	2.6434565+07	2.5256050+00
KAPPA(P)	4.0108174+01	2.0105950+01	2.0105550+01	2.0105515+01	2.0105515+01
KAPPA(R)	1.9760100+01	1.9753172+01	1.9763052+01	1.9763033+01	1.9763033+01
THERMAL = 300.0000			13 DENSITIES		
DENSITY	4.0267230+02	4.0171026+01	8.0044430+00	1.5075761+00	3.1919630+01
KAPPA(P)	1.2690500+01	2.9299460+00	7.0074180+01	2.8119170+01	2.1153315+01
KAPPA(R)	4.6010540+01	3.9494030+01	2.4976320+01	2.0415702+01	1.9827347+01
THERMAL = 3.0075070-04			13 DENSITIES		
DENSITY	3.0075070+04	3.9377430+05	4.6914910+06	9.3087123+07	4.6914920+08
KAPPA(P)	1.9769470+01	1.9769231+01	1.9769073+01	1.9769053+01	1.9769053+01
KAPPA(R)	1.9528370+01	1.9528036+01	1.9527978+01	1.9527978+01	1.9527978+01
THERMAL = 499.9900			13 DENSITIES		
DENSITY	3.6160070+02	7.1570202+01	1.4276172+01	2.8008772+00	5.6923142+01
KAPPA(P)	3.2639470+01	1.1937931+01	3.7322877+01	2.2533290+01	1.9967525+01
KAPPA(R)	4.2020530+01	2.5330626+01	2.1042240+01	1.9780720+01	1.9427667+01
THERMAL = 5.0704430-04			13 DENSITIES		
DENSITY	5.0704430+04	7.1115733+05	8.3654410+06	8.0895480+07	8.3654360+09
KAPPA(P)	1.9308410+01	1.9308327+01	1.9308269+01	1.9308269+01	1.9308269+01
KAPPA(R)	1.9309630+01	1.9309630+01	1.9309673+01	1.9309673+01	1.9309673+01
THERMAL = 699.9900			13 DENSITIES		
DENSITY	5.9670920+02	1.1829390+02	2.3614064+01	4.7100110+00	9.4292682+01
KAPPA(P)	1.3309910+01	3.9399960+01	2.1923611+01	1.9291837+01	1.8923520+01
KAPPA(R)	2.6006100+01	2.1074762+01	1.9641290+01	1.9242419+01	1.9140919+01

GREY ABSORPTION COEFFICIENTS CONTINUED

TETA = 699.9900 CONTINUED

DENSITY 9.0017900-04 1.1780334-04 1.3459218-05 1.4725425-06 1.3859221-07
 KAPPA(P) 1.8008410-01 1.9008373-01 1.8008350-01 1.8008350-01 1.8008350-01
 KAPPA(R) 1.9095100-01 1.9095100-01 1.9095089-01 1.9095089-01 1.9095089-01

TETA = 999.9920 13 DENSITIES

DENSITY 1.0140540-03 2.0145720-02 4.0324520-01 8.0557720-00 1.6100114-00 3.2186720-01 5.9161630-02 1.0057315-02
 KAPPA(P) 7.3551200-01 2.7711540-01 2.0055130-01 1.8087860-01 1.8036600-01 1.8013622-01 1.8009330-01 1.8008350-01
 KAPPA(R) 4.3069040-01 2.6204170-01 1.9385070-01 1.9161215-01 1.9103070-01 1.9097040-01 1.9095710-01 1.9095100-01

DENSITY 1.5472700-03 2.0114570-04 2.3664130-05 2.5143150-06 2.3664130-07
 KAPPA(P) 1.8008350-01 1.8008350-01 1.8008350-01 1.8008350-01 1.8008350-01
 KAPPA(R) 1.9095100-01 1.9095089-01 1.9095089-01 1.9095089-01 1.9095089-01

53	DIANE/SCAT ME-1A	TEMP(1.5-1.54)	11-6-67	SADY INPUT TAPES(3986-3993)	MATERL = 1016	ME = 900
GREY ABSORPTION COEFFICIENTS						
24 TEMPERATURES						
13 DENSITIES						
THETA = 1.5000						
DENSITY	0.3969070+01	3.9579970+00	2.55628520-01	1.35693037-02	6.37276400-06	2.13100000-07
KAPPA(P)	2.30812730+04	1.79368920+04	1.25450879+04	9.18519326+03	1.37095790+03	5.30003730+01
KAPPA(R)	3.34213650+04	3.22006510-01	3.20898560+01	3.18972106+01	2.96102610+01	3.20022000+00
DENSITY	2.9501140+00	3.73630020+09	3.78221490-10	9.50930500-11	3.60967670-12	
KAPPA(P)	0.9260700+00	1.10756670+00	1.0010360-01	3.46595760-02	2.07731220-02	
KAPPA(R)	5.3370170+01	9.58615820-02	3.18570000-02	2.19059370-02	2.20367000-02	
THETA = 2.2500						
DENSITY	1.00690002+03	0.31556600-02	5.81820630-03	9.92271110-04	6.00706130-05	3.30311000-07
KAPPA(P)	2.09703300+05	1.81273990+05	1.13939169+05	3.15908070+04	0.69096520+03	2.10400100+01
KAPPA(R)	1.03323000+03	1.04035560+03	8.65125020+02	9.94565790+02	1.60750730+02	3.64332910+01
DENSITY	0.30829570-04	0.13094990-09	9.19636110-10	9.26720900-11	3.97040500-12	
KAPPA(P)	7.21250520+00	1.18378055+00	2.1161610-01	5.9173670-02	0.29470030-02	
KAPPA(R)	7.25350550-01	2.339308170-01	7.57035070-02	9.41932160-02	0.00317050-02	
THETA = 3.0000						
DENSITY	1.60026400-01	2.06573930-02	2.99602300-03	5.11600850-04	9.09231000-05	3.23022020-07
KAPPA(P)	3.75302700+05	1.99490110+05	0.00182500+04	1.60265967+04	3.20555910+03	0.43501800+02
KAPPA(R)	1.30730000+04	7.60027900+03	3.03765000+03	1.24090000+03	0.27223330+02	1.81931800+02
DENSITY	0.70220000-06	5.00032930-09	5.32371310-10	5.35290500-11	0.90006510-12	
KAPPA(P)	5.20407000+00	9.00773020-01	1.95924030-01	7.02940000-02	0.29270610-02	
KAPPA(R)	1.05306030+00	4.57253320-01	9.69000110-02	0.00011100-02	0.07000590-02	
THETA = 3.0000						
DENSITY	1.03735000-01	2.35100710-02	3.67053700-03	5.67015330-04	9.50313930-05	1.72136150-05
KAPPA(P)	3.10007100+05	1.93705300+05	9.00223050+04	2.10507590+04	3.09472720+03	7.39047100+02
KAPPA(R)	7.05527570+04	3.77066970+04	1.27800889+04	2.59003000+03	5.20062000+02	1.19007317+02
DENSITY	5.70050130-08	0.02000270-09	7.00203010-10	7.05020150-11	0.15036200-12	
KAPPA(P)	5.24749100+00	0.05700000-01	2.10420550-01	9.70370050-02	0.90030600-02	
KAPPA(R)	1.00300030+00	3.00500000-01	1.10071303-01	0.01907160-02	0.60030950-02	
THETA = 7.0000						
DENSITY	1.50600170-01	2.51271000-02	0.10709500-03	0.90017070-04	1.16172900-04	3.30067150-04
KAPPA(P)	2.07013450+05	1.90320550+05	0.50950750+04	2.02502550+04	0.00002000+03	0.00002000+03
KAPPA(R)	1.73057070+05	5.00163010+04	1.222500025+04	2.00027000+03	0.99720010+02	3.00000000+01

RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 7.6600 CONTINUED					
DENSITY	7.6600	7.6600	DENSITY	7.6600	7.6600
KAPPA(P)	7.1320000-00	8.43159300-09	8.9934000-10	8.9000000-11	7.6100000-12
KAPPA(R)	9.10700-1000	9.42131000-01	2.10100000-01	1.10007000-01	1.10010000-01
KAPPA(R)	2.5440000-1000	3.39940000-01	1.00000000-01	1.10000000-01	1.10000000-01
THETA = 10.0000 13 DENSITIES					
DENSITY	10.0000	10.0000	DENSITY	10.0000	10.0000
KAPPA(P)	1.6201100-00	2.00855100-00	2.19000000-00	2.19000000-00	2.19000000-00
KAPPA(R)	1.50193000-00	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00
KAPPA(R)	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00
THETA = 13.0000 13 DENSITIES					
DENSITY	13.0000	13.0000	DENSITY	13.0000	13.0000
KAPPA(P)	1.7320000-00	2.00855100-00	2.19000000-00	2.19000000-00	2.19000000-00
KAPPA(R)	1.50193000-00	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00
KAPPA(R)	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00
THETA = 22.4999 13 DENSITIES					
DENSITY	22.4999	22.4999	DENSITY	22.4999	22.4999
KAPPA(P)	1.7320000-00	2.00855100-00	2.19000000-00	2.19000000-00	2.19000000-00
KAPPA(R)	1.50193000-00	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00
KAPPA(R)	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00
THETA = 33.9998 13 DENSITIES					
DENSITY	33.9998	33.9998	DENSITY	33.9998	33.9998
KAPPA(P)	1.7320000-00	2.00855100-00	2.19000000-00	2.19000000-00	2.19000000-00
KAPPA(R)	1.50193000-00	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00
KAPPA(R)	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00	1.50207100-00

ANIONIC POLYMERIZATION

[illegible]

GREY ABSORPTION COEFFICIENTS CONTINUED

TMETA = 224.99590 CONTINUED

DENSITY 5.26576-50-00 6.54246000-07 8.05345190-08 8.56679600-09 8.05345310-10
 KAPPA(P) 2.1271620-01 2.02202300-01 2.01472170-01 2.01394450-01 2.01390390-01
 KAPPA(R) 2.0764860-01 1.98030610-01 1.98161280-01 1.99111150-01 1.98105800-01

TMETA = 300.00012

11 DENSITIES

DENSITY 7.45239600-00 1.97762300-00 4.61947710-01 5.11192020-02 1.01925422-02 2.03536120-03 3.78024590-04 6.35802340-05
 KAPPA(P) 4.03005400-03 6.91139710-02 1.44875800-02 2.87196300-01 5.78231080-00 1.29190722-00 3.77678570-01 2.22369920-01
 KAPPA(R) 6.06175150-02 2.40904680-02 5.92563790-01 1.32211970-01 2.04699200-00 6.09310190-01 2.82113720-01 2.89820860-01

DENSITY 9.74147700-06

13 DENSITIES

KAPPA(P) 4.30024950-01 2.02320720-01 1.27159327-06 1.49544620-07 1.59948662-09 1.49598662-09
 KAPPA(R) 1.94724700-01 1.92747600-01 2.01799030-01 2.01842010-01 2.01839190-01 1.96621150-01

TMETA = 499.99553

13 DENSITIES

DENSITY 1.24983192-01 2.37016240-00 4.61359370-01 9.12366870-02 1.81642300-02 3.62923290-03 6.64998350-04 1.13805282-04
 KAPPA(P) 8.34650000-02 2.06170510-02 4.45783800-01 8.89896820-00 1.90857510-00 4.98047510-01 2.40484650-01 2.05969410-01
 KAPPA(R) 1.43174230-02 4.60946910-01 1.18060319-01 2.40475340-00 6.39643660-01 2.85726280-01 2.12598680-01 1.99772110-01

DENSITY 1.74037550-05

13 DENSITIES

KAPPA(P) 2.01661490-01 2.01036490-01 2.30752240-01 2.00942390-01 2.00941190-01 2.66785820-09
 KAPPA(R) 1.98046500-01 1.07791270-01 1.97757050-01 1.97752900-01 1.97752510-01

TMETA = 699.99575

13 DENSITIES

DENSITY 6.06912410-01 3.63256300-00 7.61547950-01 1.51014100-01 3.00036640-02 6.01160210-03 1.10487620-03 1.87822720-04
 KAPPA(P) 3.50041400-02 8.52927450-01 1.72599860-01 3.69482400-00 8.51094760-01 3.02890700-01 2.13607380-01 2.01986770-01
 KAPPA(R) 3.46315590-01 1.02845120-01 2.30271410-00 6.465035190-01 3.00011940-01 2.19881170-01 2.00550530-01 1.94870920-01

DENSITY 2.90055470-05

13 DENSITIES

KAPPA(P) 1.94127490-01 1.96844510-01 1.98812920-01 4.41931910-07 4.69552910-08 4.41932040-09
 KAPPA(R) 1.96205630-01 1.96120110-01 1.96108740-01 1.96107360-01 1.96107160-01

TMETA = 999.99567

13 DENSITIES

DENSITY 3.34430510-01 6.51058240-00 1.29174910-00 2.57758030-01 5.13626000-02 1.02644483-02 1.80453586-03 3.20761400-04
 KAPPA(P) 1.27463130-02 3.46000400-01 7.36539790-00 1.55639520-00 4.31241420-01 2.33067700-01 2.01174010-01 1.94883460-01
 KAPPA(R) 7.59775620-00 4.40083230-00 6.79425050-01 3.07537580-01 2.23530140-01 2.01414970-01 1.95605960-01 1.94391330-01

DENSITY 4.93383990-05

13 DENSITIES

KAPPA(P) 1.95756490-01 1.95443130-01 1.95628270-01 1.95628310-01 1.95628120-01 7.54583720-09
 KAPPA(R) 1.94203400-01 1.94173920-01 1.94169040-01 1.94169030-01 1.94169030-01

GRAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 1099.9990			13 DENSITIES		
DENSITY	5.995000000	1.192870000	2.371305000	0.725330000	9.435453000
KAPPA(P)	2.531007000	6.054770000	1.582026100	0.399510000	2.361100700
KAPPA(R)	1.106355000	0.036910000	2.000437000	2.071052000	1.957600700
THETA = 1099.9990			13 DENSITIES		
DENSITY	7.000000000	1.170320000	1.386261500	1.472903500	1.386261700
KAPPA(P)	1.800000000	1.300000000	1.630000000	1.800000000	1.800000000
KAPPA(R)	1.900000000	1.900000000	1.900000000	1.900000000	1.900000000
THETA = 2249.9990			13 DENSITIES		
DENSITY	1.097500000	2.100571200	4.350719200	0.600077100	1.733350500
KAPPA(P)	0.590000000	2.102000000	5.522720000	2.000000000	1.950752200
KAPPA(R)	0.232510000	2.997101700	2.205500500	1.900000000	1.929000500
THETA = 1099.9990			13 DENSITIES		
DENSITY	1.005170000	2.104720000	2.506730000	2.705903100	2.506731700
KAPPA(P)	1.800000000	1.800000000	1.800000000	1.800000000	1.800000000
KAPPA(R)	1.900000000	1.900000000	1.900000000	1.900000000	1.900000000
THETA = 3000.0000			13 DENSITIES		
DENSITY	2.004730000	4.002501000	0.007179200	1.012362300	3.219740200
KAPPA(P)	0.000000000	1.020000000	3.200413000	2.001000000	1.900300500
KAPPA(R)	0.000000000	2.000000000	2.000000000	1.900000000	1.910000700
THETA = 1099.9990			13 DENSITIES		
DENSITY	3.003100000	4.021100000	4.730733200	5.020000000	4.730736700
KAPPA(P)	1.800000000	1.800000000	1.800000000	1.800000000	1.800000000
KAPPA(R)	1.900000000	1.900000000	1.900000000	1.900000000	1.900000000
THETA = 4999.9990			13 DENSITIES		
DENSITY	3.004000000	7.130459000	1.037277600	2.875305000	5.701942000
KAPPA(P)	2.000000000	5.536053100	2.000000000	1.957290000	1.001000000
KAPPA(R)	2.000000000	2.000000000	1.000000000	1.929990000	1.913000700
THETA = 1099.9990			13 DENSITIES		
DENSITY	3.310000000	7.171053000	0.000000000	0.960000000	0.960000000
KAPPA(P)	1.800000000	1.800000000	1.800000000	1.800000000	1.800000000
KAPPA(R)	1.900000000	1.900000000	1.900000000	1.900000000	1.900000000
THETA = 6999.9990			13 DENSITIES		
DENSITY	0.001000000	1.000000000	2.300790000	0.725330000	9.435453000
KAPPA(P)	1.173000000	3.507190000	2.126100000	1.910000000	1.800000000
KAPPA(R)	2.500000000	2.000000000	1.950000000	1.920197500	1.910000000

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 6999.9900 CONTINUED

DENSITY 9.13759340-04 1.10784743-04 1.39751432-05 1.90946010-06 1.39751500-07
 KAPPA(P) 1.58045320-01 1.89045180-01 1.88045000-01 1.88045000-01 1.88045000-01
 KAPPA(R) 1.93942370-01 1.90942670-01 1.90942670-01 1.90942670-01 1.90942670-01

THETA = 9999.9920 13 DENSITIES

DENSITY 1.02436470-03 2.03263940-02 4.05486240-01 8.12230520-00 1.62405253-00 3.24562350-01 5.96572070-02 1.01014631-02
 KAPPA(P) 6.44747393-01 2.61304910-01 1.98102440-01 1.89488490-01 1.88284150-01 1.88089000-01 1.88089000-01 1.88045000-01
 KAPPA(R) 2.25818060-01 2.00663680-01 1.93009220-01 1.91477300-01 1.91042180-01 1.90959670-01 1.90945730-01 1.90943060-01

DENSITY 1.56021760-03 2.02928060-04 2.38628000-05 2.53534710-06 2.38628000-07
 KAPPA(P) 1.86045160-01 1.88045000-01 1.88045000-01 1.88045000-01 1.88045000-01
 KAPPA(R) 1.90942670-01 1.90942670-01 1.90942670-01 1.90942670-01 1.90942670-01

57		JANUARY CAT PNEUMOLIC-1A TEMP (1.841667-34.1)EV. SNOT INPUT TAPE 1250 11-8-67		MAY 2 1107		MAY 2 091	
WAVE ABSORPTION COEFFICIENTS		11 TEMPERATURES					
THERM = .06.67		13 DENSITIES					
DENSITY	1.7760896+00	2.11536390+00	1.5898520-01	9.0611970-03	8.4668840-04	2.1269050-05	1.02616805-06
KAPPA(P)	1.7144353+00	1.04576065+05	8.5038530+04	4.11866350+04	1.1856848+04	3.67116370+03	1.33209210+03
KAPPA(R)	1.62409020+03	1.51567470+03	1.20449650+03	7.54968660+02	4.50198790+02	2.73303700+02	1.30409530+02
DENSITY	6.57402-50+04	8.57342470-10	7.03709950-11	7.41237770-12	6.94919850-13		
KAPPA(P)	7.6490740+01	1.1800965+01	1.45231896+00	2.01147260-01	6.89425300-02		
KAPPA(R)	9.56231570+00	1.47016346+00	2.3354350-01	7.75314200-02	5.73230790-02		
THERM = 1.00000		13 DENSITIES					
DENSITY	4.54440+00+00	4.98241490-01	3.57631590-02	2.02132110-03	1.04852707-04	6.25244400-06	4.95201240-07
KAPPA(P)	3.2448540+00	2.0994900+05	1.7607400+05	8.52096520+04	2.61336740+04	7.68344790+03	1.68771600+03
KAPPA(R)	6.04418070+03	2.30234490+03	3.9094920+03	2.49792420+03	1.50328350+03	7.32681410+02	2.21072150+02
DENSITY	8.06439+13+04	7.47342520-10	8.71049640-11	9.12293150-12	7.76600860-13		
KAPPA(P)	6.6070740+01	3.43614030+00	1.03173945+00	1.60218940-01	7.60891940-02		
KAPPA(R)	7.5222640+00	4.93080130-01	1.72254370-01	7.24126930-02	6.52603290-02		
THERM = 1.50000		13 DENSITIES					
DENSITY	3.24147400-01	3.05991510-02	2.23090360-03	1.71073690-04	1.75724700-05	2.50009050-06	4.11482250-07
KAPPA(P)	9.0542300+03	8.46201230+05	5.1817640+05	2.11508400+05	4.40187050+04	7.36733390+03	1.1130000+03
KAPPA(R)	1.1321401+03	7.96416350+04	4.54442660+04	2.90194380+04	5.28713050+03	9.78123350+02	1.52416010+02
DENSITY	9.74189670-04	1.06731472-09	1.11934213-10	1.13704687-11	1.04093667-12		
KAPPA(P)	2.6946740+01	5.12775010+00	8.11342900-01	1.68418050-01	9.34822240-02		
KAPPA(R)	5.37650750+03	1.23174379+00	2.59037970-01	1.94767032-01	8.72703950-02		
THERM = 2.25000		13 DENSITIES					
DENSITY	7.96062470-02	6.19579580-03	8.70722710-04	1.14656951-04	2.03440930-05	3.67230900-06	5.78296030-07
KAPPA(P)	1.1622800+00	7.49559700+05	4.24555320+05	1.12150631+05	1.97716803+04	3.99151500+03	8.8979000+02
KAPPA(R)	5.69342450+03	3.62713360+05	1.441914930+05	3.50600330+04	6.46006470+03	1.31839780+03	2.72203700+02
DENSITY	1.26422091-04	1.58193060-09	1.60155030-10	1.59671140-11	1.43373267-12		
KAPPA(P)	2.44493720+01	3.10513120+00	5.47287610-01	1.71048840-01	1.20001140-01		
KAPPA(R)	8.23240990+03	9.20613620-01	2.31890500-01	1.33260660-01	1.14890519-01		
THERM = 3.40000		13 DENSITIES					
DENSITY	2.01135470-04	8.74503920-03	1.00180750-03	1.61059950-04	2.71829490-05	4.90605710-06	8.29203700-07
KAPPA(P)	4.26231910+05	3.43127800+05	3.20640150+05	1.02044010+04	1.93844770+04	3.34200500+03	6.30230010+02
KAPPA(R)	6.97403680+03	4.21026330+05	1.58050000+05	3.63572850+04	6.19497020+03	1.02751430+03	1.90452610+02

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.00000 CONTINUED			13 DENSITIES		
DENSITY	1.7721500-03	2.1535600-09	2.2361540-10	2.24808720-11	2.09677640-12
KAPPA(P)	1.4476250-01	2.6509350-00	5.04513140-01	1.85388250-01	1.48094600-01
KAPPA(R)	5.7045500-00	9.09534260-01	2.57452770-01	1.54090180-01	1.43640730-01
THETA = 5.00000			13 DENSITIES		
DENSITY	5.1592270-02	5.21544010-03	1.30235365-03	2.18425460-04	3.79535560-05
KAPPA(P)	9.54387170-03	4.28931890-05	2.57520800-05	7.52491560-04	1.61860321-04
KAPPA(R)	3.9630650-03	3.02229410-05	1.21694596-05	2.89003770-04	5.51728930-03
DENSITY	2.50768710-03	3.16504040-09	3.68470700-10	3.85236050-11	3.57731070-12
KAPPA(P)	1.23745721-01	1.73908720-00	3.31460050-01	1.64115340-01	1.518663370-01
KAPPA(R)	4.02102550-00	6.32407490-01	2.113601750-01	1.55536630-01	1.49046040-01
THETA = 7.00000			13 DENSITIES		
DENSITY	6.24403470-02	1.03700755-02	1.71107512-03	2.92490420-04	5.11919630-05
KAPPA(P)	4.50393170-05	3.00216740-05	1.64449630-05	4.81655780-04	9.13228260-03
KAPPA(R)	1.91784750-03	1.70447040-05	8.90354530-04	2.27490900-04	4.18767500-03
DENSITY	3.9557000-03	5.03622100-09	5.63841640-11	6.11060660-11	5.73037670-12
KAPPA(P)	5.6358610-00	9.78495670-01	2.38703770-01	1.64225140-01	1.55863750-01
KAPPA(R)	2.18444270-00	4.30457320-01	1.93526660-01	1.60727480-01	1.53242450-01
THETA = 10.00000			13 DENSITIES		
DENSITY	4.19134410-02	1.37710953-02	2.38632920-03	4.15157790-04	7.47214790-05
KAPPA(P)	2.69714350-05	1.65665120-05	9.23900990-04	2.44012240-04	4.19524040-03
KAPPA(R)	7.61547070-04	7.26522730-04	4.71099700-04	1.44907387-04	2.54893260-03
DENSITY	6.4435900-08	8.32310930-09	9.78167800-10	1.03916470-10	9.78031090-12
KAPPA(P)	2.6459500-00	4.75734620-01	1.92403990-01	1.54804950-01	1.55378530-01
KAPPA(R)	1.10724060-00	3.06208810-01	1.79110200-01	1.55948720-01	1.52728260-01
THETA = 15.00000			13 DENSITIES		
DENSITY	1.14240000-01	2.03006300-02	3.67993210-03	6.75252420-04	1.26166940-04
KAPPA(P)	1.30604636-05	8.03526150-04	3.52045250-04	7.64314230-03	1.30808950-03
KAPPA(R)	2.51236420-04	2.04449450-04	1.44534578-04	5.62681580-03	1.03666380-03
DENSITY	1.17493033-07	1.52703930-08	1.79457072-09	1.84868540-10	1.67963420-11
KAPPA(P)	9.15520440-01	2.52209300-01	1.66542950-01	1.58083450-01	1.66081610-01
KAPPA(R)	5.77989850-01	2.22735570-01	1.63961930-01	1.55358330-01	1.63087630-01

GMEY ABSORPTION COEFFICIENTS CONTINUED

TMEY = 22.49599		13 DENSITIES						
DENSITY	1.9041540-01	3.3639400-02	6.2192330-03	1.1707155-03	2.28207010-04	4.50281030-05	8.23041270-06	1.38994200-06
KAPPA(1)	5.5089530-04	3.14032610-04	1.09966790-04	2.21940390-03	3.69536290-02	6.29032110-01	1.11333262-01	2.35179250-00
KAPPA(4)	7.60237510-03	5.41825930-02	3.17809170-03	1.20796260-03	2.02622240-02	4.02676330-01	6.00189790-00	1.39952333-00
TMEY = 4.02290-00-07		2.403337150-00	2.80001790-09	2.70399080-10	2.31498320-11			
DENSITY	7.40042800-01	2.96379370-01	2.00358290-01	1.97359170-01	2.0377780-01			
KAPPA(1)	4.10220400-01	2.16895590-01	1.55265190-01	1.91916670-01	1.99862230-01			
TMEY = 33.99555		13 DENSITIES						
DENSITY	3.10435170-01	5.80777300-02	1.0960142-02	2.11620900-03	4.07304700-04	7.64211620-05	1.32764990-05	2.10354010-06
KAPPA(1)	2.5601170-04	1.06747870-04	3.22049670-03	6.65340320-02	1.75032330-02	5.44237690-01	1.30137632-01	3.94107090-00
KAPPA(4)	3.72275170-03	1.03859320-03	7.14680700-02	1.90918730-02	4.61046110-01	1.11592637-01	2.36699700-00	7.40005720-01
TMEY = 3.11390-10-07		3.95089020-06	4.59544610-09	4.02239620-10	4.50147930-11			
DENSITY	4.90015990-01	3.02280030-01	2.10985460-01	2.10036150-01	2.11305990-01			
KAPPA(1)	3.10412990-01	2.20852320-01	2.05773960-01	2.06129220-01	2.07404220-01			

W				JIANE/SCAT DPLYCA				19 FREQ. TEMP. (1.-2250.) CI/RTM-AFWL 11-25-66				MATERL = 1124				MX = 061			
KEY ABSORPTION COEFFICIENTS				21 TEMPERATURES															
THETA = 1.00000				13 DENSITIES															
DENSITY	1.30501007+00	1.43244840-01	1.15042933-02	0.41026850-04	0.08014590-05	1.05153971-05	1.20121142-06	1.11050005-07				1.20121142-06	1.11050005-07						
KAPPA(P)	1.59244521+04	1.34446320+04	1.18644520+04	8.13792060+03	3.72017470+03	1.30150420+03	5.07557980+02	1.35444130+02				5.07557980+02	1.35444130+02						
KAPPA(R)	5.74810630+02	5.16333310+02	7.55315830+02	5.01047490+02	3.33126400+02	1.36855130+02	4.52800390+01	1.30873300+01				4.52800390+01	1.30873300+01						
DENSITY	1.21499000+00	1.35750149-09	1.49043140-10	1.54620450-11	1.45390231-12														
KAPPA(P)	4.34327043+01	3.75937150+00	5.21803860-01	1.51987100-02	3.81309500-02														
KAPPA(R)	3.14706070+00	5.66041010-01	1.11048859-01	4.57875980-02	3.47604840-02														
THETA = 1.50000				13 DENSITIES															
DENSITY	2.40304013-01	3.21040530-02	3.19117840-03	3.34033760-04	3.71090410-05	4.96215760-06	7.52375760-07	1.17639617-07				7.52375760-07	1.17639617-07						
KAPPA(P)	6.90300000+00	5.41195070+04	4.53016760+04	2.48211150+04	8.80007150+03	2.23792400+03	5.01924130+02	7.04870460+01				5.01924130+02	7.04870460+01						
KAPPA(R)	4.60026570+03	0.18337720+03	5.31227780+03	3.94926510+03	1.35496100+03	6.06760390+02	1.42039320+02	2.33359700+01				1.42039320+02	2.33359700+01						
DENSITY	1.75474000+00	4.21713530-09	2.41445540-10	2.07521790-11	1.67965973-12														
KAPPA(P)	1.14772000+01	1.58049615+00	2.70973840-01	6.90747430-02	5.78442050-02														
KAPPA(R)	3.25103250+00	4.95343515-01	1.10140772-01	5.97566370-02	5.45383040-02														
THETA = 2.25000				13 DENSITIES															
DENSITY	1.24335000+01	1.45030744-02	1.63295665-03	2.21673500-04	3.67504530-05	6.75802470-06	1.14955003-06	1.46540050-07				1.14955003-06	1.46540050-07						
KAPPA(P)	1.37522000+03	4.67256330+04	6.04550300+04	2.22834580+04	5.89721140+03	1.23999100+03	2.60957650+02	6.50013450+01				2.60957650+02	6.50013450+01						
KAPPA(R)	6.43706050+04	4.45054710+04	2.56103000+04	9.84776010+03	2.61639570+03	5.77751560+02	1.26164667+02	2.57296740+01				1.26164667+02	2.57296740+01						
DENSITY	2.12578000+00	4.55022660-09	2.84223600-10	2.80453020-11	2.35870140-12														
KAPPA(P)	1.31537774+01	1.97226109+00	2.96760760-01	9.30664990-02	7.28406920-02														
KAPPA(R)	4.42059090+00	0.54493960-01	1.44133370-01	7.57003040-02	7.02163560-02														
THETA = 3.40000				13 DENSITIES															
DENSITY	3.40550200-02	1.19221295-02	1.32126313-03	3.01849300-04	5.00730860-05	8.36021480-06	1.38458524-06	2.15944340-07				1.38458524-06	2.15944340-07						
KAPPA(P)	1.33070000+05	7.60373490+04	3.85727270+04	1.79643390+04	5.88136400+03	1.73050870+03	3.24449800+02	5.62544500+01				3.24449800+02	5.62544500+01						
KAPPA(R)	1.15434000+05	0.96041920+04	3.13920466+04	1.11107003+04	3.03993040+03	6.84550900+02	1.25344499+02	2.32482520+01				1.25344499+02	2.32482520+01						
DENSITY	2.97371400-04	3.43756090-09	3.95040880-10	4.04732490-11	3.47307790-12														
KAPPA(P)	3.54596000+00	1.47636486+00	2.50409300-01	9.96793270-02	8.89530130-02														
KAPPA(R)	3.94136120+00	0.14517560-01	1.51934156-01	8.94363570-02	8.69506990-02														
THETA = 5.00000				13 DENSITIES															
DENSITY	8.63956460-02	1.47373820-02	2.32112330-03	3.74702500-04	6.45263480-05	1.13270150-05	1.86374990-06	2.97446290-07				1.86374990-06	2.97446290-07						
KAPPA(P)	1.04300010+05	6.35941460+04	3.54004530+04	1.74807950+04	5.11410090+03	1.14020210+03	2.10015070+02	3.69065940+01				2.10015070+02	3.69065940+01						
KAPPA(R)	9.38037540+04	5.43974500+04	2.47784570+04	9.53229590+03	2.62134340+03	5.59404890+02	1.01400444+02	1.70333280+01				1.01400444+02	1.70333280+01						

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.00000 CONTINUED

DENSITY 4.2102130-03 5.12866770-04 9.7959660-10 5.7388370-11 5.1000390-12
 KAPPA(P) 6.51133450-03 1.0315820-00 2.1459590-01 1.1553185-01 1.06582280-01
 KAPPA(R) 2.75326920-03 4.5778820-01 1.47840250-01 1.07031601-01 1.04613040-01

THETA = 7.00000 13 DENSITIES

DENSITY 1.0314550-01 1.7796810-02 2.9102330-03 4.0567350-04 8.4202410-05
 KAPPA(P) 7.1359700-04 3.4589180-04 3.4992590-04 1.4822953-04 3.74361110-03
 KAPPA(R) 7.3599250-04 4.6373790-04 2.4645960-04 8.32180090-03 1.78027120-03

DENSITY 3.8099170-08 7.16553770-09 7.48097110-10 7.7508200-11 7.08791530-12
 KAPPA(P) 6.1006740-00 9.6086160-01 2.1439482-01 1.3651940-01 1.26035590-01
 KAPPA(R) 2.0327510-00 3.69227420-01 1.5653240-01 1.2811040-01 1.23961777-01

THETA = 10.00000 13 DENSITIES

DENSITY 1.3537000-01 2.33092730-02 3.91254980-03 6.46331020-04 1.10177000-04
 KAPPA(P) 7.7728840-04 4.85213890-04 2.8699430-03 1.1849610-04 2.69229410-03
 KAPPA(R) 3.4201020-04 3.48181010-04 1.79915580-04 5.46149210-03 1.10307110-03

DENSITY 8.1541940-08 1.02331440-08 1.17372915-09 1.22726050-10 1.13112072-11
 KAPPA(P) 3.7240950-00 9.35024010-01 1.92413230-01 1.37355480-01 1.34177600-01
 KAPPA(R) 1.35037310-00 2.69447750-01 1.59227110-01 1.32997760-01 1.32429080-01

THETA = 15.00000 13 DENSITIES

DENSITY 1.8541800-04 3.20511730-02 5.68472190-03 9.8204440-04 1.74246820-04
 KAPPA(P) 3.9241050-04 3.05920940-04 2.25949850-04 7.82302410-03 1.76530210-03
 KAPPA(R) 3.77450650-04 2.8027420-04 1.41776027-04 4.14777770-03 8.67173170-02

DENSITY 1.3047050-07 1.73509280-04 1.99460460-09 2.0737130-10 1.09092100-11
 KAPPA(P) 1.63578003-00 3.4244640-01 1.65241700-01 1.45709080-01 1.46504010-01
 KAPPA(R) 7.73452430-01 2.34267080-01 1.55535850-01 1.43915780-01 1.40468320-01

THETA = 22.49999 13 DENSITIES

DENSITY 2.7594640-01 4.60613480-02 8.37752330-03 1.46822650-03 2.71407910-04
 KAPPA(P) 4.33780950-04 3.03338620-04 1.48251050-04 8.34326590-03 8.67107400-02
 KAPPA(R) 2.6230030-04 4.06850390-04 1.01731970-04 2.73377570-03 4.47310480-02

DENSITY 2.29771030-07 2.89571180-08 3.31009160-09 3.41371450-10 3.12960310-11
 KAPPA(P) 6.7733650-01 2.5986240-01 1.69273780-01 1.6059520-01 1.43093760-01
 KAPPA(R) 4.7630600-01 2.10597830-01 1.63369400-01 1.58016620-01 1.40726320-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 30.99°			13 DENSITIES		
DENSITY	4.1249E-04	7.3029060-02	1.31817500-02	2.41520770-03	9.59270100-04
KAPPA(P)	2.7000000-04	1.64321900-04	6.21733080-03	1.59882100-03	3.30976350-02
KAPPA(R)	1.43993E-04	1.02413420-04	4.49976720-03	1.11902500-03	2.11300010-02
DENSITY	5.65297E-07	4.89051540-08	5.55487460-09	5.65755110-10	5.17876270-11
KAPPA(P)	6.52000E-07	2.38773230-07	1.83748990-07	1.70146530-07	1.82929760-07
KAPPA(R)	3.65041E-07	1.98007570-07	1.73174670-07	1.76061830-07	1.80401920-07
THETA = 50.0000°			13 DENSITIES		
DENSITY	0.54941E-04	1.17679211-01	2.15302250-02	4.02732470-03	7.70140990-04
KAPPA(P)	1.4409751E-04	6.79272400-03	2.87000900-03	7.94759420-02	1.83019910-02
KAPPA(R)	7.17190E-05	4.33611100-03	2.04919210-03	5.22590230-02	1.05760170-02
DENSITY	6.25020E-07	7.76048570-08	8.84733140-09	9.29950400-10	8.70846920-11
KAPPA(P)	3.32115E-07	2.45031730-07	1.99876610-07	1.93809990-07	1.93889060-07
KAPPA(R)	2.05512E-07	2.04978940-07	1.93257840-07	1.90932920-07	1.91203300-07
THETA = 69.9998°			13 DENSITIES		
DENSITY	4.76537E-05	1.78541350-01	3.29577760-02	6.17696040-03	1.16045051-03
KAPPA(P)	9.11956E-05	4.54223460-03	1.77126970-03	4.98506600-02	1.19476175-02
KAPPA(R)	5.22225E-05	3.14314740-03	1.28836710-03	2.88475140-02	5.25757460-01
DENSITY	4.50440E-07	1.22722510-07	1.44025607-08	1.52963000-09	1.43957930-10
KAPPA(P)	4.10598E-07	2.23755130-07	1.97764960-07	1.94621620-07	1.94277250-07
KAPPA(R)	2.64502E-07	2.04760560-07	1.94052020-07	1.92135000-07	1.91611770-07
THETA = 89.9998°			13 DENSITIES		
DENSITY	1.52175E-05	2.79502510-01	5.04376020-02	9.34140600-03	1.77123190-03
KAPPA(P)	7.03216E-05	3.51243530-03	1.21548610-02	3.04939960-02	7.50756290-01
KAPPA(R)	4.13222E-05	2.35740310-03	6.32196840-02	1.66803750-02	3.25279260-01
DENSITY	1.60782E-09	2.08916770-07	2.45574650-08	2.54450360-09	2.40986590-10
KAPPA(P)	2.77906E-09	2.05152840-07	1.95767220-07	1.93729630-07	1.98199530-07
KAPPA(R)	2.34455E-09	2.02635790-07	1.73824340-07	1.73828770-07	1.93570410-07
THETA = 109.9995°			13 DENSITIES		
DENSITY	2.51330E-05	4.55813070-01	8.32097310-02	1.57980420-02	3.09571000-03
KAPPA(P)	5.19577E-05	2.25032200-03	6.45524990-02	1.44535610-02	3.09510240-01
KAPPA(R)	2.53297E-05	1.35340600-03	4.26239310-02	8.48790210-01	1.55376479-01

RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 149.9995 CONTINUED			13 DENSITIES		
DENSITY	2.90182700-09	3.72090000-07	4.33703500-08	4.59866400-09	4.32707200-10
KAPPA(P)	2.34762010-01	2.66565900-01	2.03130550-01	2.02807500-01	2.02774650-01
KAPPA(R)	2.22092200-01	2.02281490-01	2.00016360-01	1.99091410-01	1.990879420-01
THETA = 244.9990			13 DENSITIES		
DENSITY	4.10059020+00	7.69544350-01	1.44967900-01	2.63184400-02	5.60404860-03
KAPPA(P)	4.72670000+03	8.97313210+02	2.24401690+02	4.84242400+01	1.13124920+01
KAPPA(R)	1.02226290+03	4.77633630+02	1.44592710+02	3.07509210+01	6.39728690+00
DENSITY	5.19275000-06	6.75636960-07	7.94228290-08	8.41575810-09	7.89359090-10
KAPPA(P)	2.13100250-01	2.05179300-01	2.03159470-01	2.03444710-01	2.04111800-01
KAPPA(R)	2.13221010-01	2.02149240-01	2.00565760-01	2.00665480-01	2.01295350-01
THETA = 300.00012			13 DENSITIES		
DENSITY	7.10767000+00	1.30179700-00	2.62204890-01	5.12241030-02	1.01101541-02
KAPPA(P)	1.21215600+03	3.73539700+02	1.05562441+02	2.61443280+01	6.14974420+00
KAPPA(R)	4.65326030+02	1.80137360+02	5.24441620+01	1.04717313+01	2.28126270+00
DENSITY	7.25446100-06	1.24447105-06	1.46409750-07	1.55436620-08	1.46295140-09
KAPPA(P)	2.11341000-01	2.05056460-01	2.04714480-01	2.04612770-01	2.04603360-01
KAPPA(R)	2.06435030-01	2.02412170-01	2.01940540-01	2.01797610-01	2.01777840-01
THETA = 434.99993			13 DENSITIES		
DENSITY	1.24504300+01	2.34343050+00	4.56074540-01	8.94491520-02	1.72780060-02
KAPPA(P)	5.07906000+02	1.93202040+02	5.03218300+01	1.10924910+01	2.61167060+00
KAPPA(R)	2.47080000+02	1.13550499+02	2.69623910+01	5.11519220+00	1.22392681+00
DENSITY	1.70592400-05	2.21761120-06	2.60894460-07	2.77200480-08	2.60845000-09
KAPPA(P)	2.07612570-01	2.05130690-01	2.04858190-01	2.04826300-01	2.04823020-01
KAPPA(R)	2.04900510-01	2.02068570-01	2.01746760-01	2.01712680-01	2.01708840-01
THETA = 592.99976			13 DENSITIES		
DENSITY	1.35769200+01	3.81127200+00	7.47174360-01	1.47849560-01	2.94430610-02
KAPPA(P)	5.17672000+02	4.02622000+01	2.26592500+01	5.34456410+00	1.32306190+00
KAPPA(R)	1.23733001+02	5.63323480+01	1.45694953+01	3.14928490+00	8.33763920-01
DENSITY	4.92572000-05	3.67344740-06	4.32172970-07	4.59183970-08	4.32173040-09
KAPPA(P)	2.05397730-01	2.04662040-01	2.04567350-01	2.04556100-01	2.04554870-01
KAPPA(R)	2.02405530-01	2.01754970-01	2.01676770-01	2.01637090-01	2.01644080-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 99.997		13 DENSITIES	
DENSITY	5.2754500+01	1.26631742+00	2.51496240-01
KAPPA(P)	1.3912420+02	9.35703970+00	2.14615700+00
KAPPA(R)	4.1797620+01	5.99140680+00	1.39970611+00
DENSITY	4.8446520+03	7.37920340+07	7.84040790+08
KAPPA(P)	2.0430220+01	2.04539720+01	2.04535240+01
KAPPA(R)	2.0130420+01	2.01200970+01	2.01198760+01
THETA = 149.9970		13 DENSITIES	
DENSITY	5.9409420+01	1.17214556+01	8.61616070+01
KAPPA(P)	5.0757130+01	1.46555641+01	8.24851670+01
KAPPA(R)	9.9213070+00	3.64322760+00	3.93217400+01
DENSITY	8.5036200+05	1.15229491+05	1.44037410+07
KAPPA(P)	2.0424550+01	2.04141480+01	2.04129230+01
KAPPA(R)	2.00311020+01	2.00273970+01	2.00268360+01
THETA = 424.9970		13 DENSITIES	
DENSITY	1.00301030+02	2.18174350+01	8.47876240+01
KAPPA(P)	2.50513310+01	5.9989920+00	4.10701910+01
KAPPA(R)	2.09367770+00	7.10327220+01	2.34062750+01
DENSITY	1.6213070+04	2.11690570+05	2.49046790+08
KAPPA(P)	2.0211870+01	2.0208210+01	2.02083760+01
KAPPA(R)	1.9008400+01	1.90053320+01	1.90053320+01
DENSITY	3.2754500+01	1.26631742+00	2.51496240-01
KAPPA(P)	1.3912420+02	9.35703970+00	2.14615700+00
KAPPA(R)	4.1797620+01	5.99140680+00	1.39970611+00
DENSITY	4.8446520+03	7.37920340+07	7.84040790+08
KAPPA(P)	2.0430220+01	2.04539720+01	2.04535240+01
KAPPA(R)	2.0130420+01	2.01200970+01	2.01198760+01
DENSITY	5.9409420+01	1.17214556+01	8.61616070+01
KAPPA(P)	5.0757130+01	1.46555641+01	8.24851670+01
KAPPA(R)	9.9213070+00	3.64322760+00	3.93217400+01
DENSITY	8.5036200+05	1.15229491+05	1.44037410+07
KAPPA(P)	2.0424550+01	2.04141480+01	2.04129230+01
KAPPA(R)	2.00311020+01	2.00273970+01	2.00268360+01
DENSITY	1.00301030+02	2.18174350+01	8.47876240+01
KAPPA(P)	2.50513310+01	5.9989920+00	4.10701910+01
KAPPA(R)	2.09367770+00	7.10327220+01	2.34062750+01
DENSITY	1.6213070+04	2.11690570+05	2.49046790+08
KAPPA(P)	2.0211870+01	2.0208210+01	2.02083760+01
KAPPA(R)	1.9008400+01	1.90053320+01	1.90053320+01
DENSITY	3.2754500+01	1.26631742+00	2.51496240-01
KAPPA(P)	1.3912420+02	9.35703970+00	2.14615700+00
KAPPA(R)	4.1797620+01	5.99140680+00	1.39970611+00
DENSITY	4.8446520+03	7.37920340+07	7.84040790+08
KAPPA(P)	2.0430220+01	2.04539720+01	2.04535240+01
KAPPA(R)	2.0130420+01	2.01200970+01	2.01198760+01
DENSITY	5.9409420+01	1.17214556+01	8.61616070+01
KAPPA(P)	5.0757130+01	1.46555641+01	8.24851670+01
KAPPA(R)	9.9213070+00	3.64322760+00	3.93217400+01
DENSITY	8.5036200+05	1.15229491+05	1.44037410+07
KAPPA(P)	2.0424550+01	2.04141480+01	2.04129230+01
KAPPA(R)	2.00311020+01	2.00273970+01	2.00268360+01
DENSITY	1.00301030+02	2.18174350+01	8.47876240+01
KAPPA(P)	2.50513310+01	5.9989920+00	4.10701910+01
KAPPA(R)	2.09367770+00	7.10327220+01	2.34062750+01
DENSITY	1.6213070+04	2.11690570+05	2.49046790+08
KAPPA(P)	2.0211870+01	2.0208210+01	2.02083760+01
KAPPA(R)	1.9008400+01	1.90053320+01	1.90053320+01
DENSITY	3.2754500+01	1.26631742+00	2.51496240-01
KAPPA(P)	1.3912420+02	9.35703970+00	2.14615700+00
KAPPA(R)	4.1797620+01	5.99140680+00	1.39970611+00
DENSITY	4.8446520+03	7.37920340+07	7.84040790+08
KAPPA(P)	2.0430220+01	2.04539720+01	2.04535240+01
KAPPA(R)	2.0130420+01	2.01200970+01	2.01198760+01
DENSITY	5.9409420+01	1.17214556+01	8.61616070+01
KAPPA(P)	5.0757130+01	1.46555641+01	8.24851670+01
KAPPA(R)	9.9213070+00	3.64322760+00	3.93217400+01
DENSITY	8.5036200+05	1.15229491+05	1.44037410+07
KAPPA(P)	2.0424550+01	2.04141480+01	2.04129230+01
KAPPA(R)	2.00311020+01	2.00273970+01	2.00268360+01
DENSITY	1.00301030+02	2.18174350+01	8.47876240+01
KAPPA(P)	2.50513310+01	5.9989920+00	4.10701910+01
KAPPA(R)	2.09367770+00	7.10327220+01	2.34062750+01
DENSITY	1.6213070+04	2.11690570+05	2.49046790+08
KAPPA(P)	2.0211870+01	2.0208210+01	2.02083760+01
KAPPA(R)	1.9008400+01	1.90053320+01	1.90053320+01

6		DIANE/SCAT DPLYE		19 FREQ. TEMP. (1.-2250.)		CIRCU-APWL 11-20-6000200		MATERL = 1125		MX = 001	
KEY ADJUSTMENT - EFFICIENCY		21 TEMPERATURES		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES	
THETA = 1.0000		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSITY	1.305610700	1.40244400-01	1.15042935-02	0.41026450-04	0.00010590-05	1.05153971-05	1.20121142-06	1.11054005-07			
KAPPA(P)	1.592442100	1.34945320+04	1.10644520+04	0.13792060+03	3.72017470+03	1.30150420+03	5.07557900+02	1.35666130+02			
KAPPA(R)	3.76310030+02	0.16334310+02	7.55315630+02	0.41044990+02	3.33126400+02	1.36851130+02	4.52003900+01	1.39073306+01			
UENSITY	1.219909500	1.35750149-09	1.449093140-10	1.56204540-11	1.45390231-12						
KAPPA(P)	2.34917000+01	3.75957150+00	5.21463460-01	0.51967100-02	3.01369580-02						
KAPPA(R)	3.14706670+00	5.60441010-01	1.11043659-01	4.57875980-02	3.47644800-02						
THETA = 1.5000		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSITY	2.90264410-01	3.21040530-02	3.19117400-03	3.34033760-04	3.71090410-05	4.96215760-06	7.52373760-07	1.17639617-07			
KAPPA(P)	9.90523030+04	3.41195070+04	4.30167670+04	2.48211150+04	0.00071150+03	2.23792080+03	5.01924130+02	7.94070400+01			
KAPPA(R)	9.60426720+03	0.10327720+03	6.31227700+03	3.94926510+03	1.02996100+03	6.06760390+02	1.42030320+02	2.33359700+01			
UENSITY	1.74878090-08	4.21713530-09	2.41425540-10	2.07521790-11	1.67965973-12						
KAPPA(P)	1.14772603+01	1.53080618+00	2.70973800-01	0.90747930-02	5.78442050-02						
KAPPA(R)	3.26103290+00	4.53446150-01	1.10140772-01	5.97566370-02	5.45303040-02						
THETA = 2.2500		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSITY	1.22335455-01	1.45696744-02	1.63295660-03	2.21673500-04	3.67504530-05	6.75802470-06	1.19955003-06	1.66560050-07			
KAPPA(P)	1.37642330+05	9.07256330+04	6.08550380+04	2.22345800+04	5.09721140+03	1.23999910+03	2.60957650+02	0.50013450+01			
KAPPA(R)	6.40706060+04	4.45064710+04	2.56103000+04	9.08776010+03	2.61639570+03	5.77751560+02	1.26164667+02	2.57246740+01			
UENSITY	2.12478040-03	2.55692660-09	2.04223600-10	2.00453020-11	2.35870140-12						
KAPPA(P)	1.31537774+01	1.07229169+00	2.96708760-01	9.30664990-02	7.26406920-02						
KAPPA(R)	4.42088090+00	0.54483960-01	1.44193370-01	7.52003040-02	7.02163560-02						
THETA = 3.0000		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSITY	0.45602490-02	1.12221295-02	1.62146313-03	3.01040300-04	5.00730660-05	0.36021400-06	1.30450524-06	2.15944340-07			
KAPPA(P)	1.34976020+05	7.60373490+04	3.46727270+04	1.79643390+04	5.08136940+03	1.73650070+03	3.34049800+02	5.62546500+01			
KAPPA(R)	1.13454454+03	6.90041420+04	3.13740400+04	1.11107005+04	3.03993040+03	6.04550900+02	1.25344999+02	2.32402320+01			
UENSITY	2.97871490-08	3.49756090-09	3.95440080-10	4.04732490-11	3.47307790-12						
KAPPA(P)	9.34596900+00	1.47636486+00	2.50403930-01	9.94703270-02	0.09530130-02						
KAPPA(R)	3.01136720+00	6.10517560-01	1.51934150-01	0.94363570-02	8.69506990-02						
THETA = 3.0000		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES		13 DENSITIES	
UENSITY	0.33956960-02	1.47373029-02	2.32112330-03	3.74702500-04	6.45203400-05	1.13270150-05	1.06374900-06	2.97646290-07			
KAPPA(P)	1.03300100+05	6.35981660+04	3.50004530+04	1.79687950+04	5.11410090+03	1.18020210+03	2.18015070+02	3.69959040+01			
KAPPA(R)	4.30037440+04	5.43970500+04	2.47764570+04	9.53229590+03	2.62134540+03	5.59604890+02	1.01444040+02	1.70353220+01			

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 3.30000 CONTINUED

DENSITY 4.27062730-08 5.12456770-09 5.79659660-10 5.73688370-11 5.10000390-12
 KAPPA(P) 6.41133430-03 1.03178520-03 2.14595900-01 1.15531452-01 1.06582207-01
 KAPPA(R) 2.75326920-00 4.57748820-01 1.47840250-01 1.07031401-01 1.04613086-01

THETA = 7.00000

13 DENSITIES

DENSITY 1.03349530-01 1.77948180-02 2.91023340-03 4.85673500-04 8.42024180-05 1.53422530-05 2.58080300-06 8.10888930-07
 KAPPA(P) 9.16397000-04 5.48698860-04 3.44929960-04 1.44224353-04 3.74361110-03 7.89335512-02 1.31498830-02 2.78899600-01
 KAPPA(R) 7.33492350-04 4.63737990-04 2.46859600-04 8.32180090-03 1.78027120-03 3.66863160-02 6.88101980-01 1.28479731-01

THETA = 10.00000

13 DENSITIES

DENSITY 1.35570020-01 2.33092730-02 3.91254980-03 6.66331020-04 1.18177008-04 2.16492460-05 3.66240720-06 5.74308050-07
 KAPPA(P) 7.77248200-04 4.82213690-04 2.85994300-04 1.14496104-04 2.69229410-03 5.67000380-02 1.11654578-02 2.11763920-01
 KAPPA(R) 5.44201120-04 3.84141010-04 1.79915580-04 5.46169210-03 1.18307110-03 2.30285670-02 4.91428810-01 8.80727410-00

THETA = 15.00000

13 DENSITIES

DENSITY 8.16519740-08 1.02331848-08 1.17372915-09 1.22726450-10 1.13112872-11 1.34177600-01 1.32429080-01
 KAPPA(P) 3.72409340-00 6.35824610-01 1.42418230-01 1.37355480-01 1.34177600-01 1.32429080-01 1.32429080-01
 KAPPA(R) 1.35357731-00 2.99947750-01 1.55227110-01 1.32947760-01 1.32429080-01 1.32429080-01 1.32429080-01

THETA = 22.49999

13 DENSITIES

DENSITY 1.05510070-01 3.29541730-02 5.66572190-03 9.82244440-04 1.74266820-04 3.18383210-05 5.51504920-06 9.07883180-07
 KAPPA(P) 2.92416300-04 3.95926940-04 2.24999850-04 7.62302410-03 1.78530210-03 3.34942900-02 6.17489490-01 1.00315904-01
 KAPPA(R) 3.77458350-04 2.86224290-04 1.47766270-04 4.19776770-03 9.47173170-02 1.65852190-02 2.62956870-01 4.16598830-00

THETA = 22.49999

13 DENSITIES

DENSITY 1.36476300-07 1.73509280-08 1.99400460-09 2.07371340-10 1.89892180-11 1.46504810-01 1.44466320-01
 KAPPA(P) 1.63574003-00 3.42444400-01 1.65241700-01 1.45709890-01 1.46504810-01 1.44466320-01 1.44466320-01
 KAPPA(R) 7.75452230-01 2.34267880-01 1.55535750-01 1.43915780-01 1.44466320-01 1.44466320-01 1.44466320-01

THETA = 22.49999

13 DENSITIES

DENSITY 2.71440340-02 4.80613440-02 8.37752330-03 1.44422658-03 2.71440340-04 5.20833160-05 9.21452578-06 1.53774634-06
 KAPPA(P) 4.33780780-04 3.03338620-04 1.42851093-04 4.34365590-03 8.67107480-02 1.55174830-02 2.51270390-01 4.54374630-00
 KAPPA(R) 2.62300230-04 2.06850390-04 1.01731976-04 2.73377570-03 4.47310480-02 7.72244490-01 1.33339535-01 2.20182550-00

THETA = 22.49999

13 DENSITIES

DENSITY 2.29771030-07 2.89571180-08 3.31009160-09 3.41371430-10 3.12940310-11 1.46504810-01 1.44466320-01
 KAPPA(P) 8.77336400-01 2.59462660-01 1.69273760-01 1.60595420-01 1.63093760-01 1.63093760-01 1.63093760-01
 KAPPA(R) 4.71636080-01 2.10597830-01 1.63369460-01 1.58016620-01 1.58016620-01 1.58016620-01 1.58016620-01

GHEY ABSORPTION COEFFICIENTS CONTINUED

THETA = 39.9998			13 DENSITIES		
DENSITY	4.12499000	7.34290960	1.31817500	2.41520770	4.59270140
KAPPA(P)	2.76030000	1.64210000	6.21733000	1.59082100	3.30976350
KAPPA(R)	1.43593400	1.02413420	4.49976720	1.11990250	2.11300010
THETA = 59.9998			13 DENSITIES		
DENSITY	3.62297000	4.88051000	5.55867600	5.65755110	5.17676270
KAPPA(P)	6.62000000	2.38773230	1.80749990	1.79186530	1.62929760
KAPPA(R)	3.66021610	1.98007570	1.73174070	1.76061630	1.60601920
THETA = 79.9998			13 DENSITIES		
DENSITY	6.56338400	1.13680649	2.16037340	4.07427290	7.79101700
KAPPA(P)	1.42354230	6.78707180	2.79577900	7.47250100	1.61425300
KAPPA(R)	7.01148000	4.22490030	1.97611080	4.76729360	1.06914417
THETA = 99.9998			13 DENSITIES		
DENSITY	8.34336000	7.98964200	9.15203120	9.65920260	9.05136900
KAPPA(P)	2.50777400	2.35971360	1.92947720	1.86552420	1.86540100
KAPPA(R)	2.55293470	2.00341740	1.86947590	1.83751130	1.83963110
THETA = 119.9998			13 DENSITIES		
DENSITY	9.43031600	1.80109010	3.33643010	6.26994950	1.16121620
KAPPA(P)	8.55040100	4.33150550	1.68005360	5.04054620	1.23972152
KAPPA(R)	4.64627310	2.83195630	1.25979620	3.36092000	6.53003760
THETA = 139.9998			13 DENSITIES		
DENSITY	9.65319400	1.27227380	1.48777379	1.56932543	1.46685530
KAPPA(P)	3.92159310	2.14671570	1.91299500	1.89691350	1.90665630
KAPPA(R)	2.57333000	1.98834990	1.87959260	1.87246810	1.68036530
THETA = 159.9998			13 DENSITIES		
DENSITY	1.59763457	2.83662540	5.18654720	9.41501440	1.82335681
KAPPA(P)	6.62000000	3.38015190	1.22594950	3.10298500	7.36572030
KAPPA(R)	3.74040490	2.24714980	9.82446930	1.89818620	3.55267510
THETA = 179.9998			13 DENSITIES		
DENSITY	1.64484430	2.12441710	2.48514430	2.61749000	2.42961050
KAPPA(P)	2.74523000	2.02862060	1.93610470	1.94041930	1.96590570
KAPPA(R)	2.30592450	1.99341860	1.91346280	1.91320550	1.93782670
THETA = 199.9998			13 DENSITIES		
DENSITY	4.56594400	4.67112520	8.55440920	2.46702660	3.18329380
KAPPA(P)	4.66030600	2.17118680	6.56074400	1.48851190	3.06179670
KAPPA(R)	2.42920050	1.34511380	4.35398660	8.65395970	1.48120760
THETA = 219.9998			13 DENSITIES		
DENSITY	4.56594400	4.67112520	8.55440920	2.46702660	3.18329380
KAPPA(P)	4.66030600	2.17118680	6.56074400	1.48851190	3.06179670
KAPPA(R)	2.42920050	1.34511380	4.35398660	8.65395970	1.48120760

G-MEY ABSORPTION COEFFICIENTS CONTINUED

THETA = 149.94995 CONTINUED					
DENSITY	4.02014750-00	3.75270030-07	4.37462400-08	4.63860170-09	4.36475020-10
KAPPA(P)	2.57138700-01	2.05711280-01	2.01491510-01	2.01069430-01	2.01025400-01
KAPPA(R)	2.22350350-01	2.00975750-01	1.94517700-01	1.94204690-01	1.98157720-01
THETA = 224.99990					
DENSITY	4.23547330-00	7.97733150-01	1.48533360-01	2.64886450-02	5.68134670-03
KAPPA(P)	2.54537150-01	8.68074760-02	2.20038100-02	5.65676600-01	1.35543021-01
KAPPA(R)	1.10446300-01	5.49605140-02	1.69967790-02	3.87632240-01	7.91930120-00
DENSITY	5.24513120-00	8.91601940-07	8.01941550-09	8.51957000-09	8.01841680-10
KAPPA(P)	2.23296900-01	2.03728910-01	2.01247050-01	2.00963690-01	2.00933150-01
KAPPA(R)	2.12415040-01	2.01176430-01	1.98726060-01	1.94226300-01	1.98161880-01
THETA = 340.00012					
DENSITY	7.33000350-00	1.39601797-00	2.65946000-01	5.17745140-02	1.02038721-02
KAPPA(P)	1.18867400-01	3.80569790-02	1.18497708-02	2.91856310-01	6.73007290-00
KAPPA(R)	5.22276790-02	2.50551120-02	9.08237630-01	1.87365860-01	3.54126850-00
DENSITY	9.73492350-00	1.26603588-06	1.48934340-07	1.54152710-08	1.48482368-09
KAPPA(P)	4.67289900-01	2.01775420-01	2.01071840-01	2.91101200-01	2.01588650-01
KAPPA(R)	2.00066700-01	1.99351240-01	1.94339710-01	1.94328200-01	1.98804560-01
THETA = 499.99993					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 699.99976					
DENSITY	1.90149250-01	3.85444400-00	7.55455040-01	1.44093310-01	2.99207520-02
KAPPA(P)	3.21303220-02	4.94352420-04	2.14877460-01	4.84078940-00	1.12740260-00
KAPPA(R)	9.33093330-01	4.03336190-01	1.07493363-01	2.51821470-00	7.15876500-01
DENSITY	4.43209970-00	3.70654650-06	4.36045100-07	8.63298310-08	4.36045240-09
KAPPA(P)	2.04509460-01	2.02993970-01	2.02791880-01	2.02776480-01	2.02775050-01
KAPPA(R)	2.01217070-01	2.00279580-01	1.99997180-01	1.99974580-01	1.99972980-01
THETA = 899.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 1099.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 1299.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 1499.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 1699.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 1899.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 2099.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 2299.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 2499.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 2699.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 2899.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 3099.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 3299.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2.00362350-01	1.99512770-01	1.99783350-01	1.99915800-01	1.99929190-01
THETA = 3499.99999					
DENSITY	1.24145473-01	2.37230270-00	4.60771140-01	9.07822040-02	1.60833800-02
KAPPA(P)	5.90279440-02	2.45004200-02	5.60925030-01	1.18246130-01	2.58880190-00
KAPPA(R)	2.33457150-02	1.26189906-02	3.544853750-01	7.55095460-00	1.65124092-00
DENSITY	1.73275000-00	2.24575230-06	2.63492760-07	2.79717760-08	2.63234710-09
KAPPA(P)	4.04264420-01	2.02499900-01	2.02873630-01	2.02899300-01	2.03005540-01
KAPPA(R)	2				

GRAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 99.9967		13 DENSITIES						
DENSITY	3.32134450-01	0.5156590-00	1.28557217+00	2.55170070-01	5.00236240-02	1.01307251-02	1.06105698-03	3.10001000-00
KAPPA(P)	1.35540020-02	3.68643510-01	0.25907820+00	2.14147910+00	7.10699080-01	3.27234870-01	2.25537010-01	2.00335250-01
KAPPA(R)	3.64174110-01	1.29266085+01	3.21500910+00	9.06098010-01	3.87179210-01	2.53559760-01	2.14738340-01	2.03208290-01
DENSITY	9.03212020-03	6.32834600-06	7.44532000-07	7.91065600-08	7.44532220-09			
KAPPA(P)	2.033990-01	2.0305950-01	2.03020770-01	2.03016300-01	2.03015690-01			
KAPPA(R)	2.00310330-01	1.99986980-01	1.99957100-01	1.99953490-01	1.99953180-01			
THETA = 109.99430		13 DENSITIES						
DENSITY	0.02192420+01	1.10600555+01	2.34794990+00	4.66290120+01	9.30678010+02	1.66045150+02	3.41956400+03	5.01313710+00
KAPPA(P)	0.53034330+01	1.60556520+01	4.39015460+00	1.18402160+00	4.08346710+01	2.30945450+01	2.08557810+01	2.00173530+01
KAPPA(R)	1.61094430+01	0.55853320+00	1.79844790+00	5.94453350+01	3.00679420+01	2.24003190+01	2.03336310+01	2.00009500+01
DENSITY	8.94325-0-03	1.16261930-05	1.36779592-06	1.43320370-07	1.36779633-08			
KAPPA(P)	2.0349300-01	2.03395030-01	2.03382260-01	2.03380630-01	2.03380430-01			
KAPPA(R)	2.03093300-01	2.00033390-01	2.00027790-01	2.00026980-01	2.00026780-01			
THETA = 229.99670		13 DENSITIES						
DENSITY	1.09659914-02	2.16501410+01	4.25967510+00	8.54600770-01	1.70221480-01	3.41761920+02	6.20206050+03	1.00793971+03
KAPPA(P)	4.6200960+01	0.27057440+00	1.98437782+00	5.41203130+01	2.60950210+01	2.13400090+01	2.05502930+01	2.03900020+01
KAPPA(R)	6.35608730+00	2.40311130+00	8.44669730+01	3.30420230+01	2.23791380+01	2.04209670+01	2.00600700+01	1.99930000+01
DENSITY	1.64298420-04	2.13597320-05	2.51278210-06	2.66903250+07	2.51278260+08			
KAPPA(P)	2.03733600-01	2.03693070-01	2.03688170-01	2.03688170-01	2.03687970-01			
KAPPA(R)	1.99419460-01	1.99802880-01	1.99800680-01	1.99800480-01	1.99800480-01			

1		JIANC/SCAT STUFF		19 FREQ(1.001-1.E6) TEMP(1.-2250.) C1/LMS 11/7/66		MATERL = 1105		MX = 061	
XRAY ABSORPTION COEFFICIENTS		21 TEMPERATURES							
THETA = 1.00000		13 DENSITIES							
DENSITY	1.2490000000	1.3210300-01	1.07608073-02	7.90100050-04	7.72271900-05	1.04791232-05	1.20359225-06	1.06833979-07	
KAPPA(P)	1.5097942000	1.53656260+04	1.35541645+04	0.81036690+03	3.74912570+03	1.25534030+03	5.92049300+02	1.81280850+02	
KAPPA(R)	5.60147420+02	6.29520410+02	7.64123260-02	5.99179350+02	3.19355140+02	1.23745986+02	6.35999480+01	1.51209867+01	
DENSITY	1.13420002-03	1.26400001-09	1.38375540-10	1.45129488-11	1.36374047-12				
KAPPA(P)	4.53792000+01	4.10600680+00	5.69762490-01	9.22919830-02	4.05586180-02				
KAPPA(R)	3.52470000+00	6.3059160-01	1.21420323-01	4.89626750-02	3.68510360-02				
THETA = 1.50000		13 DENSITIES							
DENSITY	2.64600070-01	3.07710000-02	3.09477840-03	3.31509470-04	3.55507250-05	4.65155050-06	6.99877890-07	1.09333936-07	
KAPPA(P)	8.40300300+04	6.41905020+04	5.17251770+04	2.90947320+04	9.85941270+03	2.45116080+03	5.49087600+02	8.61898350+01	
KAPPA(R)	9.91601420+03	6.77070400+03	6.55807530+03	4.17231360+03	1.89738310+03	6.13206030+02	1.43559120+02	2.41098610+01	
DENSITY	1.64309050-08	2.10790000-09	2.32435170-10	2.00566590-11	1.62809617-12				
KAPPA(P)	1.20053160+01	1.58964812+00	2.69423720-01	9.04628560-02	5.95436880-02				
KAPPA(R)	3.29522500+00	4.65237380-01	1.06436121-01	6.12261450-02	5.63141190-02				
THETA = 2.25000		13 DENSITIES							
DENSITY	1.17670210-01	1.40043110-02	1.55275119-03	2.07803320-04	3.42741210-05	6.33240830-06	1.09333655-06	1.60447360-07	
KAPPA(P)	1.53243700+05	1.16611127+05	7.25111890+04	2.50244430+04	6.27734230+03	1.26814680+03	2.63893590+02	6.39869800+01	
KAPPA(R)	7.01590420+04	4.41911120+04	2.75920300+04	1.02153500+04	2.64020130+03	5.68249160+02	1.26466200+02	2.55122810+01	
DENSITY	2.05955900-06	2.44344320-09	2.77980550-10	2.70396450-11	2.33149850-12				
KAPPA(P)	1.31511750+01	1.87441830+00	2.94254560-01	9.31347430-02	7.33472690-02				
KAPPA(R)	4.41869470+00	6.55000300-01	1.45463250-01	7.61393550-02	7.10285060-02				
THETA = 3.00000		13 DENSITIES							
DENSITY	8.04571070-02	1.12584475-02	1.71574142-03	2.86094600-04	4.80970300-05	8.00155250-06	1.34914435-06	2.12152620-07	
KAPPA(P)	1.50404000+05	6.35808650+04	4.03787890+04	1.76629400+04	5.75150530+03	1.43768000+03	2.85130220+02	5.12661650+01	
KAPPA(R)	1.22363405+05	7.474444230+04	3.28911650+04	1.12129331+04	3.03002150+03	6.85144320+02	1.28514910+02	2.32646280+01	
DENSITY	2.94194450-08	3.47035140-09	3.95761280-10	4.07025720-11	3.49321400-12				
KAPPA(P)	4.96580000+00	1.41133274+00	2.39068660-01	9.79733100-02	8.63217400-02				
KAPPA(R)	3.65980240+00	6.09467350-01	1.44949500-01	8.85005970-02	8.64155200-02				
THETA = 5.00000		13 DENSITIES							
DENSITY	4.42377020-02	1.40670377-02	2.23562600-03	3.60335080-04	6.32018520-05	1.11751339-05	1.84976009-06	2.97644180-07	
KAPPA(P)	1.13070557+05	6.40282650+04	3.52855890+04	1.70689090+04	4.83728690+03	1.87621540+03	2.84473920+02	5.41528480+01	
KAPPA(R)	9.403984010+04	5.39455140+04	2.43111111+04	9.29715690+03	2.63512510+03	5.37729450+02	9.80901490+01	1.61496780+01	

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 0.0000 CONTINUED					
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
4.2412100-04	5.15694350-09	5.82790390-10	5.76546740-11	5.12372230-12	1.06045920-01
5.92280400-00	4.76441550-01	2.03553200-01	1.18077200-01	1.06045920-01	1.06045920-01
2.62308400-00	4.44502130-01	1.43697310-01	1.06029492-01	1.06029492-01	1.06029492-01
THETA = 7.0000			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
1.01560450-01	1.72919100-02	2.84363260-03	4.78939150-04	0.36454200-05	2.32721570-06
9.13243420-04	5.49522230-04	3.37325900-04	1.48375532-04	3.41330090-03	1.42035200-02
7.21355310-04	4.63603560-04	2.39436630-04	7.76079500-03	1.60041930-03	8.33084400-01
5.92025480-04	7.19794600-04	7.90460190-10	7.78096270-11	7.00912040-12	4.12006900-07
5.92998010-00	9.42275080-01	2.12420760-01	1.38230790-01	1.26006340-01	2.04932500-01
1.93420040-00	3.60190940-01	1.54258310-01	1.27789360-01	1.23915740-01	1.28205770-01
THETA = 10.0000			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
1.34705010-01	4.29130040-02	3.87453410-03	6.64302320-04	1.19554110-04	3.67763750-06
7.63337400-04	4.78072230-04	2.41299440-04	1.04007724-04	2.55559440-03	1.08450340-02
5.33425000-04	3.67406520-04	1.64289930-04	4.01451160-03	1.054444510-03	4.84215110-01
4.17070700-04	1.02279475-06	1.17102092-09	1.22247060-10	1.12519463-11	5.75707300-07
5.89424030-00	9.34262790-01	1.92890910-01	1.37056500-01	1.38090360-01	2.04643900-01
1.37302431-00	2.98973900-01	1.55303560-01	1.33445250-01	1.33127630-01	8.55944000-00
THETA = 15.0000			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
1.84137700-01	3.27287900-02	5.66490610-03	9.64352900-04	1.74544650-04	9.65037000-07
5.74583700-04	3.84567560-04	2.16752240-04	7.44630200-03	1.76043330-03	1.01174530-01
5.72586070-04	2.72527560-04	1.27721432-04	3.84900550-03	8.96002050-02	4.17745300-00
1.35044200-07	1.72355820-05	1.97795970-09	2.05429150-10	1.00403550-11	
1.42444451-00	3.47214990-01	1.67074000-01	1.47156150-01	1.47670030-01	
7.80177600-01	2.35306910-01	1.55919080-01	1.45307220-01	1.45610070-01	
THETA = 22.4999			13 DENSITIES		
DENSITY	KAPPA(I)	KAPPA(R)	DENSITY	KAPPA(I)	KAPPA(R)
4.70594446-01	4.79403300-02	8.36476530-03	1.46512010-03	2.70507150-04	1.34901700-06
4.24456730-04	3.01319070-04	1.44842582-04	4.44620300-03	0.91445230-02	4.67331400-00
2.67786630-04	2.07246270-04	1.02786566-04	2.72201570-03	4.49047630-02	2.22560400-00
2.24063510-07	2.07965520-06	3.42161700-10	3.42161700-10	3.12172420-11	
8.89143650-01	2.61035590-01	1.70169030-01	1.61139790-01	1.63503400-01	
4.70958920-01	2.11609060-01	1.64469190-01	1.50622200-01	1.61130030-01	

COEFFICIENTS MULTIPLE REGRESSION ANALYSIS

[illegible]

GALV ABSORPTION COEFFICIENTS CONTINUED

THETA = 144.99999 CONTINUED

DENSITY 4.880740-00 3.49210120-07 4.29499690-00 4.55213270-09 4.20307430-10
 KAPPA(P) 2.73907500-03 6.86921520-02 2.05222580-01 2.04091230-01 2.04059270-01
 KAPPA(R) 2.23079250-01 2.04232750-01 2.02002540-01 2.01937500-01 2.01934270-01

THETA = 224.99999 13 DENSITIES

DENSITY 4.13931400-00 7.06180400-01 1.44748250-01 2.03168050-02 5.59138090-03 1.10116121-03 1.99222360-00 3.35060330-05
 KAPPA(P) 2.73907500-03 6.86921520-02 2.05222580-01 2.04091230-01 2.04059270-01 2.04059270-01 2.04059270-01 2.04059270-01
 KAPPA(R) 1.03659420-03 4.70240110-02 1.37555700-02 3.11778200-01 6.74596800-00 1.57500962-00 4.85096080-01 2.59150460-01

DENSITY 3.14730460-06 0.680113910-07 7.56545910-04 8.34744950-09 7.80511570-10
 KAPPA(P) 2.25801440-01 2.07524620-01 2.05169050-01 2.05108740-01 2.05371860-01
 KAPPA(R) 2.12449240-01 2.04292400-01 2.02503120-01 2.02317100-01 2.02539770-01

THETA = 300.00012 13 DENSITIES

DENSITY 7.15845500-00 1.35443145-00 2.61357520-01 5.60003240-02 1.00212283-02 1.99167150-03 3.65417890-04 6.20467790-05
 KAPPA(P) 1.22111500-03 3.55387930-02 1.02320286-02 2.74677050-01 6.62467290-00 1.56762979-00 4.56302020-01 2.48230800-01
 KAPPA(R) 4.92553430-02 1.90011570-02 5.49035480-01 1.26927247-01 2.61316520-00 7.00017690-01 3.14234730-01 2.32705930-01

DENSITY 9.53248420-06 1.23790529-06 1.45593110-07 1.54680390-08 1.45540766-09
 KAPPA(P) 2.12021400-01 2.06480560-01 2.05700920-01 2.04617220-01 2.05063070-01
 KAPPA(R) 2.10511470-01 2.04015360-01 2.02924010-01 2.02747420-01 2.02023730-01

THETA = 499.99993 13 DENSITIES

DENSITY 1.24974627-01 2.33022160-00 4.52399080-01 8.90693490-02 1.77260140-02 3.53748600-03 6.49447230-04 1.10351590-04
 KAPPA(P) 6.04054700-02 2.08374880-02 5.45903970-01 1.21910452-01 2.72072900-01 7.37367400-01 3.11508700-01 2.25351020-01
 KAPPA(R) 2.57551710-02 1.10308435-02 2.95500070-01 5.79445400-00 1.32915530-00 4.09017060-01 2.62555010-01 2.21330290-01

DENSITY 1.64722050-05 2.20544790-06 2.59375250-07 2.75558790-08 2.59346790-09
 KAPPA(P) 2.06782460-01 2.06323490-01 2.06071720-01 2.06051320-01 2.06049460-01
 KAPPA(R) 2.06056400-01 2.03301530-01 2.02466770-01 2.02930850-01 2.02926500-01

THETA = 699.99976 13 DENSITIES

DENSITY 1.94449400-01 3.74134580-00 7.41135000-01 1.44010810-01 2.92768800-02 5.84953590-03 1.07460602-03 1.02622970-04
 KAPPA(P) 3.37602650-02 4.45435480-01 2.24453070-01 5.10246100-00 1.23057210-00 4.10044140-01 2.46529090-01 2.13083320-01
 KAPPA(R) 1.14152468-02 3.47262790-01 1.45681515-01 3.27220100-01 0.61261240-01 3.61067550-01 2.39677700-01 2.10209990-01

DENSITY 2.80907440-05 3.65163190-06 4.29604890-07 4.58455380-08 4.29604940-09
 KAPPA(P) 2.06870100-01 2.05940700-01 2.05425010-01 2.05012440-01 2.05011000-01
 KAPPA(R) 2.04152050-01 2.03103620-01 2.02976510-01 2.02962300-01 2.02960680-01

GREY ABSORPTION COEFFICIENTS CONTINUED

TME TA = 999.99967		13 DENSITIES						
DENSITY	3.25083470-01	8.44550130+00	1.25909623+00	2.50091600-01	4.99241710-02	9.97858480-03	1.83394296-03	3.11757000-04
KAPPA(P)	1.41205740-02	3.79543900+01	8.64674530+00	2.00372290+00	5.87362320-01	2.88477840-01	2.22237860-01	2.08539532-01
KAPPA(R)	3.60137000-01	1.69903410-01	5.40603000+00	1.40241365+00	4.70211350-01	2.65910890-01	2.15806310-01	2.00850070-01
DENSITY	4.74223450-03	8.23507400-06	7.33542760-07	7.74339410-08	7.33542990-09			
KAPPA(P)	2.06334400-01	2.06021440-01	2.06016700-01	2.06016700-01	2.06016290-01			
KAPPA(R)	2.02095000-01	2.020233740-01	2.02035080-01		2.02834680-01			
TME TA = 1499.99930		13 DENSITIES						
DENSITY	3.90481220+01	1.16551946+01	2.40671640+00	4.54908480-01	9.16695510-02	1.83280840-02	3.36905160-03	5.72731240-04
KAPPA(P)	2.94301760+01	4.40312217+01	3.36435740+00	9.54682960-01	3.34858570-01	2.31839950-01	2.11419700-01	2.07054930-01
KAPPA(R)	9.70547330+00	4.31681550+00	1.54766054+00	5.21303850-01	2.69275300-01	2.16380900-01	2.05264080-01	2.02906930-01
DENSITY	8.81123390-03	1.14545914-05	1.34759370-06	1.44119100-07	1.34759394-08			
KAPPA(P)	4.06236470-01	2.06126540-01	2.06112940-01	2.06112900-01	2.06111040-01			
KAPPA(R)	2.04445010-01	2.02343440-01	2.02375980-01	2.02374970-01	2.02374970-01			
TME TA = 2249.99970		13 DENSITIES						
DENSITY	1.0773362+02	2.12084340+01	4.22371040+00	8.42826550-01	1.68396660-01	3.36718880-02	6.18932650-03	1.05217376-03
KAPPA(P)	2.41442440+01	5.95011760+00	1.39931412+00	4.30218440-01	2.51193170-01	2.14533150-01	2.07218290-01	2.05033440-01
KAPPA(R)	2.34989360+00	9.45741600-01	4.14630630-01	2.60536060-01	2.16683240-01	2.04571440-01	2.01732040-01	2.01158720-01
DENSITY	1.61472490-04	2.10430760-05	2.47569370-06	2.63082560-07	2.47569410-08			
KAPPA(P)	4.05594000-01	2.05554770-01	2.05551840-01	2.05551220-01	2.05551220-01			
KAPPA(R)	2.01040170-01	2.01040170-01	2.01040170-01	2.01040170-01	2.01040170-01			

35		JIANE/SCAT REF-JA		TEMP(1.5-2250)REV. 5ADY I:PUT		TAPES(1019-1018)		11-8-67		MATERL = 1104		ME = 000	
GREY ABSORPTION COEFFICIENTS		19		TEMPERATURES		10		DENSITIES		10		DENSITIES	
TMETA = 1.50000		10		DENSITIES		10		DENSITIES		10		DENSITIES	
DENSITY	2.557500-04	2.09301000-02	2.70301070-03	2.00180770-04	3.20775600-05	4.52474220-06	6.09179400-07	1.00112092-07					
KAPPA(P)	7.340000-04	7.45763790-04	5.49300000-04	3.30296350-04	1.05145251-04	2.53081060-03	5.26541390-02	8.99000310-01					
KAPPA(R)	7.531170-03	0.63304000-03	5.66200200-03	3.94087350-03	2.03626590-03	7.12473690-02	1.67000350-02	2.91054000-01					
DENSITY	1.504120-00	1.00793900-00											
KAPPA(P)	1.84463035-01	2.40002190-00											
KAPPA(R)	0.70717900-00	0.74770940-01											
TMETA = 4.25000		10		DENSITIES		10		DENSITIES		10		DENSITIES	
DENSITY	1.10200000-01	1.27023312-02	1.67050520-03	2.00101903-04	3.30282100-05	6.03046900-05	9.93390150-07	1.42704470-07					
KAPPA(P)	1.27000000-01	1.22009539-05	7.49719970-04	2.00301060-04	6.00077050-03	1.57043300-03	3.50050170-02	8.03122330-01					
KAPPA(R)	0.01220000-00	0.77090190-04	2.69309900-04	1.10700010-04	3.20069960-03	7.90102260-02	1.66121020-02	3.26072030-01					
DENSITY	1.91213000-00	2.33099500-00											
KAPPA(P)	1.51094077-01	2.23126750-00											
KAPPA(R)	5.00050070-00	0.61039490-01											
TMETA = 5.00000		10		DENSITIES		10		DENSITIES		10		DENSITIES	
DENSITY	7.73529000-02	1.01491147-02	1.64050690-03	2.64146600-04	0.59297010-05	7.51507190-06	1.24747391-06	1.90767590-07					
KAPPA(P)	1.67424000-05	0.00336600-04	5.15445650-04	2.35264700-04	7.34416100-03	1.72933900-03	3.36209320-02	6.53900530-01					
KAPPA(R)	1.31607000-05	0.00399900-04	3.05306700-04	1.35681001-04	3.50816000-03	7.69920270-02	1.45006030-02	2.76647000-01					
DENSITY	2.00330000-00	3.15313110-00											
KAPPA(P)	1.17257065-01	1.90067500-00											
KAPPA(R)	0.02691710-00	0.03017930-01											
TMETA = 5.00000		10		DENSITIES		10		DENSITIES		10		DENSITIES	
DENSITY	0.00407000-02	1.31044623-02	2.06774010-03	3.34276130-04	5.76320370-05	1.01066195-05	1.67307300-06	2.43727390-07					
KAPPA(P)	1.34201013-05	7.78103600-04	0.50810180-04	2.17696670-04	6.07140030-03	1.30780410-03	2.63643530-02	4.57790000-01					
KAPPA(R)	1.00504019-05	0.79360670-04	3.08715390-04	1.20169032-04	3.10220360-03	6.11064500-02	1.16012251-02	2.02043970-01					
DENSITY	3.79016070-00	4.04000000-00											
KAPPA(P)	7.03003040-00	1.27267101-00											
KAPPA(R)	3.30993010-00	0.00547070-01											
TMETA = 7.00000		10		DENSITIES		10		DENSITIES		10		DENSITIES	
DENSITY	9.51103000-02	1.59430570-02	2.61106330-03	0.30635060-04	7.60109630-05	1.37015023-05	2.32979500-06	3.76500110-07					
KAPPA(P)	1.12762094-05	7.05036600-04	0.52996560-04	1.74111490-04	4.23346720-03	8.04246590-02	1.70009700-02	2.97070000-01					
KAPPA(R)	0.30560020-04	5.00350330-04	3.11973970-04	9.71939700-03	2.09600170-03	0.57129720-02	7.76105190-01	1.30750000-01					

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 7.00000 CONTINUED			10 DENSITIES		
DENSITY	5.51146770-08	8.83454710-09			
KAPPA(P)	5.96225930-00	9.91113620-01			
KAPPA(R)	2.30950120-00	5.07406610-01			
THETA = 10.00000			10 DENSITIES		
DENSITY	1.22749017-01	2.09450910-02	3.53963340-03	6.11421510-04	1.08954112-04
KAPPA(P)	9.20419700-04	5.91954460-04	3.45694460-04	1.16666236-04	2.64110310-03
KAPPA(R)	5.50077000-04	4.51610340-04	2.34593140-04	6.05175350-03	1.32267560-03
DENSITY	8.06235520-00	1.01663257-08			
KAPPA(P)	3.40373170-00	6.50696620-01			
KAPPA(R)	1.04331700-00	3.91132720-01			
THETA = 15.00000			10 DENSITIES		
DENSITY	1.71073000-01	3.02594400-02	5.23606100-03	9.32469650-04	1.69602170-04
KAPPA(P)	8.53062320-04	4.09224900-04	2.05521100-04	6.24497900-03	1.46844000-03
KAPPA(R)	3.42759740-04	2.81527390-04	1.46590532-04	4.14191270-03	8.78403560-02
DENSITY	1.36951170-07	1.74570900-08			
KAPPA(P)	1.51422430-00	3.40052510-01			
KAPPA(R)	8.63642460-01	3.12065560-01			
THETA = 22.49569			10 DENSITIES		
DENSITY	4.56655400-01	4.55490640-02	8.07933270-03	1.45784354-03	2.73748440-04
KAPPA(P)	4.23583100-04	2.66920210-04	1.10281740-04	2.91998000-03	5.82275440-02
KAPPA(R)	2.31583530-04	1.79421450-04	8.64410010-03	2.30443290-03	3.94964270-02
DENSITY	2.28000020-07	2.84192250-08			
KAPPA(P)	9.54704600-01	3.31352010-01			
KAPPA(R)	5.75240250-01	2.73754030-01			
THETA = 33.99598			6 DENSITIES		
DENSITY	4.06630400-01	7.19622200-02	1.33041597-02	2.44322350-03	4.63335120-04
KAPPA(P)	2.59505390-04	1.41003740-04	5.16567900-03	1.21991190-03	2.84332950-02
KAPPA(R)	1.43112450-04	9.14221440-03	3.64493000-03	8.37960900-02	1.60710910-02

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA =	50.00-00	DENSITIES					
DENSITY	3.2500570-01	1.15045903-01	2.10313950-02	3.9716980-03	7.35396350-04	1.39403320-04	
KAPPA(P)	1.6633155-04	7.85550570-03	2.93243240-03	7.47304670-02	1.94724400-02	4.93470990-01	
KAPPA(R)	3.8795-03-03	5.31613575-03	1.84233340-03	3.71205360-02	8.50663000-01	1.70399370-01	
THETA =	69.99-99	DENSITIES					
DENSITY	9.4192123-01	1.71647040-01	9.42372650-01	1.71647040-01	3.14090510-02	5.06485220-03	1.10237205-03
KAPPA(P)	1.12334-02-04	5.34503080-03	1.12423378-04	5.34503080-03	2.03233560-03	5.07152610-02	1.24422613-02
KAPPA(R)	7.20091520-03	3.82681910-03	7.20581730-03	3.82681910-03	1.28074720-03	2.51220020-02	8.56302018-01
							8.25947000-00
THETA =	99.99-98	DENSITIES					
DENSITY	1.45311106-03	2.60204000-01	4.85045080-02	9.07775850-03	1.73467540-03	3.38225750-04	
KAPPA(P)	3.29144060-03	3.72490440-03	1.7980100-03	2.92209480-02	6.60140070-01	1.44307591-01	
KAPPA(R)	5.10503000-03	2.75951920-03	8.55176390-02	1.66217660-02	2.67240000-01	4.81952790-09	
THETA =	149.99-95	DENSITIES					
DENSITY	2.41555007-03	4.33619330-01	8.17253180-02	1.56998160-02	3.09241180-03	6.15056700-04	
KAPPA(P)	5.30953170-03	2.16105740-03	5.65213170-02	1.10335269-02	2.33511670-01	4.72830120-00	
KAPPA(R)	2.80341120-03	1.327655420-03	4.11942420-02	9.07560620-01	1.39690436-01	2.75671040-00	
THETA =	224.99-90	DENSITIES					
DENSITY	4.0412470-03	7.52023190-01	1.44410540-01	2.83064420-02	5.60845510-03	1.10514913-03	
KAPPA(P)	2.5506040-03	6.29178460-02	1.55267910-02	3.83860500-01	9.37077660-00	2.67044340-00	
KAPPA(R)	3.50706300-02	3.88644500-02	1.09540366-02	2.30759730-01	4.94337390-00	1.21543835-00	
THETA =	340.00-12	DENSITIES					
DENSITY	7.03257550-03	1.34433729-00	2.62309280-01	5.12064400-02	1.00915585-02	2.00394010-03	
KAPPA(P)	1.05741550-03	2.07223960-02	8.30823530-01	2.32020700-01	5.71743330-00	1.43152511-00	
KAPPA(R)	3.92061790-02	1.39339720-02	3.71716870-01	7.94740190-00	1.70293901-00	5.49653610-01	
THETA =	499.99-93	DENSITIES					
DENSITY	1.20589040-01	2.32396230-00	4.54980740-01	8.93303860-02	1.78702670-02	3.56679100-03	
KAPPA(P)	5.24704550-02	1.74422660-02	4.39692250-01	9.80541700-00	2.15437640-00	5.96505130-01	
KAPPA(R)	4.06673050-02	4.07869400-01	2.13972620-01	3.94982380-00	9.70266830-01	4.00709360-01	

GREY ABSORPTION COEFFICIENTS CONTINUED

TALTA = 699.9975		DENSITIES	
DENSITY	1.94078/50+01	5.79240350+00	7.45950090-01 1.44296740-01
KAPPA(P)	4.90205/70+02	6.32112430+01	1.75461710+01 3.96467930+00
KAPPA(R)	7.77745250+02	3.18026300+01	7.62874980+00 1.77053630+00
TALTA = 999.99707		DENSITIES	
DENSITY	3.20397060+01	6.42113550+00	1.26407322+00 2.52786000-01
KAPPA(P)	1.35339/10+02	3.41444570+01	7.24907580+00 1.55363646+00
KAPPA(R)	1.81221310+01	5.88055110+00	1.50709150+00 8.77982070-01
TALTA = 2209.99070		DENSITIES	
DENSITY	1.00515018+02	2.14360690+01	4.27260720+00 4.31439300-01
KAPPA(P)	1.54690050+02	3.55345360+00	8.40042910-01 3.01951760-01
KAPPA(R)	4.15612010+01	5.81431270+01	2.43603340+01 2.07182080-01

JO	LIANE/SCAT	SEA WATER-1A	TEMP(1.-1.6E EV)	1 FREQ.	CI/JM	10-9-67	MATERL = 1136	NK = 900
KEY ABSORPTION COEFFICIENTS								
24 TEMPERATURES								
13 DENSITIES								
THETA =	1.5000							
DENSITY	4.8789E-04	3.9574E730-02	3.71357240-03	2.54594010-04	1.93297000-05	2.25739240-06	3.47924630-07	5.69176730-08
KAPPA(P)	5.20400E70+03	3.7077101E+25	3.17603950+05	1.63912420+05	4.11621400+04	7.521110920+03	1.240334520+03	1.73073490+02
KAPPA(R)	6.69335E+0+03		3.53294050+03	2.04443400+03	1.43226300+03	4.09942520+02	6.87674130+01	9.52971650+00
13 DENSITIES								
DENSITY	6.62194E0-09	1.1247701E-09	1.22793600-10	1.21264766-11	1.02156028-12			
KAPPA(P)	4.40222610+01	3.07999100+00	4.43494750-01	1.40718050-01	9.47618840-02			
KAPPA(R)	1.3141511E+00	2.68636260-01	1.1227411-01	9.07933700-02	8.86498810-02			
13 DENSITIES								
THETA =	2.2500							
DENSITY	9.340067E-02	9.13455+00-03	8.53926040-04	1.05010444-04	1.75611770-05	3.34183680-06	5.95309540-07	9.33108190-08
KAPPA(P)	1.04564E7+00	7.07476650+05	4.32012580+05	1.13241726+05	1.58438697+04	2.42598270+03	9.31394930+02	8.80125110+01
KAPPA(R)	7.16250E+0+04	4.95020910+04	2.93040170+04	9.64424780+03	1.82159720+03	3.06799040+02	5.92809950+01	1.66355350+01
13 DENSITIES								
DENSITY	1.27305E0-00	1.45741193E-09	1.62944190-10	1.09811320-11	1.60709968-12			
KAPPA(P)	1.73500E+0+00	2.44645270+00	3.71573160-01	1.24397290-01	1.06123687-01			
KAPPA(R)	3.87638E+0+00	8.44494100-01	1.70400620-01	1.04750428-01	1.01824860-01			
13 DENSITIES								
THETA =	3.4000							
DENSITY	4.72600E10-02	6.13795300-03	9.04773940-04	1.54821920-04	2.76977340-05	4.96756900-06	8.61580990-07	1.41560300-07
KAPPA(P)	9.68402E7+0+03	4.43742580+05	4.33403440+05	5.47312420+04	1.10413761+04	2.14931380+03	3.78559010+02	6.31407870+01
KAPPA(R)	3.16201E+0+05	1.65343430+05	3.75865300+04	1.53353197+04	3.34644450+03	6.51215700+02	1.07236747+02	1.79612550+01
13 DENSITIES								
DENSITY	2.01651E-00-00	4.38752160-09	2.79066130-10	2.79031930-11	2.38815510-12			
KAPPA(P)	1.1032858E7+02	1.84537709+00	3.30104840-01	1.42066500-01	1.29829790-01			
KAPPA(R)	3.61339E+0+00	3.92611010-01	1.95347350-01	1.23255450-01	1.25899790-01			
13 DENSITIES								
THETA =	5.0000							
DENSITY	4.67611E+00-02	7.91814740-03	1.29943980-03	2.424133140-04	4.091331120-05	7.53659630-06	1.26712509-06	2.04233400-07
KAPPA(P)	5.7504240E+03	3.32440790+05	1.73757930+05	4.74617740+04	3.90243370+03	1.72363870+03	3.85735350+02	5.08257050+01
KAPPA(R)	4.54339E+0+05	2.38433510+05	7.24435190+04	1.51791477+04	2.78177910+03	5.46750540+02	1.01212774+02	1.63174380+01
13 DENSITIES								
DENSITY	2.97974E0-00-08	3.52135540-09	3.97009990-10	3.91829260-11	3.47589190-12			
KAPPA(P)	9.34770E+0+00	1.57245327+00	3.161713090-01	1.70454000-01	1.57092570-01			
KAPPA(R)	2.99000E+0+00	5.67415940-01	2.431149520-01	1.54907820-01	1.53218690-01			
13 DENSITIES								
THETA =	7.0000							
DENSITY	8.218304E0-02	1.05443177-02	1.74555327-03	3.16854460-04	5.60495790-05	1.05003717-05	1.77125099-06	2.81675450-07
KAPPA(P)	4.20344E+0+05	2.73232100+05	1.45670120+05	3.97922490+04	7.66269450+03	1.34000300+03	2.44301600+02	4.23279230+01
KAPPA(R)	3.03403E7+05	1.82026940+05	5.74234490+04	1.32174468+04	2.288333080+03	4.201353300+02	8.77271970+01	1.56832987+01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 7.0000 CONTINUED		
DENSITY	4.0253020-06	5.40725160-10
KAPPA(P)	1.2075732+00	3.10701390-01
KAPPA(R)	2.6108520+00	2.22577930-01
THETA = 10.0000 DENSITIES		
DENSITY	3.4500700-12	2.25540760-03
KAPPA(P)	2.9207300+05	1.10507230+05
KAPPA(R)	1.5325720+05	4.10029790+04
DENSITY	3.7610500-06	8.5573540-10
KAPPA(P)	2.3702400+00	2.53104270-01
KAPPA(R)	2.7314023+00	2.05729900-01
THETA = 15.0000 DENSITIES		
DENSITY	1.2341700-01	2.15950950-02
KAPPA(P)	1.7950270+05	1.30044241+05
KAPPA(R)	2.7920100+04	5.1177790+04
DENSITY	1.0267200-07	1.33310505-08
KAPPA(P)	4.8050500+00	3.24930900-01
KAPPA(R)	7.2957900+01	2.61250220-01
THETA = 22.4959 DENSITIES		
DENSITY	1.0709700-01	3.30960000-02
KAPPA(P)	4.5109100+04	6.53353920+04
KAPPA(R)	1.4060000+04	1.67903100+04
DENSITY	1.0703700-07	2.43902120-08
KAPPA(P)	0.9412900+01	2.43904030-01
KAPPA(R)	4.4077600-01	2.29700200-01
THETA = 35.9956 DENSITIES		
DENSITY	4.9414100-04	3.41032210-02
KAPPA(P)	4.1651800+04	2.30714130+04
KAPPA(R)	5.9003500+05	4.50257490+05
DENSITY	3.0730620-07	4.47800200-08
KAPPA(P)	3.5032000+01	2.08347400-01
KAPPA(R)	3.0193010-01	1.97000030-01
THETA = 50.216070-12 DENSITIES		
DENSITY	5.02116070-12	5.41263520-11
KAPPA(P)	1.78560020-01	1.92015150-01
KAPPA(R)	1.74089600-01	1.81001950-01
THETA = 51.212090-05 DENSITIES		
DENSITY	4.09949310-05	4.53001230-04
KAPPA(P)	1.80461530+02	2.95597790+04
KAPPA(R)	6.66772600+01	9.55203050+03
THETA = 52.679070-05 DENSITIES		
DENSITY	3.99063600-06	1.22593010-04
KAPPA(P)	7.33614050+01	2.07778000+03
KAPPA(R)	2.9929900+01	1.55245900+03
THETA = 54.54179520-12 DENSITIES		
DENSITY	4.54179520-12	4.04128950-11
KAPPA(P)	1.78261800-01	1.85632220-01
KAPPA(R)	1.75120300-01	1.74540000-01
THETA = 56.5607560-09 DENSITIES		
DENSITY	1.054239790-10	1.054239790-10
KAPPA(P)	1.70553160-01	1.70553160-01
KAPPA(R)	1.75301400-01	1.75301400-01
THETA = 59.947000-04 DENSITIES		
DENSITY	2.01947000-04	2.01947000-04
KAPPA(P)	3.37711600+02	3.37711600+02
KAPPA(R)	3.71247720+02	3.71247720+02
THETA = 62.221560-11 DENSITIES		
DENSITY	2.06221560-11	2.06221560-11
KAPPA(P)	1.70060300-01	1.70060300-01
KAPPA(R)	1.75625210-01	1.75625210-01
THETA = 67.335130-04 DENSITIES		
DENSITY	3.67335130-04	3.67335130-04
KAPPA(P)	2.24940090+02	2.24940090+02
KAPPA(R)	1.54452090+02	1.54452090+02
THETA = 7.27374600-05 DENSITIES		
DENSITY	7.27374600-05	7.27374600-05
KAPPA(P)	9.01185560+01	9.01185560+01
KAPPA(R)	2.61789530+01	2.61789530+01
THETA = 7.33203139-05 DENSITIES		
DENSITY	1.33203139-05	1.33203139-05
KAPPA(P)	6.85717120+00	6.85717120+00
KAPPA(R)	4.25007650+00	4.25007650+00
THETA = 7.93137530+00 DENSITIES		
DENSITY	7.93137530+00	7.93137530+00
KAPPA(P)	1.05925563+00	1.05925563+00
KAPPA(R)	1.05925563+00	1.05925563+00

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 90.0000			15 DENSITIES			THETA = 90.0000			15 DENSITIES		
DENSITY	7.70406E-01	0.95350910-02	1.63165010-02	3.29981000-03	6.50053400-04	DENSITY	7.70406E-01	0.95350910-02	1.63165010-02	3.29981000-03	6.50053400-04
KAPPA(P)	1.64266E-03	7.9143550E-03	2.05410380E-02	4.14523040E-02	8.30293350E-01	KAPPA(P)	1.64266E-03	7.9143550E-03	2.05410380E-02	4.14523040E-02	8.30293350E-01
KAPPA(R)	2.43572E-03	1.63522E-03	8.2711430E-02	2.35056620E-02	4.51650690E-01	KAPPA(R)	2.43572E-03	1.63522E-03	8.2711430E-02	2.35056620E-02	4.51650690E-01
DENSITY	3.47365E-01	6.74175590E-09	8.07425920E-10	7.59276670E-11	2.23349610E-01	DENSITY	3.47365E-01	6.74175590E-09	8.07425920E-10	7.59276670E-11	2.23349610E-01
KAPPA(P)	3.26482E-01	2.76137040E-01	2.33701910E-01	2.28066590E-01	2.19229970E-01	KAPPA(P)	3.26482E-01	2.76137040E-01	2.33701910E-01	2.28066590E-01	2.19229970E-01
KAPPA(R)	2.73081E-01	2.23435560E-01	2.19593460E-01	2.19254310E-01	2.19229970E-01	KAPPA(R)	2.73081E-01	2.23435560E-01	2.19593460E-01	2.19254310E-01	2.19229970E-01
THETA = 69.9999			13 DENSITIES			THETA = 69.9999			13 DENSITIES		
DENSITY	7.44156E-01	1.42571560E-01	2.75477330E-02	5.32396600E-03	1.01959075E-03	DENSITY	7.44156E-01	1.42571560E-01	2.75477330E-02	5.32396600E-03	1.01959075E-03
KAPPA(P)	7.70177E-03	5.5494270E-03	9.77334820E-02	2.56374530E-02	7.87912510E-01	KAPPA(P)	7.70177E-03	5.5494270E-03	9.77334820E-02	2.56374530E-02	7.87912510E-01
KAPPA(R)	1.95563E-03	1.05550740E-03	4.34700790E-02	1.06056074E-02	1.94677250E-01	KAPPA(R)	1.95563E-03	1.05550740E-03	4.34700790E-02	1.06056074E-02	1.94677250E-01
DENSITY	8.23384E-01	1.06540459E-07	1.25701630E-04	1.33444459E-09	1.25562190E-10	DENSITY	8.23384E-01	1.06540459E-07	1.25701630E-04	1.33444459E-09	1.25562190E-10
KAPPA(P)	7.55475E-01	2.54114330E-01	2.27066810E-01	2.23903980E-01	2.23670120E-01	KAPPA(P)	7.55475E-01	2.54114330E-01	2.27066810E-01	2.23903980E-01	2.23670120E-01
KAPPA(R)	2.55990E-01	2.26144620E-01	2.21065440E-01	2.20050330E-01	2.19652620E-01	KAPPA(R)	2.55990E-01	2.26144620E-01	2.21065440E-01	2.20050330E-01	2.19652620E-01
THETA = 90.0000			13 DENSITIES			THETA = 90.0000			13 DENSITIES		
DENSITY	1.24426E-03	2.34470140E-01	4.24441530E-02	9.10752540E-03	1.54203400E-03	DENSITY	1.24426E-03	2.34470140E-01	4.24441530E-02	9.10752540E-03	1.54203400E-03
KAPPA(P)	7.83792E-03	5.20404800E-03	1.04867330E-02	2.87714570E-02	7.68158490E-01	KAPPA(P)	7.83792E-03	5.20404800E-03	1.04867330E-02	2.87714570E-02	7.68158490E-01
KAPPA(R)	2.07250110E-03	9.23354160E-02	2.930250670E-02	6.0342699E-01	1.11163498E-01	KAPPA(R)	2.07250110E-03	9.23354160E-02	2.930250670E-02	6.0342699E-01	1.11163498E-01
DENSITY	1.40256E-01	4.8222567E-07	2.14341600E-08	2.27733490E-09	2.14335200E-10	DENSITY	1.40256E-01	4.8222567E-07	2.14341600E-08	2.27733490E-09	2.14335200E-10
KAPPA(P)	3.07594E-01	2.35294910E-01	2.25039900E-01	2.23426970E-01	2.23704110E-01	KAPPA(P)	3.07594E-01	2.35294910E-01	2.25039900E-01	2.23426970E-01	2.23704110E-01
KAPPA(R)	2.87689E-01	2.30440730E-01	2.21039380E-01	2.19946670E-01	2.19639440E-01	KAPPA(R)	2.87689E-01	2.30440730E-01	2.21039380E-01	2.19946670E-01	2.19639440E-01
THETA = 149.9995			13 DENSITIES			THETA = 149.9995			13 DENSITIES		
DENSITY	2.14691E-03	3.91911190E-01	7.24441310E-02	1.37496350E-02	2.69756160E-03	DENSITY	2.14691E-03	3.91911190E-01	7.24441310E-02	1.37496350E-02	2.69756160E-03
KAPPA(P)	3.4774610E-03	2.78033350E-03	7.04213600E-02	1.44219900E-02	2.94636590E-01	KAPPA(P)	3.4774610E-03	2.78033350E-03	7.04213600E-02	1.44219900E-02	2.94636590E-01
KAPPA(R)	2.20739E-03	8.64540910E-02	2.24121410E-02	4.22041770E-01	6.28263190E-01	KAPPA(R)	2.20739E-03	8.64540910E-02	2.24121410E-02	4.22041770E-01	6.28263190E-01
DENSITY	2.57461E-03	2.27733490E-09	3.03744040E-08	4.14244490E-09	3.93364970E-10	DENSITY	2.57461E-03	2.27733490E-09	3.03744040E-08	4.14244490E-09	3.93364970E-10
KAPPA(P)	2.71143E-03	2.27733490E-01	2.24110730E-01	2.24901330E-01	2.23903540E-01	KAPPA(P)	2.71143E-03	2.27733490E-01	2.24110730E-01	2.24901330E-01	2.23903540E-01
KAPPA(R)	2.40447E-03	2.24110730E-01	2.24110730E-01	2.19744000E-01	2.19424490E-01	KAPPA(R)	2.40447E-03	2.24110730E-01	2.24110730E-01	2.19744000E-01	2.19424490E-01
THETA = 200.0000			13 DENSITIES			THETA = 200.0000			13 DENSITIES		
DENSITY	3.50133E-03	4.44444440E-01	1.27444440E-01	2.47444440E-02	4.92744440E-03	DENSITY	3.50133E-03	4.44444440E-01	1.27444440E-01	2.47444440E-02	4.92744440E-03
KAPPA(P)	3.50039E-03	1.64444440E-01	2.07444440E-02	4.35004440E-01	4.62371610E-01	KAPPA(P)	3.50039E-03	1.64444440E-01	2.07444440E-02	4.35004440E-01	4.62371610E-01
KAPPA(R)	3.94444E-03	4.44444440E-01	1.01444440E-01	1.61444440E-01	3.34074230E-01	KAPPA(R)	3.94444E-03	4.44444440E-01	1.01444440E-01	1.61444440E-01	3.34074230E-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 22°.95'±0			CONTINUED		
DENSITY	7.260070-00	6.139475-07	7.57091530-09	7.21946630-10	
KAPPA(P)	2.340964-00	2.25147440-01	2.24143640-01	2.24136960-01	
KAPPA(R)	2.27628000-01	2.21023550-01	2.20062210-01	2.20051210-01	
THETA = 340.00±2			13 DENSITIES		
DENSITY	1.24509450-00	1.15079447-00	2.22333350-01	9.14303430-03	3.35032110-04
KAPPA(P)	1.30400000-03	3.00423900-02	6.71045300-01	3.02960480-00	3.33034220-01
KAPPA(R)	2.20784700-02	7.95340310-01	2.275525240-01	1.39014741-00	2.86207560-01
DENSITY	1.76571000-00	1.13933005-06	1.34105380-07	1.34105418-09	5.70024590-05
KAPPA(P)	2.27030700-01	2.24511400-01	2.24142340-01	2.24138300-01	2.42973960-01
KAPPA(R)	2.24555400-01	2.20417490-01	2.27090370-01	2.20050980-01	2.33800090-01
THETA = 459.99±3			13 DENSITIES		
DENSITY	1.07156470-01	2.07274630-00	4.10740150-01	1.62811870-02	3.25355190-03
KAPPA(P)	4.48750650-02	1.19474968-02	2.54767600-01	1.33576744-00	7.97150400-01
KAPPA(R)	5.61222740-01	2.00335300-01	7.74761760-00	6.40058430-01	3.32262160-01
DENSITY	1.50271000-00	2.03243340-06	2.39155960-07	2.39156040-09	5.97927520-04
KAPPA(P)	2.20163000-01	2.24114380-01	2.24074450-01	2.24062740-01	2.46681780-01
KAPPA(R)	2.20196700-01	2.19444970-01	2.19401590-01	2.17990160-01	2.46239360-01
THETA = 609.99±5			13 DENSITIES		
DENSITY	1.72491770-01	3.42074390-00	5.70772900-01	2.36013350-02	5.38897030-03
KAPPA(P)	2.16180750-02	5.15077070-01	1.54144357-01	5.34537300-01	3.13804480-01
KAPPA(R)	2.33035900-01	1.01753059-01	3.29405070-00	3.35513500-01	2.60941770-01
DENSITY	2.59030470-00	3.36734510-00	3.94163050-07	3.51631700-09	9.90445260-04
KAPPA(P)	2.20137400-01	2.23459300-01	2.23409470-01	2.23402990-01	2.39960250-01
KAPPA(R)	2.16590410-01	2.19174920-01	2.13144990-01	2.18145240-01	2.26977360-01
THETA = 909.99±7			13 DENSITIES		
DENSITY	2.94175000-01	5.42470940-00	1.54299110-00	4.60300090-02	9.20135070-03
KAPPA(P)	5.51442500-04	1.31043442-01	3.70311770-00	3.34946520-01	2.44280680-01
KAPPA(R)	5.11405520-00	2.06137150-00	7.56024790-01	2.48266380-01	2.21610260-01
DENSITY	4.42485500-00	3.74771650-00	6.76434670-07	6.76434790-09	1.69114917-03
KAPPA(P)	2.20704000-01	2.20642300-01	2.20653430-01	2.20651660-01	2.24949350-01
KAPPA(R)	2.13392730-01	2.13354970-01	2.13350060-01	2.13349420-01	2.18965660-01

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 149.9920			13 DENSITIES		
DENSITY	5.3540520-01	1.0411043-01	2.12407750-00	8.24666370-01	8.45601660-02
KAPPA(P)	2.50134420-00	5.69373330-00	1.31935347-00	4.51626260-01	2.62370670-01
KAPPA(R)	1.40706781-00	5.69112710-01	3.15680350-01	2.42538700-01	2.16975900-01
THETA = 149.9920			13 DENSITIES		
DENSITY	6.12225000-00	1.03062234-05	1.32036160-07	1.24269303-08	1.69038080-02
KAPPA(P)	2.15100430-01	2.15080850-01	2.15034670-01	2.15054020-01	2.20656560-01
KAPPA(R)	2.10685520-01	2.03064313-01	2.05641670-01	2.06641670-01	2.09250280-01
THETA = 149.9920			13 DENSITIES		
DENSITY	7.82259000-01	1.96017130-01	3.90591080-00	7.74216770-01	1.55344510-01
KAPPA(P)	1.15074427-01	2.83055640-00	5.92510770-01	3.04252440-01	2.27061130-01
KAPPA(R)	6.35110730-01	3.13335690-01	2.35057370-01	2.12680990-01	2.04226560-01
THETA = 149.9920			13 DENSITIES		
DENSITY	3.49271200-04	1.94051900-05	2.20297770-06	2.42566890-07	2.20297840-08
KAPPA(P)	2.06144410-01	2.04027710-01	2.04025210-01	2.08025210-01	2.08025210-01
KAPPA(R)	2.00798470-01	2.00793160-01	2.00794560-01	2.00794560-01	2.00794560-01
THETA = 149.9920			13 DENSITIES		
DENSITY	1.84231520-02	3.81434520-01	7.22549880-00	1.44554901-00	2.88560350-01
KAPPA(P)	3.13737200-00	1.21747907-00	3.42134530-01	2.34296650-01	2.08056620-01
KAPPA(R)	3.76846400-01	2.44554970-01	2.13626890-01	2.00684350-01	1.97427270-01
THETA = 149.9920			13 DENSITIES		
DENSITY	2.77201200-04	3.60465310-05	4.24075180-06	4.58380130-07	4.24075250-08
KAPPA(P)	2.01394500-01	2.01344510-01	2.01347700-01	2.01347700-01	2.01347700-01
KAPPA(R)	1.96542610-01	1.96541440-01	1.95541230-01	1.95541230-01	1.96541230-01
THETA = 149.9920			13 DENSITIES		
DENSITY	5.24102100-02	6.44379360-01	1.29847820-01	2.57876910-00	5.14601480-01
KAPPA(P)	2.85456030-00	6.35743740-01	2.76254970-01	2.11107040-01	1.98812320-01
KAPPA(R)	2.80770500-01	2.17115680-01	2.00197080-01	1.95874180-01	1.94082640-01
THETA = 149.9920			13 DENSITIES		
DENSITY	7.94409000-04	8.42036030-05	7.56279330-06	8.03547130-07	7.56279450-08
KAPPA(P)	1.93460000-01	1.93797930-01	1.95797560-01	1.95797560-01	1.88594890-01
KAPPA(R)	1.92633710-01	1.93633320-01	1.93633320-01	1.93633320-01	1.91066060-01
THETA = 149.9920			13 DENSITIES		
DENSITY	5.37745700-02	1.00730499-02	2.13311180-01	4.24550570-00	9.52329800-01
KAPPA(P)	9.44087210-01	3.16119170-01	2.07576200-01	1.91172400-01	1.89061110-01
KAPPA(R)	2.41766470-01	2.05131770-01	1.94803760-01	1.91923770-01	1.91269660-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 6999.99000 CONTINUED		
DENSITY	5.19123270-04	1.06405907-04
KAPPA(P)	1.80595270-01	1.59594890-01
KAPPA(R)	1.91066000-01	1.91066060-01
THETA = 9999.99000 DENSITIES		
DENSITY	9.17984940+02	1.82214740+02
KAPPA(P)	5.33719400-01	2.82369700-01
KAPPA(R)	2.19407200-01	1.99864020-01
DENSITY	1.39862737-03	1.81821530-04
KAPPA(P)	1.84595060-01	1.88594890-01
KAPPA(R)	1.91066000-01	1.91066060-01
DENSITY	1.25278070-07	1.33107993-06
KAPPA(P)	1.88594890-01	1.88594890-01
KAPPA(R)	1.91066060-01	1.91066060-01
DENSITY	1.45532420+00	1.88219000-01
KAPPA(P)	1.88219000-01	1.88219000-01
KAPPA(R)	1.91173290-01	1.91173290-01
DENSITY	2.90951700-01	2.90951700-01
KAPPA(P)	1.88640150-01	1.88640150-01
KAPPA(R)	1.91080000-01	1.91080000-01
DENSITY	5.34787450-02	5.34787450-02
KAPPA(P)	1.88403190-01	1.88403190-01
KAPPA(R)	1.91070270-01	1.91070270-01
DENSITY	9.09112100-03	9.09112100-03
KAPPA(P)	1.88594890-01	1.88594890-01
KAPPA(R)	1.91066060-01	1.91066060-01

38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255	256	257	258	259	260	261	262	263	264	265	266	267	268	269	270	271	272	273	274	275	276	277	278	279	280	281	282	283	284	285	286	287	288	289	290	291	292	293	294	295	296	297	298	299	300	301	302	303	304	305	306	307	308	309	310	311	312	313	314	315	316	317	318	319	320	321	322	323	324	325	326	327	328	329	330	331	332	333	334	335	336	337	338	339	340	341	342	343	344	345	346	347	348	349	350	351	352	353	354	355	356	357	358	359	360	361	362	363	364	365	366	367	368	369	370	371	372	373	374	375	376	377	378	379	380	381	382	383	384	385	386	387	388	389	390	391	392	393	394	395	396	397	398	399	400	401	402	403	404	405	406	407	408	409	410	411	412	413	414	415	416	417	418	419	420	421	422	423	424	425	426	427	428	429	430	431	432	433	434	435	436	437	438	439	440	441	442	443	444	445	446	447	448	449	450	451	452	453	454	455	456	457	458	459	460	461	462	463	464	465	466	467	468	469	470	471	472	473	474	475	476	477	478	479	480	481	482	483	484	485	486	487	488	489	490	491	492	493	494	495	496	497	498	499	500	501	502	503	504	505	506	507	508	509	510	511	512	513	514	515	516	517	518	519	520	521	522	523	524	525	526	527	528	529	530	531	532	533	534	535	536	537	538	539	540	541	542	543	544	545	546	547	548	549	550	551	552	553	554	555	556	557	558	559	560	561	562	563	564	565	566	567	568	569	570	571	572	573	574	575	576	577	578	579	580	581	582	583	584	585	586	587	588	589	590	591	592	593	594	595	596	597	598	599	600	601	602	603	604	605	606	607	608	609	610	611	612	613	614	615	616	617	618	619	620	621	622	623	624	625	626	627	628	629	630	631	632	633	634	635	636	637	638	639	640	641	642	643	644	645	646	647	648	649	650	651	652	653	654	655	656	657	658	659	660	661	662	663	664	665	666	667	668	669	670	671	672	673	674	675	676	677	678	679	680	681	682	683	684	685	686	687	688	689	690	691	692	693	694	695	696	697	698	699	700	701	702	703	704	705	706	707	708	709	710	711	712	713	714	715	716	717	718	719	720	721	722	723	724	725	726	727	728	729	730	731	732	733	734	735	736	737	738	739	740	741	742	743	744	745	746	747	748	749	750	751	752	753	754	755	756	757	758	759	760	761	762	763	764	765	766	767	768	769	770	771	772	773	774	775	776	777	778	779	780	781	782	783	784	785	786	787	788	789	790	791	792	793	794	795	796	797	798	799	800	801	802	803	804	805	806	807	808	809	810	811	812	813	814	815	816	817	818	819	820	821	822	823	824	825	826	827	828	829	830	831	832	833	834	835	836	837	838	839	840	841	842	843	844	845	846	847	848	849	850	851	852	853	854	855	856	857	858	859	860	861	862	863	864	865	866	867	868	869	870	871	872	873	874	875	876	877	878	879	880	881	882	883	884	885	886	887	888	889	890	891	892	893	894	895	896	897	898	899	900	901	902	903	904	905	906	907	908	909	910	911	912	913	914	915	916	917	918	919	920	921	922	923	924	925	926	927	928	929	930	931	932	933	934	935	936	937	938	939	940	941	942	943	944	945	946	947	948	949	950	951	952	953	954	955	956	957	958	959	960	961	962	963	964	965	966	967	968	969	970	971	972	973	974	975	976	977	978	979	980	981	982	983	984	985	986	987	988	989	990	991	992	993	994	995	996	997	998	999	1000	1001	1002	1003	1004	1005	1006	1007	1008	1009	1010	1011	1012	1013	1014	1015	1016	1017	1018	1019	1020	1021	1022	1023	1024	1025	1026	1027	1028	1029	1030	1031	1032	1033	1034	1035	1036	1037	1038	1039	1040	1041	1042	1043	1044	1045	1046	1047	1048	1049	1050	1051	1052	1053	1054	1055	1056	1057	1058	1059	1060	1061	1062	1063	1064	1065	1066	1067	1068	1069	1070	1071	1072	1073	1074	1075	1076	1077	1078	1079	1080	1081	1082	1083	1084	1085	1086	1087	1088	1089	1090	1091	1092	1093	1094	1095	1096	1097	1098	1099	1100	1101	1102	1103	1104	1105	1106	1107	1108	1109	1110	1111	1112	1113	1114	1115	1116	1117	1118	1119	1120	1121	1122	1123	1124	1125	1126	1127	1128	1129	1130	1131	1132	1133	1134	1135	1136	1137	1138	1139	1140	1141	1142	1143	1144	1145	1146	1147	1148	1149	1150	1151	1152	1153	1154	1155	1156	1157	1158	1159	1160	1161	1162	1163	1164	1165	1166	1167	1168	1169	1170	1171	1172	1173	1174	1175	1176	1177	1178	1179	1180	1181	1182	1183	1184	1185	1186	1187	1188	1189	1190	1191	1192	1193	1194	1195	1196	1197	1198	1199	1200	1201	1202	1203	1204	1205	1206	1207	1208	1209	1210	1211	1212	1213	1214	1215	1216	1217	1218	1219	1220	1221	1222	1223	1224	1225	1226	1227	1228	1229	1230	1231	1232	1233	1234	1235	1236	1237	1238	1239	1240	1241	1242	1243	1244	1245	1246	1247	1248	1249	1250	1251	1252	1253	1254	1255	1256	1257	1258	1259	1260	1261	1262	1263	1264	1265	1266	1267	1268	1269	1270	1271	1272	1273	1274	1275	1276	1277	1278	1279	1280	1281	1282	1283	1284	1285	1286	1287	1288	1289	1290	1291	1292	1293	1294	1295	1296	1297	1298	1299	1300	1301	1302	1303	1304	1305	1306	1307	1308	1309	1310	1311	1312	1313	1314	1315	1316	1317	1318	1319	1320	1321	1322	1323	1324	1325	1326	1327	1328	1329	1330	1331	1332	1333	1334	1335	1336	1337	1338	1339	1340	1341	1342	1343	1344	1345	1346	1347	1348	1349	1350	1351	1352	1353	1354	1355	1356	1357	1358	1359	1360	1361	1362	1363	1364	1365	1366	1367	1368	1369	1370	1371	1372	1373	1374	1375	1376	1377	1378	1379	1380	1381	1382	1383	1384	1385	1386	1387	1388	1389	1390	1391	1392	1393	1394	1395	1396	1397	1398	1399	1400	1401	1402	1403	1404	1405	1406	1407	1408	1409	1410	1411	1412	1413	1414	1415	1416	1417	1418	1419	1420	1421	1422	1423	1424	1425	1426	1427	1428	1429	1430	1431	1432	1433	1434	1435	1436	1437	1438	1439	1440	1441	1442	1443	1444	1445	1446	1447	1448	1449	1450	1451	1452	1453	1454	1455	1456	1457	1458	1459	1460	1461	1462	1463	1464	1465	1466	1467	1468	1469	1470	1471	1472	1473	1474	1475	1476	1477	1478	1479	1480	1481	1482	1483	1484	1485	1486	1487	1488	1489	1490	1491	1492	1493	1494	1495	1496	1497	1498	1499	1500	1501	1502	1503	1504	1505	1506	1507	1508	1509	1510	1511	1512	1513	1514	1515	1516	1517	1518
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 224.99750 CONTINUED					
DENSITY	5.34315E-05	6.83627600-07	8.00263430-08	8.49702280-09	7.99655740-10
KAPPA(P)	4.62402420-01	2.12610380-01	2.63515870-01	2.62487350-01	2.02366078-01
KAPPA(R)	2.0325610-01	1.99158560-01	1.99936590-01	1.98746470-01	1.98694460-01
THETA = 340.00012			13 DENSITIES		
DENSITY	7.99985E-05	1.51720599+00	2.92944060-01	5.6937960-02	1.09008231-02
KAPPA(P)	1.174963410+02	4.46529710+02	1.05825018+02	3.65106550+01	1.08871583+01
KAPPA(R)	1.74739710+02	6.45537250+01	1.79217330+01	4.75980800+00	1.42633440+00
THETA = 493.99793			12 DENSITIES		
DENSITY	9.71409790+00	1.26263473-06	1.48541720-07	1.57624100-08	1.48540259-09
KAPPA(P)	2.24404460-01	2.04637740-01	2.05286410-01	2.02943670-01	2.02373760-01
KAPPA(R)	2.05301750-01	2.01221500-01	1.98944170-01	1.98726850-01	1.98714130-01
THETA = 694.99776			13 DENSITIES		
DENSITY	1.34373073+01	2.57738130+00	4.90864130-01	9.53236230-02	1.81918250-02
KAPPA(P)	8.17531440+02	2.79406310+02	9.28384560+01	2.65560820+01	6.58723040+00
KAPPA(R)	1.93962560+02	5.86130030+01	1.54476204+01	3.54056740+00	9.20082550-01
THETA = 894.99767			13 DENSITIES		
DENSITY	4.74204470-03	2.23164380-06	2.64900920-07	2.61457350-08	2.64900970-09
KAPPA(P)	2.02443210-01	2.02740180-01	2.02506560-01	2.02891050-01	2.02478410-01
KAPPA(R)	2.02320250-01	1.99141630-01	1.98944970-01	1.98924480-01	1.98922690-01
THETA = 1095.99750			13 DENSITIES		
DENSITY	2.13749750+01	4.04132250+00	7.71922720-01	1.50809630-01	2.99019370-02
KAPPA(P)	9.03509700+02	2.16785090+02	5.35194410+01	1.24117915+01	2.75799580+00
KAPPA(R)	2.05414450+02	7.04629430+01	1.50849995+01	2.94150320+00	8.22774670-01
THETA = 1296.99737			13 DENSITIES		
DENSITY	1.80912050-03	3.72945970-06	4.38805310-07	9.66230950-08	4.38805390-09
KAPPA(P)	2.03519700-01	2.02764710-01	2.02742270-01	2.02661340-01	2.02660110-01
KAPPA(R)	1.99715460-01	1.99247800-01	1.99153610-01	1.99197030-01	1.99186440-01
THETA = 1497.99728			13 DENSITIES		
DENSITY	3.47567140+01	8.53370180+00	1.29251837+00	2.55910120-01	5.09992680-02
KAPPA(P)	3.43875700+02	9.35475130+01	2.06269900+01	4.36626790+00	1.03499760+00
KAPPA(R)	9.92167010+01	3.440444370+01	7.50556690+00	1.57728481+00	4.83241270-01
THETA = 1699.99719			13 DENSITIES		
DENSITY	4.8949410-03	8.36060610-06	7.49252350-07	7.46081040-09	7.49252570-09
KAPPA(P)	2.04660720-01	2.02432250-01	2.02402070-01	2.02398450-01	2.02398040-01
KAPPA(R)	1.98994120-01	1.98899220-01	1.98846490-01	1.98805100-01	1.98804900-01

GALY ABSORPTION COEFFICIENTS CONTINUED

THETA = 1899.99930		13 DENSITIES						
DENSITY	0.17132700+01	1.1985943+01	2.3624290+00	0.69572630-01	9.36655650-02	1.87226170-02	3.44124490-03	5.86998990-04
KAPPA(P)	1.3423360+02	3.25122510+01	7.01523560+00	1.5084562+00	4.24896490-01	2.34024140-01	2.05374320-01	2.01196750-01
KAPPA(R)	1.9407560+01	3.8292420+00	1.4357407+00	4.59933120-01	2.53028890-01	2.08144440-01	1.98973420-01	1.97484930-01
DENSITY	3.7499350+00	1.16999033+05	1.37643396+06	1.44240300-07	1.37645438+08			
KAPPA(P)	4.0055550+01	2.00431240-01	2.00417410-01	2.00415610-01	2.00415610-01			
KAPPA(R)	1.97251450+01	1.97213370-01	1.97208440-01	1.97207450-01	1.97207660-01			
THETA = 4249.99070		13 DENSITIES						
DENSITY	4.1161364+02	2.14710530+01	8.33243460+00	8.62335640-01	1.72061730-01	3.43950020-02	6.32194740-03	1.07470937-03
KAPPA(P)	4.94336470+01	1.05576023+01	2.44033630+00	6.14143210-01	2.65004890-01	2.08325820-01	1.9899290-01	1.97413450-01
KAPPA(R)	3.85841700+00	4.90187150-01	3.95614310-01	2.47333910-01	2.08170040-01	1.97839930-01	1.95468700-01	1.93017880-01
DENSITY	4.65239430+04	4.14941460+05	2.52071320+06	2.64675920+07	2.52071360+08			
KAPPA(P)	1.9713840+01	1.97095080-01	1.97089370-01	1.97088780-01	1.97088580-01			
KAPPA(R)	1.94455440+01	1.94421760-01	1.94320010-01	1.94319820-01	1.94319820-01			
THETA = 3400.00050		13 DENSITIES						
DENSITY	4.0462450+02	4.02534430+01	8.01739430+00	1.40152395+00	3.19603850-01	6.38905390-02	1.17434227-02	1.99434559-03
KAPPA(P)	1.5741963+01	4.05565200+00	9.36124820+01	3.23807210-01	2.15184380-01	1.97754090-01	1.94590090-01	1.94032420-01
KAPPA(R)	5.62406640-01	3.94254470-01	2.47696110-01	2.07624110-01	1.96751650-01	1.93677840-01	1.93177070-01	1.93051750-01
DENSITY	3.07128940+04	3.99259130+05	8.69726610+06	8.99094730+07	8.69726690+08			
KAPPA(P)	1.93355620+01	1.93204930-01	1.9318360-01	1.9318170-01	1.9318170-01			
KAPPA(R)	1.93029460+01	1.93025100-01	1.93025100-01	1.93025100-01	1.93025100-01			
THETA = 4999.99670		13 DENSITIES						
DENSITY	3.59422470+02	7.17141410+01	1.42937442+01	2.84263170+00	5.69555040-01	1.13938664-01	2.89426190-02	3.56018860-03
KAPPA(P)	3.2413950+00	7.84326410-01	2.35822320-01	2.01851090-01	1.9059330-01	1.86412410-01	1.86130760-01	1.86066930-01
KAPPA(R)	3.40170110+01	4.33359280-01	2.02744040-01	1.94046590-01	1.91671560-01	1.91096070-01	1.90964790-01	1.90953180-01
DENSITY	3.47714500+04	7.12034040+05	8.37643430+06	8.40039560+07	8.37644090+08			
KAPPA(P)	1.80074240+01	1.80074040-01	1.80074040-01	1.80077900-01	1.80077900-01			
KAPPA(R)	1.90950540+01	1.90944740-01	1.90944740-01	1.90944740-01	1.90944740-01			
THETA = 8999.99090		13 DENSITIES						
DENSITY	3.94579620+02	1.14735490+02	2.36742270+01	8.72520520+00	9.44122190-01	1.86739220-01	3.46914850-02	5.89743140-03
KAPPA(P)	1.74563519+00	4.71963740-01	2.31469700-01	1.94044460-01	1.89007230-01	1.86223910-01	1.86104800-01	1.86082420-01
KAPPA(R)	2.79966030+01	2.15705190-01	1.97773460-01	1.92628650-01	1.91329160-01	1.91002640-01	1.90960050-01	1.90951460-01

GRAY ABSORPTION COEFFICIENTS CONTINUED

TALTA = 0994.99490 CONTINUED

DENSITY 9.07296740-04 1.17449555-04 1.38762761-05 1.47435496-06 1.38762760-07
 KAPPA(P) 1.44078400-01 1.83077900-01 1.88077900-01 1.88077900-01 1.88077900-01
 KAPPA(R) 1.90450430-01 1.90949740-01 1.90949740-01 1.90949740-01 1.90949740-01

TALTA = 9994.99240

DENSITY 1.04435403-03 4.32073830-02 4.04183530-01 8.06793030-00 1.61204876-00
 KAPPA(P) 9.30004450-01 3.13078290-01 2.06051730-01 1.90628830-01 1.88535890-01
 KAPPA(R) 4.40905670-01 2.04224730-01 1.94692670-01 1.91835120-01 1.91139060-01

DENSITY 1.54919437-03 2.01393690-04 2.36932600-05 2.51740990-06 2.36932640-07
 KAPPA(P) 1.88078400-01 1.88077900-01 1.88077900-01 1.88077900-01 1.88077900-01
 KAPPA(R) 1.90949740-01 1.90949740-01 1.90949740-01 1.90949740-01 1.90949740-01

13 DENSITIES

3.22265990-01 5.92346270-02 1.00697130-02
 1.88149200-01 1.88091070-01 1.88080160-01
 1.90976670-01 1.90954890-01 1.90950700-01

34	JIAV/SCAT	SHALE-18	INPUT TAPES (4424.2408.4027)	11-7-67	C1/LM	MATERL = 1129	MX = 900
GREY ABSORPTION COEFFICIENTS							
24 TEMPERATURES							
13 DENSITIES							
THETA = 1.50000							
DENSITY	4.4450840-01	4.86242790-02	2.49521350-03	3.50395170-04	4.21557290-05	5.00814110-06	8.66174010-07
KAPPA(P)	5.04700640+03	3.33432250+03	2.39977700+03	9.13405340+04	2.15130710+04	4.40292310+03	8.39385390+02
KAPPA(R)	1.74356660+03	1.27623523+03	6.45166660+04	2.11210000+04	4.82528430+03	1.06956660+03	2.02152820+02
DENSITY	1.9036470-04	2.53591870-09	2.75137570-10	2.49130400-11	1.83671980-12		
KAPPA(P)	1.70081700+01	2.13451170+00	3.39324980-01	9.90225200-02	5.54097890-02		
KAPPA(R)	3.54659250+00	4.93044370-01	1.13373782-01	5.70573140-02	5.05974050-02		
THETA = 4.45000							
DENSITY	1.24306403-01	1.55035693-02	1.33473533-03	2.54041070-04	4.18754860-05	7.64066070-06	1.30323633-06
KAPPA(P)	8.54260500+03	4.33000980+03	2.35447360+05	9.76749010+04	1.73955890+04	2.73652170+03	4.66142300+02
KAPPA(R)	5.02486640+03	2.57274300+05	1.24227636+05	3.54330900+04	7.33129160+03	1.20412920+03	1.91161950+02
DENSITY	4.33506750-04	2.79330620-09	3.39147800-10	3.03653240-11	2.54906700-12		
KAPPA(P)	1.75603610+01	2.41219540+00	3.35632400-01	9.52233600-02	6.84922460-02		
KAPPA(R)	5.26426400+00	7.31892440-01	1.51137400-01	7.13141870-02	6.54473690-02		
THETA = 3.40000							
DENSITY	3.20501450-02	1.33455741-02	2.36492590-03	3.41315400-04	5.59562320-05	9.21719320-06	1.51370546-06
KAPPA(P)	5.41890660+03	3.29713690+05	1.93743400+05	7.00475770+04	1.59479282+04	2.86834350+03	4.63444170+02
KAPPA(R)	4.04444500+03	2.01194570+05	1.23981778+05	3.44399440+04	6.90776150+03	1.21096150+03	1.89630900+02
DENSITY	3.22556400-04	3.79521130-09	4.32572540-10	4.444809500-11	3.81362870-12		
KAPPA(P)	1.16660330+01	1.67411059+00	2.61969410-01	9.47232300-02	8.18185750-02		
KAPPA(R)	4.34454200+00	6.47107530-01	1.47200740-01	8.26755810-02	7.95591900-02		
THETA = 5.00000							
DENSITY	9.77564700-02	1.65019460-02	2.58958410-03	4.13626580-04	7.06272920-05	1.23226687-05	2.02619690-06
KAPPA(P)	4.04109400+05	2.74679400+05	1.67167220+05	5.41379100+04	1.08395844+04	1.83939490+03	2.78383020+02
KAPPA(R)	3.34424410+05	2.20173220+05	1.33401937+05	2.94879300+04	5.41887750+03	8.39132760+02	1.23161635+02
DENSITY	4.60760070-04	5.62434420-09	6.35874480-10	6.24651000-11	5.58369820-12		
KAPPA(P)	7.14322470+01	1.14666140+00	2.15206120-01	1.07942026-01	9.79355190-02		
KAPPA(R)	2.86411090+00	4.74468780-01	1.41883920-01	9.86413250-02	9.56097950-02		
THETA = 7.00000							
DENSITY	1.15516491-01	1.96461040-02	3.20123380-03	5.34163810-04	9.22752220-05	1.66108150-05	2.83142630-06
KAPPA(P)	2.98674280+05	2.08931120+05	1.18323270+05	3.30180590+04	6.03009600+03	1.01278978+03	1.70380470+02
KAPPA(R)	2.00501600+05	1.52855740+05	7.29055400+04	1.87024340+04	2.79025410+03	4.58598430+02	8.10912420+01

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 7.00000 CONTINUED			13 DENSITIES		
DENSITY	6.455360-10-08	7.94146760-09	8.59371330-10	8.35941320-11	7.63056050-12
KAPPA(P)	5.25194440-00	8.49100600-01	2.52970220-01	1.25757220-01	1.17671552-01
KAPPA(R)	4.06359410-00	3.66566540-01	1.47163460-01	1.14715427-01	1.15207202-01
THETA = 10.00000			13 DENSITIES		
DENSITY	1.48500740-01	2.50901920-02	4.28213740-03	7.39079590-04	1.30389560-04
KAPPA(P)	2.09523400-05	1.44013590-05	7.59643880-04	2.01113570-04	3.77061340-03
KAPPA(R)	1.15463610-05	9.03213740-04	3.95079490-04	9.05647170-03	1.65372070-03
DENSITY	9.60791550-08	1.09563151-09	1.25117857-09	1.30167390-10	1.19177781-11
KAPPA(P)	3.96410450-00	6.57453440-01	1.40163440-01	1.30997770-01	1.27951480-01
KAPPA(R)	1.44730311-00	3.02493460-01	1.48622700-01	1.25732960-01	1.25668350-01
THETA = 15.00000			13 DENSITIES		
DENSITY	2.04658440-01	3.61504430-02	6.19205670-03	1.04067656-03	1.89837900-04
KAPPA(P)	1.34543110-05	9.42035540-04	4.39136240-04	1.12355472-04	2.09956600-03
KAPPA(R)	5.42353530-04	5.71514460-04	2.43196490-04	6.33703920-03	1.15976530-03
DENSITY	1.43974450-07	1.01744350-08	2.07424370-09	2.14457420-10	1.95731990-11
KAPPA(P)	1.78269490-00	3.52322550-01	1.54539270-01	1.41739980-01	1.42742210-01
KAPPA(R)	8.28079420-01	2.36637940-01	1.51241700-01	1.39072340-01	1.40161070-01
THETA = 22.49499			13 DENSITIES		
DENSITY	4.94172780-01	5.21173170-02	9.00765930-03	1.54547969-03	2.89478370-04
KAPPA(P)	9.36294430-04	6.37540030-04	2.48363080-04	5.64185900-03	1.04628280-03
KAPPA(R)	6.04218400-04	4.03749370-04	1.70970620-04	3.74078652-03	5.89845700-02
DENSITY	4.37274460-07	2.94054970-08	3.39971550-09	3.44532410-10	3.18466160-11
KAPPA(P)	1.12084458-00	2.98707840-01	1.69947620-01	1.58327120-01	1.60943960-01
KAPPA(R)	5.57961450-01	2.20413930-01	1.61846810-01	1.55075630-01	1.57982650-01
THETA = 33.99498			13 DENSITIES		
DENSITY	4.46152030-01	7.61939510-02	1.39251803-02	2.55549080-03	4.79592410-04
KAPPA(P)	5.97270320-04	3.73505130-04	1.43363112-04	3.45523890-03	5.77427540-02
KAPPA(R)	2.59478440-04	2.13533500-04	8.92407450-03	1.92170280-03	3.29313750-02
DENSITY	3.92463450-07	4.96091820-08	5.64836350-09	5.76543740-10	5.28554760-11
KAPPA(P)	7.66193440-01	2.49997340-01	1.80188270-01	1.76725420-01	1.80004570-01
KAPPA(R)	4.28884790-01	2.02259430-01	1.71317620-01	1.72827210-01	1.76720310-01

CHEY ABSORPTION COEFFICIENTS CONTINUED

50.0000			13 DENSITIES			13 DENSITIES		
THETA =	50.0000							
DENSITY	6.700000000	1.23152212-01	2.27009150-02	4.45194630-03	9.02475680-04	1.53070470-04	2.69442680-05	6.37710230-06
KAPPA(P)	4.863320000	1.13140510-04	3.72020760-03	9.33049660-02	2.30642510-02	5.68816100-01	1.12092123-01	2.28991090-01
KAPPA(R)	4.041352000	0.24751440-03	2.45213040-03	5.55133590-02	1.26520957-02	2.68708740-01	4.87063050-00	9.40940290-01
DENSITY	6.499111000	6.13715340-04	9.33439440-03	9.05492100-01	9.23680580-11			
KAPPA(P)	5.470741000	2.35591320-01	1.49504640-01	1.83642500-01	1.83604370-01			
KAPPA(R)	5.014420000	1.93100230-01	1.43035990-01	1.80121070-01	1.80263610-01			
69.9999			13 DENSITIES			13 DENSITIES		
THETA =	69.9999							
DENSITY	1.014013100	1.25337200-01	3.44532370-02	6.44364650-03	1.20707044-03	2.28326250-04	4.02814340-05	6.62712220-06
KAPPA(P)	1.252683700	0.11324470-03	2.09333460-03	5.37914640-02	1.38991520-02	3.26335520-01	6.97327510-00	1.86062350-01
KAPPA(R)	0.642613000	3.55334120-03	1.43373750-03	3.47741740-02	7.02716160-01	1.28736800-01	2.40605190-00	5.80419280-01
DENSITY	1.002543500	1.22345530-07	1.51931550-08	1.02264600-09	1.49849470-10			
KAPPA(P)	3.925114000	2.12213640-01	1.34303760-01	1.34550740-01	1.87425840-01			
KAPPA(R)	2.614490100	1.95174930-01	1.34444460-01	1.83364560-01	1.84050150-01			
99.9998			13 DENSITIES			13 DENSITIES		
THETA =	99.9998							
DENSITY	1.586664300	2.90940060-01	5.32373660-02	9.85998150-03	1.86215641-03	3.60368650-04	6.53053890-05	1.10124954-05
KAPPA(P)	8.706559100	4.20011930-03	1.35034670-03	3.27930260-02	7.68164620-01	1.68397810-01	3.44114400-00	7.43761090-01
KAPPA(R)	4.851394900	2.61549580-03	9.21519620-02	1.93111330-02	3.60037800-01	6.56348690-00	1.30914793-00	4.07831410-01
DENSITY	1.6415577500	2.17075640-07	2.53477300-08	2.05927250-09	2.46682310-10			
KAPPA(P)	2.736914700	1.99439050-01	1.93471440-01	1.91040660-01	1.94384140-01			
KAPPA(R)	2.533714200	1.95996990-01	1.37496710-01	1.87604730-01	1.90844560-01			
109.9995			13 DENSITIES			13 DENSITIES		
THETA =	109.9995							
DENSITY	2.6300448000	4.77116130-01	8.40153440-02	1.56915610-02	3.25555350-03	6.42889320-04	1.17087747-04	1.96854640-05
KAPPA(P)	5.937790000	2.50742970-03	6.65045850-02	1.50545500-02	3.21842420-01	6.96029590-00	1.50405460-00	4.43842780-01
KAPPA(R)	2.522606900	1.47229100-03	4.52469410-02	9.17273910-01	1.62851070-01	3.48989970-00	8.72082720-01	3.36072460-01
DENSITY	2.9752874006	3.79602950-07	4.41174710-08	4.67498530-09	4.39837640-10			
KAPPA(P)	2.470736000	2.45301630-01	2.00741350-01	2.00304210-01	2.00259950-01			
KAPPA(R)	2.215814400	1.98860840-01	1.96845130-01	1.96646810-01	1.96617310-01			
220.9990			13 DENSITIES			13 DENSITIES		
THETA =	220.9990							
DENSITY	4.3554340000	8.05370930-01	1.52691610-01	2.95127570-02	5.79840730-03	1.13559222-03	2.04841050-04	3.44421140-05
KAPPA(P)	2.908259300	9.42824340-02	2.23766580-02	5.51530800-01	1.41115692-01	3.83090470-00	1.03729887-00	3.57495090-01
KAPPA(R)	1.239881300	5.76699280-02	1.68681270-02	3.84936380-01	8.43035580-00	1.86511106-00	5.20366310-01	2.62832540-01

OMLY ABSORPTION COEFFICIENTS CONTINUED

THETA = 22.9950 CONTINUED

DENSITY	2.206455-0-03	6.9639150-07	8.0047620-08	8.5550960-09	8.08047760-10
KAPPA(P)	2.249232-0-01	2.3733630-01	2.30528360-01	2.06294400-01	2.00259150-01
KAPPA(R)	2.10374500-01	1.99503590-01	1.97253610-01	1.94690080-01	1.96614360-01

THETA = 340.00012 13 DENSITIES

DENSITY	7.40180470-03	1.41304278-00	2.72360150-01	5.24120030-02	1.03098763-02	2.04634100-03	3.75427190-04	6.37975350-05
KAPPA(P)	2.375100-0-03	4.04235570-02	1.13109527-02	3.23777010-01	7.71601450-00	1.76475627-00	9.46139130-01	2.46858950-01
KAPPA(R)	3.99208470-02	2.41631520-02	7.31733430-01	1.80725910-01	3.51334650-00	8.47000750-01	3.80630150-01	2.33729520-01

THETA = 499.99553 13 DENSITIES

DENSITY	1.20537576-01	2.41145750-00	4.07220330-01	9.17929310-02	1.82378350-02	3.64198460-03	6.69185690-04	1.13766032-04
KAPPA(P)	0.51732090-02	2.46332290-02	6.52402120-01	1.42196003-01	2.95894560-00	7.43687470-01	2.99548770-01	2.17661120-01
KAPPA(R)	2.50202030-02	1.38572490-02	3.93523220-01	7.99043280-00	1.70858766-00	5.35350610-01	2.77076680-01	2.13342800-01

THETA = 699.99370 13 DENSITIES

DENSITY	2.01277600-01	3.90075060-00	7.64304120-01	1.51509940-01	3.01714850-02	6.02130670-03	1.10349439-03	1.07167940-04
KAPPA(P)	3.84600650-02	1.32293047-02	2.51767260-01	5.22172590-00	1.24830195-00	4.35494770-01	2.53451110-01	2.12607400-01
KAPPA(R)	1.15149421-02	4.35494130-01	1.29336967-01	2.84290940-00	7.80212860-01	3.34599160-01	2.27626080-01	2.04313040-01

THETA = 999.99767 13 DENSITIES

DENSITY	2.07569610-03	3.73724950-00	4.39661830-07	4.67136320-09	4.39637500-09	1.02227571-02	1.87286280-03	3.19044920-04
KAPPA(P)	2.03750740-01	2.02173130-01	2.01984160-01	2.01968000-01	2.01966580-01	3.33418770-01	2.25842370-01	2.05508400-01
KAPPA(R)	1.99629740-01	1.99571500-01	1.98311350-01	1.94290530-01	1.98288940-01	2.59791670-01	2.14986030-01	2.01740300-01

THETA = 1.90598060-03 13 DENSITIES

DENSITY	3.36303470-01	0.58229440-00	1.29916375-00	2.57749790-01	5.12554160-02	1.02227571-02	1.87286280-03	3.19044920-04
KAPPA(P)	1.62670220-02	4.12311060-02	9.27570930-00	2.35109410-00	7.46063690-01	3.33418770-01	2.25842370-01	2.05508400-01
KAPPA(R)	4.30412060-01	1.55728950-01	3.47315430-00	1.02883124-00	4.12964350-01	2.59791670-01	2.14986030-01	2.01740300-01

THETA = 2.02417460-01 13 DENSITIES

DENSITY	4.90598060-03	0.58229440-00	1.29916375-00	2.57749790-01	5.12554160-02	1.02227571-02	1.87286280-03	3.19044920-04
KAPPA(P)	2.02417460-01	2.02048200-01	2.02048200-01	2.01999310-01	2.01998700-01	3.33418770-01	2.25842370-01	2.05508400-01
KAPPA(R)	1.90735190-01	1.93409530-01	1.93372240-01	1.94372240-01	1.98371840-01	2.59791670-01	2.14986030-01	2.01740300-01

X-RAY ABSORPTION COEFFICIENTS CONTINUED

THETA = 1499.99710		13 DENSITIES	
DENSITY	9.60673000-01	2.27155010-00	9.70923000-01
KAPPA(P)	9.67771000-01	4.04011730-01	1.23006700-00
KAPPA(R)	1.90200000-01	7.21763020-00	6.33385000-01
DENSITY		1.37917670-06	1.46582300-07
KAPPA(P)	4.04231710-01	2.02242590-01	2.02219610-01
KAPPA(R)	1.90039000-01	1.90776750-01	1.90765200-01
THETA = 2299.99670		13 DENSITIES	
DENSITY	1.10769440-02	2.19426610-01	4.32697630-00
KAPPA(P)	3.00141000-01	6.35319730-00	5.58532920-01
KAPPA(R)	0.29797300-00	2.72157320-00	9.42769120-01
DENSITY		4.15353350-05	2.53362370-06
KAPPA(P)	2.04290790-01	2.04290790-01	2.04290790-01
KAPPA(R)	1.90096600-01	1.99076510-01	1.99076510-01
THETA = 3000.00050		13 DENSITIES	
DENSITY	4.03154420-02	4.02712150-01	6.03006610-00
KAPPA(P)	1.07941000-01	2.79113430-00	6.37323160-01
KAPPA(R)	1.31464467-00	3.460700970-01	2.90546390-01
DENSITY		4.00040470-05	4.70633710-06
KAPPA(P)	4.01575000-01	2.01502950-01	2.01502950-01
KAPPA(R)	1.90120470-01	1.93115500-01	1.93115500-01
THETA = 4999.99070		13 DENSITIES	
DENSITY	3.61377000-02	7.17499300-01	1.43173910-01
KAPPA(P)	9.97263000-00	1.21425490-00	3.28285900-01
KAPPA(R)	7.31200010-01	2.76144970-01	2.29132540-01
DENSITY		7.13915200-05	8.12310530-06
KAPPA(P)	4.03007200-01	1.03002700-01	1.03002700-01
KAPPA(R)	4.93215000-01	1.95917230-01	1.95917230-01
THETA = 6999.99090		13 DENSITIES	
DENSITY	3.97317010-02	1.13798401-02	2.37139610-01
KAPPA(P)	4.87599200-00	6.22176540-01	2.73390260-01
KAPPA(R)	3.04088340-01	2.22450360-01	2.03070920-01

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 999.9900 CONTINUED

DENSITY 9.0905740-01 1.817730-04 1.3003225-05 1.7721401-06 1.39032240-07
 KAPPA(P) 1.9335970-01 1.95376720-01 1.95835330-01 1.95835330-01 1.95835330-01
 KAPPA(R) 1.3416820-01 1.94157710-01 1.94167710-01 1.94167710-01 1.94167710-01

THETA = 999.9900 13 DENSITIES

DENSITY 1.02019050-01 2.02799340-02 4.04513480-01 8.08324170-01 1.61518903-00 1.61518903-00 1.00892579-02
 KAPPA(P) 1.00306580-01 3.51272950-01 2.19352770-01 1.94481330-01 1.88379640-01 1.88379640-01 1.88070570-01
 KAPPA(R) 2.31799620-01 2.0272930-01 1.94603320-01 1.92371570-01 1.91083070-01 1.91083070-01 1.90948800-01

DENSITY 1.55210755-01 2.0174360-04 2.37392690-05 2.52229850-06 2.37392730-07
 KAPPA(P) 1.8406970-01 1.89064380-01 1.88068880-01 1.88068880-01 1.88068880-01
 KAPPA(R) 1.90947330-01 1.90947330-01 1.90947330-01 1.90947330-01 1.90947330-01

18		JANUARY 1965		3/3/67		TAPC 1809		THETA(1-10)EV/FRONSD2		MATERL = 1076		MK = 207	
GREY ABSORPTION COEFFICIENTS		7		124		TEMPERATURES							
THETA =		1.0000		13		DENSITIES							
DENSITY	2.2592350-01	6.65172430-02	7.13825190-03	9.31433760-04	1.56433600-04	2.90490000-05	4.70243570-06	6.06531040-07					
KAPPA(P)	2.33790110-01	1.02305740-03	1.13933377-05	4.51001120-04	8.68299200-03	1.60997180-03	3.00542610-02	5.44463740-01					
KAPPA(R)	3.30295400-01	4.99610350-04	2.95414570-04	8.75674870-03	1.39511330-03	1.72127750-02	2.73966760-01	5.19429000-00					
DENSITY	7.4720640-01	9.33377420-09	3.04595830-10	7.85097430-11	7.30925470-12								
KAPPA(P)	8.43331700-01	9.03402420-11	7.97494850-02	1.24591137-02	7.20975710-03								
KAPPA(R)	7.6052500-01	8.87725210-02	1.6343410-02	7.76815140-03	6.68188620-03								
THETA =		1.5500		13		DENSITIES							
DENSITY	1.3506040-01	4.62259310-02	7.32974310-03	1.19507423-03	1.86115330-04	2.93449540-05	4.48007140-06	6.35780490-07					
KAPPA(P)	2.02140810-01	1.50354390-03	1.34124930-05	6.51143330-04	1.36389629-04	1.93160700-03	2.28772930-02	2.34360000-01					
KAPPA(R)	2.06212370-01	5.5534920-04	4.12439600-04	9.6929730-03	1.60895790-03	2.56144550-02	3.21044920-01	3.40000000-00					
DENSITY	9.0295030-01	1.12422216-03	1.33410141-09	1.7703260-10	1.13222661-11								
KAPPA(P)	2.10797450-01	2.1474610-01	3.11337270-02	1.14671163-02	9.45594190-03								
KAPPA(R)	3.23333030-01	4.05947413-02	1.16714070-02	7.76742950-03	7.97392870-03								
THETA =		2.2500		13		DENSITIES							
DENSITY	3.44074520-01	5.31104010-02	8.03557540-03	1.2599440-03	2.05472780-04	3.58449770-05	6.22224410-06	1.02188664-06					
KAPPA(P)	1.60147400-01	4.32301320-03	1.02460751-05	4.24223210-04	5.66724440-03	7.64736210-02	8.80755800-01	1.37525601-01					
KAPPA(R)	3.75319130-01	5.67519530-04	3.39787270-04	8.86875700-03	1.21941550-03	1.56461970-02	1.80346870-01	2.66219610-00					
DENSITY	1.4372500-01	1.54143500-03	1.20452242-09	1.70337410-10	1.30388699-11								
KAPPA(P)	3.0353500-01	5.71546770-01	8.0777700-02	1.44594440-02	1.25598750-02								
KAPPA(R)	3.3346920-01	4.39100330-02	2.24175530-02	1.27940820-02	1.19417090-02								
THETA =		3.4000		13		DENSITIES							
DENSITY	7.7509540-01	9.03705140-02	9.70621730-03	1.67976397-03	3.05368280-04	5.51433980-05	8.96496740-06	1.35640075-06					
KAPPA(P)	1.1700040-01	8.25035020-04	5.17149430-04	2.10168330-04	4.41954020-03	7.89693560-02	1.24366180-02	1.85440300-01					
KAPPA(R)	3.1155940-01	3.33061050-04	2.31301120-04	6.24760780-03	1.17494060-03	1.97150020-02	3.25272090-01	5.20956310-00					
DENSITY	1.7109450-01	1.9404730-08	2.29411240-09	2.43192000-10	2.28813250-11								
KAPPA(P)	1.95755140-01	1.62146039-01	2.21899230-02	1.41342133-02	1.33348016-02								
KAPPA(R)	3.1513300-01	4.43003180-02	1.39559100-02	1.33444880-02	1.30362621-02								
THETA =		5.0000		13		DENSITIES							
DENSITY	4.8039100-01	8.17372040-02	1.33693315-02	2.41246760-03	4.08073610-04	6.43383350-05	1.04467469-05	1.74000976-06					
KAPPA(P)	5.7212230-01	5.16450670-04	3.02723100-04	1.29144425-04	2.46750610-03	2.73618270-02	1.79437340-01	2.00001600-00					
KAPPA(R)	6.0146740-01	1.303794300-04	1.53552226-04	5.70043030-03	1.21613120-03	1.26791243-02	7.24665510-00	5.08669430-01					

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.0000 CONTINUED			13 DENSITIES		
DENSITY	2.6793750-17	3.43236930-03	3.74902560-09	3.85966760-10	3.36058850-11
KAPPA(P)	2.77591760-11	4.81051760-02	1.92366110-02	1.50396110-02	1.62289110-02
KAPPA(R)	6.5020310-12	2.1037470-02	1.49939752-02	1.49127912-02	1.58379550-02
THETA = 7.0000			13 DENSITIES		
DENSITY	6.4295250-11	4.10705311-01	1.30253120-02	2.68856150-03	4.70626880-04
KAPPA(P)	3.7703150-11	4.70340410-04	1.22268500-04	3.87233340-03	3.75310230-02
KAPPA(R)	1.30021877-11	1.30318591-04	1.02255190-04	2.25076380-03	1.61978720-02
DENSITY	3.87670350-17	4.63140310-06	4.97679380-09	4.89444380-10	4.33042700-11
KAPPA(P)	3.68847150-11	7.64293790-02	2.78072360-02	2.10712230-02	2.09401060-02
KAPPA(R)	7.20103750-12	4.92407200-02	2.33961520-02	1.97276680-02	2.08396020-02
THETA = 10.0000			13 DENSITIES		
DENSITY	3.5195840-11	1.33740750-01	2.10226680-02	3.90092340-03	7.44608500-04
KAPPA(P)	2.3420330-11	1.95319140-04	1.37281075-04	2.53142310-03	5.10956760-02
KAPPA(R)	9.4630530-11	1.04349257-04	3.19822380-03	4.45582730-02	6.86636510-01
DENSITY	3.10053010-17	3.93772160-06	5.07190280-09	4.57081320-10	4.10947840-11
KAPPA(P)	5.8839930-11	1.49253410-01	1.96527280-01	3.7921500-02	3.71679670-02
KAPPA(R)	1.38553320-11	5.18202130-02	3.47513100-02	3.55080090-02	3.65878520-02

9.20671820-05 1.67138970-05 2.73289260-06
 5.18334630-01 9.11698030-00 1.79380957-00
 1.25491756-01 1.71458487-00 3.08663990-01

1.37959690-04 2.30897920-05 3.58788740-06
 9.50174800-01 1.70132580-01 3.06829180-08
 1.36658084-01 2.02117370-00 5.89031150-01

33	DIAPYSCAT	AE-12A	TEMP(1-10)	12 FREQ	CI/RS	9-2-67	INPUT TAPE(S235)	MATERL = 1054	NR = 287
GREY ABSORPTION COEFFICIENTS									
7 TEMPERATURES									
13 DENSITIES									
THETA =	1.00000								
DENSITY	1.32019457-12	2.64200330-03	5.29191000-04	1.05713178-04	2.11253370-05	4.22288940-06	7.74157070-07	1.31943770-07	
KAPPA(P)	1.23107700-13	2.42334330-03	5.04952600-04	1.84865050-04	6.68210400-03	1.86992010-03	4.29564120-02	8.01304420-01	
KAPPA(R)	1.09311023-15	2.50224310-04	5.22461790-03	1.64656560-03	5.09524020-02	1.30334590-02	2.77530830-01	5.16677130-00	
DENSITY	2.02388000-03	2.63857130-09	3.10452600-10	3.24856020-11	3.10452650-12				
KAPPA(P)	1.31060336-11	1.76747309-00	2.24067890-01	3.77550520-02	1.75836990-02				
KAPPA(R)	8.56732550-11	1.35560130-01	3.43279290-02	1.87536100-02	1.57422200-02				
THETA =	1.50000								
DENSITY	2.84230400-02	4.43417300-03	9.71806070-04	1.74008880-04	3.87941950-05	7.75719360-06	1.42886770-06	2.42344320-07	
KAPPA(P)	2.71984600-03	1.31497433-05	3.92191290-04	1.13383258-04	2.93931820-03	6.95943100-02	1.42764290-02	2.59044550-01	
KAPPA(R)	1.10308572-03	3.39349970-04	7.28951960-03	1.60547500-03	4.18334740-02	9.60873780-01	1.91378400-01	3.43049520-00	
DENSITY	3.74315220-03	4.84790130-09	5.70333210-10	6.05905670-11	5.70333310-12				
KAPPA(P)	4.14264723-00	5.60404600-01	8.60771710-02	2.92872810-02	2.29614630-02				
KAPPA(R)	3.54598020-01	9.1912320-02	2.09135630-02	1.72646540-02	1.55594363-02				
THETA =	2.25000								
DENSITY	4.40042700-02	6.92303470-03	1.78454829-03	3.56480150-04	7.12630240-05	1.42504808-05	2.41946680-06	4.45307880-07	
KAPPA(P)	3.04328050-03	9.39213100-04	5.12448250-04	2.42211100-04	5.65875340-03	1.17516740-03	2.25367850-02	4.23444638-01	
KAPPA(R)	3.67482390-04	3.439441340-04	1.07445263-04	2.34979170-03	5.36251860-02	1.13504369-02	2.15419640-01	3.74442470-00	
DENSITY	3.23390450-08	8.90604650-09	1.04779230-09	1.11326944-10	1.04774077-11				
KAPPA(P)	9.06776430-00	3.09020050-00	2.19087500-00	2.13020680-00	1.94365552-00				
KAPPA(R)	3.99716700-01	9.77304480-02	2.44604180-02	1.74202490-02	1.58796660-02				
THETA =	3.40000								
DENSITY	8.30330400-02	1.66077470-02	3.31541630-03	6.62215850-04	1.32375760-04	2.64712860-05	4.86584600-06	8.27174650-07	
KAPPA(P)	1.50661600-03	7.22446590-04	8.74015390-04	1.93932910-04	4.42320480-03	1.12153110-03	2.98372260-02	1.28269550-02	
KAPPA(R)	2.46358440-04	1.778657650-04	1.07466649-04	3.74814350-03	8.96519430-02	1.87155720-02	3.49111740-01	6.00810870-00	
DENSITY	1.27209490-07	1.61909410-08	1.47477564-09	1.47334170-10	1.39023977-11				
KAPPA(P)	7.82262400-01	5.96446120-01	1.19714179-01	1.93817350-01	2.32893290-02				
KAPPA(R)	9.49783510-01	1.42785850-01	3.24467810-02	2.32816680-02	2.21679880-02				
THETA =	5.00000								
DENSITY	1.49916520-01	2.97344660-02	5.92121270-03	1.14139065-03	2.36021660-04	4.70251080-05	8.10661670-06	1.09645320-06	
KAPPA(P)	8.79901300-04	4.51872390-04	3.30071680-04	1.96709650-04	5.98041090-03	1.77562890-03	6.10316680-02	6.70030378-01	
KAPPA(R)	1.34561720-04	1.07573112-04	6.56400870-03	3.67939650-03	1.514448380-03	3.77178660-02	6.36288330-01	3.12688720-00	

GREY ABSORPTION COEFFICIENTS CONTINUED

THETA = 5.0000 CONTINUED

DENSITY 1.621740-07 2.47637530-09 2.60734120-10 2.32878360-11
 KAPPA(P) 1.965042+00 2.49688830-02 2.31952910-02 2.34835290-02
 KAPPA(R) 1.61594510-01 2.33987230-02 2.21628460-02 2.29400720-02

THETA = 7.0000 13 DENSITIES

DENSITY 2.50584210-01 7.96444340-02 9.40193010-03 1.90709532-03 3.28802940-04 5.69607590-05 1.02784618-05 1.74182011-06
 KAPPA(P) 3.29784470+04 3.07292390+04 2.04015870+04 9.36667920+03 2.02458080+03 1.44827580+02 1.21989879+01 1.95471790+00
 KAPPA(R) 1.83524300+04 5.19167040+03 4.53427790+03 2.56460810+03 9.52339830+02 7.49085430+01 5.08320000+00 5.05307450-01

DENSITY 2.65059400-07 3.28688690-08 3.65229580-09 3.80403040-10 3.44555900-11
 KAPPA(P) 4.97974610-01 1.73000410-01 5.38554630-02 2.83708240-02 2.61475700-02
 KAPPA(R) 1.63932420-01 7.45017990-02 3.69417340-02 2.66722390-02 2.56706490-02

THETA = 10.0000 13 DENSITIES

DENSITY 4.29705110-01 8.04141610-02 1.38023775-02 2.44468210-03 4.77805410-04 9.43714540-05 1.67938140-05 2.68862690-06
 KAPPA(P) 3.16363310+04 2.04565600+04 8.71463470+03 1.70934370+03 3.45794280+02 8.61818210+01 2.35453170+01 6.38490100+00
 KAPPA(R) 1.24364450+04 8.27486270+03 3.62149750+03 6.44684820+02 1.11813797+02 2.63931390+01 9.28278040+00 2.59669990+00

DENSITY 3.96671450-07 4.70215450-08 5.043337810-09 4.96479060-10 4.31236360-11
 KAPPA(P) 1.11424234+00 1.86100940-01 5.27993710-02 3.53704690-02 3.53712830-02
 KAPPA(R) 4.81035740-01 9.31768570-02 4.88769070-02 3.41019060-02 3.46934200-02

TAPE EDITING IS SUCCESSFUL
 THE NUMBER OF GREY SETS EDITED IS 31 THE NUMBER OF GREY SETS REQUESTED IS -0

This page intentionally left blank.

CARD INPUT USED WITH

GREYS

DIANE GREY TAPE 11/11/67 A. KNOPP MATERIALS ARE AIR, WET ALLUVIUM, AL, HE,
C, F2, CH2, C-PHENOLIC, PL, GINA-1HONIC, GRANITE, GROUT, H, H-M-O-X, L, L, LIMESTONE,
NE, PHEOLIC, PLTCA, PLTYL, WET TUFF, REFNASIL, SEAWATER, S, SMALL, W, XE

1081201

1061201
DIANE AIR-12A, 12 FREQUENCIES DECEMBER 21, 1965 COMBINED WITH AIR-11F

0.120000+02 0.742000+03

1102.

0.1102	0.230000+02	0.677237+01	0.924061+01	0.434821+01	0.613962+01	23	40
0.256501+00	0.600000+01	0.563093+01	0.872546+01	0.895338+01	0.501413+01	23	41
0.914742+01	0.865079+01	0.563093+01	0.872546+01	0.135565+02	0.169848+01	23	42
0.799319+01	0.112560+02	0.374186+01	0.658701+01	0.181637+02	0.204224+01	23	43
0.450265+01	0.158611+02	0.446168+00	0.218908+01	0.689550+01	0.102140+02	23	44
-0.685781+01	0.204663+02	0.405465+00	0.100000+02	0.674567+01	0.100627+02	23	45
-0.208363+00	0.677235+01	0.101662+02	0.217646+01	0.594792+01	0.904098+01	23	46
0.487587+01	0.655066+01	0.963923+01	0.764838+01	0.314731+01	0.592050+01	23	47
0.101614+02	0.475467+01	0.765627+01	0.121977+02	0.192841+00	0.216075+01	23	48
0.140188+02	0.149875+01	0.403196+01	0.158198+02	0.615186+00	0.100000+02	23	49
0.177106+02	0.638672+00	0.511200+00	0.198432+02	0.109449+02	0.338272+01	23	50
0.840781+01	0.110527+02	0.967186+00	0.818188+01	0.100375+02	0.382856+01	23	51
0.798034+01	0.108822+02	0.595402+01	0.476710+01	0.708948+01	0.120157+02	23	52
0.620001+01	0.873409+01	0.102979+02	0.631176+01	0.379999+01	0.155999+02	23	53
0.339192+01	0.5394701+01	0.137490+02	0.231999+01	0.105607+01	0.199993+02	23	54
0.132568+01	0.258329+01	0.177068+02	0.115112+02	0.172770+01	0.922199+01	13	1
0.810930+00	0.100000+02	0.943287+01	0.107284+02	0.636263+01	0.783562+01	13	2
0.112665+02	0.405747+01	0.875466+01	0.836716+01	0.101129+02	0.546547+01	13	3
0.979416+01	0.836361+01	0.654533+01	0.836716+01	0.136533+02	0.313045+01	13	4
0.691535+01	0.117972+02	0.445660+01	0.563859+01	0.172767+02	0.407684+00	13	5
0.938777+01	0.156926+02	0.131816+01	0.270894+01	0.104598+02	0.117046+02	13	6
0.760632+00	0.198171+02	0.101160+01	0.100000+02	0.934230+01	0.105915+02	13	7
0.216990+01	0.100113+02	0.112669+02	0.433946+01	0.736564+01	0.849002+01	13	8
0.637895+01	0.842795+01	0.964324+01	0.814682+01	0.445134+01	0.592302+01	13	9
0.994456+01	0.613663+01	0.733372+01	0.117761+02	0.445134+01	0.592302+01	13	9
0.137030+02	0.259037+01	0.418178+01	0.155836+02	0.104337+01	0.434568+01	13	10
0.175057+02	0.260632+00	0.677329+00	0.196712+02	0.122378+01	0.100000+02	13	11
0.111393+02	0.117270+02	0.234674+01	0.105745+02	0.112197+02	0.435141+01	13	12
0.982372+02	0.106667+02	0.624494+01	0.879924+01	0.996039+01	0.807307+01	13	13
0.734851+01	0.878575+01	0.993804+01	0.561925+01	0.731333+01	0.117394+02	13	14
0.410667+01	0.564420+01	0.135253+02	0.286733+01	0.408699+01	0.154026+02	13	15
0.142332+01	0.254677+01	0.174443+02	0.222558+00	0.768713+00	0.195869+02	13	16
0.160944+01	0.100000+02	0.114442+02	0.117443+02	0.237513+01	0.107682+02	13	17
0.113455+02	0.420567+01	0.962378+01	0.108493+02	0.609454+01	0.841519+01	13	18
0.993068+01	0.793930+01	0.731562+01	0.864760+01	0.971447+01	0.603192+01	13	19
0.726796+01	0.114913+02	0.447808+01	0.573506+01	0.133161+02	0.289057+01	13	20

AFWL-TR-67-131, Vol IV

0.913123+01	0.713833+01	0.705805+01	0.757811+01	0.885435+01	0.522097+01	13	35
0.588422+01	0.105227+02	0.330792+01	0.402849+01	0.122415+02	0.144472+01	13	36
0.215378+01	0.140199+02	0.188504+00	0.357146+00	0.158930+02	0.116441+01	13	37
-0.103982+01	0.179334+02	0.311352+01	0.100000+02	0.922718+01	0.109396+02	13	38
0.146986+01	0.898218+01	0.104330+02	0.321347+01	0.849665+01	0.952396+01	13	39
0.495518+01	0.745352+01	0.794485+01	0.666029+01	0.590100+01	0.626493+01	13	40
0.831132+01	0.419906+01	0.456534+01	0.993846+01	0.241301+01	0.278082+01	13	41
0.116395+02	0.634242+00	0.966881+00	0.134129+02	0.845557+00	0.678550+00	13	42
0.152450+02	0.167660+01	0.164791+01	0.173259+02	0.352636+01	0.110000+02	13	43
0.803590+01	0.101886+02	0.101662+01	0.745051+01	0.946126+01	0.273446+01	13	44
0.654284+01	0.821148+01	0.442217+01	0.528069+01	0.662242+01	0.607470+01	13	45
0.383104+01	0.444144+01	0.770556+01	0.231795+01	0.327239+01	0.932348+01	13	46
0.837833+00	0.168089+01	0.110295+02	0.356589+00	0.399216+00	0.128328+02	13	47
-0.116481+01	0.611398+00	0.147679+02	0.151629+01	0.132617+01	0.168580+02	13	48
-0.159916+01	0.154740+01	0.192371+02	0.391202+01	0.110000+02	0.732884+01	13	49
0.939175+01	0.534833+00	0.641067+01	0.841827+01	0.221485+01	0.526586+01	13	50
0.718032+01	0.388251+01	0.393636+01	0.580200+01	0.552401+01	0.263748+01	13	51
0.460665+01	0.717576+01	0.142382+01	0.348018+01	0.884869+01	0.296376+00	13	52
0.223158+01	0.106070+02	0.637079+00	0.922559+00	0.124520+02	0.130453+01	13	53
-0.430592+00	0.143728+02	0.155278+01	0.129547+01	0.164372+02	0.160512+01	13	54
-0.155735+01	0.187522+02	0.424350+01	0.110000+02	0.734139+01	0.908506+01	13	55
0.807368+01	0.625192+01	0.814114+01	0.175808+01	0.504329+01	0.707234+01	13	56
0.343595+01	0.381969+01	0.596412+01	0.512607+01	0.252132+01	0.479154+01	13	57
0.681394+01	0.122580+01	0.351866+01	0.849528+01	0.487093+01	0.201756+01	13	58
0.102335+02	0.100330+01	0.412418+00	0.120270+02	0.144756+01	0.898935+00	13	59
0.139055+02	0.156301+01	0.147204+01	0.159469+02	0.159784+01	0.158334+01	13	60
0.182497+02	0.460517+01	0.110000+02	0.771458+01	0.907600+01	0.385538+00	13	61
0.660875+01	0.827616+01	0.131961+01	0.535416+01	0.711347+01	0.303207+01	13	62
0.392067+01	0.578244+01	0.472798+01	0.231921+01	0.430429+01	0.639034+01	13	63
0.724033+00	0.273943+01	0.802286+01	0.532945+00	0.108043+01	0.972468+01	13	64
-0.115367+01	0.404407+00	0.114995+02	0.141672+01	0.130007+01	0.133718+02	13	65
-0.156222+01	0.155858+01	0.154121+02	0.160871+01	0.159603+01	0.177147+02	13	66
0.501064+01	0.110000+02	0.774611+01	0.874798+01	0.872527+00	0.681442+01	13	67
0.772504+01	0.642410+00	0.543275+01	0.637259+01	0.253456+01	0.370974+01	13	68
0.480153+01	0.418402+01	0.192452+01	0.319553+01	0.580857+01	0.423395+00	13	69
0.159820+01	0.742239+01	0.586861+00	0.504535+01	0.911793+01	0.122336+01	13	70
-0.108062+01	0.108915+02	0.153737+01	0.151885+01	0.127636+02	0.160328+01	13	71
-0.158788+01	0.148039+02	0.161154+01	0.159639+01	0.171065+02	0.541610+01	13	72
0.110000+02	0.650342+01	0.801177+01	0.138005+01	0.557203+01	0.673216+01	13	73
0.311508+00	0.428474+01	0.523786+01	0.196204+01	0.274826+01	0.364089+01	13	74
0.358903+01	0.117205+01	0.202089+01	0.520327+01	0.251208+00	0.466176+00	13	75
0.681491+01	0.118191+01	0.858206+00	0.850991+01	0.152739+01	0.145814+01	13	76
0.102834+02	0.160054+01	0.157639+01	0.121554+02	0.161189+01	0.159348+01	13	77
0.141957+02	0.161334+01	0.159571+01	0.164983+02	0.582895+01	0.110000+02	13	78
0.468747+01	0.664161+01	0.193037+01	0.361921+01	0.552972+01	0.271855+00	13	79
0.224161+01	0.400525+01	0.135653+01	0.764918+00	0.242780+01	0.297263+01	13	80
-0.525141+00	0.850862+00	0.458555+01	0.124661+01	0.547886+00	0.619623+01	13	81
-0.152822+01	0.136313+01	0.789093+01	0.160391+01	0.156949+01	0.966409+01	13	82
-0.161869+01	0.160276+01	0.115362+02	0.162102+01	0.160774+01	0.135764+02	13	83
-0.162130+01	0.160838+01	0.158790+02	0.621461+01	0.110000+02	0.322939+01	13	84
0.586630+01	0.246805+01	0.198888+01	0.448949+01	0.838755+00	0.555154+00	13	85
0.298515+01	0.782076+00	0.651724+00	0.136495+01	0.239480+01	0.128905+01	13	86
-0.116127+00	0.400792+01	0.152468+01	0.116519+01	0.561832+01	0.160568+01	13	87
-0.195216+01	0.731268+01	0.162687+01	0.160666+01	0.908560+01	0.163084+01	13	88
-0.161814+01	0.109577+02	0.163147+01	0.161988+01	0.129979+02	0.163156+01	13	89

```

-0.162011+01 0.153005+02 0.655108+01 0.900000+01-0.151621+01-0.673025+00 13 90
0.350288+01-0.160659+01-0.147109+01 0.511375+01-0.163312+01-0.160920+01 13 91
0.680819+01-0.163939+01-0.163288+01 0.858089+01-0.164053+01-0.163681+01 13 92
0.104530+02-0.164072+01-0.163744+01 0.124932+02-0.164074+01-0.163752+01 13 93
0.147958+02-0.164075+01-0.163753+01 0.170984+02-0.164075+01-0.163753+01 13 94
0.194010+02 0.690770+01 0.900000+01-0.160157+01-0.130573+01 0.296873+01 13 95
-0.163606+01-0.158007+01 0.457709+01-0.164574+01-0.164112+01 0.627337+01 13 96
-0.164702+01-0.164951+01 0.000450+01-0.164023+01-0.165095+01 0.771775+01 13 97
-0.164830+01-0.165117+01 0.119502+02-0.164831+01-0.165120+01 0.142600+02 13 98
-0.164831+01-0.165120+01 0.165034+02-0.164831+01-0.165121+01 0.188660+02 13 99
0.731322+01 0.700000+01-0.163773+01-0.151007+01 0.236077+01-0.165034+01 13 100
-0.162730+01 0.527077+01-0.163344+01-0.165173+01 0.666521+01-0.165000+01 13 101
-0.165575+01 0.743700+01-0.165417+01-0.165645+01 0.430775+01-0.165417+01 13 102
-0.165676+01 0.113500+02-0.165420+01-0.165677+01 0.136526+02-0.165420+01 13 103
-0.165677+01 0.113500+02-0.165420+01-0.165677+01 0.162370+02 0.771000+01 13 104
0.900000+01-0.164001+01-0.165327+01 0.173522+01-0.165330+01-0.165330+01 13 105
0.350300+01-0.165433+01-0.165093+01 0.505714+01-0.165434+01-0.165093+01 13 106
0.602700+01-0.165434+01-0.165016+01 0.070155+01-0.165434+01-0.165019+01 13 107
0.107410+02-0.165434+01-0.165019+01 0.130444+02-0.165434+01-0.165019+01 13 108
0.133470+02-0.165434+01-0.165019+01 0.176496+02 0. 13 109

```

DIANE/SCAT ALLUUVIUM=10 INPUT TAPLS(440/2686,3903) 11-7-67 C1/LN

```

.1000000+01 .9040000+03 1 0
.1130. .2400000+02 1 1
.4054651+00 .1300000+02 .1210211+02 .1314954+02 .1386000+01 .1175560+02 1 2
.1275456+02 .3530000+01 .1108417+02 .1272574+02 .5814212+01 .9074235+01 1 3
.1149855+02 .7995490+01 .0517470+01 .1006115+02 .1016543+02 .7025324+01 1 4
.8459760+01 .1217246+02 .5500003+01 .6788167+01 .1407134+02 .3403782+01 1 5
.4870420+01 .1543754+02 .1330009+01 .2004427+01 .1783607+02 .6505289+00 1 6
.0174234+00 .1907130+02 .2131502+01 .1043266+01 .2210414+02 .2007806+01 1 7
- .2273732+01 .2457008+02 .2923975+01 .2837849+01 .2708455+02 .8109302+00 1 8
.1300000+02 .1314190+02 .1343532+02 .2130912+01 .1257392+02 .1302925+02 1 9
.4224920+01 .1173079+02 .1260641+02 .6389536+01 .1047850+02 .1152752+02 1 10
.8381848+01 .8901670+01 .9787643+01 .1018662+02 .7093116+01 .7934236+01 1 11
.1188140+02 .5250519+01 .6163332+01 .1364425+02 .3527284+01 .4574189+01 1 12
.1557567+02 .1670930+01 .2874569+01 .1763741+02 .2976324+00 .8893305+00 1 13
.1975577+02 .1856848+01 .1022122+01 .2195175+02 .2595775+01 .2322142+01 1 14
.2420084+02 .2682652+01 .2638732+01 .2674024+02 .1223775+01 .1300000+02 1 15
.1307276+02 .1324652+02 .2457442+01 .1256233+02 .1273430+02 .4405435+01 1 16
.1173541+02 .1219572+02 .6279429+01 .1046124+02 .1115309+02 .8075918+01 1 17
.8840741+01 .9672305+01 .9870285+01 .7099316+01 .7957113+01 .1166060+02 1 18
.5247773+01 .6135610+01 .1345970+02 .3368760+01 .4314206+01 .1531659+02 1 19
.1477360+01 .2455569+01 .1729632+02 .4157226+00 .5201386+00 .1943329+02 1 20
- .1880707+01 .1324971+01 .2100398+02 .2455226+01 .2323305+01 .2387812+02 1 21
- .2492028+01 .2464255+01 .2633254+02 .1609438+01 .1300000+02 .1274071+02 1 22
.1293604+02 .2403592+01 .1231833+02 .1253555+02 .4187738+01 .1155922+02 1 23
.1202903+02 .6032113+01 .1030471+02 .1089686+02 .7855889+01 .8594922+01 1 24
.9289424+01 .9614204+01 .6729962+01 .7517072+01 .1135293+02 .4831251+01 1 25
.5632960+01 .1315388+02 .2908432+01 .3740539+01 .1498081+02 .1060812+01 1 26
.1981455+01 .1691701+02 .7298276+00 .1498317+00 .1903493+02 .1925168+01 1 27
- .1513761+01 .2121474+02 .2281550+01 .2192672+01 .2352738+02 .2311544+01 1 28
- .2287573+01 .2594747+02 .1945910+01 .1300000+02 .1224830+02 .1262534+02 1 29
.2225420+01 .1194923+02 .1226007+02 .3994367+01 .1170027+02 .1169274+02 1 30
.5804269+01 .9833086+01 .1041055+02 .7586187+01 .7929054+01 .8711154+01 1 31
.9336194+01 .6130140+01 .6930402+01 .1103588+02 .4347941+01 .5149097+01

```

AFWL-TR-67-131, Vol IV

.1281496+02	.2580077+01	.3380947+01	.1465142+02	.7335765+00	.1672713+02	1	32
.1659324+02	.9862258+00	.1465331+00	.1670001+02	.1888769+01	.1570571+01	1	33
.2090921+02	.2101083+01	.2044187+01	.2323640+02	.2131185+01	.2110061+01	1	34
.2562890+02	.2302585+01	.1300000+02	.1170343+02	.1226826+02	.1963387+01	1	35
.1143195+02	.1189851+02	.3718386+01	.1056387+02	.1125126+02	.5501988+01	1	36
.9112231+01	.4922271+01	.7253751+01	.7415001+01	.8248817+01	.8985313+01	1	37
.5700462+01	.6551893+01	.1066575+02	.3937263+01	.4819458+01	.1246439+02	1	38
.2170885+01	.3110415+01	.1432079+02	.3762539+00	.1388695+01	.1627591+02	1	39
.1181711+01	.4068141+00	.1835592+02	.1884034+01	.1640715+01	.2052657+02	1	40
.2048457+01	.2907835+01	.2278824+02	.2049946+01	.2031899+01	.2517727+02	1	41
.2708050+01	.1300000+02	.1134192+02	.1181819+02	.1641854+01	.1095877+02	1	42
.1146373+02	.3365440+01	.1010585+02	.1070194+02	.5125315+01	.8761507+01	1	43
.9337534+01	.6867236+01	.7062040+01	.7657921+01	.8602844+01	.5250327+01	1	44
.5932398+01	.1031083+02	.3340427+01	.4142652+01	.1206925+02	.1478883+01	1	45
.2362528+01	.1387823+02	.1919291+00	.5811237+00	.1577825+02	.1431115+01	1	46
.1012316+01	.1784606+02	.1866598+01	.1789665+01	.2001462+02	.1953972+01	1	47
.1935334+01	.2228227+02	.1947453+01	.1929238+01	.2467445+02	.3113515+01	1	48
.1300000+02	.1098416+02	.1144400+02	.1261368+01	.1061131+02	.1106011+02	1	49
.2991522+01	.9747717+01	.1012001+02	.4742370+01	.8244655+01	.8633336+01	1	50
.6475829+01	.6378948+01	.6943619+01	.8173862+01	.4559463+01	.5218984+01	1	51
.9830085+01	.2797426+01	.3449351+01	.1156407+02	.1000487+01	.1792777+01	1	52
.1336855+02	.5893570+00	.9913234+01	.1527216+02	.1505219+01	.1245235+01	1	53
.1734475+02	.1809210+01	.1762383+01	.1951686+02	.1851643+01	.1831070+01	1	54
.2178991+02	.1034217+01	.1815660+01	.2418120+02	.3526360+01	.1300000+02	1	55
.1024435+02	.1090291+02	.8512523+00	.9948400+01	.1052302+02	.2577967+01	1	56
.9087813+01	.4549789+01	.4300172+01	.7553873+01	.8121817+01	.5992533+01	1	57
.5784517+01	.6334407+01	.7662775+01	.3984450+01	.4626419+01	.9317258+01	1	58
.2201426+01	.2937047+01	.1104948+02	.5448456+00	.1280163+01	.1285706+02	1	59
.6542364+00	.2850565+00	.1476151+02	.1593699+01	.1389477+01	.1682984+02	1	60
.1754735+01	.1705320+01	.1900251+02	.1744707+01	.1722503+01	.2128485+02	1	61
.1722133+01	.1703716+01	.2367454+02	.3912023+01	.1300000+02	.9244134+01	1	62
.1012445+02	.4271455+00	.8756487+01	.9338826+01	.2120636+01	.7839183+01	1	63
.8319763+01	.3817790+01	.6306278+01	.6849719+01	.5492059+01	.4787225+01	1	64
.5432130+01	.7157540+01	.3207021+01	.3986842+01	.8812608+01	.1531384+01	1	65
.2390267+01	.1054686+02	.1049067+00	.8160591+00	.1236647+02	.1200519+01	1	66
.5950290+00	.1427427+02	.1598099+01	.1417821+01	.1635267+02	.1670622+01	1	67
.1634433+01	.1851630+02	.1686125+01	.1666658+01	.2076608+02	.1686705+01	1	68
.1668326+01	.2313190+02	.4248495+01	.1300000+02	.8729855+01	.9477706+01	1	69
.1753163+01	.8216487+01	.8743660+01	.1710021+01	.7265253+01	.7671065+01	1	70
.3398518+01	.5747053+01	.6264346+01	.5071846+01	.4193835+01	.4931932+01	1	71
.6747455+01	.2477108+01	.3476667+01	.8412590+01	.8232877+00	.1947750+01	1	72
.1014779+02	.5674356+00	.3963593+00	.1195272+02	.1335898+01	.9214360+00	1	73
.1383785+02	.1608462+01	.1524474+01	.1588274+02	.1667763+01	.1646635+01	1	74
.1802621+02	.1675667+01	.1658081+01	.2027212+02	.1674882+01	.1656709+01	1	75
.2263907+02	.4605170+01	.1300000+02	.8422995+01	.9096876+01	.4310307+00	1	76
.7891497+01	.8371687+01	.1263771+01	.6804485+01	.7220706+01	.2762153+01	1	77
.5220768+01	.5788995+01	.4647704+01	.3510363+01	.4328523+01	.6314163+01	1	78
.1811181+01	.2808652+01	.7955603+01	.2016167+00	.1207575+01	.9661896+01	1	79
.9202217+00	.3203235+00	.1143940+02	.1453699+01	.1300447+01	.1331565+02	1	80
.1618144+01	.1599050+01	.1535996+02	.1659784+01	.1644447+01	.1750391+02	1	81
.1659645+01	.1641539+01	.1975529+02	.1642276+01	.1623898+01	.2213695+02	1	82
.5010635+01	.1300000+02	.7887819+01	.8703106+01	.9376086+00	.7303079+01	1	83
.7888424+01	.7679183+00	.6107053+01	.6510252+01	.2457503+01	.4484373+01	1	84
.4988959+01	.4118437+01	.2735773+01	.3410705+01	.5750261+01	.1156478+01	1	85
.1847889+01	.7369205+01	.2147726+00	.3219659+00	.9069378+01	.1111882+01	1	86

AFWL-TR-67-131, Vol IV

- .0660195-00	.1085054+02	.1500765+01	.1420967+01	.1273447+02	.1602154+01	1	87
- .1571341+01	.1479868+02	.1610968+01	.1591113+01	.1645130+02	.1611463+01	1	88
- .1592470+01	.1919602+02	.1611524+01	.1593157+01	.2155956+02	.5416100+01	1	89
.1300000+02	.7070184+01	.8022474+01	.1445169+01	.6296457+01	.6062936+01	1	90
.2411105-00	.5038554+01	.5360577+01	.1901367+01	.3576030+01	.3725951+01	1	91
.3530354+01	.2039601+01	.2555467+01	.5166243+01	.550457H-00	.1278675+01	1	92
.6795537+01	.6919564-00	.3753074-02	.6507845+01	.1340493+01	.1035070+01	1	93
.1029057+02	.1552393+01	.1482490+01	.1216533+02	.1598513+01	.1578134+01	1	94
.1420000+02	.1608414+01	.1591388+01	.1634621+02	.1611149+01	.1592988+01	1	95
.1858818+02	.1611536+01	.1593160+01	.2095159+02	.5828946+01	.1300000+02	1	96
.6334476+01	.7234829+01	.1990469+01	.5376227+01	.5472272+01	.3278895-00	1	97
.4226657+01	.4721642+01	.1317468+01	.2730215+01	.3416016+01	.2960495+01	1	98
.1141583+01	.2002037+01	.4589762+01	.2459725-00	.5381392-00	.6206706+01	1	99
- .1112121+01	.7332440-00	.7902436+01	.1453177+01	.1384703+01	.9674783+01	1	100
- .1569106+01	.1558418+01	.1154665+02	.1604655+01	.1588604+01	.1358689+02	1	101
- .1610689+01	.1592598+01	.1572700+02	.1611134+01	.1592767+01	.1796927+02	1	102
- .1609889+01	.1591492+01	.2033380+02	.6214608+01	.1306790+02	.5640671+01	1	103
.6514454+01	.2520140+01	.4871348+01	.5492436+01	.8633628-00	.3534524+01	1	104
.4130560+01	.7768204-00	.1944049+01	.2617630+01	.2403616+01	.4259789-00	1	105
.1058774+01	.4019540+01	.6766121-00	.3114736-00	.5630250+01	.1285810+01	1	106
- .120371+01	.7324397+01	.1532994+01	.1514541+01	.9096658+01	.1597132+01	1	107
- .1578805+01	.1096942+02	.1606858+01	.1588321+01	.1301128+02	.1606969+01	1	108
- .1588565+01	.1515280+02	.1606726+01	.1588343+01	.1739523+02	.1606707+01	1	109
- .1588308+01	.1975850+02	.6551080+01	.1300000+02	.4725202+01	.5944456+01	1	110
- .2984501+01	.3850264+01	.4654601+01	.1344970+01	.2508005+01	.3190569+01	1	111
.2842532-00	.9987531-00	.1617424+01	.1902370+01	.2893223-00	.1826300-00	1	112
.3515714+01	.1102649+01	.8722718-00	.5126702+01	.1472541+01	.1392053+01	1	113
.6822097+01	.1577813+01	.1547216+01	.8595573+01	.1600461+01	.1581480+01	1	114
.1040814+02	.1605664+01	.1587512+01	.1250853+02	.1606614+01	.1588226+01	1	115
.1464062+02	.1606693+01	.1588295+01	.1689059+02	.1606701+01	.1588302+01	1	116
.1925380+02	.6907755+01	.1300000+02	.3637444+01	.5856931+01	.3498642+01	1	117
.2659386+01	.3667233+01	.1868764+01	.1300000+01	.2163157+01	.2467266-00	1	118
- .7336700-02	.7357500-00	.1369416+01	.9027135-00	.4245551-00	.2983646+01	1	119
- .1354888+01	.1177277+01	.4594975+01	.1539421+01	.1501074+01	.6289939+01	1	120
- .1594053+01	.1574900+01	.8081494+01	.1605271+01	.1588527+01	.9083322+01	1	121
- .1600554+01	.1588005+01	.1197355+02	.1606697+01	.1588280+01	.1411361+02	1	122
- .1606714+01	.1588303+01	.1635557+02	.1606716+01	.1583305+01	.1871878+02	1	123
.7313220+01	.1300000+02	.2685402+01	.1544979+01	.4093384+01	.1773164+01	1	124
.2729552+01	.2470316+01	.5658398-00	.1373413+01	.8506328-00	.5497228-00	1	125
.3197158+01	.7648972-00	.1221998+01	.9045149-00	.2377312+01	.1519810+01	1	126
- .1449541+01	.3987411+01	.1593229+01	.1564497+01	.5681337+01	.1604800+01	1	127
- .1584497+01	.7453322+01	.1606601+01	.1587792+01	.9325124+01	.1606886+01	1	128
- .1588312+01	.1136535+02	.1606924+01	.1588301+01	.1350542+02	.1606928+01	1	129
- .1588309+01	.1574738+02	.1606929+01	.1588390+01	.1811059+02	.7718685+01	1	130
.1300000+02	.1449648+01	.3289713+01	.4693749+01	.6143336-00	.1454244+01	1	131
- .3071048+01	.4528704-00	.5350460-00	.1453028+01	.1226218+01	.7126393-00	1	132
.1582574-00	.1518837+01	.1365381+01	.1769316+01	.1589387+01	.1543324+01	1	133
.3379261+01	.1605246+01	.1581193+01	.5073147+01	.1608417+01	.1588397+01	1	134
.6845125+01	.1608978+01	.1589654+01	.8716931+01	.1609063+01	.1589850+01	1	135
.1075715+02	.1609074+01	.1589875+01	.1289722+02	.1609075+01	.1589878+01	1	136
.1913918+02	.1609076+01	.1589879+01	.1750239+02	.8131531+01	.1300000+02	1	137
- .6660149-01	.2204292+01	.5301110+01	.8429336-00	.8072703-00	.3683605+01	1	138
- .1335092+01	.5142427-00	.2071688+01	.1538860+01	.1888303+01	.4608924-00	1	139
- .1494888+01	.1884444+01	.1170000+01	.1818777+01	.1884444+01	.8770000+01	1	140
- .1818830+01	.1880034+01	.4453881+01	.1817278+01	.1881111+01	.6228888+01	1	141

AFWL-TR-67-131, Vol IV

-.1616004+01-.1597310+01 .8097064+01-.1616621+01-.1597366+01 .1013788+02 1 142
 -.1616023+01-.1597373+01 .1227795+02-.1616623+01-.1597374+01 .1451991+02 1 143
 -.1616024+01-.1597374+01 .1688312+02 .8517193+01 .1300000+02-.9006423+00 1 144
 .1448014+01-.5877030+01-.1354139+01 .4444135+01-.4261383+01-.1537046+01 1 145
 -.1022604+01-.2649968+01-.1601903+01-.1474924+01-.1038770+01-.1622458+01 1 146
 -.1585640+01 .5716044+00-.1627754+01-.1608454+01 .2181510+01-.1628963+01 1 147
 -.1613178+01 .3875387+01-.1629020+01-.1614476+01 .5647364+01-.1629059+01 1 148
 -.1614027+01 .7519170+01-.1629005+01-.1614651+01 .9559391+01-.1629066+01 1 149
 -.1614034+01 .1169946+02-.1629066+01-.1614654+01 .1394142+02-.1629066+01 1 150
 -.1614654+01 .7630463+02 .8853005+01 .1300000+02-.1253258+01 .7737571+00 1 151
 -.0381408+01-.1516442+01-.5672006+00-.4765733+01-.1601495+01-.1331637+01 1 152
 -.3154579+01-.1627446+01-.1563945+01-.1543453+01-.1635906+01-.1615857+01 1 153
 .5649032+01-.1637996+01-.1628385+01 .1676803+01-.1638464+01-.1628562+01 1 154
 .3370679+01-.1638553+01-.1628471+01 .5142656+01-.1638569+01-.1629041+01 1 155
 .7014461+01-.1638571+01-.1629053+01 .9054683+01-.1638572+01-.1629054+01 1 156
 .1119475+02-.1638572+01-.1629054+01 .1343671+02-.1638572+01-.1629054+01 1 157
 .1579992+02 .9210340+01 .1300000+02-.1469549+01 .1457363+01-.6915838+01 1 158
 -.1598204+01-.1074040+01-.5300556+01-.1637576+01-.1524635+01-.3688593+01 1 159
 -.1644452+01-.1628231+01-.2078447+01-.1655015+01-.1669094+01-.4681047+00 1 160
 -.1655596+01-.1670390+01 .1141792+01-.1655677+01-.1670616+01 .2835667+01 1 161
 -.1655692+01-.1670657+01 .4607043+01-.1655695+01-.1670664+01 .6479449+01 1 162
 -.1655695+01-.1670660+01 .8519070+01-.1655696+01-.1670666+01 .1065974+02 1 163
 -.1655696+01-.1670666+01 .1240170+02-.1655696+01-.1670666+01 .1526491+02 1 164

1030301

DIANE ALUMINUM JA -- 12 FREQUENCIES -- OCTOBER 15, 1965

0.120000+02 .498 +03

1013 .250000+02

-0.230259+01 0.170000+02-0.395445+02-0.365011+02-0.493252+00-0.395445+02 13 1
 -0.365011+02 0.158041+00-0.395445+02-0.365011+02 0.130933+01-0.395445+02 13 2
 -0.365011+02 0.240063+01-0.395445+02-0.365011+02 0.361192+01-0.395445+02 13 3
 -0.365011+02 0.470321+01-0.395445+02-0.365011+02 0.591450+01-0.395445+02 13 4
 -0.365011+02 0.706580+01-0.395445+02-0.365011+02 0.821709+01-0.395445+02 13 5
 -0.365011+02 0.936838+01-0.395445+02-0.365011+02 0.105197+02-0.395445+02 13 6
 -0.365011+02 0.116710+02-0.395445+02-0.365011+02 0.128223+02-0.395445+02 13 7
 -0.365011+02 0.139736+02-0.395445+02-0.365011+02 0.151248+02-0.395445+02 13 8
 -0.365011+02 0.162761+02-0.395445+02-0.365011+02 0.174274+02-0.160944+01 13 9
 0.170000+02-0.110551+02-0.861635+01-0.493252+00-0.110551+02-0.861635+01 13 10
 0.158041+00-0.110551+02-0.861635+01 0.130933+01-0.110551+02-0.861635+01 13 11
 0.240063+01-0.110551+02-0.861635+01 0.361192+01-0.110551+02-0.861635+01 13 12
 0.470321+01-0.110551+02-0.861635+01 0.591450+01-0.110551+02-0.861635+01 13 13
 0.706580+01-0.110551+02-0.861635+01 0.821709+01-0.110551+02-0.861635+01 13 14
 0.936838+01-0.110551+02-0.861635+01 0.105197+02-0.110551+02-0.861635+01 13 15
 0.116710+02-0.110551+02-0.861635+01 0.128223+02-0.110551+02-0.861635+01 13 16
 0.139736+02-0.110551+02-0.861635+01 0.151248+02-0.110551+02-0.861635+01 13 17
 0.162761+02-0.110551+02-0.861635+01 0.174274+02-0.120397+01 0.170000+02 13 18
 -0.189337+01 0.157404+00-0.993252+00-0.189337+01 0.157407+00 0.158041+00 13 19
 -0.189337+01 0.157404+00 0.130933+01-0.189338+01 0.157398+00 0.246063+01 13 20
 -0.189339+01 0.157397+00 0.361192+01-0.189341+01 0.157368+00 0.476321+01 13 21
 -0.189344+01 0.157334+00 0.591450+01-0.189350+01 0.157274+00 0.706580+01 13 22
 -0.189361+01 0.157167+00 0.821709+01-0.189380+01 0.156977+00 0.936838+01 13 23
 -0.189414+01 0.156634+00 0.105197+02-0.189474+01 0.156038+00 0.116710+02 13 24
 -0.189501+01 0.154968+00 0.128223+02-0.189771+01 0.153067+00 0.139736+02 13 25
 -0.190109+01 0.149686+00 0.151248+02-0.190710+01 0.143674+00 0.162761+02 13 26
 -0.191779+01 0.132983+00 0.174274+02-0.916291+00 0.170000+02 0.251757+01 13 27
 0.428976+01-0.993252+00 0.251754+01 0.428973+01 0.158041+00 0.251749+01 13 28

0.428968+01	U.136933+01	U.251740+01	0.428959+01	0.246063+01	0.251724+01	13	29
0.428943+01	U.361142+01	U.251696+01	0.428914+01	0.476321+01	0.251645+01	13	30
0.428864+01	U.591450+01	U.251555+01	0.428773+01	0.706580+01	0.251394+01	13	31
0.428613+01	U.821709+01	U.251104+01	0.428527+01	0.436838+01	0.250601+01	13	32
0.427820+01	U.105197+02	U.249098+01	0.426917+01	U.116710+02	0.248073+01	13	33
0.425312+01	U.128223+02	U.245239+01	U.422458+01	0.139736+02	0.240107+01	13	34
0.417386+01	U.151248+02	U.231164+01	0.408388+01	0.162761+02	0.215241+01	13	35
0.392500+01	U.174274+02	U.693147+00	0.170000+02	0.506284+01	0.661751+01	13	36
-0.493252+00	U.506274+01	U.661736+01	0.158041+00	0.506247+01	0.661709+01	13	37
0.130933+01	U.506199+01	U.661662+01	0.246063+01	0.506115+01	0.661577+01	13	38
0.361142+01	U.505964+01	U.661426+01	0.476321+01	0.505696+01	0.661158+01	13	39
0.591450+01	U.505220+01	U.660062+01	0.706580+01	U.504373+01	0.659835+01	13	40
0.821709+01	U.502666+01	U.658328+01	0.436838+01	0.500180+01	0.655650+01	13	41
0.105197+02	U.449428+01	U.650890+01	U.116710+02	0.486981+01	0.642443+01	13	42
0.128223+02	U.472053+01	U.627515+01	0.139736+02	U.446013+01	0.601475+01	13	43
0.151248+02	U.402217+01	U.557680+01	0.162761+02	0.334615+01	0.490077+01	13	44
0.174274+02	U.510826+00	U.170000+02	0.669312+01	0.806848+01	-0.493252+00	13	45
0.669266+01	U.806601+01	U.158041+00	0.669182+01	0.806718+01	0.130933+01	13	46
0.869034+01	U.806570+01	U.246063+01	0.668771+01	U.806307+01	0.361142+01	13	47
0.666303+01	U.805838+01	U.476321+01	0.667470+01	U.805006+01	0.591450+01	13	48
0.665964+01	U.803525+01	U.706580+01	0.663357+01	0.800892+01	U.821709+01	13	49
U.658078+01	U.746214+01	U.436838+01	0.650374+01	U.787910+01	U.105197+02	13	50
0.635697+01	U.773233+01	U.116710+02	U.610077+01	U.747613+01	U.128223+02	13	51
0.566917+01	U.704453+01	U.139736+02	U.500064+01	0.637594+01	U.151248+02	13	52
0.410046+01	U.547582+01	U.162761+02	U.305153+01	U.442688+01	U.174274+02	13	53
-0.356675+00	U.170000+02	U.781161+01	U.903271+01	-0.993252+00	U.781053+01	13	54
0.903104+01	U.158041+00	U.780863+01	U.902973+01	U.130933+01	U.780524+01	13	55
0.902035+01	U.246063+01	U.779921+01	U.902032+01	U.361142+01	U.778850+01	13	56
0.900900+01	U.476321+01	U.776944+01	U.899055+01	U.591450+01	U.773556+01	13	57
0.895067+01	U.706580+01	U.767538+01	U.889464+01	U.821709+01	U.756671+01	13	58
U.870981+01	U.936634+01	U.738088+01	U.860149+01	U.105197+02	U.705674+01	13	59
0.827705+01	U.116710+02	U.652648+01	U.774759+01	U.128223+02	U.574996+01	13	60
0.697108+01	U.139736+02	U.477249+01	U.599362+01	U.151248+02	U.368866+01	13	61
0.490704+01	U.162761+02	U.255765+01	U.377898+01	U.174274+02	-0.223144+00	13	62
0.170000+02	U.661474+01	U.470210+01	-0.493252+00	U.861777+01	U.970008+01	13	63
0.258041+00	U.861417+01	U.469648+01	U.130933+01	U.860778+01	U.969009+01	13	64
0.246063+01	U.859642+01	U.467072+01	U.361142+01	U.857621+01	U.965852+01	13	65
0.476321+01	U.854024+01	U.462254+01	U.591450+01	U.847647+01	U.955678+01	13	66
0.706580+01	U.836340+01	U.444571+01	U.821709+01	U.816456+01	U.924687+01	13	67
0.936838+01	U.782260+01	U.890492+01	U.105197+02	U.726789+01	U.835023+01	13	68
0.116710+02	U.646724+01	U.754968+01	U.128223+02	U.547464+01	U.655719+01	13	69
0.139736+02	U.438238+01	U.546543+01	U.151248+02	U.325150+01	U.433620+01	13	70
U.162761+02	U.210890+01	U.319874+01	U.174274+02	-U.105361+00	U.170000+02	13	71
0.922005+01	U.101791+02	-0.493252+00	U.922470+01	U.101754+02	U.158041+00	13	72
0.921676+01	U.101698+02	U.130933+01	U.920018+01	U.101592+02	U.246063+01	13	73
0.918937+01	U.101804+02	U.361142+01	U.915594+01	U.101070+02	U.476321+01	13	74
0.909653+01	U.100476+02	U.591450+01	U.899123+01	U.994229+01	U.706580+01	13	75
0.880577+01	U.975684+01	U.821709+01	U.848550+01	U.943658+01	U.936838+01	13	76
0.796063+01	U.891179+01	U.105197+02	U.718970+01	U.814137+01	U.116710+02	13	77
0.621623+01	U.716836+01	U.128223+02	U.513336+01	U.608800+01	U.139736+02	13	78
0.400890+01	U.497170+01	U.151248+02	U.287781+01	U.386667+01	U.162761+02	13	79
0.178148+01	U.264187+01	U.174274+02	0.	U.110000+02	U.912861+01	13	80
0.108095+02	U.176672+01	U.885818+01	U.106592+02	U.391134+01	U.864614+01	13	81
0.104399+02	U.633046+01	U.804194+01	U.985268+01	U.863581+01	U.691848+01	13	82
0.873944+01	U.105922+02	U.552787+01	U.715080+01	U.123093+02	U.380251+01	13	83

0.541120+01	0.140326+02	0.215203+01	0.373631+01	0.158297+02	0.677637+00	13	84
0.236027+01	0.170086+02	0.344232+00	0.120964+01	0.201586+02	0.193164+01	13	85
-0.514440+00	0.225071+02	0.405465+00	0.110000+02	0.107678+02	0.113007+02	13	86
0.255294+01	0.103602+02	0.108540+02	0.462561+01	0.978546+01	0.102489+02	13	87
0.664435+01	0.887308+01	0.944754+01	0.445796+01	0.774492+01	0.849814+01	13	88
0.101708+02	0.605323+01	0.743676+01	0.119596+02	0.535273+01	0.614373+01	13	89
0.134210+02	0.363740+01	0.453302+01	0.158482+02	0.175134+01	0.265441+01	13	90
0.177734+02	0.102034+00	0.875308+00	0.144077+02	0.173683+01	0.717144+00	13	91
0.222401+02	0.810430+00	0.110000+02	0.107741+02	0.112408+02	0.261864+01	13	92
0.104250+02	0.108084+02	0.453377+01	0.942670+01	0.104424+02	0.638673+01	13	93
0.932835+01	0.100015+02	0.824174+01	0.834139+01	0.847697+01	0.100816+02	13	94
0.705540+01	0.752217+01	0.118283+02	0.551833+01	0.600197+01	0.136630+02	13	95
0.364419+01	0.434001+01	0.155743+02	0.165343+01	0.251174+01	0.175432+02	13	96
-0.438152+00	0.414171+00	0.175702+02	0.208205+01	0.158845+01	0.217403+02	13	97
0.122370+01	0.110000+02	0.104727+02	0.111251+02	0.243474+01	0.103570+02	13	98
0.107570+02	0.427577+01	0.101564+02	0.104800+02	0.616727+01	0.455350+01	13	99
0.443107+01	0.001125+01	0.830090+01	0.871519+01	0.981468+01	0.872847+01	13	100
0.705748+01	0.115471+02	0.443003+01	0.514443+01	0.132450+02	0.287710+01	13	101
0.527455+01	0.150070+02	0.841400+00	0.131857+01	0.149407+02	0.107342+01	13	102
-0.698040+00	0.184812+02	0.240127+01	0.234244+01	0.711213+02	0.160444+01	13	103
0.110000+02	0.953771+01	0.108230+02	0.218884+01	0.437204+01	0.104500+02	13	104
0.402104+01	0.701274+01	0.100294+02	0.547000+01	0.020133+01	0.110447+01	13	105
0.747573+01	0.888888+01	0.744444+01	0.437720+01	0.130870+01	0.844444+01	13	106
0.110101+02	0.555170+01	0.402155+01	0.127171+02	0.170000+01	0.214443+01	13	107
0.144700+02	0.160000+00	0.201515+00	0.103030+02	0.104700+01	0.161013+01	13	108
0.184102+02	0.270074+01	0.201533+01	0.205457+02	0.144411+01	0.110000+02	13	109
0.037450+01	0.142593+02	0.100000+01	0.777170+01	0.975782+01	0.308170+01	13	110
0.733062+01	0.711100+01	0.444444+01	0.634444+01	0.700000+01	0.723100+01	13	111
0.501473+01	0.643000+01	0.801300+01	0.305935+01	0.478770+01	0.100012+02	13	112
0.230773+01	0.315705+01	0.122370+02	0.166782+01	0.174746+01	0.140034+02	13	113
-0.124437+00	0.335593+02	0.160800+02	0.104355+01	0.128335+01	0.181800+02	13	114
-0.243442+01	0.226522+01	0.204021+02	0.230259+01	0.110000+02	0.746489+01	13	115
0.464173+01	0.144440+01	0.688248+01	0.910323+01	0.323944+01	0.617743+01	13	116
0.844622+01	0.502012+01	0.543492+01	0.747719+01	0.675618+01	0.472589+01	13	117
0.630416+01	0.847524+01	0.381706+01	0.517973+01	0.102024+02	0.261352+01	13	118
0.363432+01	0.114616+02	0.126672+01	0.203326+01	0.138488+02	0.281246+00	13	119
0.431166+00	0.158149+02	0.163719+01	0.111158+01	0.179327+02	0.223259+01	13	120
-0.207555+01	0.201675+02	0.270805+01	0.110000+02	0.738402+01	0.947679+01	13	121
0.101805+01	0.679233+01	0.410744+01	0.283834+01	0.645534+01	0.869083+01	13	122
0.463410+01	0.543615+01	0.767083+01	0.641086+01	0.507267+01	0.645823+01	13	123
0.816397+01	0.344243+01	0.514314+01	0.988682+01	0.273016+01	0.369022+01	13	124
0.116649+02	0.125042+01	0.210638+01	0.135458+02	0.346491+00	0.483822+00	13	125
0.155064+02	0.153474+01	0.102302+01	0.176245+02	0.149106+01	0.183983+01	13	126
0.140534+02	0.311352+01	0.110000+02	0.821171+01	0.958877+01	0.759898+00	13	127
0.744622+01	0.911737+01	0.252660+01	0.684812+01	0.866268+01	0.429702+01	13	128
0.610449+01	0.775889+01	0.607646+01	0.523751+01	0.659806+01	0.783781+01	13	129
0.412076+01	0.514228+01	0.956704+01	0.271060+01	0.373437+01	0.113633+02	13	130
0.115136+01	0.231574+01	0.132279+02	0.369112+00	0.641066+00	0.151861+02	13	131
-0.142400+01	0.958646+00	0.173062+02	0.176874+01	0.166901+01	0.195197+02	13	132
.352636+01	.100000+02	.952738+01	.100983+02	.543773+00	.878405+01	1	1
.962152+01	.226713+01	.783525+01	.897516+01	.403171+01	.670275+01	1	2
.778757+01	.577693+01	.545345+01	.646332+01	.750780+01	.407180+01	1	3
.584934+01	.922178+01	.244316+01	.341863+01	.110086+02	.745996+00	1	4
.188711+01	.128562+02	.756452+00	.127304+00	.147722+02	.156804+01	1	5
-.123196+01	.168246+02	.391202+01	.100000+02	.918972+01	.985121+01	1	6

AFWL-TR-67-131, Vol IV

.1837170-00	.8746120+01	.9426367+01	.1932700+01	.7893279+01	.8534515+01	1	7
.3689338+01	.6683950+01	.7315647+01	.5426444+01	.5140051+01	.5868344+01	1	8
.7141098+01	.3372153+01	.4260909+01	.8822633+01	.1524794+01	.2530433+01	1	9
.1055059+02	.1583944-00	.7090946-00	.1233358+02	.1261935+01	.7397432-00	1	10
.1420757+02	.1676086+01	.1585598+01	.1624814+02	.4248495+01	.1000000+02	1	11
.8491557+01	.9579191+01	.1397524-00	.8237979+01	.9165618+01	.1610352+01	1	12
.7578153+01	.8147335+01	.3350492+01	.6198561+01	.6672679+01	.5057992+01	1	13
.4328169+01	.5000998+01	.6724924+01	.2495442+01	.3292869+01	.8355292+01	1	14
.6691241-00	.1552904+01	.1005549+02	.7105209-00	.9301331-01	.1183055+02	1	15
-.1426769+01	.1278362+01	.1370312+02	.1727698+01	.1716051+01	.1574347+02	1	16
.4805170+01	.1000000+02	.7422224+01	.9104226+01	.5212119-00	.7062274+01	1	17
.8609054+01	.1212111+01	.6237838+01	.7328236+01	.2917552+01	.4911968+01	1	18
.5615009+01	.4579276+01	.3297175+01	.3925406+01	.6209216+01	.1591562+01	1	19
.2254870+01	.7825292+01	.3180283-01	.5938050-00	.4522003+01	.1073846+01	1	20
-.8099806+00	.1129602+02	.1621174+01	.1556233+01	.1317017+02	.1772749+01	1	21
-.1740031+01	.1522208+02	.5010635+01	.1000000+02	.6185145+01	.8338615+01	1	22
-.1007814+01	.5841655-00	.7479605+01	.6885306-00	.2144719+01	.6049353+01	1	23
.2350191+01	.2947264+01	.4379425+01	.3985414+01	.1512903+01	.2747360+01	1	24
.5608825+01	.2161900-00	.1425461+01	.7228468+01	.7596437-00	.3391993-00	1	25
.6951111+01	.1365612+01	.5575562-00	.1077182+02	.1598306+01	.1221464+01	1	26
.1264279+02	.1643522+01	.1551470+01	.1476083+02	.5416100+01	.1000000+02	1	27
.5519152+01	.7412880+01	.1526498+01	.4478410+01	.6349076+01	.1245860+00	1	28
.3309278+01	.5124872+01	.1771014+01	.1979714+01	.3972468+01	.3418297+01	1	29
.7691705-00	.2929300+01	.5076016+01	.2891430-00	.1743856+01	.6738252+01	1	30
-.1078019+01	.3779824-00	.8462575+01	.1482080+01	.8575797-00	.1024410+02	1	31
-.1602892+01	.1464604+01	.1211844+02	.1632457+01	.1610841+01	.1415907+02	1	32
.655108 +01	.4.	.24476 +01	.347242+01	.234174	.865025		
.19149 +01	.185275 +01	-.474324	.414307	.346653+01	-.128128+01		
-.84636	.507721 +01						

DIANE/SCAT AL=108 TEMP(11-7000, EV) 10 FREQ. C1/WBL 10-26-67

.1000000+02	.9430000+03					1	0
.3013.	.2300000+02					1	1
.0000000	.1300000+02	.1195794+02	.1358466+02	.1777143+01	.1174710+02	1	2
.1366326+02	.3919002+01	.1128722+02	.1313726+02	.6338482+01	.1023696+02	1	3
.1174908+02	.6643357+01	.8563120+01	.9919029+01	.1059967+02	.6477006+01	1	4
.7918035+01	.1231677+02	.4301137+01	.6016570+01	.1404002+02	.2404366+01	1	5
.4255232+01	.1583711+02	.1037822+01	.2771879+01	.1781574+02	.2212078-00	1	6
.1498087+01	.2016558+02	.1846017+01	.2732148-00	.2251447+02	.2973384+01	1	7
-.2190714+01	.2479681+02	.3382848+01	.3261868+01	.2717293+02	.4054651-00	1	8
.1300000+02	.1307766+02	.1348404+02	.2608712+01	.1272140+02	.1315375+02	1	9
.4644635+01	.1185384+02	.1246477+02	.6657301+01	.1045280+02	.1117208+02	1	10
.8467082+01	.8817092+01	.9689596+01	.1018454+02	.7289053+01	.8230070+01	1	11
.1196687+02	.5675296+01	.6653355+01	.1392824+02	.3857871+01	.4964107+01	1	12
.1585555+02	.1911784+01	.3041898+01	.1778089+02	.3196798+01	.1164591+01	1	13
.1991512+02	.1658319+01	.5440367-00	.2225353+02	.2707375+01	.2213462+01	1	14
.2458407+02	.3026144+01	.2970067+01	.2696007+02	.8109302-00	.1300000+02	1	15
.1254033+02	.1318852+02	.2727391+01	.1233203+02	.1268300+02	.4548719+01	1	16
.1168822+02	.1220257+02	.6397773+01	.1063094+02	.1163549+02	.8247581+01	1	17
.9142246+01	.1023063+02	.1008903+02	.7532120+01	.8478715+01	.1183569+02	1	18
.5894359+01	.6646185+01	.1367044+02	.3962561+01	.4743305+01	.1560681+02	1	19
.1799787+01	.2716690+01	.1755066+02	.3553870-00	.5796457-00	.1960568+02	1	20
-.2043833+01	.1445498+01	.2174780+02	.2856938+01	.2736443+01	.2399001+02	1	21
-.3073784+01	.3059123+01	.2635325+02	.1223775+01	.1300000+02	.1149990+02	1	22
.1283535+02	.2557746+01	.1142088+02	.1244391+02	.4349987+01	.1113270+02	1	23

.1215277+02	.6173363+01	.1029262+02	.1118308+02	.8018731+01	.8855043+01	1	23
.9540496+01	.9822137+01	.7040454+01	.7543500+01	.1155452+02	.5028889+01	1	24
.5441888+01	.1329247+02	.3001842+01	.3448607+01	.1507451+02	.9726370+00	1	25
.1462758+01	.1694818+02	.1005719+01	.5715810+00	.1898870+02	.2418450+01	1	26
.2267464+01	.2112681+02	.2981052+01	.2477309+01	.2337078+02	.3101163+01	1	27
.3090367+01	.2573406+02	.1609438+01	.1300000+02	.1035233+02	.1219782+02	1	28
.2348148+01	.1011088+02	.1145614+02	.4064441+01	.9623814+01	.1129851+02	1	29
.5868794+01	.8672425+01	.9901498+01	.7681191+01	.7263400+01	.9007959+01	1	30
.9384661+01	.5612365+01	.6121474+01	.1102353+02	.3801644+01	.4214512+01	1	31
.1272454+02	.1914285+01	.2245031+01	.1449808+02	.8081138+02	.3367015+00	1	32
.1637048+02	.1707671+01	.1445601+01	.1841769+02	.2661687+01	.2554718+01	1	33
.2060314+02	.2839816+01	.2742484+01	.2248754+02	.2029816+01	.2811204+01	1	34
.2543254+02	.1445910+01	.1300300+02	.9622778+01	.1158664+02	.2082951+01	1	35
.9073923+01	.1106004+02	.3751794+01	.8249064+01	.1022562+02	.5532230+01	1	36
.7070414+01	.6819016+01	.7239124+01	.5646446+01	.6863161+01	.8901340+01	1	37
.4252148+01	.5166023+01	.1052467+02	.2855795+01	.3505528+01	.1224442+02	1	38
.1554918+01	.2040471+01	.1409492+02	.4071418+01	.5800058+00	.1608744+02	1	39
.1556618+01	.1042964+01	.1819545+02	.2409115+01	.2202384+01	.2640954+02	1	40
.2574091+01	.2528874+01	.2276274+02	.2544941+01	.2568091+01	.2517510+02	1	41
.2302583+01	.1300000+02	.9244765+01	.1181135+02	.1699857+01	.8414774+01	1	42
.1118850+02	.3376640+01	.7604240+01	.1002824+02	.5075177+01	.6652053+01	1	43
.8632444+01	.6763307+01	.5736277+01	.7173874+01	.8484427+01	.4568282+01	1	44
.5752167+01	.1021134+02	.3054530+01	.4077267+01	.1198454+02	.1489258+01	1	45
.2344694+01	.1385635+02	.1736517+00	.6454718+00	.1542242+02	.1545218+01	1	46
.4775240+00	.1744022+02	.2214532+01	.2028122+01	.2017524+02	.2347735+01	1	47
.2311216+01	.2248151+02	.2294470+01	.2278186+01	.2493284+02	.2708050+01	1	48
.1300000+02	.9811734+01	.1235528+02	.1255211+01	.9084348+01	.1186454+02	1	49
.2924224+01	.8481752+01	.1065324+02	.4642493+01	.7476010+01	.9115460+01	1	50
.6446585+01	.6051546+01	.7368356+01	.8183425+01	.4496820+01	.5594187+01	1	51
.9848156+01	.2948815+01	.3934326+01	.1164145+02	.1358307+01	.2269295+01	1	52
.1355445+02	.2844158+00	.5886757+00	.1551600+02	.1525058+01	.9459983+00	1	53
.1763843+02	.1984986+01	.1820266+01	.1986235+02	.2053304+01	.2022278+01	1	54
.2217665+02	.2006411+01	.1941406+01	.2461438+02	.3113515+01	.1300000+02	1	55
.1076381+02	.1234404+02	.9242303+00	.1009320+02	.1163902+02	.2610191+01	1	56
.9200564+01	.1016484+02	.4374608+01	.7545836+01	.8603696+01	.6124216+01	1	57
.5800210+01	.7072053+01	.7863422+01	.4286628+01	.5407723+01	.9582029+01	1	58
.2786349+01	.3819370+01	.1137364+02	.1178624+01	.2367638+01	.1323625+02	1	59
.3618844+01	.6918895+00	.1514364+02	.1419571+01	.9293565+00	.1731564+02	1	60
.1767347+01	.1663514+01	.1452717+02	.1014589+01	.1791740+01	.2182110+02	1	61
.1817872+01	.1802724+01	.2414712+02	.3526360+01	.1300000+02	.1050625+02	1	62
.1157844+02	.5520428+00	.1003086+02	.1089578+02	.3275053+01	.8691254+01	1	63
.9400491+01	.4040263+01	.6465556+01	.7936297+01	.5785362+01	.5592256+01	1	64
.6554844+01	.7522168+01	.4162137+01	.5117249+01	.9235037+01	.2503670+01	1	65
.3467871+01	.1101864+02	.7547066+00	.1827897+01	.1286424+02	.7528578+00	1	66
.1343359+00	.1477986+02	.1566881+01	.1231750+01	.1683211+02	.1776311+01	1	67
.1718454+01	.1847347+02	.1804561+01	.1744741+01	.2121615+02	.1816243+01	1	68
.1803158+01	.4357444+02	.3912023+01	.1300000+02	.9410314+01	.1654997+02	1	69
.1918958+00	.9215712+01	.9747089+01	.1941265+01	.8092135+01	.8671706+01	1	70
.3697376+01	.6744710+01	.7342369+01	.5433845+01	.5236295+01	.5941900+01	1	71
.7154305+01	.3446578+01	.4306362+01	.8835517+01	.1566797+01	.2532580+01	1	72
.1056148+02	.1476621+00	.7441965+00	.1234176+02	.1259506+01	.7399426+00	1	73
.1421518+02	.1675283+01	.1588701+01	.1625562+02	.1783468+01	.1777048+01	1	74
.1839572+02	.1812956+01	.1801078+01	.2063768+02	.1817255+01	.1803673+01	1	75
.2388889+02	.4248493+01	.1300000+02	.8683042+01	.9798623+01	.1311263+00	1	76
.8384492+01	.9269933+01	.1618225+01	.7651929+01	.8287793+01	.3357999+01	1	77

.6235903+01	.6703000+01	.5065404+01	.4377461+01	.5018425+01	.6736960+01	1	78
.2489246+01	.3300132+01	.8366436+01	.6783576+00	.1562195+01	.1006575+02	1	79
-.7030474-00	-.4024018-01	.1183671+02	.1424331+01	.1280055+01	.1371070+02	1	80
-.1726592+01	-.1719279+01	.1575095+02	.1805309+01	.1793120+01	.1789103+02	1	81
-.1816494+01	.1001999+01	.2013314+02	.1816161+01	.1801392+01	.2249793+02	1	82
.4605170+01	.1500000+02	.7532796+01	.9222736+01	.5134078+00	.7140833+01	1	83
.8679928+01	.219619+01	.6286433+01	.7366644+01	.2925017+01	.4942032+01	1	84
.5635339+01	.4586743+01	.3309769+01	.3933313+01	.6219542+01	.1605430+01	1	85
.2266039+01	.7836175+01	.5043915+01	.6050262+00	.9531629+01	.1066558+01	1	86
-.8064726+00	.1130417+02	.1618835+01	.1556490+01	.1317774+02	.1772663+01	1	87
-.1741555+01	.1522956+02	.1757528+01	.1734277+01	.1741209+02	.1711460+01	1	88
-.1693035+01	.1970405+02	.1665538+01	.1648582+01	.2211872+02	.5010635+01	1	89
.1300000+02	.6255878+01	.8403224+01	.1000326+01	.5539733+01	.7539415+01	1	90
.6959980+00	.4399908+01	.6076127+01	.2363647+01	.2943110+01	.4396089+01	1	91
.3994868+01	.1542694+01	.2822273+01	.5617085+01	.2339426+00	.1440827+01	1	92
.7238616+01	.7479826+00	.3562656+00	.8960434+01	.1364988+01	.5525871+00	1	93
.1678009+02	.1600995+01	.1223719+01	.1270042+02	.1643767+01	.1651398+01	1	94
.1476832+02	.1649624+01	.1621944+01	.1691405+02	.1650407+01	.1631165+01	1	95
.1915673+02	.1650927+01	.1632169+01	.2152002+02	.5416100+01	.1300000+02	1	96
.5578201+01	.7472406+01	.1519030+01	.4521476+01	.6393225+01	.1320505+00	1	97
.3338807+01	.5138164+01	.1778328+01	.2010482+01	.3975745+01	.3426302+01	1	98
.6002657+00	.2944943+01	.5089321+01	.2865842+00	.1761902+01	.671351+01	1	99
-.1073492+01	.3901977+00	.8471712+01	.1477113+01	.6483383+00	.1022252+02	1	100
-.1602970+01	.1462647+01	.1212605+02	.1632549+01	.1608298+01	.1416558+02	1	101
-.1647983+01	.1628200+01	.1630666+02	.1650027+01	.1629589+01	.1854862+02	1	102
-.1650096+01	.1629661+01	.2091183+02	.6214604+01	.1300000+02	.5610716+01	1	103
.6912521+01	.2606250+01	.4791142+01	.5869259+01	.9296288+00	.3334975+01	1	104
.4416614+01	.7279821+00	.1628244+01	.2913151+01	.2362922+01	.1828367+00	1	105
.1347676+01	.3979585+01	.7848138+00	.9746181+01	.5590650+01	.1365307+01	1	106
-.1173664+01	.7284775+01	.1594617+01	.1558414+01	.9056798+01	.1628421+01	1	107
-.1610365+01	.1092661+02	.1631536+01	.1615956+01	.1296863+02	.1631929+01	1	108
-.1616669+01	.1510890+02	.1631977+01	.1616754+01	.1735086+02	.1631982+01	1	109
-.1616763+01	.1971407+02	.6551080+01	.1300000+02	.4949486+01	.6297602+01	1	110
-.3058579+01	.3924112+01	.5045675+01	.1396320+01	.2456130+01	.3490699+01	1	111
.2416438+00	.8428281+00	.1911445+01	.1862252+01	.4881298+00	.4176304+00	1	112
.3475797+01	.1283285+01	.6887599+00	.5086134+01	.1569518+01	.1490998+01	1	113
.6780103+01	.1619428+01	.1596587+01	.8552096+01	.1625335+01	.1609945+01	1	114
.1042390+02	.1626093+01	.1611010+01	.1246413+02	.1626194+01	.1612056+01	1	115
.1460419+02	.1626206+01	.1612086+01	.1684615+02	.1626208+01	.1612089+01	1	116
.1920936+02	.6907753+01	.1300000+02	.3482403+01	.5479861+01	.3559797+01	1	117
.2284387+01	.4650420+01	.1915464+01	.8638585+00	.2532921+01	.2886132+00	1	118
-.4598926+00	.9431654+00	.1328367+01	.1233278+01	.4736508+00	.2941038+01	1	119
-.1536111+01	.1336913+01	.4551175+01	.1613760+01	.1572993+01	.6245101+01	1	120
-.1626634+01	.1609502+01	.8017085+01	.1628852+01	.1615442+01	.9888893+01	1	121
-.1629207+01	.1616373+01	.1192911+02	.1629242+01	.1616480+01	.1406918+02	1	122
-.1629246+01	.1616493+01	.1631114+02	.1629246+01	.1616494+01	.1867435+02	1	123
.7313220+01	.1300000+02	.1856909+01	.4458880+01	.4148703+01	.5671446+00	1	124
.3630172+01	.2507219+01	.6093053+00	.1476474+01	.8908083+00	.1278417+01	1	125
-.2645216+01	.7206181+00	.1531172+01	.1116260+01	.2332942+01	.1611134+01	1	126
-.1525536+01	.3942999+01	.1632155+01	.1610721+01	.5636907+01	.1636276+01	1	127
-.1625090+01	.7408888+01	.1637062+01	.1627587+01	.9280695+01	.1637189+01	1	128
-.1627962+01	.1132092+02	.1637206+01	.1628035+01	.1346098+02	.1637208+01	1	129
-.1628041+01	.1970294+02	.1637208+01	.1628042+01	.1806315+02	.7718685+01	1	130
.1300000+02	.4938759+00	.3487134+01	.4727138+01	.6315942+00	.1977021+01	1	131
-.3112763+01	.1264089+01	.4949023+00	.1498269+01	.1530327+01	.8122249+00	1	132

.1126147+00-	.1613584+01-	.1449221+01	.1724790+01-	.1638131+01-	.1606485+01	1	133
.3334611+01-	.1644244+01-	.1635400+01	.5028711+01-	.1645442+01-	.1641119+01	1	134
.6800691+01-	.1645665+01-	.1642028+01	.8672497+01-	.1645701+01-	.1642172+01	1	135
.1071272+02-	.1645706+01-	.1642191+01	.1285278+02-	.1645707+01-	.1642193+01	1	136
.1504475+02-	.1645707+01-	.1642193+01	.1745795+02	.6131531+01	.1300000+02	1	137
.0224633+00	.1647494+01-	.5342914+01-	.1360177+01	.2308724+00-	.3730753+01	1	138
.1564692+01-	.9640102+00-	.2117172+01-	.1630516+01-	.1536394+01-	.5051186+00	1	139
.1644858+01-	.1651544+01	.1105547+01-	.1654604+01-	.1667972+01	.2715549+01	1	140
.1655745+01-	.1670077+01	.4409445+01-	.1655899+01-	.1671090+01	.6181424+01	1	141
.1655927+01-	.1671162+01	.6053230+01-	.1655932+01-	.1671173+01	.1009345+02	1	142
.1655932+01-	.1671174+01	.1223352+02-	.1655932+01-	.1671175+01	.1647548+02	1	143
.1655932+01-	.1671175+01	.1633669+02	.8517193+01	.1300000+02-	.1139984+01	1	144
.9756247+00-	.5919669+01-	.1486517+01-	.4238484+00-	.4308613+01-	.1606031+01	1	145
.1336203+01-	.2695462+01-	.1642402+01-	.1618121+01-	.1083562+01-	.1653135+01	1	146
.1663576+01	.5270667+00-	.1655472+01-	.1670107+01	.2137058+01-	.1655844+01	1	147
.1671131+01	.3630452+01-	.1655917+01-	.1671319+01	.5602930+01-	.1655930+01	1	148
.1671352+01	.7474736+01-	.1655932+01-	.1671357+01	.9514957+01-	.1655932+01	1	149
.1671358+01	.1165502+02-	.1655932+01-	.1671358+01	.1344678+02-	.1655932+01	1	150
.1671358+01	.1626019+02	.6853665+01	.1300000+02-	.1328304+01	.3564635+00	1	151
.6424510+01-	.1553601+01-	.8945925+00-	.4812993+01-	.1626865+01-	.1510764+01	1	152
.3147502+01-	.1648750+01-	.1647892+01-	.1588243+01-	.1654363+01-	.1667712+01	1	153
.2236576+01-	.1655646+01-	.1670847+01	.1632351+01-	.1655887+01-	.1671355+01	1	154
.3326244+01-	.1655925+01-	.1671450+01	.5048222+01-	.1655931+01-	.1671466+01	1	155
.6470024+01-	.1655932+01-	.1671464+01	.9010249+01-	.1655932+01-	.1671469+01	1	156
.1115032+02-	.1655932+01-	.1671464+01	.1334228+02-	.1655932+01-	.1671464+01	1	157
.1575549+02	.0000000	.0000000	.0000000	.0000000	.0000000	1	158

DIANE/SCAT BE(HI/LO)-2 10 FREQ. TEMP(1.-2250.) CI/JP 12-9-66 000000

.1000000+02	.8610000+03						
1004.	.2100000+02						
.6000000	.1300000+02	.1120797+02	.1225239+02	.1817634+01	.1110633+02	1	1
.1218590+02	.3993325+01	.1044825+02	.1194585+02	.6547831+01	.1052811+02	1	2
.1165585+02	.9155444+01	.9549431+01	.1060220+02	.1145886+02	.7943660+01	1	3
.8855362+01	.1334456+02	.5479154+01	.6447883+01	.1512141+02	.4015629+01	1	4
.5201925+01	.1691895+02	.2354369+01	.3561411+01	.1885130+02	.9470235+00	1	5
.2228171+01	.2113898+02	.6417287+00	.6746542+00	.2356899+02	.1886346+01	1	6
.1171910+01	.2586707+02	.2531033+01	.2200430+01	.2825964+02	.4054651+00	1	7
.1300000+02	.1268564+02	.1303414+02	.3304670+01	.1241557+02	.1273844+02	1	8
.5381821+01	.1163673+02	.1233191+02	.7561255+01	.1074342+02	.1163475+02	1	9
.9440022+01	.9380473+04	.1031799+02	.1122901+02	.7981574+01	.8902133+01	1	10
.1245905+02	.6484164+01	.7424438+01	.1440002+02	.4706212+01	.5752500+01	1	11
.1640217+02	.2671414+01	.3856456+01	.1885055+02	.5484357+00	.1780483+01	1	12
.2040504+02	.1254626+01-	.2827348+00	.2304705+02-	.2158867+01-	.1849065+01	1	13
.2520425+02	.2374245+01-	.2341553+01	.2765248+02	.6109302+00	.1300800+02	1	14
.1251767+02	.1315402+02	.3603674+01	.1239196+02	.1278393+02	.5438854+01	1	15
.1144456+02	.1257183+02	.7362686+01	.1045132+02	.1187088+02	.9220243+01	1	16
.9475225+01	.1040493+02	.1108704+02	.7647003+01	.8520614+01	.1285512+02	1	17
.9647541+01	.6525721+01	.1460113+02	.3617277+01	.4598206+01	.1638455+02	1	18
.1673675+01	.2650190+01	.1825844+02-	.3755846+00	.5765313+00	.2029900+02	1	19
.1715996+01-	.1284627+01	.2243411+02-	.2241056+01-	.2213466+01	.2468108+02	1	20
.2344278+01-	.2367664+01	.2704424+02	.1223775+01	.1300000+02	.1142509+02	1	21
.1288465+02	.3418578+01	.1126845+02	.1256276+02	.5272824+01	.1074543+02	1	22
.1198148+02	.7122534+01	.9781961+01	.1076499+02	.8951153+01	.8290559+01	1	23
.8993869+01	.1065715+02	.6578982+01	.7128549+01	.1229403+02	.4730859+01	1	24
.8242396+01	.1399425+02	.2808336+01	.3365830+01	.1576749+02	.8670888+00	1	25

.1437230+01	.1763952+02	-.9129302-00	-.5093937-00	.1967978+02	-.1994287+01	1	26
-.1905233+01	.2181985+02	-.2362246+01	-.2341091+01	.2406181+02	-.2420126+01	1	27
-.2401655+01	.2642502+02	.1609438+01	.1300000+02	.1009802+02	.1227335+02	1	28
.3142451+01	.4586454+01	.1167571+02	.4965120+01	.8755885+01	.1078577+02	1	29
.6739154+01	.7556899+01	.9403846+01	.8449571+01	.6134108+01	.7676116+01	1	30
.1010089+02	.4586882+01	.5877897+01	.1172067+02	.2918190+01	.4049461+01	1	31
.1341676+02	.1195363+01	.2211047+01	.1518917+02	.4370335-00	.3592745-00	1	32
.1706105+02	.1704313+01	-.1345231+01	.1910129+02	-.2282667+01	-.2202374+01	1	33
.2124139+02	.2409045+01	-.2384154+01	.2348366+02	-.2421131+01	-.2402032+01	1	34
.2585018+02	.1945910+01	.1300000+02	.8982691+01	.1154172+02	.2086789+01	1	35
.6123342+01	.1062299+02	.4570132+01	.7091598+01	.9556583+01	.6290296+01	1	36
.5788412+01	.8095816+01	.7963156+01	.4335203+01	.6439996+01	.9600912+01	1	37
.2802656+01	.4747963+01	.1121704+02	.1206059+01	.2992756+01	.1291236+02	1	38
-.2689078-00	.1217446+01	.1466508+02	.1368610+01	.4612911-00	.1656004+02	1	39
-.2013568+01	.1573060+01	.1862323+02	-.2160202+01	.1902212+01	.2788788+02	1	40
-.2061064+01	.1983516+01	.2332230+02	-.2025011+01	.2000063+01	.2574097+02	1	41
.2302505+01	.1300000+02	.8012773+01	.1089769+02	.2422371+01	.7003243+01	1	42
.4888483+01	.4088954+01	.5848217+01	.8588297+01	.5779189+01	.4498615+01	1	43
.7111144+01	.7436405+01	.3100003+01	.5596709+01	.9070758+01	.1869371+01	1	44
.4174138+01	.1069575+02	.1017652+01	.3051035+01	.1243880+02	.2634495-00	1	45
.2175162+01	.1435544+02	.7806009-00	.8724764-00	.1637442+02	.1620614+01	1	46
-.7165070-00	.1846501+02	-.1898668+01	.1610816+01	.2084876+02	.1427719+01	1	47
-.1744794+01	.2302719+02	-.1747106+01	.1720694+01	.2548419+02	.2708050+01	1	48
.1300000+02	.7368834+01	.1003923+02	.1858524+01	.6422863+01	.9460926+01	1	49
.3570508+01	.5363211+01	.8485695+01	.5234721+01	.4565944+01	.7440086+01	1	50
.6917144+01	.3786768+01	.6437063+01	.8682122+01	.2635593+01	.5188409+01	1	51
.1042436+02	.1365566+01	.3727074+01	.1218825+02	.3419047-00	.2378167+01	1	52
.1405045+02	.7075832-00	.1017491+01	.1604569+02	.1450052+01	.5547144-00	1	53
.1813685+02	.1691659+01	.1480665+01	.2028541+02	.1727797+01	.1687253+01	1	54
.2252842+02	.1731848+01	.1712302+01	.2484174+02	.3113515+01	.1300000+02	1	55
.8310048+01	.1061430+02	.1418869+01	.7504452+01	.1015095+02	.3105112+01	1	56
.6621957+01	.9062373+01	.4868752+01	.5499829+01	.7763172+01	.6624582+01	1	57
.4267336+01	.6454094+01	.8347537+01	.2927645+01	.5148838+01	.1007386+02	1	58
.1347382+01	.3614620+01	.1183302+02	-.2582419-00	.1907479+01	.1362240+02	1	59
-.1245434+01	.1200727+00	.1549749+02	.1610924+01	.1195359+01	.1753824+02	1	60
-.1694535+01	.1440000+01	.1967838+02	.1723844+01	.1788478+01	.2142035+02	1	61
-.1772105+01	.1713101+01	.2428356+02	.3526800+01	.1300000+02	.9280063+01	1	62
.1047830+01	.2225399+00	.8007050+01	.1000000+02	.2732912+01	.7322912+01	1	63
.0207800+01	.9497060+01	.5000000+01	.7478100+01	.6230060+01	.5453700+01	1	64
.5720000+01	.7202530+01	.2097000+01	.4100000+01	.0530010+01	.2561001-00	1	65
.2452302+01	.1123415+02	-.0270254-00	.7220013-00	.1300000+02	.1333415+01	1	66
-.7652350-00	.1407801+02	.1606200+01	.1551015+01	.1691405+02	.1701602+01	1	67
-.1692639+01	.1905912+02	.1706514+01	.1694670+01	.2130108+02	.1706781+01	1	68
-.1700206+01	.2368429+02	.3912023+01	.1300000+02	.9115052+01	.1024072+02	1	69
.6065458-00	.8389852+01	.9364286+01	.2337080+01	.7125858+01	.8037130+01	1	70
.4063329+01	.5366178+01	.6412067+01	.5725783+01	.3478264+01	.4731306+01	1	71
.7349453+01	.1702169+01	.3071482+01	.8961991+01	.1717367-00	.1391040+01	1	72
.1065643+02	.8067268-00	.2198786-00	.1242851+02	.1487678+01	.1348741+01	1	73
.1430033+02	.1655019+01	.1645107+01	.1634056+02	.1668715+01	.1668839+01	1	74
.1848063+02	.1671546+01	.1672592+01	.2072259+02	.1671699+01	.1672808+01	1	75
.2308580+02	.4248495+01	.1300000+02	.7815535+01	.9523183+01	.2202117-00	1	76
.7054317+01	.8482553+01	.1928862+01	.5740937+01	.6910580+01	.3595562+01	1	77
.4182816+01	.5264006+01	.5231267+01	.2533360+01	.3652411+01	.6896983+01	1	78
.9044832-00	.2006058+01	.8457749+01	.5435062-00	.3796611-00	.1015181+02	1	79
-.1365640+01	.1007297+01	.1192382+02	.1611417+01	.1568466+01	.1379563+02	1	80

-.1644338+01-.1641033+01 .1583585+02-.1647292+01-.1647920+01 .1797592+02	1	81
-.1647550+01-.1648612+01 .2021788+02-.1647574+01-.1648682+01 .2258109+02	1	82
.4605170+01 .1300000+02 .6301667+01 .6590840+01-.2599055-00 .5373403+01	1	83
.7456636+01 .1431346+01 .3442837+01 .5841840+01 .3072415+01 .2483575+01	1	84
.4275959+01 .4699180+01 .9283376-00 .2678337+01 .6312595+01-.4333193-00	1	85
.1100908+01 .7922866+01-.1259205+01-.4853311-00 .9616814+01-.1563802+01	1	86
-.1409663+01 .1138881+02-.1630126+01-.1611795+01 .1326062+02-.1639158+01	1	87
-.1636561+01 .1530064+02-.1640254+01-.1634525+01 .1744090+02-.1639974+01	1	88
-.1634261+01 .1968286+02-.1634988+01-.1634303+01 .2204608+02 .5010635+01	1	89
.1300000+02 .4980758+01 .7741457+01-.7930314-00 .3685565+01 .6374490+01	1	90
.6395440-00 .2217061+01 .4743556+01 .2469221+01 .7294957-00 .3227499+01	1	91
.4092137+01-.5534607-00 .1630960+01 .5704644+01-.1261025+01 .9134291-01	1	92
.7314720+01-.1538346+01-.1121541+01 .9008631+01-.1620594+01-.1558103+01	1	93
.1078001+02-.1638411+01-.1630307+01 .1265242+02-.1642050+01-.1640564+01	1	94
.1464264+02-.1642435+01-.1641638+01 .1683271+02-.1642812+01-.1643106+01	1	95
.1907467+02-.1642818+01-.1643123+01 .2143788+02 .5416100+01 .1300000+02	1	96
.2657163+01 .5663006+01-.1383448+01 .1238225+01 .4240272+01 .2394243-00	1	97
-.1244268+00 .3125824+01 .1862465+01-.1045002+01 .1591037+01 .3484431+01	1	98
-.1457778+01 .8543853-01 .5046552+01-.1544457+01-.1285696+01 .6706544+01	1	99
-.1642563+01-.1616498+01 .8400438+01-.1653800+01-.1667178+01 .1017242+02	1	100
-.1656040+01-.1672810+01-.1204422+02-.1656349+01-.1673525+01 .1408444+02	1	101
-.1656344+01-.1673614+01 .1622451+02-.1656399+01-.1673630+01 .1846647+02	1	102
-.1656400+01-.1673631+01 .2082768+02 .5028946+01 .1300000+02 .1921166+01	1	103
.4427441+01-.1993847+01 .4404442-00 .3461669+01-.3764745-00-.6793498-00	1	104
.1945088+01 .1244644+01-.1310023+01 .4225815-00 .2865423+01-.1551595+01	1	105
-.8848615-00 .4477334+01-.1627336+01-.1516319+01 .6087288+01-.1649985+01	1	106
-.1653813+01 .7781172+01-.1655357+01-.1671175+01 .9553144+01-.1656235+01	1	107
-.1673275+01 .1142445+02-.1656378+01-.1673585+01 .1346518+02-.1656397+01	1	108
-.1673626+01 .1560524+02-.1656400+01-.1673630+01 .1784720+02-.1656400+01	1	109
-.1673631+01 .2021041+02 .6214608+01 .1300000+02 .1217859+01 .4219604+01	1	110
-.2567930+01-.1175628+01 .2755434+01-.4356738-00-.1046238+01 .1211116+01	1	111
.6747444-00-.1454035+01-.2654074-00 .2287060+01-.1549041+01-.1281994+01	1	112
.3848675+01-.1641324+01-.1611441+01 .5508800+01-.1653408+01-.1655828+01	1	113
.7202680+01-.1655938+01-.1672502+01 .6974655+01-.1656322+01-.1673466+01	1	114
.1084646+02-.1656340+01-.1673610+01 .1288660+02-.1656394+01-.1673629+01	1	115
.1502675+02-.1656400+01-.1673631+01 .1726871+02-.1656400+01-.1673631+01	1	116
.1463142+02 .6551060+01 .1300000+02 .6107720-00 .3590575+01-.3070379+01	1	117
-.5008048-00 .2106207+01-.1434723+01-.1270268+01 .5671553-00 .1705083-00	1	118
-.1537823+01-.7808458-00 .1702422+01-.1623298+01-.1484073+01 .3394183+01	1	119
-.1648168+01-.1648544+01 .5004045+01-.1654804+01-.1669968+01 .6697972+01	1	120
-.1656152+01-.1673086+01 .6464447+01-.1656360+01-.1673547+01 .1634175+01	1	121
-.1656345+01-.1673620+01 .1238147+02-.1656399+01-.1673630+01 .1452204+02	1	122
-.1656400+01-.1673631+01 .1676400+02-.1656400+01-.1673631+01 .1912721+02	1	123
.6407735+01 .1300000+02 .1144334-01 .2414892+01-.3603923+01-.9564424-00	1	124
.1415471+01-.1974245+01-.1425373+01-.8322388-01-.3643437-00-.1588543+01	1	125
-.1189783+01 .1247458+01-.1638246+01-.1542237+01 .2854182+01-.1652206+01	1	126
-.1662263+01 .4469085+01-.1655753+01-.1672060+01 .6162960+01-.1656275+01	1	127
-.1673364+01 .7934435+01-.1656360+01-.1673590+01 .9806740+01-.1656397+01	1	128
-.1673626+01 .1184696+02-.1656344+01-.1673630+01 .1398703+02-.1656400+01	1	129
-.1673631+01 .1622899+02-.1656400+01-.1673631+01 .1859220+02 .7313220+01	1	130
.1300000+02-.5602227-00 .2138561+01-.4211143+01-.1249109+01 .6391202-00	1	131
-.2582184+01-.1530788+01-.7278077-00-.9724276-00-.1620877+01-.1466121+01	1	132
.6392934-00-.1647582+01-.1643705+01 .2250992+01-.1654488+01-.1669174+01	1	133
.3860889+01-.1656085+01-.1672932+01 .5554762+01-.1656342+01-.1673511+01	1	134
.7326737+01-.1656389+01-.1673612+01 .9148542+01-.1656397+01-.1673628+01	1	135

.1123876+02-.1656398+01-.1673630+01	.1337883+02-.1656398+01-.1673630+01	1	136
.1562079+02-.1656398+01-.1673630+01	.1748400+02-.7718685+01-.1300000+02	1	137
-.9830070+00-.1358213+01-.4816798+01	-.1428523+01-.1000251+00-.3190194+01	1	138
-.1589664+01-.1198034+01-.1500531+01	-.1638578+01-.1544094+01-.3112217+01	1	139
-.1652269+01-.1662461+01-.1642800+01	-.1655709+01-.1671941+01-.3252693+01	1	140
-.1656251+01-.1673316+01-.4946565+01	-.1656371+01-.1673574+01-.6718539+01	1	141
-.1656392+01-.1673614+01-.8590344+01	-.1656396+01-.1673625+01-.1063057+02	1	142
-.1656396+01-.1673626+01-.1277063+02	-.1656396+01-.1673626+01-.1501259+02	1	143
-.1656396+01-.1673626+01-.1737580+02	.0000000 .0000000 .0000000	1	144
1060000			
C-4A, 14 FREQ, TEMP(1.12925-101.2-3-66 REMADE 3-28-67, 4 DENSITIES DELETED			
.1400000+02-.7860000+03			
1000.	.2100000+02		
-.2045970+01-.1200000+02-.6257760+01	.1147990+02-.1334230+01-.6257920+01	1	1
.1198010+02-.2452970+01-.6258000+01	.1198020+02-.3637130+01-.6258130+01	1	2
.1198030+02-.4735950+01-.6258230+01	.1198040+02-.5940220+01-.6258280+01	1	3
.1198040+02-.7039180+01-.6258390+01	.1198050+02-.8243650+01-.6258530+01	1	4
.1198050+02-.9342640+01-.6258670+01	.1198060+02-.1054760+02-.6259370+01	1	5
.1198060+02-.1164720+02-.6260370+01	.1198060+02-.1285260+02-.6262020+01	1	6
.1198070+02-.1395300+02-.1758240+01	.1200000+02-.7148200+01-.1177020+02	1	7
.1625190+01-.7149140+01-.1177090+02	.2725100+01-.7150500+01-.1177170+02	1	8
.3930900+01-.7152110+01-.1177220+02	.5031700+01-.7155070+01-.1177270+02	1	9
.6238860+01-.7159600+01-.1177300+02	.7341440+01-.7167390+01-.1177310+02	1	10
.8551450+01-.7176520+01-.1177260+02	.9657950+01-.7186140+01-.1177120+02	1	11
.1087480+02-.7190980+01-.1176800+02	.1199160+02-.7188570+01-.1175980+02	1	12
.1322780+02-.7175010+01-.1174310+02	.1437570+02-.1535150+01-.1200000+02	1	13
.7727940+01-.1139530+02-.1860600+01	.7733510+01-.1139740+02-.2965470+01	1	14
.7742200+01-.1139900+02-.4176770+01	.7753630+01-.1139940+02-.5289770+01	1	15
.7768300+01-.1139790+02-.6514380+01	.7778750+01-.1139270+02-.7642720+01	1	16
.7777780+01-.1137760+02-.8900200+01	.7754480+01-.1134530+02-.1008040+02	1	17
.7677840+01-.1126060+02-.1143250+02	.7505160+01-.1107800+02-.1273390+02	1	18
.7095560+01-.1064330+02-.1418760+02	.6520550+01-.1001560+02-.1544130+02	1	19
-.1352620+01-.1200000+02-.8216230+01	.1102230+02-.2077400+01-.0230050+01	1	20
.1102430+02-.3198560+01-.8245760+01	.1102130+02-.4441330+01-.8252660+01	1	21
.1100490+02-.5597180+01-.8234220+01	.1097160+02-.6904450+01-.8164830+01	1	22
.1088830+02-.6153510+01-.7965660+01	.1067310+02-.9588630+01-.7604190+01	1	23
.1028820+02-.1090150+02-.7082910+01	.9728680+01-.1225420+02-.6676300+01	1	24
.9292640+01-.1342060+02-.6428400+01	.9031940+01-.1467450+02-.6392600+01	1	25
.8995460+01-.1582610+02-.1198670+01	.1200000+02-.8658770+01-.1073810+02	1	26
.2312420+01-.8670120+01-.1073030+02	.3480520+01-.8657740+01-.1069600+02	1	27
.8806530+01-.8588940+01-.1061250+02	.6075640+01-.8387390+01-.1040650+02	1	28
.7519690+01-.8064700+01-.1009590+02	.8815370+01-.7693280+01-.9757260+01	1	29
.1015270+02-.7482793+01-.9575580+01	.1152890+02-.7426540+01-.9524060+01	1	30
.1262020+02-.7481530+01-.9560290+01	.1343830+02-.7549810+01-.9594520+01	1	31
.1525460+02-.7441420+01-.9469100+01	.1663400+02-.1065140+01-.1200000+02	1	32
.9030110+01-.1061740+02-.2607540+01	.9004730+01-.1058100+02-.3861760+01	1	33
.8900750+01-.1047420+02-.5247770+01	.8688930+01-.1030020+02-.6612350+01	1	34
.8420040+01-.1010190+02-.7985600+01	.8267600+01-.9994750+01-.9192500+01	1	35
.8230230+01-.9954320+01-.1052110+02	.8252210+01-.9975230+01-.1178280+02	1	36
.8195400+01-.9816410+01-.1324670+02	.7850550+01-.9423800+01-.1459490+02	1	37
.7012260+01-.8568360+01-.1595300+02	.5998620+01-.7569450+01-.1718020+02	1	38
-.9473590+00-.1200000+02-.9270140+01	.1069410+02-.2974010+01-.9202380+01	1	39
.1062300+02-.4300230+01-.9038720+01	.1058150+02-.5732670+01-.8898130+01	1	40
.1040800+02-.6983800+01-.8830470+01	.1034880+02-.8336450+01-.8813110+01	1	41
.1029600+02-.9603970+01-.8713670+01	.1013480+02-.1105730+02-.8356140+01	1	42

AFWL-TR-67-131, Vol IV

.8545200+01	.1171620+02	.5416520+01	.7229210+01	.1298430+02	.3196420+01	1	98
.4842420+01	.1532730+02	.1555000+01	.2843350+01	.1774190+02	.1581270+00	1	99
.1375640+01	.2037200+02	.6104300+00	.1200000+02	.1117640+02	.1202690+02	1	100
.2324790+01	.1094970+02	.1186000+02	.3609170+01	.1079640+02	.1172400+02	1	101
.4545250+01	.1047070+02	.1137170+02	.6100000+01	.9732300+01	.1076500+02	1	102
.7544280+01	.8944720+01	.1000780+02	.8830370+01	.8033860+01	.9022990+01	1	103
.1012010+02	.7227090+01	.8152920+01	.1130420+02	.6291170+01	.7281500+01	1	104
.1206430+02	.4050510+01	.5399160+01	.1529670+02	.1700250+01	.3101850+01	1	105
.1769520+02	.2604140+00	.9068040+00	.2004690+02	.1223780+01	.1200000+02	1	106
.1167090+02	.1195710+02	.2497330+01	.1146440+02	.1140240+02	.3703250+01	1	107
.1125180+02	.1166460+02	.4589430+01	.1076370+02	.1145230+02	.5927080+01	1	108
.9972790+01	.1114790+02	.7334190+01	.9040590+01	.1051210+02	.8626450+01	1	109
.7924990+01	.9498050+01	.1001340+02	.6948410+01	.8404390+01	.1122000+02	1	110
.5953880+01	.7221290+01	.1250350+02	.4103670+01	.5233220+01	.1499840+02	1	111
.1935300+01	.5123690+01	.1746370+02	.1103760+00	.9902940+00	.1984820+02	1	112
.1609440+01	.1200000+02	.1160650+02	.1189920+02	.2435770+01	.1145150+02	1	113
.1178550+02	.3542100+01	.1125990+02	.1170050+02	.4447270+01	.1073770+02	1	114
.1151410+02	.5771750+01	.1012320+02	.1113850+02	.7178620+01	.9473100+01	1	115
.1046800+02	.8422530+01	.6463890+01	.9463930+01	.9770020+01	.7411800+01	1	116
.6425140+01	.1098660+02	.6174260+01	.7201040+01	.1228430+02	.3993780+01	1	117
.4981120+01	.1474310+02	.1648980+01	.2816350+01	.1716950+02	.5084550+00	1	118
.5598490+00	.1944750+02	.1945910+01	.1200000+02	.1124370+02	.1171220+02	1	119
.2309150+01	.1117480+02	.1154960+02	.3424790+01	.1109430+02	.1151960+02	1	120
.4260200+01	.1086230+02	.1144810+02	.5564780+01	.1027250+02	.1098680+02	1	121
.6941290+01	.9437520+01	.1021310+02	.8202210+01	.8317130+01	.9122620+01	1	122
.9549010+01	.7271350+01	.8005610+01	.1072560+02	.5961440+01	.6724210+01	1	123
.1201510+02	.3208900+01	.4353690+01	.1438110+02	.6958490+00	.1690900+01	1	124
.1662400+02	.1097660+01	.3183800+00	.1849580+02	.2302590+01	.1200000+02	1	125
.1049560+02	.1136590+02	.2105180+01	.1047680+02	.1127460+02	.3196210+01	1	126
.1042600+02	.1121240+02	.4013830+01	.1020900+02	.1101910+02	.5291390+01	1	127
.9702390+01	.1039600+02	.6661420+01	.8912330+01	.9453090+01	.7481320+01	1	128
.7691350+01	.8164670+01	.9177020+01	.6371760+01	.6932190+01	.1031950+02	1	129
.4870660+01	.5605220+01	.1154330+02	.2238430+01	.3159010+01	.1385470+02	1	130
-.1538510+02	.8333960+00	.1615820+02	.1358980+01	.1070520+01	.1846090+02	1	131

DIANE/SCAT C-1A T4M(1-2250 EV) 11-7-67 SADT INPUT TAPES(1303-1159)

.1000000+01	.8610000+03					1	0
.3006.	.2100000+02					1	1
.0000000	.1300000+02	.6606878+01	.9820556+01	.1296147+01	.6784705+01	1	2
.9745294+01	.9102045+00	.6754538+01	.9579939+01	.3544070+01	.6698247+01	1	3
.9587894+01	.6415692+01	.6449031+01	.9101728+01	.9367875+01	.5979535+01	1	4
.8421456+01	.1215713+02	.4857572+01	.6961544+01	.1456576+02	.3188336+01	1	5
.5265691+01	.1630605+02	.1273977+01	.3354430+01	.1848699+02	.7362190+00	1	6
.1264200+01	.2053533+02	.2373932+01	.6353852+00	.2267964+02	.3100166+01	1	7
-.2481413+01	.2495091+02	.3083827+01	.2947838+01	.2751901+02	.4054651+00	1	8
.1300000+02	.9532645+01	.1151485+02	.1218917+01	.9381120+01	.1143385+02	1	9
.3573113+01	.9202302+01	.1121364+02	.6182297+01	.8646091+01	.1070680+02	1	10
.8651143+01	.7466477+01	.9487384+01	.1073897+02	.5902082+01	.7743084+01	1	11
.1250431+02	.4203384+01	.5952477+01	.1424021+02	.2636864+01	.4173534+01	1	12
.1604387+02	.1402289+01	.2673865+01	.1804059+02	.1580685+00	.1382059+01	1	13
.2039951+02	.1407174+01	.3627442+00	.2272414+02	.2417224+01	.1987483+01	1	14
.2449904+02	.2675778+01	.2600041+01	.2736700+02	.8109302+00	.1300000+02	1	15
.1114380+02	.1210130+02	.2434420+01	.1083171+02	.1176496+02	.4638560+01	1	16
.1813446+02	.1114215+02	.6762764+01	.9114142+01	.1015095+02	.8638609+01	1	17
.7864337+01	.8841002+01	.1036561+02	.6650536+01	.7612688+01	.1213190+02	1	18

.5168049+01	.6351424+01	.1404586+02	.3311826+01	.4726169+01	.1604508+02	1	18
.1454859+01	.2841439+01	.1796432+02	.2668597+00	.9061521+00	.2005444+02	1	19
-.1577982+01	-.0883283+00	.2235510+02	.2109404+01	.1833993+01	.2476142+02	1	20
-.2273112+01	-.2227684+01	.2716408+02	.1223775+01	.1300000+02	.1183807+02	1	21
.1213252+02	.2693631+01	.1131906+02	.1172617+02	.4647583+01	.1045933+02	1	22
.1135997+02	.6536379+01	.9204761+01	.1064858+02	.8420349+01	.7749817+01	1	23
.9294581+01	.1027071+02	.6333694+01	.7679511+01	.1200990+02	.4984353+01	1	24
.6133920+01	.1382079+02	.3469849+01	.4631637+01	.1578545+02	.1667311+01	1	25
.2872528+01	.1774285+02	.1370937+00	.9843153+00	.1985577+02	.1406124+01	1	26
-.6364230+00	.2213738+02	.1876029+01	.1696893+01	.2445557+02	.2000143+01	1	27
-.1967788+01	.2683064+02	.1609438+01	.1300000+02	.1184060+02	.1218059+02	1	28
.2667112+01	.1137115+02	.1184401+02	.4514546+01	.1054995+02	.1146572+02	1	29
.6400813+01	.9605425+01	.1061400+02	.8225306+01	.8274195+01	.9277375+01	1	30
.1002754+02	.6659671+01	.7693746+01	.1179019+02	.5007292+01	.5989510+01	1	31
.1359338+02	.3310538+01	.4351566+01	.1549396+02	.1379474+01	.2566205+01	1	32
.1744552+02	.1984473+00	.5659338+00	.1950505+02	.1617564+01	.1137194+01	1	33
.2164789+02	.1948238+01	.1864787+01	.2389018+02	.2004897+01	.1986544+01	1	34
.2625343+02	.1945910+01	.1300000+02	.1142945+02	.1211812+02	.2539882+01	1	35
.1128198+02	.1181306+02	.4364768+01	.1074918+02	.1142160+02	.6194824+01	1	36
.9611972+01	.1040100+02	.8013253+01	.8127835+01	.8928677+01	.9784286+01	1	37
.6501690+01	.7233428+01	.1152538+02	.4503240+01	.5481414+01	.1329368+02	1	38
.2409754+01	.3611940+01	.1508663+02	.4438287+00	.1629638+01	.1696250+02	1	39
-.1097603+01	-.3100030+00	.1900339+02	.1785013+01	.1591735+01	.2114354+02	1	40
-.1961416+01	.1949047+01	.2338552+02	.2011379+01	.1996123+01	.2574873+02	1	41
.2302585+01	.1300000+02	.1064222+02	.1194699+02	.2330537+01	.1056371+02	1	42
.1160104+02	.4131400+01	.1014951+02	.1099850+02	.5916096+01	.9152111+01	1	43
.9770009+01	.7700100+01	.7463753+01	.7946815+01	.9829030+01	.5489976+01	1	44
.6133300+01	.1107100+02	.3431741+01	.4229427+01	.1270011+02	.1000000+01	1	45
.2457600+01	.1455002+02	.2103720+00	.5939492+00	.1642019+02	.1354044+01	1	46
-.1060608+01	.1846047+02	.1853921+01	.1834795+01	.2010854+02	.1946835+01	1	47
-.1982375+01	.2285050+02	.2017092+01	.1949271+01	.2521371+02	.2708050+01	1	48
.1300000+02	.9385040+01	.1138911+02	.2001555+01	.9050773+01	.1084750+02	1	49
.3752512+01	.8395869+01	.9917572+01	.5507390+01	.7273416+01	.8338724+01	1	50
.7209719+01	.5769000+01	.6588700+01	.8859835+01	.4109399+01	.4851636+01	1	51
.1047963+02	.2352331+01	.3068797+01	.1217575+02	.5999711+00	.1270387+01	1	52
.1394817+02	.8553296+00	.4420382+00	.1582007+02	.1701623+01	.1604256+01	1	53
.1786050+02	.1968023+01	.1941415+01	.2000223+02	.1996946+01	.1976701+01	1	54
.2225887+02	.1915920+01	.1896829+01	.2470812+02	.3113515+01	.1300000+02	1	55
.6203033+01	.1057701+02	.1552197+01	.7511445+01	.9820837+01	.3275192+01	1	56
.6417102+01	.8593470+01	.4963512+01	.5139524+01	.7055435+01	.6625805+01	1	57
.3687101+01	.5383447+01	.8258150+01	.2170084+01	.3713048+01	.9873744+01	1	58
.7111113+00	.2059845+01	.1157247+02	.4100334+00	.6702279+00	.1336449+02	1	59
-.1169738+01	.2940714+00	.1531092+02	.1630370+01	.1192318+01	.1744716+02	1	60
-.1740547+01	.1625934+01	.1963685+02	.1681278+01	.1643172+01	.2196745+02	1	61
-.1624006+01	.1603222+01	.2439225+02	.3526360+01	.1300000+02	.7452357+01	1	62
.9754282+01	.1029901+01	.6450446+01	.8717444+01	.2721566+01	.5278575+01	1	63
.7462245+01	.4385560+01	.3962339+01	.6139538+01	.6027863+01	.2828579+01	1	64
.5055593+01	.7693094+01	.1785726+01	.4036041+01	.9389228+01	.6226522+00	1	65
.2766652+01	.1116387+02	.3606221+00	.1411297+01	.1300922+02	.1151701+01	1	66
.7125150+01	.1496101+02	.1518389+01	.1104599+01	.1703245+02	.1601215+01	1	67
-.1522474+01	.1917764+02	.1611621+01	.1587659+01	.2142023+02	.1613165+01	1	68
-.1594959+01	.2378351+02	.3912023+01	.1300000+02	.7306998+01	.9589687+01	1	69
.5120196+00	.6494001+01	.8762718+01	.2149301+01	.5447650+01	.7760897+01	1	70
.3901914+01	.4295266+01	.6631862+01	.5624541+01	.3022224+01	.5369912+01	1	71
.7326920+01	.1714798+01	.4106420+01	.9018814+01	.3143433+00	.2577604+01	1	72

.1075987+02-.8205019-00	.8585928-00	.1254483+02-.1388709+01	.6220374-00	1	73		
.1441911+02-.1554040+01	.1403452+01	.1645973+02-.1593306+01	.1573673+01	1	74		
.1859408+02-.1611921+01	.1594270+01	.2044181+02-.1613772+01	.1595513+01	1	75		
.2320502+02-.4248445+01	.1300700+02	.7963085+01	.9595818+01	.8806889+01	1	76	
.7071307+01	.8264304+01	.1833653+01	.5928582+01	.7697861+01	.3562204+01	1	77
.4468827+01	.6354014+01	.5273964+01	.2823981+01	.4861396+01	.6942898+01	1	78
.1123439+01	.3294923+01	.8571628+01	.3564670-00	.1582973+01	.1027001+02	1	79
-.1103344+01	-.7619046+02	.1204287+02	-.1402518+01	-.1139618+01	.1391483+02	1	80
-.1561368+01	-.1539568+01	.1595507+02	-.1609495+01	-.1591550+01	.1809514+02	1	81
-.1612779+01	-.1594669+01	.2033710+02	-.1612989+01	-.1595134+01	.2270031+02	1	82
.4605170+01	.1300000+02	.8200481+01	.9360953+01	-.3098410-00	.7322354+01	1	83
.8445142+01	.1424444+01	.6012414+01	.7095269+01	.3145608+01	.4271631+01	1	84
.5504314+01	.4805265+01	.2399823+01	.3888232+01	.6428827+01	.7346503-00	1	85
.2257362+01	.0041663+01	.4349913-00	.6343804-00	.9735928+01	.1124264+01	1	86
-.7500742-00	.1150002+02	-.1515002+01	.1454348+01	.1337484+02	.1404044+01	1	87
-.1504191+01	.1542008+02	-.1611306+01	.1593522+01	.1756013+02	-.1411967+01	1	88
-.1594266+01	.1460209+02	-.1612024+01	.1594433+01	.2216530+02	.5010635+01	1	89
.1300000+02	.7076272+01	.8611673+01	.7903264-00	.6106252+01	.7325883+01	1	90
.9156109-00	.4842555+01	.5884744+01	.2580574+01	.3232281+01	.4273936+01	1	91
.4209462+01	.1566485+01	.2663295+01	.5823448+01	.6342535+01	.1100831+01	1	92
.7433657+01	-.1620393+01	-.3915609-00	.9127841+01	-.1494039+01	.1339367+01	1	93
.1089984+02	-.1600692+01	-.1568212+01	.1277165+02	-.1614519+01	.1595067+01	1	94
.1481187+02	-.1615576+01	-.1547583+01	.1695193+02	-.1615696+01	.1497875+01	1	95
.1919389+02	-.1615709+01	-.1547906+01	.2155710+02	.5416100+01	.1300000+02	1	96
.5275411+01	.7545446+01	-.1313792+01	.4318177+01	.6306478+01	.3512244-00	1	97
.2912470+01	.4750387+01	.1982535+01	.1395746+01	.3165886+01	.3603695+01	1	98
-.5783007-01	.1590752+01	.5215775+01	-.1040805+01	.2369191+01	.6825769+01	1	99
-.1481256+01	-.1147263+01	.8519064+01	-.1601565+01	-.1539835+01	.1029164+02	1	100
-.1622537+01	-.1601185+01	.1216345+02	-.1625628+01	-.1609807+01	.1420367+02	1	101
-.1625231+01	-.1609652+01	.1634374+02	-.1625279+01	-.1609785+01	.1858570+02	1	102
-.1625284+01	-.1609799+01	.2694891+02	.5828946+01	.1300000+02	.3917760+01	1	103
.6679357+01	.1882292+01	.2594405+01	.5234030+01	-.2564633-00	.1138083+01	1	104
.3676234+01	.1366573+01	-.2381127-00	.2042497+01	.2985201+01	.1110415+01	1	105
.5305695-00	.4596673+01	-.1476051+01	.7838667-00	.6206535+01	.1598122+01	1	106
-.1452723+01	.7900402+01	-.1624732+01	-.1599900+01	.9672376+01	.1635785+01	1	107
-.1622780+01	.1154418+02	.1636761+01	-.1626285+01	.1358440+02	.1636916+01	1	108
-.1626740+01	.1572447+02	.1636932+01	-.1626803+01	.1796643+02	.1636934+01	1	109
-.1626809+01	.2032964+02	.6214608+01	.1300000+02	.1639776+01	.4645344+01	1	110
-.2448786+01	.2523767+00	.3576774+01	-.8303536-00	.6209592-00	.2070176+01	1	111
.7893873-00	.1366494+01	.5558020-00	.2407018+01	-.1566881+01	-.7462923-00	1	112
.4018247+01	-.1632340+01	-.1552190+01	.5628055+01	.1650631+01	.1655394+01	1	113
.7321911+01	-.1647944+01	.1668688+01	.9043882+01	.1655631+01	.1670571+01	1	114
.1096569+02	.1655720+01	-.1670812+01	.1300591+02	.1655732+01	.1670844+01	1	115
.1514597+02	.1655734+01	.1670848+01	.1738793+02	.1655734+01	.1670848+01	1	116
.1475114+02	.6551080+01	.1300000+02	.1037855+01	.4036057+01	.2947952+01	1	117
-.2688150-00	.2558718+01	.1332496+01	.1112817+01	.1042747+01	.2853629-00	1	118
-.1480852+01	.3930504-00	.1902456+01	.1605339+01	.1334825+01	.3513571+01	1	119
-.1642795+01	.1618139+01	.5123354+01	-.1653149+01	.1663843+01	.6817204+01	1	120
-.1655360+01	.1669880+01	.8589174+01	-.1655681+01	.1670707+01	.1046098+02	1	121
-.1655727+01	.1670836+01	.1250120+02	-.1655733+01	.1670846+01	.1464127+02	1	122
-.1655734+01	.1670848+01	.1688323+02	-.1655734+01	.1670848+01	.1924644+02	1	123
.6907755+01	.1306000+02	.4137381-00	.3377297+01	.3479598+01	.7188094-00	1	124
.1677365+01	.1866384+01	.1321200+01	.3798146-00	.2437243-00	.1534106+01	1	125
-.9053913-00	.1347537+01	-.1627621+01	-.1517426+01	.2978579+01	.1648890+01	1	126
-.1648915+01	.4588346+01	-.1654329+01	-.1667547+01	.6282192+01	.1659570+01	1	127

AFWL-TR-67-131, Vol IV

-.1670398+01	.0054182+01	-.1655708+01	-.1670779+01	.9925965+01	-.1655731+01	1	128
-.1670639+01	.1196819+02	-.1655734+01	-.1670847+01	.1410625+02	-.1655734+01	1	129
-.1670848+01	.1634821+02	-.1655734+01	-.1670848+01	.1471142+02	.7313220+01	1	130
.1300000+02	-.2260034+00	.2615650+01	-.4085608+01	.826144+01	.1121463+01	1	131
-.2481720+01	-.1470533+01	-.3318500+00	-.6517030+00	.002024+01	-.1306573+01	1	132
.7544038+00	-.1641669+01	-.1612391+01	.2370396+01	-.1652604+01	-.1662263+01	1	133
.3980151+01	-.1655186+01	-.1669332+01	.5673995+01	-.1655659+01	-.1670644+01	1	134
.7445464+01	-.1655722+01	-.1670818+01	.9317769+01	-.1655733+01	-.1670844+01	1	135
.1135799+02	-.1655734+01	-.1670848+01	.1349806+02	-.1655734+01	-.1670848+01	1	136
.1574002+02	-.1655734+01	-.1670848+01	.1810323+02	.7718685+01	.1300000+02	1	137
-.7373354+00	.1844760+01	-.4692567+01	.1326724+01	.3565200+00	-.3969563+01	1	138
-.1555657+01	.9180342+00	.1459772+01	-.1628085+01	-.1520655+01	.1512447+00	1	139
-.1648948+01	-.1648909+01	.1762207+01	-.1654226+01	-.1667286+01	.3371955+01	1	140
-.1655544+01	-.1670325+01	.5065796+01	-.1655700+01	-.1670759+01	.6837767+01	1	141
-.1655749+01	-.1670835+01	.8709571+01	-.1655733+01	-.1670847+01	.1074979+02	1	142
-.1655734+01	-.1670848+01	.1288986+02	-.1655734+01	-.1670848+01	.1513182+02	1	143
-.1655734+01	-.1670848+01	.1749503+02	.0000000	.0000000	.0000000	1	144

10

DIANE/SCAT CF2-10A C1/JT. MEDO OF RUN 1-6-67. TEMP(1-2250). TAPE 1432

.1000000+02	.8550000+03						
1103.	.2100000+02						
.0000000	.1300000+02	.7547093+01	.1166047+02	.2711039+01	.7404677+01	1	1
.1147181+02	-.5046785+00	.7329407+01	.1134207+02	.2129211+01	.6911944+01	1	2
.1061840+02	.5000933+01	.6286152+01	.9277879+01	.7953599+01	.5447278+01	1	3
.7833045+01	.1074564+02	.4126678+01	.6245991+01	.1317273+02	.2422501+01	1	4
.4524271+01	.1527754+02	.7572899+00	.2857616+01	.1756259+02	.9123004+00	1	5
.1204010+01	.2005305+02	-.2598435+01	-.7835944+00	.2232766+02	-.3462862+01	1	6
-.2620579+01	.2459823+02	.3586981+01	.3427494+01	.2703830+02	.4054651+00	1	7
.1300000+02	.1050219+02	.1263291+02	-.1209925+00	.1039524+02	.1243032+02	1	8
.2230599+01	.9966466+01	.1220121+02	.4839487+01	.9037897+01	.1107862+02	1	9
.7379847+01	.7589954+01	.9578130+01	.9645451+01	.5983739+01	.7996177+01	1	10
.1176509+02	.4244195+01	.6358602+01	.1378998+02	.2440801+01	.4578801+01	1	11
.1567305+02	.7927939+00	.2729488+01	.1760940+02	.7711164+00	.4925357+00	1	12
.1970405+02	-.2347166+01	.1030345+01	.2202462+02	.3108867+01	-.2568168+01	1	13
.2437966+02	.3091077+01	.2997274+01	.2695623+02	.6109302+00	.1300000+02	1	14
.1232213+02	.1317855+02	.1406095+01	.1196897+02	.1274353+02	.3705175+01	1	15
.1112058+02	.1259627+02	.6022170+01	.9629633+01	.1134526+02	.8123408+01	1	16
.7614211+01	.9646713+01	.9952561+01	.6085647+01	.7932220+01	.1167164+02	1	17
.4436394+01	.8139171+01	.1350272+02	.2654719+01	.4301271+01	.1542464+02	1	18
.1016477+01	.2584551+01	.1749012+02	-.7465219+00	.7321004+00	.1946886+02	1	19
-.2149399+01	-.1109636+01	.2189289+02	-.2723852+01	.2408266+01	.2420650+02	1	20
-.2833895+01	-.2779773+01	.2661304+02	.1223775+01	.1300000+02	.1291690+02	1	21
.1335762+02	.2144234+01	.1231562+02	.1304898+02	.4172065+01	.1115468+02	1	22
.1242677+02	.6097090+01	.9443633+01	.1102205+02	.7913693+01	.7632586+01	1	23
.9426291+01	.9732046+01	.6027615+01	.7760642+01	.1154886+02	.4455503+01	1	24
.6012017+01	.1336605+02	.2781280+01	.4215401+01	.1525876+02	.1035288+01	1	25
.2360239+01	.1721463+02	.6006330+00	.5644446+00	.1939441+02	-.1842721+01	1	26
-.1122354+01	.2166547+02	.2302978+01	-.2208255+01	.2395715+02	-.2460043+01	1	27
-.2428957+01	.2637137+02	.1609438+01	.1300000+02	.1290064+02	.1326608+02	1	28
.2193184+01	.1225688+02	.1296462+02	.4046000+01	.1103537+02	.1228752+02	1	29
.5934284+01	.9419351+01	.1095172+02	.7781876+01	.7880435+01	.9330686+01	1	30
.9558388+01	.6275537+01	.7649546+01	.1129968+02	.4679412+01	.5854646+01	1	31
.1313830+02	.2893466+01	.4009520+01	.1503058+02	.1008895+01	.2154151+01	1	32
.1697772+02	-.7484303+00	.3158765+00	.1911014+02	-.1868075+01	-.1333371+01	1	33
.2131135+02	-.2227604+01	-.2122992+01	.2359088+02	-.2219911+01	-.2198324+01	1	34

.2603675+02	.1945910+01	.1300000+02	.1268217+02	.1310944+02	.2111142+01	1	35
.1222513+02	.1305626+02	.3923671+01	.1111941+02	.1229815+02	.5755051+01	1	36
.9593127+01	.1021031+02	.7559005+01	.7917677+01	.9032160+01	.9346267+01	1	37
.6133008+01	.7183244+01	.1130371+02	.4240368+01	.5405544+01	.1248344+01	1	38
.2521637+01	.3643440+01	.1473461+02	.7433440+00	.1819631+01	.1667003+02	1	39
-.6476808+00	.4242725+01	.1678466+02	.1748565+01	.1435198+01	.2098289+02	1	40
-.2038617+01	.1971696+01	.2324495+02	.2046148+01	.2028262+01	.2571173+02	1	41
.2302565+01	.1300000+02	.1207132+02	.1241625+02	.1932364+01	.1174674+02	1	42
.1275636+02	.3726653+01	.1085233+02	.1169052+02	.5514147+01	.9250095+01	1	43
.1001772+02	.7305630+01	.7386324+01	.6280637+01	.9064077+01	.5666555+01	1	44
.6572273+01	.1077247+02	.4040444+01	.4904632+01	.1255144+02	.2283293+01	1	45
.3218711+01	.1439523+02	.4576452+00	.1474561+01	.1634014+02	.1058264+01	1	46
-.3001490+00	.1844397+02	.1726168+01	.1441579+01	.2064953+02	.1906957+01	1	47
-.1873771+01	.2242215+02	.1438641+01	.1923261+01	.2528998+02	.2708050+01	1	48
.1300000+02	.1120083+02	.1234450+02	.1655040+01	.1049385+02	.1185127+02	1	49
.3420870+01	.1014470+02	.1070806+02	.5144428+01	.8639491+01	.9180380+01	1	50
.6449265+01	.6448064+01	.7666684+01	.8678281+01	.5291292+01	.6097164+01	1	51
.1037990+02	.3544073+01	.4413232+01	.1214497+02	.1737241+01	.2688730+01	1	52
.1348579+02	.5518045+01	.8726654+00	.1588879+02	.1377007+01	.8520809+00	1	53
.1743598+02	.1044236+01	.1732404+01	.2007740+02	.1920666+01	.1902284+01	1	54
.2232276+02	.1415054+01	.1902533+01	.2470601+02	.3113515+01	.1300000+02	1	55
.1018901+02	.1151825+02	.1308286+01	.1004031+02	.1083747+02	.3060165+01	1	56
.9407133+01	.4473286+01	.4808003+01	.8005715+01	.8447803+01	.6544097+01	1	57
.6365100+01	.6896816+01	.8251274+01	.4446723+01	.5144160+01	.9921783+01	1	58
.2478079+01	.3376468+01	.1163437+02	.5974061+00	.1544047+01	.1342115+02	1	59
-.8255054+00	.7274111+01	.1531133+02	.1574990+01	.1321072+01	.1737558+02	1	60
-.1805924+01	.1775184+01	.1452669+02	.1847625+01	.1832462+01	.2179513+02	1	61
-.1834301+01	.1824817+01	.2417624+02	.3526360+01	.1100000+02	.9335017+01	1	62
.1061310+02	.4011604+00	.9037718+01	.4940143+01	.2622754+01	.8337021+01	1	63
.8441933+01	.4360086+01	.7026176+01	.7345654+01	.6053294+01	.5225624+01	1	64
.5708013+01	.7715132+01	.3384404+01	.4107067+01	.9359222+01	.1661544+01	1	65
.2443217+01	.1107681+02	.1076416+00	.8784439+00	.1246910+02	.1083063+01	1	66
-.5807231+00	.1476372+02	.1670591+01	.1538320+01	.1641314+02	.1413064+01	1	67
-.1784147+01	.1895409+02	.3912023+01	.1300000+02	.4806815+01	.9447212+01	1	68
.4626488+00	.8272464+01	.9181931+01	.2104427+01	.7248554+01	.7440686+01	1	69
.3877148+01	.5045310+01	.2406325+01	.5550705+01	.4164406+01	.4444684+01	1	70
.7144400+01	.2533057+01	.3401136+01	.8430521+01	.4340344+00	.1747673+01	1	71
.1054775+02	.6534982+00	.1021344+00	.1232555+02	.1457158+01	.1124461+01	1	72
.1420803+02	.1698337+01	.1605494+01	.1628721+02	.1722890+01	.1697550+01	1	73
.1847140+02	.1643911+01	.1677505+01	.2075894+02	.1661205+01	.1647003+01	1	74
.2315724+02	.4246445+01	.1300000+02	.1435773+02	.4303107+01	.6326289+01	1	75
-.7162723+01	.8444447+01	.1754448+01	.6556547+01	.7197144+01	.3435111+01	1	76
.4453545+01	.5643273+01	.5045320+01	.3244623+01	.4163405+01	.6734417+01	1	77
.1584277+01	.2714470+01	.8364866+01	.2376625+00	.1447175+01	.1009368+02	1	78
-.8088574+00	.2272444+00	.1411111+02	.1344604+01	.8357070+00	.1382809+02	1	79
-.1604005+01	.1446905+01	.1540387+02	.1648169+01	.1614080+01	.1805279+02	1	80
-.1653900+01	.1637373+01	.2029594+02	.1654676+01	.1639923+01	.2265928+02	1	81
.4605170+01	.1300000+02	.6114386+01	.8862914+01	.3970450+00	.7247980+01	1	82
.7824622+01	.1286051+01	.5884590+01	.6448597+01	.2451666+01	.4316667+01	1	83
.5221321+01	.4615778+01	.2811858+01	.4016592+01	.6277778+01	.1435186+01	1	84
.2784444+01	.7937137+01	.5530385+01	.1375180+01	.9672264+01	.1028285+01	1	85
-.1083551+00	.1146220+02	.1512191+01	.1140195+01	.1333804+02	.1624243+01	1	86
-.1364919+01	.1537844+02	.1645872+01	.1632871+01	.1751910+02	.1653722+01	1	87
-.1639939+01	.1976107+02	.1654305+01	.1640335+01	.2212420+02	.5010635+01	1	88
.1300000+02	.7768547+01	.8486555+01	.9311653+00	.6768803+01	.7510131+01	1	89

.7556330-00	.5435967+01	.6305374+01	.2441574+01	.5874823+01	.4968027+01	1	90
.4110988+01	.2178500+01	.3548358+01	.5765703+01	.5685394-00	.1987636+01	1	91
.7368869+01	.6968979-00	.4060673-00	.9086055+01	.1312591+01	.8798327-00	1	92
.1085868+02	.1543321+01	.1493124+01	.1273160+02	.1636498+01	.1624145+01	1	93
.1477084+02	.1647931+01	.1635237+01	.1691091+02	.1648622+01	.1636056+01	1	94
.1915247+02	.1648667+01	.1636127+01	.2151608+02	.5416100+01	.1300000+02	1	95
.7120055+01	.8037009+01	.1450449+01	.6313749+01	.7017744+01	.2419597-00	1	96
.4933084+01	.5607610+01	.1912892+01	.3163228+01	.4009760+01	.3552805+01	1	97
.14004750+01	.2440166+01	.5172444+01	.1627668+01	.8591304-00	.6784272+01	1	98
.9051690-00	.5500486-00	.8478551+01	.1481712+01	.1395612+01	.1025060+02	1	99
.1619917+01	.1600575+01	.1212342+02	.1634515+01	.1622565+01	.1416265+02	1	100
.1635885+01	.1624897+01	.1630271+02	.1636002+01	.1625136+01	.1654467+02	1	101
.1636015+01	.1625161+01	.2090708+02	.5828946+01	.1360000+02	.5725972+01	1	102
.7259279+01	.1490605+01	.4751830+01	.5962737+01	.3243730-00	.3390860+01	1	103
.4416763+01	.1317130+01	.1808731+01	.2793429+01	.2939995+01	.2691323-00	1	104
.1235008+01	.4554728+01	.8977662-00	.2093952-00	.6165321+01	.1459938+01	1	105
.1254400+01	.7859343+01	.1602571+01	.1563955+01	.9631346+01	.1623154+01	1	106
.1607624+01	.1150316+02	.1626097+01	.1114039+01	.1354338+02	.1626399+01	1	107
.1614755+01	.1588344+02	.1626435+01	.1614640+01	.1792540+02	.1626439+01	1	108
.1614849+01	.2028861+02	.6214606+01	.1390000+02	.4057697+01	.6248505+01	1	109
.2529247+01	.2773237+01	.4772417+01	.8842670-00	.1417284+01	.3292304+01	1	110
.7442772-00	.2020700+01	.1729417+01	.2362794+01	.9430103-00	.2041534-00	1	111
.3476527+01	.1447614+01	.1000768+01	.5566888+01	.1595959+01	.1505806+01	1	112
.7280801+01	.1624926+01	.1599109+01	.9052854+01	.1629619+01	.1613482+01	1	113
.1092466+02	.1629617+01	.1614527+01	.1296488+02	.1629722+01	.1614830+01	1	114
.1510495+02	.1629734+01	.1614806+01	.1734691+02	.1629736+01	.1614870+01	1	115
.1471012+02	.6551080+01	.1300000+02	.2584855+01	.5334399+01	.3009144+01	1	116
.1472504+01	.4029131+01	.1373597+01	.8471458+01	.2487007+01	.2455057-00	1	117
.939023-00	.4161208-00	.1858514+01	.1409024+01	.4843538-00	.3471916+01	1	118
.1574501+01	.1337474+01	.5004201+01	.1673919+01	.1576061+01	.6776157+01	1	119
.1635075+01	.1616337+01	.8591147+01	.1639110+01	.1634491+01	.1641000+02	1	120
.1637209+01	.1620012+01	.1246016+02	.1637247+01	.1629414+01	.1460024+02	1	121
.1637252+01	.1626163+01	.1684220+02	.1637252+01	.1626163+01	.1920541+02	1	122
.6407755+01	.1300000+02	.1556373+01	.4597723+01	.3527174+01	.2468443-00	1	123
.3138595+01	.1405567+01	.6174976-00	.1581661+01	.2872753-00	.1367381+01	1	124
.6276681+01	.1323726+01	.1563401+01	.1673711+01	.2936957+01	.1623856+01	1	125
.1523437+01	.4547200+01	.1640931+01	.1620270+01	.6241146+01	.1644790+01	1	126
.1637162+01	.8013135+01	.1645443+01	.1639969+01	.9884942+01	.1643979+01	1	127
.1637020+01	.1192516+02	.1643994+01	.1637090+01	.1406523+02	.1643996+01	1	128
.1637097+01	.1630719+02	.1643996+01	.1637098+01	.1867040+02	.7313220+01	1	129
.1300000+02	.4690366+01	.2879129+01	.4125333+01	.9856999-00	.1384846+01	1	130
.2509146+01	.1430950+01	.8222301+01	.8949870-00	.1588993+01	.1173460+01	1	131
.7177332-00	.1637383+01	.1570857+01	.2328793+01	.1651786+01	.1656784+01	1	132
.3439010+01	.1655261+01	.1667004+01	.5632950+01	.1655847+01	.1669425+01	1	133
.7404937+01	.1655937+01	.1669684+01	.9276745+01	.1655952+01	.1669725+01	1	134
.1131697+02	.1655954+01	.1669730+01	.1345703+02	.1655954+01	.1669731+01	1	135
.1569494+02	.1655954+01	.1669731+01	.1806220+02	.7718685+01	.1300000+02	1	136
.5454105-00	.2106951+01	.4731108+01	.1264618+01	.6096913-00	.3116473+01	1	137
.1533416+01	.7286329-00	.1502891+01	.1621173+01	.1458784+01	.1096082+00	1	138
.1647333+01	.1638542+01	.1720615+01	.1634041+01	.1665385+01	.3330816+01	1	139
.1655687+01	.1669653+01	.5024753+01	.1655906+01	.1670285+01	.6796740+01	1	140
.1655946+01	.1670395+01	.8668547+01	.1655953+01	.1670413+01	.1070877+02	1	141
.1655954+01	.1670415+01	.1284883+02	.1655954+01	.1670415+01	.1509080+02	1	142
.1655954+01	.1670415+01	.1745400+02	.0000000	.0000000	.0000000	1	143

DIAM/SCAT CM2-10A TEMP(1.5-1.4) 4-1V-67 INPUT TAPES(1832-1980)

.1600000+02	.9440000+03	1101.	.2400000+02	.4054051+00	.1300000+02	.9764724+01	.1245500+02	.1383864+01	.9633694+01	1	1
.1268730+02	.3747165+01	.9461782+01	.1253182+02	.6374426+01	.9025431+01	1	2				
.1193056+02	.8982454+01	.8074476+01	.1056852+02	.1132741+02	.6702258+01	1	3				
.3883646+01	.1332805+02	.5036621+01	.7031163+01	.1515488+02	.3339464+01	1	4				
.5187087+01	.1646407+02	.1875346+01	.3404634+01	.1888487+02	.4295530+00	1	5				
.1724208+01	.2105526+02	.1101558+01	.1032583+00	.2328186+02	.1937739+01	1	6				
-.1600052+01	.2554003+02	.2130750+01	.2087766+01	.2790562+02	.8109302+00	1	7				
.1300000+02	.1175480+02	.1352034+02	.2848452+01	.1145070+02	.1317842+02	1	8				
.5153553+01	.1082958+02	.1266605+02	.7435519+01	.9793498+01	.1132775+02	1	9				
.9464446+01	.8403467+01	.9624846+01	.1124630+02	.7031560+01	.8068446+01	1	10				
.1244444+02	.5547364+01	.6584786+01	.1475643+02	.3748257+01	.4884364+01	1	11				
.1661204+02	.1823063+01	.2940150+01	.1850991+02	.5597503+01	.1039643+01	1	12				
.2057283+02	.1304714+01	.5734027+00	.2274808+02	.1770353+01	.1595438+01	1	13				
.2513343+02	.1422744+01	.1840176+01	.2752053+02	.1273775+01	.1300000+02	1	14				
.1250448+02	.1330856+02	.3374311+01	.1204608+02	.1263440+02	.5404924+01	1	15				
.1127470+02	.1188333+02	.7321353+01	.1010157+02	.1085163+02	.9133578+01	1	16				
.8525084+01	.4363444+01	.1087310+02	.6750546+01	.7698874+01	.1255041+02	1	17				
.5191487+01	.6126481+01	.1430524+02	.3524366+01	.4586608+01	.1617237+02	1	18				
.1700604+01	.2818544+01	.1810540+02	.5646175+01	.9325317+00	.2019011+02	1	19				
-.1219556+01	.6277126+00	.2241438+02	.1648142+01	.1526216+01	.2471129+02	1	20				
-.1753719+01	.1726286+01	.2708238+02	.1604438+01	.1300000+02	.1212276+02	1	21				
.1277869+02	.3340534+01	.1186412+02	.1214373+02	.5178144+01	.1115179+02	1	22				
.1148338+02	.6782843+01	.9450003+01	.1055727+02	.8747788+01	.8384635+01	1	23				
.9145020+01	.1048854+02	.6642408+01	.7610708+01	.1216743+02	.5026033+01	1	24				
.5902808+01	.1342742+02	.3334480+01	.4252479+01	.1578040+02	.1417726+01	1	25				
.2844057+01	.1770436+02	.4282404+00	.4911579+00	.1475741+02	.1442680+01	1	26				
-.1076217+01	.2164933+02	.1711484+01	.1651051+01	.2414151+02	.1756469+01	1	27				
-.1734528+01	.2650475+02	.1445410+01	.1300000+02	.1144062+02	.1239220+02	1	28				
.3110748+01	.1132677+02	.1186437+02	.4885088+01	.1079164+02	.1134037+02	1	29				
.6667746+01	.9621458+01	.1050731+02	.8405127+01	.6078767+01	.8420845+01	1	30				
.1011647+02	.6446186+01	.7127596+01	.1181067+02	.4441223+01	.5372466+01	1	31				
.1355358+02	.2353428+01	.3504296+01	.1533954+02	.4292062+00	.1534757+01	1	32				
.1721407+02	.9444747+00	.3374401+00	.1925474+02	.1575732+01	.1446091+01	1	33				
.2134486+02	.1723595+01	.1713000+01	.2363603+02	.1762624+01	.1746330+01	1	34				
.2600004+02	.2302585+01	.1300000+02	.1054359+02	.1145351+02	.2786907+01	1	35				
.1045140+02	.1155084+02	.4561815+01	.1004790+02	.1084464+02	.6282113+01	1	36				
.4050450+01	.9613092+01	.8010782+01	.7364329+01	.7844023+01	.9696730+01	1	37				
.5356363+01	.6034224+01	.1133338+02	.3348416+01	.4199431+01	.1303411+02	1	38				
.1446444+01	.2362745+01	.1480747+02	.1901210+00	.5274138+00	.1667952+02	1	39				
-.1218443+01	.1005373+01	.1871479+02	.1644578+01	.1629660+01	.2085986+02	1	40				
-.1752588+01	.1736584+01	.2310182+02	.1766611+01	.1748535+01	.2546503+02	1	41				
.2708050+01	.1300000+02	.4255547+01	.1130329+02	.2356948+01	.8915246+01	1	42				
.1075044+02	.4094465+01	.8254407+01	.4801221+01	.5794127+01	.7135246+01	1	43				
.8223644+01	.7474531+01	.5632054+01	.6475497+01	.9114611+01	.3975554+01	1	44				
.4737740+01	.1073172+02	.2228376+01	.2956506+01	.1242721+02	.5190620+00	1	45				
.1171853+01	.1414954+02	.8203468+00	.4669142+00	.1607138+02	.1534158+01	1	46				
-.1454016+01	.1811174+02	.1732836+01	.1708101+01	.2025292+02	.1753107+01	1	47				
-.1733335+01	.2250470+02	.1648027+01	.1679098+01	.2492634+02	.3117515+01	1	48				
.1300000+02	.8042773+01	.1055209+02	.1897533+01	.7391054+01	.9734278+01	1	49				
.3571213+01	.6289663+01	.8446073+01	.5234485+01	.5014672+01	.6937266+01	1	50				
.6882767+01	.3553523+01	.5282464+01	.8510843+01	.2054798+01	.3618425+01	1	51				
.1812507+02	.6311584+00	.1458582+01	.1182229+02	.4206936+00	.5793864+00	1	52				

.1300770+02-.1109205+01-.3488669+00	.1553027+02-.1487581+01-.1141156+01	1	53
.1763750+02-.1572754+01-.1463350+01	.1941306+02-.1530482+01-.1497499+01	1	54
.2211950+02-.1467972+01-.1467791+01	.2452643+02-.3526360+01-.1300000+02	1	55
.7309715+01-.9728754+01-.1305520+01	.6361231+01-.8657004+01-.2496197+01	1	56
.5170274+01-.7380153+01-.4643115+01	.3842193+01-.6039451+01-.6277359+01	1	57
.2699584+01-.4933459+01-.7927661+01	.1661219+01-.3900529+01-.4597483+01	1	58
.5323120+00-.2627694+01-.1134843+02-.3944063+00	.1280537+01-.1317328+02	1	59
-.1100467+01-.1766539+01-.1510372+02-.1405448+01	.1071707+01-.1716744+02	1	60
-.1470470+01-.1406546+01-.1931135+02-.1478407+01	.1456114+01-.2155378+02	1	61
-.1479767+01-.1461615+01-.2391704+02-.3912023+01	.1300000+02-.7477270+01	1	62
.9469303+01-.7651116+00-.6419098+01-.8649841+01	.2452872+01-.5336736+01	1	63
.7633627+01-.4131323+01-.4157394+01-.6447991+01	.5817433+01-.2485388+01	1	64
.5227115+01-.7495916+01-.1588953+01-.3961578+01	.4166174+01-.2372210+00	1	65
.2432740+01-.1089525+02-.6000656+00-.7367323+00	.1267696+02-.1295435+01	1	66
-.6556025+00-.1455063+02-.1430390+01-.1316536+01	.1659115+02-.1465784+01	1	67
-.1448299+01-.1873125+02-.1403645+01-.1464002+01	.2047322+02-.1485908+01	1	68
-.1465200+01-.2333643+02-.4248495+01-.1300000+02	.7951146+01-.9484979+01	1	69
.3481782+00-.7012530+01-.8740396+01-.2043270+01	.5803022+01-.7552055+01	1	70
.3739485+01-.4341516+01-.6215017+01-.5425771+01	.2692728+01-.4718108+01	1	71
.7079448+01-.1014950+01-.3151185+01-.8704333+01	.1739040+00-.1448887+01	1	72
.1040166+02-.1032064+01-.9312502+01-.1217432+02	.1297430+01-.1106225+01	1	73
.1400624+02-.1451240+01-.1426908+01-.1608648+02	.1446772+01-.1468119+01	1	74
.1522655+02-.1501139+01-.1471564+01-.2046851+02	.1501541+01-.1471891+01	1	75
.2283172+02-.4605170+01-.1300000+02-.8138971+01	.9253055+01-.9434952+01	1	76
.7215739+01-.6309998+01-.1597730+01-.5897922+01	.6961926+01-.3293080+01	1	77
.4142931+01-.5364601+01-.4940126+01-.2277393+01	.3747135+01-.6560663+01	1	78
.6580624+00-.2119681+01-.8172965+01-.4277669+00	.5238619+00-.9867352+01	1	79
-.1081810+01-.7803937+00-.1163943+02-.1445936+01	.1375551+01-.1351125+02	1	80
-.1525799+01-.1480245+01-.1555147+02-.1534183+01	.1491097+01-.1769154+02	1	81
-.1534478+01-.1492177+01-.1493350+02-.1535064+01	.1492292+01-.2229671+02	1	82
.5010635+01-.1300000+02-.6935329+01-.8491041+01	.6124792+00-.5970627+01	1	83
.7206994+01-.1062101+01-.4706351+01-.5757540+01	.2717146+01-.3099672+01	1	84
.4134365+01-.4341273+01-.1445713+01-.2526570+01	.5954591+01-.2448693+01	1	85
.9753449+00-.7565213+01-.1047230+01-.4674050+00	.9259238+01-.1469864+01	1	86
-.1300010+01-.1103124+02-.1562069+01-.1502320+01	.1240305+02-.1575787+01	1	87
-.1527479+01-.1494327+02-.1577212+01-.1530300+01	.1708334+02-.1577379+01	1	88
-.1530630+01-.1932530+02-.1577397+01-.1530665+01	.2168851+02-.5416100+01	1	89
.1300000+02-.5180727+01-.7478646+01-.1164105+01	.4176575+01-.6184082+01	1	90
.4867079+00-.2768289+01-.4623784+01-.2116618+01	.1251613+01-.3036111+01	1	91
.3734917+01-.1729185+00-.1462366+01-.5346792+01	.1093581+01-.7983307+01	1	92
.6957098+01-.1406446+01-.1167303+01-.8651056+01	.1588684+01-.1508147+01	1	93
.1042305+02-.1606918+01-.1564139+01-.1229485+02	.1607736+01-.1572400+01	1	94
.1433508+02-.1608927+01-.1571481+01-.1647514+02	.1608970+01-.1571609+01	1	95
.1471710+02-.1608975+01-.1571623+01-.2108031+02	.5828946+01-.1300000+02	1	96
.3792634+01-.6572352+01-.1740561+01-.2461670+01	.5118160+01-.1187956+00	1	97
.1000047+01-.3554794+01-.1479000+01-.3410503+00	.1468523+01-.3116238+01	1	98
-.1156622+01-.4227822+00-.4727651+01-.1490286+01	.8491341+00-.6337856+01	1	99
-.1597956+01-.1451676+01-.8031793+01-.1624819+01	.1582330+01-.9803780+01	1	100
-.1629842+01-.1603320+01-.1167559+02-.1630745+01	.1606672+01-.1371581+02	1	101
-.1630867+01-.1607114+01-.1585587+02-.1630882+01	.1607167+01-.1809784+02	1	102
-.1630883+01-.1607173+01-.2046104+02-.6214608+01	.1300000+02-.1589647+01	1	103
.4595006+01-.2310049+01-.1902796+00-.3505698+01	.6938186+00-.8640382+00	1	104
.1986362+01-.4223643+00-.1385003+01-.4706520+00	.2538780+01-.1572553+01	1	105
-.8050238+00-.4149568+01-.1633822+01-.1560431+01	.5759373+01-.1650336+01	1	106
-.1652738+01-.7453302+01-.1653963+01-.1664976+01	.9225286+01-.1654712+01	1	107

AFWL-TR-67-131, Vol IV

.9728750+01	.1234250+02	.7543040+01	.8848430+01	.1375490+02	.6555760+01	1	43
.7920130+01	.1440460+02	.5393890+01	.6758310+01	.1613390+02	.4295350+01	1	44
.5671590+01	.1723630+02	.8419780+00	.1200000+02	.9348730+01	.1090860+02	1	45
.3354760+01	.9295870+01	.1082420+02	.4676200+01	.9224990+01	.1075320+02	1	46
.6067200+01	.4186660+01	.1064570+02	.7331270+01	.9109410+01	.1057910+02	1	47
.8758160+01	.8064840+01	.1024450+02	.1004090+02	.8232350+01	.9649590+01	1	48
.1149760+02	.7352940+01	.8770240+01	.1268760+02	.6237890+01	.7651430+01	1	49
.1342870+02	.5182510+01	.6577470+01	.1503640+02	.4024030+01	.5382670+01	1	50
.1624630+02	.2964380+01	.4286440+01	.1734610+02	.7466480+00	.1100000+02	1	51
.9286130+01	.1116600+02	.3648060+01	.4255550+01	.1102260+02	.6398360+01	1	52
.9141580+01	.1088120+02	.7711680+01	.8775840+01	.1049790+02	.9155450+01	1	53
.8127470+01	.9840040+01	.1041090+02	.7158890+01	.8845250+01	.1169640+02	1	54
.6186610+01	.7814360+01	.1282230+02	.5116610+01	.6634880+01	.1403630+02	1	55
.4131980+01	.5543950+01	.1513790+02	.3003040+01	.4343230+01	.1634240+02	1	56
.1957290+01	.3247600+01	.1744180+02	.6546770+00	.1200000+02	.9091340+01	1	57
.1141400+02	.3991670+01	.9086030+01	.1133850+02	.5290140+01	.8956630+01	1	58
.1117200+02	.6728250+01	.8623570+01	.1081750+02	.8037310+01	.7949440+01	1	59
.1010230+02	.9405550+01	.7136760+01	.9200630+01	.1057740+02	.6203770+01	1	60
.8074460+01	.1181230+02	.5353400+01	.6947740+01	.1292100+02	.4338080+01	1	61
.5798690+01	.1412480+02	.3336480+01	.4648800+01	.1523190+02	.2207420+01	1	62
.3443670+01	.1644120+02	.1147520+01	.2407540+01	.1754790+02	.5796340+00	1	63
.1000000+02	.8411900+01	.1112800+02	.7003190+01	.7843920+01	.1052470+02	1	64
.8258420+01	.7151220+01	.4578650+01	.9553040+01	.6453770+01	.8567580+01	1	65
.1068490+02	.5658410+01	.7343740+01	.1140260+02	.4787100+01	.6301950+01	1	66
.1300640+02	.3743420+01	.5044480+01	.1421620+02	.2743520+01	.4013600+01	1	67
.1532160+02	.1636570+01	.2876470+01	.1653630+02	.6923730+00	.1977160+01	1	68
.1765880+02	.5055260+00	.1100000+02	.8449850+01	.1174450+02	.4510290+01	1	69
.7847130+01	.1091510+02	.7202060+01	.7321980+01	.1011930+02	.8402480+01	1	70
.6724550+01	.9648860+01	.4655220+01	.6114710+01	.7940230+01	.1077080+02	1	71
.5245430+01	.6794690+01	.1148330+02	.4356230+01	.5710530+01	.1308820+02	1	72
.3316300+01	.4546190+01	.1430180+02	.2372590+01	.3575560+01	.1541510+02	1	73
.1440560+01	.2744600+01	.1664680+02	.7443740+00	.2291490+01	.1778830+02	1	74
.1485000+00	.1200000+02	.5554270+01	.8800270+01	.2639180+01	.5530400+01	1	75
.8794800+01	.1449540+01	.5530650+01	.8780490+01	.5111400+00	.5529220+01	1	76
.8704260+01	.1221150+01	.5522310+01	.8668260+01	.3287660+01	.5497860+01	1	77
.8564740+01	.5277140+01	.5421270+01	.8157450+01	.7528700+01	.5280340+01	1	78
.7723060+01	.4611540+01	.5032400+01	.7267570+01	.1186450+02	.4001510+01	1	79
.6155490+01	.1564140+02	.1444100+01	.4084830+01	.1838410+02	.2761660+00	1	80
.1744700+01	.2074460+02	.4531020+01	.1200000+02	.7529830+01	.1032580+02	1	81
.5742130+00	.7472330+01	.1030430+02	.6451280+00	.7469890+01	.1029910+02	1	82
.1678490+01	.7454080+01	.1022710+02	.3459440+01	.7420930+01	.1015460+02	1	83
.5547570+01	.7322110+01	.1003660+02	.7513950+01	.7073400+01	.9584220+01	1	84
.9642880+01	.6622760+01	.8418990+01	.1144130+02	.5810370+01	.7965750+01	1	85
.1313510+02	.3626240+01	.5706760+01	.1573670+02	.1255120+01	.3295790+01	1	86
.1807910+02	.9188930+00	.9637120+00	.2038910+02	.3220830+00	.1200000+02	1	87
.9032810+01	.1124770+02	.8046480+00	.8429900+01	.1120990+02	.2087580+01	1	88
.8414980+01	.1119250+02	.3147340+01	.8860680+01	.1110850+02	.4933130+01	1	89
.8700430+01	.1043740+02	.6944490+01	.8352600+01	.1060610+02	.8707770+01	1	90
.7641500+01	.4784140+01	.1042440+02	.6703990+01	.8725050+01	.1176820+02	1	91
.5516970+01	.7446780+01	.1308330+02	.3132480+01	.5012700+01	.1543820+02	1	92
.1137720+01	.2731360+01	.1777700+02	.2835610+00	.1043290+01	.2028190+02	1	93
.4054650+00	.1200000+02	.9524570+01	.1150280+02	.1203300+01	.9399650+01	1	94
.1145230+02	.2446170+01	.9373490+01	.1142370+02	.3557940+01	.9282090+01	1	95
.1130570+02	.5323940+01	.7031940+01	.1104720+02	.7262640+01	.8543730+01	1	96
.1061020+02	.8702490+01	.7663760+01	.9703790+01	.1046660+02	.6645810+01	1	97

-1666424+01	.1109704+02	-1654447+01	-1667123+01	.1313732+02	-1654465+01	1	108
-1667162+01	.1527736+02	-1654668+01	-1667166+01	.1751934+02	-1654668+01	1	109
-1667167+01	.1968235+02	.6551060+01	.1300000+02	.9811038+00	.3477809+01	1	110
-2610581+01	.3245622+00	.2483039+01	-1196969+01	-1144306+01	.9575803+00	1	111
.4161725+00	-1442607+01	-4467701+00	.2034184+01	-1608714+01	-1362880+01	1	112
.3644444+01	-1643224+01	-1619234+01	.5254670+01	-1652509+01	-1668419+01	1	113
.6948594+01	-1654377+01	-1666048+01	.8720578+01	-1654788+01	-1666994+01	1	114
.1054234+02	-1654657+01	-1667144+01	.1263261+02	-1654867+01	-1667164+01	1	115
.1477267+02	-1654668+01	-1667166+01	.1701463+02	-1654868+01	-1667167+01	1	116
.1937744+02	.6907755+01	.1300000+02	.3548880+00	.3312256+01	-3343034+01	1	117
-7637474+00	.1747548+01	-1730651+01	-1344617+01	.2868728+00	-1165580+00	1	118
-1361305+01	-4606714+00	.1494243+01	-1624440+01	.1529064+01	.3109888+01	1	119
-1644444+01	-1644459+01	.4719661+01	-1653609+01	-1663947+01	.6413582+01	1	120
-1654416+01	-1666617+01	.8185566+01	-1654826+01	-1647081+01	.1005737+02	1	121
-1654461+01	-1667154+01	.1204754+02	-1654865+01	-1667164+01	.1423746+02	1	122
-1654866+01	-1667165+01	.1647462+02	-1654866+01	-1667165+01	.1884213+02	1	123
.7313220+01	.1300000+02	-2746854+00	.2944257+01	.3949597+01	-1122217+01	1	124
.1017455+01	-2338177+01	-1482458+01	-4054657+00	.7203992+00	-1605455+01	1	125
-1336598+01	.8910951+00	-1642263+01	-1614149+01	.2501701+01	-1652002+01	1	126
-1658944+01	.4111466+01	-1654244+01	-1665732+01	.5805385+01	-1654753+01	1	127
-1666920+01	.7577368+01	-1654444+01	-1667126+01	.9449175+01	-1654864+01	1	128
-1667154+01	.1144440+02	-1654866+01	-1667163+01	.1362446+02	-1654866+01	1	129
-1667164+01	.1587142+02	-1654866+01	-1667164+01	.1423463+02	.7718685+01	1	130
.1300000+02	.7746801+00	.2131243+01	-4556854+01	-1346416+01	.6281147+00	1	131
-2937205+01	-1562498+01	-7060533+00	-1328497+01	-1629466+01	-1423834+01	1	132
.2824274+00	-1644458+01	-1615274+01	.1843511+01	-1653265+01	-1650901+01	1	133
.3503269+01	-1654337+01	-1657681+01	.5147188+01	-1654581+01	-1658955+01	1	134
.6944717+01	-1654625+01	-1654176+01	.8840977+01	-1654632+01	-1659211+01	1	135
.1088120+02	-1654633+01	-1654216+01	.1302127+02	-1654633+01	-1659217+01	1	136
.1526323+02	-1654633+01	-1654217+01	.1762643+02	.8131331+01	.1300000+02	1	137
-1136645+01	.1411246+01	-5175574+01	-1444684+01	.4323655+01	-3556310+01	1	138
-1606208+01	-1125622+01	.1447704+01	-1641638+01	-1545066+01	-3363215+00	1	139
-1651078+01	-1655783+01	.1274247+01	-1654289+01	-1652680+01	.2844003+01	1	140
-1653440+01	-1656086+01	.4577420+01	-1653952+01	-1656724+01	.6349903+01	1	141
-1653972+01	-1656635+01	.6221710+01	-1653976+01	-1656853+01	.1026193+02	1	142
-1653976+01	-1656855+01	.1240200+02	-1653976+01	-1656855+01	.1464396+02	1	143
-1653976+01	-1656855+01	.1700717+02	.8517193+01	.1300000+02	-1351202+01	1	144
.6007740+00	.5753772+01	-1561693+01	-6438304+00	.4134710+01	-1628701+01	1	145
-1346375+01	-2525164+01	-1647651+01	-1606739+01	.9140043+00	-1652521+01	1	146
-1647222+01	.6957561+00	-1653544+01	-1654902+01	.2305504+01	-1653867+01	1	147
-1656677+01	.3944427+01	-1653920+01	-1656772+01	.5771404+01	-1653929+01	1	148
-1656623+01	.7643216+01	-1653931+01	-1656831+01	.9683437+01	-1653931+01	1	149
-1656832+01	.1182350+02	-1653931+01	-1656832+01	.1406546+02	-1653931+01	1	150
-1656832+01	.1642867+02	.8853665+01	.1300000+02	-1469203+01	.7174263+01	1	151
.6258327+01	.1594601+01	-1048626+01	-4639365+01	-1639621+01	-1524894+01	1	152
-3024452+01	-1650545+01	-1632057+01	-1414506+01	-1653226+01	-1652020+01	1	153
.1410444+00	-1653451+01	-1655938+01	.1800802+01	-1653993+01	-1656738+01	1	154
.3444718+01	-1654020+01	-1656847+01	.5264701+01	-1654023+01	-1656913+01	1	155
.7138508+01	-1654026+01	-1656918+01	.9178729+01	-1654026+01	-1656918+01	1	156
.1131880+02	-1654026+01	-1656918+01	.1356076+02	-1654026+01	-1656918+01	1	157
.1592397+02	.9210340+01	.1300000+02	-1544449+01	.9043990+00	.6793243+01	1	158
-1623576+01	-1334692+01	-5174340+01	-1644334+01	-1593920+01	-3564851+01	1	159
-1652254+01	-1644907+01	-1954514+01	-1653520+01	-1654418+01	-3436821+00	1	160
-1653844+01	-1656343+01	.1265861+01	-1653913+01	-1656734+01	.2959786+01	1	161
-1653926+01	-1656809+01	.4731688+01	-1653929+01	-1656821+01	.6483495+01	1	162

-1653929+01-1656823+01 .6643717+01-1653929+01-1656824+01 .1078378+02 1 163
 -1653929+01-1656824+01 .1302574+02-1653929+01-1656824+01 .1538895+02 1 164
 1
 DIANE/HUSCT CH2 TEMP(100--2250.) 11 FREQ. C(MY 11/18/66) 666666
 .1100000+02 .3690000+03
 2101. .9000000+01
 .4605170+01 .1300000+02 .8141120+01 .4255235+01-.9223911-01 .7217855+01 1 1
 .8312240+01 .1599846+01 .5900038+01 .6963847+01 .3295202+01 .4145062+01 1 2
 .5366708+01 .4942250+01 .2279475+01 .3749276+01 .6562787+01 .6607235+00 1 3
 .2121840+01 .8175064+01-.425620-00 .5280170-00 .9869477+01-.1116107+01 1 4
 .7796006+00 .1164155+02-.1756427+01-.1409819+01 .1351337+02-.2093079+01 1 5
 -1561425+01 .1555360+02-.2158862+01-.1584339+01 .1769366+02-.2167216+01 1 6
 -1586023+01 .1993562+02-.2168122+01-.1586301+01 .2229883+02 .5010635+01 1 7
 .1300030+02 .6937513+01 .6493206+01 .6103621+00 .5972797+01 .7209183+01 1 8
 .1064223+01 .4706512+01 .5759458+01 .2719270+01 .3101703+01 .4141502+01 1 9
 .4363397+01 .1446633+01 .2530654+01 .5956716+01-.5008338-01 .9774243+00 1 10
 .7567337+01-.1386410+01-.4763514+00 .4261363+01-.2498025+01-.1436071+01 1 11
 .1103337+02-.3030607+01-.1775142+01 .1290518+02-.3153392+01-.1839578+01 1 12
 .1494540+02-.3170638+01-.1847891+01 .1708546+02-.3172939+01-.1848876+01 1 13
 .1932743+02-.3173165+01-.1848982+01 .2149063+02 .5416100+01 .1300000+02 1 14
 .5190699+01 .7486610+01-.1161984+01 .4178742+01 .6186241+01 .4488317+00 1 15
 .2770430+01 .4625946+01 .2118743+01 .1249688+01 .3038255+01 .3737041+01 1 16
 -3092250+00 .1464217+01 .5348916+01-.1828863+01-.9629561-01 .6959222+01 1 17
 -3190589+01-.1382552+01 .6653181+01-.3946636+01-.2056854+01 .1042517+02 1 18
 -4241100+01-.2243291+01 .1229698+02-.4286029+01-.2276156+01 .1433720+02 1 19
 -4261203+01-.2265251+01 .1647727+02-.4261908+01-.2265765+01 .1871923+02 1 20
 -4261944+01-.2265620+01 .2108244+02 .5628946+01 .1300000+02 .3794797+01 1 21
 .6574512+01-.1738384+01 .2463812+01 .5120320+01-.1166717+00 .9235804+00 1 22
 .3556932+01 .1501984+01-.5446449+00 .1970396+01 .3118362+01-.2092635+01 1 23
 .4042366+00 .4729775+01-.3546841+01-.1041697+01 .6339981+01-.4693628+01 1 24
 -2167495+01 .8033918+01-.5210018+01-.2669362+01 .9805904+01-.5335049+01 1 25
 -2786580+01 .1167771+02-.5356370+01-.2808794+01 .1371793+02-.5359217+01 1 26
 -2611490+01 .1585600+02-.5354557+01-.2811812+01 .1809996+02-.5359594+01 1 27
 -2811847+01 .2046317+02 .6214608+01 .1300000+02 .1590884+01 .4597159+01 1 28
 -2307926+01 .1213330+00 .3507839+01-.6916947+00-.1398863+01 .1987185+01 1 29
 .9244886+00-.2443817+01 .4400450+00 .2540904+01-.4464832+01-.1090981+01 1 30
 .4151642+01-.5953677+01-.2888080+01 .5761448+01-.7060874+01-.3685480+01 1 31
 .7455426+01-.7539738+01-.4273222+01 .4227411+01-.7652541+01-.4359060+01 1 32
 .1109922+02-.7671627+01-.4373352+01 .1313944+02-.7674172+01-.4375252+01 1 33
 .1527431+02-.7674475+01-.4375474+01 .1752147+02-.7674508+01-.4375503+01 1 34
 .1984688+02 .6551080+01 .1300000+02 .4732505+00 .3479462+01-.2408457+01 1 35
 -5210770+00 .4485029+01-.1194445+01-.2056944+01 .9409176+00 .4282444+00 1 36
 -3610292+01-.5478478+00 .2036308+01-.5137596+01-.2104471+01 .3647004+01 1 37
 -6467034+01-.3363734+01 .5256795+01-.7315094+01-.4045726+01 .6950719+01 1 38
 -7603467+01-.4322001+01 .8722703+01-.7663241+01-.4367080+01 .1059451+02 1 39
 -7673039+01-.4374406+01 .1263473+02-.7674338+01-.4375376+01 .1477480+02 1 40
 -7674493+01-.4375491+01 .1701676+02-.7674510+01-.4375504+01 .1937997+02 1 41
 .6907755+01 .1300000+02 .3076184+00 .3314401+01-.3340930+01-.1208680+01 1 42
 .1798509+01-.1726527+01-.2754114+01 .2550062+00-.1144337+00-.4300100+01 1 43
 -1281902+01 .1501368+01-.5769447+01-.2713524+01 .3112012+01-.6908825+01 1 44
 -3755579+01 .4721785+01-.7482219+01-.4228566+01 .6415707+01-.7639063+01 1 45
 -4348910+01 .8187690+01-.7668973+01-.4371351+01 .1005950+02-.7673790+01 1 46
 -4374949+01 .1209972+02-.7674427+01-.4375424+01 .1423979+02-.7674503+01 1 47
 -4375481+01 .1448175+02-.7674511+01-.4375487+01 .1884495+02 .7313220+01 1 48
 .1300000+02-.4606728+00 .2546276+01-.3947473+01-.1995470+01 .1012377+01 1 49

AFWL-TR-67-131, Vol IV

-0.2330053+01	-0.3535564+01	-0.5234932+00	-0.7142746+00	-0.5064297+01	-0.2032991+01	1	50
-0.6432198+00	-0.6400090+01	-0.3310059+01	-0.2503026+01	-0.7261214+01	-0.4051927+01	1	51
-0.4113590+01	-0.7564432+01	-0.4307470+01	-0.5407510+01	-0.7658601+01	-0.4363562+01	1	52
-0.7574493+01	-0.7672046+01	-0.4373621+01	-0.9451300+01	-0.7674191+01	-0.4375222+01	1	53
-0.1149152+02	-0.7674474+01	-0.4375434+01	-0.1363159+02	-0.7674507+01	-0.4375459+01	1	54
-0.1507355+02	-0.7674511+01	-0.4375461+01	-0.1823676+02	-0.7718685+01	-0.1300000+02	1	55
-0.1237993+01	-0.2132551+01	-0.4554730+01	-0.2704603+01	-0.0059457+00	-0.2935001+01	1	56
-0.4316760+01	-0.9468254+00	-0.1326373+01	-0.5784074+01	-0.2407184+01	-0.2450520+00	1	57
-0.6416376+01	-0.3526004+01	-0.1895035+01	-0.7464484+01	-0.4004777+01	-0.3405394+01	1	58
-0.7633473+01	-0.4222770+01	-0.5149312+01	-0.7667410+01	-0.4255354+01	-0.6971295+01	1	59
-0.7673415+01	-0.4261113+01	-0.6843102+01	-0.7674368+01	-0.4262027+01	-0.1086332+02	1	60
-0.7674474+01	-0.4262148+01	-0.1302339+02	-0.7674509+01	-0.4262162+01	-0.1526535+02	1	61
-0.7674511+01	-0.4262164+01	-0.1762656+02	-0.0000000	-0.0000000	-0.0000000	1	62
1100302							
DIANE CARBON PHENOLIC 30 -- 12 FREQUENCIES -- JANUARY 21, 1966							
0.1200000+02 0.6740000+03							
1115. 2300000E+02							
-0.204597+01	0.1200000+02	-0.136575+02	-0.113948+02	0.219988+01	-0.133496+02	13	1
-0.109345+02	0.324905+01	-0.127887+02	-0.104309+02	0.450361+01	-0.122718+02	13	2
-0.997183+01	0.560274+01	-0.116986+02	-0.946917+01	0.640729+01	-0.111605+02	13	3
-0.401040+01	0.790045+01	-0.105796+02	-0.850798+01	0.911107+01	-0.100325+02	13	4
-0.804850+01	0.102103+02	-0.942302+01	-0.754303+01	0.114151+02	-0.845909+01	13	5
-0.707876+01	0.125146+02	-0.823169+01	-0.656533+01	0.137198+02	-0.765227+01	13	6
-0.608993+01	0.148197+02	-0.175829+01	-0.120000+02	-0.607132+01	-0.442256+01	13	7
-0.249037+01	-0.553985+01	-0.397303+01	0.358998+01	-0.496303+01	-0.347077+01	13	8
0.479520+01	-0.444311+01	-0.300289+01	0.589512+01	-0.368181+01	-0.247878+01	13	9
0.710082+01	-0.337793+01	-0.196934+01	0.820136+01	-0.283584+01	-0.144082+01	13	10
0.940799+01	-0.235059+01	-0.929464+00	0.105097+02	-0.142886+01	-0.358973+00	13	11
0.117102+02	-0.136165+01	0.168169+00	0.128223+02	-0.858349+00	0.748987+00	13	12
0.140343+02	-0.407117+00	0.127705+01	0.151428+02	-0.153515+01	0.120000+02	13	13
-0.181804+01	0.353035+00	0.271882+01	-0.135079+01	0.806072+00	0.381980+01	13	14
-0.843081+00	0.130977+01	0.502709+01	-0.383324+00	0.177352+01	0.612968+01	13	15
0.116294+00	0.228282+01	0.733951+01	0.568055+00	0.274381+01	0.844535+01	13	16
0.105789+01	0.324177+01	0.966007+01	0.149850+01	0.368758+01	0.107719+02	13	17
0.197323+01	0.417188+01	0.119957+02	0.239811+01	0.462109+01	0.131195+02	13	18
0.285590+01	0.514010+01	0.143642+02	0.326785+01	0.565262+01	0.155202+02	13	19
-0.135282+01	0.120000+02	0.971356+00	0.330760+01	0.291064+01	0.142425+01	13	20
0.374915+01	0.401489+01	0.191656+01	0.422848+01	0.522730+01	0.235832+01	13	21
0.463637+01	0.033648+01	0.283512+01	0.511573+01	0.755649+01	0.326465+01	13	22
0.553122+01	0.867561+01	0.373412+01	0.549586+01	0.941220+01	0.416738+01	13	23
0.644336+01	0.110558+02	0.465357+01	0.647255+01	0.123367+02	0.510761+01	13	24
0.748907+01	0.135423+02	0.559730+01	0.806070+01	0.149067+02	0.599197+01	13	25
0.852487+01	0.161661+02	-0.119867+01	0.120000+02	0.310212+01	0.527163+01	13	26
0.308103+01	0.354197+01	0.568870+01	0.419167+01	0.401811+01	0.613751+01	13	27
0.541433+01	0.444976+01	0.654419+01	0.653761+01	0.492879+01	0.699982+01	13	28
0.778218+01	0.537945+01	0.743695+01	0.843833+01	0.589397+01	0.794692+01	13	29
0.104221+02	0.637343+01	0.842857+01	0.114790+02	0.686428+01	0.892094+01	13	30
0.128848+02	0.714904+01	0.924402+01	0.141826+02	0.735297+01	0.738730+01	13	31
0.156032+02	0.718397+01	0.920479+01	0.168997+02	-0.106514+01	0.120000+02	13	32
0.476175+01	0.665252+01	0.324373+01	0.519480+01	0.705813+01	0.436342+01	13	33
0.568395+01	0.750847+01	0.560753+01	0.613903+01	0.793210+01	0.676370+01	13	34
0.665812+01	0.841838+01	0.806451+01	0.714315+01	0.887331+01	0.931499+01	13	35
0.763507+01	0.932704+01	0.107481+02	0.743656+01	0.956432+01	0.120860+02	13	36
0.794764+01	0.954129+01	0.135349+02	0.753889+01	0.909540+01	0.148061+02	13	37
0.863836+01	0.818803+01	0.161031+02	0.560523+01	0.717292+01	0.172301+02	13	38

-0.947354+00	0.120000+02	0.604380+01	0.771608+01	0.340067+01	0.634483+01	13	39
0.413224+01	0.454713+01	0.705661+01	0.860658+01	0.543656+01	0.754024+01	13	40
0.905061+01	0.706323+01	0.805312+01	0.951778+01	0.848686+01	0.840709+01	13	41
0.982224+01	0.944741+01	0.846364+01	0.941991+01	0.113257+02	0.807464+01	13	42
0.934621+01	0.126046+02	0.721224+01	0.852134+01	0.139094+02	0.620557+01	13	43
0.752549+01	0.150417+02	0.502751+01	0.635772+01	0.162580+02	0.393519+01	13	44
0.527116+01	0.173604+02	-0.841948+00	0.120000+02	0.719666+01	0.861668+01	13	45
0.357480+01	0.766722+01	0.905553+01	0.476625+01	0.814388+01	0.954587+01	13	46
0.614010+01	0.863231+01	0.944447+01	0.747760+01	0.869534+01	0.101692+02	13	47
0.844383+01	0.872942+01	0.947211+01	0.103225+02	0.805695+01	0.929136+01	13	48
0.116730+02	0.714357+01	0.838486+01	0.128244+02	0.600760+01	0.725470+01	13	49
0.140502+02	0.442441+01	0.618110+01	0.151620+02	0.373360+01	0.499878+01	13	50
0.163701+02	0.264240+01	0.393828+01	0.174734+02	-0.746688+00	0.120000+02	13	51
0.812018+01	0.942456+01	0.377444+01	0.860317+01	0.987715+01	0.504541+01	13	52
0.906072+01	0.103104+02	0.653147+01	0.923659+01	0.104683+02	0.792563+01	13	53
0.843734+01	0.101630+02	0.936444+01	0.824224+01	0.947802+01	0.105772+02	13	54
0.721473+01	0.845745+01	0.118336+02	0.617394+01	0.742056+01	0.124446+02	13	55
0.444425+01	0.625188+01	0.141616+02	0.340404+01	0.514594+01	0.152664+02	13	56
0.272252+01	0.407424+01	0.164014+02	0.164210+01	0.308084+01	0.175440+02	13	57
-0.654677+00	0.120000+02	0.441675+01	0.101446+02	0.403121+01	0.933447+01	13	58
0.105553+02	0.538873+01	0.452706+01	0.107467+02	0.442328+01	0.925170+01	13	59
0.104740+02	0.824007+01	0.844163+01	0.974009+01	0.956845+01	0.756207+01	13	60
0.881772+01	0.107152+02	0.643161+01	0.764074+01	0.119396+02	0.536334+01	13	61
0.663764+01	0.130475+02	0.418344+01	0.550705+01	0.142626+02	0.310807+01	13	62
0.450050+01	0.153751+02	0.142634+01	0.338038+01	0.165445+02	0.453707+00	13	63
0.233319+01	0.177054+02	-0.579634+00	0.120000+02	0.455711+01	0.107444+02	13	64
0.432740+01	0.979184+01	0.104063+02	0.573466+01	0.457177+01	0.107830+02	13	65
0.720078+01	0.842450+01	0.101646+02	0.842688+01	0.744615+01	0.920020+01	13	66
0.464314+01	0.643347+01	0.814012+01	0.108147+02	0.578274+01	0.705384+01	13	67
0.120320+02	0.471776+01	0.603317+01	0.131446+02	0.354728+01	0.492041+01	13	68
0.143653+02	0.248523+01	0.588744+01	0.154774+02	0.136516+01	0.277544+01	13	69
0.160461+02	0.437576+00	0.188544+01	0.178134+02	-0.505526+00	0.120000+02	13	70
0.100046+02	0.111643+02	0.463195+01	0.944416+01	0.111134+02	0.600249+01	13	71
0.935571+01	0.105654+02	0.737766+01	0.851075+01	0.974791+01	0.854964+01	13	72
0.744403+01	0.867786+01	0.978014+01	0.641673+01	0.765504+01	0.109038+02	13	73
0.526743+01	0.653944+01	0.121253+02	0.421427+01	0.551619+01	0.132397+02	13	74
0.308447+01	0.434774+01	0.144567+02	0.212434+01	0.344902+01	0.155726+02	13	75
0.121187+01	0.264014+01	0.168014+02	0.558886+00	0.219066+01	0.174383+02	13	76
-0.436533+00	0.120000+02	0.102458+02	0.113584+02	0.448868+01	0.986854+01	13	77
0.110192+02	0.618534+01	0.903754+01	0.102446+02	0.750002+01	0.811375+01	13	78
0.932218+01	0.864426+01	0.702443+01	0.822335+01	0.487402+01	0.600634+01	13	79
0.720748+01	0.104413+02	0.487529+01	0.608819+01	0.122133+02	0.387652+01	13	80
0.906027+01	0.133262+02	0.287980+01	0.412318+01	0.145487+02	0.211229+01	13	81
0.350046+01	0.156734+02	0.147945+01	0.311336+01	0.164243+02	0.108469+01	13	82
0.288733+01	0.180404+02	-0.371445+00	0.120000+02	0.102861+02	0.113649+02	13	83
0.507683+01	0.966523+01	0.108173+02	0.631540+01	0.872091+01	0.990447+01	13	84
0.754334+01	0.778304+01	0.844242+01	0.872606+01	0.670423+01	0.783835+01	13	85
0.995684+01	0.569835+01	0.682010+01	0.110731+02	0.463374+01	0.574291+01	13	86
0.124433+02	0.375642+01	0.440842+01	0.134093+02	0.245645+01	0.429604+01	13	87
0.144427+02	0.241458+01	0.348462+01	0.157851+02	0.200534+01	0.375944+01	13	88
0.170652+02	0.167726+01	0.344967+01	0.182627+02	-0.148500+00	0.120000+02	13	89
0.995427+01	0.880027+01	-0.263918+01	0.553090+01	0.779468+01	-0.149959+01	13	90
0.354065+01	0.878049+01	-0.511140+00	0.552922+01	0.870426+01	0.122115+01	13	91
0.254201+01	0.866326+01	0.328766+01	0.549786+01	0.856047+01	0.527719+01	13	92
0.842127+01	0.816743+01	0.752870+01	0.528034+01	0.772306+01	0.961154+01	13	93

0.503290+01	0.726757+01	0.118645+02	0.400151+01	0.615549+01	0.156419+02	13	94
0.199910+01	0.408483+01	0.103841+02	0.276166+00	0.174470+01	0.207446+02	13	95
0.953102+01	0.120000+02	0.752983+01	0.103258+02	0.574213+00	0.747233+01	13	96
0.103093+02	0.645128+00	0.746909+01	0.102991+02	0.167849+01	0.745908+01	13	97
0.102271+02	0.345944+01	0.742093+01	0.101546+02	0.554757+01	0.732211+01	13	98
0.100366+02	0.751395+01	0.707340+01	0.958422+01	0.964288+01	0.62276+01	13	99
0.091099+01	0.114413+02	0.581037+01	0.796576+01	0.131351+02	0.362624+01	13	100
0.570670+01	0.157307+02	0.125512+01	0.329579+01	0.140791+02	0.918892+00	13	101
0.963714+00	0.703091+02	0.322003+00	0.120003+02	0.983281+01	0.112477+02	13	102
0.009048+00	0.092990+01	0.112100+02	0.200754+01	0.851400+01	0.111925+02	13	103
0.314734+01	0.080060+01	0.111005+02	0.493313+01	0.870093+01	0.109374+02	13	104
0.094449+01	0.035600+01	0.106061+02	0.070777+01	0.764150+01	0.070019+01	13	105
0.104244+02	0.070377+01	0.077000+01	0.117000+02	0.541007+01	0.794070+01	13	106
0.130033+02	0.313540+01	0.500170+01	0.154302+02	0.113770+01	0.273147+01	13	107
0.177700+02	0.035500+00	0.100330+01	0.202611+02	0.405405+00	0.170000+02	13	108
0.952470+01	0.117000+01	0.120330+01	0.939005+01	0.114000+02	0.240617+01	13	109
0.937347+01	0.114737+02	0.355724+01	0.920000+01	0.113007+02	0.543000+01	13	110
0.903174+01	0.110472+02	0.700000+01	0.054373+01	0.106102+02	0.000249+01	13	111
0.700370+01	0.970300+01	0.104000+02	0.000001+01	0.854020+01	0.117102+02	13	112
0.541052+01	0.722421+01	0.129043+02	0.314642+01	0.444242+01	0.153273+02	13	113
0.150500+01	0.284336+01	0.177419+02	0.158127+00	0.137564+01	0.203920+02	13	114
0.010930+00	0.120000+02	0.111764+02	0.120240+02	0.732479+01	0.109497+02	13	115
0.110027+02	0.360017+01	0.107004+02	0.117258+02	0.450525+01	0.104007+02	13	116
0.113000+02	0.610000+01	0.973234+01	0.107621+02	0.759420+01	0.894476+01	13	117
0.100051+02	0.883037+01	0.803390+01	0.902013+01	0.101201+02	0.722713+01	13	118
0.014985+01	0.113042+02	0.629121+01	0.727798+01	0.126643+02	0.405053+01	13	119
0.539541+01	0.152907+02	0.170027+01	0.309798+01	0.176452+02	0.260390+00	13	120
0.902923+00	0.200469+02	0.122378+01	0.120000+02	0.116709+02	0.119566+02	13	121
0.249703+01	0.114644+02	0.118020+02	0.370325+01	0.112510+02	0.116642+02	13	122
0.458443+01	0.107637+02	0.114520+02	0.542708+01	0.947281+01	0.111477+02	13	123
0.733719+01	0.904060+01	0.105118+02	0.862645+01	0.793000+01	0.949754+01	13	124
0.100134+02	0.694642+01	0.840385+01	0.112200+02	0.545388+01	0.722080+01	13	125
0.125005+02	0.410368+01	0.523286+01	0.149984+02	0.143531+01	0.312335+01	13	126
0.174637+02	0.110363+00	0.984948+00	0.148482+02	0.160944+01	0.120000+02	13	127
0.116065+02	0.119011+02	0.243577+01	0.114515+02	0.117872+02	0.359210+01	13	128
0.112599+02	0.117019+02	0.444727+01	0.107377+02	0.115150+02	0.577175+01	13	129
0.101232+02	0.111343+02	0.717862+01	0.947308+01	0.104691+02	0.842253+01	13	130
0.846387+01	0.946533+01	0.977002+01	0.741178+01	0.842660+01	0.109866+02	13	131
0.617425+01	0.720249+01	0.122843+02	0.349376+01	0.498233+01	0.147431+02	13	132
0.164847+01	0.281761+01	0.171695+02	0.508471+00	0.561163+00	0.194975+02	13	133
0.144591+01	0.120000+02	0.112437+02	0.117122+02	0.230915+01	0.111748+02	13	134
0.115430+02	0.342479+01	0.110943+02	0.115196+02	0.426020+01	0.108623+02	13	135
0.114481+02	0.556478+01	0.102725+02	0.109867+02	0.696129+01	0.943752+01	13	136
0.102131+02	0.820221+01	0.831713+01	0.912260+01	0.452901+01	0.727135+01	13	137
0.800579+01	0.107256+02	0.596144+01	0.672418+01	0.120151+02	0.320889+01	13	138
0.435367+01	0.143811+02	0.645849+00	0.184088+01	0.166924+02	0.109768+01	13	139
-0.318405+00	0.189958+02	0.230259+01	0.120000+02	0.104956+02	0.113661+02	13	140
0.210518+01	0.104768+02	0.112748+02	0.319621+01	0.104260+02	0.112125+02	13	141
0.401383+01	0.102090+02	0.110192+02	0.529139+01	0.970243+01	0.103961+02	13	142
0.666142+01	0.891237+01	0.945323+01	0.788132+01	0.769139+01	0.816482+01	13	143
0.917702+01	0.637180+01	0.643233+01	0.103195+02	0.487068+01	0.560538+01	13	144
0.115433+02	0.223845+01	0.315921+01	0.138547+02	0.152030+02	0.833605+00	13	145
0.161582+02	0.135894+01	0.107036+01	0.184609+02	0.	0.	13	146

21

DIANE/SCAT PE-10A THETA(50-10000) 10 FREQ C1/FCT 5-24-67 TRT 2

AFWL-TR-67-131, Vol IV

[illegible]

.1917503+02	.6907755+01	.1300000+02	.3725065+01	.5435707+01	.3679116+01	1	54
.2051384+01	.4381942+01	.2024713+01	.1327015+01	.2869385+01	.3990723+00	1	55
.7584403+01	.1624985+01	.1236838+01	.8025696+00	.8378091+00	.2676612+01	1	56
-.1295362+01	.2334530+00	.4505580+01	.1550191+01	.1186190+01	.6208495+01	1	57
-.1633825+01	.1567657+01	.7982347+01	.1669235+01	.1653883+01	.9854495+01	1	58
-.1681638+01	.1665136+01	.1189477+02	.1682185+01	.1665718+01	.1403484+02	1	59
-.1682217+01	.1665769+01	.1627681+02	.1682220+01	.1665775+01	.1664002+02	1	60
.7313220+01	.1300000+02	.3681182+01	.4951708+01	.4245947+01	.2544650+01	1	61
.3921744+01	.2607399+01	.1184365+01	.2789684+01	.9584138+00	.8020773+01	1	62
.1533142+01	.6771695+00	.9108178+00	.1777708+00	.2296321+01	.1332408+01	1	63
-.9725557+00	.3908173+01	.1567681+01	.1521999+01	.5602480+01	.1656801+01	1	64
-.1643980+01	.7374538+01	.1666574+01	.1655932+01	.9246358+01	.1667097+01	1	65
-.1658994+01	.1128658+02	.1667106+01	.1657134+01	.1342665+02	.1667174+01	1	66
-.1657151+01	.1568881+02	.1667175+01	.1657153+01	.1803182+02	.7718685+01	1	67
.1300000+02	.3434660+01	.4477437+01	.4813459+01	.2384009+01	.3350264+01	1	68
-.3172125+01	.1041621+01	.2028096+01	.1540367+01	.2608444+00	.3503298+00	1	69
.7875086+01	.1138181+01	.7392630+00	.1690550+01	.1532868+01	.1445300+01	1	70
.3300495+01	.1630317+01	.1613965+01	.4994380+01	.1642399+01	.1635316+01	1	71
.6766357+01	.1644048+01	.1638430+01	.8638163+01	.1644230+01	.1638852+01	1	72
.1067638+02	.1644252+01	.1638904+01	.1281845+02	.1644255+01	.1638910+01	1	73
.1506041+02	.1644255+01	.1638911+01	.1742362+02	.7824046+01	.1300000+02	1	74
.3148950+01	.4231933+01	.4962668+01	.2139645+01	.3117332+01	.3323589+01	1	75
.6725585+00	.1668657+01	.1695946+01	.5658286+00	.1828393+00	.7867086+01	1	76
-.1318618+01	.9992015+00	.1532644+01	.1582404+01	.1524972+01	.3142482+01	1	77
-.1632921+01	.1620459+01	.4836345+01	.1638828+01	.1632413+01	.6608317+01	1	78
-.1639696+01	.1634258+01	.8480122+01	.1639836+01	.1634551+01	.1052034+02	1	79
-.1639854+01	.1634590+01	.1266041+02	.1639856+01	.1634595+01	.1490237+02	1	80
-.1639857+01	.1634595+01	.1726558+02	.7919356+01	.1300000+02	.2818471+01	1	81
.4042120+01	.5998813+01	.1867473+01	.2860179+01	.3462311+01	.4339414+00	1	82
.1390718+01	.1837432+01	.7742124+00	.3475340+01	.2212707+00	.1405867+01	1	83
-.1164274+01	.1389757+01	.1600556+01	.1563250+01	.2999533+01	.1633103+01	1	84
-.1626059+01	.4693382+01	.1636732+01	.1634869+01	.6465353+01	.1637099+01	1	85
-.1635937+01	.8337157+01	.1637152+01	.1636107+01	.1037738+02	.1637165+01	1	86
-.1636129+01	.1251744+02	.1637166+01	.1636132+01	.1475940+02	.1637166+01	1	87
-.1636132+01	.1712261+02	.8006368+01	.1300000+02	.2623025+01	.3985130+01	1	88
-.5225466+01	.1538447+01	.2678432+01	.3589826+01	.1738024+00	.1189429+01	1	89
-.1966980+01	.9422789+00	.2668694+00	.3515544+00	.1465790+01	.1265443+01	1	90
.1259290+01	.1608668+01	.1577064+01	.2869026+01	.1631576+01	.1625380+01	1	91
.4562867+01	.1634396+01	.1631971+01	.6334836+01	.1634904+01	.1633117+01	1	92
.6206640+01	.1634985+01	.1635299+01	.1024686+02	.1634996+01	.1633323+01	1	93
.1238693+02	.1634997+01	.1635326+01	.1462889+02	.1634998+01	.1633326+01	1	94
.1699210+02	.8131531+01	.1300000+02	.2119519+01	.3747992+01	.5406350+01	1	95
.9914579+00	.2343812+01	.3774363+01	.2815460+00	.8397392+00	.2153749+01	1	96
-.1168233+01	.5376478+00	.5398077+00	.1528238+01	.1373534+01	.1071595+01	1	97
-.1015750+01	.1590237+01	.2881291+01	.1638370+01	.1624227+01	.4375124+01	1	98
-.1632622+01	.1627256+01	.6147077+01	.1632770+01	.1627011+01	.8811887+01	1	99
-.1632633+01	.1629967+01	.1005912+02	.1632640+01	.1629985+01	.1219918+02	1	100
-.1632641+01	.1629967+01	.1444114+02	.1632641+01	.1629987+01	.1680435+02	1	101
.8517193+01	.1000000+02	.5561449+00	.2812914+01	.5971634+01	.5687791+00	1	102
.1288927+01	.4346797+01	.1200105+01	.7521593+01	.2730772+01	.1508121+01	1	103
-.1156931+01	.1117215+01	.1607371+01	.1545187+01	.4931751+00	.1629857+01	1	104
-.1617739+01	.2102813+01	.1634409+01	.1638814+01	.3796634+01	.1635819+01	1	105
-.1634537+01	.5568598+01	.1635476+01	.1634943+01	.7440402+01	.1636000+01	1	106
-.1635008+01	.9480623+01	.8853665+01	.1300000+02	.4678222+00	.1993384+01	1	107
-.6470745+01	.1194876+01	.4584320+00	.4849929+01	.1485676+01	.7658047+00	1	108

AFWL-TR-67-131, Vol IV

-.3234956+01-.1596226+01-.1438118+01-.1621798+01-.1631605+01-.1604283+01 1 109
 -.1150607-01-.1639559+01-.1634310+01-.1598110+01-.1641404+01-.1640299+01 1 110
 .3291926+01-.1641773+01-.1641430+01-.5063890+01-.1641838+01-.1641626+01 1 111
 .6935693+01-.1641848+01-.1641658+01-.6975914+01-.1641849+01-.1641662+01 1 112
 .1111598+02-.1641649+01-.1641662+01-.1335794+02-.1641849+01-.1641662+01 1 113
 .1572115+02-.9210340+01-.1300000+02-.1359786+01-.6074121-00-.7002565+01 1 114
 -.1556710+01-.7088303-00-.5379504+01-.1625762+01-.1413976+01-.3767608+01 1 115
 -.1645726+01-.1612455+01-.2156741+01-.1650989+01-.1651293+01-.5465033-00 1 116
 -.1655258+01-.1663228+01-.1063101+01-.1655470+01-.1664707+01-.2756914+01 1 117
 -.1655512+01-.1664985+01-.4526878+01-.1655520+01-.1665033+01-.6400661+01 1 118
 -.1655521+01-.1665041+01-.8440902+01-.1655521+01-.1665042+01-.1058097+02 1 119
 -.1655521+01-.1665042+01-.1282293+02-.1655521+01-.1665042+01-.1518614+02 1 120
 U
 GNEY DIANE LIVERMORE IRON DATA. GINA IRONIC APRIL 5, 1966
 .1000000+01 .4140000+03
 3026. 1800000E+02
 .3912020+01 .7000000+01 .7992940+01 .7992940+01-.2302590+01 .8514590+01 1 1
 .6514590+01-.6931470-00 .8622490+01 .8622990+01-.0000000 .8429670+01 1 2
 .8429670+01 .1609440+01 .8247480+01 .8247480+01 .2302590+01 .7298450+01 1 3
 .7298450+01 .3912020+01 .6661050+01 .6661650+01 .4605170+01 .4317490+01 1 4
 .7000000+01 .8024760+01 .6024760+01-.2302590+01 .8279700+01 .8279700+01 1 5
 -.6931470-00 .8113730+01 .6113730+01-.0000000 .7754480+01 .7754480+01 1 6
 .1609440+01 .7481560+01 .7481560+01 .2302590+01 .6491940+01 .6491940+01 1 7
 .3912020+01 .5852200+01 .5852200+01 .4605170+01 .4605170+01 .7000000+01 1 8
 .8038510+01 .6038510+01-.2302590+01 .7956480+01 .7956480+01-.6931470-00 1 9
 .7736310+01 .7736310+01-.0000000 .7247790+01 .7247790+01 .1609440+01 1 10
 .6963190+01 .6963190+01 .2302590+01 .5923450+01 .5923450+01 .3912020+01 1 11
 .5283200+01 .5283200+01 .4605170+01 .5010640+01 .7000000+01 .7468250+01 1 12
 .7468250+01-.2302590+01 .7557470+01 .7557470+01-.6931470-00 .7347300+01 1 13
 .7347300+01-.0000000 .6547500+01 .6547500+01 .1609440+01 .6176040 1 14
 .6176040+01 .2302590+01 .5010640+01 .5010640+01 .3912020+01 .4347690+01 1 15
 .4347690+01 .4605170+01 .5249420+01 .7000000+01 .7658700+01 .7658700+01 1 16
 -.2302590+01 .7370230+01 .7370230+01-.6931470-00 .7156180+01 .7156180+01 1 17
 -.0000000 .6215610+01 .6215610+01 .1609440+01 .5648620+01 .5648620+01 1 18
 .2302590+01 .4484920+01 .4484920+01 .3912020+01 .3663560+01 .3663560+01 1 19
 .4605170+01 .5703780+01 .7000000+01 .6851080+01 .6851080+01-.2302590+01 1 20
 .6637260+01 .6637260+01-.6931470-00 .6439350+01 .6439350+01-.0000000 1 21
 .5349010+01 .5349010+01 .1609440+01 .4677490+01 .4677490+01 .2302590+01 1 22
 .2927450+01 .2927450+01 .3912020+01 .2093100+01 .2093100+01 .4605170+01 1 23
 .5991460+01 .7000000+01 .5997200+01 .5997200+01-.2302590+01 .5555670+01 1 24
 .5555670+01-.6931470-00 .5135800+01 .5135800+01-.0000000 .3895890+01 1 25
 .3895890+01 .1609440+01 .3242590+01 .3242590+01 .2302590+01 .1660130+01 1 26
 .1660130+01 .3912020+01 .9895410-00 .9895410-00 .4605170+01 .6214610+01 1 27
 .7000000+01 .5181220+01 .5181220+01-.2302590+01 .4587720+01 .4587720+01 1 28
 -.6931470-00 .4154180+01 .4154180+01-.0000000 .2844910+01 .2844910+01 1 29
 .1609440+01 .2236450+01 .2236450+01 .2302590+01 .7929930-00 .7929930-00 1 30
 .3912020+01 .1906200-00 .1906200-00 .4605170+01 .6551080+01 .7000000+01 1 31
 .3867030+01 .3867030+01-.2302590+01 .2898120+01 .2898120+01-.6931470-00 1 32
 .2317470+01 .2317470+01-.0000000 .1000630+01 .1000630+01 .1609440+01 1 33
 .4574250-00 .4574250-00 .2302590+01-.6143360-00 .6143360-00 .3912020+01 1 34
 -.9187940-00-.9187940-00 .4605170+01 .6684610+01 .7000000+01 .3441380+01 1 35
 .3441380+01-.2302590+01 .2348510+01 .2348510+01-.6931470-00 .1766440+01 1 36
 .1766440+01-.0000000 .4946960-00 .4946960-00 .1609440+01 .1093990+01 1 37
 .1093990+01 .2302590+01-.8964880-00-.8964880-00 .3912020+01-.1127010+01 1 38
 -.1127010+01 .4605170+01 .6907760+01 .7000000+01 .2857620+01 .2857620+01 1 39

-.2302590+01	.1024130+01	.1024130+01	.6931470+00	.1064710+01	.1064710+01	1	40
-.0000000	-.8773690+01	-.8773690+01	.1609440+01	.4796500+00	.4796500+00	1	41
.2302590+01	.1171180+01	.1171180+01	.3912020+01	.1339410+01	.1339410+01	1	42
.4605170+01	.7313220+01	.7000000+01	.2330200+01	.2330200+01	.2302590+01	1	43
.6544150+00	.8544150+00	.6931470+00	.3293040+00	.3293040+00	.0000000	1	44
-.6346780+00	-.6346780+00	.1609440+01	.9545120+00	.9545120+00	.2302590+01	1	45
-.1398370+01	-.1398370+01	.3912020+01	.1518680+01	.1518680+01	.4605170+01	1	46
.7600900+01	.7000000+01	.2016900+01	.2018900+01	.2302590+01	.5341510+00	1	47
.5341510+00	.6931470+00	.1980260+01	.1980260+01	.0000000	-.8770700+00	1	48
-.8770700+00	.1609440+01	.1136310+01	.1136310+01	.2302590+01	.1514130+01	1	49
-.1514130+01	.3912020+01	.1609440+01	.1609440+01	.4605170+01	.7624050+01	1	50
.7000000+01	.1172480+01	.1172480+01	.2302590+01	.1444480+00	.1444480+00	1	51
-.6931470+00	-.5516480+00	-.5516480+00	.0000000	-.1180910+01	.1180910+01	1	52
.1609440+01	.1328030+01	.1328030+01	.2302590+01	.1629640+01	.1629640+01	1	53
.3912020+01	.1672910+01	.1672910+01	.4605170+01	.8160520+01	.7000000+01	1	54
-.1404120+00	-.1404120+00	.2302590+01	.9675840+00	.9675840+00	.6931470+00	1	55
-.1224160+01	-.1224160+01	.0000000	-.1604450+01	.1604450+01	.1609440+01	1	56
-.1660730+01	-.1660730+01	.2302590+01	.1714800+01	.1714800+01	.3912020+01	1	57
-.1723170+01	-.1723170+01	.4605170+01	.8517190+01	.7000000+01	.1207310+01	1	58
-.1207310+01	.2302590+01	.1584960+01	.1584960+01	.6931470+00	.1650260+01	1	59
-.1650260+01	.0000000	-.1742970+01	.1742970+01	.1609440+01	.1754460+01	1	60
-.1754460+01	.2302590+01	.1754460+01	.1754460+01	.3912020+01	.1757360+01	1	61
-.1757360+01	.4605170+01	.8422660+01	.7000000+01	.1645070+01	.1645070+01	1	62
-.2302590+01	.1731610+01	.1731610+01	.6931470+00	.1760260+01	.1760260+01	1	63
-.0000000	-.1771960+01	.1771960+01	.1609440+01	.1771960+01	.1771960+01	1	64
.2302590+01	.1773130+01	.1773130+01	.3912020+01	.1773130+01	.1773130+01	1	65
.4605170+01	.9210340+01	.7000000+01	.1783790+01	.1783790+01	.2302590+01	1	66
-.1626350+01	-.1626350+01	.6931470+00	.1838850+01	.1838850+01	.0000000	1	67
-.1845160+01	-.1845160+01	.1609440+01	.1845160+01	.1845160+01	.2302590+01	1	68
-.1842630+01	-.1842630+01	.3912020+01	.1842630+01	.1842630+01	.4605170+01	1	69

10

DIANE/SCAT UGHAN11L-1A 1EM(11-2250) 1 FREQ C1/KDP 2-16-67

.1000000+01	.6010000+03						
1126.	.2100000+02						
.0000000	.1300000+02	.6513020+01	.9403540+01	.3787374+01	.6918841+01	1	1
.9383596+01	.2212227+01	.6833137+01	.9242392+01	.4766373+01	.6577467+01	1	2
.8997217+01	.7374314+01	.5884978+01	.8224692+01	.9684505+01	.4776727+01	1	3
.6890391+01	.1162386+02	.3380773+01	.5513859+01	.1359640+02	.2076541+01	1	4
.4253558+01	.1579495+02	.6876317+00	.2759852+01	.1746880+02	.7410312+00	1	5
.1142455+01	.4023067+02	.2328005+01	.7346810+00	.2245339+02	.3226117+01	1	6
-.2571975+01	.4771543+02	.3520975+01	.3433227+01	.2708111+02	.4054651+00	1	7
.1300000+02	.9248431+01	.1063106+02	.1443642+01	.4091214+01	.1039440+02	1	8
.3634363+01	.8816710+01	.1003015+02	.5879242+01	.8247439+01	.9482962+01	1	9
.7977748+01	.7410354+01	.8639601+01	.1003126+02	.6284457+01	.7610722+01	1	10
.1196139+02	.4382476+01	.6068572+01	.1389072+02	.3114451+01	.4245802+01	1	11
.1577764+02	.1109009+01	.2372769+01	.1766300+02	.8520485+00	.3449206+00	1	12
.1474175+02	.2290292+01	.1396182+01	.2146855+02	.2926097+01	.2492993+01	1	13
.2446125+02	.3031407+01	.2464081+01	.2648356+02	.8104302+00	.1300000+02	1	14
.1081603+02	.1127061+02	.2125871+01	.1043311+02	.1092698+02	.4158320+01	1	15
.9894502+01	.1046800+02	.6255945+01	.8994347+01	.9760501+01	.8209307+01	1	16
.7826120+01	.6597733+01	.1001982+02	.6460033+01	.7093483+01	.1172712+02	1	17
.4895732+01	.5561121+01	.1350190+02	.3302292+01	.4178371+01	.1545487+02	1	18
.1509122+01	.2574934+01	.1753305+02	.4363967+00	.6161041+00	.1965780+02	1	19
-.1998825+01	-.1244514+01	.2186565+02	.2684467+01	.2447268+01	.2419263+02	1	20
-.2761897+01	-.2725429+01	.2666489+02	.1223775+01	.1300000+02	.1118321+02	1	21

.1140652+02	.2344426+01	.1072803+02	.1042465+02	.4265121+01	.1010077+02	1	22
.1034711+02	.6123447+01	.4236083+01	.4724367+01	.7930385+01	.4031412+01	1	23
.6734171+01	.4745451+01	.6554035+01	.7338132+01	.1155372+02	.4483688+01	1	24
.5706458+01	.1336461+02	.3154546+01	.4016574+01	.1523432+02	.1316202+01	1	25
.2230735+01	.1722006+02	.5408437+00	.3324853+00	.1935585+02	.1977503+01	1	26
-.1482876+01	.2152580+02	.2536409+01	.2430729+01	.2379889+02	.2576140+01	1	27
-.2551541+01	.2625035+02	.1604438+01	.1300000+02	.1118015+02	.1135201+02	1	28
.2283024+01	.1065440+02	.1085634+02	.4055462+01	.1003116+02	.1041223+02	1	29
.5404860+01	.4147712+01	.4748118+01	.7749649+01	.7429424+01	.8509815+01	1	30
.9523036+01	.6361976+01	.6497127+01	.1127277+02	.4593325+01	.5298036+01	1	31
.1307581+02	.2760511+01	.3527035+01	.1440215+02	.9143044+00	.1772436+01	1	32
.1683643+02	.6784557+00	.4747554+01	.1645192+02	.2032454+01	.1673070+01	1	33
.2113054+02	.2374784+01	.2247001+01	.2344120+02	.2400002+01	.2377201+01	1	34
.2585474+02	.1445410+01	.1300000+02	.1103869+02	.1128431+02	.2120569+01	1	35
.1065444+02	.1082554+02	.3885541+01	.1007326+02	.1036233+02	.5703913+01	1	36
.6983105+01	.9525362+01	.7504744+01	.7341939+01	.8056414+01	.9259812+01	1	37
.5813416+01	.6487555+01	.1045643+02	.4162610+01	.4864974+01	.1273307+02	1	38
.2424446+01	.3164031+01	.1456447+02	.5841134+00	.1648444+01	.1650733+02	1	39
-.1113101+01	.1434030+00	.1861273+02	.1984606+01	.1677045+01	.2082300+02	1	40
-.2180448+01	.2128034+01	.2315597+02	.2208191+01	.2187544+01	.2555217+02	1	41
.2302585+01	.1300000+02	.1075651+02	.1114258+02	.1867030+01	.1042463+02	1	42
.1065211+02	.3619114+01	.4647554+01	.1013437+02	.5412575+01	.8455161+01	1	43
.9166084+01	.7181888+01	.6913274+01	.7725006+01	.8408000+01	.5337180+01	1	44
.1801814+01	.1060253+02	.3761043+01	.4572244+01	.1237443+02	.2067462+01	1	45
.2921227+01	.1423868+02	.2620770+00	.1202723+01	.1619820+02	.1282984+01	1	46
-.5534767+00	.1828178+02	.1455246+01	.1736103+01	.2045891+02	.2111411+01	1	47
-.2074421+01	.2272516+02	.2106056+01	.2084102+01	.2512017+02	.2708050+01	1	48
.1300000+02	.1042645+02	.1087254+02	.1555453+01	.1012282+02	.1045413+02	1	49
.3274187+01	.4354336+01	.4868004+01	.5038345+01	.8152274+01	.8794694+01	1	50
.6742803+01	.6707448+01	.7365477+01	.4524915+01	.5027033+01	.5784758+01	1	51
.1023754+02	.3222437+01	.4064650+01	.1149962+02	.1429640+01	.2278927+01	1	52
.1381404+02	.2540265+00	.4846126+00	.1572005+02	.1477164+01	.1074550+01	1	53
.1774344+02	.1912190+01	.1837912+01	.1946877+02	.1991666+01	.1973102+01	1	54
.2224185+02	.1481618+01	.1463386+01	.2463996+02	.3113515+01	.1300000+02	1	55
.1016487+02	.1054426+02	.1183164+01	.4408774+01	.1023746+02	.2911224+01	1	56
.9162261+01	.9488540+01	.4667065+01	.7830403+01	.8416449+01	.6417956+01	1	57
.6060444+01	.6831161+01	.8116133+01	.4344240+01	.5044372+01	.9779069+01	1	58
.2715164+01	.3346042+01	.1151484+02	.8545856+00	.1627384+01	.1332583+02	1	59
-.7127758+00	.2046442+01	.1523544+02	.1574279+01	.1310207+01	.1731496+02	1	60
-.1636181+01	.1788077+01	.1444323+02	.1864334+01	.1848734+01	.2177201+02	1	61
-.1847118+01	.1828534+01	.2416829+02	.3526360+01	.1300000+02	.9673393+01	1	62
.1021407+02	.7842700+00	.4302325+01	.4722311+01	.2512413+01	.8437468+01	1	63
.6814445+01	.4241506+01	.7022211+01	.7514131+01	.5452970+01	.5412182+01	1	64
.5446242+01	.7625516+01	.3762071+01	.4471052+01	.9283214+01	.2035740+01	1	65
.2925776+01	.1102161+02	.3727310+00	.1401156+01	.1283562+02	.9621902+00	1	66
-.2416345+00	.1474576+02	.1614177+01	.1387139+01	.1581771+02	.1768351+01	1	67
-.1717644+01	.1894404+02	.1761824+01	.1734670+01	.2126784+02	.1741500+01	1	68
-.1723130+01	.2365515+02	.3412023+01	.1300000+02	.8781664+01	.9540137+01	1	69
.3501254+00	.8380707+01	.8844833+01	.2080145+01	.7818152+01	.8035299+01	1	70
.3785374+01	.6631651+01	.6907464+01	.5471911+01	.5003031+01	.5394688+01	1	71
.7132158+01	.3318438+01	.3824401+01	.8777334+01	.1562761+01	.2208941+01	1	72
.1050455+02	.5452760+01	.7037781+00	.1232140+02	.1189158+01	.6741542+00	1	73
.1423108+02	.1616993+01	.1461125+01	.1631243+02	.1702270+01	.1667847+01	1	74
.1848149+02	.1717654+01	.1698865+01	.2073445+02	.1714959+01	.1696537+01	1	75
.2310370+02	.4248495+01	.1300000+02	.8374504+01	.9119536+01	.3670743+01	1	76

.745533+01	.840355+01	.166464+01	.730546+01	.754536+01	.336743+01	1	77
.601547+01	.630728+01	.504364+01	.433502+01	.483467+01	.671146+01	1	78
.265776+01	.336434+01	.837157+01	.992272+00	.186372+01	.101082+02	1	79
-.470222+00	.356047+00	.114165+02	.133464+01	.938429+00	.138057+02	1	80
-.163729+01	.155467+01	.156545+02	.164250+01	.167026+01	.180023+02	1	81
-.169703+01	.167463+01	.202510+02	.164207+01	.167386+01	.226217+02	1	82
.460517+01	.130000+02	.813226+01	.677446+01	.474292+00	.765456+01	1	83
.811975+01	.122429+01	.672636+01	.707492+01	.242977+01	.525357+01	1	84
.571537+01	.461634+01	.357436+01	.425619+01	.627489+01	.197608+01	1	85
.274604+01	.792268+01	.300447+00	.122197+01	.963237+01	.935507+02	1	86
-.271618+00	.114143+02	.146827+01	.127444+01	.132453+02	.162422+01	1	87
-.160337+01	.153443+02	.167034+01	.165441+01	.174922+02	.167081+01	1	88
-.165265+01	.197438+02	.165851+01	.164016+01	.221206+02	.501063+01	1	89
.130000+02	.779839+01	.846340+01	.972486+00	.717112+01	.764568+01	1	90
.733765+01	.600524+01	.640035+01	.243143+01	.445830+01	.495108+01	1	91
.404220+01	.263003+01	.340028+01	.572531+01	.123733+01	.144971+01	1	92
.734913+01	.190863+00	.442036+00	.905430+01	.111448+01	.795719+00	1	93
.108379+02	.150759+01	.142446+01	.127239+02	.161867+01	.149197+01	1	94
.147762+02	.163372+01	.161519+01	.164273+02	.163594+01	.161766+01	1	95
.191713+02	.163625+01	.161790+01	.215348+02	.541610+01	.130000+02	1	96
.716467+01	.764515+01	.147846+01	.634804+01	.677765+01	.210326+00	1	97
.528364+01	.552445+01	.108170+01	.384280+01	.411731+01	.352293+01	1	98
.219647+01	.260254+01	.515227+01	.653686+00	.129117+01	.677884+01	1	99
-.619270+00	.471705+01	.848684+01	.131595+01	.108149+01	.102667+02	1	100
-.156030+01	.151221+01	.121407+02	.162055+01	.160369+01	.141813+02	1	101
-.163322+01	.161621+01	.163214+02	.163575+01	.161757+01	.185636+02	1	102
-.163467+01	.161626+01	.207232+02	.582894+01	.130000+02	.648597+01	1	103
.716467+01	.202027+01	.574318+01	.606566+01	.351030+00	.457236+01	1	104
.486231+01	.130503+01	.301431+01	.344893+01	.294328+01	.141073+01	1	105
.196527+01	.456763+01	.174434+01	.493411+00	.616261+01	.102361+01	1	106
-.765538+00	.787787+01	.145503+01	.140994+01	.965044+01	.159281+01	1	107
-.157470+01	.115240+02	.162303+01	.160528+01	.135692+02	.162541+01	1	108
-.160710+01	.157123+02	.162556+01	.160720+01	.179541+02	.162560+01	1	109
-.160721+01	.203180+02	.621406+01	.130000+02	.564611+01	.650920+01	1	110
-.254619+01	.500435+01	.547534+01	.884756+00	.371023+01	.407981+01	1	111
.757337+00	.214600+01	.252925+01	.238202+01	.618327+00	.102284+01	1	112
.349066+01	.596999+00	.262320+00	.560851+01	.129896+01	.114113+01	1	113
.730673+01	.154995+01	.150520+01	.408147+01	.160961+01	.159107+01	1	114
.109540+02	.162283+01	.160525+01	.124443+02	.162523+01	.160698+01	1	115
.151344+02	.162549+01	.160716+01	.173763+02	.162548+01	.160717+01	1	116
.147346+02	.655106+01	.130000+02	.484561+01	.540667+01	.301041+01	1	117
.406535+01	.466403+01	.136804+01	.273917+01	.318298+01	.263380+00	1	118
.124125+01	.173247+01	.168352+01	.156269+00	.373363+00	.349880+01	1	119
-.104935+01	.761187+00	.511044+01	.145537+01	.138736+01	.680548+01	1	120
-.158732+01	.156878+01	.857759+01	.161862+01	.160134+01	.104444+02	1	121
-.162405+01	.160621+01	.124896+02	.162467+01	.160688+01	.146297+02	1	122
-.162438+01	.160671+01	.168716+02	.162438+01	.160671+01	.192346+02	1	123
.690775+01	.130000+02	.347630+01	.507152+01	.352449+01	.316127+01	1	124
.378051+01	.189049+01	.183022+01	.237500+01	.263208+00	.403747+00	1	125
.930036+00	.135501+01	.725676+00	.392147+00	.296678+01	.134374+01	1	126
-.123221+01	.457674+01	.156867+01	.153461+01	.627063+01	.161335+01	1	127
-.159383+01	.804261+01	.162061+01	.160361+01	.991441+01	.162172+01	1	128
-.160511+01	.114546+02	.162072+01	.160455+01	.140947+02	.162073+01	1	129
-.160458+01	.163366+02	.162073+01	.160458+01	.186998+02	.731322+01	1	130
.130000+02	.272662+01	.423627+01	.411432+01	.181648+01	.286369+01	1	131

AFWL-TR-67-131, Vol IV

-0.2487559+01	.4410208+00	.1406400+01	-.8665109+00	-.7109438+00	-.3023469+01	1	132
.7482819+00	-.1343624+01	-.1063898+01	.2358928+01	-.1554723+01	-.1477731+01	1	133
.3468017+01	-.1605436+01	-.1578835+01	.5002449+01	-.1615227+01	-.1597803+01	1	134
.7434410+01	-.1610880+01	-.1601016+01	.9306220+01	-.1617308+01	-.1601324+01	1	135
.1134044+02	-.1617360+01	-.1601740+01	.1348651+02	-.1617369+01	-.1601747+01	1	136
.1572047+02	-.1617370+01	-.1601746+01	.1609168+02	.7718685+01	.1300000+02	1	137
.1091581+01	.3334370+01	-.4711255+01	.3404795+01	.1920521+01	-.3089102+01	1	138
-.9391496+00	.4124518+00	-.1471538+01	-.1342458+01	-.8078393+00	.1403563+00	1	139
-.1551352+01	-.1393275+01	.1750790+01	-.1604712+01	-.1561795+01	.3360432+01	1	140
-.1617041+01	-.1547190+01	.5054253+01	-.1620062+01	-.1603570+01	.6826219+01	1	141
-.1620482+01	-.1604600+01	.8698022+01	-.1621991+01	-.1606683+01	.1073824+02	1	142
-.1621499+01	-.1606704+01	.1287831+02	-.1621999+01	-.1606707+01	.1512027+02	1	143
-.1622000+01	-.1606707+01	.1748348+02	.0000000	.0000000	.0000000	1	144
J							
DIANE GROUT 1A/INT LMS/RP 7/27/66							
0.100000+01	0.451000+03						
1114.	.1100000E+02						
0.391202+01	0.130000+02	0.822134+01	0.938122+01	0.580303+00	0.775822+01	2	1
0.851888+01	0.225140+01	0.649941+01	0.756140+01	0.393200+01	0.570423+01	2	2
0.633831+01	0.558693+01	0.408609+01	0.502435+01	0.724419+01	0.243855+01	2	3
0.373100+01	0.892230+01	0.874571+00	0.231815+01	0.106719+02	0.413043+00	2	4
0.899719+00	0.125007+02	0.122521+01	0.438179+00	0.144082+02	0.152767+01	2	5
-0.134152+01	0.164591+02	0.154703+01	0.155974+01	0.186025+02	0.160561+01	2	6
-0.158047+01	0.208404+02	0.160558+01	0.158759+01	0.232127+02	0.424850+01	2	7
0.130000+02	0.817270+01	0.910455+01	0.135226+00	0.763650+01	0.835636+01	2	8
0.181433+01	0.009187+01	0.735752+01	0.350207+01	0.516967+01	0.616298+01	2	9
0.519549+01	0.351475+01	0.482721+01	0.687517+01	0.147751+01	0.344444+01	2	10
0.854042+01	0.454294+00	0.186079+01	0.102631+02	0.749034+00	0.266418+00	2	11
0.120442+02	0.136576+01	0.983496+00	0.139197+02	0.154395+01	0.148403+01	2	12
0.159629+02	0.158673+01	0.157272+01	0.181052+02	0.160004+01	0.158290+01	2	13
0.203405+02	0.164196+01	0.158370+01	0.227121+02	0.460517+01	0.130000+02	2	14
0.821224+01	0.906520+01	0.320665+00	0.757157+01	0.834595+01	0.137836+01	2	15
0.636367+01	0.714430+01	0.308906+01	0.477047+01	0.571876+01	0.477430+01	2	16
0.304204+01	0.418606+01	0.642134+01	0.142088+01	0.263656+01	0.804365+01	2	17
-0.478165+01	0.102134+01	0.974260+01	0.984571+00	0.443893+00	0.115175+02	2	18
-0.139036+01	0.130374+01	0.133911+02	0.155067+01	0.153955+01	0.154332+02	2	19
-0.158814+01	0.157154+01	0.175782+02	0.158703+01	0.157082+01	0.198262+02	2	20
-0.158347+01	0.156559+01	0.221453+02	0.501064+01	0.130000+02	0.768303+01	2	21
0.863936+01	0.015487+00	0.645518+01	0.762189+01	0.882302+00	0.571668+01	2	22
0.628252+01	0.256980+01	0.415248+01	0.474467+01	0.421083+01	0.252637+01	2	23
0.320125+01	0.583097+01	0.956173+00	0.162440+01	0.744513+01	0.353912+00	2	24
0.157024+00	0.914336+01	0.114255+01	0.958824+00	0.109213+02	0.147945+01	2	25
-0.143337+01	0.127491+02	0.156055+01	0.154468+01	0.148424+02	0.157991+01	2	26
-0.156135+01	0.164637+02	0.158177+01	0.156353+01	0.192258+02	0.158213+01	2	27
-0.156378+01	0.215890+02	0.541610+01	0.130000+02	0.663968+01	0.783727+01	2	28
-0.153695+01	0.574430+01	0.651312+01	0.339348+00	0.468137+01	0.520479+01	2	29
0.148951+01	0.329050+01	0.373397+01	0.361719+01	0.171050+01	0.222976+01	2	30
0.523604+01	0.241784+00	0.803759+00	0.685234+01	0.877972+00	0.498667+00	2	31
0.855011+01	0.134702+01	0.126330+01	0.103233+02	0.153897+01	0.151534+01	2	32
0.121953+02	0.157363+01	0.155742+01	0.142355+02	0.158103+01	0.156303+01	2	33
0.163750+02	0.158148+01	0.156363+01	0.186177+02	0.158156+01	0.156316+01	2	34
0.204814+02	0.582895+01	0.130000+02	0.560362+01	0.684958+01	0.189647+01	2	35
0.495744+01	0.567420+01	0.244075+00	0.375927+01	0.433149+01	0.138805+01	2	36
0.220023+01	0.285307+01	0.301268+01	0.656770+00	0.132597+01	0.462728+01	2	37
-0.554949+00	0.918363+01	0.623811+01	0.122027+01	0.108322+01	0.793225+01	2	38

AFWL-TR-67-131, Vol IV

-0.146889+01-0.146294+01	0.970441+01-0.156494+01-0.154620+01	0.115768+02	2	39			
-0.157775+01-0.155904+01	0.136164+02-0.157250+01-0.155977+01	0.157594+02	2	40			
-0.157775+01-0.155931+01	0.180027+02-0.157761+01-0.155922+01	0.203661+02	2	41			
0.621401+01	0.130000+02	0.474447+01	0.616368+01-0.243538+01	0.399704+01	2	42	
0.489442+01-0.605923+00	0.271138+01	0.346639+01	0.481964+00	0.121437+01	2	43	
0.190661+01	0.243657+01-0.140094+00	0.439701+00	0.405928+01-0.101139+01		2	44	
-0.667622+00	0.566047+01-0.142125+01	0.130472+01	0.735613+01	0.154296+01	2	45	
-0.150561+01	0.412945+01-0.156784+01-0.154992+01	0.110020+02-0.157632+01			2	46	
0.155617+01	0.130423+02-0.157755+01-0.155912+01	0.151824+02-0.157767+01			2	47	
-0.155921+01	0.174244+02-0.157768+01-0.155922+01	0.197876+02	0.655108+01		2	48	
0.130000+02	0.377200+01	0.512106+01-0.292622+01	0.286313+01	0.381031+01	2	49	
-0.130262+01	0.150550+01	0.232685+01	0.318607+00	0.152242+00	0.404644+00	2	50
0.193585+01-0.824600+00	0.294214+00	0.354011+01-0.132061+01-0.110007+01			2	51	
0.515977+01-0.150470+01-0.145349+01	0.685349+01-0.156262+01-0.154295+01				2	52	
0.862500+01-0.157670+01-0.155740+01	0.104974+02-0.157844+01-0.155930+01				2	53	
0.125377+02-0.157863+01-0.155354+01	0.146777+02-0.157865+01-0.155936+01				2	54	
0.169197+02-0.157005+01-0.155357+01	0.192629+02	0.690776+01	0.130000+02		2	55	
0.303909+01	0.443664+01-0.345170+01	0.216863+01	0.307779+01-0.183282+01		2	56	
0.847066+00	0.676744+01-0.213307+00	0.338995+00	0.329761+00	0.140344+01	2	57	
0.109377+01-0.837000+00	0.301440+01-0.144706+01-0.136154+01	0.462473+01			2	58	
-0.155621+01-0.155332+01	0.631063+01-0.157901+01-0.155569+01	0.809062+01			2	59	
-0.156250+01-0.156080+01	0.994242+01-0.158304+01-0.156161+01	0.120026+02			2	60	
-0.156250+01-0.156157+01	0.141427+02-0.158280+01-0.156154+01	0.163847+02			2	61	
-0.156250+01-0.156154+01	0.147479+02	0.731322+01	0.130000+02	0.192241+01	2	62	
0.363673+01-0.403522+01	0.111703+01	0.227416+01-0.243646+01-0.415608+01			2	63	
0.884977+00-0.813632+00	0.101458+01-0.422772+00	0.796151+00-0.145010+01			2	64	
-0.121758+01	0.240606+01-0.156301+01-0.149908+01	0.401658+01	0.158698+01		2	65	
-0.135528+01	0.571445+01-0.159253+01-0.156670+01	0.748242+01-0.159344+01			2	66	
-0.156861+01	0.935423+01-0.159357+01-0.156890+01	0.113944+02-0.159358+01			2	67	
-0.156893+01	0.135345+02-0.159388+01-0.156894+01	0.157765+02-0.159358+01			2	68	
-0.156894+01	0.181397+02	0.771869+01	0.130000+02	0.480177+00	0.280601+01	2	69
-0.465069+01-0.426232+00	0.152044+01-0.303429+01-0.113012+01-0.258116+01				2	70	
-0.142301+01-0.146748+01-0.105036+01	0.188123+00-0.157334+01-0.146134+01				2	71	
0.179065+01-0.159980+01-0.155740+01	0.340039+01-0.160649+01-0.157825+01				2	72	
0.510225+01-0.160775+01-0.158211+01	0.687422+01-0.160797+01-0.158278+01				2	73	
0.674003+01-0.160800+01-0.158269+01	0.107862+02-0.160801+01-0.158290+01				2	74	
0.129263+02-0.160801+01-0.158290+01	0.151683+02-0.160801+01-0.158290+01				2	75	
0.175315+02	0.	0.	0.	0.	0.	2	76

DIANE/SCAT H-21A TEMP(1.-34.) 1:2PUT TAPE 1505 8-9-67 C1/BGF

[illegible]

AFWL-TR-67-131, Vol IV

.2706030+02-	.9041420-00-	.8391161-00	.2942352+02	.4054651-00	.1300000+02	1	14
.9969973+01	.1460564+02	.2027567+01	.9A67899+01	.1434128+02	.4414648+01	1	15
.9829541+01	.1420250+02	.7133633+01	.96/4474+01	.1355649+02	.9967616+01	1	16
.9128746+01	.1212075+02	.1262115+02	.7881585+01	.1043784+02	.1479492+02	1	17
.6074056+01	.8598009+01	.1667427+02	.40/09467+01	.6707482+01	.1848422+02	1	18
.2079972+01	.4011438+01	.2036325+02	.3987488-00	.2783635+01	.2240463+02	1	19
.5173818-00	.8122962-00	.2454465+02-	.8226541-00-	.5384567-00	.2678683+02	1	20
.8962154-00-	.8732004-00	.2915004+02	.5596158-00	.1300000+02	.1114344+02	1	21
.1499600+02	.2921419+01	.1098783+02	.1464102+02	.5353783+01	.1085761+02	1	22
.1448248+02	.8028749+01	.1042371+02	.1349731+02	.1065670+02	.9336435+01	1	23
.1180634+02	.1249177+02	.7047172+01	.9992114+01	.1472535+02	.5669199+01	1	24
.8129072+01	.1647564+02	.3025709+01	.6258837+01	.1A25917+02	.1682282+01	1	25
.4341350+01	.2013298+02	.1656357-00	.2325128+01	.2217353+02-	.5694345-00	1	26
.3811136-00	.2431364+02-	.8060146-00-	.6749579-00	.2455560+02-	.9088298-00	1	27
.8975041-00	.2891881+02	.6931472-00	.1300000+02	.1207682+02	.1515727+02	1	28
.3532804+01	.1184600+02	.1484461+02	.59/5409+01	.1156376+02	.1453326+02	1	29
.6544098+01	.1070548+02	.1345303+02	.1090796+02	.9294214+01	.1151112+02	1	30
.1286006+02	.7425489+01	.9565526+01	.1456745+02	.5387038+01	.7678833+01	1	31
.1628393+02	.3350504+01	.5840473+01	.1806033+02	.1454748+01	.3889681+01	1	32
.1995291+02	.6093553+01	.1892007+01	.2197326+02-	.5635074-00	.1153726+00	1	33
.2411334+02-	.8141273-00-	.7605397-00	.2635530+02-	.9183732-00-	.7051625-00	1	34
.2871851+02	.8109302+00	.1300000+02	.1276434+02	.1522733+02	.3952419+01	1	35
.1248096+02	.1468194+02	.6375507+01	.1200545+02	.1439417+02	.8799443+01	1	36
.1092740+02	.1294453+02	.1094042+02	.9224350+01	.1103422+02	.1274547+02	1	37
.7285324+01	.9163704+01	.1440501+02	.5224135+01	.7335376+01	.1611000+02	1	38
.3211647+01	.5467929+01	.1780413+02	.1357058+01	.3584733+01	.1975631+02	1	39
.4955309+01	.1608462+01	.2174059+02-	.5361917-00-	.7892454-01	.2393667+02	1	40
.8450003+00-	.8140259+00	.2617863+02-	.9204400-00-	.9068484-00	.2854184+02	1	41
.1223775+01	.1300000+02	.1341460+02	.1495419+02	.4752689+01	.1274401+02	1	42
.1416043+02	.6824200+01	.1170530+02	.1314486+02	.8763859+01	.1023394+02	1	43
.1154369+02	.1052793+02	.8445576+01	.9585485+01	.1217843+02	.6530863+01	1	44
.7789257+01	.1379713+02	.4536551+01	.6020512+01	.1549290+02	.2602776+01	1	45
.4174770+01	.1726523+02	.9470319+00	.2316892+01	.1913710+02-	.1910004-00	1	46
.4672740+00	.2117733+02-	.7984936-00-	.6934751-00	.2331740+02-	.9146724-00	1	47
.8967030+00	.2553936+02-	.9222352-00-	.9098682-00	.2742257+02	.1609438+01	1	48
.1300000+02	.1213872+02	.1411128+02	.4703821+01	.1118567+02	.1304370+02	1	49
.8534855+01	.9956322+01	.1177247+02	.8288708+01	.8538253+01	.1009192+02	1	50
.9977585+01	.8983167+01	.8353637+01	.1160634+02	.5368984+01	.6671662+01	1	51
.1321999+02	.3651708+01	.4914319+01	.1491466+02	.1869347+01	.3131350+01	1	52
.1668678+02	.2252389+00	.1311072+01	.1855862+02-	.6838911-00-	.3007359-00	1	53
.2059884+02-	.9012138-00-	.8539384-00	.2273891+02-	.9246463-00-	.9097577-00	1	54
.2498087+02-	.9267774-00-	.9148126-00	.2734408+02	.1945910+01	.1300000+02	1	55
.1078328+02	.1325089+02	.4307550+01	.9652667+01	.1205634+02	.6112519+01	1	56
.8330113+01	.1068231+02	.7810545+01	.6883050+01	.9068062+01	.9479774+01	1	57
.5330950+01	.7400938+01	.1110318+02	.3752441+01	.5733947+01	.1271560+02	1	58
.2072507+01	.4021961+01	.1441301+02	.4702737+00	.2259425+01	.1618209+02	1	59
.5144508+00	.5034863+00	.1805391+02-	.8609523-00-	.6659882-00	.2009413+02	1	60
.9269130+00-	.8996397+00	.2223420+02-	.9348439-00-	.9232786-00	.2447616+02	1	61
.9356850+00-	.9250652+00	.2683937+02	.2302585+01	.1300000+02	.9500402+01	1	62
.1239459+02	.3943560+01	.8250727+01	.1106663+02	.5614123+01	.6899874+01	1	63
.9675401+01	.7321083+01	.5390349+01	.8096232+01	.8947778+01	.3832869+01	1	64
.6445341+01	.1056884+02	.2246791+01	.4813559+01	.1218073+02	.6737954+00	1	65
.3114088+01	.1387503+02-	.3851081-00	.1370342+01	.1564708+02-	.8065576-00	1	66
.1779057+00	.1751840+02-	.9215749-00-	.8445324+00	.1955912+02-	.9421034+00	1	67
.9311889+00	.2169919+02-	.9451977-00-	.9415019-00	.2394115+02-	.9454626-00	1	68

AFWL-TR-67-131, Vol IV

-9424551-00	.2630436+02	.2708050+01	.1300000+02	.7244423+01	.1071491+02	1	69
.3383927+01	.6017186+01	.9447276+01	.5047425+01	.4545505+01	.7975594+01	1	70
.6716620+01	.3012703+01	.6442744+01	.8341189+01	.1462134+01	.4874248+01	1	71
.9961012+01	.1505761+00	.3202194+01	.1157261+02	.5441134+00	.1614041+01	1	72
.1326644+02	.0644989+00	.7125223+01	.1503888+02	.9406214+00	.7659346+00	1	73
.1691070+02	.9583948+00	.9453963+00	.1845092+02	.7615229+00	.9667246+00	1	74
.2109099+02	.9618000+00	.9690226+00	.2333295+02	.9616395+00	.9692705+00	1	75
.2569016+02	.3113515+01	.1300000+02	.6604838+01	.1004823+02	.2799458+01	1	76
.5271940+01	.6715341+01	.4497347+01	.3766793+01	.7210186+01	.6113247+01	1	77
.2215557+01	.5660253+01	.7733817+01	.7371013+00	.4083787+01	.9353006+01	1	78
-.2877596+00	.2490625+01	.1096446+02	.7594093+00	.8668966+00	.1265865+02	1	79
-.9109212+00	.4058581+00	.1443064+02	.9510106+00	.8795845+00	.1630250+02	1	80
-.9599785+00	.9562534+00	.1834273+02	.9614950+00	.9677409+00	.2048279+02	1	81
-.9610261+00	.9687905+00	.2272475+02	.9616408+00	.9689037+00	.2508796+02	1	82
.3520360+01	.1300000+02	.5876213+01	.9322009+01	.2192666+01	.4496232+01	1	83
.7940029+01	.3882408+01	.2465564+01	.6409248+01	.5495526+01	.1422545+01	1	84
.4640445+01	.7115016+01	.1304316+00	.3264477+01	.8733848+01	.5791353+00	1	85
.1681262+01	.1034521+02	.6541782+00	.1807733+00	.1203939+02	.9358236+00	1	86
-.7068411+00	.1361142+02	.9565092+00	.9314541+00	.1568324+02	.9609504+00	1	87
-.9643707+00	.1772346+02	.9615+14+00	.9683745+00	.1986352+02	.9615996+00	1	88
-.9666348+00	.2210544+02	.9616059+00	.9686843+00	.2446864+02	.0000000	1	89

DIANE/SCAT HMX/LU=H1/JP2 10 FREQ. TEMP.(1.-2250.) C1/JP 12-9-66 000000

.1000000+02	.6610000+03	1111.	.2100000+02	.0000000	.1300000+02	.5567853+01	.9683676+01	.2706865+01	.5332093+01	1	1		
.9376063+01	.4999629+00	.5316747+01	.9204131+01	.2135534+01	.5250618+01	.6766097+01	.5013815+01	.5080408+01	.8067862+01	.7944572+01	.447964+01	1	2
.7362256+01	.1090230+02	.3876747+01	.6646315+01	.1370426+02	.2760707+01	.5293367+01	.1630333+02	.1145244+01	.3546767+01	.1853243+02	.7744648+00	1	3
.1501667+01	.2065020+02	.2361407+01	.6170555+00	.2260174+02	.3073948+01	.2366608+01	.2504944+02	.3196720+01	.3084828+01	.2744771+02	.4054651+00	1	4
.1300000+02	.6466753+01	.1150226+02	.2821406+00	.6347651+01	.1128156+02	.2655465+01	.0208335+01	.1113509+02	.5317024+01	.7797721+01	.1064945+02	1	5
.6010717+01	.6909900+01	.9566424+01	.1046254+02	.5561805+01	.8092504+01	.1250320+02	.3893171+01	.0303506+01	.1433524+02	.2190811+01	.4381346+01	1	6
.1614135+02	.6631618+00	.2512247+01	.1804298+02	.6694940+00	.7450674+00	.2017696+02	.1897635+01	.8705626+00	.2247731+02	.2565535+01	.2168465+01	1	7
.2487339+02	.2715251+01	.2646092+01	.2732272+02	.8109302+00	.1300000+02	.1066141+02	.1227036+02	.2003662+01	.1037861+02	.1196955+02	.4330362+01	1	8
.9744139+01	.1144796+02	.6638821+01	.6638196+01	.1026933+02	.8662975+01	.7265642+01	.8730610+01	.1042706+02	.5993882+01	.7250810+01	.1211277+02	1	9
.4722056+01	.5891762+01	.1393162+02	.3229237+01	.4444622+01	.1588530+02	.1481314+01	.2710016+01	.1789342+02	.4282241+00	.7281843+00	.1498670+02	1	10
-.1868217+01	.1074622+01	.2217856+02	.2380612+01	.2151517+01	.2452883+02	-.2420933+01	.2374547+01	.2701467+02	.1223775+01	.1300000+02	.1185674+02	1	11
.1224078+02	.2615303+01	.1126630+02	.1163502+02	.4630421+01	.1039386+02	.1095875+02	.6533866+01	.9260446+01	.1011607+02	.8344376+01	.7805722+01	1	12
.8945037+01	.1015294+02	.6125170+01	.7569366+01	.1191833+02	.4524643+01	.5686208+01	.1369441+02	.3056598+01	.4280198+01	.1556433+02	.1417715+01	1	13
.7541288+01	.1756395+02	.3469601+00	.7013922+00	.1970293+02	.1673557+01	-.1038019+01	.2190714+02	.2117946+01	.1960984+01	.2423318+02	.2146422+01	1	14
-.2114424+01	.2668422+02	.1609438+01	.1300000+02	.1186155+02	.1197807+02	.2615972+01	.1131619+02	.1141228+02	.4444469+01	.1039210+02	.1091041+02	1	15
.6304232+01	.9052361+01	.1013347+02	.8120040+01	.7678286+01	.8906221+01							1	16

.9874197+01	.6191330+01	.7456023+01	.1162134+02	.4645177+01	.5605869+01	1	31
.1343159+02	.2998671+01	.4111540+01	.1529435+02	.1275938+01	.2375349+01	1	32
.1726642+02	.5453751+00	.4763011+00	.1938427+02	.1598045+01	.1129208+01	1	33
.2158523+02	.1908784+01	.1818473+01	.2390064+02	.1955976+01	.1933816+01	1	34
.2630235+02	.1945910+01	.1360000+02	.1160069+02	.1184441+02	.2453113+01	1	35
.1114670+02	.1134536+02	.4260273+01	.1024947+02	.1084687+02	.6076226+01	1	36
.9044088+01	.1016067+02	.7872432+01	.7607991+01	.8884402+01	.9632226+01	1	37
.6167291+01	.7251658+01	.1136011+02	.4508188+01	.5543965+01	.1315939+02	1	38
.2805352+01	.3794964+01	.1500820+02	.9623917+00	.2149405+01	.1495831+02	1	39
-.7327447+00	.2564504+00	.1905008+02	.1596977+01	.1270970+01	.2122709+02	1	40
-.1840002+01	.1790227+01	.2350303+02	.1884965+01	.1866475+01	.2587431+02	1	41
.2302585+01	.1300000+02	.1114084+02	.1162523+02	.2226724+01	.1090523+02	1	42
.1120605+02	.4009446+01	.1018506+02	.1074379+02	.5798290+01	.9004391+01	1	43
.9820448+01	.7587052+01	.7469552+01	.8373610+01	.9330880+01	.5949007+01	1	44
.6795897+01	.1103743+02	.4239917+01	.5075676+01	.1260821+02	.2347061+01	1	45
.3274844+01	.1462885+02	.5153067+00	.1414054+01	.1653794+02	.1024217+01	1	46
-.3856085+00	.1859234+02	.1640548+01	.1538872+01	.2073475+02	.1856261+01	1	47
-.1834417+01	.2297700+02	.1886796+01	.1870670+01	.2534024+02	.2708050+01	1	48
.1300000+02	.1036803+02	.1133337+02	.1925637+01	.1026439+02	.1093042+02	1	49
.3680444+01	.9787580+01	.1034430+02	.5446563+01	.8692871+01	.9178924+01	1	50
.7200280+01	.7143173+01	.7609196+01	.8906531+01	.5387888+01	.5931046+01	1	51
.1057186+02	.3484651+01	.4085391+01	.1224324+02	.1576635+01	.2197183+01	1	52
.1407299+02	.1806356+00	.3479347+00	.1544631+02	.1361364+01	.1162190+01	1	53
.1788081+02	.1776279+01	.1761463+01	.2012715+02	.1873048+01	.1859619+01	1	54
.2237122+02	.1875901+01	.1857908+01	.2474737+02	.3113515+01	.1300000+02	1	55
.9339006+01	.1088741+02	.1538040+01	.9138222+01	.1040459+02	.3277310+01	1	56
.8685861+01	.9524625+01	.5005687+01	.7656240+01	.8074916+01	.6717686+01	1	57
.6095369+01	.6364774+01	.6373423+01	.4313686+01	.4614061+01	.9996850+01	1	58
.2497730+01	.2822307+01	.1164450+02	.7266390+00	.1051447+01	.1347000+02	1	59
-.7731763+00	.5010479+00	.1535318+02	.1590525+01	.1489870+01	.1740923+02	1	60
-.1809346+01	.1777552+01	.1956002+02	.1815407+01	.1794173+01	.2183322+02	1	61
-.1773670+01	.1754620+01	.2424263+02	.3526360+01	.1300000+02	.8438820+01	1	62
.1020515+02	.1076421+01	.7847479+01	.9538276+01	.2790582+01	.7037407+01	1	63
.8357942+01	.4476888+01	.5776551+01	.6782639+01	.6141239+01	.4283482+01	1	64
.5144006+01	.7774472+01	.2711069+01	.3574742+01	.9401716+01	.1090364+01	1	65
.2015205+01	.1111244+02	.3144808+00	.5969265+00	.1291205+02	.1257276+01	1	66
-.6308148+00	.1482647+02	.1642035+01	.1434409+01	.1690096+02	.1684749+01	1	67
-.1631191+01	.1909005+02	.1649479+01	.1626772+01	.2138180+02	.1629105+01	1	68
-.1610395+01	.2376794+02	.3912023+01	.1300000+02	.8075020+01	.9501185+01	1	69
.5984646+00	.7207630+01	.8568968+01	.2273551+01	.6051309+01	.7390264+01	1	70
.3946803+01	.4638181+01	.6036715+01	.5604687+01	.3133025+01	.4747384+01	1	71
.7254445+01	.1735095+01	.3515565+01	.8910032+01	.4354815+00	.2184108+01	1	72
.1064913+02	.6487027+00	.8312422+00	.1247645+02	.1312461+01	.5034025+00	1	73
.1434036+02	.1533206+01	.1242778+01	.1646254+02	.1575726+01	.1525933+01	1	74
.1862201+02	.1584770+01	.1564433+01	.2086777+02	.1587016+01	.1568762+01	1	75
.2323143+02	.4248495+01	.1300000+02	.8202991+01	.9152391+01	.1494544+00	1	76
.7145597+01	.8277332+01	.1827858+01	.5786823+01	.7136344+01	.3502714+01	1	77
.4332414+01	.5940937+01	.5184673+01	.2843472+01	.4719791+01	.6858333+01	1	78
.1439127+01	.3415748+01	.8524723+01	.1532978+00	.1958003+01	.1025913+02	1	79
-.8171821+00	.4233204+00	.1205794+02	.1347735+01	.8672393+00	.1393921+02	1	80
-.1524480+01	.1443579+01	.1548125+02	.1571356+01	.1553913+01	.1812156+02	1	81
-.1584934+01	.1567812+01	.2036355+02	.1587490+01	.1569133+01	.2272676+02	1	82
.4605170+01	.1300000+02	.8326673+01	.9033696+01	.3190003+00	.7245427+01	1	83
.8217233+01	.1373686+01	.5847904+01	.7042311+01	.3079070+01	.4271624+01	1	84
.5708551+01	.4766030+01	.2701407+01	.4284111+01	.6424558+01	.1213404+01	1	85

.2758472+01	.8058674+01	.1196110+00	.1119752+01	.9780448+01	.9908075+00	1	86
-.3687836+00	.1153413+02	.1301371+01	.1288404+01	.1340624+02	.1538987+01	1	87
-.1528808+01	.1544651+02	.1583352+01	.1505697+01	.1758658+02	.182166+01	1	88
-.1504240+01	.1982654+02	.1588597+01	.1504556+01	.2219175+02	.5010635+01	1	89
.1300000+02	.7913150+01	.8705398+01	.8235757+00	.7065468+01	.7720151+01	1	90
.8806828+00	.5756985+01	.6405389+01	.2574275+01	.4111116+01	.4855051+01	1	91
.4224895+01	.2447223+01	.3247998+01	.5847118+01	.9167996+00	.1645580+01	1	92
.7459717+01	.3457967+00	.1039364+00	.9154181+01	.1163162+01	.1047584+01	1	93
.1042027+02	.1520427+01	.1492542+01	.1279809+02	.1585227+01	.1563120+01	1	94
.1403832+02	.1592202+01	.1575911+01	.1697838+02	.1593029+01	.1571882+01	1	95
.1922035+02	.1593115+01	.1571979+01	.2158355+02	.5416100+01	.1300000+02	1	96
.6579810+01	.7989555+01	.1337703+01	.5720961+01	.6752095+01	.3479772+00	1	97
.4468885+01	.5250652+01	.2003092+01	.2924567+01	.3635909+01	.3628497+01	1	98
.1342027+01	.2036721+01	.5241809+01	.1215230+00	.5019209+00	.6A52131+01	1	99
-.1144080+01	.6354080+00	.6548098+01	.1521503+01	.1444731+01	.1031809+02	1	100
-.1592132+01	.1561564+01	.1218790+02	.1601572+01	.1577527+01	.1423012+02	1	101
-.1002603+01	.1579402+01	.1637019+02	.1602794+01	.1579692+01	.1861215+02	1	102
-.1802808+01	.1579717+01	.2097536+02	.5826946+01	.1300000+02	.4835223+01	1	103
.5965570+01	.1892448+01	.3705835+01	.5610145+01	.2386504+00	.2391829+01	1	104
.4095704+01	.1392652+01	.8909429+00	.2511106+01	.3011541+01	.4341810+00	1	105
.9461857+00	.4023004+01	.1205284+01	.4595453+00	.6232954+01	.1517958+01	1	106
-.1325493+01	.7926048+01	.1599932+01	.1553678+01	.9698826+01	.1614031+01	1	107
-.1589106+01	.1157033+02	.1016276+01	.1594543+01	.1361085+02	.1616573+01	1	108
-.1595255+01	.1575092+02	.1616609+01	.1545340+01	.1794288+02	.1616612+01	1	109
-.1595349+01	.2035609+02	.6214608+01	.1300000+02	.3274680+01	.5970816+01	1	110
-.2436771+01	.2070225+01	.4605701+01	.8035088+00	.6385278+00	.3077332+01	1	111
.6167143+00	.5902500+00	.1504690+01	.2433642+01	.1264514+01	.2402611+02	1	112
.4044698+01	.1520680+01	.1095908+01	.5654491+01	.1663531+01	.1513262+01	1	113
.7340360+01	.1624962+01	.1597000+01	.9120333+01	.1628799+01	.1610777+01	1	114
.1099214+02	.1629430+01	.1612831+01	.1303236+02	.1627514+01	.1613101+01	1	115
.1517243+02	.1629524+01	.1613133+01	.1741439+02	.1629525+01	.1613137+01	1	116
.1977760+02	.6551080+01	.1300000+02	.2011095+01	.5022184+01	.2922120+01	1	117
.6401004+00	.3551437+01	.1304740+01	.5666340+00	.2012157+01	.3130002+00	1	118
-.1255116+01	.4755007+00	.1929165+01	.1523954+01	.8122377+00	.3540040+01	1	119
-.1008489+01	.1437154+01	.5149793+01	.1632816+01	.1595436+01	.6843653+01	1	120
-.1036719+01	.1624539+01	.8615625+01	.1639774+01	.1629432+01	.1048743+02	1	121
-.1639749+01	.1630210+01	.1252765+02	.1639972+01	.1630313+01	.1466772+02	1	122
-.1639775+01	.1630325+01	.1690768+02	.1639975+01	.1630320+01	.1927289+02	1	123
.6907755+01	.1300000+02	.5441500+00	.3519182+01	.3451962+01	.6255840+00	1	124
.2413614+01	.1037712+01	.1280255+01	.9019135+00	.2205543+00	.1537885+01	1	125
-.4817998+00	.1594287+01	.1620058+01	.1327426+01	.3005057+01	.1647577+01	1	126
-.1642526+01	.4614767+01	.1653716+01	.1666122+01	.6308642+01	.1655406+01	1	127
-.1669643+01	.0088013+01	.1655568+01	.1670103+01	.9952418+01	.1655594+01	1	128
-.1670175+01	.1199204+02	.1655597+01	.1670184+01	.1413271+02	.1655598+01	1	129
-.1670185+01	.1637467+02	.1655598+01	.1670185+01	.1873787+02	.7315220+01	1	130
.1300000+02	.1100534+00	.2764936+01	.4056983+01	.1025058+01	.1261809+01	1	131
-.2442720+01	.1446401+01	.1949775+00	.8266431+00	.1594117+01	.1238317+01	1	132
.7861754+00	.1639371+01	.1598021+01	.2396878+01	.1651775+01	.1659472+01	1	133
.4006594+01	.1654636+01	.1668476+01	.5700445+01	.1655512+01	.1669346+01	1	134
.7472416+01	.1655583+01	.1670148+01	.9344220+01	.1655594+01	.1670180+01	1	135
.1138444+02	.1655596+01	.1670164+01	.1352451+02	.1655596+01	.1670184+01	1	136
.1576647+02	.1655596+01	.1670164+01	.1812968+02	.7718685+01	.1300000+02	1	137
-.6464947+00	.1999573+01	.4663447+01	.1288272+01	.5037347+00	.3046381+01	1	138
-.1542159+01	.8118785+00	.1434651+01	.1623831+01	.1487158+01	.1780276+00	1	139
-.1647668+01	.1642982+01	.1788692+01	.1653808+01	.1665805+01	.3398398+01	1	140

AFWL-TR-67-131, Vol IV

-1655342+01-	-1669521+01	-5092248+01-	-1655556+01-	-1670074+01	-6864218+01	1	141
-1655580+01-	-1670164+01	-6736022+01-	-1655593+01-	-1670178+01	-1077624+02	1	142
-1655594+01-	-1670180+01	-1291631+02-	-1655594+01-	-1670180+01	-1515827+02	1	143
-1655594+01-	-1670180+01	-1752148+02	.0000000	.0000000	.0000000	1	144
14							
DIANE/SCAT LHM/ATRAHI-10A 30 FREQ. TEMP(50.-22500.) CI/ML 1/1000000							
.1000000+02	.6970000+03						
.1108.	.1700000+02						
.3912023+01	.1300000+02	.7670779+01	.9793608+01	.9026840+00	.6605788+01	1	1
.8589481+01	.2564498+01	.5267976+01	.7010211+01	.4231161+01	.3769586+01	1	2
.5389453+01	.5863943+01	.2198304+01	.3731792+01	.7478350+01	.6283974+00	1	3
.2123576+01	.9089196+01-	.7029054+00	.4881980+00	.1078327+02-	.1382526+01	1	4
-.9124451+00	.1255528+02-	.1582575+01-	.1447894+01	.1442704+02-	.1615618+01	1	5
-.1589713+01	.1640731+02-	.1619015+01-	.1600251+01	.1860738+02-	.1620030+01	1	6
-.1601409+01	.2084934+02-	.1620074+01-	.1601534+01	.2321255+02	.4248495+01	1	7
.1300000+02	.6360556+01	.6966270+01	.4653230+00	.5131334+01	.7667334+01	1	8
.2098846+01	.3696263+01	.6073066+01	.3736503+01	.2202030+01	.4476133+01	1	9
.5360647+01	.6576491+00	.2856192+01	.6973946+01-	.6107952+00	.1261654+01	1	10
.8584550+01-	.1307592+01-	.2905224+00	.1027857+02-	.1556612+01-	.1311025+01	1	11
.1205057+02-	.1618539+01-	.1573633+01	.1392238+02-	.1629237+01-	.1611358+01	1	12
.1596261+02-	.1630751+01-	.1616184+01	.1610267+02-	.1630738+01-	.1616767+01	1	13
.2034463+02-	.1630958+01-	.1616824+01	.2270784+02	.4605170+01	.1300000+02	1	14
.5116427+01	.6080620+01-	.4775553+01	.3765739+01	.6683284+01	.1574416+01	1	15
.2311951+01	.5149721+01	.3204099+01	.8131442+00	.3558721+01	.4026319+01	1	16
-.5009528+00	.1955694+01	.6439079+01-	.1239697+01	.3843207+00	.8049568+01	1	17
-.1524243+01-	.9373617+00	.9743564+01-	.1615626+01-	.1507051+01	.1151556+02	1	18
-.1636333+01-	.1614584+01	.1338737+02-	.1640026+01-	.1630162+01	.1542759+02	1	19
-.1640529+01-	.1632173+01	.1756760+02-	.1640590+01-	.1632413+01	.1980462+02	1	20
-.1640597+01-	.1632439+01	.2217283+02	.5010635+01	.1300000+02	.3233510+01	1	21
.6240157+01-	.6434634+00	.1759400+01	.4765396+01	.9711713+00	.2944063+00	1	22
.3244543+01	.2597323+01-	.8207614+00	.1692116+01	.4218493+01-	.1376034+01	1	23
.1526075+00	.5830964+01-	.1573391+01-	.1061996+01	.7441388+01-	.1635117+01	1	24
-.1570972+01	.9135370+01-	.1651497+01-	.1658714+01	.1090736+02-	.1655050+01	1	25
-.1669160+01	.1277917+02-	.1655633+01-	.1670493+01	.1481940+02-	.1655687+01	1	26
-.1670642+01	.1695940+02-	.1655694+01-	.1670659+01	.1920142+02-	.1655695+01	1	27
-.1670661+01	.2156463+02	.5416100+01	.1300000+02	.2488046+01	.5494681+01	1	28
-.1245313+01	.9900396+00	.3986983+01	.3652303+00-	.3364513+00	.2466719+01	1	29
.1998226+01-	.1164877+01	.8992905+00	.3610444+01-	.1503138+01-	.5360055+00	1	30
.5222812+01-	.1612666+01-	.1397255+01	.6833200+01-	.1645567+01-	.1633261+01	1	31
.8527174+01-	.1653761+01-	.1665864+01	.1029917+02-	.1655490+01-	.1670086+01	1	32
.1217098+02-	.1655667+01-	.1670586+01	.1421120+02-	.1655692+01-	.1670652+01	1	33
.1635126+02-	.1655695+01-	.1670660+01	.1859322+02-	.1655695+01-	.1670661+01	1	34
.2095643+02	.5828946+01	.1300000+02	.1712567+01	.4718411+01-	.1661091+01	1	35
.2745502+00	.3222141+01-	.2349755+00-	.8398721+00	.1655421+01	.1379347+01	1	36
-.1302854+01	.1211563+00	.2991342+01-	.1575230+01-	.1077792+01	.4603571+01	1	37
-.1634250+01-	.1564237+01	.6213536+01-	.1650966+01-	.1656717+01	.7907907+01	1	38
-.1654638+01-	.1660697+01	.4679900+01-	.1655603+01-	.1670409+01	.1155171+02	1	39
-.1655683+01-	.1670620+01	.1359193+02-	.1655694+01-	.1670657+01	.1573200+02	1	40
-.1655695+01-	.1670661+01	.1797396+02-	.1655695+01-	.1670661+01	.2033717+02	1	41
.6214608+01	.1300000+02	.9852841+00	.3982097+01-	.2437751+01-	.3351506+00	1	42
.2468536+01-	.8128647+00-	.1163633+01	.9027928+00	.8010684+00-	.1502455+01	1	43
-.5316392+00	.2412914+01-	.1612330+01-	.1394237+01	.4025093+01-	.1644633+01	1	44
-.1628604+01	.5635448+01-	.1653465+01-	.1664904+01	.7329914+01-	.1655411+01	1	45
-.1669886+01	.9101406+01-	.1655652+01-	.1670545+01	.1097321+02-	.1655690+01	1	46
-.1670646+01	.1301344+02-	.1655695+01-	.1670659+01	.1515350+02-	.1655695+01	1	47

-.1670661+01	.1739546+02	-.1655695+01	-.1670661+01	.1475867+02	.6551080+01	1	48
.1300000+02	.3737182+00	.3333110+01	-.2741502+01	-.7564327+00	.1810776+01	1	49
-.1312341+01	-.1349670+01	.2651517+00	.2464763+00	-.1564571+01	-.9894899+00	1	50
.1908242+01	-.1630632+01	-.1541308+01	.3520393+01	-.1649832+01	-.1652095+01	1	51
.5130741+01	-.1654475+01	-.1667841+01	.6824706+01	-.1655556+01	-.1670275+01	1	52
.8596690+01	-.1655673+01	-.1676602+01	.1046851+02	-.1655693+01	-.1670653+01	1	53
.1250873+02	-.1655695+01	-.1670660+01	.1464879+02	-.1655695+01	-.1670661+01	1	54
.1687075+02	-.1655695+01	-.1670661+01	.1425396+02	.6907755+01	.1300000+02	1	55
-.2073641+00	.2640113+01	-.3475896+01	-.1085504+01	.1114027+01	-.1847142+01	1	56
-.1475153+01	.3597944+00	.2344261+00	-.1604147+01	-.1323468+01	.1373259+01	1	57
-.1642330+01	-.1615774+01	.2985367+01	-.1652754+01	-.1642612+01	.4459573+01	1	58
-.1655169+01	-.1669406+01	.6284969+01	-.1655626+01	-.1670472+01	.8061686+01	1	59
-.1655685+01	-.1670632+01	.9933494+01	-.1655694+01	-.1670658+01	.1197372+02	1	60
-.1655696+01	-.1670661+01	.1411378+02	-.1655696+01	-.1670662+01	.1435574+02	1	61
-.1655696+01	-.1670662+01	.1871895+02	.7313220+01	.1300000+02	.7342393+00	1	62
.1850243+01	-.4082580+01	-.1331164+01	.3409584+00	-.2455188+01	-.1458805+01	1	63
-.9427587+00	-.8465665+00	.1629296+01	-.1528924+01	.7658790+00	-.1649264+01	1	64
-.1655688+01	.2377554+01	-.1654256+01	-.1667282+01	.3487533+01	-.1655518+01	1	65
-.1670168+01	.5661497+01	-.1655664+01	-.1670577+01	.7453488+01	-.1655690+01	1	66
-.1670648+01	.9325296+01	-.1655694+01	-.1670660+01	.1136552+02	-.1655695+01	1	67
-.1670661+01	.1350558+02	-.1655695+01	-.1670661+01	.1574754+02	-.1655695+01	1	68
-.1670661+01	.1811075+02	.7718685+01	.1300000+02	-.1095232+01	.1088755+01	1	69
-.4667628+01	-.1477261+01	.3722407+00	-.3063293+01	-.1604816+01	-.1329909+01	1	70
-.1454720+01	-.1642574+01	-.1617035+01	.157629+00	-.1652808+01	-.1662764+01	1	71
.1769359+01	-.1655116+01	-.1669300+01	.3379336+01	-.1655615+01	-.1670443+01	1	72
.5073299+01	-.1655681+01	-.1670625+01	.6845291+01	-.1655693+01	-.1670656+01	1	73
.8717099+01	-.1655695+01	-.1670661+01	.1075732+02	-.1655695+01	-.1670662+01	1	74
.1287739+02	-.1655695+01	-.1670662+01	.1513935+02	-.1655695+01	-.1670662+01	1	75
.1750256+02	.8131531+01	.1300000+02	-.1339639+01	.3067636+00	-.5288154+01	1	76
-.1561249+01	.9611407+00	.3683761+01	.1629758+01	-.1534490+01	-.2075224+01	1	77
-.1649511+01	-.1651010+01	.4626261+00	-.1654305+01	-.1667436+01	.1148835+01	1	78
-.1655513+01	-.1670173+01	.2758810+01	-.1655663+01	-.1670595+01	.4452773+01	1	79
-.1655693+01	-.1670674+01	.6224764+01	-.1655696+01	-.1670687+01	.8096572+01	1	80
-.1655699+01	-.1670690+01	.1013679+02	-.1655699+01	-.1670690+01	.1227686+02	1	81
-.1655699+01	-.1670690+01	.1451802+02	-.1655699+01	-.1670690+01	.1688203+02	1	82
.8517193+01	.1300000+02	.1476004+01	.2071814+01	-.5866648+01	-.1803735+01	1	83
-.1094321+01	-.4262221+01	-.1641224+01	-.1541305+01	-.2649787+01	-.1651591+01	1	84
-.1634385+01	-.1037540+01	-.1654023+01	-.1657307+01	.5703422+00	-.1654551+01	1	85
-.1660726+01	.2180317+01	-.1654630+01	-.1661390+01	.3674279+01	-.1654646+01	1	86
-.1661514+01	.5646270+01	-.1654646+01	-.1661535+01	.7518078+01	-.1654649+01	1	87
-.1661539+01	.9558300+01	-.1654649+01	-.1661539+01	.1169837+02	-.1654649+01	1	88
-.1661539+01	.1394033+02	-.1654649+01	-.1661539+01	.1630335+02	.0853665+01	1	89
.1300000+02	.1547760+01	.5154220+00	.6371356+01	.1625090+01	-.1354169+01	1	90
-.4766911+01	-.1647152+01	-.1602107+01	.3154489+01	-.1652428+01	-.1650378+01	1	91
-.1544245+01	-.1654406+01	-.1659473+01	.6563459+01	-.1654597+01	-.1661125+01	1	92
.1675609+01	-.1654638+01	-.1661461+01	.3369571+01	-.1654646+01	-.1661524+01	1	93
.5141562+01	-.1654647+01	-.1661535+01	.7013370+01	-.1654647+01	-.1661536+01	1	94
.9053542+01	-.1654647+01	-.1661537+01	.1119366+02	-.1654647+01	-.1661537+01	1	95
.1343562+02	-.1654647+01	-.1661537+01	.1579883+02	.9210340+01	.1300000+02	1	96
-.1593715+01	.9944575+00	.6906369+01	-.1658783+01	.1517358+01	.5301911+01	1	97
-.1651098+01	-.1635384+01	.3689497+01	-.1654197+01	-.1657137+01	-.2079256+01	1	98
-.1654902+01	-.1651275+01	.4693774+00	-.1654998+01	.1662036+01	.1140596+01	1	99
-.1655018+01	-.1662190+01	.2834558+01	-.1655022+01	-.1662218+01	.4606550+01	1	100
-.1655023+01	-.1662223+01	.6476358+01	-.1655023+01	-.1662224+01	.8518579+01	1	101
-.1655023+01	-.1662224+01	.1065865+02	-.1655023+01	-.1662224+01	.1290061+02	1	102

-.1650023+01	-.160222+01	.1526302+02	.9615005+01	.1300000+02	-.1673135+01	1	103
-.1332778+01	-.7514500+01	-.1044007+01	-.1599187+01	-.5010094+01	-.1653051+01	1	104
-.1650101+01	-.4790000+01	-.1044007+01	-.1654799+01	-.2667453+01	-.1654078+01	1	105
-.1661555+01	-.1677570+01	-.1654078+01	-.1651000+01	-.5010094+01	-.1654078+01	1	106
-.1661955+01	-.2220001+01	-.1654078+01	-.1651767+01	-.3790032+01	-.1654078+01	1	107
-.1661969+01	-.5070100+01	-.1654078+01	-.1661970+01	-.7910302+01	-.1654078+01	1	108
-.1661970+01	-.1005005+02	-.1654078+01	-.1661970+01	-.1279241+02	-.1654078+01	1	109
-.1661970+01	-.1655002+02	-.1007127+02	.1300000+02	-.1654078+01	-.1654078+01	1	110
-.0812270+01	-.1655002+02	-.1654078+01	-.1651821+01	-.1654078+01	-.1654078+01	1	111
-.4904070+01	-.1654078+01	-.1654078+01	-.3270049+01	-.1654078+01	-.1654078+01	1	112
-.1665772+01	-.1654078+01	-.1654078+01	-.7579001+01	-.1654078+01	-.1654078+01	1	113
-.1610103+01	-.1654078+01	-.1654078+01	.3390154+01	-.1654078+01	-.1654078+01	1	114
-.5201702+01	-.1654078+01	-.1654078+01	.7302104+01	-.1654078+01	-.1654078+01	1	115
-.9442251+01	-.1654078+01	-.1654078+01	.1164421+02	-.1654078+01	-.1654078+01	1	116
.1404742+02	.00000000	.00000000	.00000000	.00000000	.00000000	1	117
111							
DATA LINE 50. EV - 2250. EV 11 FREQ. CHD/GAL 9/30/66 000000							
.1100000+02	.5150000+03	.2108	.1300000+02				
.3912023+01	.1300000+02	.7670779+01	.9793608+01	.9026840+00	.6605787+01	1	1
.8589481+01	.2584496+01	.5267976+01	.7010212+01	.4231161+01	.3769586+01	1	2
.5389464+01	.5863443+01	.2198236+01	.5731793+01	.7478350+01	.6075961+00	1	3
.2123568+01	.9089196+01	.1032266+01	.4052223+00	.1078327+02	.2576200+01	1	4
-.1010208+01	.1255526+02	.3652110+01	.1936675+01	.1442704+02	.4024813+01	1	5
-.2213703+01	.1646731+02	.4086466+01	.2256554+01	.1860738+02	.4044103+01	1	6
-.2261769+01	.2084934+02	.4044426+01	.2262354+01	.2321255+02	.4248495+01	1	7
.1300000+02	.6360555+01	.8966270+01	.4653230+00	.5131334+01	.7667335+01	1	8
.2096846+01	.3690263+01	.6073307+01	.3736503+01	.2201941+01	.4476133+01	1	9
.5360647+01	.0340063+00	.2850188+01	.6973946+01	.9443694+00	.1260578+01	1	10
.8584550+01	.2550517+01	.3504131+00	.1027057+02	.3471523+01	.1732668+01	1	11
.1203057+02	.4754463+01	.2461847+01	.1342238+02	.4463186+01	.2648407+01	1	12
.1546201+02	.4494294+01	.2675960+01	.1810267+02	.4498067+01	.2679286+01	1	13
.2034463+02	.4494474+01	.2675965+01	.2270784+02	.4605170+01	.1300000+02	1	14
.5118427+01	.8080620+01	.4775553+01	.3765739+01	.6683890+01	.1574416+01	1	15
.2311900+01	.5149722+01	.3204099+01	.7972127+00	.3558421+01	.4826319+01	1	16
-.7776048+00	.1955142+01	.6439374+01	.2352157+01	.3680257+00	.8049568+01	1	17
-.3913435+01	.1200052+01	.9743564+01	.5155346+01	.2443619+01	.1151556+02	1	18
-.5713957+01	.3002142+01	.1338737+02	.5840099+01	.3128414+01	.1542759+02	1	19
-.5857942+01	.3146340+01	.1756766+02	.5860147+01	.3148498+01	.1980962+02	1	20
-.5860379+01	.3146731+01	.2417263+02	.5010635+01	.1300000+02	.3233510+01	1	21
.6240158+01	.6434634+00	.1756730+01	.4765396+01	.9711713+00	.2377816+00	1	22
.3244532+01	.2597323+01	.1316611+01	.1640548+01	.4218403+01	.2900287+01	1	23
.1088753+00	.5830964+01	.4472719+01	.1453981+01	.7441388+01	.6015867+01	1	24
-.2953809+01	.9135370+01	.7188579+01	.4012917+01	.1090736+02	.7678364+01	1	25
-.4408943+01	.1277917+02	.7783761+01	.4488975+01	.1481940+02	.7796529+01	1	26
-.4500025+01	.1695946+02	.7800303+01	.4501350+01	.1920142+02	.7800495+01	1	27
-.4501443+01	.2156463+02	.5416100+01	.1300000+02	.2488027+01	.5494681+01	1	28
-.1245313+01	.9802400+00	.3986983+01	.3652303+00	.5403322+00	.2466547+01	1	29
.1948226+01	.2118488+01	.8873048+00	.3610494+01	.3698772+01	.6865394+00	1	30
.5222812+01	.5238446+01	.2205464+01	.6833200+01	.6635899+01	.3528559+01	1	31
.8527174+01	.7481913+01	.4254584+01	.1029917+02	.7744371+01	.4459304+01	1	32
.1217040+02	.7793034+01	.4445919+01	.1421120+02	.7799632+01	.4500849+01	1	33
.1635126+02	.7800421+01	.4501438+01	.1859322+02	.7800506+01	.4501502+01	1	34
.2095643+02	.5828946+01	.1300000+02	.1711744+01	.4718412+01	.1861091+01	1	35
.2153759+00	.3222130+01	.2349755+00	.1353479+01	.1653699+01	.1379347+01	1	36

-.2934470+01	.7477301+01	.2991342+01	-.4501124+01	-.1462050+01	.4603571+01	1	37
-.5968822+01	-.2909254+01	.6213938+01	-.7124545+01	-.3958582+01	.7907907+01	1	38
-.7640359+01	-.4305795+01	.9679400+01	-.7775538+01	-.4482805+01	.1155171+02	1	39
-.7797232+01	-.4444057+01	.1359443+02	-.7800128+01	-.4501220+01	.1573200+02	1	40
-.7800473+01	-.4501478+01	.1747346+02	-.7800511+01	-.4501505+01	.2033717+02	1	41
.6214008+01	.1300000+02	.9754031+00	.3982122+01	.2437751+01	-.5385135+00	1	42
.2408390+01	-.6128847+00	.2114707+01	.8929052+00	.8010684+00	.3693213+01	1	43
-.6610010+00	.2412914+01	-.5228915+01	-.2196674+01	.4025093+01	-.6568900+01	1	44
-.3467782+01	.5635448+01	.7431179+01	-.4213687+01	.7329414+01	-.7727266+01	1	45
-.4440312+01	.9101406+01	.7780888+01	-.4442799+01	.1097321+02	-.7798995+01	1	46
-.4500356+01	.1301344+02	.7800336+01	-.4501357+01	.1515350+02	.7800496+01	1	47
-.4501476+01	.1739546+02	.7800513+01	-.4501489+01	.1975867+02	.6551080+01	1	48
.1300000+02	.3263614+00	.3333197+01	-.2941502+01	.1197476+01	.1809718+01	1	49
-.1312341+01	.2779165+01	.2297429+00	.2964783+00	.4340113+01	.1330730+01	1	50
.1908242+01	-.5830171+01	-.2777254+01	.3520343+01	.6994638+01	.3846726+01	1	51
.5130741+01	.7595144+01	.4344240+01	.6824706+01	.7762473+01	-.4472907+01	1	52
.8590698+01	.7794566+01	.4446796+01	.1046851+02	.7797394+01	-.4500861+01	1	53
.1250873+02	.7800423+01	-.4501371+01	.1464879+02	.7800505+01	-.4501432+01	1	54
.1689075+02	.7800514+01	-.4501434+01	.1925346+02	.6407755+01	.1300000+02	1	55
-.3667475+00	.3041405+01	-.3475046+01	-.1849768+01	.1508441+01	.1847142+01	1	56
-.3431688+01	.7271508+01	.2384211+00	-.5027200+01	.1617680+01	.1373259+01	1	57
-.6407464+01	.2943977+01	.2985387+01	-.7326094+01	.3904645+01	.4595730+01	1	58
-.7694618+01	.4267308+01	.6289644+01	-.7781694+01	.4352661+01	.8061686+01	1	59
-.7797495+01	.4368231+01	.9433444+01	-.7800134+01	.4370717+01	.1197372+02	1	60
-.7800469+01	.4371045+01	.1411378+02	-.7800509+01	.4371084+01	.1535574+02	1	61
-.7800513+01	.4371088+01	.1871895+02	.7313220+01	.1300000+02	.1157865+01	1	62
.2133816+01	.4082580+01	.2646464+01	.5932061+00	.2455186+01	.4271959+01	1	63
-.9774310+00	.6465657+00	.5761323+01	-.2456583+01	.7658770+00	.6947648+01	1	64
-.3613404+01	.2377554+01	.7561668+01	.4192540+01	.3987533+01	.7752075+01	1	65
-.4367391+01	.5681497+01	.7792110+01	.4403795+01	.7453448+01	.7799217+01	1	66
-.4410244+01	.9325240+01	.7800346+01	-.4411268+01	.1136552+02	.7800495+01	1	67
-.4411403+01	.1350554+02	.7800512+01	-.4411414+01	.1574754+02	.7800514+01	1	68
-.4411421+01	.1811075+02	.7800492+01	.1000000+02	.2340474+01	.1027813+01	1	22
-.3817020+01	.3357477+01	.5074431+01	-.2774413+01	.3658442+01	.2479117+00	1	23
-.2487032+01	.4051671+01	.6431775+00	.2002444+01	.4724095+01	.1314924+01	1	24
-.1391003+01	.5459400+01	.2049157+01	.5894466+00	.6149161+01	.2736881+01	1	25
.2121785+00	.6631307+01	.3216443+01	.8582077+00	.7447748+01	.4074612+01	1	26
.2516571+01	.7750648+01	.432813	.014760271	.017718685	.0113		02
-.192545	.011445146	-.014667028	.013496158	-.011251106	-.013063293		01
-.5044348	-.01671184	-.0145472	.016420971	-.013039836	.011576929		
-.7331566	-.013934717	.011769354	-.017687355	.014279416	.013379336		01
-.7778715	-.014367255	.015073244	-.017796773	.01438458	.016845291		01
-.7749437	-.014387615	.018717044	-.017800434	.014388096	.011075732		02
-.7800505	-.014388154	.011289734	-.017800513	.014388166	.011513935		02
-.7800514	-.014388167	.011750256	.017824046	.011	.0102		-.2619758
.5205092	-.014152466	.013794436	.014534123	-.013133091	.014093477		01
-.7520297	-.012821718	.014482227	.01114	.012415127	.015143603		01
-.1749136	-.011726302	.015852302	-.012503016	.019242025	-.016492848		01
-.3135128	-.011225313	-.0169162	.013549538	.015234468	-.017551325		01
-.4170124	.017181857	.01772345	-.014369367	.014425556	.01		

DIANE/SCAT LIMESTONE-18 5-25-67 TEMP(50-1.E4) AK/RW INPUT TAPE(3971)

.1000000+01	.6150000+03						
.1131.	.1500000+02						
.3912023+01	.1300000+02	.8675739+01	.9610432+01	.4085977+00	.8105946+01	1	1

.6680718+01	.2095978+01	.7312465+01	.7921584+01	.3785015+01	.6054209+01	1	2
.6534984+01	.5446025+01	.4513311+01	.5005622+01	.7100656+01	.2988857+01	1	3
.3618555+01	.0748771+01	.1437020+01	.2135081+01	.1048225+02	.7073347+01	1	4
.7047927+00	.1230788+02	.1154262+01	.6237974+00	.1423141+02	.1495596+01	1	5
-.1421314+01	.1632690+02	.1679594+01	.1638634+01	.1850871+02	.1678021+01	1	6
-.1657261+01	.2077446+02	.1685436+01	.1646921+01	.2315317+02	.4248495+01	1	7
.1300000+02	.6643770+01	.9393347+01	.1733738+01	.7887182+01	.8622951+01	1	8
.1670099+01	.0809400+01	.7477360+01	.3351961+01	.5412983+01	.6107136+01	1	9
.5021457+01	.4048195+01	.4013194+01	.0694787+01	.2613557+01	.3481740+01	1	10
.8367464+01	.1068491+01	.2091240+01	.1011814+02	.3649802+00	.5733847+00	1	11
.1193973+02	.1264002+01	.7512444+00	.1384251+02	.1583438+01	.1465864+01	1	12
.1590113+02	.1644906+01	.1617063+01	.1804872+02	.1654964+01	.1637278+01	1	13
.2029289+02	.1654210+01	.1636103+01	.2265962+02	.4605170+01	.1300000+02	1	14
.6549745+01	.9171733+01	.4638247+00	.7893381+01	.8390442+01	.1223806+01	1	15
.6485951+01	.7213231+01	.2921444+01	.4979644+01	.5780037+01	.4615015+01	1	16
.3578981+01	.4499040+01	.6293869+01	.2077455+01	.3105132+01	.7951391+01	1	17
.4739419+00	.1568113+01	.4673228+01	.0293367+00	.7304373+01	.1145878+02	1	18
-.1421709+01	.1179559+01	.1333036+02	.1587674+01	.1557931+01	.1538090+02	1	19
-.1635843+01	.1621662+01	.1752464+02	.1645210+01	.1627620+01	.1976915+02	1	20
-.1648363+01	.1628008+01	.2213270+02	.5010635+01	.1300000+02	.8075697+01	1	21
.8700250+01	.4595196+00	.7114554+01	.7730998+01	.7450793+00	.5907481+01	1	22
.6510128+01	.2442744+01	.4579572+01	.5281151+01	.4118560+01	.2689122+01	1	23
.3766616+01	.5763295+01	.1271412+01	.2146038+01	.7388102+01	.1682896+00	1	24
.5505511+00	.4064004+01	.1083307+01	.7824806+00	.1086512+02	.1471228+01	1	25
-.1442730+01	.1273873+02	.1614013+01	.1602233+01	.1477933+02	.1641765+01	1	26
-.1625071+01	.1691445+02	.1645996+01	.1627616+01	.1916142+02	.1646457+01	1	27
-.1626096+01	.2152463+02	.5416100+01	.1300000+02	.7099274+01	.8082603+01	1	28
-.1455217+01	.8360391+01	.6910717+01	.2394144+00	.5267021+01	.5642912+01	1	29
.1409158+01	.3792483+01	.4186472+01	.3552572+01	.2158931+01	.2599143+01	1	30
.5177024+01	.6346964+00	.1042625+01	.6791646+01	.6100469+00	.3965872+00	1	31
.6488859+01	.1321650+01	.1287241+01	.1025912+02	.1579958+01	.1568377+01	1	32
.1213102+02	.1636711+01	.1619658+01	.1417161+02	.1642377+01	.1624030+01	1	33
.1631426+02	.1634090+01	.1615647+01	.1856552+02	.1622558+01	.1604148+01	1	34
.2094039+02	.5628448+01	.1300000+02	.5610553+01	.7208937+01	.1995222+01	1	35
.5076647+01	.6021542+01	.3232594+00	.4016769+01	.4645857+01	.1319231+01	1	36
.2593735+01	.3048582+01	.2946228+01	.1094095+01	.1446612+01	.4542698+01	1	37
-.2452261+00	.6070865+01	.6174301+01	.1165114+01	.9979064+00	.7470635+01	1	38
-.1527705+01	.1447304+01	.9649748+01	.1608402+01	.1563173+01	.1153236+02	1	39
-.1614317+01	.1590065+01	.1358095+02	.1614593+01	.1545777+01	.1572324+02	1	40
-.1614744+01	.1598424+01	.1740556+02	.1614802+01	.1596400+01	.2032881+02	1	41
.8214600+01	.1300000+02	.4777401+01	.0264780+01	.2526591+01	.3888042+01	1	42
.5065875+01	.6746574+00	.2577773+01	.3575127+01	.7533653+00	.1137940+01	1	43
.2141452+01	.2373701+01	.1267479+00	.9116683+00	.3994013+01	.9749202+00	1	44
-.1347805+00	.5614561+01	.1421735+01	.1016144+01	.7316951+01	.1565253+01	1	45
-.1460591+01	.9092212+01	.1598690+01	.1574805+01	.1096472+02	.1611684+01	1	46
-.1544290+01	.1300506+02	.1614561+01	.1596286+01	.1514514+02	.1614750+01	1	47
-.1546436+01	.1738711+02	.1614764+01	.1596449+01	.1975032+02	.6531080+01	1	48
.1300000+02	.4393973+01	.5685308+01	.3000773+01	.3281121+01	.4431100+01	1	49
-.1360186+01	.1680598+01	.3152575+01	.2612464+00	.4418119+00	.1420910+01	1	50
.1888824+01	.6289791+00	.6103329+00	.3507778+01	.1210063+01	.5958487+00	1	51
.5121326+01	.1459080+01	.1321215+01	.6816142+01	.1571091+01	.1531202+01	1	52
.8988305+01	.1609350+01	.1541355+01	.1046014+02	.1613577+01	.1595590+01	1	53
.1250037+02	.1613967+01	.1546043+01	.1464044+02	.1614003+01	.1596091+01	1	54
.1688240+02	.1614607+01	.1546096+01	.1924561+02	.6907755+01	.1300000+02	1	55
.4003619+01	.5020353+01	.3513272+01	.2878964+01	.3870614+01	.1684519+01	1	56

.144270+01	.2594667+01	.2566313-00	.4736788-01	.1160399+01	.1363524+01	1	57
-.8506524-00	.1979728-00	.2976982+01	.1332553+01	.1148770+01	.4587357+01	1	58
-.1563150+01	.1525692+01	.6281334+01	.1607305+01	.1586443+01	.8053328+01	1	59
-.1612227+01	.1594165+01	.9925137+01	.1612847+01	.1595257+01	.1196536+02	1	60
-.1612928+01	.1595401+01	.1410543+02	.1612938+01	.1545418+01	.1634739+02	1	61
-.1612939+01	.1595420+01	.1671060+02	.7313220+01	.1300000+02	.3068661+01	1	62
.4325955+01	.4104624+01	.2065882+01	.3037716+01	.2477642+01	.6609440-00	1	63
.1557523+01	.8573222-00	.6227073-00	.1064714+00	.7575462-00	.1330123+01	1	64
-.1016882+01	.2369293+01	.1554613+01	.1482311+01	.3979266+01	.1604882+01	1	65
-.1577101+01	.5673158+01	.1611814+01	.1542292+01	.7445134+01	.1612466+01	1	66
-.1594836+01	.9316940+01	.1613151+01	.1545238+01	.1135716+02	.1613175+01	1	67
-.1595292+01	.1349723+02	.1613178+01	.1545248+01	.1573411+02	.1613178+01	1	68
-.1595299+01	.1610440+02	.7718665+01	.1300000+02	.1435811+01	.3481097+01	1	69
-.4700577+01	.2654173-00	.2047148+01	.3080228+01	.7686510-00	.5691915-00	1	70
-.1461761+01	.1355208+01	.7574952-00	.1506458-00	.1561937+01	.1611049+01	1	71
.1761186+01	.1610176+01	.1566725+01	.3371087+01	.1619959+01	.1598685+01	1	72
.5064962+01	.1620906+01	.1603058+01	.6436937+01	.1621300+01	.1604004+01	1	73
.8708742+01	.1621350+01	.1604154+01	.1074896+02	.1621356+01	.1604174+01	1	74
.1288903+02	.1621357+01	.1604176+01	.1513099+02	.1621357+01	.1604176+01	1	75
.1749420+02	.6131531+01	.1300000+02	.3236964+01	.2540860+01	.5314523+01	1	76
-.9164400-00	.1074984+01	.3643146+01	.1347242+01	.3556157-00	.2080484+01	1	77
-.1564670+01	.1268677+01	.4684880-00	.1618108+01	.1553279+01	.1141949+01	1	78
-.1631342+01	.1610556+01	.2751826+01	.1632564+01	.1618414+01	.4445695+01	1	79
-.1633319+01	.1620645+01	.6217669+01	.1633301+01	.1621033+01	.8089475+01	1	80
-.1633319+01	.1621094+01	.1012470+02	.1633321+01	.1621102+01	.1226976+02	1	81
-.1633322+01	.1621103+01	.1451172+02	.1633322+01	.1621103+01	.1687493+02	1	82
.8517193+01	.1300000+02	.8574736-00	.1660890+01	.5890652+01	.1373156+01	1	83
.1771358-00	.4270680+01	.1556449+01	.9485637-00	.2658732+01	.1620057+01	1	84
-.1440176+01	.1046925+01	.1638472+01	.1611063+01	.5634682-00	.1643152+01	1	85
-.1634653+01	.2173335+01	.1644295+01	.1639429+01	.3867202+01	.1644518+01	1	86
-.1640320+01	.5639176+01	.1644557+01	.1640474+01	.7510981+01	.1644563+01	1	87
-.1640499+01	.9551202+01	.1644564+01	.1640502+01	.1169127+02	.1644564+01	1	88
-.1640502+01	.1393323+02	.1644564+01	.1640502+01	.1629644+02	.8853665+01	1	89
.1300000+02	.1343384+01	.2916410-00	.6391447+01	.1557093+01	.9314070-00	1	90
-.4773190+01	.1627536+01	.1517606+01	.3162012+01	.1648053+01	.1645488+01	1	91
-.1551470+01	.1653347+01	.1664932+01	.5876660+01	.1655531+01	.1670295+01	1	92
.1666628+01	.1655699+01	.1670763+01	.3362494+01	.1655732+01	.1670851+01	1	93
.5134467+01	.1655738+01	.1670866+01	.7006273+01	.1655738+01	.1670868+01	1	94
.9046494+01	.1655739+01	.1670869+01	.1118656+02	.1655739+01	.1670869+01	1	95
.1342852+02	.1655739+01	.1670869+01	.1579173+02	.9210340+01	.1300000+02	1	96
-.1466661+01	.3085461-00	.6922303+01	.1599281+01	.1263321+01	.5307561+01	1	97
-.1640667+01	.1606685+01	.3676950+01	.1652282+01	.1661370+01	.2086389+01	1	98
-.1655047+01	.1664259+01	.4762413-00	.1655634+01	.1670589+01	.1133616+01	1	99
-.1655719+01	.1670817+01	.2827482+01	.1655735+01	.1670860+01	.4599455+01	1	100
-.1655738+01	.1670867+01	.6471260+01	.1655739+01	.1670869+01	.8511481+01	1	101
-.1655739+01	.1670869+01	.1065155+02	.1655739+01	.1670869+01	.1289351+02	1	102
-.1655739+01	.1670869+01	.1525672+02	.0000000	.0000000	.0000000	1	103

53

DIANE/SCAT NL-1A TLMPI1.5-1.E4) 11-6-67 SAUV INPUT TAPES(3956.39631

.1000000+01	.9840000+03						
1013.	.2400000+02						
.4054651-00	.1300000+02	.3509196+01	.1008005+02	.3783041+01	.3471987+01	1	1
.9794615+01	.1385241+01	.3468540+01	.9437083+01	.1364030+01	.3449899+01	1	2
.8334518+01	.4314791+01	.3388121+01	.7223265+01	.7356307+01	.3193403+01	1	3
.6346392+01	.1034880+02	.2557088+01	.5388150+01	.1311818+02	.1190349+01	1	4

.3970299+01	.1536146+02	.6092082+00	.2139229+01	.1734564+02	.2344850+01	1	5
.1021474+00	.1940517+02	.3452796+01	.1910473+01	.2154921+02	.3825573+01	1	6
.3379644+01	.2380469+02	.3774386+01	.3647996+01	.2628298+02	.8109302+00	1	7
.1300000+02	.6940509+01	.1222961+02	.6876729+02	.6947318+01	.1199086+02	1	8
.2487041+01	.6762675+01	.1164342+02	.5147451+01	.6207716+01	.1036075+02	1	9
.7610481+01	.5079655+01	.8445145+01	.9649177+01	.3595483+01	.6586633+01	1	10
.1138644+02	.2015636+01	.4766942+01	.1311536+02	.7511151+00	.3066513+01	1	11
.1492323+02	.3210947+00	.1550232+01	.1694174+02	.1454838+01	.1486794+00	1	12
.1930475+02	.2580930+01	.1552960+01	.2140362+02	.3119184+01	.2627279+01	1	13
.2387260+02	.3208141+01	.3157144+01	.2625014+02	.1223775+01	.1300000+02	1	14
.9534134+01	.1283570+02	.1740199+01	.8935943+01	.1220352+02	.3679682+01	1	15
.8148288+01	.1124001+02	.5027299+01	.7121502+01	.9042005+01	.7577958+01	1	16
.6057307+01	.0085351+01	.9305496+01	.5020742+01	.6737324+01	.1114097+02	1	17
.3618451+01	.5260672+01	.1307381+02	.1773436+01	.3524904+01	.1494307+02	1	18
.5170245+01	.1672490+01	.1685947+02	.1357694+01	.1045013+00	.1402759+02	1	19
.2342778+01	.1630014+01	.2135368+02	.2738518+01	.2573140+01	.2365454+02	1	20
.2600305+01	.2765774+01	.2604006+02	.1604438+01	.1300000+02	.1124312+02	1	21
.1205103+02	.1934778+01	.1053754+02	.1217430+02	.3750118+01	.9455988+01	1	22
.1145478+02	.5607440+01	.7957691+01	.9996557+01	.7474419+01	.6262373+01	1	23
.6267379+01	.4257103+01	.4779185+01	.6606038+01	.1096981+02	.3502120+01	1	24
.5112191+01	.1281469+02	.2037461+01	.3511820+01	.1473254+02	.3673397+00	1	25
.1653693+01	.1666963+02	.1189084+01	.1225017+00	.1880328+02	.2133084+01	1	26
.1536748+01	.2107965+02	.2451100+01	.2332654+01	.2337538+02	.2446392+01	1	27
.2418186+01	.2581386+02	.1945910+01	.1300000+02	.1266594+02	.1256729+02	1	28
.1865336+01	.1094848+02	.1219764+02	.3683805+01	.9411291+01	.1135856+02	1	29
.5475748+01	.7960069+01	.9916333+01	.7267267+01	.6550690+01	.8341749+01	1	30
.9060431+01	.5070514+01	.6693267+01	.1079767+02	.3546442+01	.5014780+01	1	31
.1259565+02	.2080595+01	.3401100+01	.1449631+02	.4357301+00	.1646202+01	1	32
.1645245+02	.1090748+01	.7913120+01	.1459128+02	.1961161+01	.1560146+01	1	33
.2082433+02	.2198676+01	.2129746+01	.2313738+02	.2157405+01	.2134409+01	1	34
.2560102+02	.2302585+01	.1300000+02	.1142066+02	.1238420+02	.1703687+01	1	35
.1097220+02	.1197204+02	.3477480+01	.9621047+01	.1126823+02	.5259408+01	1	36
.8121883+01	.9604320+01	.7050742+01	.6028943+01	.0206484+01	.8819183+01	1	37
.5252689+01	.6583501+01	.1055480+02	.3673767+01	.4943723+01	.1235972+02	1	38
.2054323+01	.3263079+01	.1423419+02	.4191158+00	.1508998+01	.1620215+02	1	39
.1002779+01	.2028417+00	.1833908+02	.1784041+01	.1503991+01	.2056247+02	1	40
.1931637+01	.1800100+01	.2288601+02	.1902154+01	.1840824+01	.2532376+02	1	41
.2706050+01	.1300000+02	.1154662+02	.1207397+02	.1434319+01	.1084905+02	1	42
.1164296+02	.3212077+01	.9605706+01	.1081612+02	.4994704+01	.8109213+01	1	43
.9339033+01	.6765598+01	.6617472+01	.7763711+01	.8527066+01	.5128184+01	1	44
.6185382+01	.1025785+02	.3612790+01	.4606281+01	.1205938+02	.1895637+01	1	45
.2983826+01	.1392861+02	.1728474+00	.1265432+01	.1588496+02	.1157761+01	1	46
.4189447+00	.1800025+02	.1704918+01	.1513633+01	.2018864+02	.1626465+01	1	47
.1789444+01	.2241494+02	.1843797+01	.1824239+01	.2477863+02	.3113515+01	1	48
.1300000+02	.1075528+02	.1156157+02	.1159183+01	.1041710+02	.1122079+02	1	49
.2915057+01	.9453594+01	.1041677+02	.4695267+01	.8045428+01	.8938454+01	1	50
.6451512+01	.6561695+01	.7327937+01	.8198958+01	.4905675+01	.5701143+01	1	51
.9914869+01	.3049874+01	.4058441+01	.1168979+02	.1124346+01	.2222513+01	1	52
.1350140+02	.5595050+00	.3712281+00	.1538307+02	.1510027+01	.1129311+01	1	53
.1742499+02	.1774892+01	.1715453+01	.1956528+02	.1829856+01	.1815646+01	1	54
.2180727+02	.1844033+01	.1826772+01	.2417048+02	.3526360+01	.1300000+02	1	55
.9700133+01	.1097746+02	.8034166+00	.9522104+01	.1058174+02	.2549041+01	1	56
.8928445+01	.9537628+01	.4323031+01	.7542137+01	.8012245+01	.6062694+01	1	57
.5731730+01	.6357613+01	.7765798+01	.3782444+01	.4623473+01	.9414549+01	1	58
.1828666+01	.2836793+01	.1111925+02	.8867510+01	.1040924+01	.1289347+02	1	59

-.1091265+01	-.5915076-00	.1476568+02	-.1625054+01	-.1557727+01	.1640597+02	1	60
-.1802905+01	-.1792435+01	.1094604+02	-.1841091+01	-.1824132+01	.2118401+02	1	61
-.1845713+01	-.1027552+01	.2555123+02	.3912023+01	.1300000+02	.8403888+01	1	62
.1035146+02	.4315471-00	.6205724+01	.4826730+01	.2162461+01	.7470890+01	1	63
.6566604+01	.3900738+01	.6191456+01	.6878801+01	.5582059+01	.4535295+01	1	64
.5131669+01	.7226085+01	.2760726+01	.3419310+01	.8846562+01	.1004981+01	1	65
.1692444+01	.1054290+02	-.4652459-00	.1556838+01	.1231538+02	-.1380525+01	1	66
-.1244369+01	.1418738+02	-.1754041+01	-.1727784+01	.1622851+02	-.1826050+01	1	67
-.1695167+01	.1037572+02	-.1795750+01	-.1775917+01	.2065647+02	-.1735504+01	1	68
-.1716830+01	.2308332+02	.4248445+01	.1300000+02	.7358771+01	.9584414+01	1	69
.6147072+01	.6601025+01	.0842797+01	.1763008+01	.5825688+01	.7544659+01	1	70
.3455035+01	.4488719+01	.5940538+01	.5101621+01	.2965413+01	.4130878+01	1	71
.6727065+01	.1441414+01	.2417593+01	.8343762+01	.1205101+01	.7828608-00	1	72
.1004164+02	.1020371+01	.5085568-00	.1182742+02	-.1538906+01	-.1226558+01	1	73
.1374520+02	-.1677691+01	-.1544696+01	.1564489+02	-.1657349+01	-.1606370+01	1	74
.1804487+02	.1628778+01	-.1605662+01	.2032146+02	-.1623745+01	-.1604915+01	1	75
.2264051+02	.4605170+01	.1300000+02	.6512639+01	.8669656+01	-.3784718-00	1	76
.5586735+01	.7080273+01	.1281751+01	.4480772+01	.6272324+01	.2942952+01	1	77
.3039505+01	.4730273+01	.4578172+01	.1708234+01	.3458182+01	.6212607+01	1	78
.5603825-00	.2450340+01	.7887855+01	-.3998702-00	.1315948+01	.9620762+01	1	79
-.1134294+01	.9222192+01	.1145064+02	-.1500514+01	-.9843932-00	.1335947+02	1	80
-.1602970+01	.1494182+01	.1540931+02	-.1619043+01	-.1591189+01	.1755078+02	1	81
-.1621596+01	.1603463+01	.1979291+02	-.1623029+01	-.1604740+01	.2215614+02	1	82
.5010635+01	.1300000+02	.6541936+01	.8314122+01	-.9320016-00	.5355249+01	1	83
.7316620+01	.7260391-00	.4081105+01	.6126346+01	.2393574+01	.2803290+01	1	84
.4491397+01	.4070263+01	.1491705+01	.3775158+01	.5747148+01	.1446782-00	1	85
.2423579+01	.7402473+01	-.6327777-00	.6896498-00	.9113836+01	-.1358760+01	1	86
-.5229320-00	.1080982+02	.1535748+01	-.1359010+01	.1276235+02	-.1593953+01	1	87
-.1574028+01	.1480267+02	-.1619682+01	-.1602549+01	.1694277+02	-.1622345+01	1	88
-.1604403+01	.1916474+02	-.1622404+01	-.1604524+01	.2154795+02	.5416100+01	1	89
.1300000+02	.6732098+01	.8140223+01	-.1479233+01	.5643504+01	.7154653+01	1	90
.2083193-00	.4317666+01	.5681898+01	.1900093+01	.2709182+01	.4456059+01	1	91
.3567054+01	.4970839-00	.2896832+01	.5199951+01	-.3109239-00	.1348124+01	1	92
.6615177+01	-.1021264+01	.1331048-00	.8510235+01	.1369064+01	-.1178421+01	1	93
.1026244+02	.1572006+01	.1547793+01	.1215428+02	.1615302+01	-.1598091+01	1	94
.1419451+02	-.1618674+01	.1602104+01	.1633458+02	.1614927+01	-.1602470+01	1	95
.1857654+02	-.1618954+01	.1602510+01	.2893975+02	.5028946+01	.1300000+02	1	96
.6407169+01	.7620240+01	.2088536+01	.5484418+01	.6538342+01	-.3204607-00	1	97
.4064808+01	.4975877+01	.1339534+01	.2324453+01	.3558284+01	.2964708+01	1	98
.7163714-00	.1754838+01	.4580099+01	-.4954278-00	.2561196-00	.6147082+01	1	99
-.1265445+01	.7737118-00	.7891189+01	-.1561463+01	.1503413+01	.4663208+01	1	100
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	101
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	102
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	103
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	104
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	105
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	106
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	107
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	108
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	109
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	110
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	111
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	112
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	113
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	114
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	115
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	116
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	117
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	118
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	119
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	120
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	121
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	122
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	123
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	124
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	125
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	126
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	127
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	128
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	129
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	130
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	131
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	132
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	133
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	134
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	135
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	136
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	137
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	138
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	139
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	140
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	141
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	142
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	143
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	144
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	145
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	146
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	147
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	148
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	149
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	150
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	151
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	152
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	153
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	154
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	155
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	156
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	157
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	158
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	159
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	160
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	161
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	162
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	163
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	164
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	165
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	166
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	167
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	168
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	169
-.1610818+01	.1582513+01	.1173388+02	-.1616066+01	.1599305+01	.1576244+02	1	170
-.1610818+01	.1582513+01	.11					

AFWL-TR-67-131, Vol IV

.1045182+02-.1629024+01-.1615207+01 .1249204+02-.1629086+01-.1615391+01 1 114
 .1403211+02-.1629093+01-.1615413+01 .1687407+02-.1629094+01-.1615415+01 1 115
 .1923728+02 .0907755+01 .1300000+02 .2027853+01 .4851585+01-.3511190+01 1 117
 .8923391-00 .3543855+01-.1873429+01-.3859198-00 .1994074+01-.2559972-00 1 118
 -.1179158+01 .4410866-00 .1355734+01-.1498209+01-.8410872-00 .2968845+01 1 119
 -.1602308+01-.1456422+01 .4579069+01-.1631653+01-.1603585+01 .6273013+01 1 120
 -.1637882+01-.1627176+01 .8045000+01-.1638849+01-.1630883+01 .9916808+01 1 121
 -.1639001+01-.1631463+01 .1195703+02-.1639022+01-.1631539+01 .1409710+02 1 122
 -.1639024+01-.1631549+01 .1633906+02-.1639024+01-.1631550+01 .1470227+02 1 123
 .7313220+01 .1300000+02 .1010669+00 .3021967+01-.4093578+01-.8447949-00 1 124
 .1924946+01-.2478953+01-.1392539+01 .4370966-00-.8634407-00-.1574528+01 1 125
 -.6210908-00 .7496036-00-.1630843+01-.1451928+01 .2360696+01-.1650704+01 1 126
 -.1655793+01 .3970882+01-.1654779+01-.1668758+01 .5664817+01-.1655658+01 1 127
 -.1670743+01 .7436803+01-.1655763+01-.1671023+01 .9308610+01-.1655780+01 1 128
 -.1671067+01 .1134883+02-.1655782+01-.1671073+01 .1348890+02-.1655782+01 1 129
 -.1671074+01 .1573086+02-.1655782+01-.1671074+01 .1809407+02 .7718685+01 1 130
 .1300000+02-.728055-00 .2271574+01-.4698209+01-.1204926+01 .7802448-00 1 131
 -.3085834+01-.1511627+01-.5934336-00-.1471259+01-.1614249+01-.1411030+01 1 132
 .1415086-00-.1645127+01-.1631299+01 .1752524+01-.1653464+01-.1665072+01 1 133
 .3362690+01-.1655474+01-.1670212+01 .5056620+01-.1655726+01-.1670927+01 1 134
 .6828606+01-.1655774+01-.1671051+01 .8700413+01-.1655781+01-.1671071+01 1 135
 .1074003+02-.1655782+01-.1671073+01 .1288070+02-.1655782+01-.1671074+01 1 136
 .1512260+02-.1655782+01-.1671074+01 .1748587+02 .8131531+01 .1300000+02 1 137
 -.9192870-00 .1496234+01-.5315536+01-.1402691+01 .2858587-01-.3704384+01 1 138
 -.1579390+01-.1111572+01-.2090280+01-.1634927+01-.1569696+01-.4777004-00 1 139
 -.1650829+01-.1656328+01 .1133272+01-.1654715+01-.1668612+01 .2743426+01 1 140
 -.1655641+01-.1670696+01 .4437353+01-.1655758+01-.1671010+01 .6209338+01 1 141
 -.1655779+01-.1671064+01 .0081145+01-.1655782+01-.1671072+01 .1012137+02 1 142
 -.1655782+01-.1671074+01 .1226143+02-.1655782+01-.1671074+01 .1450339+02 1 143
 -.1655782+01-.1671074+01 .1646800+02 .8517193+01 .1300000+02-.1207334+01 1 144
 .7729930-00-.5693009+01-.1510750+01-.5873372-00-.4275062+01-.1613996+01 1 145
 -.1408915+01-.2665336+01-.1645008+01-.1631021+01 .1056159+01-.1653450+01 1 146
 -.1665030+01 .5547675-00-.1655417+01-.1670101+01 .2164934+01-.1655716+01 1 147
 -.1670900+01 .3858860+01-.1655771+01-.1671044+01 .5630844+01-.1655781+01 1 148
 -.1671069+01 .7502651+01-.1655782+01-.1671073+01 .9542873+01-.1655782+01 1 149
 -.1671074+01 .1168294+02-.1655782+01-.1671074+01 .1392490+02-.1655782+01 1 150
 -.1671074+01 .1620811+02 .8853065+01 .1300000+02-.1374367+01 .1596129-00 1 151
 -.6597174+01-.1568903+01-.1025219+01-.4779620+01-.1631763+01-.1548287+01 1 152
 -.3169990+01-.1650157+01-.1653376+01-.1559613+01-.1654516+01-.1668142+01 1 153
 .5008435+01-.1655604+01-.1670093+01 .1660227+01-.1655748+01-.1670985+01 1 154
 .3354192+01-.1655777+01-.1671059+01 .5126136+01-.1655781+01-.1671071+01 1 155
 .6997943+01-.1655782+01-.1671073+01 .9038164+01-.1655782+01-.1671074+01 1 156
 .1117823+02-.1655782+01-.1671074+01 .1342019+02-.1655782+01-.1671074+01 1 157
 .1578340+02 .9210340+01 .1300000+02-.1488023+01-.4389584-00-.6931825+01 1 158
 -.1606125+01-.1342052+01-.5314530+01-.1642947+01-.1618971+01-.3704965+01 1 159
 -.1652986+01-.1663427+01-.2094614+01-.1655261+01-.1669803+01-.4849246-00 1 160
 -.1655693+01-.1670640+01 .1125216+01-.1655766+01-.1671031+01 .2819139+01 1 161
 -.1655780+01-.1671066+01 .4591123+01-.1655782+01-.1671073+01 .6462930+01 1 162
 -.1655782+01-.1671074+01 .8503152+01-.1655782+01-.1671074+01 .1064322+02 1 163
 -.1655782+01-.1671074+01 .1288518+02-.1655782+01-.1671074+01 .1524839+02 1 164

DIANE/SCAT PHENOLIC-1A TEMP(.861667-34.1EV. SAU INPUT TAPE 1250 11-8-67

.1000000+01 .4510000+03 1 0
 1107. .1100000+02 1 1
 -.1488864-00 .1300000+02 .7396268+01 .1205435+02-.2876988+01 .7323616+01

.115570+02	.7492264-00	.7045312+01	.1135086+02	.1842010+01	.6626596+01	1	2
.1062392+02	.4703754+01	.6118535+01	.9380664+01	.7713694+01	.5610584+01	1	3
.8200204+01	.1070118+02	.4930217+01	.7144506+01	.1379163+02	.3784311+01	1	4
.5911545+01	.1644249+02	.2236093+01	.4335992+01	.1884014+02	.3853600-00	1	5
.2468522+01	.2117293+02	.1454346+01	.3731602-00	.2337724+02	.2557072+01	1	6
.1603718+01	.2562787+02	.2659036+01	.2674442+01	.2799498+02	.0000000	1	7
.1300000+02	.8704367+01	.1269055+02	.1509883+01	.8575912+01	.1225431+02	1	8
.6965901-00	.0271030+01	.1207306+02	.3330837+01	.7823217+01	.1135297+02	1	9
.0204004+01	.7315407+01	.1017078+02	.9162954+01	.6596711+01	.8047084+01	1	10
.1198253+02	.5402552+01	.7543123+01	.1451814+02	.3845427+01	.5983883+01	1	11
.1680257+02	.2017667+01	.4199706+01	.1491721+02	.6943911-02	.2138434+01	1	12
.2101423+02	.1750783+01	.1737945-02	.2316305+02	.2619865+01	.1831214+01	1	13
.2542023+02	.2726942+01	.2575849+01	.2788385+02	.4054651-00	.1300000+02	1	14
.1163704+02	.1371671+02	.1126432+01	.1128572+02	.1337897+02	.3486783+01	1	15
.1072433+02	.1313606+02	.6101769+01	.9904459+01	.1226202+02	.8673415+01	1	16
.8573031+01	.1069237+02	.1094918+02	.6885636+01	.8904814+01	.1289567+02	1	17
.5026619+01	.7013293+01	.1470350+02	.3226430+01	.5099725+01	.1651134+02	1	18
.1682039+01	.3295718+01	.1844663+02	.2084309-00	.1634667+01	.2065812+02	1	19
.1354571+01	.2090645-00	.2291311+02	.2218547+01	.1781306+01	.2520000+02	1	20
.2436744+01	.2369984+01	.2759390+02	.8109302-00	.1300000+02	.1328778+02	1	21
.1396296+02	.2527477+01	.1280136+02	.1352724+02	.4804134+01	.1186231+02	1	22
.1295880+02	.7046187+01	.1046484+02	.1162760+02	.9039274+01	.8773395+01	1	23
.9892006+01	.1080272+02	.7184165+01	.6291926+01	.1251469+02	.5606551+01	1	24
.6791198+01	.1436318+02	.3768977+01	.5071801+01	.1625668+02	.1829731+01	1	25
.3197410+01	.1818522+02	.8270833+01	.1133056+01	.2026462+02	.1461490+01	1	26
.6028539-00	.2250613+02	.2015388+01	.1765606+01	.2486049+02	.2163706+01	1	27
.2120254+01	.2727074+02	.1223775+01	.1300000+02	.1345512+02	.1373888+02	1	28
.2993424+01	.1295045+02	.1320510+02	.4948948+01	.1147320+02	.1267814+02	1	29
.6900149+01	.1050115+02	.1153356+02	.8733734+01	.0731493+01	.9872228+01	1	30
.1051292+02	.6934694+01	.0120531+01	.1222504+02	.5250453+01	.6446079+01	1	31
.1400260+02	.3623132+01	.4708058+01	.1589147+02	.1741215+01	.2916272+01	1	32
.1704045+02	.9482261+01	.9749307-00	.1995614+02	.1356919+01	.68841614-00	1	33
.2219098+02	.1839542+01	.1645303+01	.2450072+02	.1440440+01	.1409904+01	1	34
.2687002+02	.1609438+01	.1300000+02	.1289070+02	.1338732+02	.2464364+01	1	35
.1261917+02	.1296917+02	.4801739+01	.1170927+02	.1241925+02	.6643582+01	1	36
.1027161+02	.1122656+02	.8429004+01	.8615642+01	.9641984+01	.1017915+02	1	37
.6854428+01	.7946944+01	.1170588+02	.5130827+01	.8126881+01	.1369097+02	1	38
.3352906+01	.4341444+01	.1556108+02	.1391538+01	.2515668+01	.1750132+02	1	39
.4580784-00	.5535904-00	.1957110+02	.1543642+01	.1184248+01	.2172166+02	1	40
.1860674+01	.1783105+01	.2377775+02	.1403500+01	.1984774+01	.2135641+02	1	41
.1945910+01	.1300000+02	.1216413+02	.1301721+02	.2772794+01	.1204618+02	1	42
.1261226+02	.4580831+01	.1139679+02	.1204261+02	.6370160+01	.1003228+02	1	43
.1070240+02	.0137078+01	.8339701+01	.9114571+01	.4079928+01	.8619211+01	1	44
.7365898+01	.1159074+02	.4638641+01	.5550115+01	.1335494+02	.2613813+01	1	45
.3648925+01	.1516032+02	.7813608-00	.1764193+01	.1705059+02	.8429071-00	1	46
.1295443-00	.1910001+02	.1642340+01	.1432511+01	.2126146+02	.1828045+01	1	47
.1000517+01	.2351841+02	.1875734+01	.1858773+01	.2700524+02	.2302585+01	1	48
.1300000+02	.1124072+02	.1250506+02	.2501238+01	.1119344+02	.1213170+02	1	49
.4285118+01	.1076024+02	.1143384+02	.6037999+01	.9615188+01	.1008636+02	1	50
.7786876+01	.7843430+01	.8341706+01	.9501743+01	.5831803+01	.6481209+01	1	51
.1116069+02	.3881518+01	.4636573+01	.1288049+02	.1960238+01	.2804159+01	1	52
.1467017+02	.1036813+00	.9730338-00	.1655775+02	.1183488+01	.7428909-00	1	53
.1860423+02	.1719754+01	.1648158+01	.2074534+02	.1858228+01	.1839512+01	1	54
.2298743+02	.1879095+01	.1861891+01	.2535065+02	.2708050+01	.1300000+02	1	55
.1008661+02	.1177993+02	.2126617+01	.9925491+01	.1129418+02	.3872772+01	1	56

AFWL-TR-67-131, Vol IV

.9578609+01	.1046693+02	.5606765+01	.8635299+01	.9946784+01	.7300424+01	1	57
.6943763+01	.7178323+01	.8962177+01	.5036142+01	.5377825+01	.1060140+02	1	58
.3023019+01	.3519554+01	.1230864+02	.1086245+01	.1680600+01	.1408434+02	1	59
-.5481989+00	-.6026237+01	.1595668+02	.1501770+01	.1377496+01	.1794735+02	1	60
-.1806121+01	.1742502+01	.2013850+02	.1862021+01	.1844631+01	.2238997+02	1	61
-.1813457+01	.1795276+01	.24880786+02	.3113515+01	.1300000+02	.8036216+01	1	62
.1094286+02	.1664106+01	.8547530+01	.1035594+02	.3392075+01	.8064288+01	1	63
.9296377+01	.5080062+01	.7046707+01	.7705021+01	.6743330+01	.5490681+01	1	64
.5912249+01	.8384907+01	.3645548+01	.4142503+01	.1000800+02	.1925984+01	1	65
.2404443+01	.1170731+02	.3361317+00	.8551778+00	.1349273+02	.8910610+00	1	66
-.2956566+00	.1541381+02	.1537603+01	.1216115+01	.1751915+02	.1685967+01	1	67
-.1607088+01	.1464364+02	.1650694+01	.1622730+01	.2198838+02	.1610127+01	1	68
-.1590681+01	.2440617+02	.3526360+01	.1300000+02	.8224901+01	.1013809+02	1	69
.1150635+01	.7516756+01	.9275640+01	.2845973+01	.6571836+01	.8077271+01	1	70
.4513468+01	.5251848+01	.6500299+01	.6158129+01	.3832690+01	.5165085+01	1	71
.7805444+01	.2412270+01	.3946801+01	.9474251+01	.9427020+00	.2625664+01	1	72
.1124950+02	.2930220+00	.1235699+01	.1305305+02	.1150707+01	.1075674+00	1	73
.1498238+02	.1510261+01	.1196373+01	.1704674+02	.1580977+01	.1518749+01	1	74
.1919020+02	.1579252+01	.1556674+01	.2145258+02	.1572700+01	.1554448+01	1	75
.2362403+02	.0000000	.0000000	.0000000	.0000000	.0000000	1	76

DIANE/SCAT UPLTCA 19 FREQ. TEMP. (1.-2250.) C1/HTW-AFWL 11-25-66

.1900000+02	.8610000+03						
1124.	.2100000+02						
.0000000	.1300000+02	.6360457+01	.9675488+01	.2662175+00	.6704824+01	1	1
.9509306+01	.1908690+01	.6627136+01	.9381302+01	.4465035+01	.6398674+01	1	2
.9004290+01	.7080887+01	.5808522+01	.8221526+01	.9422521+01	.4918923+01	1	3
.7171276+01	.1146267+02	.3812484+01	.6375975+01	.1363218+02	.2638152+01	1	4
.4910197+01	.1600605+02	.1146469+01	.3156651+01	.1822594+02	.5676764+00	1	5
.1324305+01	.2041762+02	.2197785+01	.6503493+00	.2262645+02	.3083742+01	1	6
-.2462769+01	.2488244+02	.3359159+01	.3266519+01	.2725677+02	.4054651+00	1	7
.1300000+02	.9169659+01	.1115098+02	.1271949+01	.4009848+01	.1089895+02	1	8
.3438773+01	.8750252+01	.1066435+02	.5747365+01	.8293466+01	.1011945+02	1	9
.7990001+01	.7512050+01	.9091565+01	.1020165+02	.6408134+01	.7713306+01	1	10
.1221367+02	.4956104+01	.6218444+01	.1410003+02	.3149996+01	.4375091+01	1	11
.1545364+02	.1182044+01	.2440370+01	.1785606+02	.7267326+00	.4579919+00	1	12
.1992705+02	.2205996+01	.1305733+01	.2214446+02	.2817475+01	.2418279+01	1	13
.2459637+02	.2908652+01	.2850302+01	.2711243+02	.8109302+00	.1300000+02	1	14
.1108015+02	.1183227+02	.2100790+01	.1070339+02	.1150017+02	.4228613+01	1	15
.1015075+02	.1101625+02	.6417363+01	.9199053+01	.1001160+02	.8414305+01	1	16
.7869553+01	.8682235+01	.1021136+02	.6359144+01	.7122866+01	.1190478+02	1	17
.4837588+01	.5594554+01	.1367614+02	.3247645+01	.4174408+01	.1560791+02	1	18
.1486339+01	.2576709+01	.1766607+02	.4239082+00	.6271632+00	.1978446+02	1	19
-.1936600+01	.1214802+01	.2198126+02	.2587600+01	.2374441+01	.2429720+02	1	20
-.2656174+01	.2622230+01	.2677291+02	.1223775+01	.1300000+02	.1166009+02	1	21
.1181946+02	.2470291+01	.1115058+02	.1123898+02	.4429359+01	.1035431+02	1	22
.1056289+02	.6308225+01	.9315664+01	.9796144+01	.8105460+01	.8019590+01	1	23
.8679545+01	.9902027+01	.6528763+01	.7460829+01	.1169107+02	.4831070+01	1	24
.5819934+01	.1349011+02	.3146230+01	.4024928+01	.1534806+02	.1363887+01	1	25
.2256119+01	.1732919+02	.4804297+00	.3845829+00	.1947120+02	.1884308+01	1	26
-.1364660+01	.2165102+02	.2414228+01	.2305007+01	.2393038+02	.2442414+01	1	27
-.2419647+01	.2638598+02	.1609438+01	.1300000+02	.1144896+02	.1159322+02	1	28
.2425932+01	.1090408+02	.1106034+02	.4217368+01	.1011773+02	.1047448+02	1	29
.8065704+01	.9162441+01	.9796392+01	.7889378+01	.7871443+01	.8539757+01	1	30
.9648406+01	.6327231+01	.7039031+01	.1138832+02	.4619551+01	.5388227+01	1	31

.1319292+02	.2035289+01	.3610860+01	.1502736+02	.1012789+01	.1858067+01	1	32
.1690092+02	.7013473+00	.3109666+01	.1908842+02	.1911623+01	.1539000+01	1	33
.2120058+02	.2230033+01	.2158209+01	.2358152+02	.2257487+01	.2238838+01	1	34
.2000176+02	.1945910+01	.1300000+02	.1120571+02	.1142562+02	.2250511+01	1	35
.1074449+02	.1091272+02	.4026848+01	.1011399+02	.1046003+02	.5839522+01	1	36
.4026034+01	.4003931+01	.7629774+01	.7484521+01	.8227806+01	.9382287+01	1	37
.5904909+01	.0671191+01	.1108490+02	.4231352+01	.5020578+01	.1286741+02	1	38
.2537497+01	.3331844+01	.1470505+02	.7093901+00	.1818186+01	.1664727+02	1	39
-.9963425+00	.3992484+01	.1875398+02	.1854492+01	.1539936+01	.2096140+02	1	40
-.2054797+01	.2000000+01	.2328322+02	.2087782+01	.2071191+01	.2567263+02	1	41
.2302585+01	.1300000+02	.1090449+02	.1126073+02	.1998267+01	.1055618+02	1	42
.1078976+02	.3756904+01	.9797058+01	.1026464+02	.5543566+01	.8605514+01	1	43
.9345711+01	.7313724+01	.7075869+01	.7898149+01	.9043327+01	.5522603+01	1	44
.6340360+01	.1074054+02	.3694732+01	.4715410+01	.1251739+02	.2175578+01	1	45
.3052687+01	.1437010+02	.3297190+00	.1314824+01	.1632080+02	.1204147+01	1	46
-.4526322+00	.1639763+02	.1662866+01	.1648084+01	.2056308+02	.2017423+01	1	47
-.1985183+01	.2282106+02	.2921708+01	.2008591+01	.2520522+02	.2708050+01	1	48
.1300000+02	.1053663+02	.1098938+02	.1643027+01	.1026196+02	.1058640+02	1	49
.3412516+01	.9559423+01	.1002127+02	.5173321+01	.8342313+01	.8938929+01	1	50
.6925074+01	.6853482+01	.7487343+01	.8654923+01	.5111097+01	.5871957+01	1	51
.1035404+02	.3269405+01	.4123077+01	.1210603+02	.1426944+01	.2305736+01	1	52
.1391204+02	.2543039+00	.4920990+00	.1580710+02	.1451290+01	.1071640+01	1	53
.1786902+02	.1660679+01	.1600346+01	.2003282+02	.1938527+01	.1926138+01	1	54
.2229651+02	.1934695+01	.1920697+01	.2468715+02	.3113515+01	.1300000+02	1	55
.1017466+02	.1067771+02	.1302516+01	.9937166+01	.1032002+02	.3035277+01	1	56
.9227512+01	.9566973+01	.4702203+01	.7913439+01	.8376405+01	.6523700+01	1	57
.6103233+01	.0765163+01	.6211593+01	.4346719+01	.4977934+01	.9862666+01	1	58
.2627126+01	.3251422+01	.1158587+02	.7889234+00	.1513763+01	.1338516+02	1	59
-.7515476+00	.1308645+00	.1526016+02	.1557805+01	.1347602+01	.1735745+02	1	60
-.1811741+01	.1776234+01	.1956024+02	.1845055+01	.1828867+01	.2179805+02	1	61
-.1626051+01	.1813430+01	.2418753+02	.3526360+01	.1300000+02	.9574938+01	1	62
.1022508+02	.0001268+00	.9234188+01	.9706997+01	.2611435+01	.8411781+01	1	63
.8735096+01	.4328422+01	.7020797+01	.7377035+01	.6025970+01	.5353279+01	1	64
.5802047+01	.7665672+01	.3622455+01	.4257660+01	.9333313+01	.1845372+01	1	65
.2736978+01	.1106185+02	.3121712+00	.1217026+01	.1286652+02	.9996136+00	1	66
-.3780445+00	.1476425+02	.1619450+01	.1432241+01	.1683543+02	.1753458+01	1	67
-.1710646+01	.1900859+02	.1736420+01	.1719540+01	.2129286+02	.1712568+01	1	68
-.1698653+01	.2368367+02	.3912023+01	.1300000+02	.8877927+01	.9575676+01	1	69
.4246144+00	.8374272+01	.8823608+01	.2139793+01	.7644528+01	.7950531+01	1	70
.3836265+01	.0258813+01	.5670040+01	.5514652+01	.4661174+01	.5209595+01	1	71
.7168937+01	.2962150+01	.3711504+01	.6816376+01	.1308127+01	.2185795+01	1	72
.1055005+02	.2276067+00	.7253857+00	.1237225+02	.1236107+01	.6308949+00	1	73
.1426631+02	.1584648+01	.1406490+01	.1637161+02	.1643730+01	.1610055+01	1	74
.1854315+02	.1656357+01	.1640877+01	.2079589+02	.1654418+01	.1640469+01	1	75
.2316414+02	.4246495+01	.1300000+02	.8560684+01	.9124735+01	.2374196+01	1	76
.8052940+01	.6429943+01	.1722735+01	.7161131+01	.7479452+01	.3412528+01	1	77
.5604609+01	.6211617+01	.5086429+01	.3962255+01	.4783117+01	.6758947+01	1	78
.2341423+01	.3387646+01	.8424123+01	.8028794+00	.1935083+01	.1016491+02	1	79
-.5563596+00	.4317234+00	.1197594+02	.1329903+01	.8756332+00	.1386592+02	1	80
-.1565914+01	.1497203+01	.1591334+02	.1639629+01	.1620676+01	.1805586+02	1	81
-.1649557+01	.1636698+01	.2029824+02	.1652284+01	.1638469+01	.2266150+02	1	82
.4605170+01	.1300000+02	.8331545+01	.8858250+01	.4198661+00	.7765316+01	1	83
.8164065+01	.1274744+01	.6724069+01	.7102883+01	.2979119+01	.5116818+01	1	84
.5720115+01	.4668983+01	.3482099+01	.4318497+01	.6336080+01	.1854934+01	1	85
.2861677+01	.7980821+01	.2281032+00	.1248141+01	.9690045+01	.9676575+00	1	86

-.00000000	.119079400	-.145039101	.110001101	.113007002	.110039001	1	87
-.150000001	.150015502	-.100000001	.110000201	.110000202	.110000101	1	88
-.163102101	.147000002	-.103200001	.101000101	.221002002	.501003501	1	89
.130000002	.700000101	.855521701	-.921600000	.721000001	.771000201	1	90
.785072500	.605500101	.047000501	.240003910	.440122701	.497352601	1	91
.414780001	.274320001	.342917001	.577773801	.105000301	.141100001	1	92
.739357201	-.310000000	.200500100	.900000001	.112460001	-.920015700	1	93
.100000002	.149100001	-.144910001	.127501702	.159000001	-.157716101	1	94
.148000102	-.100000001	-.150000001	.100000002	-.100000001	.159500001	1	95
.191975002	-.100000101	-.150000001	.215007602	.541610001	.130000002	1	96
.695076101	.792300001	-.142500101	.010000001	.679900001	.263250000	1	97
.497342101	.541370001	.193110001	.342500001	.388030001	.356341601	1	98
.185507401	.242500001	.510000001	.407200000	.109216001	.680630701	1	99
-.750000000	-.100010000	.051310001	.136100001	.112510001	.102920102	1	100
-.155000001	-.150000001	.121600002	-.150000001	.158307101	.142076102	1	101
-.160000101	-.150000001	.163000002	-.160011601	.159236101	.145931602	1	102
-.160200001	-.158000001	.200000002	.502000001	.130000002	.614916501	1	103
.710010001	-.197231101	.522000001	.543632101	.308005200	.396070201	1	104
.465000001	.133000001	.230010001	.326039701	.297146701	.824720100	1	105
.181001701	.459421501	-.425100100	.363724300	.620000001	.110072001	1	106
-.608207700	.790077401	-.146747401	.140500001	.907907201	.156012501	1	107
-.155420101	.115501002	-.150000001	.158203501	.135960002	.159970201	1	108
-.158613001	.157000002	-.160000001	.158663601	.174700002	.100050001	1	109
-.158600101	.203420102	.021400001	.130000002	.550974701	.634195701	1	110
-.250000001	.473312801	.520000001	.851615900	.329000001	.391000001	1	111
.745000000	.103221501	.240070101	.240017001	.202000000	.959990100	1	112
.402410001	.745342000	-.200371100	.563730001	.129839101	.115591501	1	113
.733300201	.152420001	-.140000001	.910600701	.158493601	.157200001	1	114
.100780202	-.157000001	-.150010001	.130190002	.160074201	.158544701	1	115
.151591502	-.100001101	-.150000001	.170111102	.160093001	.158560001	1	116
.197043202	.055100001	.130000002	.481813301	.576103601	.297435401	1	117
.403120001	.454350001	-.133790001	.267893001	.312059801	.291456700	1	118
.115970001	.167000001	.191150001	.181781000	.279936000	.352529701	1	119
-.103472001	.836242700	.513617001	-.144201601	.140600001	.603031201	1	120
-.157300001	-.155790001	.002030001	-.154740201	.158200701	.104741602	1	121
-.160000002	-.158639501	.125143802	-.160100001	.158605001	.146544402	1	122
-.160113701	-.158691301	.160000002	-.160114201	.158691901	.192596102	1	123
.690775501	.130000002	.373200001	.493536801	.348004101	.301201501	1	124
.368036701	-.186130001	.177179001	.223612001	.236507000	.336262300	1	125
.763670000	.130036701	-.814024400	.514947600	.299164701	.139007101	1	126
-.128000001	.460149201	-.150000001	.153372001	.629536501	.159791901	1	127
-.157031701	.006733001	-.160263001	-.158571001	.493914401	.160335701	1	128
-.158600001	.119793702	-.160345101	-.158699801	.141194302	.160346201	1	129
-.158701501	.163613002	-.160346301	.158701701	.187246002	.731322001	1	130
.130000002	.229770001	.410705001	.408445401	.129287001	.260550901	1	131
-.240142101	.772032701	.122000001	.841571200	.933392900	.192551700	1	132
.773017400	-.141971101	-.115112201	.230364101	.156482301	.149071701	1	133
.399333001	-.154994301	-.157097701	.560717401	.160669001	.158596101	1	134
.745914301	-.160700101	-.158853501	.933004701	.160000001	.158074201	1	135
.113711702	-.160000001	-.158899601	.135112302	.160009701	.158900201	1	136
.157531902	-.160000001	-.158900301	.181164002	.771860001	.130000002	1	137
.730922200	.322092701	-.468547601	-.333618200	.179159101	.306422401	1	138
-.110307701	.300255000	.144603201	-.145216601	.889007600	.165020600	1	139
-.157237201	-.142504001	.177548601	-.160000001	.156436901	.330514501	1	140
-.161777001	-.159367801	.507897801	-.161000001	.159793701	.685090501	1	141

AFWL-TR-67-131, Vol IV

-1619161+01	-1598899+01	.8722749+01	-1619212+01	-1599051+01	.1076297+02	1	142
-1619218+01	-1599071+01	.1290304+02	-1619219+01	-1599073+01	.1514500+02	1	143
-1619219+01	-1599074+01	.1750821+02	.0000000	.0000000	.0000000	1	144
<p>DIANE/SCAT GPLYFE 19 FREQ. TEMP. (1.-2250.) C1/HT=AFWL 11-28-6200000</p>							
.1900000+02	.8610000+03						
1125.	.2100000+02						
.0000000	.1300000+02	.6360457+01	.9675488+01	-2662175+00	.6704824+01	1	1
.9509306+01	.1908890+01	.6627136+01	.9381302+01	.4465035+01	.6398674+01	1	2
.9004290+01	.7080687+01	.5808522+01	.8221526+01	.9422521+01	.4918923+01	1	3
.7171276+01	.1146267+02	.3812384+01	.6375975+01	.1363218+02	.2638152+01	1	4
.4910197+01	.1600605+02	.1146369+01	.3156651+01	.1822594+02	.5676764+00	1	5
.1324305+01	.2041762+02	.2197785+01	.6503493+00	.2262645+02	.3083742+01	1	6
-2462769+01	.2488244+02	.3359154+01	.3266519+01	.2725677+02	.4054651+00	1	7
.1300000+02	.9164854+01	.1115098+02	.1271949+01	.9009848+01	.1089895+02	1	8
.3430773+01	.8750252+01	.1066935+02	.5747365+01	.8293868+01	.1011945+02	1	9
.7990001+01	.7512050+01	.9091565+01	.1020165+02	.6408134+01	.7713306+01	1	10
.1221367+02	.4956104+01	.6218449+01	.1410003+02	.3149996+01	.4375091+01	1	11
.1595364+02	.1182044+01	.2440370+01	.1785606+02	.7267326+00	.4579919+00	1	12
.1992705+02	.2205996+01	.1305733+01	.2214446+02	.2817475+01	.2418279+01	1	13
.2459837+02	.2908852+01	.2850002+01	.2711243+02	.8109302+00	.1300000+02	1	14
.1100015+02	.1183227+02	.2100990+01	.1070339+02	.1150010+02	.4226813+01	1	15
.1015075+02	.1101625+02	.6417363+01	.9199053+01	.1001160+02	.8414305+01	1	16
.7809553+01	.8682235+01	.1021136+02	.6359144+01	.7122866+01	.1190478+02	1	17
.4837588+01	.5594554+01	.1367614+02	.3247645+01	.4174408+01	.1560791+02	1	18
.1480339+01	.2576709+01	.1766007+02	.4239082+00	.6271632+00	.1784446+02	1	19
-1936000+01	.1214602+01	.2196126+02	.2587600+01	.2374441+01	.2429720+02	1	20
-2656174+01	.2622230+01	.2677291+02	.1223775+01	.1300000+02	.1166009+02	1	21
.1181946+02	.2470291+01	.1115058+02	.1123894+02	.4429359+01	.1035431+02	1	22
.1056269+02	.6308225+01	.9315664+01	.9796144+01	.8105480+01	.8019590+01	1	23
.8679545+01	.9902027+01	.6528763+01	.7400829+01	.1169157+02	.4831070+01	1	24
.5819934+01	.1349011+02	.3146250+01	.4029928+01	.1534406+02	.1363887+01	1	25
.2256119+01	.1732419+02	.4804291+00	.3895829+00	.1447120+02	.1884308+01	1	26
-1364680+01	.2165102+02	.2414226+01	.2305807+01	.2393038+02	.2442414+01	1	27
-2419647+01	.2638599+02	.1609438+01	.1300000+02	.1144496+02	.1159322+02	1	28
.2425932+01	.1090408+02	.1106334+02	.4217368+01	.1011773+02	.1047448+02	1	29
.6065704+01	.9162441+01	.9796392+01	.7889378+01	.7871443+01	.8539757+01	1	30
.9648406+01	.6327231+01	.7039031+01	.1138032+02	.4619551+01	.5386227+01	1	31
.1319292+02	.2835249+01	.3610880+01	.1502736+02	.1012789+01	.1858067+01	1	32
.1696892+02	.7813473+00	.3109666+01	.1908642+02	.1911623+01	.1539000+01	1	33
.2120858+02	.2234633+01	.2158209+01	.2358152+02	.2257487+01	.2238838+01	1	34
.2600178+02	.1945910+01	.1300000+02	.1120571+02	.1142562+02	.2250511+01	1	35
.1074449+02	.1091272+02	.4028648+01	.1011399+02	.1046003+02	.5839522+01	1	36
.9026634+01	.9603931+01	.7629974+01	.7484521+01	.8227806+01	.9382287+01	1	37
.5904939+01	.6671191+01	.1108490+02	.4231352+01	.5020578+01	.1286741+02	1	38
.2537497+01	.3331844+01	.1470505+02	.7093901+00	.1818186+01	.1664727+02	1	39
-9963425+00	.3992489+01	.1875398+02	.1854492+01	.1539936+01	.2096140+02	1	40
-2054797+01	.2006080+01	.2328322+02	.2087782+01	.2071191+01	.2567263+02	1	41
.2302585+01	.1300000+02	.1090449+02	.1126093+02	.1998267+01	.1055618+02	1	42
.1078976+02	.3758904+01	.9797658+01	.1026464+02	.5543566+01	.8605514+01	1	43
.9345711+01	.7313724+01	.7075069+01	.7848149+01	.9043327+01	.5522603+01	1	44
.6340360+01	.1074054+02	.3894732+01	.4715410+01	.1251739+02	.2175578+01	1	45
.3052887+01	.1437010+02	.3297190+00	.1314824+01	.1632080+02	.1204147+01	1	46
-4528322+00	.1839763+02	.1862866+01	.1648084+01	.2056308+02	.2017423+01	1	47
-1985183+01	.2262106+02	.2021708+01	.2008591+01	.2520522+02	.2708050+01	1	48

.13000000+02	.10538603+02	.1096938+02	.1683027+01	.1026196+02	.1058640+02	1	49
.3412510+01	.9559423+01	.1002127+02	.5173321+01	.8342313+01	.7638929+01	1	50
.6925874+01	.6853402+01	.7487343+01	.8654923+01	.5111097+01	.5871957+01	1	51
.1035484+02	.3269405+01	.4123077+01	.1210003+02	.1426944+01	.2305736+01	1	52
.1391204+02	.2543306+00	.4920490+00	.1540710+02	.1451290+01	.1071640+01	1	53
.1786462+02	.1800874+01	.1800346+01	.2003242+02	.1936527+01	.1026138+01	1	54
.2224651+02	.1934695+01	.1926677+01	.2468715+02	.3113515+01	.1300000+02	1	55
.1017466+02	.1067771+02	.1302518+01	.9937166+01	.1032002+02	.3035277+01	1	56
.9227012+01	.9566473+01	.4782203+01	.7913434+01	.8376405+01	.6523700+01	1	57
.6103253+01	.6765163+01	.8211543+01	.4346719+01	.4977934+01	.9462666+01	1	58
.2627126+01	.3251422+01	.1156587+02	.7889234+00	.1513763+01	.1338516+02	1	59
.7515476+00	.1300645+00	.1528618+02	.1557805+01	.1347602+01	.1735745+02	1	60
.1611741+01	.176238+01	.1952024+02	.1045055+01	.1828867+01	.2179805+02	1	61
.1828051+01	.1613430+01	.2416753+02	.3526360+01	.1300000+02	.9574938+01	1	62
.1022568+02	.8661208+00	.9234188+01	.9706997+01	.2611435+01	.8411781+01	1	63
.8735046+01	.4328922+01	.7020497+01	.7377035+01	.6025970+01	.5353279+01	1	64
.9802047+01	.7885672+01	.3622755+01	.4257680+01	.9333313+01	.1895372+01	1	65
.2736976+01	.1106185+02	.3121712+00	.1217026+01	.1286652+02	.9996136+00	1	66
.3760445+00	.1476425+02	.1619450+01	.1432241+01	.1683543+02	.1753458+01	1	67
.1710646+01	.1900859+02	.1736420+01	.1719540+01	.2129286+02	.1712568+01	1	68
.1696053+01	.2368367+02	.3912023+01	.1300000+02	.6855562+01	.9563493+01	1	69
.4210781+00	.6348751+01	.8822775+01	.2131314+01	.7508086+01	.7937224+01	1	70
.3825674+01	.6166949+01	.6616400+01	.5503063+01	.4653145+01	.5200844+01	1	71
.7157369+01	.3114826+01	.3611047+01	.8804381+01	.1394416+01	.2232638+01	1	72
.1053717+02	.1936454+00	.7349625+00	.1235415+02	.1243777+01	.6524325+00	1	73
.1426280+02	.1607531+01	.1439816+01	.1634261+02	.1676713+01	.1645336+01	1	74
.1650929+02	.1694173+01	.1679043+01	.2075794+02	.1693020+01	.1679109+01	1	75
.2312552+02	.4246495+01	.1300000+02	.6439508+01	.9092125+01	.1709401+01	1	76
.7948716+01	.8373689+01	.1714143+01	.7122704+01	.7428965+01	.3400866+01	1	77
.5817385+01	.6230584+01	.5071474+01	.4179007+01	.4820057+01	.6741209+01	1	78
.2446993+01	.3372281+01	.6402074+01	.7969074+00	.1880301+01	.1013747+02	1	79
.5783852+00	.3652397+00	.1194368+02	.1348098+01	.9360871+00	.1383030+02	1	80
.1615280+01	.1530646+01	.1537724+02	.1671530+01	.1653915+01	.1402340+02	1	81
.1675317+01	.1662357+01	.2027262+02	.1671114+01	.1657234+01	.2264273+02	1	82
.4605170+01	.1300000+02	.8223735+01	.8797972+01	.4302433+00	.7717418+01	1	83
.6125674+01	.1254970+01	.6782676+01	.7111471+01	.2959102+01	.5246068+01	1	84
.5737535+01	.4644424+01	.3570286+01	.4299422+01	.6307075+01	.1818904+01	1	85
.2785364+01	.7948608+01	.1670631+00	.1200332+01	.9656843+01	.9597912+00	1	86
.2476443+00	.1143720+02	.1467972+01	.1292720+01	.1331687+02	.1612734+01	1	87
.1545224+01	.1530441+02	.1653600+01	.1641907+01	.1751035+02	.1653805+01	1	88
.1639081+01	.1976105+02	.1641018+01	.1626632+01	.2213812+02	.5010635+01	1	89
.1300000+02	.7795320+01	.8494260+01	.9421111+00	.7204234+01	.7683030+01	1	90
.7611851+00	.6076258+01	.6470594+01	.2458714+01	.4460602+01	.4975707+01	1	91
.4118416+01	.2695443+01	.3421507+01	.5749039+01	.1073157+01	.1033308+01	1	92
.7370960+01	.2585462+00	.3756833+00	.4073679+01	.1126880+01	.8378812+00	1	93
.1085531+02	.1502602+01	.1427005+01	.1274114+02	.1604571+01	.1581233+01	1	94
.1479562+02	.1616877+01	.1602008+01	.1694486+02	.1618455+01	.1604105+01	1	95
.1918884+02	.1610692+01	.1604374+01	.2155229+02	.5416100+01	.1300000+02	1	96
.7063432+01	.7000507+01	.1440200+01	.6307379+01	.6767113+01	.2385705+00	1	97
.5135609+01	.5394020+01	.1900712+01	.3657472+01	.4035404+01	.3544342+01	1	98
.2069303+01	.2006704+01	.5170567+01	.5330973+00	.1234204+01	.6746009+01	1	99
.7115077+00	.0746317+01	.0500100+01	.1335513+01	.1089580+01	.1070421+02	1	100
.1547329+01	.1499253+01	.1215821+02	.1603573+01	.1500988+01	.1419882+02	1	101
.1618828+01	.1603282+01	.1633674+02	.1618436+01	.1604631+01	.1458090+02	1	102
.1618671+01	.1604703+01	.2079441+02	.5082946+01	.1300000+02	.6258197+01	1	103

.7080702+01-.1991976+01 .5523003+01 .5941067+01-.3270119-00 .4508921+01	1	104
.4776931+01 .1524462+01 .2930476+01 .3373656+01 .2960780+01 .1264485+01	1	105
.1900500+01 .4584900+01-.1766174-00 .4380700-00 .6200040+01-.1077155+01	1	106
-.0052764-00 .7895278+01-.1452023+01-.1415501+01 .9687527+01-.1579654+01	1	107
-.1573065+01 .1153930+02-.1612007+01-.1600595+01 .1357962+02-.1617774+01	1	108
-.1604093+01 .1571976+02-.1617032+01-.1603947+01 .1796229+02-.1615433+01	1	109
-.1601520+01 .2032797+02 .0214008+01 .1300000+02 .5461529+01 .6340765+01	1	110
-.2520401+01 .4837788+01 .5419006+01-.0638611-00 .3446928+01 .4027004+01	1	111
.7740530-00 .2021674+01 .2478940+01 .2349292+01 .5015271-00 .9481002-00	1	112
.4012702+01-.0590214-00-.3976021-00 .5623129+01-.1309491+01-.1249059+01	1	113
.7317195+01-.1550151+01-.1531798+01 .9089643+01-.1605133+01-.1588242+01	1	114
.1096321+02-.1611677+01-.1596030+01 .1300647+02-.1610521+01-.1595172+01	1	115
.1514924+02-.1609859+01-.1594002+01 .1739207+02-.1609792+01-.1594522+01	1	116
.1975539+02 .0551080+01 .1300000+02 .4533608+01 .5784759+01-.2986436+01	1	117
.3690907+01 .4595476+01-.1348823+01 .2375217+01 .3065927+01 .2799056-00	1	118
.9227557-00 .1537037+01 .1097498+01-.3342476-00 .1199165+00 .3509203+01	1	119
-.1131973+01-.6781145-00 .5120388+01-.1485076+01-.1376092+01 .6816911+01	1	120
-.1583165+01-.1546434+01 .8591055+01-.1603367+01-.1587143+01 .1046487+02	1	121
-.1600041+01-.1594579+01 .1250541+02-.1609452+01-.1545575+01 .1464552+02	1	122
-.1609505+01-.1595051+01 .1688748+02-.1609573+01-.1595658+01 .1925069+02	1	123
.6907755+01 .1300000+02 .3545047+01 .4909267+01-.3503015+01 .2559291+01	1	124
.3607245+01-.1874210+01 .1168079+01 .2111313+01-.2512039-00-.9860691-01	1	125
.7014908-00 .1365025+01-.9488078-00-.3415062-00 .2979394+01-.1371998+01	1	126
-.1117016+01 .4591393+01-.1356335+01-.1484005+01 .6286181+01-.1443140+01	1	127
-.1570253+01 .0050371+01-.1007006+01-.1597201+01 .4930210+01-.1609503+01	1	128
-.1594257+01 .1197044+02-.1604052+01-.1594447+01 .1411051+02-.1609670+01	1	129
-.1594469+01 .1635247+02-.1609072+01-.1594472+01 .1871568+02 .7313220+01	1	130
.1300000+02 .2896433+01 .4108721+01-.4097992+01 .1880767+01 .2776061+01	1	131
-.2474061+01 .5872020-00 .1467910+01-.8535426-00-.5134067-00 .1689168-00	1	132
.7024301-00-.1175452+01-.04956387-00 .2374427+01-.1496095+01-.1431520+01	1	133
.3484351+01-.1592894+01-.1567539+01 .5678242+01-.1606993+01-.1588 .01	1	134
.7450220+01-.1608971+01-.1592094+01 .9322026+01-.1609261+01-.1492601+01	1	135
.1136225+02-.1609299+01-.1592668+01 .1350231+02-.1609303+01-.1592676+01	1	136
.1574427+02-.1609304+01-.1592677+01 .1810740+02 .7718685+01 .1300000+02	1	137
.1849413+01 .3361072+01-.4697381+01 .1030730+01 .2112704+01-.3075012+01	1	138
-.1662084-00 .0863125-00-.1456211+01-.1107340+01-.6139606-00 .1559514-00	1	139
-.1497041+01-.1343395+01 .1766551+01-.1588600+01-.1542523+01 .3376226+01	1	140
-.1606399+01-.1582295+01 .5070056+01-.1609788+01-.1589694+01 .6842024+01	1	141
-.1610340+01-.1590941+01 .8713628+01-.1610424+01-.1591137+01 .1075405+02	1	142
-.1610435+01-.1591162+01 .1209412+02-.1610436+01-.1591165+01 .1513608+02	1	143
-.1610436+01-.1591160+01 .1749929+02 .0000000 .0000000 .0000000	1	144
DIANE/SCAT G10FF 19 FRLQ(1.001-1.6) TLMF(1.-2250.) C1/LMS 11/7/66		
.1900000+02 .8610000+03		
1105 .2100000+02		
.0000000 .1300000+02 .6342381+01 .4857336+01-.1978742-00 .6720848+01	1	1
.9651594+01 .1976810+01 .6638737+01 .9514818+01 .4531841+01 .6395561+01	1	2
.9084592+01 .7143350+01 .5786304+01 .8224278+01 .9468754+01 .4818231+01	1	3
.7135162+01 .1146995+02 .3 .5056+01 .6383667+01 .1363020+02 .2716024+01	1	4
.4950495+01 .1605194+02 .1254798+01 .3233931+01 .1829475+02-.4611800-C0	1	5
.1412451+01 .2049140+02-.2108497+01-.5625348-00 .2270105+02-.3016697+01	1	6
-.2382798+01 .2445598+02-.3300871+01-.3205007+01 .2732079+02 .4054651-00	1	7
.1300000+02 .9200978+01 .1134496+02 .1320996+01 .9044369+01 .1106969+02	1	8
.3411180+01 .8786544+01 .1085370+02 .5778039+01 .8336226+01 .1027845+02	1	9
.8011853+01 .7548231+01 .9198182+01 .1024455+02 .6418701+01 .7604317+01	1	10

.1227831+02	.4960747+01	.6308258+01	.1417236+02	.3182621+01	.4456543+01	1	11
.1602885+02	.1192565+01	.2501877+01	.1742410+02	.7652075+00	.4735127+01	1	12
.1997757+02	.2217912+01	.1311470+01	.2218241+02	.2793213+01	.2398404+01	1	13
.2463246+02	.2076610+01	.2021045+01	.2714361+02	.3109302+00	.1300000+02	1	14
.1115852+02	.1200300+02	.2139047+01	.1078243+02	.1166660+02	.4268390+01	1	15
.1022690+02	.1119151+02	.6467727+01	.9231642+01	.1012761+02	.8478919+01	1	16
.7881636+01	.8744702+01	.1028112+02	.6342500+01	.7145312+01	.1196983+02	1	17
.4839991+01	.3575546+01	.1372025+02	.3239160+01	.4158711+01	.1564530+02	1	18
.1484984+01	.2576513+01	.1764814+02	.4231195+00	.6282987+00	.1981362+02	1	19
.1925072+01	.1223310+01	.2200347+02	.2575190+01	.2373708+01	.2431177+02	1	20
.2644674+01	.2612550+01	.2078451+02	.1223775+01	.1300000+02	.1172467+02	1	21
.1194396+02	.2522395+01	.1122103+02	.1133357+02	.4486601+01	.1040096+02	1	22
.1060000+02	.6367910+01	.9324025+01	.9779222+01	.8159223+01	.8016325+01	1	23
.8057217+01	.9742290+01	.6531088+01	.7270786+01	.1172296+02	.4756045+01	1	24
.5652946+01	.1351604+02	.3146934+01	.3937031+01	.1536590+02	.1350616+01	1	25
.2195900+01	.1734161+02	.4951699+00	.3445649+00	.1947901+02	.1900489+01	1	26
.1431012+01	.2165021+02	.2424746+01	.2324858+01	.2392473+02	.2448588+01	1	27
.2420769+01	.2638020+02	.1609438+01	.1300000+02	.1145528+02	.1163577+02	1	28
.2474112+01	.1089573+02	.1106708+02	.4263921+01	.1010072+02	.1047123+02	1	29
.6103234+01	.9137464+01	.9741375+01	.7918810+01	.7876686+01	.8484097+01	1	30
.9069177+01	.6323674+01	.6981206+01	.1140173+02	.4585887+01	.5305660+01	1	31
.1320045+02	.2781603+01	.3530038+01	.1502730+02	.9643433+00	.1703839+01	1	32
.1696411+02	.0107105+00	.2332045+01	.1908242+02	.1426224+01	.1567647+01	1	33
.2126318+02	.2244034+01	.2167379+01	.2357655+02	.2263080+01	.2243883+01	1	34
.2599714+02	.1945910+01	.1300000+02	.1118672+02	.1142436+02	.2287042+01	1	35
.1074420+02	.1091422+02	.4057516+01	.1008346+02	.1042622+02	.5862884+01	1	36
.8957613+01	.9577568+01	.7643937+01	.7378021+01	.8136021+01	.9388924+01	1	37
.5817122+01	.6585862+01	.1108449+02	.4179129+01	.4956075+01	.1286302+02	1	38
.2486620+01	.3284411+01	.1464945+02	.6546984+00	.1740757+01	.1664230+02	1	39
.1021122+01	.5945602+01	.1674947+02	.1802665+01	.1550034+01	.2095789+02	1	40
.2057372+01	.2608135+01	.2328191+02	.2088153+01	.2071423+01	.2567246+02	1	41
.2302565+01	.1300000+02	.1088449+02	.1124287+02	.2019622+01	.1051815+02	1	42
.1076657+02	.3776047+01	.9718897+01	.1024459+02	.5553317+01	.8479390+01	1	43
.9287373+01	.7315209+01	.6960770+01	.7846003+01	.9040141+01	.5412837+01	1	44
.6304856+01	.1073599+02	.3637763+01	.4645471+01	.1251324+02	.2147082+01	1	45
.3036140+01	.1436751+02	.3170138+00	.1306775+01	.1632008+02	.1207399+01	1	46
.4552919+00	.1839014+02	.1802335+01	.1645589+01	.2056539+02	.2014064+01	1	47
.1981542+01	.2282465+02	.2016447+01	.2003293+01	.2521048+02	.2708050+01	1	48
.1300000+02	.1052564+02	.1095699+02	.1692070+01	.1021291+02	.1055729+02	1	49
.3418154+01	.9455022+01	.9993110+01	.5173465+01	.8255674+01	.8918182+01	1	50
.6923526+01	.6798032+01	.7473321+01	.6653330+01	.5083365+01	.5668652+01	1	51
.1035476+02	.3257067+01	.4126912+01	.1210959+02	.1429703+01	.2314281+01	1	52
.1391529+02	.2477952+00	.5046958+00	.1581205+02	.1444318+01	.1057797+01	1	53
.1767629+02	.1852025+01	.1789328+01	.2004120+02	.1928905+01	.1916261+01	1	54
.2230592+02	.1926768+01	.1412775+01	.2469502+02	.3113515+01	.1300000+02	1	55
.1014536+02	.1066536+02	.1306765+01	.9939078+01	.1031334+02	.3037798+01	1	56
.9239760+01	.9579436+01	.4793727+01	.7909128+01	.8404294+01	.6525818+01	1	57
.6107129+01	.6792844+01	.8215212+01	.4361637+01	.5002418+01	.9868092+01	1	58
.2645847+01	.3280276+01	.1154309+02	.7997861+00	.1541915+01	.1339357+02	1	59
.7529844+00	.1174962+00	.1529304+02	.1552633+01	.1343097+01	.1736301+02	1	60
.1805032+01	.1770963+01	.1953179+02	.1841230+01	.1825483+01	.2180160+02	1	61
.1825489+01	.1810921+01	.2419005+02	.3526360+01	.1300000+02	.9564721+01	1	62
.1022961+02	.8902562+00	.9244978+01	.9723945+01	.2615891+01	.8429702+01	1	63
.8758611+01	.4534373+01	.7046947+01	.7414270+01	.6033001+01	.5379486+01	1	64
.5833412+01	.7693243+01	.3667127+01	.4277732+01	.9339584+01	.1906727+01	1	65

.2737087+01	.1106710+02	.3181302-00	.1224645+01	.1287082+02	.7741840-00	1	66
-.3827004+00	.1477196+02	.1613803+01	.1432946+01	.1683823+02	.1747778+01	1	67
-.1706220+01	.1901156+02	.1734039+01	.1716685+01	.2129578+02	.1709711+01	1	68
-.1695785+01	.2388674+02	.3912023+01	.1300000+02	.8886536+01	.9596336+01	1	69
.4624849+00	.6383704+01	.8858045+01	.2152274+01	.7656604+01	.7796778+01	1	70
.3651414+01	.6282792+01	.6728104+01	.5528370+01	.4669119+01	.5241129+01	1	71
.7183480+01	.3028230+01	.8742803+01	.8830332+01	.1336273+01	.2203253+01	1	72
.1056405+02	.2424077+00	.7344910+00	.1238387+02	.1244192+01	.6279192+00	1	73
.1429330+02	.1583977+01	.1404674+01	.1637775+02	.1641477+01	.1608601+01	1	74
.1854663+02	.1656002+01	.1640717+01	.2079641+02	.1655943+01	.1642014+01	1	75
.2316201+02	.4248493+01	.1300000+02	.8422081+01	.9120515+01	.4859822+01	1	76
.8021034+01	.6467654+01	.1736064+01	.7194927+01	.7530615+01	.3425851+01	1	77
.5734365+01	.6221188+01	.5099147+01	.3984431+01	.4804317+01	.6770057+01	1	78
.2304886+01	.3378521+01	.6433576+01	.7222712+00	.1920800+01	.1017171+02	1	79
-.5974233+00	.4110637+00	.1198000+02	.1331365+01	.8929606+00	.1386716+02	1	80
-.1585646+01	.1504763+01	.1591246+02	.1641239+01	.1623308+01	.1805450+02	1	81
-.1650376+01	.1637747+01	.2029734+02	.1652607+01	.1638760+01	.2266122+02	1	82
.4605170+01	.1300000+02	.8222933+01	.8848271+01	.4036073+00	.7726966+01	1	83
.8188057+01	.1286151+01	.6733717+01	.7109419+01	.2988746+01	.5115243+01	1	84
.5715672+01	.4076739+01	.3409521+01	.4287303+01	.6341460+01	.1738938+01	1	85
.2799644+01	.7983610+01	.1604473+00	.1190260+01	.9690440+01	.9677469+00	1	86
-.3210212+00	.1140664+02	.1453941+01	.1293381+01	.1334009+02	.1597529+01	1	87
-.1586091+01	.1538127+02	.1640743+01	.1630265+01	.1752299+02	.1642573+01	1	88
-.1628583+01	.1977227+02	.1627460+01	.1613073+01	.2215169+02	.5010635+01	1	89
.1300000+02	.7611425+01	.8562564+01	.9118936+00	.7217019+01	.7741046+01	1	90
.7921244+00	.6038884+01	.6463064+01	.2491152+01	.4369310+01	.4913367+01	1	91
.4150244+01	.2683929+01	.3350698+01	.5778166+01	.1046432+01	.1767596+01	1	92
.7393411+01	.3267625+00	.2290327+00	.9090323+01	.1131860+01	.9267319+00	1	93
.1088079+02	.1487666+01	.1434056+01	.1275492+02	.1588495+01	.1565028+01	1	94
.1481190+02	.1599475+01	.1583665+01	.1696323+02	.1599797+01	.1585276+01	1	95
.1920767+02	.1599613+01	.1585432+01	.2157118+02	.5416100+01	.1300000+02	1	96
.6902006+01	.7915447+01	.1420288+01	.6167311+01	.6778009+01	.2663371+00	1	97
.4924029+01	.5578076+01	.1737122+01	.3439787+01	.3888054+01	.3566217+01	1	98
.1908745+01	.2535478+01	.5100229+01	.4997692+00	.1147227+01	.8811388+01	1	99
-.7217005+00	.1010180+00	.6521087+01	.1350331+01	.1088058+01	.1030278+02	1	100
-.1549052+01	.1407745+01	.1217703+02	.1588201+01	.1572486+01	.1421776+02	1	101
-.1590005+01	.1583921+01	.1635820+02	.1597919+01	.1584215+01	.1460131+02	1	102
-.1590019+01	.1582933+01	.2096596+02	.5828946+01	.1300000+02	.6179604+01	1	103
.7107523+01	.1988280+01	.5247085+01	.5873210+01	.3063307+00	.4005578+01	1	104
.4628108+01	.1341666+01	.2541029+01	.3313011+01	.2977886+01	.9605622+00	1	105
.1690801+01	.4603050+01	.3555075+00	.4495643+00	.6218781+01	.1157615+01	1	106
-.7845127+00	.7914469+01	.1457636+01	.1393367+01	.9687622+01	.1558217+01	1	107
-.1549933+01	.1156082+02	.1589560+01	.1577549+01	.1360209+02	.1594904+01	1	108
-.1561332+01	.1574245+02	.1595547+01	.1581739+01	.1798449+02	.1595418+01	1	109
-.1581516+01	.2034798+02	.6214608+01	.1300000+02	.5551066+01	.6403731+01	1	110
-.2501228+01	.4773263+01	.5339358+01	.8459634+00	.3386084+01	.3999858+01	1	111
.7931888+00	.1756971+01	.2500705+01	.2418340+01	.2845437+00	.1001761+01	1	112
.4032722+01	.7137233+00	.3046690+00	.5644339+01	.1263882+01	.1166328+01	1	113
.7339389+01	.1508063+01	.1490096+01	.9111839+01	.1579410+01	.1566460+01	1	114
.1098393+02	.1593065+01	.1578310+01	.1302458+02	.1594713+01	.1579531+01	1	115
.1516499+02	.1594890+01	.1579630+01	.1740705+02	.1594911+01	.1579639+01	1	116
.1977027+02	.6551080+01	.1300000+02	.4737535+01	.5822462+01	.2967567+01	1	117
.3965114+01	.4590499+01	.1330060+01	.2680289+01	.3121721+01	.2995714+00	1	118
.1186998+01	.1629602+01	.1918556+01	.1493574+00	.2074792+00	.3530957+01	1	119
-.1016477+01	.8721204+00	.5141393+01	.1428467+01	.1400272+01	.6835726+01	1	120

-1559268+01	-1546072+01	.0608089+01	-1588890+01	-1575626+01	.1048007+02	1	121
-1594039+01	-1580167+01	.1252032+02	-1594665+01	-1580725+01	.1466040+02	1	122
-1594735+01	-1580790+01	.1690236+02	-1594743+01	-1580797+01	.1926557+02	1	123
.6907755+01	.1300000+02	.3583463+01	.4950218+01	.3482726+01	.2832645+01	1	124
.3636401+01	-1654030+01	.1687315+01	.2157183+01	-2303942+00	.3381948+00	1	125
.6950069+00	.1385928+01	.7545730+00	.5321134+00	.2997250+01	.1324594+01	1	126
-1243137+01	.4607314+01	.1533374+01	-1504007+01	.6301287+01	-1585474+01	1	127
-1567629+01	.6073285+01	-1594075+01	-1578160+01	.9945095+01	-1595189+01	1	128
-1579587+01	.1198532+02	-1595344+01	-1579775+01	.1412538+02	-1595362+01	1	129
-1579798+01	.1636734+02	-1595364+01	-1579800+01	.1873055+02	.7313220+01	1	130
.1300000+02	.2272090+01	.4085744+01	.4078354+01	.1462514+01	.2641285+01	1	131
-2455752+01	.4368737+00	.1213237+01	.8358251+00	.6514222+00	-1523555+00	1	132
.7789036+00	.1312021+01	.1094047+01	.2389565+01	-1530715+01	-1461708+01	1	133
.3999276+01	-1583455+01	-1553910+01	.5643124+01	-1594498+01	-1574747+01	1	134
.7465094+01	-1597283+01	.1578742+01	.9336898+01	-1597584+01	-1579265+01	1	135
.1137712+02	-1597628+01	-1579331+01	.1351719+02	-1597633+01	-1579339+01	1	136
.1579515+02	-1597633+01	-1579340+01	.1812236+02	.7718685+01	.1300000+02	1	137
.6456226+00	.3183975+01	.4679664+01	-5578584+01	.1743411+01	.3058164+01	1	138
-8800367+00	.3359822+00	.1440714+01	-1345014+01	.8227584+00	.1709941+00	1	139
-1524411+01	-1361533+01	.1701433+01	-1586838+01	-1539291+01	.3391092+01	1	140
-1600015+01	-1574002+01	.3004929+01	-1603661+01	-1580688+01	.6856897+01	1	141
-1600158+01	-1581644+01	.8726701+01	-1604237+01	-1582033+01	.1076892+02	1	142
-1604247+01	-1582057+01	.1290099+02	-1604248+01	-1582060+01	.1515095+02	1	143
-1604249+01	-1582060+01	.1751416+02	.0000000	.0000000	.0000000	1	144

56

DIAGN/SCAT REF-1A TEMP(1.5-2250.1EV. SADD INPUT IAPES(1819,1818) 11-8-67

.1000000+01	.4640000+03						
1100.	.1900000+02					1	0
.4054051+00	.1000000+02	.8926806+01	.1145091+02	.1352577+01	.8808878+01	1	1
.1121985+02	.3541557+01	.8641533+01	.1100100+02	.5891142+01	.8284119+01	1	2
.1043205+02	.8165900+01	.7018075+01	.9265513+01	.1032272+02	.6568743+01	1	3
.7036245+01	.1230595+02	.5121036+01	.6286330+01	.1418777+02	.3372307+01	1	4
.4490705+01	.1604000+02	.1549004+01	.2670440+01	.1746065+02	.2555276+01	1	5
.9021196+00	.2009843+02	.8109302+00	.1000000+02	.1109926+02	.1205968+02	1	6
.2205454+01	.1077394+02	.1171839+02	.4344166+01	.1027336+02	.1122497+02	1	7
.6522086+01	.9381773+01	.1019728+02	.8512111+01	.8095812+01	.8837648+01	1	8
.1030023+02	.6682337+01	.7362920+01	.1201736+02	.5112714+01	.5882905+01	1	9
.1383226+02	.3484536+01	.4305922+01	.1576249+02	.1690262+01	.2715354+01	1	10
.1777246+02	.3911564+01	.8291052+00	.1987440+02	.1223775+01	.1000000+02	1	11
.1176758+02	.1202831+02	.2559247+01	.1129837+02	.1145798+02	.4523764+01	1	12
.1055921+02	.1085059+02	.6412750+01	.4515182+01	.1006584+02	.8231463+01	1	13
.8176999+01	.8901661+01	.1003292+02	.6646287+01	.7455494+01	.1179860+02	1	14
.4982847+01	.5817734+01	.1359439+02	.3320154+01	.4180517+01	.1547221+02	1	15
.1574208+01	.2461787+01	.1744862+02	.1235042+00	.6439968+00	.1957487+02	1	16
.1609438+01	.1000000+02	.1157594+02	.1178510+02	.2524895+01	.1112663+02	1	17
.1126203+02	.4329929+01	.1033759+02	.1073228+02	.6181294+01	.9394073+01	1	18
.9988273+01	.7997572+01	.6039868+01	.8775154+01	.9761432+01	.6416511+01	1	19
.7235478+01	.1150232+02	.4760568+01	.5574598+01	.1330049+02	.3009852+01	1	20
.3823843+01	.1514835+02	.1214892+01	.2059039+01	.1708827+02	.4330207+00	1	21
.2411105+00	.1910601+02	.1945910+01	.1000000+02	.1133208+02	.1143304+02	1	22
.2352717+01	.1099936+02	.1116347+02	.4131171+01	.1034004+02	.1067570+02	1	23
.5947788+01	.9181874+01	.9764006+01	.7731041+01	.7647806+01	.8353136+01	1	24
.4484633+01	.6080230+01	.6784736+01	.1119509+02	.4351703+01	.5136385+01	1	25
.1296973+02	.2600881+01	.3394095+01	.1479222+02	.8370342+00	.1788800+01	1	26
.1671385+02	.6784426+00	.8926094+02	.1880127+02	.2302585+01	.1000000+02	1	27

.1091523+02	.1143000+02	.2097007+01	.1071799+02	.1048860+02	.3465851+01	1	28
.1007993+02	.1045074+02	.5643763+01	.8832260+01	.9364659+01	.7399724+01	1	29
.7187412+01	.7876452+01	.9125502+01	.5613245+01	.6296933+01	.1081191+02	1	30
.3945126+01	.4634065+01	.1256694+02	.2144480+01	.2967282+01	.1440154+02	1	31
.4011351+00	.1224873+01	.1633345+02	.9334554+00	.4297087+00	.1340220+02	1	32
.2706050+01	.1000000+02	.1044220+02	.1108981+02	.1765662+01	.1024540+02	1	33
.1061944+02	.3497653+01	.9592060+01	.9930719+01	.5252033+01	.8328913+01	1	34
.6745918+01	.6977674+01	.6775418+01	.7291955+01	.8682055+01	.5061203+01	1	35
.5702898+01	.1036650+02	.3227458+01	.3957058+01	.1211234+02	.1412502+01	1	36
.2151637+01	.1391167+02	.1465963+00	.4149063+00	.1580364+02	.1164542+01	1	37
-.9414739+00	.1786352+02	.3113515+01	.1000000+02	.1005011+02	.1065392+02	1	38
.1360020+01	.9794944+01	.1019212+02	.3087890+01	.9069250+01	.9178240+01	1	39
.4810446+01	.7742590+01	.7990235+01	.6530797+01	.5978846+01	.6366944+01	1	40
.6203301+01	.4209569+01	.4746372+01	.9854134+01	.2571041+01	.3101169+01	1	41
.1157840+02	.6447390+00	.1443609+01	.1337690+02	.5529675+00	.4217263+00	1	42
.1529038+02	.1295507+01	.1104574+01	.1737620+02	.3526360+01	.6000000+01	1	43
.9566601+01	.1016395+02	.9147167+00	.9120658+01	.9553957+01	.2631614+01	1	44
.6206567+01	.8549792+01	.4336353+01	.6730981+01	.7106534+01	.6014437+01	1	45
.5079657+01	.5650146+01	.7677060+01	.3477630+01	.4213701+01	.9338155+01	1	46
.3912023+01	.6000000+01	.9146162+01	.9682416+01	.4699944+00	.8478502+01	1	47
.8966470+01	.2162424+01	.7518772+01	.7983591+01	.3061739+01	.5916971+01	1	48
.6617202+01	.5544942+01	.4443451+01	.5281614+01	.7215101+01	.2481378+01	1	49
.3896679+01	.6678140+01	.4248495+01	.8000000+01	.6881964+01	.9326650+01	1	50
.5983360+01	.8249766+01	.6620668+01	.1762315+01	.8882644+01	.9327451+01	1	51
.5935448+01	.8249766+01	.6620668+01	.1762315+01	.7155199+01	.7616941+01	1	52
.3450090+01	.5526361+01	.6226812+01	.5138778+01	.3821185+01	.4423604+01	1	53
.6810291+01	.2111361+01	.3356310+01	.6466352+01	.4605170+01	.6000000+01	1	54
.6537866+01	.9022980+01	.3737122+00	.7922648+01	.6224138+01	.1324182+01	1	55
.6727643+01	.7089911+01	.3024039+01	.5113300+01	.5677471+01	.4701928+01	1	56
.3285595+01	.4189867+01	.6356935+01	.1572676+01	.2669362+01	.7991797+01	1	57
.5010635+01	.6003000+01	.7784644+01	.8588496+01	.8819303+00	.7191169+01	1	58
.7676353+01	.8232141+00	.6021005+01	.6337203+01	.2504389+01	.4391443+01	1	59
.4781937+01	.4154170+01	.2636901+01	.3150647+01	.5778804+01	.1014041+01	1	60
.1553566+01	.7393796+01	.5416100+01	.6000000+01	.6746161+01	.7446465+01	1	61
-.1396553+01	.5962768+01	.6720433+01	.2841906+00	.4696295+01	.5221803+01	1	62
.1935095+01	.3136792+01	.3647715+01	.3561490+01	.1598048+01	.2237596+01	1	63
.5183480+01	.1951048+00	.9623943+00	.6807775+01	.5828946+01	.6000000+01	1	64
.5971420+01	.6963583+01	.1950553+01	.4936915+01	.5694486+01	.2986722+00	1	65
.3615542+01	.4416069+01	.1336231+01	.2072908+01	.3144276+01	.2971840+01	1	66
.5323556+00	.1743520+01	.4590056+01	.5944488+00	.3587404+00	.6212626+01	1	67
.6214608+01	.6000000+01	.5331142+01	.6262835+01	.2492295+01	.4508515+01	1	68
.5163779+01	.6456521+00	.3063263+01	.3783490+01	.7875002+00	.1373671+01	1	69
.2282935+01	.2409632+01	.3018415+01	.7675013+00	.4024617+01	.9145189+00	1	70
-.5166674+00	.5636089+01	.6551080+01	.4000000+01	.4353814+01	.5656920+01	1	71
-.2965679+01	.3461434+01	.4421383+01	.1333000+01	.2031924+01	.2865975+01	1	72
.2917569+00	.5712825+00	.1377425+01	.1908540+01	.6907755+01	.4000000+01	1	73
.2897134+01	.4907788+01	.3484610+01	.1773010+01	.3530612+01	.1859595+01	1	74
.4101817+00	.1980874+01	.2381293+00	.7382239+00	.4405983+00	.1375212+01	1	75
.7718685+01	.4000000+01	.8616165+01	.2738894+01	.4686896+01	.9638246+00	1	76
.1267920+01	.3065075+01	.1412205+01	.1671261+00	.1449881+01	.1574346+01	1	77
-.1197488+01	.1602400+00	.0000000	.0000000	.0000000	.0000000	1	78

50

DIANE/SCAT SEA WATER-1A TEMP(1.-1.E4 EV) 1 FREQ. CI/JM 10-9-67

.1000000+01	.9840000+03
1138.	.2400000+02

1 0

AFWL-TR-67-131, Vol IV

.4054651-00	.1300000+02	.9070314+01	.1316246+02	.1245527+01	.8423728+01	1	1
.1282334+02	.3229571+01	.8169887+01	.1266674+02	.5595761+01	.7864971+01	1	2
.1200709+02	.6260290+01	.7267011+01	.1062576+02	.1085060+02	.6016017+01	1	3
.8425489+01	.1300130+02	.4230730+01	.7139141+01	.1487128+02	.2254415+01	1	4
.5158328+01	.1600160+02	.2762316-00	.3178981+01	.1858084+02	.1314397+01	1	5
.1124927+01	.2000560+02	.2164564+01	.8130693-00	.2277281+02	.2399169+01	1	6
-.1960497+01	.2513563+02	.2422835+01	.2356177+01	.2760464+02	.8104302-00	1	7
.1390000+02	.1117920+02	.1300014+02	.2366583+01	.1000477+02	.1346940+02	1	8
.4095000+01	.1020544+02	.1297621+02	.7085606+01	.9170256+01	.1163728+02	1	9
.9161447+01	.7507469+01	.9676538+01	.1044982+02	.5726193+01	.7793492+01	1	10
.1260494+02	.4002350+01	.6067024+01	.1433405+02	.2749446+01	.4477474+01	1	11
.1618733+02	.1354903+01	.2853598+01	.1817879+02	.4392896-00	.8048432-00	1	12
.2026957+02	.1764603+01	.9900045-00	.2242184+02	.2265767+01	.2076269+01	1	13
.2468863+02	.2284501+01	.2243150+01	.2715659+02	.1223775+01	.1300000+02	1	14
.1267044+02	.1367425+02	.3052091+01	.1201578+02	.1300300+02	.5093264+01	1	15
.1106286+02	.1222333+02	.7007664+01	.9637914+01	.1091019+02	.8773235+01	1	16
.8115655+01	.9307405+01	.1044416+02	.6478841+01	.7672904+01	.1221258+02	1	17
.4675039+01	.5436372+01	.1396452+02	.2868217+01	.4145367+01	.1577054+02	1	18
.1284644+01	.2400878+01	.1771931+02	.3671857-00	.8125214-00	.1485301+02	1	19
-.1632976+01	.1108345+01	.2202527+02	.2077400+01	.1951460+01	.2430228+02	1	20
-.2072269+01	.2041531+01	.2676050+02	.1609438+01	.1300000+02	.1302660+02	1	21
.1320220+02	.3020412+01	.1236172+02	.1271572+02	.4838598+01	.1119387+02	1	22
.1208543+02	.8645435+01	.9627678+01	.1078768+02	.8407742+01	.7930646+01	1	23
.9094080+01	.1010466+02	.6307644+01	.7452309+01	.1179574+02	.4617225+01	1	24
.5722733+01	.1357676+02	.2792234+01	.3912537+01	.1540400+02	.1095275+01	1	25
.2235131+01	.1734296+02	.5666609-00	.4526370-00	.1946442+02	.1593813+01	1	26
-.1149759+01	.2164706+02	.1864925+01	.1764264+01	.2396270+02	.1875889+01	1	27
-.1850920+01	.2830517+02	.1945910+01	.1300000+02	.1262295+02	.1294883+02	1	28
.2777600+01	.1211191+02	.1251828+02	.4553117+01	.1046515+02	.1188910+02	1	29
.6328027+01	.9489293+01	.1059143+02	.8057068+01	.7735578+01	.8944119+01	1	30
.9774750+01	.6040577+01	.7224841+01	.1146410+02	.4474232+01	.5498731+01	1	31
.1324382+02	.2747482+01	.3745447+01	.1508322+02	.9596773-00	.2054260+01	1	32
.1702008+02	.8836296-00	.2528369-00	.1913621+02	.1502478+01	.1168923+01	1	33
.2133811+02	.1707040+01	.1650161+01	.2383970+02	.1743943+01	.1722826+01	1	34
.2601736+02	.2302585+01	.1300000+02	.1144032+02	.1260916+02	.2469860+01	1	35
.1162030+02	.1223066+02	.4232819+01	.1062140+02	.1161356+02	.5969121+01	1	36
.9164510+01	.1029417+02	.7647675+01	.7602617+01	.8644416+01	.9421124+01	1	37
.5467407+01	.6950794+01	.1111894+02	.4149864+01	.5196736+01	.1289438+02	1	38
.2427026+01	.3447453+01	.1473520+02	.5727550-00	.1662548+01	.1666956+02	1	39
-.9369663-00	.1332299-00	.1873447+02	.1576347+01	.1350216+01	.2087906+02	1	40
-.1722920+01	.1662411+01	.2312222+02	.1742236+01	.1724502+01	.2548605+02	1	41
.2708050+01	.1300000+02	.1048882+02	.1209828+02	.2088948+01	.1084310+02	1	42
.1177563+02	.3835252+01	.1022558+02	.1105044+02	.5566574+01	.9032275+01	1	43
.9664273+01	.7291653+01	.7347596+01	.7964776+01	.9006634+01	.5454349+01	1	44
.6176133+01	.1064404+02	.3348861+01	.4245398+01	.1243156+02	.1414074+01	1	45
.2434253+01	.1421672+02	.3152867-00	.5905908-00	.1609172+02	.1342246+01	1	46
-.9546343-00	.1813317+02	.1646751+01	.1601741+01	.2027431+02	.1724049+01	1	47
-.1711730+01	.2251759+02	.1741248+01	.1723780+01	.2488155+02	.3113515+01	1	48
.1300000+02	.9845139+01	.1148278+02	.1672926+01	.9728796+01	.1108683+02	1	49
.3408313+01	.9291782+01	.1019703+02	.5128427+01	.8155811+01	.8572520+01	1	50
.6836514+01	.6347823+01	.6730674+01	.8507501+01	.4269362+01	.4908915+01	1	51
.1013472+02	.2295699+01	.3049981+01	.1184005+02	.5063691-00	.1296859+01	1	52
.1361447+02	.8101634-00	.3679829-00	.1548769+02	.1470597+01	.1410814+01	1	53
.1752892+02	.1693871+01	.1681528+01	.1966984+02	.1735348+01	.1718023+01	1	54
.2191263+02	.1739403+01	.1721150+01	.2427684+02	.3526360+01	.1300000+02	1	55

.6665674+01	.1063710+02	.1206839+01	.8412427+01	.1064635+02	.2915384+01	1	56
.7780201+01	.6932365+01	.4614878+01	.6614170+01	.7187704+01	.6273524+01	1	57
.5039664+01	.5415763+01	.7909236+01	.3264952+01	.3641839+01	.9528654+01	1	58
.1446937+01	.1925295+01	.1122562+02	.1511699+00	.2412285+00	.1299914+02	1	59
-.1197841+01	-.1048884+01	.1407300+02	-.1620458+01	-.1568548+01	.1692137+02	1	60
-.1675063+01	-.1641644+01	.1909989+02	-.1632805+01	-.1611096+01	.2139923+02	1	61
-.1598856+01	-.1578829+01	.2380046+02	.3912023+01	.1300000+02	.7797999+01	1	62
.9706659+01	.7541540+00	.7396314+01	.6894511+01	.2413147+01	.6719872+01	1	63
.7627595+01	.4079461+01	.5454869+01	.6036732+01	.5714172+01	.3410324+01	1	64
.4419194+01	.7336456+01	.2095139+01	.2884396+01	.8959898+01	.5890441+00	1	65
.1598287+01	.1067588+02	-.5837898+00	.4075532+00	.1249762+02	-.1290688+01	1	66
-.6415374+00	.1441615+02	.1446196+01	-.1280858+01	.1651242+02	-.1515991+01	1	67
-.1466631+01	.1888617+02	-.1517523+01	-.1495612+01	.2093717+02	-.1517634+01	1	68
-.1499017+01	.2330124+02	.4244495+01	.1300000+02	.7578164+01	.9180064+01	1	69
.2955042+00	.6961777+01	.8174546+01	.1947210+01	.6074658+01	.6407232+01	1	70
.3591835+01	.4063968+01	.5546977+01	.5235533+01	.2968758+01	.4366802+01	1	71
.8666354+01	.1462688+01	.3230392+01	.8555154+01	.1441897+00	.1910887+01	1	72
.1030190+02	-.8518457+00	.4839956+00	.1211885+02	-.1350578+01	-.7864132+00	1	73
.1400740+02	.1486386+01	.1369971+01	.1605099+02	-.1509206+01	-.1482511+01	1	74
.1819194+02	.1513699+01	.1496538+01	.2043445+02	.1515708+01	-.1497583+01	1	75
.2279822+02	.4605170+01	.1300000+02	.7636415+01	.8966730+01	-.2022921+00	1	76
.6828043+01	.6091946+01	.1456427+01	.5670745+01	.6974361+01	.3126202+01	1	77
.4100040+01	.5661969+01	.4803923+01	.2408417+01	.4341411+01	.6474653+01	1	78
.8026413+00	.2872668+01	.8122101+01	-.4641747+00	.1260935+01	.9429115+01	1	79
-.1152978+01	-.2303277+00	.1160437+02	-.1395580+01	-.1172170+01	.1347721+02	1	80
-.1407588+01	-.1446697+01	.1551802+02	-.1505351+01	-.1441482+01	.1765828+02	1	81
-.1514634+01	.1496886+01	.1990026+02	-.1515768+01	-.1497431+01	.2226348+02	1	82
.5010635+01	.1300000+02	.7735168+01	.8776437+01	.7452239+00	.6785114+01	1	83
.7935558+01	.9367200+00	.5429678+01	.6557082+01	.2624912+01	.3742614+01	1	84
.4996697+01	.4286743+01	.1637769+01	.3383159+01	.5915407+01	.2550796+00	1	85
.1782130+01	.7530266+01	.6992161+00	.2455132+00	.9225570+01	-.1145117+01	1	86
-.9131741+00	.1099793+02	.1391344+01	-.1381729+01	.1266981+02	.1494447+01	1	87
-.1481822+01	.1491005+02	.1513240+01	-.1495615+01	.1705015+02	-.1515318+01	1	88
-.1496997+01	.1929237+02	.1514324+01	-.1496531+01	.2165622+02	.5416100+01	1	89
.1300000+02	.6907201+01	.6183227+01	-.1270193+01	.6012264+01	.6988599+01	1	90
.4121270+00	.4614764+01	.5392645+01	.2066174+01	.2900394+01	.3766060+01	1	91
.3697089+01	.1206208+01	.2154748+01	.5312846+01	-.6322155+01	.6283131+00	1	92
.6923065+01	-.8945582+00	.6402363+00	.8617842+01	-.1329660+01	-.1287778+01	1	93
.1039008+02	.1480040+01	.1400594+01	.1226243+02	-.1509488+01	-.1490998+01	1	94
.1430333+02	.1513373+01	.1495013+01	.1644378+02	-.1513845+01	.1495468+01	1	95
.1868583+02	.1513695+01	.1495498+01	.2104907+02	.5828946+01	.1300000+02	1	96
.5397169+01	.7176717+01	.1628588+01	.4376185+01	.5726274+01	-.1710793+00	1	97
.3115847+01	.4206192+01	.1459496+01	.1706218+01	.2652311+01	.3081928+01	1	98
.3294098+00	.1108452+01	.4694763+01	-.6888060+00	.2258772+00	.6305502+01	1	99
-.1251038+01	.1099510+01	.8000091+01	-.1453289+01	-.1414801+01	.9772412+01	1	100
-.1502219+01	.1462669+01	.1164432+02	-.1512230+01	-.1493827+01	.1368457+02	1	101
-.1513717+01	.1495299+01	.1582464+02	-.1513896+01	.1495474+01	.1806660+02	1	102
-.1513915+01	.1495492+01	.2042981+02	.6214608+01	.1300000+02	.4063753+01	1	103
.6106467+01	.2373568+01	.3282171+01	.4782520+01	.7298630+00	.2052535+01	1	104
.3237767+01	.8896825+00	.6714396+00	.1705288+01	.2505338+01	-.4461958+00	1	105
.2895060+00	.4117745+01	.1101351+01	.8070363+00	.5728008+01	.1401452+01	1	106
-.1329227+01	.7822041+01	.1491673+01	-.1463958+01	.9194050+01	-.1511418+01	1	107
-.1490927+01	.1106566+02	.1514633+01	-.1495224+01	.1310608+02	.1515030+01	1	108
-.1495759+01	.1526615+02	.1515077+01	-.1495822+01	.1748811+02	-.1515082+01	1	109
-.1495829+01	.1985132+02	.6551060+01	.1300000+02	.3149894+01	.5388528+01	1	110

-2840344+01 .2319954+01 .3945220+01 .1229842+01 .1142725+01 .2434616+01 1 111
 .3670207-00 .5874038+01 .9174010-00 .2001618+01 .9401958-00 .3079390-00 1 112
 .3613396+01 .1343458+01 .1158724+01 .5223431+01 .1482905+01 .1427282+01 1 113
 .6917356+01 .1515383+01 .1406221+01 .8689346+01 .1521472+01 .1496836+01 1 114
 .1056115+02 .1522447+01 .1490526+01 .1260138+02 .1522577+01 .1498744+01 1 115
 .1474144+02 .1522542+01 .1496775+01 .1698340+02 .1522594+01 .1498778+01 1 116
 .1934661+02 .6907755+01 .1300000+02 .1631211+01 .4010279+01 .3377161+01 1 117
 .7233717-00 .2577512+01 .1761949+01 .3340405-00 .1049671+01 .1469518-00 1 118
 .1055483+01 .2232362-00 .1466922+01 .1393253+01 .1083271+01 .3078460+01 1 119
 .1500835+01 .1409412+01 .4684605+01 .1537277+01 .1491680+01 .6382347+01 1 120
 .1543504+01 .1507604+01 .6154334+01 .1544621+01 .1510661+01 .1002614+02 1 121
 .1544798+01 .1511104+01 .1206036+02 .1544821+01 .1511162+01 .1420643+02 1 122
 .1544824+01 .1511167+01 .1644834+02 .1544824+01 .1511170+01 .1081160+02 1 123
 .7313220+01 .1300000+02 .3978394-00 .3243195+01 .3981335+01 .5624651-00 1 124
 .1773927+01 .2368471+01 .1149231+01 .3289645-00 .7545604-00 .1416594+01 1 125
 .7949003-00 .8580555-00 .1527969+01 .1337235+01 .2470792+01 .1564272+01 1 126
 .1493142+01 .4080214+01 .1574267+01 .1528652+01 .5774150+01 .1576336+01 1 127
 .1535463+01 .7546136+01 .1576703+01 .1536650+01 .9447944+01 .1576762+01 1 128
 .1536838+01 .1145617+02 .1576769+01 .1536803+01 .1359823+02 .1576770+01 1 129
 .1536868+01 .1564019+02 .1576770+01 .1536868+01 .1820340+02 .7713645+01 1 130
 .1300000+02 .4571105-00 .2450783+01 .4567270+01 .1154422+01 .9672334-00 1 131
 .2975017+01 .1444528+01 .3672071-00 .1362491+01 .1548150+01 .1191508+01 1 132
 .2307214-00 .1588515+01 .1482536+01 .1862110+01 .1602254+01 .1553394+01 1 133
 .3472020+01 .1605775+01 .1588558+01 .5185953+01 .1605327+01 .1569507+01 1 134
 .6937934+01 .1605451+01 .1570005+01 .8809746+01 .1605470+01 .1570084+01 1 135
 .1084997+02 .1605473+01 .1570094+01 .1249003+02 .1605473+01 .1570096+01 1 136
 .1523199+02 .1605473+01 .1570096+01 .1759520+02 .6131531+01 .1300000+02 1 137
 .9706230-00 .1648153+01 .5205390+01 .1407890+01 .1967824-00 .3587496+01 1 138
 .1557607+01 .9258651-00 .1977016+01 .1606022+01 .1434239+01 .3684892-00 1 139
 .1622365+01 .1569945+01 .1242451+01 .1627361+01 .1549478+01 .2852754+01 1 140
 .1626006+01 .1601328+01 .4546686+01 .1626435+01 .1602485+01 .6318671+01 1 141
 .1626075+01 .1602660+01 .6190478+01 .1626882+01 .1602718+01 .1023070+02 1 142
 .1626083+01 .1602722+01 .1237077+02 .1626883+01 .1602722+01 .1461273+02 1 143
 .1626083+01 .1602722+01 .1697594+02 .8517173+01 .1300000+02 .1270196+01 1 144
 .6476649-00 .5783218+01 .1527325+01 .4528968-00 .4165701+01 .1608453+01 1 145
 .1266431+01 .2556047+01 .1632327+01 .1555390+01 .9457599-00 .1639471+01 1 146
 .1615394+01 .6643625-00 .1641279+01 .1627589+01 .2274261+01 .1641693+01 1 147
 .1630105+01 .3968192+01 .1641773+01 .1630577+01 .5740177+01 .1641787+01 1 148
 .1630654+01 .7611984+01 .1641789+01 .1630672+01 .4652206+01 .1641789+01 1 149
 .1630674+01 .1179227+02 .1641789+01 .1630674+01 .1403423+02 .1655136+01 1 150
 .1668154+01 .1639744+02 .8853665+01 .1300000+02 .1419783+01 .5753673+01 1 151
 .6207365+01 .1583654+01 .1151636+01 .4670307+01 .1635352+01 .1572539+01 1 152
 .3060637+01 .1650657+01 .1654502+01 .1450458+01 .1654071+01 .1656685+01 1 153
 .1597817-00 .1654895+01 .1667659+01 .1769610+01 .1655090+01 .1668063+01 1 154
 .3463444+01 .1655128+01 .1668134+01 .5235469+01 .1655135+01 .1668152+01 1 155
 .7107276+01 .1655136+01 .1668154+01 .9147498+01 .1655136+01 .1668154+01 1 156
 .1128756+02 .1655136+01 .1668154+01 .1352952+02 .1655136+01 .1668154+01 1 157
 .1589273+02 .9210340+01 .1300000+02 .1516826+01 .6278840-00 .6822181+01 1 158
 .1615134+01 .1417241+01 .5205186+01 .1644926+01 .1629237+01 .3595624+01 1 159
 .1652975+01 .1662142+01 .1985463+01 .1654575+01 .1666951+01 .3752287-00 1 160
 .1655017+01 .1667914+01 .1234598+01 .1655114+01 .1668110+01 .2928471+01 1 161
 .1655132+01 .1668147+01 .4700457+01 .1655135+01 .1668153+01 .6572264+01 1 162
 .1655136+01 .1668154+01 .8612485+01 .1655136+01 .1668154+01 .1075255+02 1 163
 .1655136+01 .1668154+01 .1299451+02 .1655136+01 .1668154+01 .1535772+02 1 164

467

AFWL-TR-67-131, Vol IV

.8587103+01-.1610663+01-.1592000+01 .1045892+02-.1613206+01-.1595709+01	1	53
.1249914+02-.1613478+01-.1596165+01 .1463921+02-.1613511+01-.1596219+01	1	54
.1688117+02-.1613514+01-.1596225+01 .1924438+02 .6907755+01 .1300000+02	1	55
.4597307+01 .5833017+01-.3548718+01 .3539928+01 .4538897+01-.1892163+01	1	56
.2013645+01 .3036245+01-.2585927+00 .4557049+00 .1480756+01 .1362929+01	1	57
-.7272392+00 .3439916+01 .2975944+01-.1371471+01-.1109441+01 .4586165+01	1	58
-.1578697+01-.1525714+01 .6280110+01-.1611030+01-.1588618+01 .8052098+01	1	59
-.1614480+01-.1596222+01 .9923906+01-.1614957+01-.1597350+01 .1196413+02	1	60
-.1615021+01-.1597499+01 .1410419+02-.1615028+01-.1597517+01 .1634615+02	1	61
-.1615029+01-.1597519+01 .1870936+02 .7313220+01 .1300000+02 .2965662+01	1	62
-.4899956+01-.4122499+01 .1762887+01 .3481617+01-.2483735+01 .3617111+00	1	63
.1948234+01-.8597174+00-.7920108+00 .4110869+00 .7559323+00-.1372672+01	1	64
-.8559097+00 .2368014+01-.1589523+01-.1452331+01 .3978023+01-.1614584+01	1	65
-.1582921+01 .5671922+01-.1622093+01-.1603472+01 .7443902+01-.1623277+01	1	66
-.1606761+01 .9315708+01-.1623469+01-.1607284+01 .1135593+02-.1623494+01	1	67
-.1607353+01 .1349600+02-.1623497+01-.1607361+01 .1573796+02-.1623498+01	1	68
-.1607362+01 .1810117+02 .7716685+01 .1300000+02 .1350257+01 .3904669+01	1	69
-.4715043+01-.9861305+02 .2358590+01-.3085164+01-.9273155+00 .8921359+00	1	70
-.1466246+01-.1397016+01-.4874620+00 .1481107+00-.1569400+01-.1328007+01	1	71
.1759902+01-.1620297+01-.1566652+01 .3389844+01-.1632355+01-.1614454+01	1	72
.5063728+01-.1634664+01-.1622454+01 .6835705+01-.1635089+01-.1623848+01	1	73
.8707510+01-.1635157+01-.1624069+01 .1074773+02-.1635166+01-.1624098+01	1	74
.1288780+02-.1635167+01-.1624101+01 .1512976+02-.1635167+01-.1624102+01	1	75
.1749297+02 .8131531+01 .1300000+02-.1474949+00 .2759501+01-.5321459+01	1	76
-.9307577+00 .1400358+01-.3695208+01-.1395593+01-.4486262+01-.2081614+01	1	77
-.1572026+01-.1130700+01-.4709425+00-.1625813+01-.1536260+01 .1140673+01	1	78
-.1640527+01-.1620731+01 .2750584+01-.1644148+01-.1636860+01 .4444462+01	1	79
-.1644797+01-.1639729+01 .6216437+01-.1644914+01-.1640228+01 .8088243+01	1	80
-.1644933+01-.1640307+01 .1012846+02-.1644935+01-.1640318+01 .1226853+02	1	81
-.1644935+01-.1640319+01 .1451049+02-.1644935+01-.1640319+01 .1687370+02	1	82
.8517193+01 .1300000+02-.1060825+01 .1176001+01-.5884498+01-.1455176+01	1	83
-.2429300+00-.4272888+01-.1595811+01-.1252175+01-.2659822+01-.1639657+01	1	84
-.1600225+01-.1048242+01-.1651972+01-.1660419+01 .5621978+00-.1654979+01	1	85
-.1669122+01 .2172095+01-.1655640+01-.1670618+01 .3865969+01-.1655727+01	1	86
-.1670831+01 .5637944+01-.1655742+01-.1670892+01 .7509749+01-.1655745+01	1	87
-.1670898+01 .9549970+01-.1655745+01-.1670899+01 .1169004+02-.1655745+01	1	88
-.1670899+01 .1393200+02-.1655745+01-.1670899+01 .1629521+02 .8853665+01	1	89
.1300000+02-.1273087+01 .5571208+00-.6387855+01-.1533835+01-.7508531+00	1	90
-.4776901+01-.1620631+01-.1463308+01-.3164387+01-.1646991+01-.1639668+01	1	91
-.1552911+01-.1653760+01-.1685970+01 .5749968+01-.1655468+01-.1670123+01	1	92
.1667389+01-.1655691+01-.1670756+01 .3361261+01-.1655736+01-.1670875+01	1	93
.5133235+01-.1655743+01-.1670895+01 .7005041+01-.1655745+01-.1670899+01	1	94
.9045262+01-.1655745+01-.1670899+01 .1118533+02-.1655745+01-.1670899+01	1	95
.1342729+02-.1655745+01-.1670899+01 .1579050+02 .9210340+01 .1300000+02	1	96
-.1423349+01-.7256554+01-.6922004+01-.1585093+01-.1161302+01-.5311598+01	1	97
-.1636333+01-.1579428+01-.3699284+01-.1651119+01-.1657427+01-.2087898+01	1	98
-.1654754+01-.1668826+01-.4775059+00-.1655604+01-.1670520+01 .1132378+01	1	99
-.1655718+01-.1670829+01 .2826249+01-.1655740+01-.1670887+01 .4598223+01	1	100
-.1655744+01-.1670897+01 .6470028+01-.1655745+01-.1670899+01 .8510249+01	1	101
-.1655745+01-.1670899+01 .1065032+02-.1655745+01-.1670899+01 .1288228+02	1	102
-.1655745+01-.1670899+01 .1525549+02 .0000000 .0000000 .0000000	1	103

DIANE/SCAT SHALE-18 INPUT TAPES (4628,2408,4027) 11-7-67 CI/LN
 .1800800+01 .9840000+03
 1129. .2400000+02

1 0

AFWL-TR-67-131, Vol IV

.4054651-00	.1300000+02	.1209713+02	.1313172+02	.1407073+01	.1175684+02	1	1
.1273210+02	.3553500+01	.1108455+02	.1238831+02	.5814084+01	.9958061+01	1	2
.1142235+02	.7956443+01	.8481625+01	.9976416+01	.1007414+02	.6475009+01	1	3
.8390024+01	.1205625+02	.5309024+01	.6732670+01	.1395918+02	.3351515+01	1	4
.4820672+01	.1583413+02	.1279987+01	.2833694+01	.1773562+02	.7071561-00	1	5
.7675641-00	.1979271+02	.2177021+01	.1080797+01	.2201375+02	.2863699+01	1	6
.2312408+01	.2449928+02	.2983355+01	.2492999+01	.2702304+02	.8109302-00	1	7
.1300000+02	.1312612+02	.1338820+02	.2100572+01	.1256820+02	.1247988+02	1	8
.4166685+01	.1173549+02	.1256182+02	.6301543+01	.1048103+02	.1148940+02	1	9
.8274792+01	.8899907+01	.9763972+01	.1008081+02	.7093512+01	.7914443+01	1	10
.1178098+02	.5253121+01	.6144491+01	.1355066+02	.3529425+01	.4560963+01	1	11
.1549705+02	.1884494+01	.2865841+01	.1757264+02	.3121217-00	.8805373-00	1	12
.1969604+02	.1889563+01	.1033220+01	.2189704+02	.2640660+01	.2351530+01	1	13
.2421772+02	.2726509+01	.2681034+01	.2669498+02	.1223775+01	.1300000+02	1	14
.1304946+02	.1320282+02	.2382168+01	.1254682+02	.1270598+02	.4315073+01	1	15
.1172789+02	.1218450+02	.6181659+01	.1045852+02	.1115693+02	.7982703+01	1	16
.8840041+01	.9677084+01	.9790905+01	.7099170+01	.7961490+01	.1159444+02	1	17
.5245080+01	.6138886+01	.1340095+02	.3359784+01	.4317655+01	.1526423+02	1	18
.1484316+01	.2458853+01	.1724945+02	.4352428-00	.5158792-00	.1938952+02	1	19
.1915958+01	.1339526+01	.2156104+02	.2492831+01	.2356796+01	.2383596+02	1	20
.2531254+01	.2503251+01	.2629244+02	.1609438+01	.1300000+02	.1272018+02	1	21
.1290964+02	.2325337+01	.1230217+02	.1252336+02	.4104277+01	.1155024+02	1	22
.1202675+02	.9556258+01	.1030521+02	.1089929+02	.7790547+01	.8597644+01	1	23
.9290960+01	.9558094+01	.6732369+01	.7517192+01	.1130407+02	.4829606+01	1	24
.5628998+01	.1310935+02	.2903664+01	.3734360+01	.1493800+02	.1052258+01	1	25
.1971748+01	.1687576+02	.7455193-00	.1368546-00	.1899539+02	.1952746+01	1	26
.1530159+01	.2117602+02	.2318285+01	.2226161+01	.2349003+02	.2347480+01	1	27
.2333446+01	.2991117+02	.1945910+01	.1300000+02	.1223101+02	.1260711+02	1	28
.2158342+01	.1193725+02	.1224976+02	.5928757+01	.1119692+02	.1168631+02	1	29
.5744219+01	.9836409+01	.1040481+02	.7534808+01	.7933888+01	.8704504+01	1	30
.9290735+01	.6128175+01	.8920464+01	.1099350+02	.4395575+01	.5138034+01	1	31
.1277473+02	.2574431+01	.3388384+01	.1461257+02	.7244482-00	.1658427+01	1	32
.1655577+02	.1003297+01	.1635776-00	.1866384+02	.1916176+01	.1594696+01	1	33
.2087482+02	.2131026+01	.2073402+01	.2320500+02	.2161023+01	.2139858+01	1	34
.2559886+02	.2302585+01	.1300000+02	.1169093+02	.1225259+02	.1906721+01	1	35
.1141665+02	.1187767+02	.3061646+01	.1055862+02	.1123802+02	.5453303+01	1	36
.9111235+01	.9909040+01	.7210105+01	.7410783+01	.8234993+01	.8944984+01	1	37
.5693745+01	.6537660+01	.1064764+02	.3928641+01	.4804401+01	.1242827+02	1	38
.2169505+01	.3097611+01	.1428724+02	.3697033-00	.1377280+01	.1624503+02	1	39
.1195079+01	.4193719-00	.1832657+02	.1906343+01	.1659844+01	.2049918+02	1	40
.2073595+01	.2032575+01	.2276220+02	.2074109+01	.2056026+01	.2515299+02	1	41
.2708050+01	.1300000+02	.1134137+02	.1180964+02	.1596253+01	.1095346+02	1	42
.1145385+02	.3319236+01	.1004904+02	.1068998+02	.5084488+01	.8754167+01	1	43
.9326838+01	.8830168+01	.7055973+01	.7649486+01	.8569340+01	.5246343+01	1	44
.5928800+01	.1028026+02	.3341629+01	.4140532+01	.1204093+02	.1484207+01	1	45
.2363368+01	.1385182+02	.1886456-00	.5837179-00	.1575363+02	.1446379+01	1	46
.1015441+01	.1782325+02	.1884390+01	.1804606+01	.1999365+02	.1972761+01	1	47
.1953761+01	.2226291+02	.1964963+01	.1946715+01	.2465686+02	.3113515+01	1	48
.1300000+02	.1100579+02	.1144710+02	.1223588+01	.1061827+02	.1106285+02	1	49
.2954258+01	.9746662+01	.1012007+02	.4709680+01	.8240276+01	.8637969+01	1	50
.6446816+01	.6379861+01	.6952999+01	.8147430+01	.4570085+01	.5231016+01	1	51
.9809918+01	.2811537+01	.3508419+01	.1154200+02	.1013183+01	.1809823+01	1	52
.1334849+02	.5834654-00	.1137229+00	.1525405+02	.1512248+01	.1243348+01	1	53
.1732856+02	.1821105+01	.1772265+01	.1958252+02	.1863841-01	.1843092+01	1	54
.2177729+02	.1845270+01	.1826699+01	.2417089+02	.3526360+01	.1308800+02	1	55

AFWL-TR-67-131, Vol IV

.1027325+02	.1044754+02	.0206351-00	.9468992+01	.1054140+02	.2548563+01	1	56
.9096508+01	.9570551+01	.4274056+01	.7560967+01	.8147647+01	.5964511+01	1	57
.5797011+01	.6358563+01	.7642574+01	.4002452+01	.4652202+01	.9299349+01	1	58
.2222251+01	.2963441+01	.1103378+02	.5633972-00	.1307548+01	.1284336+02	1	59
-.8467535-00	-.2637137-00	.1474955+02	-.1548204+01	.1386305+01	.1681909+02	1	60
-.1764236+01	-.1713753+01	.1844140+02	-.1755463+01	.1733158+01	.2127397+02	1	61
-.1733187+01	-.1714773+01	.2366346+02	.3912023+01	.1300000+02	.9229295+01	1	62
.1011104+02	.3953294-00	.8734439+01	.4335920+01	.2094253+01	.7804737+01	1	63
.8273900+01	.3765350+01	.6319204+01	.6849119+01	.5460402+01	.4840408+01	1	64
.5440869+01	.7127804+01	.3241043+01	.4026608+01	.8784586+01	.1583225+01	1	65
.2416736+01	.1052174+02	-.0087559-01	.8285147-00	.1233911+02	-.1149175+01	1	66
-.6031649-00	.1424643+02	-.1618432+01	-.1441421+01	.1632424+02	-.1698067+01	1	67
-.1663025+01	.1848456+02	-.1714126+01	-.1644704+01	.2073788+02	-.1713335+01	1	68
-.1694472+01	.2310524+02	.4248445+01	.1300000+02	.8704543+01	.9435793+01	1	69
-.1341998-01	.8202576+01	.8718213+01	.1678803+01	.7268054+01	.7641731+01	1	70
.3368132+01	.5837044+01	.6287514+01	.5043110+01	.4252368+01	.4434413+01	1	71
.8714559+01	.2555185+01	.3485341+01	.8384735+01	.8779872-00	.1942085+01	1	72
.1011961+02	-.5371360-00	.3844014-00	.1142434+02	-.1341516+01	-.9351904-00	1	73
.1381027+02	-.1628743+01	-.1550138+01	.1585692+02	-.1690396+01	-.1669290+01	1	74
.1800275+02	-.1696279+01	.1674052+01	.2025161+02	.1642547+01	-.1674372+01	1	75
.2262139+02	.4605170+01	.1300000+02	.8400974+01	.9071832+01	-.4617582-00	1	76
.7864209+01	.6342668+01	.1234038+01	.6826023+01	.7208133+01	.2432991+01	1	77
.5237034+01	.5742801+01	.4014271+01	.3583624+01	.4341419+01	.6286020+01	1	78
.1881522+01	.2823744+01	.7926383+01	.2643765-00	.1235804+01	.9636436+01	1	79
-.8964014-00	.2960346-00	.1141648+02	-.1455124+01	.1245752+01	.1329579+02	1	80
-.1624656+01	.1610243+01	.1534302+02	-.1673994+01	-.1658253+01	.1748900+02	1	81
-.1673418+01	.1655264+01	.1474146+02	-.1656296+01	-.1637919+01	.2212292+02	1	82
.5010635+01	.1300000+02	.7871947+01	.8672108+01	.9670005-00	.7294575+01	1	83
.7827173+01	.7344897-00	.614718+01	.6449856+01	.2430238+01	.4518821+01	1	84
.5013661+01	.4092652+01	.2790251+01	.3471477+01	.5727373+01	.1249873+01	1	85
.1940222+01	.7344534+01	-.1368710-00	.4081646-00	.9052587+01	-.1090427+01	1	86
-.8134989-00	.1083563+02	-.1506766+01	-.1415898+01	.1272517+02	-.1615150+01	1	87
-.1503275+01	.1478414+02	-.1625338+01	-.1605737+01	.1673641+02	-.1626346+01	1	88
-.1607918+01	.1918104+02	-.1626496+01	-.1608139+01	.2154457+02	.5416100+01	1	89
.1300000+02	.7122771+01	.7445822+01	-.1471424+01	.6357321+01	.6848880+01	1	90
.2164523-00	.5128011+01	.5404307+01	.1879335+01	.3650545+01	.4010153+01	1	91
.3519550+01	.2131634+01	.2646445+01	.5150172+01	.6233367-00	.1343101+01	1	92
.6780601+01	-.6533372-00	.3662010-01	.8443081+01	.1336238+01	-.1029191+01	1	93
.1027565+02	-.1558806+01	.1442307+01	.1215036+02	-.1611923+01	-.1492399+01	1	94
.1419104+02	-.1623265+01	-.1606301+01	.1633123+02	-.1626126+01	-.1607967+01	1	95
.1857319+02	-.1626511+01	-.1608143+01	.2093640+02	.5828946+01	.1300000+02	1	96
.6395410+01	.7222644+01	-.2012474+01	.5447414+01	.6002008+01	-.3475837-00	1	97
.4371646+01	.4771604+01	.1300000+01	.2844396+01	.3477470+01	.2944811+01	1	98
.1256569+01	.2043248+01	.4574653+01	-.1660537-00	.5680126-00	.6191702+01	1	99
-.1076958+01	-.7212604-00	.7887446+01	-.1453595+01	.1390864+01	.9659796+01	1	100
-.1582132+01	-.1571833+01	.1153167+02	-.1619447+01	.1603369+01	.1357191+02	1	101
-.1625814+01	-.1607525+01	.1571204+02	-.1625846+01	-.1607485+01	.1795454+02	1	102
-.1623613+01	-.1605222+01	.2032007+02	.6214608+01	.1300000+02	.5656698+01	1	103
.6524931+01	-.2538745+01	.4931345+01	.5517181+01	-.8804014-00	.3672555+01	1	104
.4178168+01	.7604539-00	.2078295+01	.2654551+01	.2388220+01	.5356671-00	1	105
.1084833+01	.4004257+01	-.6248334-00	-.2961344-00	.5615254+01	-.1283461+01	1	106
-.1205478+01	.7309449+01	-.1544855+01	-.1524724+01	.9081894+01	-.1610796+01	1	107
-.1591444+01	.1095536+02	-.1619625+01	-.1600775+01	.1299844+02	-.1618698+01	1	108
-.1600243+01	.1514105+02	-.1618121+01	-.1544742+01	.1738382+02	-.1618064+01	1	109
-.1599670+01	.1974713+02	.6551080+01	.1300000+02	.4746235+01	.5952726+01	1	110

- .3002100+01 .3885470+01 .4684841+01 .4361169+01 .2560068+01 .3225920+01	1 111
.2087895+00 .1058800+01 .1652328+01 .1887104+01 .2481885+00 .2217842+00	1 112
.3500058+01 .1094022+01 .6312725+00 .5112451+01 .1480051+01 .1371031+01	1 113
.6000911+01 .1588090+01 .1546308+01 .8583504+01 .1611291+01 .1590857+01	1 114
.1045063+02 .1610000+01 .1590631+01 .1249715+02 .1617917+01 .1599566+01	1 115
.1463726+02 .1618022+01 .1599046+01 .1607923+02 .1618030+01 .1599653+01	1 116
.1924244+02 .6907755+01 .1300000+02 .3762158+01 .5091725+01 .3515428+01	1 117
.2745532+01 .3719193+01 .1834384+01 .1371981+01 .2227399+01 .2617208+00	1 118
.2842349+01 .8420404+00 .1355766+01 .8843940+00 .2929443+00 .2970934+01	1 119
- .1347876+01 .1098355+01 .4543139+01 .1539977+01 .1487918+01 .6277928+01	1 120
- .1600734+01 .1582267+01 .8050116+01 .1615779+01 .1597423+01 .9921960+01	1 121
- .1617422+01 .1599249+01 .1196219+02 .1617590+01 .1599465+01 .1410225+02	1 122
- .1617610+01 .1599491+01 .1634421+02 .1617612+01 .1599494+01 .1470743+02	1 123
.7313220+01 .1300000+02 .2961555+01 .4230871+01 .4108706+01 .1976535+01	1 124
.2845152+01 .2484692+01 .6935671+00 .1534742+01 .8635472+00 .4614244+00	1 125
.2077193+00 .7530500+00 .1153978+01 .8734200+00 .2365843+01 .1498210+01	1 126
- .1427336+01 .3976033+01 .1598360+01 .1570963+01 .5669974+01 .1613171+01	1 127
- .1594116+01 .7441962+01 .1615258+01 .1597748+01 .9313769+01 .1615543+01	1 128
- .1598317+01 .1135399+02 .1615626+01 .1598393+01 .1349406+02 .1615631+01	1 129
- .1598401+01 .1573602+02 .1615631+01 .1598402+01 .1809923+02 .7718685+01	1 130
.1300000+02 .1840228+01 .3403731+01 .4707451+01 .1001201+01 .2122884+01	1 131
- .3003005+01 .1710305+00 .7127535+00 .1464869+01 .1105120+01 .5896291+00	1 132
.1460414+00 .1496537+01 .1355312+01 .1757950+01 .1590797+01 .1445035+01	1 133
.3367902+01 .1609011+01 .1507615+01 .5061709+01 .1613383+01 .1595406+01	1 134
.6833766+01 .1613964+01 .1598813+01 .8705572+01 .1614056+01 .1597024+01	1 135
.1074579+02 .1614068+01 .1597052+01 .1288586+02 .1614070+01 .1597055+01	1 136
.1512782+02 .1614070+01 .1597055+01 .1749103+02 .8131531+01 .1300000+02	1 137
.2767546+00 .2379004+01 .5313765+01 .8038533+00 .4936718+00 .3695637+01	1 138
- .1235792+01 .3749507+00 .2003260+01 .1516224+01 .1243725+01 .4772023+00	1 139
- .1594527+04 .1522050+01 .1130735+01 .1613934+01 .1598872+01 .2740045+01	1 140
- .1610735+01 .1599990+01 .4942723+01 .1614050+01 .1602344+01 .6214479+01	1 141
- .1610000+01 .1601500+01 .0004300+01 .1610000+01 .1601500+01 .1612000+01	1 142
- .1610000+01 .1601500+01 .1200000+01 .1610000+01 .1601500+01 .1610000+01	1 143
- .1610000+01 .1601500+01 .1601500+01 .1601500+01 .1601500+01 .1601500+01	1 144
.1607844+01 .5009922+01 .1277949+01 .1941307+00 .4273187+01 .1513525+01	1 145
- .9460136+00 .2681475+01 .1596649+01 .1450301+01 .1050124+01 .1622206+01	1 146
- .1584699+01 .5062559+00 .1628476+01 .1610190+01 .2170155+01 .1629910+01	1 147
- .1615460+01 .3064030+01 .1630011+01 .1616061+01 .5636005+01 .1630056+01	1 148
- .1617027+01 .7507011+01 .1630063+01 .1617053+01 .9548032+01 .1630064+01	1 149
- .1617056+01 .1168810+02 .1630064+01 .1617057+01 .1393006+02 .1630064+01	1 150
- .1617057+01 .1629327+02 .6053605+01 .1300000+02 .1187409+01 .9054291+00	1 151
- .6393452+01 .1493507+01 .4745314+00 .4777428+01 .1594200+01 .1296855+01	1 152
- .3166004+01 .1626174+01 .1554312+01 .1554401+01 .1635947+01 .1616911+01	1 153
- .5555455+01 .1638362+01 .1627527+01 .1665448+01 .1638907+01 .1629932+01	1 154
- .3359322+01 .1639011+01 .1630363+01 .5131297+01 .1639030+01 .1630462+01	1 155
.7003102+01 .1639033+01 .1630474+01 .9043324+01 .1639033+01 .1630476+01	1 156
.1118339+02 .1639033+01 .1630476+01 .1342535+02 .1639033+01 .1630476+01	1 157
.1578856+02 .9210340+01 .1300000+02 .1461882+01 .6115247+01 .6427750+01	1 158
- .1595925+01 .1046192+01 .5312217+01 .1636792+01 .1517074+01 .3700100+01	1 159
- .1648326+01 .1627186+01 .2089793+01 .1655047+01 .1669296+01 .4794520+00	1 160
- .1655647+01 .1670659+01 .1130437+01 .1655735+01 .1670694+01 .2624309+01	1 161
- .1655752+01 .1670938+01 .4596284+01 .1655755+01 .1670946+01 .6468090+01	1 162
- .1655755+01 .1670947+01 .8508311+01 .1655755+01 .1670947+01 .1064838+02	1 163
- .1655755+01 .1670947+01 .1289034+02 .1655755+01 .1670947+01 .1525355+02	1 164

AFWL-TR-67-134, Vol IV

DIANE/12 FREQUENCIES LN/HS 3/8/67 TAPE 1809 THE 1A(1.-10.)EV/W/FROM SD2

[illegible]

DIANE/SCAT XF=12A TEMP(1-10) 12 FREQ C1/R5 5-2-67 INPUT TAPE(S230)

DATE/SCALE	AE=12A	TEMP
.1200000+02	.2870000+03	
1854.	.7000000+01	

AFWL-TR-67-131, Vol IV

.000000	.150000+02	.1160196+02	.1399873+02	.4327391+01	.1012753+02	1	1
.1239795+04	.5935003+01	.8561137+01	.1082944+02	.7544161+01	.7406447+01	1	2
.9846203+01	.9154761+01	.6233477+01	.6807264+01	.1076517+02	.4070105+01	1	3
.7533651+01	.1237501+02	.3323347+01	.6041597+01	.1406891+02	.1642248+01	1	4
.4383736+01	.1584089+02	.1522976+00	.2573075+01	.1771270+02	.1998340+01	1	5
.5695526+00	.1975292+02	.3371796+01	.1495808+01	.2189299+02	.3076369+01	1	6
-.3270036+01	.2413495+02	.4151409+01	.4040763+01	.2649816+02	.4054651+00	1	7
.1300000+02	.1160828+02	.1326247+02	.3718802+01	.1043232+02	.1176978+02	1	8
.5326967+01	.8894193+01	.1057692+02	.6936766+01	.7381175+01	.9335944+01	1	9
.8547215+01	.6036282+01	.7985933+01	.1015724+02	.4565258+01	.6444693+01	1	10
.1176689+02	.2951668+01	.4461195+01	.1346073+02	.1232760+01	.3254415+01	1	11
.1523270+02	.5805355+00	.1421335+01	.1710450+02	.2386845+01	.5677402+00	1	12
.1914472+02	.3614939+01	.2443260+01	.2128479+02	.4059094+01	.3531970+01	1	13
.2352675+02	.4163088+01	.3773938+01	.2588996+02	.8109302+00	.1300000+02	1	14
.1094630+02	.1263957+02	.3109036+01	.1046265+02	.1150208+02	.4718447+01	1	15
.7282617+01	.1084437+02	.6328794+01	.7762082+01	.1009498+02	.7939232+01	1	16
.6284604+01	.8640959+01	.9549133+01	.4731859+01	.7069166+01	.1115672+02	1	17
.3070003+01	.5417734+01	.1285254+02	.1320268+01	.3769179+01	.1462450+02	1	18
-.5112979+00	.2204726+01	.1649030+02	.2325537+01	.1120236+01	.1853653+02	1	19
-.3559241+01	.7643010+00	.2067059+02	.4021824+01	.7562200+00	.2291855+02	1	20
-.4142716+01	.6645705+00	.2528180+02	.1223775+01	.1300000+02	.1011194+02	1	21
.1202252+02	.2488516+01	.4786210+01	.1118637+02	.4097886+01	.9286066+01	1	22
.1076641+02	.5709172+01	.8229016+01	.9872682+01	.7319919+01	.6798520+01	1	23
.8481194+01	.8929866+01	.5231941+01	.7022468+01	.1053945+02	.3552807+01	1	24
.5699012+01	.1223327+02	.1793122+01	.4854134+01	.1400525+02	.5152120+01	1	25
.4363442+01	.1587744+02	.1946409+01	.4087733+01	.1793832+02	.3426922+01	1	26
.2482522+01	.2033476+02	.3760049+01	.1640039+01	.2263493+02	.3809106+01	1	27
-.3759760+01	.2499696+02	.1609438+01	.1300000+02	.9823697+01	.1138498+02	1	28
.1903698+01	.9283341+01	.1071857+02	.3515435+01	.8789966+01	.1040448+02	1	29
.5129214+01	.6263435+01	.9886899+01	.6741063+01	.7322830+01	.8696246+01	1	30
.8351587+01	.5932719+01	.7481910+01	.9964829+01	.4152941+01	.6413978+01	1	31
.1172263+02	.1140038+01	.4204736+01	.1372343+02	.1822663+01	.6863783+00	1	32
.1563371+02	.3171260+01	.2318725+01	.1767533+02	.3729838+01	.3541533+01	1	33
.1981647+02	.3809338+01	.3763806+01	.2206752+02	.3774870+01	.3751456+01	1	34
.2448309+02	.1945910+01	.1300000+02	.9819154+01	.1087764+02	.1383940+01	1	35
.9126053+01	.1033297+02	.3002869+01	.8432567+01	.9923368+01	.4625176+01	1	36
.7849561+01	.9144914+01	.6262174+01	.6858922+01	.7613118+01	.8020052+01	1	37
.4316268+01	.4975544+01	.9773148+01	.1625941+01	.2501353+01	.1148546+02	1	38
-.5356180+00	.6702459+00	.1326058+02	.1808301+01	.6972058+00	.1514331+02	1	39
-.2596932+01	.1754459+01	.1723074+02	.3301124+01	.2921444+01	.1942791+02	1	40
-.3624132+01	.3565925+01	.2168979+02	.3662407+01	.3643999+01	.2409135+02	1	41
.2302585+01	.1300000+02	.9428387+01	.1036301+02	.8446533+00	.9021461+01	1	42
.9926059+01	.2520565+01	.8194643+01	.9081217+01	.4282871+01	.6478947+01	1	43
.7443866+01	.6089758+01	.4716835+01	.5845844+01	.7646307+01	.3346218+01	1	44
.4454450+01	.9288272+01	.2228162+01	.3158927+01	.1099450+02	.9543184+00	1	45
.1844817+01	.1282648+02	.7318137+00	.1117635+00	.1475540+02	.2373254+01	1	46
-.1681466+01	.1687266+02	.3197190+01	.2941256+01	.1909729+02	.3378402+01	1	47
-.3341878+01	.2142348+02	.3355457+01	.3341855+01	.2386695+02	.0000000	1	48

THIS IS THE END OF THE DIANE OPACITY TAPE - A. KNOPP 11/11/67

3983

This page intentionally left blank.

APPENDIX III

EQUATION-OF-STATE AND RELATED PROGRAMS

Results of running HELAS and HELIKE were used as card input to MARIER. MARIER uses a polynomial fit among ionization potentials to obtain all unknown ionization potentials. The results of MARIER are used in the block data program MARI, which is used by GOLEM when GOLEM is used to run EIONX. TEDIUS computes number fractions for a given compound and these are used in DATA statements in EIONX. Input and format specifications for each code are given with the description of the code. The flow of information (dotted lines) and control (solid lines) is summarized in figure 1.

OPACITY PROGRAMS

AUGEAS creates an input data tape for DIAPHANOUS, which makes an input data tape for DIANE. DENSER condenses the DIAPHANOUS tape onto a new tape, which is edited by DASE. ANDIMX makes an opacity data tape from an 1100 binary tape converted from a LASL binary data tape. COMBO can combine DIAPHANOUS, ANDIMX, or DENSER tapes to produce a DENSER-like tape or an ANDIMX-like tape to be used by DIANE. IMESI is a calling program for DIANE, DIANTC, and DIANCT. DIANE uses a DENSER tape, an ANDIMX tape, or a DIAPHANOUS tape and creates a DIANE tape. DIANTC punches data cards or writes a DIANE BCD tape, or both, from a DIANE binary tape. DIANCT writes a DIANE binary tape from data cards punched by DIANCT or from a DIANE BCD tape.

IMES2 is a calling routine for GREYS, GREY, and REDGRE. Cards punched by DIANTC are used as input for GREYS, which makes a data tape




Figure 1. Equation-of-State and Related Programs General Flow

that is edited by EGREY. REDGRE condenses data from the GREY tape onto another data tape or punches cards in the form of DATA statements. Flow of information and control are summarized in figure 2.

PROCEDURE FOR CREATING A DIANE TAPE

AUGEAS is run to obtain an input data tape for DIAPHANOUS. This input tape must be mounted on unit 12. The card input and its formats are listed in reference 1b. AUGIAS can also be run with subroutines LEVELS and MARI as indicated in the LEVELS section of this report. To run DIAPHANOUS, the AUGIAS data tape must be mounted on unit 12 and the output tape written by DIAPHANOUS must be mounted on unit 15. The formats for the card input are listed in reference 1b. However, DIAPHANOUS has been modified slightly for use with another program. This modification necessitates that the first input card, a heading card, must not have columns 1 through 6 entirely blank for DIAPHANOUS to run in its normal mode.

LASL data tapes must be converted to 6600 binary tapes. These binary tapes are input to the ANDIMX code and must be mounted on unit 14. ANDIMX writes an output tape that must be mounted on unit 12. The card input and formats are listed in the ANDIMX section of this report.

A DIANE run is made by using a DASIAC DIAPHANOUS or SILVIA data tape, or a DIAPHANOUS tape, or an ANDIMX tape as input. If a DASIAC tape is used, the tape must be read in even parity at 556 BPI. The following routines are necessary to make a DIANE run:

IMESI is the main program and uses the following subroutines:

ALUETO, DIANTC, DIANE, DIANCT, DINNEW, DOLDIN,
DYPDIN, EDIANE, PLNKUT, SILVIA, ZSA ZSU, MERR,
DIVCHK, and DVCKON.




Figure 2. Opacity Programs General Flow

Now, SILVIA, ZSAZSU, MERR, DIVCHK, ALUETO, and DVCKON are dummy subroutines; MERR, DIVCHK, and DVCKON are system subroutines for the UNIVAC 1108, which may be dummied on the 6600.

Further information on DIANE may be found in the comments at the beginning of the listing. A flow summary is given in figure 3.

INPUT TO IMESI is two cards containing the following information:

<u>CARD</u>	<u>COLUMNS</u>	<u>FORMAT</u>	<u>VAR. NAME</u>	<u>MEANING</u>
1	1-72	12A6	ID(12)	72 columns of Hollerith title information
2	1	I1	IBIN0	Used to indicate tape identification type for DINNEW, DIANCT, DIANTC, EDIANE runs. 0 if binary ID 1 if BCD ID If > 1, used by DIANTC or DIANCT to determine output tape unit for writing a BCD-formatted DIANE tape
2	2	I1	IRUN	Determines run type: *0 if "normal" run; IBIN0 is set to zero and routines DIANE (0, IBCD0), DINNEW (0), EDIANE (10, 0), and DIANTC (10, 0) are called 1 for all other runs

* To obtain a usable "new format" (Grey absorption coefficients first), DIANE tape, and punched output data cards, set IRUN to zero. The DIANE subprogram produces an "intermediate format" (Grey coefficients last) data tape; the DINNEW subprogram produces a "new format" DIANE tape; the EDIANE subprogram edits the "new format" tape; the DIANTC subprogram punches output cards from the "new format" tape.




Figure 3. Procedure for Creating a DIANE Tape

<u>CARD</u>	<u>COLUMNS</u>	<u>FORMAT</u>	<u>VAR. NAME</u>	<u>MEANING</u>
2	3-23	20A1	IPATH(J)	<p>Array used to determine subroutines (and order of subroutines) called:</p> <p>D DIANE (SCAT, IBCD0) W DINNEW (IBIN0) E EDIANE (TAPE 10, IBIN0) C DIANTC (Tape 10, IBIN0) T DIANCT (Tape 10, IBIN0) Y DYPDIN P EDIANE (Tape 11, IBIN0) Q DIANTC (Tape 11, IBIN0) R DIANCT (Tape 11, IBIN0) N DOLDIN (IBIN0) O ALUETO A SILVIA U ZSAZSU Z calls EXIT</p>
2	25	I1	SCAT	<p>Used to indicate scattering limit in DIANE:</p> <p>0 if limit of 0.2 1 if limit of 1.E-10 2 if limit of 0.3977</p>
2	26	I1	IBCD0	<p>Used to indicate type of input DIAPHANOUS tape used by DIANE:</p> <p>0 if compressed BCD input tape 1 if noncompressed binary input tape</p>

REFERENCES CODES

Throughout this volume numerous references are made to writeups of the codes shown below. The writeups can be found in reports listed by each code.

<u>CODE</u>	<u>REFERENCE</u>
1. DIAPHANOUS	a. Stewart, J. C., and K. D. Pyatt, Jr., "A Theoretical Study of Optical Properties," Air Force Special Weapons Center Report AFSWC-TR-61-71, v. I, September 1961. b. Walsh, R. T., "DIAPHANOUS II," General Dynamics, General Atomic Division Informal Report GAMD-5549, 1964 (AD 453-351L)
2. DIANE	a. Lindley, W. B., "DIANE-A Computer Program to Provide Multi-Frequency Absorption Coefficients by Local Rosseland Averaging," General Dynamics, General Atomic Division Informal Report GAMD-5501, July 1964. b. Freeman, B. E., and C. G. Davis, "Fireball Phenomenology and Code Development," v. V, "Material Properties," Air Force Weapons Laboratory Report AFWL-TR-65-143, August 1965.
3. ZSAZSA	a. Lindley, W. B., "ZSAZSA-A Data Processor for Low-Temperature Air Absorption Coefficients," General Dynamics, General Atomic Division Informal Report GAMD-5496, July 1964. b. Freeman, B. E., and C. G. Davis, "Fireball Phenomenology and Code Development," v. V, "Material Properties," Air Force Weapons Laboratory Report AFWL-TR-65-143, August 1965.
4. SYLVIA	Smith, P. R., W. G. Vulliet, and W. B. Lindley, "Predictions of Thermal Damage in Nuclear Fireballs," v. II, "Material Properties," Air Force Flight Dynamics Laboratory Report AFFDL TR-66-45, February 1966.
5. EIONX CMOL	Pyatt, K. D., "Nuclear Explosion Interaction Studies," v. II, "Methods of Analysis of Thermal Phenomena," Air Force Weapons Laboratory Report AFWL-TR-66-108, May 1967.

<u>CODE</u>	<u>REFERENCE</u>
6. SPUTTER	a. "Optical Interactions. The SPUTTER Program," RTD TDR-63-3128, v. 2, General Dynamics, General Atomic Division, 1964. (AD 440-287).
	b. Pyatt, K. D., "Nuclear Explosion Interaction Studies," v. II, Methods of Analysis of Thermal Phenomena," Air Force Weapons Laboratory Report AFWL-TR-66-108, May 1967.

Applications of codes listed herein are given in reference 1. The contract that generated reference 1 runs concurrent with the contract for which this report is supplied; the contract for this report specifies that codes will be developed. The codes developed were supported by both of these contracts plus others.

This page intentionally left blank.

APPENDIX IV

EQUATION-OF-STATE INVERSION TECHNIQUES-
MODIFICATION TO THE GEST AND LIBEX PROGRAMS

Introduction

GEST is a Fortran IV computer program which generates equation-of-state tables. These tables are designed to be used in other programs which require thermodynamic quantities (e.g., pressure (P) and temperature (θ)) as functions of the internal energy (E) and specific volume (τ). For each material of interest GEST requires an equation-of-state subroutine, EIONX, which uses temperature and specific volume as the two independent thermodynamic variables. The program then is essentially an inversion calculation, starting, for example, with the functions $P = P(\theta, \tau)$ and $E = E(\theta, \tau)$, and producing the tabular quantities $P_{ij} = P(E_i, \tau_j)$ and $\theta_{ij} = \theta(E_i, \tau_j)$ by an iterative process, for the given set of points E_i and τ_j .

LIBEX is a subprogram which provides the calling program with pressure, temperature, and other thermodynamic quantities as functions of E and τ . It is basically a table lookup program, using the output of GEST for the tabular data.

The GEST and LIBEX programs have been revised to make available a more flexible equation-of-state system in E - τ space. Basically, the method of calculation remains the same as that described in a previous report.* The changes have concentrated on two major areas: increasing the variety of thermodynamic variables available as data tables for the calculation of temperature and pressure; and providing a section specifically for equations of state which are applicable in both the molecular and atomic regimes. (The present version is limited to two-element compounds, but can easily be extended to compounds of an arbitrary number of elements.)

Revisions to the GEST Program1. Choice of tabulated quantities

The table entries calculated in GEST are no longer limited to \bar{Z} , the mean number of free electrons per atom, and $\ln I$, where I is the

*Reed, L. L., "Equation of State Inversion from Temperature-Density to Specific Energy-Density by Table Look-up", GAMD-7189-Rev., July 1966.

internal energy due to ionization and excitation. The user now has a choice of six variables: \bar{Z} ; $\ln I$; \bar{N} , the mean number of atoms per molecule; $\ln D$, where D is the dissociation energy; \bar{Z}_1 , the mean ionic charge of the first element of a compound; \bar{Z}_2 , the mean ionic charge of the second element. Any or all of these variables may be selected by setting the appropriate flags (see Input section).

2. Extension to Molecular Regime

For a single-element material consisting of atoms, ions, and free electrons it has been found convenient to tabulate the quantities \bar{Z} , the mean number of free electrons per atom, and $\ln I$, the logarithm of the ionization energy for a given set of points in E - τ space. By analogy, equations of state have been extended to the molecular regime simply by tabulating two additional quantities: \bar{N} , the mean number of atoms per molecule, and D , the dissociation energy. These two quantities are computed in a "molecular" subroutine written expressly for the desired material. Currently available subroutines are:

<u>Name</u>	<u>Material</u>
ESILMS	Polyethylene
CMOL	Carbon
MESA	Air
ASTER	Polyethylene (improved)

The "molecular" subroutine is called by the EIONX subroutine, which acts as the master routine.

Molecular dissociation normally occurs at lower internal energies than does ionization, so that the range of internal energies for which \bar{N} and D are changing is different from the range in which \bar{Z} and I are changing. Consequently it was found desirable to tabulate \bar{N} and D for one set of energy points (the E set) and to tabulate \bar{Z} and $\ln I$ for a second set of energy points (the E' set). The two sets are related by

$$E = E' + D.$$

The reason for using two energy scales is the following: (1) The energy points are equally spaced on a logarithmic scale; (2) \bar{Z} and I go to zero

as E' goes to zero; (3) thus for small values of E' (compared to D) one would get poorly resolved tables of \bar{Z} and $\ln I$ if they were tabulated as functions of the total internal energy E . To give a numerical example, polyethylene has a total dissociation energy of 8.2×10^{11} erg/g. Using the GEST-generated data given in the listing of LIBEX at the end of this report, one finds that, at a specific volume of 10^5 cm³/g, \bar{Z} varies with E' as follows:

$\log_{10} E'$	\bar{Z}
11.2125	$< 10^{-3}$
11.3792	9.4×10^{-3}
11.5459	3.66×10^{-2}
11.7125	8.45×10^{-2}

Note that there are four entries for \bar{Z} varying between ~ 0 and 8.45×10^{-2} . In this energy range, and at this particular specific volume, the polyethylene is fully dissociated, or close to it, so that $E \approx E' + 8.2 \times 10^{11}$ erg/g. If we evaluate $\log E$ at the four points we get

$\log_{10} E'$	$\log_{10} E$
11.2125	11.968
11.3792	12.017
11.5459	12.076
11.7125	12.134

The difference between the maximum and minimum values of $\log E'$ is 0.50; the corresponding difference for E is 0.166. Thus, the tabulated \bar{Z} variation would be covered by only two points on the $\log E$ scale, as compared to four points on the $\log E'$ scale.

3. Selection of minimum energy

The criterion for choosing θ_0 for the purpose of calculating a minimum E or E' has been changed since the previous report. θ_0 is now selected so that $\bar{N}(\theta_0, \tau_{\max})$ must be greater than or equal to EN , an estimate of the maximum value of \bar{N} , and $\bar{Z}(\theta_0, \tau_{\max})$ must be less than or equal to EB , the minimum \bar{Z} . For purely atomic materials, \bar{N} is always unity and the input number EN should be set to 1.

4. Restart procedure

To deal with the more time-consuming equations of state, a data dump has been added to GEST. For each energy point and all its corresponding values of τ , the temperature and the quantities selected for the data tables are written out on tape 10. Also, an edit is printed giving the number of the energy point, MS for E or LS for E', and the quantities which have been saved on the tape. The problem can then be restarted from any energy point by specifying in input the current value of MS or LS. If restarting from an E' point, MS must be set to its maximum.

The final dump tape has several uses. By setting both MS and LS (if E' is being used) to their maximum, the tape can be used to repunch the data deck or make a final data tape using NTRAN. This tape can also be used to increase the number of decades of E and E'. The following table gives a diagram of how to set the input variables to accomplish this procedure.

To increase decades of:	MS	LS	NDUMP	DM	DL
E (not using E')	max.	0.	-1	increased no. decades	0.
E (using E')	max.	0.	-1	increased no. decades	no. decades
E'	max.	max.	-1	no. decades	increased no. decades
E and E'	max.	max.	-1	increased no. decades	increased no. decades

5. Iteration Criterion

Because any irregularity in the variation of E with θ makes iteration difficult, a new procedure has been added to GEST. If after 20 iterations the relative error between the E calculated by GEST and the desired E is greater than .5% but less than 15%, the code will use the values calculated at the energy closest to the desired E point to make up the tables. This same procedure is used for the E' points.

6. Input for GEST

Cards 2 and 6 have an integer field width of 5 and cards 3, 4, and 5 have a floating point field width of 10.

Card	Cols.	Mnemonics	Information
1			Header card-any BCD information. Will be reproduced as first line of output.
2	1-5	MS	No. of E point to be picked up on a tape restart. At start of calculation, MS must be 0.
	6-10	LS	No. of E' point to be picked up on a tape restart. Must be 0 until all E points have been calculated.
	11-15	NOPNCH	Set to 1 if punched data deck is desired, otherwise 0.
	16-20	NDUMP	0 - no dump on tape 10. 1 - pick up existing dump tape. -1 - start of problem and want to dump on tape 10 (tape 10 must be assigned). Picking up an existing dump tape to increase the number of decades of E or E'.
	21-25	ND11	Set to 1 if a data tape made using NTRAN is desired for LIBEX.
	26-30	NED	Set to 1 if table of $\ln D$ is desired, otherwise 0 or blank.
	31-35	NEI	Set to 1 if table of $\ln I$ is desired, otherwise 0 or blank.
	36-40	NNB	Set to 1 if \bar{N} table is desired, otherwise 0 or blank.
	41-45	NZB	Set to 1 if \bar{Z} table is desired, otherwise 0 or blank.
	46-50	NZB1	Set to 1 if \bar{Z}_1 table is desired, otherwise 0 or blank.
	51-55	NZB2	Set to 1 if \bar{Z}_2 table is desired, otherwise 0 or blank.

AFWL-TR-67-131, Vol IV

Card	Cols.	Mnemonics	Information
3	1-10	Z	Atomic no. of material
	11-20	A	Atomic mass no.
	21-30	V1	First ionization potential.
	31-40	VZ	Last ionization potential.
	41-50	R	No. of points per decade of E'.
	51-60	S	No. of points per decade of τ .
	61-70	T	No. of points per decade of E.
4	1-10	DN	No. of decades of τ .
	11-20	DM	No. of decades of E.
	21-30	DL	No. of decades of E'
	31-40	TAUZ	Minimum value of τ .
	41-50	EZ	Minimum value of E. If 0, the code will choose a minimum value.
	51-60	EPRZ	Minimum value of E'. If 0 the code will choose a minimum value.
	61-70	EN	Estimate of the maximum value of \bar{N} . Used to compute the minimum values of E and E'.
5	1-10	EB	Choice of minimum \bar{Z} . Sets ZBRMIN in EIONX. Used to compute the minimum value of E and E'.
	11-20	E14	Sets EION(14) before the call to EIONX. If 1, calls the molecular equation of state. Should be 0 otherwise.
	21-30	WT1	Percent of first element in the compound.
	31-40	WT2	Percent of second element in the compound.
	41-50	PAN1	Atomic number of first element of the compound.
	51-60	PAN2	Atomic number of second element of the compound.
6	1-5	IS	1 - uses EIONX for equation of state. Generally for nonmolecular equations of state. All E' quantities should be set to 0.
			2 - Uses EIONX for equation of state. Particularly for equation of state where the molecular regime is of interest. All E' variables should be set.

Card	Cols.	Mnemonics	Information
6	6-45	I1 - I8	Table region flags. If a region of the table has been entered which has no tabulated values and the flag of that region has been set to zero, a calculation will proceed using the available analytic equations. At present regions 1, 7, and 8 have analytic equations or data. (see GAM-7189 for a fuller discussion.)

Sample Data Cards

1) EXAMPLE OF CH2 DATA

2) 5 10 15 20 25 30 35 40 45 50 55
| 19 | 14 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 0 |

Pick up the 14th value of E' from tape 10 and continue the calculation.
Do not punch a data deck.

Make a final data tape using NTRAN (tape 11 must be assigned.)

Make up tables of the following quantities: $\ln D$, $\ln I$, \bar{N} , \bar{Z} .

3) 10 20 30 40 50 60 70
| 101. | 4.6667 | 11.256 | 489.84 | 6. | 3. | 6. |

Atomic number of CH2, atomic mass number, first and last ionization potentials.

6 points/decade of E'

3 points/decade of τ

6 points/decade of E

4) 10 20 30 40 50 60 70
| 9. | 3. | 3. | 1. | 0. | 0. | 4. |

9 decades τ

3 decades E

3 decades E'

Minimum value of τ is $1.0 \text{ cm}^3/\text{g}$.

Zeros indicate that the code is to choose a minimum E and E'. Estimate of maximum \bar{N} is 4.

5)

	10	20	30	40	50	60	70
	1.0	-0.3	1.0	0.0	0.0	0.0	0.0

Minimum \bar{Z}

EION(14) is set before each call to EIONX to call the molecular equation of state. Since the partial \bar{Z} 's are not being calculated, the quantities WT1, WT2, PAN1, PAN2 are unnecessary.

6)

2	0	1	1	1	1	1	0	0
---	---	---	---	---	---	---	---	---

Uses section of GEST for molecular equation of state.

The zeros indicate that the code is to use the analytic solutions provided in sections 1, 7, and 8.

6. Output

The GEST program has three forms of output: punched cards, a data tape, and printed tables.

The data tape is a new feature in GEST. The systems subroutine NTRAN is used to write out on tape 11 that portion of the data block containing all the variables necessary for LIBEX. This tape must be read in by NTRAN and a series of equivalences for the data variables must be set up with unused arrays in the calling program. This procedure has been developed especially for HECTIC as a space-saving device, but other programs could easily be adapted to use it.

The punched cards are in the form of data statements and are ready for immediate placement into LIBEX. However, for use on the 1108 all the data statements must be reproduced, placing an "E" in the data, e.g., 1.46E+10.

The printed output in the form of data tables can be used to check the punched data statements. Also a table of the θ 's corresponding to each (E, τ) and (E', τ) point is printed so that the temperature range can be checked.

Revisions to the LIBEX Program

The revisions to the LIBEX program follow the same general scheme as those in GEST. The method of calculation remains the same as that described in GAMD-7189. The major changes have been made to deal with the increased number of thermodynamic variables and the E' energy term.

The flags, set in the GEST input to determine the series of tables, are transmitted to LIBEX in the data statements to determine which quantities are to be used to calculate Θ and P.

The value of IS is also transmitted to LIBEX. If IS was set equal to 2 in GEST, the variables \bar{Z} , \bar{Z}_1 , \bar{Z}_2 , and $\ln I$ are calculated from the data tables as a function E' and τ . Otherwise all the variables are calculated as a function of E and τ . The E' term is calculated in LIBEX by subtracting the dissociation energy, previously calculated from the tables as a function of E and τ , from E. The equations for the calculation of Θ and P have also been adapted for the molecular equation of state:

$$\begin{aligned}\Theta &= (E - \phi I - D) / [1.5 \phi (1./\bar{N} + \bar{Z})] \\ P &= \phi (1./\bar{N} + \bar{Z}) \Theta / \tau\end{aligned}$$

A new function subroutine, EIONIZ, is now being used with LIBEX. This subroutine calculates the ionization energy given \bar{Z} and the atomic number. This subroutine is used when tables of \bar{Z} and \bar{Z}_1 , or \bar{Z}_1 and \bar{Z}_2 , or \bar{Z} and \bar{Z}_2 are needed, to eliminate the need for an extra table containing the ionization energy.

If a region outside the limits of the table has been entered and no analytic solution is available, an S1 flag will be set and control returned to the calling program. Thus the subroutine ERR, or a comparable error routine should always be used with LIBEX.

GEST Mnemonics

<u>Mnemonic</u>	<u>Definition</u>
A	*
AIN	!
ALGE	!
ALGEPR	$\text{Log}_{10} E'$
ALGT	!
ALIN	!
D	Dissociation energy
DLGE	!
DLGEPR	$\text{Log}_{10} E'/E'_0$
DLGT	!
DLLEPR	$\Delta E'$ above position K in the table.
DMLE	!
DNLT	!
DP	Dissociation energy
E	!
E'	Specific internal energy-dissociation energy
EB	*
EDIS	$\ln D$
EDLN	Array of $\ln D$ used in LIBEX
EDLNID	Array of $\ln D$ used in GEST
EILN	Array of $\ln I$ used in LIBEX
EILNID	!
EL	!
EM	!
EMAX	!
EMIN	!
EN	*
EPR	E'
EPRIME	Current value of EPR
EPRL	$\text{Log}_{10} E'$

! - see GAMD-7180-Rev.

* - see input for GEST, pp. 5-7.

Mnemonic	Definition
EPRM	Maximum value of E' in table
EPRZ	*
EZ	*
E14	*
GAND	Current value of E
I	!
IS	*
I1-I8	*
K	Index for table entries ($K=(M-1)NN+N$)
LL	Total number of E' points
LS	*
MM	Total number of E points
MS	*
NB	\bar{N} array used in LIBEX
NBAR	Number of atoms per molecule
NBID	\bar{N} array used in GEST
NEMAX	Maximum \bar{N}
NDUMP	*
NED	*
NEI	*
NN	Total number of τ points
NOPNCH	*
NZB	*
NZB1	*
NZB2	*
P	Pressure
PAN1	*
PAN2	*
PHI	!
STORM	Stores closest value of θ below that desired
STORTX	Stores closest value of θ above that desired
T	!
τ	!
TAUL	!

Mnemonic	Definition
TAUM	!
TAUZ	!
TH	Array of temperature in ev for E' points
THETA	!
THMAX	!
THMIN	!
THLMAX	Θ_{\max} used in interpolation, E' points
THLMIN	Θ_{\min} used in interpolation, E' points
V1	*
VZ	*
WT1	*
WT2	*
Z	*
ZB	\bar{Z} array used in LIBEX
ZBAR	!
ZBAR1	Mean ionic charge for first element of a compound
ZBAR2	Mean ionic charge of second element
ZB1	Array of \bar{Z}_1 used in LIBEX
ZB2	Array of \bar{Z}_2 used in LIBEX
ZBLD	Array of \bar{Z} in GEST
ZB1LD	Array of \bar{Z}_1 in GEST
ZB2LD	Array of \bar{Z}_2 in GEST
ZPART	Stores values of \bar{Z}_1 and \bar{Z}_2 in LIBEX

GEST, LIBEX, and EIONIZ Listings

C	GENERATE EQUATION OF STATE TABLES	EST	10
C		EST	20
	DIMENSION THETA(50,50),CARD(14),TH(50,50)	EST	30
	DIMENSION TAU(50),TAUL(50),E(50),EL(50),EPR(50),EPRL(50)	EST	40
	DIMENSION IT(1),NED(1),NEI(1),NNB(1),NZB(1),NZB1(1),NZB2(1),TAUM(1)	EST	50
	1),EM(1),EPRM(1),TAUZ(1),EZ(1),EPRZ(1),TAULZ(1),ELZ(1),EPRLZ(1),R(1)	EST	60
	2),S(1),T(1),V1(1),VZ(1),FHI(1),NBMAX(1),NX(1),MX(1),LZ(1),I1(1),I2	EST	70
	3),I3(1),I4(1),I5(1),I6(1),I7(1),I8(1),WT1(1),WT2(1),PAN1(1),		
	4 PAN2(1)		
	DIMENSION ZB1D(1594),EILN1D(1594),NB1D(1594),EDLN1D(1594),ZB11D(15	EST	90
	93),ZB21D(1593)		
	EQUIVALENCE (EB,ZBRMIN), (ZBRMIN(1),EIONIN(29))	EST	110
	EQUIVALENCE (EION(5),PHI), (EION(8),GAND), (EPRIME,EION(15))	EST	120
	EQUIVALENCE (TLMSB(14),DIS), (EION(17),NBAR)	EST	130
	COMMON/LMSC/M1(51)	EST	140
	EQUIVALENCE (ZBAR1,M1(5)), (ZBAR2,M1(15))	EST	150
	COMMON/LMSG/CARBZ(10)	EST	160
	COMMON/LMSD/ TLMS(16)	EST	170
	COMMON/LMSESN/TLMSB(15)	EST	180
	COMMON/EOSIN/EIONIN(30)	EST	190
	DIMENSION ZBRMIN(1)	EST	200
	COMMON/LMS/ EION(20)	EST	210
	EQUIVALENCE (ZBAR, EION(3)), (PHI,EION(5))	EST	220
	REAL NB1D	EST	230
	REAL NBAR	EST	240
	REAL NBMAX	EST	250
	EXPT(Q)=EXP(2.3026*Q)	EST	260
	READ (5,1860) (CARD(I),I=1,12)	EST	270
	WRITE (6,1860) (CARD(I),I=1,12)	EST	280
C	READ AND STORE INPUT	EST	290
	READ (5,1850) MS,LS,NOPNCH,NDUMP,ND11,NED,NEI,NNB,NZB,NZB1,NZB2	EST	300
	WRITE (6,1850) MS,LS,NOPNCH,NDUMP,ND11,NED,NEI,NNB,NZB,NZB1,NZB2	EST	310
	READ (5,1840) Z,A,V1,VZ,R,S,T,DN,DM,DL,TAUZ,EZ,EPRZ,EN,EB,E14,	EST	320
	1 WT1,WT2,PAN1,PAN2		
	WRITE (6,2380) Z,A,V1,VZ,R,S,T,DN,DM,DL,TAUZ,EZ,EPRZ,EN,EB,E14,	EST	330
	1 WT1,WT2,PAN1,PAN2		
	READ (5,1850) IS,I1,I2,I3,I4,I5,I6,I7,I8	EST	340
	WRITE (6,1850) IS,I1,I2,I3,I4,I5,I6,I7,I8	EST	350
	IF (NNB.NE.1) NBAR=1.0	EST	360
	IF (NDUMP) 50,50,10	EST	370
10	J=2	EST	380
C	READ DUMP TAPE		
	READ (10) TAUM,EM,EPRM,TAUZ,EZ,EPRZ,TAUL(1),EL(1),EPRL(1),PHI,NN,MEST	EST	390
	1M,LL	EST	400
	READ (10) (TAU(N),N=1,NN)	EST	410
	READ (10) (E(M),M=1,MM)	EST	420
	IF (IS.EQ.2) READ (10) (EPR(L),L=1,LL)	EST	430
	DO 20 M=1,MS	EST	440
	READ (10) (THETA(N,M),N=1,NN)	EST	450
	KMN=(M-1)*NN+1	EST	460
	KMX=KMN+NN-1	EST	470
	IF (NED.EQ.1) READ (10) (EDLN1D(K),K=KMN,KMX)	EST	480
	IF (NNB.EQ.1) READ (10) (NB1D(K),K=KMN,KMX)	EST	490
	IF (IS.EQ.2) GO TO 20	EST	500
	IF (NEI.EQ.1) READ (10) (EILN1D(K),K=KMN,KMX)	EST	510
	IF (NZB.EQ.1) READ (10) (ZB1D(K),K=KMN,KMX)	EST	520
	IF (NZB1.EQ.1) READ (10) (ZB11D(K),K=KMN,KMX)	EST	530
	IF (NZB2.EQ.1) READ (10) (ZB21D(K),K=KMN,KMX)	EST	540

20	CONTINUE	EST	550
	IF (IS.NE.2.OR.LS.EQ.0.) GO TO 40	EST	560
	DO 30 L=1,LS	EST	570
	READ (10) (TH(N,L),N=1,NN)	EST	580
	KMN=(L-1)*NN+1	EST	590
	KMX=KMN+NN-1	EST	600
	IF (NE1.EQ.1) READ (10) (EILN1D(K),K=KMN,KMX)	EST	610
	IF (NZB.EQ.1) READ (10) (ZB1D(K),K=KMN,KMX)	EST	620
	IF (NZB1.EQ.1) READ (10) (ZB11D(K),K=KMN,KMX)	EST	630
	IF (NZB2.EQ.1) READ (10) (ZB21D(K),K=KMN,KMX)	EST	640
30	CONTINUE	EST	650
40	CONTINUE	EST	660
	GO TO 160	EST	670
C	MS = E POINT FOR TAPE RESTART		
C	LS = EPRIME POINT FOR TAPE RESTART		
C	NOPNCH = 1 - PUNCH A DATA DECK		
C	NDUMP = 0 - NO DUMP ON TAPE 10		
C	= 1 - PICKUP TAPE 10		
C	= -1 - START PROBLEM AND DUMP OF TAPE 10		
C	ND11 = 1 - MAKE AN NTRAN TAPE		
C	NED = FLAG FOR EDIS TABLE		
C	NEI = FLAG FOR EION TABLE		
C	NNB = FLAG FOR NBAR TABLE		
C	NZB = FLAG FOR ZBAR TABLE		
C	NZB1 = FLAG FOR ZBAR1 TABLE		
C	NZB2 = FLAG FOR ZBAR2 TABLE		
C	Z = ATOMIC CHARGE NO.	EST	680
C	A = ATOMIC MASS NO.	EST	690
C	V1 = FIRST IONIZATION POTENTIAL	EST	700
C	V2 = LAST IONIZATION POTENTIAL	EST	710
C	R = NUMBER OF TABULAR POINTS/DECADE OF EPRIME		
C	S = NO. OF TABULAR PTS/DECADE OF TAU	EST	720
C	T = NO. OF TABULAR PTS/DECADE OF E	EST	730
C	DN = NO. OF DECADES OF TAU	EST	740
C	DM = NO OF DECADES OF E	EST	750
C	DL = NUMBER OF DECADES OF EPRIME		
C	TAUZ = MIN VALUE OF TAU IN TABLE	EST	760
C	EZ = MIN VALUE OF E IN TABLE	EST	770
C	EPRZ = MINIMUM VALUE OF EPRIME IN TABLE		
C	EN = ESTIMATE OF MAX NBAR		
C	EB = MIN ZBAR		
C	E14 = 1. - SETS EION(1J) BEFORE CALL TO EIONX		
C	TO CALL MOLECULAT EQUATION OF STATE		
C	WT1 = PERCENT OF FIRST ELEMENT IN A COMPOUND		
C	WT2 = PERCENT OF SECOND ELEMENT IN A COMPOUND		
C	PAN1 = ATOMIC NUMBER OF FIRST ELEMENT IN A COMPOUND		
C	PAN2 = ATOMIC NUMBER OF SECOND ELEMENT IN A COMPOUND		
C	IS = SECTION USED TO GENERATE TABLE		
C	= 1 - FOR NON-MOLECULAR EQUATIONS OF STATE		
C	= 2 - FOR MOLECULAR EQUATIONS OF STATE		
C	I1 THRU I8 FLAGS INDICATING TREATMENT AT BOUNDARIES OF TABLE	EST	800
C	IN = 1 STOP IF REGION IS ENTERED	EST	810
C	= 0 CALCULATE WITH AVAILABLE ANALYTIC EQS	EST	820
C	3 * 4 * 5	EST	830
C	*****	EST	840
C	* * *	EST	850
C	E 2 * * 6	EST	860

C			EST 870
C			EST 880
C			EST 890
C			EST 900
	50	J=Z	EST 910
		PHI=9.648679E11/A	EST 920
		AM=T*DM+1.0	EST 930
		AN=S*DN+1.0	EST 940
		AL=R*DL+1.0	LST 950
		NN=AN	EST 960
		MM=AM	EST 970
		LL=AL	EST 980
		TAUM=TAUZ*10.0**DN	EST 990
		TAUL(1)=ALOG10(TAUZ)	EST 1000
		DTAUL=1./S	EST 1010
		TAU(1)=TAUZ	EST 1020
		IF (EZ.NE.0.) GO TO 90	EST 1030
		THA=1.1	EST 1040
		DO 60 I=1,10	EST 1050
		THA=THA-.1	EST 1060
		EION(14)=E14	EST 1070
		CALL EIONX (THA,TAUM,J,0.)	EST 1080
		S1=EION(14)	EST 1090
		IF (S1.NE.0.) CALL ERR (S1)	EST 1100
		IF ((EION(17).LT.EN).OR.(EION(3).GT.EB)) GO TO 60	EST 1110
		EZ=EION(8)	EST 1120
		GO TO 70	EST 1130
	60	CONTINUE	EST 1140
		S1=10.20	EST 1150
		CALL ERR (S1)	EST 1160
	70	IF (EPRZ.NE.0.0.OR.IS.NE.2) GO TO 90	EST 1170
		THA=1.1	EST 1180
		DO 80 I=1,10	EST 1190
		THA=THA-.1	EST 1200
		EION(14)=E14	EST 1210
		CALL EIONX (THA,TAUM,J,0.)	EST 1220
		S1=EION(14)	EST 1230
		IF (S1.NE.0.) CALL ERR (S1)	EST 1240
		IF ((EION(17).LT.EN).OR.(EION(3).GT.EB)) GO TO 80	EST 1250
		EPRZ=EPRIME	EST 1260
		GO TO 90	EST 1270
	80	CONTINUE	EST 1280
		S1=10.46	EST 1290
		CALL ERR (S1)	EST 1300
	90	CONTINUE	EST 1310
C		PREPARE TABLES OF SPECIFIC VOLUME AND ENERGY	EST 1330
C		IN REAL SPACE AND IN LOG BASE 10.	EST 1340
		DO 100 I=2,NN	EST 1350
		TAUL(I)=TAUL(I-1)+DTAUL	EST 1360
		TAU(I)=EXPT(TAUL(I))	EST 1370
	100	CONTINUE	EST 1380
		EM=EZ*10.0**DM	EST 1390
		EL(1)=ALOG10(EZ)	EST 1400
		DEL=1./T	EST 1410
		E(1)=EZ	EST 1420
		DO 110 I=2,MM	EST 1430
		EL(I)=EL(I-1)+DEL	

E(I)=EXPT(EL(I))	EST 1440
110 CONTINUE	EST 1450
IF (IS.EQ.2) GO TO 120	EST 1460
EPRM=0.0	EST 1470
EPRL(1)=0.0	EST 1480
GO TO 140	EST 1490
120 EPRM=EPRZ*10.0**DL	EST 1500
EPRL(1)=ALOG10(EPRZ)	EST 1510
EPR(1)=EPRZ	EST 1520
DO 130 I=2,LL	EST 1530
EPRL(I)=EPRL(I-1)+DEL	EST 1540
EPR(I)=EXPT(EPRL(I))	EST 1550
130 CONTINUE	EST 1560
WRITE (6,2340)	EST 1570
WRITE (6,2380) (EPRL(M),M=1,MM)	EST 1580
140 WRITE (6,2350)	EST 1590
WRITE (6,2380) (TAUL(N),N=1,NN)	EST 1600
WRITE (6,2330)	EST 1610
WRITE (6,2380) (EL(M1),M1=1,MM)	EST 1620
IF (NDUMP.EQ.-1.AND.MS.NE.0) GO TO 160	EST 1630
IF (NDUMP) 150,160,160	EST 1640
150 WRITE (10) TAUM,EM,EPRM,TAUZ,EZ,EPRZ,TAUL(1),EL(1),EPRL(1),PHI,NN,	EST 1650
1MM,LL	EST 1660
WRITE (10) (TAU(N),N=1,NN)	EST 1670
WRITE (10) (E(M),M=1,MM)	EST 1680
IF (IS.EQ.2) WRITE (10) (EPR(L),L=1,LL)	EST 1690
C DETERMINE SECTION USED TO CALCULATE DATA TABLES	EST 1700
160 GO TO (170,390,800,810), IS	EST 1710
170 CONTINUE	EST 1720
C	
C SINGLE ENERGY SCALE SECTION	
C (NO E-PRIME)	
C	
IF (MS.EQ.MM) GO TO 820	EST 1730
MS2=MS+1	EST 1740
DO 380 M=MS2,MM	EST 1750
DO 300 N=1,NN	EST 1760
STORTM=1.0E-10	EST 1770
STORTX=1.0E+10	EST 1780
AX=0.	EST 1790
AM=0.	EST 1800
K=(M-1)*NN+N	EST 1810
C INITIAL GUESS AT THE TEMPERATURE	EST 1820
THMIN=THETA(N,M-1)	EST 1830
THMAX=THETA(N-1,M)	EST 1840
IF (N.EQ.1) THMAX=E(M)/PHI	EST 1850
IF ((N.EQ.1).AND.(M.GT.1)) THMAX=3.*THETA(N,M-1)	EST 1860
IF (M.EQ.1) THMIN=.2	EST 1870
THETA(N,M)=THMIN	EST 1880
DO 230 I=1,20	EST 1890
EION(14)=E14	EST 1900
CALL EIONX (THMIN,TAU(N),J,0.)	EST 1910
S1=EION(14)	EST 1920
IF (S1.NE.0.) CALL ERR (S1)	EST 1930
EMIN=EION(8)	EST 1940
EION(14)=E14	EST 1950
180 CALL EIONX (THMAX,TAU(N),J,0.)	EST 1960

S1=EION(14)	EST 1970
IF (S1.NE.0.) CALL ERR (S1)	EST 1980
EMAX=EION(8)	EST 1990
GAMMA=3.*E(M)	EST 2000
IF (EMAX.LT.GAMMA) GO TO 190	EST 2010
THMAX=THMAX*.9	EST 2020
GO TO 180	EST 2030
190 EION(14)=E14	EST 2040
CALL EIONX (THETA(N,M),TAU(N),J,0.)	EST 2050
WS=THETA(N,M)	EST 2060
C NEWTON'S INTERPOLATION	EST 2070
THETA(N,M)=THETA(N,M)+(THMAX-THMIN)*(E(M)-EION(8))/(EMAX-E14)	EST 2080
ZETA=ABS(EION(8)-E(M))/(E(M))	EST 2090
IF (ZETA.LE..005) GO TO 290	EST 2100
IF (ZETA.GT..15) GO TO 210	EST 2110
IF (EION(8).GT.E(M)) GO TO 200	EST 2120
STORTM=AMAX1(WS,STORTM)	EST 2130
AM=1.	EST 2140
GO TO 210	EST 2150
200 STORTX=AMIN1(WS,STORTX)	EST 2160
AX=1.	EST 2170
210 IF (EION(8).LT.E(M)) THMIN=THETA(N,M)	EST 2180
IF (EION(8).GT.E(M)) GO TO 220	EST 2190
THMIN=THETA(N,M)	EST 2200
GO TO 230	EST 2210
220 THMAX=THETA(N,M)	EST 2220
230 CONTINUE	EST 2230
IF ((AX.EQ.1.).AND.(AM.EQ.1.)) GO TO 240	EST 2240
IF ((AX.EQ.1.).AND.(AM.EQ.0.)) GO TO 250	EST 2250
IF ((AX.EQ.0.).AND.(AM.EQ.1.)) GO TO 260	EST 2260
IF ((AX.EQ.0.).AND.(AM.EQ.0.)) GO TO 280	EST 2270
240 AVR=ABS((STORTX-STORTM)/2.)	EST 2280
THETA(N,M)=STORTM+AVR	EST 2290
GO TO 270	EST 2300
250 THETA(N,M)=STORTX	EST 2310
GO TO 270	EST 2320
260 THETA(N,M)=STORTM	EST 2330
270 EION(14)=E14	EST 2340
CALL EIONX (THETA(N,M),TAU(N),J,0.)	EST 2350
S1=EION(14)	EST 2360
IF (S1.NE.0.) CALL ERR (S1)	EST 2370
GO TO 290	EST 2380
280 S1=10.120	EST 2390
CALL ERR (S1)	EST 2400
290 CONTINUE	EST 2410
C ALL VARIABLES DETERMINED FROM EIONX USING E	EST 2420
ZB1D(K)=EION(3)	EST 2430
NB1D(K)=EION(17)	EST 2440
NBMAX=NB1D(1)	EST 2450
ZB11D(K)=M1(5)	EST 2460
ZB21D(K)=M1(15)	EST 2470
AEI=(EION(8)-1.5*EION(1)*PHI*(1./NBAR+ZBAR))/PHI	EST 2480
IF (AEI.LE.1.E-10) AEI=1.E-10	EST 2490
EILN1D(K)=ALOG(AEI)	EST 2500
DP=CARBENZ(1)+DIS	EST 2510
IF (DP.LE.1.E-10) DP=1.E-10	EST 2520
EDLN1D(K)=ALOG(DP)	EST 2530

C	END OF SPECIFIC VOLUME LOOP	
300	CONTINUE	EST 2540
C	MAKE DUMP TAPE	
	IF (NDUMP) 310,380,310	EST 2550
310	MS=M	EST 2560
	WRITE (10) (THETA(N,MS),N=1,NN)	EST 2570
	WRITE (6,2360)	EST 2580
	WRITE (6,2380) (THETA(N,MS),N=1,NN)	EST 2590
	KMN=(MS-1)*NN+1	EST 2600
	KMX=KMN+NN-1	EST 2610
	IF (NED.EQ.0) GO TO 320	EST 2620
	WRITE (10) (EDLN1D(K),K=KMN,KMX)	EST 2630
	WRITE (6,2270)	EST 2640
	WRITE (6,2380) (EDLN1D(K),K=KMN,KMX)	EST 2650
320	IF (NEI.EQ.0) GO TO 330	EST 2660
	WRITE (10) (EILN1D(K),K=KMN,KMX)	EST 2670
	WRITE (6,2280)	EST 2680
	WRITE (6,2380) (EILN1D(K),K=KMN,KMX)	EST 2690
330	IF (NNB.EQ.0) GO TO 340	EST 2700
	WRITE (10) (NB1D(K),K=KMN,KMX)	EST 2710
	WRITE (6,2290)	EST 2720
	WRITE (6,2380) (NB1D(K),K=KMN,KMX)	EST 2730
340	IF (NZB.EQ.0) GO TO 350	EST 2740
	WRITE (10) (ZB1D(K),K=KMN,KMX)	EST 2750
	WRITE (6,2300)	EST 2760
	WRITE (6,2380) (ZB1D(K),K=KMN,KMX)	EST 2770
350	IF (NZB1.EQ.0) GO TO 360	EST 2780
	WRITE (10) (ZB11D(K),K=KMN,KMX)	EST 2790
	WRITE (6,2310)	EST 2800
	WRITE (6,2380) (ZB11D(K),K=KMN,KMX)	EST 2810
360	IF (NZB2.EQ.0) GO TO 370	EST 2820
	WRITE (10) (ZB11D(K),K=KMN,KMX)	EST 2830
	WRITE (6,2320)	EST 2840
	WRITE (6,2380) (ZB21D(K),K=KMN,KMX)	EST 2850
370	WRITE (6,2390) MS	EST 2860
C	END OF ENERGY LOOP	
380	CONTINUE	EST 2870
	GO TO 820	EST 2880
390	CONTINUE	EST 2890
C		
C	THIS SECTION FOR MOLECULAR MATERIALS WHOSE DISSOCIATION ENERGY	
C	IS CALCULATED.	
C	TWO ENERGY SCALES ARE USED	
C		
	IF (MS.EQ.MM) GO TO 590	EST 2900
	MS2=MS+1	EST 2910
	DO 580 M=MS2,MM	EST 2920
	DO 540 N=1,NN	EST 2930
	STORTM=1.0E-10	EST 2940
	STORTX=1.0E+10	EST 2950
	AX=0.	EST 2960
	AM=0.	EST 2970
	K=(M-1)*NN+N	EST 2980
C	INITIAL GUESS AT THE TEMPERATURE	EST 2990
	THMIN=THETA(N,M-1)	EST 3000
	THMAX=THETA(N-1,M)	EST 3010
	IF (N.EQ.1) THMAX=EION(17)*E(M)*2.0/(3.0*EION(5))	EST 3020

IF ((N.EQ.1).AND.(M.GT.1)) THMAX=2.*THETA(N,M-1)	EST 3030
IF (M.EQ.1) THMIN=3.0E-2	EST 3040
THETA(N,M)=THMIN	EST 3050
DO 470 I=1,20	EST 3060
IF (I.EQ.1) THMIN1=THMIN	EST 3070
EION(14)=E14	EST 3080
CALL EIONX (THMIN,TAU(N),J,0.)	EST 3090
S1=EION(14)	EST 3100
IF (S1.NE.0.) CALL ERR (S1)	EST 3110
EMIN=GAND	EST 3120
IF (I.EQ.1) EMIN1=EMIN	EST 3130
400 EION(14)=E14	EST 3140
CALL EIONX (THMAX,TAU(N),J,0.)	EST 3150
S1=EION(14)	EST 3160
IF (S1.NE.0.) CALL ERR (S1)	EST 3170
EMAX=GAND	EST 3180
GAMMA=3.*E(M)	EST 3190
IF (EMAX.LT.GAMMA) GO TO 410	EST 3200
THMAX=THMAX*.9	EST 3210
GO TO 400	EST 3220
410 EION(14)=E14	EST 3230
CALL EIONX (THETA(N,M),TAU(N),J,0.)	EST 3240
WS=THETA(N,M)	EST 3250
C NEWTON'S INTERPOLATION	EST 3260
420 THETA(N,M)=WS+(THMAX-THMIN)*(E(M)-GAND)/(EMAX-EMIN)	EST 3270
IF (THETA(N,M).GT.0.0) GO TO 430	EST 3280
THMAX=WS	EST 3290
THMIN=THMIN1	EST 3300
EMAX=GAND	EST 3310
EMIN=EMIN1	EST 3320
GO TO 420	EST 3330
430 ZETA=ABS((GAND-E(M))/E(M))	EST 3340
IF (ZETA.LE..005) GO TO 530	EST 3350
IF (ZETA.GT..15) GO TO 450	EST 3360
IF (GAND.GT.E(M)) GO TO 440	EST 3370
STORTM=AMAX1(WS,STORTM)	EST 3380
AM=1.	EST 3390
GO TO 450	EST 3400
440 STORTX=AMIN1(WS,STORTX)	EST 3410
AX=1.	EST 3420
450 IF (GAND.GT.E(M)) GO TO 460	EST 3430
IF ((WS+.01).GT.THETA(N,M)) THETA(N,M)=WS+.01	EST 3440
THMIN=THETA(N,M)	EST 3450
GO TO 470	EST 3460
460 THMAX=THETA(N,M)	EST 3470
470 CONTINUE	EST 3480
IF ((AX.EQ.1.).AND.(AM.EQ.1.)) GO TO 480	EST 3490
IF ((AX.EQ.1.).AND.(AM.EQ.0.)) GO TO 490	EST 3500
IF ((AX.EQ.0.).AND.(AM.EQ.1.)) GO TO 500	EST 3510
IF ((AX.EQ.0.).AND.(AM.EQ.0.)) GO TO 520	EST 3520
480 AVR=ABS((STORTX-STORTM)/2.)	EST 3530
THETA(N,M)=STORTM+AVR	EST 3540
GO TO 510	EST 3550
490 THETA(N,M)=STORTX	EST 3560
GO TO 510	EST 3570
500 THETA(N,M)=STORTM	EST 3580
GO TO 510	EST 3590

510	EION(14)=E14	EST 3600
	CALL EIONX (THETA(N,M),TAU(N),J,0.)	EST 3610
	S1=EION(14)	EST 3620
	IF (S1.NE.0.) CALL ERR (S1)	EST 3630
	GO TO 530	EST 3640
520	S1=10.120	EST 3650
	CALL ERR (S1)	EST 3660
530	CONTINUE	EST 3670
C	NBAR AND EDIS OBTAINED FROM EIONX USING E	EST 3680
	NB1D(K)=EION(17)	EST 3690
	NBMAX=NB1D(1)	EST 3700
	DP=CARBENZ(1)+DIS	EST 3710
	IF (DP.LE.1.E-10) DP=1.E-10	EST 3720
	EDLN1D(K)=ALOG(DP)	EST 3730
C	END OF SPECIFIC VOLUME LOOP	
540	CONTINUE	EST 3740
C	MAKE DUMP TAPE	
	IF (NDUMP) 550,580,550	
550	MS=M	EST 3750
	WRITE (10) (THETA(N,MS),N=1,NN)	EST 3760
	WRITE (6,2360)	EST 3770
	WRITE (6,2380) (THETA(N,MS),N=1,NN)	EST 3780
	KMN=(MS-1)*NN+1	EST 3790
	KMX=KMN+NN-1	EST 3800
	IF (NED.EQ.0) GO TO 560	EST 3810
	WRITE (10) (EDLN1D(K),K=KMN,KMX)	EST 3820
	WRITE (6,2270)	EST 3830
	WRITE (6,2380) (EDLN1D(K),K=KMN,KMX)	EST 3840
560	IF (NNB.EQ.0) GO TO 570	EST 3850
	WRITE (10) (NB1D(K),K=KMN,KMX)	EST 3860
	WRITE (6,2290)	EST 3870
	WRITE (6,2380) (NB1D(K),K=KMN,KMX)	EST 3880
570	WRITE (6,2390) MS	EST 3890
C	END OF ENERGY LOOP	EST 3900
580	CONTINUE	
590	IF (LS.EQ.LL) GO TO 820	EST 3910
	LS2=LS+1	EST 3920
	DO 790 L=LS2,LL	EST 3930
	DO 730 N=1,NN	EST 3940
	STORM1=1.0E-10	EST 3950
	STORX1=1.0E+10	EST 3960
	AX1=0.	EST 3970
	AM1=0.	EST 3980
	K=(L-1)*NN+N	EST 3990
C	INITIAL GUESS AT THE TEMPERATURE	EST 4000
	TH1MIN=TH(N,L-1)	EST 4010
	TH1MAX=TH(N-1,L)	EST 4020
	IF (N.EQ.1) TH1MAX=EION(17)*EPR(L)*2.0/(3.0*EION(5))	EST 4030
	IF ((N.EQ.1).AND.(L.GT.1)) TH1MAX=3.*TH(N,L-1)	EST 4040
	IF (L.EQ.1) TH1MIN=3.0E-2	EST 4050
	TH(N,L)=TH1MIN	EST 4060
	DO 660 I=1,20	EST 4070
	IF (I.EQ.1) THMIN2=TH1MIN	EST 4080
	EION(14)=E14	EST 4090
	CALL EIONX (TH1MIN,TAU(N),J,0.)	EST 4100
	S1=EION(14)	EST 4110
	IF (S1.NE.0.) CALL ERR (S1)	EST 4120
		EST 4130

EMIN=EPRIME	EST 4140
IF (I.EQ.1) EMIN2=EMIN	EST 4150
600 EION(14)=E14	EST 4160
CALL EIONX (TH1MAX,TAU(N),J,0.)	EST 4170
S1=EION(14)	EST 4180
IF (S1.NE.0.) CALL ERR (S1)	EST 4190
EMAX=EPRIME	EST 4200
GAMMA=3.*EPR(M)	EST 4210
IF (EMAX.LT.GAMMA) GO TO 610	EST 4220
TH1MAX=TH1MAX*.9	EST 4230
GO TO 600	EST 4240
610 EION(14)=E14	EST 4250
CALL EIONX (TH(N,L),TAU(N),J,0.)	EST 4260
DP=CARBENZ(1)+DIS	EST 4270
WS1=TH(N,L)	EST 4280
C NEWTONS INTERPOLATION	EST 4290
620 TH(N,L)=WS1+(TH1MAX-TH1MIN)*(EPR(L)-EPRIME)/(EMAX-EMIN)	EST 4300
IF (TH(N,L).GT.0.0) GO TO 630	EST 4310
TH1MAX=WS1	EST 4320
TH1MIN=THMIN2	EST 4330
EMAX=EPRIME	EST 4340
EMIN=EMIN2	EST 4350
GO TO 620	EST 4360
630 ZETA1=ABS((EPRIME-EPR(L))/EPR(L))	EST 4370
IF (ZETA1.LE..005) GO TO 720	EST 4380
IF (ZETA1.GT..25) GO TO 650	EST 4390
IF (EPRIME.GT.EPR(L)) GO TO 640	EST 4400
STORM1=AMAX1(WS1,STORM1)	EST 4410
AM1=1.	EST 4420
GO TO 650	EST 4430
640 STORX1=AMIN1(WS1,STORX1)	EST 4440
AX1=1.	EST 4450
650 IF (EPRIME.LT.EPR(L)) TH1MIN=TH(N,L)	EST 4460
IF (EPRIME.GT.EPR(L)) TH1MAX=TH(N,L)	EST 4470
660 CONTINUE	EST 4480
IF ((AX1.EQ.1.).AND.(AM1.EQ.1.)) GO TO 670	EST 4490
IF ((AX1.EQ.1.).AND.(AM1.EQ.0.)) GO TO 680	EST 4500
IF ((AX1.EQ.0.).AND.(AM1.EQ.1.)) GO TO 690	EST 4510
IF ((AX1.EQ.0.).AND.(AM1.EQ.0.)) GO TO 710	EST 4520
670 AVR1=ABS((STORX1-STORM1)/2.)	EST 4530
TH(N,M)=STORM1+AVR1	EST 4540
GO TO 700	EST 4550
680 TH(N,M)=STORX1	EST 4560
GO TO 700	EST 4570
690 TH(N,M)=STORM1	EST 4580
GO TO 700	EST 4590
700 EION(14)=E14	EST 4600
CALL EIONX (TH(N,L),TAU(N),J,0.)	EST 4610
DP=CARBENZ(1)+DIS	EST 4620
S1=EION(14)	EST 4630
IF (S1.NE.0.) CALL ERR (S1)	EST 4640
GO TO 720	EST 4650
710 S1=10.50	EST 4660
CALL ERR (S1)	EST 4670
720 CONTINUE	EST 4680
C ZBAR AND EION OBTAINED FROM EIONX USING EPRIME	EST 4690
ZBID(K)=EION(3)	EST 4700

	ZB1D(K)=M1(5)	EST 4710
	ZB2D(K)=M1(15)	EST 4720
	AEI=(GAND-OP-1.5*EION(1)*TLMS(9))/EION(5)	EST 4730
	IF (AEI.LE.1.E-10) AEI=1.E-10	EST 4740
	EILN1D(K)=ALOG(AEI)	EST 4750
C	END OF SPECIFIC VOLUME LOOP	
730	CONTINUE	
C	MAKE DUMP TAPE	EST 4760
	IF (NDUMP) 740,790,740	
740	LS=L	EST 4770
	WRITE (10) (TH(N,LS),N=1,NN)	EST 4780
	WRITE (6,2360)	EST 4790
	WRITE (6,2380) (TH(N,LS),N=1,NN)	EST 4800
	KMN=(LS-1)*NN+1	EST 4810
	KMX=KMN+NN-1	EST 4820
	IF (NEI.EQ.0) GO TO 750	EST 4830
	WRITE (10) (EILN1D(K),K=KMN,KMX)	EST 4840
	WRITE (6,2280)	EST 4850
	WRITE (6,2380) (EILN1D(K),K=KMN,KMX)	EST 4860
750	IF (NZB.EQ.0) GO TO 760	EST 4870
	WRITE (10) (ZB1D(K),K=KMN,KMX)	EST 4880
	WRITE (6,2300)	EST 4890
	WRITE (6,2380) (ZB1D(K),K=KMN,KMX)	EST 4900
760	IF (NZB1.EQ.0) GO TO 770	EST 4910
	WRITE (10) (ZB1D(K),K=KMN,KMX)	EST 4920
	WRITE (6,2310)	EST 4930
	WRITE (6,2380) (ZB1D(K),K=KMN,KMX)	EST 4940
770	IF (NZB2.EQ.0) GO TO 780	EST 4950
	WRITE (10) (ZB2D(K),K=KMN,KMX)	EST 4960
	WRITE (6,2320)	EST 4970
	WRITE (6,2380) (ZB2D(K),K=KMN,KMX)	EST 4980
780	WRITE (6,2400) LS	EST 4990
C	END OF ENERGY LOOP	EST 5000
790	CONTINUE	
	GO TO 820	EST 5010
800	CONTINUE	EST 5020
810	CONTINUE	EST 5030
C		EST 5040
C	PUNCH DATA STATEMENTS FOR PROGRAM EST	EST 5050
820	CONTINUE	EST 5060
	KM=NN*MM	EST 5070
	IF (NOPNCH.EQ.0) GO TO 1610	EST 5080
	ID=1	EST 5090
	PUNCH 2200	EST 5100
	PUNCH 1950, ID,IS,NED,NEI,NNB,NZB,NZB1,NZB2	EST 5110
	PUNCH 2160	EST 5120
	PUNCH 1940, ID,TAUM,EM,EPRM,TAUZ,EZ,EPRZ	EST 5130
	PUNCH 2170	EST 5140
	PUNCH 1940, ID,TAUL(1),EL(1),EPRL(1),R,S,T	EST 5150
	PUNCH 2180	EST 5160
	PUNCH 1950, ID,V1,VZ,PHI,NBMAX	EST 5170
	PUNCH 2410	EST 5180
	PUNCH 1950, ID,WT1,WT2,PAN1,PAN2	
	PUNCH 2190	
	PUNCH 1970, ID,NN,MM,LL,I1,I2,I3,I4,I5,I6,I7,I8	EST 5190
	IF (NNB.EQ.0) GO TO 830	EST 5200
	PUNCH 2040, NN,MM	EST 5210
		EST 5220

PUNCH 2230	EST 5230
830 IF (NED.EQ.0) GO TO 840	EST 5240
PUNCH 1980, NN,MM	EST 5250
PUNCH 2210	EST 5260
840 IF (IS.EQ.2) MM=LL	EST 5270
IF (NZB.EQ.0) GO TO 850	EST 5280
PUNCH 2070, NN,MM	EST 5290
PUNCH 2240	EST 5300
850 IF (NZB1.EQ.0) GO TO 860	EST 5310
PUNCH 2100, NN,MM	EST 5320
PUNCH 2250	EST 5330
860 IF (NZB2.EQ.0) GO TO 870	EST 5340
PUNCH 2130, NN,MM	EST 5350
PUNCH 2260	EST 5360
870 IF (NEI.EQ.0) GO TO 880	EST 5370
PUNCH 2010, NN,MM	EST 5380
PUNCH 2220	EST 5390
880 IF (IS.EQ.2) KM=NN*LL	EST 5400
IF (NZB.EQ.0) GO TO 1000	EST 5410
NM=KM	EST 5420
IF (NN*MM.GT.54) NM=54	EST 5430
PUNCH 2080, ID,NM	EST 5440
PUNCH 2090, ID	EST 5450
ICNT=0	EST 5460
DO 990 I=1,KM,6	EST 5470
I6=I+5	EST 5480
ICNT=ICNT+1	EST 5490
IP=I	EST 5500
IF ((I6.LT.KM).OR.(ICNT.EQ.10)) GO TO 950	EST 5510
890 I6=KM	EST 5520
KI=KM-I+1	EST 5530
GO TO (900,910,920,930,940), KI	EST 5540
900 PUNCH 1880, ICNT,(ZB1D(K),K=IP,I6)	EST 5550
GO TO 980	EST 5560
910 PUNCH 1890, ICNT,(ZB1D(K),K=IP,I6)	EST 5570
GO TO 980	EST 5580
920 PUNCH 1900, ICNT,(ZB1D(K),K=IP,I6)	EST 5590
GO TO 980	EST 5600
930 PUNCH 1910, ICNT,(ZB1D(K),K=IP,I6)	EST 5610
GO TO 980	EST 5620
940 PUNCH 1920, ICNT,(ZB1D(K),K=IP,I6)	EST 5630
GO TO 980	EST 5640
950 IF (ICNT.LT.10) GO TO 960	EST 5650
ID=ID+1	EST 5660
NM=54	EST 5670
IF ((ID*54.GT.KM) NM=KM-(ID-1)*54	EST 5680
PUNCH 2080, ID,NM	EST 5690
PUNCH 2090, ID	EST 5700
ICNT=1	EST 5710
IF (I6.GT.KM) GO TO 890	EST 5720
GO TO 970	EST 5730
960 IF (ICNT.NE.9) GO TO 970	EST 5740
PUNCH 1930, ICNT,(ZB1D(K),K=I,I6)	EST 5750
GO TO 980	EST 5760
970 PUNCH 1870, ICNT,(ZB1D(K),K=I,I6)	EST 5770
980 CONTINUE	EST 5780
990 CONTINUE	EST 5790

1000 IF (NEI.EQ.0) GO TO 1120	EST 5800
NM=KM	EST 5810
IF (NN*MM.GT.54) NM=54	EST 5820
ID=1	EST 5830
PUNCH 2020, ID,NM	EST 5840
PUNCH 2030, ID	EST 5850
ICNT=0	EST 5860
DO 1110 I=1,KM,6	EST 5870
I6=I+5	EST 5880
ICNT=ICNT+1	EST 5890
IP=I	EST 5900
IF ((I6.LT.KM).OR.(ICNT.EQ.10)) GO TO 1070	EST 5910
1010 I6=KM	EST 5920
KI=KM-I+1	EST 5930
GO TO (1020,1030,1040,1050,1060), KI	EST 5940
1020 PUNCH 1880, ICNT,(EILN1D(K),K=IP,I6)	EST 5950
GO TO 1100	EST 5960
1030 PUNCH 1890, ICNT,(EILN1D(K),K=IP,I6)	EST 5970
GO TO 1100	EST 5980
1040 PUNCH 1900, ICNT,(EILN1D(K),K=IP,I6)	EST 5990
GO TO 1100	EST 6000
1050 PUNCH 1910, ICNT,(EILN1D(K),K=IP,I6)	EST 6010
GO TO 1100	EST 6020
1060 PUNCH 1920, ICNT,(EILN1D(K),K=IP,I6)	EST 6030
GO TO 1100	EST 6040
1070 IF (ICNT.LT.10) GO TO 1080	EST 6050
ID=ID+1	EST 6060
NM=54	EST 6070
IF ((ID)*54.GT.KM) NM=KM-(ID-1)*54	EST 6080
PUNCH 2020, ID,NM	EST 6090
PUNCH 2030, ID	EST 6100
ICNT=1	EST 6110
IF (I6.GT.KM) GO TO 1010	EST 6120
GO TO 1090	EST 6130
1080 IF (ICNT.NE.9) GO TO 1090	EST 6140
PUNCH 1930, ICNT,(EILN1D(K),K=I,I6)	EST 6150
GO TO 1100	EST 6160
1090 PUNCH 1870, ICNT,(EILN1D(K),K=I,I6)	EST 6170
1100 CONTINUE	EST 6180
1110 CONTINUE	EST 6190
KM=NN*MM	EST 6200
1120 IF (NNB.EQ.0) GO TO 1240	EST 6210
KM=NN*MM	EST 6220
NM=KM	EST 6230
IF (NN*MM.GT.54) NM=54	EST 6240
ID=1	EST 6250
PUNCH 2050, ID,NM	EST 6260
PUNCH 2060, ID	EST 6270
ICNT=0	EST 6280
DO 1230 I=1,KM,6	EST 6290
I6=I+5	EST 6300
ICNT=ICNT+1	EST 6310
IP=I	EST 6320
IF ((I6.LT.KM).OR.(ICNT.EQ.10)) GO TO 1190	EST 6330
1130 I6=KM	EST 6340
KI=KM-I+1	EST 6350
GO TO (1140,1150,1160,1170,1180), KI	EST 6360

1140 PUNCH 1880, ICNT, (NB1D(K), K=IP, I6)	EST 6370
GO TO 1220	EST 6380
1150 PUNCH 1890, ICNT, (NB1D(K), K=IP, I6)	EST 6390
GO TO 1220	EST 6400
1160 PUNCH 1900, ICNT, (NB1D(K), K=IP, I6)	EST 6410
GO TO 1220	EST 6420
1170 PUNCH 1910, ICNT, (NB1D(K), K=IP, I6)	EST 6430
GO TO 1220	EST 6440
1180 PUNCH 1920, ICNT, (NB1D(K), K=IP, I6)	EST 6450
GO TO 1220	EST 6460
1190 IF (ICNT.LT.10) GO TO 1200	EST 6470
ID=ID+1	EST 6480
NM=54	EST 6490
IF ((ID)*54.GT.KM) NM=KM-(ID-1)*54	EST 6500
PUNCH 2050, ID, NM	EST 6510
PUNCH 2060, ID	EST 6520
ICNT=1	EST 6530
IF (I6.GT.KM) GO TO 1130	EST 6540
GO TO 1210	EST 6550
1200 IF (ICNT.NE.9) GO TO 1210	EST 6560
PUNCH 1930, ICNT, (NB1D(K), K=I, I6)	EST 6570
GO TO 1220	EST 6580
1210 PUNCH 1870, ICNT, (NB1D(K), K=I, I6)	EST 6590
1220 CONTINUE	EST 6600
1230 CONTINUE	EST 6610
1240 IF (NED.EQ.0) GO TO 1360	EST 6620
NM=KM	EST 6630
IF (NM*MM.GT.54) NM=54	EST 6640
ID=1	EST 6650
PUNCH 1990, ID, NM	EST 6660
PUNCH 2000, ID	EST 6670
ICNT=0	EST 6680
DO 1350 I=1, KM, 6	EST 6690
I6=I+5	EST 6700
ICNT=ICNT+1	EST 6710
IP=I	EST 6720
IF ((I6.LT.KM).OR.(ICNT.EQ.10)) GO TO 1310	EST 6730
1250 I6=KM	EST 6740
KI=KM-I+1	EST 6750
GO TO (1260, 1270, 1280, 1290, 1300), KI	EST 6760
1260 PUNCH 1880, ICNT, (EDLN1D(K), K=IP, I6)	EST 6770
GO TO 1340	EST 6780
1270 PUNCH 1890, ICNT, (EDLN1D(K), K=IP, I6)	EST 6790
GO TO 1340	EST 6800
1280 PUNCH 1900, ICNT, (EDLN1D(K), K=IP, I6)	EST 6810
GO TO 1340	EST 6820
1290 PUNCH 1910, ICNT, (EDLN1D(K), K=IP, I6)	EST 6830
GO TO 1340	EST 6840
1300 PUNCH 1920, ICNT, (EDLN1D(K), K=IP, I6)	EST 6850
GO TO 1340	EST 6860
1310 IF (ICNT.LT.10) GO TO 1320	EST 6870
ID=ID+1	EST 6880
NM=54	EST 6890
IF ((ID)*54.GT.KM) NM=KM-(ID-1)*54	EST 6900
PUNCH 1990, ID, NM	EST 6910
PUNCH 2000, ID	EST 6920
ICNT=1	EST 6930

AFWL-TR-67-131, Vol IV

IF (I6.GT.KM) GO TO 1250	EST 6940
GO TO 1330	EST 6950
1320 IF (ICNT.NE.9) GO TO 1330	EST 6960
PUNCH 1930, ICNT, (EDLN1D(K), K=I, I6)	EST 6970
GO TO 1340	EST 6980
1330 PUNCH 1870, ICNT, (EDLN1D(K), K=I, I6)	
1340 CONTINUE	EST 7000
1350 CONTINUE	EST 7010
IF (IS.EQ.2) KM=NN*LL	EST 7020
1360 IF (NZB1.EQ.0) GO TO 1480	EST 7030
NM=KM	EST 7040
IF (NN*MM.GT.54) NM=54	EST 7050
ID=1	EST 7060
PUNCH 2110, ID, NM	EST 7070
PUNCH 2120, ID	EST 7080
ICNT=0	EST 7090
DO 1470 I=1, KM, 6	EST 7100
I6=I+5	EST 7110
ICNT=ICNT+1	EST 7120
IP=I	EST 7130
IF ((I6.LT.KM).OR.(ICNT.EQ.10)) GO TO 1430	EST 7140
1370 I6=KM	EST 7150
KI=KM-I+1	EST 7160
GO TO (1380, 1390, 1400, 1410, 1420), KI	EST 7170
1380 PUNCH 1880, ICNT, (ZB11D(K), K=IP, I6)	EST 7180
GO TO 1460	EST 7190
1390 PUNCH 1890, ICNT, (ZB11D(K), K=IP, I6)	EST 7200
GO TO 1460	EST 7210
1400 PUNCH 1900, ICNT, (ZB11D(K), K=IP, I6)	EST 7220
GO TO 1460	EST 7230
1410 PUNCH 1910, ICNT, (ZB11D(K), K=IP, I6)	EST 7240
GO TO 1460	EST 7250
1420 PUNCH 1920, ICNT, (ZB11D(K), K=IP, I6)	EST 7260
GO TO 1460	EST 7270
1430 IF (ICNT.LT.10) GO TO 1440	EST 7280
ID=ID+1	EST 7290
NM=54	EST 7300
IF ((ID)*54.GT.KM) NM=KM-(ID-1)*54	EST 7310
PUNCH 2110, ID, NM	EST 7320
PUNCH 2120, ID	EST 7330
ICNT=1	EST 7340
IF (I6.GT.KM) GO TO 1370	EST 7350
GO TO 1450	EST 7360
1440 IF (ICNT.NE.9) GO TO 1450	EST 7370
PUNCH 1930, ICNT, (ZB11D(K), K=I, I6)	EST 7380
GO TO 1460	EST 7390
1450 PUNCH 1870, ICNT, (ZB11D(K), K=I, I6)	EST 7400
1460 CONTINUE	EST 7410
1470 CONTINUE	EST 7420
1480 IF (NZB2.EQ.0) GO TO 1600	EST 7430
NM=KM	EST 7440
IF (NN*MM.GT.54) NM=54	EST 7450
ID=1	EST 7460
PUNCH 2140, ID, NM	EST 7470
PUNCH 2150, ID	EST 7480
DO 1590 I=1, KM, 6	EST 7490
I6=I+5	EST 7500

ICNT=ICNT+1	EST 7510
IP=I	EST 7520
IF ((I6.LT.KM).OR.(ICNT.EQ.10)) GO TO 1550	EST 7530
1490 I6=KM	EST 7540
KI=KM-I+1	EST 7550
GO TO (1500,1510,1520,1530,1540), KI	EST 7560
1500 PUNCH 1880, ICNT,(ZB21D(K),K=IP,I6)	EST 7570
GO TO 1580	EST 7580
1510 PUNCH 1890, ICNT,(ZB21D(K),K=IP,I6)	EST 7590
GO TO 1580	EST 7600
1520 PUNCH 1900, ICNT,(ZB21D(K),K=IP,I6)	EST 7610
GO TO 1580	EST 7620
1530 PUNCH 1910, ICNT,(ZB21D(K),K=IP,I6)	EST 7630
GO TO 1580	EST 7640
1540 PUNCH 1920, ICNT,(ZB21D(K),K=IP,I6)	EST 7650
GO TO 1580	EST 7660
1550 IF (ICNT.LT.10) GO TO 1560	EST 7670
ID=ID+1	EST 7680
NM=54	EST 7690
IF ((ID)*54.GT.KM) NM=KM-(ID-1)*54	EST 7700
PUNCH 2140, ID,NM	EST 7710
PUNCH 2150, ID	EST 7720
ICNT=1	EST 7730
IF (I6.GT.KM) GO TO 1490	EST 7740
GO TO 1570	EST 7750
1560 IF (ICNT.NE.9) GO TO 1570	EST 7760
PUNCH 1930, ICNT,(ZB21D(K),K=I,I6)	EST 7770
GO TO 1580	EST 7780
1570 PUNCH 1870, ICNT,(ZB21D(K),K=I,I6)	EST 7790
1580 CONTINUE	EST 7800
1590 CONTINUE	EST 7810
1600 CONTINUE	EST 7820
1610 CONTINUE	EST 7840
C MAKE NTRAN TAPE	
IF (NED.EQ.1) GO TO 1630	EST 7850
DO 1620 K=1,1594	EST 7860
1620 EDLN1D(K)=0.0	EST 7870
1630 IF (NEI.EQ.1) GO TO 1650	EST 7880
DO 1640 K=1,1595	EST 7890
1640 EILN1D(K)=0.0	EST 7900
1650 IF (NNB.EQ.1) GO TO 1670	EST 7910
DO 1660 K=1,1594	EST 7920
1660 NB1D(K)=0.0	EST 7930
1670 IF (NZB.EQ.1) GO TO 1690	EST 7940
DO 1680 K=1,1595	EST 7950
1680 ZB1D(K)=0.0	EST 7960
1690 IF (NZB1.EQ.1) GO TO 1710	EST 7970
DO 1700 K=1,1594	EST 7980
1700 ZB11D(K)=0.0	EST 7990
1710 IF (NZB2.EQ.1) GO TO 1730	EST 8000
DO 1720 K=1,1594	EST 8010
1720 ZB21D(K)=0.0	EST 8020
1730 CONTINUE	EST 8030
IF (ND11.EQ.0) GO TO 1760	EST 8040
LZ=LL	EST 8050
NX=NN	EST 8060
MX=MM	EST 8070

FHI=PHI	EST 8080
IT=IS	EST 8090
TAULZ=TAUL(1)	EST 8100
ELZ=EL(1)	EST 8110
EPRLZ=EPRL(1)	EST 8120
I61=I6	EST 8130
CALL NTRAN (11,1,9600,IT,LX)	EST 8140
1740 IF (LX.EQ.-1) GO TO 1740	EST 8150
IF (LX.LT.0) GO TO 1750	EST 8160
END FILE 11	EST 8170
REWIND 11	EST 8180
GO TO 1760	EST 8190
1750 S1=1.0655	EST 8200
CALL ERR (S1)	EST 8210
1760 CONTINUE	EST 8220
C EDIT PRINTS	
IF (NNB.EQ.0) GO TO 1770	EST 8230
WRITE (6,2290)	EST 8240
WRITE (6,2380) (NB1D(K),K=1,KM)	EST 8250
1770 IF (NED.EQ.0) GO TO 1780	EST 8260
WRITE (6,2270)	EST 8270
WRITE (6,2380) (EDLN1D(K),K=1,KM)	EST 8280
1780 IF (IS.EQ.2) KM=NN*LL	EST 8290
IF (NZB.EQ.0) GO TO 1790	EST 8300
WRITE (6,2300)	EST 8310
WRITE (6,2380) (ZB1D(K),K=1,KM)	EST 8320
1790 IF (NEI.EQ.0) GO TO 1800	EST 8330
WRITE (6,2280)	EST 8340
WRITE (6,2380) (E1LN1D(K),K=1,KM)	EST 8350
1800 IF (NZB1.EQ.0) GO TO 1810	EST 8360
WRITE (6,2310)	EST 8370
WRITE (6,2380) (ZB11D(K),K=1,KM)	EST 8380
1810 IF (NZB2.EQ.0) GO TO 1820	EST 8390
WRITE (6,2380) (ZB21D(K),K=1,KM)	EST 8400
WRITE (6,2320)	EST 8410
1820 WRITE (6,2360)	EST 8420
WRITE (6,2380) ((THETA(N,M),N=1,NN),M=1,MM)	EST 8430
IF (IS.NE.2) GO TO 1830	EST 8440
WRITE (6,2370)	EST 8450
WRITE (6,2380) ((TH(N,L),N=1,NN),L=1,LL)	EST 8460
1830 CONTINUE	EST 8470
CALL EXIT	EST 8480
C	EST 8490
1840 FORMAT (7E10.4)	EST 8500
1850 FORMAT (14I5)	EST 8510
1860 FORMAT (12A6)	EST 8520
1870 FORMAT (5X11,6(1F10.6,1H,))	EST 8530
1880 FORMAT (5X11,F10.6,1H/)	EST 8540
1890 FORMAT (5X11,F10.6,1H,F10.6,1H/)	EST 8550
1900 FORMAT (5X11,F10.6,2(1H,F10.6),1H/)	EST 8560
1910 FORMAT (5X11,F10.6,3(1H,F10.6),1H/)	EST 8570
1920 FORMAT (5X11,F10.6,4(1H,F10.6),1H/)	EST 8580
1930 FORMAT (5X11,F10.6,5(1H,F10.6),1H/)	EST 8590
1940 FORMAT (5X11,1PE10.4,5(1H,1PE10.4),1H/)	EST 8600
1950 FORMAT (5X11,1PE10.4,3(1H,1PE10.4),1H/)	EST 8610
1960 FORMAT (5X11,6(I3,1H,),I3,1H/)	EST 8620
1970 FORMAT (5X11,10(I3,1H,),I3,1H/)	EST 8630

AFWL-TR-67-131, Vol IV

1980 FORMAT (6X,14H DIMENSION ED(I2,1H,I2,1H))	EST 8640
1990 FORMAT (6X,14H COMMON/EST/EDI2,1H(I2,1H))	EST 8650
2000 FORMAT (6X,8H DATA EDI2,1H/)	EST 8660
2010 FORMAT (6X,14H DIMENSION EI(I2,1H,I2,1H))	EST 8670
2020 FORMAT (6X,14H COMMON/EST/EII2,1H(I2,1H))	EST 8680
2030 FORMAT (6X,8H DATA EII2,1H/)	EST 8690
2040 FORMAT (6X,14H DIMENSION NB(I2,1H,I2,1H))	EST 8700
2050 FORMAT (6X,14H COMMON/EST/NBI2,1H(I2,1H))	EST 8710
2060 FORMAT (6X,8H DATA NBI2,1H/)	EST 8720
2070 FORMAT (6X,14H DIMENSION ZB(I2,1H,I2,1H))	EST 8730
2080 FORMAT (6X,14H COMMON/EST/ZBI2,1H(I2,1H))	EST 8740
2090 FORMAT (6X,8H DATA ZBI2,1H/)	EST 8750
2100 FORMAT (6X,15H DIMENSION ZB1(I2,1H,I2,1H))	EST 8760
2110 FORMAT (6X,15H COMMON/EST/ZB1I2,1H(I2,1H))	EST 8770
2120 FORMAT (6X,9H DATA ZB1I2,1H/)	EST 8780
2130 FORMAT (6X,15H DIMENSION ZB2(I2,1H,I2,1H))	EST 8790
2140 FORMAT (6X,15H COMMON/EST/ZB2I2,1H(I2,1H))	EST 8800
2150 FORMAT (6X,9H DATA ZB2I2,1H/)	EST 8810
2160 FORMAT (6X,32H DATA TAUM,EM,EPRM,TAUZ,EZ,EPRZ/)	EST 8820
2170 FORMAT (6X,28H DATA TAULZ,ELZ,EPRLZ,R,S,T/)	EST 8830
2180 FORMAT (6X,22H DATA V1,VZ,PHI,NBMAX/)	EST 8840
2190 FORMAT (6X,39H DATA NN,MM,LL,I1,I2,I3,I4,I5,I6,I7,I8/)	EST 8850
2200 FORMAT (6X,35H DATA IS,NED,NEI,NNB,NZB,NZB1,NZB2/)	EST 8860
2210 FORMAT (6X,21H EQUIVALENCE (ED,ED1))	EST 8870
2220 FORMAT (6X,21H EQUIVALENCE (EI,EI1))	EST 8880
2230 FORMAT (6X,21H EQUIVALENCE (NB,NB1))	EST 8890
2240 FORMAT (6X,21H EQUIVALENCE (ZB,ZB1))	EST 8900
2250 FORMAT (6X,23H EQUIVALENCE (ZB1,ZB11))	EST 8910
2260 FORMAT (6X,23H EQUIVALENCE (ZB2,ZB12))	EST 8920
2270 FORMAT (6H EDLN)	EST 8930
2280 FORMAT (6H EILN)	EST 8940
2290 FORMAT (6H NBAR)	EST 8950
2300 FORMAT (6H ZBAR)	EST 8960
2310 FORMAT (7H ZBAR1)	EST 8970
2320 FORMAT (7H ZBAR2)	EST 8980
2330 FORMAT (4H EL)	EST 8990
2340 FORMAT (6H EPRL)	EST 9000
2350 FORMAT (6H TAUL)	EST 9010
2360 FORMAT (9H E THETA)	EST 9020
2370 FORMAT (14H EPRIME THETA)	EST 9030
2380 FORMAT (1X,1P6E12,5)	EST 9040
2390 FORMAT (1H0,27H TAPE 10 DUMP VALUE OF MS=I4)	EST 9050
2400 FORMAT (1H0,27H TAPE 10 DUMP VALUE OF LS=I4)	EST 9060
2410 FORMAT (6X,24H DATA WT1,WT2,PAN1,PAN2/)	
END	EST 9070

```

C   THIS VERSION OF LIBEX FOR USE WITH DATA CARDS
C   DATA IS FOR CH2
SUBROUTINE LIBEX(TAU, E, THA, P, ZBAR, GG, NBAR, SEDEI,
EQUIVALENCE (Z(131),S1)
REAL NB
REAL NBMAX
REAL NBAR
COMMON Z(10000)
COMMON/BOB/ZPART(1200,3)
DATA IS,NEO,NEI,NNB,NZB,NZB1,NZB2/
1 2, 1, 1, 1, 1, 0, 0/
DATA TAUM,EH,EPRM,TAUZ,EZ,EPRZ/
1 1.0000+09, 5.1587+12, 5.1587+12, 1.0000+00, 5.1587+09, 5.1587+09/
DATA TAUZ,ELZ,EPRLZ,R,S,T/
1 0.0000, 9.7125+00, 9.7125+00, 6.0000+00, 3.0000+00, 6.0000+00/
DATA V1,VZ,PHI,NBMAX/
1 1.1256+01, 4.8984+02, 2.0675+11, 6.0000+00/
DATA NN,MM,LL,I1,I2,I3,I4,I5,I6,I7,I8/
1 28, 19, 19, 0, 1, 1, 1, 1, 1, 0, 0/
DIMENSION NB(28,19)
EQUIVALENCE (NB,NB1)
DIMENSION EO(28,19)
EQUIVALENCE (EO,EO1)
DIMENSION ZB(28,19)
EQUIVALENCE (ZB,ZB1)
DIMENSION EI(28,19)
EQUIVALENCE (EI,EI1)
COMMON/EST/ZB 1(54)
DATA ZB 1/
1 .000000, .000000, .000000, .000000, .000000, .000000,
2 .000000, .000000, .000000, .000000, .000000, .000000,
3 .000000, .000000, .000000, .000000, .000000, .000000,
4 .000000, .000000, .000000, .000000, .000000, .000000,
5 .000000, .000000, .000000, .000000, .000000, .000000,
6 .000000, .000000, .000000, .000000, .000000, .000000,
7 .000000, .000000, .000000, .000000, .000000, .000000,
8 .000000, .000000, .000000, .000000, .000000, .000000,
9 .000000, .000000, .000000, .000000, .000000, .000000/
COMMON/EST/ZB 2(54)
DATA ZB 2/
1 .000000, .000000, .000000, .000000, .000000, .000000,
2 .000000, .000000, .000000, .000000, .000000, .000000,
3 .000000, .000000, .000000, .000000, .000000, .000000,
4 .000000, .000000, .000000, .000000, .000000, .000000,
5 .000000, .000000, .000000, .000000, .000000, .000000,
6 .000000, .000000, .000000, .000000, .000000, .000000,
7 .000000, .000000, .000000, .000000, .000000, .000000,
8 .000000, .000000, .000000, .000000, .000000, .000000,
9 .000000, .000000, .000000, .000000, .000000, .000000/
COMMON/EST/ZB 3(54)
DATA ZB 3/
1 .000000, .000000, .000000, .000000, .000000, .000000,
2 .000000, .000000, .000000, .000000, .000000, .000000,
3 .000000, .000000, .000000, .000000, .000000, .000000,
4 .000000, .000000, .000000, .000000, .000000, .000000,
5 .000000, .000000, .000000, .000000, .000000, .000000,
6 .000000, .000000, .000000, .000000, .000000, .000000,
7 .000000, .000000, .000000, .000000, .000000, .000000,

```

```

LIBE 10
LBX 20
LBX 130
LBX 140
LBX 150
LBX 160
LBX 170

```


8	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
9	.000000,	.000000,	.000000,	.000000,	.000000,	.000000/
COMMON/EST/ZB 4(54)						
DATA ZB 4/						
1	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
2	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
3	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
4	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
5	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
6	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
7	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
8	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
9	.000000,	.000000,	.000000,	.000000,	.000000,	.000000/
COMMON/EST/ZB 5(54)						
DATA ZB 5/						
1	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
2	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
3	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
4	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
5	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
6	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
7	.001375,	.000000,	.000000,	.000000,	.000000,	.000000,
8	.000000,	.000000,	.000000,	.000000,	.000000,	.000000,
9	.000000,	.000000,	.000000,	.000000,	.000000,	.001025/
COMMON/EST/ZB 6(54)						
DATA ZB 6/						
1	.001386,	.001845,	.002392,	.003171,	.003972,	.004863,
2	.005825,	.006842,	.007898,	.008980,	.002165,	.001453,
3	.001018,	.000000,	.000000,	.000000,	.000000,	.001017,
4	.001416,	.001966,	.002683,	.003581,	.004660,	.006132,
5	.007678,	.009392,	.011240,	.013183,	.015182,	.017221,
6	.019279,	.021328,	.023356,	.025352,	.027308,	.029587,
7	.031466,	.033289,	.033305,	.002510,	.002125,	.003008,
8	.004120,	.005563,	.007379,	.009542,	.012376,	.015347,
9	.018590,	.022033,	.025610,	.029260,	.032925,	.036567/
COMMON/EST/ZB 7(54)						
DATA ZB 7/						
1	.040154,	.043662,	.047073,	.050376,	.053563,	.056637,
2	.059574,	.062393,	.065092,	.067673,	.070141,	.072497,
3	.006451,	.008939,	.011798,	.015438,	.020100,	.025151,
4	.030705,	.036627,	.042780,	.049041,	.055305,	.061488,
5	.067552,	.073404,	.079059,	.084488,	.089684,	.094644,
6	.099369,	.103865,	.108140,	.112192,	.116055,	.119713,
7	.123183,	.126476,	.129601,	.132567,	.022550,	.029372,
8	.037760,	.046765,	.056490,	.066674,	.077067,	.087457,
9	.097672,	.107592,	.117154,	.126278,	.134955,	.143179/
COMMON/EST/ZB 8(54)						
DATA ZB 8/						
1	.150955,	.158299,	.165227,	.171791,	.178403,	.184369,
2	.190535,	.194808,	.199512,	.203055,	.206890,	.208952,
3	.212317,	.214984,	.055995,	.070481,	.086022,	.102427,
4	.119235,	.136026,	.152489,	.168387,	.183538,	.197870,
5	.211345,	.223981,	.236104,	.247291,	.256832,	.265029,
6	.272522,	.279397,	.285713,	.291530,	.296898,	.301848,
7	.306537,	.310995,	.315162,	.319057,	.322715,	.326150,
8	.111426,	.136153,	.162043,	.188504,	.214795,	.240392,
9	.264893,	.288068,	.309845,	.329440,	.346662,	.362322/

COMMON/EST/ZB 9(54)

DATA ZB 9/

1	.376563,	.389536,	.401388,	.412261,	.422231,	.431389,
2	.439821,	.447598,	.454789,	.461449,	.467631,	.473380,
3	.478736,	.483736,	.488411,	.492790,	.491916,	.230571,
4	.270380,	.310347,	.349491,	.387092,	.421993,	.451410,
5	.480242,	.506713,	.531402,	.553976,	.574697,	.593697,
6	.607744,	.622505,	.635983,	.648317,	.659616,	.669992,
7	.679541,	.688345,	.696480,	.704010,	.710996,	.717488,
8	.723533,	.729172,	.297996,	.353707,	.411865,	.471231,
9	.527633,	.577922,	.626699,	.671599,	.709234,	.744693/

COMMON/EST/ZB10(46)

DATA ZB10/

1	.776754,	.805720,	.831883,	.855520,	.876885,	.896205,
2	.913679,	.929478,	.943750,	.956630,	.968233,	.978674,
3	.988055,	.996493,	1.004091,	1.010952,	1.017173,	1.022840,
4	.425780,	.510008,	.594169,	.672576,	.744677,	.808484,
5	.868860,	.922703,	.970060,	1.011201,	1.046563,	1.076752,
6	1.103657,	1.123317,	1.141089,	1.160070,	1.173028,	1.184398,
7	1.194515,	1.205969,	1.213874,	1.221149,	1.227891,	1.234171,
8	1.240043,	1.245551,	1.250730,	1.255609/		

COMMON/EST/EI 1(54)

DATA EI 1/

1-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 2-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 3-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 4-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 5-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 6-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 7-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 8-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 9-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850/

COMMON/EST/EI 2(54)

DATA EI 2/

1-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 2-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 3-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 4-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 5-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 6-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 7-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 8-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 9-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850/

COMMON/EST/EI 3(54)

DATA EI 3/

1-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 2-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 3-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 4-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 5-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 6-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 7-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 8-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 9-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850/

COMMON/EST/EI 4(54)

DATA EI 4/

1-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,

2-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 3-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 4-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 5-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 6-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 7-23.025850,-23.025850,-23.025850,-23.025850,-19.121368,-23.025850,
 8-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 9-23.025850,-23.025850,-19.121368,-23.025850,-23.025850,-23.025850/

COMMON/EST/EI 5(54)

DATA EI 5/

1-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 2-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 3-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 4-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 5-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 6-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 7 -4.123382,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 8-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
 9-23.025850,-23.025850,-23.025850,-23.025850,-23.025850, -4.457728/

COMMON/EST/EI 6(54)

DATA EI 6/

1 -4.156404, -3.870282, -3.610777, -3.328852, -3.103802, -2.901839,
 2 -2.721497, -2.560797, -2.417514, -2.289392, -3.664721, -4.072567,
 3 -4.435791,-23.025850,-23.025850,-18.428221,-23.025850, -.912638,
 4 -2.639282, -3.793462, -3.483021, -3.194972, -2.932156, -2.658109,
 5 -2.433998, -2.233350, -2.054593, -1.896018, -1.755708, -1.630594,
 6 -1.518587, -1.418454, -1.328422, -1.247146, -1.173510, -1.093992,
 7 -1.033019, -.977226, -3.236126, -3.519532, .104213, -.430702,
 8 -1.580806, -2.732056, -2.450434, -2.194612, -1.935585, -1.721872,
 9 -1.531787, -1.363589, -1.214971, -1.083603, -.967472, -.864430/

COMMON/EST/EI 7(54)

DATA EI 7/

1 -.772686, -.690705, -.617174, -.550978, -.491172, -.436792,
 2 -.387577, -.342571, -.301360, -.263504, -.228641, -.196460,
 3 .066419, -.579267, -.520131, -.449692, -.366256, -.283425,
 4 -.199950, -.118360, -.040473, .032605, .100362, .162655,
 5 .219855, .271785, .319244, .362526, .402032, .438141,
 6 .471202, .501532, .529415, .555051, .578817, .600746,
 7 .621071, .639949, .657516, .673891, -.316351, -.208517,
 8 -.090299, .022297, .130730, .232470, .326132, .411246,
 9 .487915, .556665, .618289, .673331, .722609, .766817/

COMMON/EST/EI 8(54)

DATA EI 8/

1 .806570, .842415, .874831, .904381, .933264, .958328,
 2 .983668, 1.000055, 1.019479, 1.034641, 1.051086, 1.059490,
 3 1.073742, 1.084852, 1.137313, 1.281975, .416497, .540818,
 4 .653488, .754180, .843481, .922304, .991618, 1.052628,
 5 1.106402, 1.153981, 1.197353, 1.235449, 1.267268, 1.295537,
 6 1.320937, 1.343880, 1.364646, 1.383515, 1.400707, 1.416374,
 7 1.431059, 1.444880, 1.457669, 1.469512, 1.480535, 1.490800,
 8 .614286, .768409, .907450, 1.031708, 1.141222, 1.237120,
 9 1.320736, 1.393595, 1.457297, 1.511792, 1.558882, 1.600401/

COMMON/EST/EI 9(54)

DATA EI 9/

1 1.637092, 1.669648, 1.698678, 1.724723, 1.748120, 1.769211,
 2 1.788294, 1.805619, 1.821401, 1.835822, 1.849041, 1.861192,
 3 1.872392, 1.882742, 1.892329, 1.901232, 1.055842, 1.212095,

AFWL-TR-67-131, Vol IV

4	1.350815,	1.472947,	1.579541,	1.672155,	1.752300,	1.816542,
5	1.876708,	1.929510,	1.976725,	2.018240,	2.055015,	2.087660,
6	2.111153,	2.135276,	2.156811,	2.176118,	2.193482,	2.209162,
7	2.223371,	2.236290,	2.248074,	2.258856,	2.268749,	2.277853,
8	2.286251,	2.294019,	1.443107,	1.597401,	1.736608,	1.860831,
9	1.969935,	2.060713,	2.143033,	2.214076,	2.270280,	2.320675/

COMMON/EST/EI10(46)

DATA EI10/

1	2.364231,	2.402053,	2.435059,	2.464010,	2.489531,	2.512136,
2	2.532244,	2.550201,	2.566288,	2.580744,	2.593766,	2.605529,
3	2.616178,	2.625862,	2.634700,	2.642804,	2.650271,	2.657184,
4	1.771012,	1.937605,	2.089148,	2.219229,	2.329331,	2.419531,
5	2.499551,	2.567096,	2.624108,	2.672329,	2.713255,	2.748209,
6	2.779896,	2.803067,	2.824647,	2.848658,	2.865081,	2.880107,
7	2.893955,	2.910217,	2.921626,	2.932306,	2.942338,	2.951782,
8	2.960688,	2.969101,	2.977057,	2.984589/		

COMMON/EST/NB 1(54)

DATA NB 1/

1	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
2	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
3	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
4	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
5	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
6	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
7	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
8	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
9	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	5.991147/

COMMON/EST/NB 2(54)

DATA NB 2/

1	5.980486,	5.969981,	6.000000,	6.000000,	6.000000,	6.000000,
2	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
3	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
4	6.000000,	6.000000,	5.983711,	5.965959,	5.949257,	5.931445,
5	5.917412,	5.902410,	5.889917,	5.877577,	5.865907,	5.855065,
6	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
7	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,	6.000000,
8	5.977492,	5.948688,	5.918998,	5.891096,	5.865938,	5.843042,
9	5.820780,	5.801593,	5.784027,	5.767848,	5.752925,	5.739068/

COMMON/EST/NB 3(54)

DATA NB 3/

1	5.726187,	5.714162,	5.702917,	5.692377,	6.000000,	6.000000,
2	6.000000,	6.000000,	5.993184,	5.963240,	5.926456,	5.892512,
3	5.858166,	5.827527,	5.798051,	5.772375,	5.750608,	5.717156,
4	5.687274,	5.660236,	5.635739,	5.611224,	5.591197,	5.572837,
5	5.555954,	5.540375,	5.523215,	5.509963,	5.497633,	5.486130,
6	5.475372,	5.465287,	6.000000,	5.884723,	5.789128,	5.749161,
7	5.702450,	5.661340,	5.617487,	5.579817,	5.543010,	5.511750,
8	5.483185,	5.455402,	5.429414,	5.403113,	5.374787,	5.349291,
9	5.321200,	5.300475,	5.281584,	5.264278,	5.248366,	5.233685/

COMMON/EST/NB 4(54)

DATA NB 4/

1	5.220089,	5.207475,	5.195733,	5.184776,	5.174527,	5.164920,
2	5.774427,	5.509112,	5.400023,	5.350777,	5.300285,	5.252188,
3	5.206642,	5.170256,	5.135800,	5.102584,	5.071138,	5.048096,
4	5.023514,	5.001376,	4.968020,	4.944589,	4.923397,	4.904153,
5	4.886592,	4.870502,	4.855705,	4.842050,	4.829411,	4.817677,
6	4.806755,	4.796564,	4.787031,	4.778096,	5.266429,	5.013392,

7 4.909512, 4.847803, 4.794539, 4.745758, 4.701477, 4.659396,
 8 4.628836, 4.600563, 4.571672, 4.544541, 4.525727, 4.499321,
 9 4.475782, 4.454619, 4.429255, 4.412327, 4.396876, 4.382717/

COMMON/EST/NB 5(54)

DATA NB 5/

1 4.369641, 4.357666, 4.346532, 4.336190, 4.326560, 4.317570,
 2 4.309158, 4.301269, 4.297364, 4.292429, 4.286649, 4.281798,
 3 4.204197, 4.156621, 4.114410, 4.076765, 4.040914, 4.015163,
 4 3.993628, 3.969731, 3.947384, 3.924075, 3.903820, 3.885605,
 5 3.869124, 3.854156, 3.840493, 3.827971, 3.816452, 3.805820,
 6 3.795976, 3.786835, 3.778325, 3.770382, 3.762951, 3.755984,
 7 3.961872, 3.771100, 3.675624, 3.613715, 3.561891, 3.517090,
 8 3.478129, 3.443949, 3.413664, 3.385111, 3.366005, 3.347951,
 9 3.329016, 3.309615, 3.292403, 3.276922, 3.262923, 3.250202/

COMMON/EST/NB 6(54)

DATA NB 6/

1 3.238593, 3.227954, 3.218169, 3.209140, 3.200782, 3.193022,
 2 3.185799, 3.179059, 3.172754, 3.166845, 3.160791, 3.105434,
 3 3.018090, 2.954007, 2.912544, 2.871745, 2.836886, 2.806756,
 4 2.780412, 2.757115, 2.735633, 2.715104, 2.706939, 2.691247,
 5 2.677219, 2.664603, 2.653195, 2.635510, 2.626666, 2.618545,
 6 2.611059, 2.604136, 2.597715, 2.591743, 2.586174, 2.580969,
 7 2.576092, 2.571515, 2.610354, 2.473933, 2.398627, 2.342306,
 8 2.302062, 2.266039, 2.235741, 2.209899, 2.187573, 2.168051,
 9 2.150787, 2.135353, 2.120403, 2.108415, 2.097903, 2.088431/

COMMON/EST/NB 7(54)

DATA NB 7/

1 2.079850, 2.072038, 2.064898, 2.058346, 2.052312, 2.046737,
 2 2.041570, 2.036756, 2.032265, 2.028072, 2.024150, 2.020472,
 3 2.022045, 1.914107, 1.850945, 1.800267, 1.761534, 1.734504,
 4 1.708825, 1.687182, 1.668681, 1.652666, 1.638640, 1.626227,
 5 1.615130, 1.605965, 1.597774, 1.590413, 1.583759, 1.577716,
 6 1.572202, 1.567150, 1.562504, 1.558217, 1.554249, 1.550564,
 7 1.547134, 1.543933, 1.540938, 1.538111, 1.528232, 1.452819,
 8 1.396629, 1.353141, 1.320814, 1.293506, 1.276882, 1.255734,
 9 1.240891, 1.228287, 1.217525, 1.208336, 1.200551, 1.192621/

COMMON/EST/NB 8(54)

DATA NB 8/

1 1.188851, 1.182839, 1.176976, 1.171536, 1.166144, 1.162256,
 2 1.160911, 1.154866, 1.153557, 1.146557, 1.150168, 1.141086,
 3 1.143772, 1.142307, 1.133658, 1.078449, 1.035555, 1.000000,
 4 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 5 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 6 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 7 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 8 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 9 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000/

COMMON/EST/NB 9(54)

DATA NB 9/

1 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 2 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 3 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 4 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 5 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 6 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 7 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
 8 1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,


```

9  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000/
COMMON/EST/NB10(46)
DATA NB10/
1  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
2  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
3  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
4  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
5  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
6  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
7  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000,
8  1.000000, 1.000000, 1.000000, 1.000000, 1.000000, 1.000000/
COMMON/EST/ED 1(54)
DATA ED 1/
1-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
2-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
3-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
4-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
5-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
6-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
7-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
8-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
9-23.025850,-23.025850,-23.025850,-23.025850,-23.025850, 10.305801/
COMMON/EST/ED 2(54)
DATA ED 2/
1 20.097997, 20.530467,-23.025850,-23.025850,-23.025850,-23.025850,
2-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
3-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
4-23.025850,-23.025850, 19.916814, 20.656865, 21.058886, 21.362743,
5 21.551345, 21.720789, 21.843376, 21.951713, 22.044751, 22.124351,
6-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
7-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,-23.025850,
8 20.241250, 21.070132, 21.531683, 21.832401, 22.044519, 22.206105,
9 22.342554, 22.447567, 22.535428, 22.610470, 22.675360, 22.732338/
COMMON/EST/ED 3(54)
DATA ED 3/
1 22.782773, 22.827855, 22.868410, 22.905123,-23.025850,-23.025850,
2-23.025850,-23.025850, 19.044068, 20.734181, 21.433837, 21.819072,
3 22.102202, 22.303022, 22.465868, 22.589992, 22.685096, 22.816803,
4 22.922473, 23.010163, 23.084117, 23.153611, 23.207418, 23.254637,
5 23.296434, 23.333726, 23.373482, 23.403300, 23.430389, 23.455124,
6 23.477805, 23.498689,-23.025850, 21.890353, 22.510645, 22.691133,
7 22.870062, 23.006713, 23.136256, 23.236912, 23.327500, 23.399321,
8 23.461375, 23.518817, 23.570209, 23.620129, 23.671749, 23.716474,
9 23.764005, 23.797981, 23.828200, 23.855285, 23.879709, 23.901854/
COMMON/EST/ED 4(54)
DATA ED 4/
1 23.922042, 23.940506, 23.957470, 23.973113, 23.987585, 24.001014,
2 22.580582, 23.405189, 23.625866, 23.713911, 23.798289, 23.873883,
3 23.941716, 23.993572, 24.040944, 24.085149, 24.125771, 24.154830,
4 24.185207, 24.212041, 24.251589, 24.278768, 24.302944, 24.324577,
5 24.344062, 24.361708, 24.377766, 24.392445, 24.405915, 24.418321,
6 24.429785, 24.440413, 24.450292, 24.459500, 23.851949, 24.197536,
7 24.318583, 24.386276, 24.442516, 24.492412, 24.536482, 24.577367,
8 24.606486, 24.633023, 24.659757, 24.684526, 24.701519, 24.725123,
9 24.745932, 24.764461, 24.786451, 24.800999, 24.814191, 24.826211/
COMMON/EST/ED 5(54)
DATA ED 5/

```

AFWL-TR-67-131, Vol IV

1 24.837209, 24.847313, 24.856628, 24.865246, 24.873240, 24.880678,
 2 24.887616, 24.894103, 24.888887, 24.792328, 24.881439, 24.929529,
 3 24.972501, 25.010030, 25.042877, 25.071836, 25.099140, 25.118591,
 4 25.134759, 25.152602, 25.169194, 25.186408, 25.201293, 25.214621,
 5 25.226637, 25.237513, 25.247411, 25.256459, 25.264762, 25.272409,
 6 25.279475, 25.286025, 25.292113, 25.297786, 25.303086, 25.308049,
 7 25.158447, 25.297273, 25.364861, 25.408134, 25.444063, 25.474929,
 8 25.501639, 25.524976, 25.545588, 25.564967, 25.577907, 25.590116,
 9 25.602902, 25.615984, 25.627576, 25.637990, 25.647399, 25.655942/

COMMON/EST/ED 6(54)

DATA ED 6/

1 25.663733, 25.670869, 25.677428, 25.683479, 25.689077, 25.694273,
 2 25.699107, 25.703617, 25.707835, 25.711787, 25.648832, 25.752813,
 3 25.811072, 25.853796, 25.881452, 25.908688, 25.931982, 25.952139,
 4 25.969786, 25.985411, 25.999835, 26.013637, 26.019131, 26.029629,
 5 26.039156, 26.047669, 26.055373, 26.067331, 26.073318, 26.078819,
 6 26.083893, 26.088589, 26.092947, 26.097002, 26.100785, 26.104324,
 7 26.107641, 26.110756, 26.084372, 26.177506, 26.229551, 26.268829,
 8 26.297102, 26.322567, 26.344110, 26.362578, 26.378605, 26.392677,
 9 26.405167, 26.416370, 26.427257, 26.436012, 26.443708, 26.450658/

COMMON/EST/ED 7(54)

DATA ED 7/

1 26.456966, 26.462720, 26.467988, 26.472829, 26.477295, 26.481427,
 2 26.485260, 26.488836, 26.492177, 26.495296, 26.498221, 26.500964,
 3 26.499791, 26.581421, 26.630316, 26.670218, 26.701148, 26.722969,
 4 26.743887, 26.761664, 26.776970, 26.790305, 26.802049, 26.812495,
 5 26.821876, 26.829655, 26.836631, 26.842920, 26.848619, 26.853810,
 6 26.858557, 26.862916, 26.866932, 26.870645, 26.874088, 26.877290,
 7 26.880275, 26.883066, 26.885679, 26.888131, 26.896804, 26.964134,
 8 27.015860, 27.056895, 27.088007, 27.114718, 27.131180, 27.152348,
 9 27.167362, 27.180217, 27.191270, 27.200766, 27.208852, 27.217130/

COMMON/EST/ED 8(54)

DATA ED 8/

1 27.221081, 27.227399, 27.233585, 27.239345, 27.245074, 27.249217,
 2 27.250654, 27.257123, 27.258527, 27.266057, 27.262168, 27.271967,
 3 27.269062, 27.270645, 27.280025, 27.341232, 27.390496, 27.432570,
 4 27.088259, 27.113649, 27.134874, 27.152497, 27.167626, 27.180668,
 5 27.192015, 27.201970, 27.210761, 27.218021, 27.224368, 27.230152,
 6 27.235440, 27.240288, 27.244709, 27.248713, 27.252468, 27.255777,
 7 27.259157, 27.261668, 27.264726, 27.266873, 27.269832, 27.272096,
 8 27.283713, 27.341292, 27.391940, 27.432570, 27.432570, 27.432570,
 9 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570/

COMMON/EST/ED 9(54)

DATA ED 9/

1 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 2 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 3 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 4 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 5 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 6 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 7 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 8 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 9 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570/

COMMON/EST/ED10(46)

DATA ED10/

1 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
 2 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,


```

3 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
4 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
5 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
6 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
7 27.432570, 27.432570, 27.432570, 27.432570, 27.432570, 27.432570,
8 27.432570, 27.432570, 27.432570, 27.432570/
  MNZB = NZB1+NZB2
  IF (NZB.EQ.1.OR.MNZB.EQ.2) GO TO 5
  S1 = 10.005
  RETURN
5 IF (NNB.NE.1) NBAR=1.0
  IF (NNB.NE.1) NBMAX=1.
  TAU1=TAU
  K=NBAR
  E0=E
  ZBAR1=ZPART(K,1)
  ZBAR2=ZPART(K,2)
  IF (E.GT.0.) GO TO 30
  IF (GG) 20,10,10
10 ZBAR=0.
  ZBAR1=0.
  ZBAR2=0.
  ZPART(K,1)=ZBAR1
  ZPART(K,2)=ZBAR2
  IF (GG.EQ.1.) RETURN
20 THA=1.E-3
  NBAR=NBMAX
  GO TO 400
30 CONTINUE
  IF (GG) 120,40,40
40 ALGT=ALOG10(TAU)
  ALGE=ALOG10(E)
  DLGT=ALGT-TAULZ
  DLGE=ALGE-ELZ
  AN=DLGT*S+1.
  AM=DLGE*T+1.
  IF (DLGT.LT.0.) AN=0.
  IF (DLGE.LT.0.) AM=0.
  N=IFIX(AN)
  M=IFIX(AM)
  IN=0
  E0=E
  IF (N.LE.0) GO TO 180
  IF (N.GE.NN) GO TO 190
  IF (M.LE.0) GO TO 370
  IF (M.GE.MM) GO TO 280
50 CONTINUE
  DNLT=AN-AINT(AN)
  DMLE=AM-AINT(AM)
  K=(M-1)*NN+N
  KN=K+1
  KM=M*NN+N
  KNM=KM+1
  IF (NNB.EQ.0) GO TO 60
  NBAR=NB(K)+(NB(KN)-NB(K))*DNLT+(NB(KM)-NB(K))*DMLE+(NB(KNM)-NB(K))-
1NB(KN)-NB(KM))*DMLE*DNLT
  LBX 200
  LBX 210
  LBX 220
  LBX 230
  LBX 240
  LBX 250
  LBX 260
  LBX 270
  LBX 280
  LBX 290
  LBX 300
  LBX 310
  LBX 320
  LBX 330
  LBX 340
  LBX 350
  LBX 360
  LBX 370
  LBX 380
  LBX 390
  LBX 400
  LBX 410
  LBX 420
  LBX 430
  LBX 440
  LBX 450
  LBX 460
  LBX 470
  LBX 480
  LBX 490
  LBX 500
  LBX 510
  LBX 520
  LBX 530
  LBX 540
  LBX 550
  LBX 560
  LBX 570
  LBX 580
  LBX 590
  LBX 600
  LBX 610
  LBX 620
  LBX 630
  LBX 640
  LBX 650
  LBX 660
60 IF (NED.EQ.0) GO TO 70

```

```

      EDIS=EDLN(K)+(EDLN(KN)-EDLN(K))*DNLT+(EDLN(KM)-EDLN(K))*DMLE+(EDLN(LBX
      1(KNM)+EDLN(K)-EDLN(KN)-EDLN(KM))*DMLE*DNLT                      LBX 680
70  IF (IS.EQ.2) GO TO 90                      LBX 690
      EPR=E-EXP(EDIS)                      LBX 700
      ALGEPR=ALOG10(EPR)                      LBX 710
      DLGEPR=ALGEPR-EPRLZ                      LBX 720
      AL=DLGEPR*R+1                      LBX 730
      IF (DLGEPR.LT.0.) AL=0.                      LBX 740
      L=IFIX(AL)                      LBX 750
      IN=0                      LBX 760
      EPR0=EPR                      LBX 770
      IF (N.LE.0) GO TO 200                      LBX 780
      IF (N.GE.NN) GO TO 210                      LBX 790
      IF (L.LT.0) GO TO 410                      LBX 800
      IF (L.GE.LL) GO TO 280                      LBX 810
80  CONTINUE                      LBX 820
      DLLEPR=AL-AINT(AL)                      LBX 830
      K=(L-1)*NN+N                      LBX 840
      KN=K+1                      LBX 850
      KM=L*NN+N                      LBX 860
      KNM=KM+1                      LBX 870
      DMLE=DLLEPR                      LBX 880
90  IF (NZB.EQ.0) GO TO 110
      ZBAR=ZB(K)+(ZB(KN)-ZB(K))*DNLT+(ZB(KM)-ZB(K))*DMLE+(ZB(KNM)+ZB(K)-LBX
      1ZB(KN)-ZB(KM))*DNLT*DMLE                      LBX 910
110 IF (NZB1.EQ.0) GO TO 140                      LBX 950
      ZBAR1=ZB1(K)+(ZB1(KN)-ZB1(K))*DNLT+(ZB1(KM)-ZB1(K))*DMLE+(ZB1(KNM)LBX
      1+ZB1(K)-ZB1(KN)-ZB1(KM))*DNLT*DMLE                      LBX 970
      IF (NZB2.EQ.1) GO TO 140
      ZBAR2 = (ZBAR-WT1*ZBAR1)/WT2
      ZPART(K,1)=ZBAR1
      ZPART(K,2)=ZBAR2
      IF (GG.EQ.1) RETURN
140 IF (NZB2.EQ.0) GO TO 145
      ZBAR2=ZB2(K)+(ZB2(KN)-ZB2(K))*DNLT+(ZB2(KM)-ZB2(K))*DMLE+(ZB2(KNM)LBX 1100
      1+ZB2(K)-ZB2(KN)-ZB2(KM))*DNLT*DMLE                      LBX 1110
      IF (NZB1.EQ.1) GO TO 141
      ZBAR1 = (ZBAR-WT2*ZBAR2)/WT1
      GO TO 142
141 ZBAR = WT1*ZBAR1+WT2*ZBAR2
142 ZPART(K,1)=ZBAR1
      ZPART(K,2)=ZBAR2
      IF (GG.EQ.1) RETURN
145 IF (NEI.EQ.0) GO TO 146
      ALIN=EILN(K)+(EILN(KN)-EILN(K))*DNLT+(EILN(KM)-EILN(K))*DMLE+(EILN(LBX 930
      1(KNM)+EILN(K)-EILN(KN)-EILN(KM))*DNLT*DMLE                      LBX 940
      GO TO 150
146 ALIN1 = EIONIZ(PAN1,0.0,ZBAR1)
      ALIN2 = EIONIZ(PAN2,0.0,ZBAR2)
      ALIN = WT1*ALIN1+WT2*ALIN2
      ALIN = ALOG(ALIN)
150 IF (IS.EQ.2) GO TO 160                      LBX 1120
      THA=(EO-PHI*EXP(ALIN))/(1.5*PHI*(1./NBAR+ZBAR))                      LBX 1130
      GO TO 148
160 THA=(EO-PHI*EXP(ALIN)-EXP(EDIS))/(1.5*PHI*(1./NBAR+ZBAR))                      LBX 1150
148 IF (THA) 147,147,170
147 THA = 1.E-3

```

170 IF (IN.NE.0) GO TO (230,250,270,290,310,330,360,380), IN	LBX 1160
GO TO 400	LBX 1170
180 IF (M.LE.0) GO TO 220	LBX 1180
IF (M.GE.MM) GO TO 260	LBX 1190
GO TO 240	LBX 1200
190 IF (M.LE.0) GO TO 340	LBX 1210
IF (M.GE.MM) GO TO 300	LBX 1220
GO TO 320	LBX 1230
200 IF (L.LE.0) GO TO 220	LBX 1240
IF (L.GE.LL) GO TO 260	LBX 1250
GO TO 240	LBX 1260
210 IF (L.LE.0) GO TO 350	LBX 1270
IF (L.GE.LL) GO TO 300	LBX 1280
220 CONTINUE	LBX 1290
IF (I1.EQ.1) GO TO 420	LBX 1300
ZBAR=0.	LBX 1310
NBAR=NBMAX	LBX 1320
THA=1.E-3	LBX 1330
GO TO 400	LBX 1340
230 CONTINUE	LBX 1350
RETURN	LBX 1360
240 CONTINUE	LBX 1370
IF (I2.EQ.1) GO TO 430	LBX 1380
250 CONTINUE	LBX 1390
RETURN	LBX 1400
260 CONTINUE	LBX 1410
IF (I3.EQ.1) GO TO 440	LBX 1420
270 CONTINUE	LBX 1430
RETURN	LBX 1440
280 CONTINUE	LBX 1450
IF (I4.EQ.1) GO TO 450	LBX 1460
290 CONTINUE	LBX 1470
RETURN	LBX 1480
300 CONTINUE	LBX 1490
IF (I5.EQ.1) GO TO 460	LBX 1500
310 CONTINUE	LBX 1510
RETURN	LBX 1520
320 TAU=.999*TAUM	LBX 1530
GO TO 30	LBX 1540
330 CONTINUE	LBX 1550
RETURN	LBX 1560
340 CONTINUE	LBX 1570
IF (I7.EQ.1) GO TO 470	LBX 1580
IN=7	LBX 1590
M=1	LBX 1600
N=NN	LBX 1610
EO=EZ	LBX 1620
GO TO 50	LBX 1630
350 IF (I7.EQ.1) GO TO 470	LBX 1640
IN=7	LBX 1650
L=1	LBX 1660
N=NN	LBX 1670
EPR0=EPRZ	LBX 1680
GO TO 80	LBX 1690
360 THAP=E*THA/EZ	LBX 1700
ZBAR=ZBAR*(THAP/THA)**.75*SQRT(TAUM/TAU)*EXP(V1*(THAP-THA)/(THA*THL	LBX 1710
1AP*2.))	LBX 1720

AIN=V1*ZBAR	LBX 1730
GO TO 390	LBX 1740
370 CONTINUE	LBX 1750
IF (I8.EQ.1) GO TO 480	LBX 1760
IN=8	LBX 1770
M=1	LBX 1780
E0=EZ	LBX 1790
GO TO 50	LBX 1800
380 THAP=E*THA/EZ	LBX 1810
ZBAR=ZBAR*(THAP/THA)**.75*EXP(V1*(THAP-THA)/(THA*THAP*2.))	LBX 1820
AIN=V1*ZBAR	LBX 1830
390 CONTINUE	LBX 1840
THA=(E/PHI-AIN)/(1.5*(1./NBAR+ZBAR))	LBX 1850
400 P=PHI*(1./NBAR+ZBAR)*THA/TAU1	LBX 1860
C SEDEI = SUM OF IONIZATION ENERGY AND DISSOCIATION ENERGY	LBX 1870
SEDEI=EXP(EDIS)+PHI*EXP(ALIN)	LBX 1880
RETURN	LBX 1890
410 CONTINUE	LBX 1900
IF (I8.EQ.1) GO TO 480	LBX 1910
IN=8	LBX 1920
L=1	LBX 1930
EPR0=EPRZ	LBX 1940
GO TO 80	LBX 1950
420 S1=16.0100	LBX 1960
GO TO 490	LBX 1970
430 S1=16.0200	LBX 1980
GO TO 490	LBX 1990
440 S1=16.0300	LBX 2000
GO TO 490	LBX 2010
450 S1=16.0400	LBX 2020
GO TO 490	LBX 2030
460 S1=16.0500	LBX 2040
GO TO 490	LBX 2050
S1=16.0600	LBX 2060
GO TO 490	LBX 2070
470 S1=16.0700	LBX 2080
GO TO 490	LBX 2090
480 S1=16.0800	LBX 2100
490 RETURN	LBX 2110
END	LBX 2120

```

C   THIS VERSION OF LIBEX ADAPTED FOR USE WITH AN MTRAN TYPE
C   EQUIVALENCES WERE SET UP SPECIFICALLY FOR HECTIC
SUBROUTINE LIBEX(TAU, E, THA, P, ZBAR, GG, NBAR, SEDEI)
EQUIVALENCE (Z(131),S1)
EQUIVALENCE (Z(5001),IS),(Z(5002),NED),(Z(5003),NEI),(Z(5004),NNB)
1, (Z(5005),NZB),(Z(5006),NZB1),(Z(5007),NZB2),(Z(5008),TAUM),(Z(5009),EM),
29, (Z(5010),EPRM),(Z(5011),TAUZ),(Z(5012),EZ),(Z(5013),EPRZ),
3, (Z(5014),TAULZ),(Z(5015),ELZ),(Z(5016),EPRLZ),(Z(5017),R),(Z(5018),LBX
4, S),(Z(5019),T),(Z(5020),Y1),(Z(5021),VZ),(Z(5022),PHI),(Z(5023),NLBX
58MAX),(Z(5024),NN),(Z(5025),MM),(Z(5026),LL),(Z(5027),I1),(Z(5028),LBX
6, I2),(Z(5029),I3),(Z(5030),I4),(Z(5031),I5),(Z(5032),I6),(Z(5033),LBX
7, I7),(Z(5034),I8),(Z(5035),WT1),(Z(5036),WT2),(Z(5037),PAN1),
8 Z(5038),PAN2)
EQUIVALENCE (Z(5039),ZB),(Z(6633),EILN),(Z(8227),NB),(Z(9221),EDLN)
1, (Z(11415),ZB1),(Z(13008),ZB2)
REAL NB
REAL NBMAX
REAL NBAR
COMMON Z(10000)
COMMON/BOB/ZPART(1200,3)
DIMENSION ZB1D(1594),EILN1D(1594),NB1D(1594),EDLN1D(1594),ZB11D(1594)
193,ZB21D(1593)
MNZB = NZB1+NZB2
IF (NZB.EQ.1.OR.MNZB.EQ.2) GO TO 5
S1 = 10.005
RETURN
5 IF (NNB.NE.1) NBAR=1.0
IF (NNB.NE.1) NBMAX=1.
TAU1=TAU
K=NBAR
EO=E
ZBAR1=ZPART(K,1)
ZBAR2=ZPART(K,2)
IF (E.GT.0.) GO TO 30
IF (GG) 20,10,10
10 ZBAR=0.
ZBAR1=0.
ZBAR2=0.
ZPART(K,1)=ZBAR1
ZPART(K,2)=ZBAR2
IF (GG.EQ.1.) RETURN
20 THA=1.E-3
NBAR=NBMAX
GO TO 400
30 CONTINUE
IF (GG) 120,40,40
40 ALGT=ALOG10(TAU)
ALGE=ALOG10(E)
DLGT=ALGT-TAULZ
DLGE=ALGE-ELZ
AN=DLGT*S+1.
AM=DLGE*T+1.
IF (DLGT.LT.0.) AN=0.
IF (DLGE.LT.0.) AM=0.
N=IFIX(AN)
M=IFIX(AM)
IN=0
EO=E

```

```

LIBE 10
LBX 20
LBX 30
LBX 40
LBX 50
LBX 60
LBX 70
LBX 80
LBX 90
LBX 110
LBX 120
LBX 130
LBX 140
LBX 150
LBX 160
LBX 170
LBX 90
LBX 200
LBX 210
LBX 220
LBX 230
LBX 240
LBX 250
LBX 260
LBX 270
LBX 280
LBX 290
LBX 300
LBX 310
LBX 320
LBX 330
LBX 340
LBX 350
LBX 360
LBX 370
LBX 380
LBX 390
LBX 400
LBX 410
LBX 420
LBX 430
LBX 440
LBX 450
LBX 460
LBX 470
LBX 480
LBX 490
LBX 500
LBX 510

```

IF (N.LE.0) GO TO 180	LBX 520
IF (N.GE.NN) GO TO 190	LBX 530
IF (M.LE.0) GO TO 370	LBX 540
IF (M.GE.MM) GO TO 280	LBX 550
50 CONTINUE	LBX 560
DNLT=AN-AINT(AN)	LBX 570
DMLE=AM-AINT(AM)	LBX 580
K=(M-1)*NN+N	LBX 590
KN=K+1	LBX 600
KM=M*NN+N	LBX 610
KNM=KM+1	LBX 620
IF (NNB.EQ.0) GO TO 60	LBX 630
NBAR=NB(K)+(NB(KN)-NB(K))*DNLT+(NB(KM)-NB(K))*DMLE+(NB(KNM)+NB(K)-	LBX 640
1NB(KN)-NB(KM))*DMLE*DNLT	LBX 650
60 IF (NED.EQ.0) GO TO 70	LBX 660
EDIS=EDLN(K)+(EDLN(KN)-EDLN(K))*DNLT+(EDLN(KM)-EDLN(K))*DMLE+(EDLN	LBX 670
1(KNM)+EDLN(K)-EDLN(KN)-EDLN(KM))*DMLE*DNLT	LBX 680
70 IF (IS.NE.2) GO TO 90	LBX 690
EPR=E-EXP(EDIS)	LBX 700
ALGEPR=ALOG10(EPR)	LBX 710
DLGEPR=ALGEPR-EPRLZ	LBX 720
AL=DLGEPR*R+1	LBX 730
IF (DLGEPR.LT.0.) AL=0.	LBX 740
L=IFIX(AL)	LBX 750
IN=0	LBX 760
EPRO=EPR	LBX 770
IF (N.LE.0) GO TO 200	LBX 780
IF (N.GE.NN) GO TO 210	LBX 790
IF (L.LT.0) GO TO 410	LBX 800
IF (L.GE.LL) GO TO 280	LBX 810
80 CONTINUE	LBX 820
DLLEPR=AL-AINT(AL)	LBX 830
K=(L-1)*NN+N	LBX 840
KN=K+1	LBX 850
KM=L*NN+N	LBX 860
KNM=KM+1	LBX 870
DMLE=DLLEPR	LBX 880
90 IF (NZB.EQ.0) GO TO 110	LBX 890
ZBAR=ZB(K)+(ZB(KN)-ZB(K))*DNLT+(ZB(KM)-ZB(K))*DMLE+(ZB(KNM)+ZB(K)-	LBX 900
1ZB(KN)-ZB(KM))*DMLE*DNLT	LBX 910
110 IF (NZB1.EQ.0) GO TO 140	LBX 950
ZBAR1=ZB1(K)+(ZB1(KN)-ZB1(K))*DNLT+(ZB1(KM)-ZB1(K))*DMLE+(ZB1(KNM)	LBX 960
1+ZB1(K)-ZB1(KN)-ZB1(KM))*DMLE*DNLT	LBX 970
IF (NZB2.EQ.1) GO TO 140	
ZBAR2 = (ZBAR-WT1*ZBAR1)/WT2	
ZPART(K,1)=ZBAR1	
ZPART(K,2)=ZBAR2	
IF (GG.EQ.1) RETURN	LBX 1010
140 IF (NZB2.EQ.0) GO TO 145	LBX 1090
ZBAR2=ZB2(K)+(ZB2(KN)-ZB2(K))*DNLT+(ZB2(KM)-ZB2(K))*DMLE+(ZB2(KNM)	LBX 1100
1+ZB2(K)-ZB2(KN)-ZB2(KM))*DMLE*DNLT	LBX 1110
IF (NZB1.EQ.1) GO TO 141	
ZBAR1 = (ZBAR-WT2*ZBAR2)/WT1	
GO TO 142	
141 ZBAR = WT1*ZBAR1+WT2*ZBAR2	
142 ZPART(K,1)=ZBAR1	
ZPART(K,2)=ZBAR2	

```

      IF (GG.EQ.1) RETURN
145 IF (NE1.EQ.0) GO TO 146
      ALIN=EILN(K)+(EILN(KN)-EILN(K))*DNLT+(EILN(KM)-EILN(K))*DMLE+(EILN(LB
      1(KNM)+EILN(K)-EILN(KN)-EILN(KM))*DNLT*DMLE
                                                    LBX 930
                                                    LBX 940
      GO TO 150
146 ALIN1 = EIONIZ(PAN1,0.0,ZBAR1)
      ALIN2 = EIONIZ(PAN2,0.0,ZBAR2)
      ALIN = WT1*ALIN1+WT2*ALIN2
      ALIN = ALOG(ALIN)
150 IF (IS.EQ.2) GO TO 160
      THA=(EO-PHI*EXP(ALIN))/(1.5*PHI*(1./NBAR+ZBAR))
                                                    LBX 1120
                                                    LBX 1130
      GO TO 148
160 THA=(EO-PHI*EXP(ALIN)-EXP(EDIS))/(1.5*PHI*(1./NBAR+ZBAR))
                                                    LBX 1150
148 IF (THA) 147,147,170
147 THA = 1.E-3
170 IF (IN.NE.0) GO TO (230,250,270,290,310,330,360,380), IN
                                                    LBX 1160
      GO TO 400
                                                    LBX 1170
180 IF (M.LE.0) GO TO 220
      IF (M.GE.MM) GO TO 260
                                                    LBX 1180
      GO TO 240
                                                    LBX 1190
190 IF (M.LE.0) GO TO 340
      IF (M.GE.MM) GO TO 300
                                                    LBX 1200
      GO TO 320
                                                    LBX 1210
200 IF (L.LE.0) GO TO 220
      IF (L.GE.LL) GO TO 260
                                                    LBX 1220
      GO TO 240
                                                    LBX 1230
210 IF (L.LE.0) GO TO 350
      IF (L.GE.LL) GO TO 300
                                                    LBX 1240
                                                    LBX 1250
220 CONTINUE
                                                    LBX 1260
      IF (I1.EQ.1) GO TO 420
                                                    LBX 1270
      ZBAR=0.
                                                    LBX 1280
      NBAR=NBMAX
                                                    LBX 1290
      THA=1.E-3
                                                    LBX 1300
      GO TO 400
                                                    LBX 1310
230 CONTINUE
                                                    LBX 1320
      RETURN
                                                    LBX 1330
240 CONTINUE
                                                    LBX 1340
      IF (I2.EQ.1) GO TO 430
                                                    LBX 1350
250 CONTINUE
                                                    LBX 1360
      RETURN
                                                    LBX 1370
260 CONTINUE
                                                    LBX 1380
      IF (I3.EQ.1) GO TO 440
                                                    LBX 1390
270 CONTINUE
                                                    LBX 1400
      RETURN
                                                    LBX 1410
280 CONTINUE
                                                    LBX 1420
      IF (I4.EQ.1) GO TO 450
                                                    LBX 1430
290 CONTINUE
                                                    LBX 1440
      RETURN
                                                    LBX 1450
300 CONTINUE
                                                    LBX 1460
      IF (I5.EQ.1) GO TO 460
                                                    LBX 1470
310 CONTINUE
                                                    LBX 1480
      RETURN
                                                    LBX 1490
320 TAU=.999*TAUM
                                                    LBX 1500
      GO TO 30
                                                    LBX 1510
330 CONTINUE
                                                    LBX 1520
      RETURN
                                                    LBX 1530
340 CONTINUE
                                                    LBX 1540
                                                    LBX 1550
                                                    LBX 1560
                                                    LBX 1570

```


IF (I7.EQ.1) GO TO 470	LBX 1580
IN=7	LBX 1590
M=1	LBX 1600
N=NN	LBX 1610
E0=EZ	LBX 1620
GO TO 50	LBX 1630
350 IF (I7.EQ.1) GO TO 470	LBX 1640
IN=7	LBX 1650
L=1	LBX 1660
N=NN	LBX 1670
EPR0=EPRZ	LBX 1680
GO TO 80	LBX 1690
360 THAP=E*THA/EZ	LBX 1700
ZBAR=ZBAR*(THAP/THA)**.75*SQRT(TAUM/TAU)*EXP(V1*(THAP-THA)/(THA*THAP*2.))	LBX 1710
1AP*2.))	LBX 1720
AIN=V1*ZBAR	LBX 1730
GO TO 390	LBX 1740
370 CONTINUE	LBX 1750
IF (I8.EQ.1) GO TO 480	LBX 1760
IN=8	LBX 1770
M=1	LBX 1780
E0=EZ	LBX 1790
GO TO 50	LBX 1800
380 THAP=E*THA/EZ	LBX 1810
ZBAR=ZBAR*(THAP/THA)**.75*EXP(V1*(THAP-THA)/(THA*THAP*2.))	LBX 1820
AIN=V1*ZBAR	LBX 1830
390 CONTINUE	LBX 1840
THA=(E/PHI-AIN)/(1.5*(1./NBAR+ZBAR))	LBX 1850
400 P=PHI*(1./NBAR+ZBAR)*THA/TAU	LBX 1860
C SEDEI = SUM OF IONIZATION ENERGY AND DISSOCIATION ENERGY	LBX 1870
SEDEI=EXP(EDIS)+PHI*EXP(ALIN)	LBX 1880
RETURN	LBX 1890
410 CONTINUE	LBX 1900
IF (I8.EQ.1) GO TO 480	LBX 1910
IN=8	LBX 1920
L=1	LBX 1930
EPR0=EPRZ	LBX 1940
GO TO 80	LBX 1950
420 S1=16.0100	LBX 1960
GO TO 490	LBX 1970
430 S1=16.0200	LBX 1980
GO TO 490	LBX 1990
440 S1=16.0300	LBX 2000
GO TO 490	LBX 2010
450 S1=16.0400	LBX 2020
GO TO 490	LBX 2030
460 S1=16.0500	LBX 2040
GO TO 490	LBX 2050
S1=16.0600	LBX 2060
GO TO 490	LBX 2070
470 S1=16.0700	LBX 2080
GO TO 490	LBX 2090
480 S1=16.0800	LBX 2100
490 RETURN	LBX 2110
END	LBX 2120

C	REAL FUNCTION EIONIZ(A, B, C)	EION 10
C	FUNCTION TO COMPUTE IONIZATION ENERGY	EION 20
C	COMPILED MARCH 9, 1967, BY CHRIS IMES	EION 30
C	MODIFICATION OF CODING DONE BY GARY LANE ON MAY 6, 1966, FOR EIONM5EION	EION 40
C	AND EIONF3	EION 50
C		EION 60
C	Z = A	EION 70
C	PHI = B	EION 80
C	ZBAR = C	EION 90
C		EION 100
C	OPTION TO INCLUDE PHI IN CALCULATIONS	EION 110
C	IF (PHI .EQ. 0.) PHI IS SET TO 1.	EION 120
C	IF (PHI .NE. 0.) PHI IS USED IN CALCULATIONS	EION 130
C		EION 140
C	IF (PHI .EQ. 0.)	EION 150
C	PHI = 1.	EION 160
C		EION 170
C	COMMON /LMSB/U(1)	EION 180
C	DATA MARIMX/11/	EION 190
C	DATA ERROR/0./	EION 200
C		EION 210
C	J1 = 1	EION 220
C	IZK = IFIX(Z + .5)	EION 230
C		EION 240
C	400 CONTINUE	EION 250
C	START SEARCHING THE MARI DECK TO FIND THE DESIRED Z.	EION 260
C	IL = IFIX(U(J1) + .5)	EION 270
C	IF (IZK .EQ. IL)	EION 280
C	GO TO 401	EION 290
C	J1 = J1 + IL + 2	EION 300
C	IF (J1 .GT. MARIMX)	EION 310
C	GO TO 800	EION 320
C	GO TO 400	EION 330
C		EION 340
C	401 CONTINUE	EION 350
C	ATOMIC NUMBER OF DESIRED ELEMENT HAS BEEN LOCATED IN MARI	EION 360
C	IF (ZBAR .GT. (U(J1) - .5))	EION 370
C	GO TO 410	EION 380
C	GL = ZBAR	EION 390
C	LAG = GL	EION 400
C	GAL = GL - FLOAT(LAG)	EION 410
C		EION 420
C	J2 IS THE NUMBER OF IONIZATION POTENTIALS FOR THE ELEMENT	EION 430
C	IF (GAL .GT. .5)	EION 440
C	J2 = LAG + 2	EION 450
C	IF (GAL .LE. .5)	EION 460
C	J2 = LAG + 1	EION 470
C	GO TO 420	EION 480
C		EION 490
C	410 CONTINUE	EION 500
C	J2 = IZK	EION 510
C		EION 520
C	420 CONTINUE	EION 530
C	J3 DETERMINES THE LOCATION OF THE HIGHEST POTENTIAL FOR THE	EION 540
C	ELEMENT	EION 550
C	J3 = J1 + J2 + 1	EION 560
C	XI = PHI*(1. + ZBAR)	EION 570
		EION 580

IF (J2 .EQ. 1)	EION 590
GO TO 430	EION 600
IF (J2 .EQ. IZK)	EION 610
GO TO 440	EION 620
C	EION 630
J2.NE.1 .AND. J2.NE.2, MID-PATH	EION 640
TLMS4 = J2	EION 650
TLMS13 = U(J3) - U(J3 - 1)	EION 660
SIGMA = ((ZBAR - TLMS4 + 1.5)**2)*TLMS13/2.*PHI + U(J3 - 1)*(XI -	EION 670
TLMS4*PHI)	EION 680
GO TO 500	EION 690
C	EION 700
430 CONTINUE	EION 710
J2.EQ.1 LOW PATH	EION 720
XBAR = ZBAR	EION 730
GO TO 450	EION 740
C	EION 750
440 CONTINUE	EION 760
J2 .EQ. IZK, HIGH PATH	EION 770
XBAR = ZBAR - U(J1) + 1.	EION 780
C	EION 790
450 CONTINUE	EION 800
COMPUTE SIGMA FOR LOW PATH AND HIGH PATH	EION 810
SIGMA = XBAR*U(J3)*PHI	EION 820
C	EION 830
500 CONTINUE	EION 840
SUM ALL LOWER POTENTIALS	EION 850
TLMS14 = 0.	EION 860
IF (J2 .EQ. 1)	EION 870
GO TO 480	EION 880
J6 = J2 - 1	EION 890
DO 475 J4 = 1, J6	EION 900
J7 = J1 + J4 + 1	EION 910
TLMS14 = TLMS14 + U(J7)	EION 920
475 CONTINUE	EION 930
C	EION 940
480 CONTINUE	EION 950
DETERMINE TOTAL IONIZATION ENERGY	EION 960
ENERGY = TLMS14*PHI	EION 970
C	EION 980
EIONIZ = ENERGY + SIGMA	EION 990
RETURN	EION1000
C	EION1010
C	EION1020
800 CONTINUE	EION1030
ERROR IS SET IF A NEEDED ELEMENT HAS BEEN LEFT OUT OF THE	EION1040
MARI DECK	EION1050
ERROR = 18.0800	EION1060
CALL DUMP	EION1070
RETURN	EION1080
CALL MARI	EION1090
RETURN	EION1100
END	EION1110
SUBROUTINE ERR(S1)	
3 FORMAT (6H S1 = F10.4)	
WRITE(6,3) S1	
CALL EXIT	

This page intentionally left blank.

REFERENCES

1. Schalit, L. M., "Material Properties," Defense Atomic Support Agency Report GA-7760, v. IV, Gulf General Atomic Incorporated, to be published.
2. Stewart, J. C., and K. D. Pyatt, Jr., "A Theoretical Study of Optical Properties," Air Force Special Weapons Center Report AFSWC-TR-61-71, v. I. 1961.
3. Walsh, R. T., "DIAPHANOUS II," General Dynamics, General Atomic Division Informal Report GAMD-5549, 1964 (AD 453-351L).
4. Pyatt, K. D., "Nuclear Explosion Interaction Studies," v. II, "Methods of Analysis of Thermal Phenomena," Air Force Weapons Laboratory Report AFWL-TR-66-108, General Dynamics, General Atomic Division, 1967.
5. Allen, C. W., Astrophysical Quantities, (3rd ed), Athlone Press, University of London, 1955.
6. Garstang, R. H., "The Physical Constants Relating to Atomic Spectra," International Astronomical Union Symposium, No. 26, University of Colorado, Boulder, 1966, pp. 57-76.
7. Moore, C. E., Atomic Energy Levels as Derived from the Analysis of Optical Spectra, Circular of the National Bureau of Standards 467, v. I 1949, v. II 1952, v. III 1958.
8. Wagman, D. D., et al., "Selected Values of Chemical Thermodynamic Properties," National Bureau of Standards, Part I, NBS-TN-270-1, 1965; Part II, NBS-TN-270-2, 1966.
9. Stewart, J. C., and M. Rotenberg, "Wave Functions and Transition Probabilities in Scaled Thomas-Fermi Ion Potentials," Phys. Rev. 140 A1508, 1965.

AFWL-TR-67-131, Vol IV

10. Lotz, W., "Ionization Potentials of Atoms and Ions from H to N,"
Institut für Plasma Physik, Garching bei München, Germany, 1966.
11. Brenner, S., and G. E. Brown, "Calculations of K Absorption Edges
in Some Heavy Atoms," Proc. Roy. Soc. (London) Series A 218,
422 (1953).
12. Welch, J. E., "Visual Display Subroutines," General Dynamics,
General Atomic Division, GAMD-8051, 1967, unpublished data.

DOCUMENT CONTROL DATA - R & D

(Security classification of title, body of abstract and indexing annotation must be entered when the overall report is classified)

1. ORIGINATING ACTIVITY (Corporate author) Gulf General Atomic Incorporated San Diego, California 92112		2a. REPORT SECURITY CLASSIFICATION UNCLASSIFIED	
		2b. GROUP	
3. REPORT TITLE NUCLEAR EXPLOSION INTERACTION STUDIES, Vol IV, Material Property Codes			
4. DESCRIPTIVE NOTES (Type of report and inclusive dates) 29 September 1966-27 October 1967			
5. AUTHOR(S) (First name, middle initial, last name) J. R. Triplett et al.			
6. REPORT DATE April 1968		7a. TOTAL NO. OF PAGES 546	7b. NO. OF REFS 12
8a. CONTRACT OR GRANT NO. F29601-67-C-0014		9a. ORIGINATOR'S REPORT NUMBER(S) AFWL-TR-67-131, Vol IV	
b. PROJECT NO. 5710		9b. OTHER REPORT NO(S) (Any other numbers that may be assigned this report) Contractor's report No. GA-7764, Vol IV	
c. Subtask No. 07.017 ARPA Order No. 313			
10. DISTRIBUTION STATEMENT This document is subject to special export controls and each transmittal to foreign governments or foreign nationals may be made only with prior approval of AFWL (WLRT), Kirtland AFB, NM, 87117. Distribution is limited because of the technology discussed in the report.			
11. SUPPLEMENTARY NOTES		12. SPONSORING MILITARY ACTIVITY AFWL (WLRT) Kirtland AFB, NM 87117	
13. ABSTRACT (Distribution Limitation Statement No. 2) The work covered by this volume falls into three parts: (1) opacity data generated by the DIAPHANOUS code; (2) equation-of-state data generated by the SPUTTER/HECTIC subroutines AIRMOL and CMOL and the MARIER, HELAS, and HELIKE ionization potential routines; (2) descriptions of codes used to transfer data between LASL, AFWL, Gulf General Atomic, and the DASA Analysis and Information Center (DASIAC).			

UNCLASSIFIED

Security Classification

14 KEY WORDS	LINK A		LINK B		LINK C	
	ROLE	WT	ROLE	WT	ROLE	WT
Radiation absorption coefficients Opacity data Equation of state Material properties codes						